




**CR3034A**  
**Mockingbird Radio**  
**Instruction Manual**

---



Questions, problems, missing parts?  
Before returning to the store, call Customer Service  
8 a.m. – 6 p.m., EST, Monday – Friday  
1-888-CROSLEY  
[www.crosleyradio.com](http://www.crosleyradio.com)

## **Safety Instructions**

---

Read and understand this entire manual before using this product. Keep these instructions for future reference.

1. Do not use this product near water.
2. This product should be operated only by the type of power source indicated on the marking label or in this instruction manual.
3. Do not defeat the safety purpose of the polarized plug. A polarized plug has two blades with one blade wider than the other. This plug will fit into the power outlet only one way. If you are unable to insert the plug fully into the outlet try reversing the plug. If the plug should still fail to fit, contact your electrician.
4. Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the product.
5. Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
6. Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short-out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
7. Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
8. Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
9. Do not use attachments not recommended by the product manufacturer as they may cause hazards.
10. A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.
11. Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating. Do not block or cover these openings.
12. Unplug the product during lightning storm or when unused for long periods of time.

## Items in this package

---

Before throwing away any packaging materials, please check thoroughly and make sure you find the following items that come along with this package:

- Mockingbird radio
- 3.5mm aux in cable
- Power adaptor

Please contact Crosley customer service if there is any accessory missing from the package. **Retain the original packaging materials for exchange or return purposes.**

## Specifications


---

Power	AC power adaptor, DC output 5V 1.2A Lithium Battery (Model # 18650) (Not Included)
Power consumption	12W
Speaker	2.5", 4 $\Omega$ , 5 W x 1

*Note:*

- *Design and specifications are subject to change without notice.*
- **To help save power consumption, some models will comply with ERP energy saving standard. When there is no audio input for 20 minutes, their powers will automatically cut-off. To turn power back on and resume playing, you will need to turn off the power and turn it on again.**

## Product Description



- |                      |                              |
|----------------------|------------------------------|
| 1. Handle            | 7. Power/Bluetooth Indicator |
| 2. Dial Scale        | 8. Power Jack                |
| 3. Tuning Knob       | 9. Headphone Jack            |
| 4. Volume Knob       | 10. Aux In Jack              |
| 5. Battery Indicator | 11. Battery Compartment      |
| 6. Function Knob     |                              |

## Power Source/Battery Operation

1. This speaker could operate either with the power adapter or on a Lithium Battery (Model # 18650) (Not Included).
2. You can connect AC adaptor to the Power Jack of the back of the unit.
3. When a lithium battery is installed into the Battery Compartment and being operated by the power adapter, the lithium battery will charge. When the battery is being charged the Battery Indicator will light up RED, and once the battery is fully charged it will go off.
4. When the Lithium Battery is low and isn't connected to the AC adaptor it will beep as an indicator.

## Aux Input Connection

---

You can connect an audio device to this unit and play your music through its speakers. To do this, rotate the Function Knob to Aux mode, connect the 3.5mm auxiliary cable between your audio device, and the Aux In Jack of this unit and start playing.

## Radio Operation

---


1. Rotate the Function Knob to FM or AM position.
2. Rotate the Tuning Knob for desired radio station.

*Note:*

- *The unit is equipped with a FM wire antenna. To FM improve reception, move the wire around until the reception is clear without interferences. Do not connect the wire to any additional antenna.*
- *The AM antenna is built inside the unit. If AM reception is poor, try to rotate the unit for better reception.*

## Bluetooth Operation

---

1. Turn the Function Knob to Bluetooth mode , the Power/Bluetooth Indicator will start flashing blue quickly.
2. Turn on the Bluetooth feature of your audio device, search for "CROSLEY CR3034" and pair.
3. Once your device is successfully paired with the unit, you will hear a short confirmation sound from the unit.
4. Play and stream music from your device to the unit.
5. When the device is paused the Power/Bluetooth Indicator will start flashing blue once per second.

*Note: Bluetooth version - 4.2*

## FCC Statements

---

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.