

FT-112 Panel

Weighing Terminal

User Manual



Table of Contents

1	Safety Instructions.....	4
2	Introduction.....	5
2.1	Overview.....	5
2.2	Specifications.....	5
2.3	The Front View and Key Functions.....	10
2.3.1	Display.....	10
2.3.2	Key Pad.....	11
2.4	Passwords.....	13
2.4.1	Keylock.....	13
2.4.2	Passwords.....	13
3	Installation.....	14
3.1	Recommendations.....	14
3.1.1	Environment.....	14
3.1.2	Cabling.....	14
3.1.3	Electrical Connection.....	14
3.1.4	Location of the Peripheral Connections.....	15
3.2	Cleaning.....	15
3.3	Disposal.....	15
3.4	Housing.....	16
3.5	Mechanical Installation.....	16
3.6	Electrical Connections.....	17
3.6.1	Analogue Load Cell Connection (Only FT-112 Panel).....	17
3.6.2	Digital Load Cell Connection (Only FT-112D).....	18
3.6.3	RS232C Serial Port.....	20
3.6.4	RS485 Serial Port.....	21
3.6.5	RS422 Serial Port.....	22
3.6.6	Ethernet TCP/IP.....	23
3.6.7	Profibus PB.....	24
3.6.8	Profinet.....	24
3.6.9	CANopen.....	25
3.6.10	EtherNET/IP.....	26
3.6.11	EtherCAT.....	27
3.6.12	CC-Link.....	28
3.6.13	Powerlink.....	28
3.6.14	CC-Link IE.....	29
3.6.15	USB Port.....	29
3.6.16	Installation of Alibi SD card.....	30
3.6.17	Installation of SD Card.....	31
3.6.18	Digital Inputs.....	31
3.6.19	Digital Outputs.....	31
3.6.20	Analogue Output Connection.....	32
3.6.21	Power Source Connection and Grounding.....	32
4	FT-112 Functions.....	33
4.1	Basic Functions.....	33
4.2	Advanced Functions.....	35
4.3	Alibi Memory.....	38
5	Programming and Calibration.....	41
5.1	Entering to the Programming and Calibration.....	41

5.2	Quick Access to frequently Used Parameter Blocks	42
5.3	Exit from Programming.....	42
5.4	Programming and Parameters	43
	[1-- INTERFACE] Interface Block.....	44
	[2-- CONFIGURATIO] Configuration Block.....	54
	[3-- APPLICATION] Application Block.....	57
	[5-- SCALE] Scale Block.....	63
	[6-- CALB / ADJUST] Calibration and Adjustment Block.....	66
	[8-- METROLOGY] Metrology Block	67
	[9-- DIAGNOSTIC] Diagnostic Block.....	68
5.5	Calibration.....	70
5.5.1	Linearity Correction	70
5.5.2	Zero and Span Adjustments	71
5.5.3	eCal Electronic Calibration	72
5.5.4	Gravity adjustment	73
5.5.5	Calibration coefficients.....	73
6	Digital Load Cell (DLC).....	74
6.1	Addressing Digital Load cells	74
7	Identifications.....	77
8	SmartAPP	79
9	Standard Applications	80
9.1	Classifying	80
9.1.1	Product Limit values at Classifying	81
9.1.2	Start and Stop the Classifying	82
9.1.3	SmartAPP at Classifying	82
9.2	Checkweighing.....	84
9.2.1	Product Limit values at Checkweighing	85
9.2.2	Start and Stop the Checkweighing.....	86
9.2.3	SmartAPP at Checkweighing.....	86
9.3	Filling.....	87
9.3.1	Product Entries at Filling.....	88
9.3.2	Start and Stop the filling	89
9.3.3	SmartAPP at filling.....	89
9.4	Peak Hold.....	91
9.4.1	Product entries	91
9.4.2	Start and Stop the peak hold.....	93
9.4.3	SmartAPP at peak hold.....	93
9.4.4	Digital inputs and outputs.....	93
9.5	Totalization	94
10	Digital inputs and outputs.....	96
10.1	Basic Weighing.....	96
10.2	Application Weighing	97
10.3	Digital inputs.....	98
10.4	Digital outputs.....	99
11	Serial Data Outputs.....	109
11.1	Continuous Data Output	109
11.1.1	Continuous Data Formats.....	110
11.2	Fast Continuous Data Output	114
11.3	Print Mode.....	114
11.4	EPL Format.....	116

11.5	BSI Data Structure for Dialog with PC and PLC	117
11.5.1	BSI-Base Commands	120
12	Optional Communication	124
12.1	Analogue Output	124
12.2	Modbus RTU and TCP/IP	125
12.2.1	Modbus Data Structure	126
12.3	Ethernet TCP/IP	134
12.3.1	Ethernet Parameters	134
13.1	Profibus DP	135
13.1.1	Data Format	135
13.1.2	GSD Configuration	136
13.1.3	Profibus DP Data Structure	136
13.2	Profinet	137
13.2.1	Data Format	138
13.2.2	Profinet Parameters	138
13.2.3	GSDML Configuration	138
13.2.4	Profinet Data Structure	139
13.3	CANopen	140
13.3.1	Data Format	140
13.3.2	EDS Configuration	141
13.3.3	CANopen Data Structure	141
13.4	EtherNet/IP	142
13.4.1	Data Format	143
13.4.2	EtherNet/IP Parameters	143
13.4.3	EDS Configuration	143
13.4.4	EtherNet/IP Data Structure	144
13.5	EtherCAT	145
13.5.1	Data Format	146
13.5.2	ESI Configuration	146
13.5.3	EtherCAT Data Structure	146
13.6	CC-Link	147
13.6.1	Data Format	147
13.6.2	CC-Link Configuration	147
13.6.3	CC-Link Data Structure	148
13.7	Powerlink	149
13.7.1	Data Format	150
13.7.2	XDD Configuration	150
13.7.3	Powerlink Data Structure	150
13.8	CC-Link IE Field	151
13.8.1	Data Format	151
13.8.2	CC-Link IE Configuration	151
13.8.3	CC-Link IE Data Structure	152
14	Appendix 1: Data Structure Profibus, Profinet, EtherNET/IP, EtherCAT, CC-Link, Powerlink, CC-Link IE	153
15	Appendix 2: Data Structure - CANopen	164
16	Sealing of Approved Scale	174
17	Error Codes	175

Disclaimer

All rights reserved.

No part of this publication may be reproduced, stored in a retrieval system, or transmitted in any form or by any means, mechanical, photocopying, recording, or otherwise, without the prior written permission of Flintec.

No patent liability is assumed with respect to the use of the information contained herein. While every precaution has been taken in the preparation of this book, Flintec assumes no responsibility for errors or omissions. Neither is any liability assumed for damages resulting from the use of the information contained herein.

The information herein is believed to be both accurate and reliable. Flintec, however, would be obliged to be informed if any errors occur. Flintec cannot accept any liability for direct or indirect damages resulting from the use of this manual.

Flintec reserves the right to revise this manual and alter its content without notification at any time. Neither Flintec nor its affiliates shall be liable to the purchaser of this product or third parties for damages, losses, costs, or expenses incurred by purchaser or third parties because of: accident, misuse, or abuse of this product or unauthorized modifications, repairs, or alterations to this product, or failure to strictly comply with Flintec operating and maintenance instructions.

Flintec shall not be liable against any damages or problems arising from the use of any options or any consumable products other than those designated as Original Flintec Products.

NOTICE: The contents of this manual are subject to change without notice.

1 SAFETY INSTRUCTIONS



CAUTION: READ this manual BEFORE operating or servicing this equipment. FOLLOW these instructions carefully. SAVE this manual for future reference. DO NOT allow untrained personnel to operate, clean, inspect, maintain, service, or tamper with this equipment. ALWAYS DISCONNECT this equipment from the power source before cleaning or performing maintenance.

CALL Flintec for parts, information, and service.



WARNING: Only permit qualified personnel to service this equipment. Exercise care when making checks, tests and adjustments that must be made with power on. Failing to observe these precautions can result in bodily harm.



WARNING: For continued protection against shock hazard connect to properly grounded outlet only. Do not remove the ground prong.



WARNING: Disconnect all power to this unit before removing the fuse or servicing.



WARNING: Before connecting/disconnecting any internal electronic components or interconnecting wiring between electronic equipment always remove power and wait at least thirty (30) seconds before any connections or disconnections are made. Failure to observe these precautions could result in damage to or destruction of the equipment or bodily harm.



CAUTION: Observe precautions for handling electrostatic sensitive devices.

2 INTRODUCTION

2.1 Overview

FT-112 Panel weighing indicator is economic and powerful state-of-the-art indicator for industrial weighing applications like basic weighing, checkweighing, classifying, peak holding, labelling, filling and totalization etc. This compact instrument provides flexible solutions besides its high-speed weighing and interfacing features. The weighing indicator has two identification data memory each has 500 items record size, 500 items record size specific tare memory and 500 items set memory which has 6 set values for each item.

Digital inputs and outputs of the instrument can be programmed as a Remote IO on the fieldbus. This feature gives advantage to eliminate additional PLC in the cabinet for only having remote IO's.

The scales equipped with FT-112 Panel weighing indicator can be used in all kinds of industrial areas up harsh to wet and hygienic environments with its fast and efficient cleaning that was designed and built according to the international guidelines.

2.2 Specifications

Analogue Load cell (only FT-112)	
A/D converter type	24-bit Delta-Sigma ratio metric with integral analog and digital filters
Conversion rate	Up to 1600 measurement values per second
Input sensitivity	0.4 $\mu\text{V}/\text{e}$ approved; 0.05 $\mu\text{V}/\text{d}$ non approved.
Analog input range	-5 mV to +19 mV
Internal resolution	up to 16 000 000
Excitation	5 VDC max. 150 mA
Number of load cells	Up to 8 load cells 350 Ω or 25 load cells 1100 Ω .
Connection	4- or 6-wire technique. Cable length: maximum 1000 m/mm ² for 6-wire connection
Digital load cell (only FT-112D)	
Interface	RS 485
Interface baud rate	Up to 57600
Connection	4 wire. Up to 500 meters.
Number of load cell	Up to 24 digital load cells.
Internal resolution	200 000 counts
Excitation	12 VDC, max. 1.3 A
Scale	
Range	Single range, up to 3 x multi-intervals, up to 3 x multi-ranges.
Display resolution	FT-112 Panel Approval, up to 10 000 division at usage in trade, according to EN45501 and OIML R76. Up to 300 000 division at industrial usage. FT-112D Panel Maximum 20 000. Should be limited by 10% of the maximum count of the digital load cell for accurate measurement.
Calibration and Functions	
Calibration	Calibration with test weights, eCal electronic calibration without test weights, Temporary zero calibration, Zero adjustment, Gain adjustment, Coefficient entry.

Digital filter	5 steps programmable adaptive filter	
Dynamic filter	Programmable dynamic filter	
Weighing functions	Taring, zeroing, auto zero tracking, motion detection, auto zero at power up, tare status saves at power off, increased resolution, automatic tare and clear, temporary gross indication, unit change.	
Standard applications	Labelling with barcode, checkweighing, classifying, basic filling, peak holding, totalization, livestock weighing and free setpoints, functional outputs, Remote IO of PLC or HMI, fieldbus interface.	
Memory		
Application memories	ID1, ID2, Limit values for weighing of items / setpoint memory and preset tare memory. Each memory size is 500 item records.	
Alibi memory (optional)	99 999 records	
Communication		
Connectable with	PC, PLC, Printer, Remote display, EPL printer etc.	
RS 232	Isolation	Galvanically isolated.
	Baud rate	1200 to 57600 programmable
	Data	Length 7 or 8 bits; parity even, odd or none
RS 485	Isolation	Galvanically isolated.
	Baud rate	1200 to 57600 programmable
	Data	Length 7 or 8 bits; parity even, odd or none
	Stations	Up to 31 stations
RS 422	Baud rate	1200 to 57600 programmable
	Data	Length 7 or 8 bits; parity even, odd or none
	Stations	Up to 10 stations
Ethernet TCP/IP	Transmission rate	10 / 100 Mbit/s, Full duplex
	TCP/IP settings	Manual IP assign over Indface2x PC Software or by keys in programming mode.
	Connection method	Server or Client
	Installation	Switched Ethernet transmission with shielded twisted pair cables and RJ-45.
	Isolation	Galvanically isolated bus electronics
	Response speed	Up to 4 ms response delay after read/write commands
USB	Connection	Standard USB Micro-B cable
	Response speed	Min. 4 ms response delay after read/write commands
Digital Inputs and Outputs (optional)		
Digital Inputs	Optoisolated 4 digital input, 12 to 28 VDC, 10mA. Any input(s) can be used as a Remote input of your PLC over BSI or Modbus.	
Digital Outputs	5 free relay contact, 250 VAC or 30 VDC, 0.2A Any output(s) can be used as a Remote output of your PLC over BSI or Modbus.	
Analogue Output (optional)		
Voltage output	0-5 VDC, 0-10 VDC	

Current output	4-20mA, 0-20mA
Resolution	60 000 steps
Max. cable length	300 meters
Max. load resistance (current output)	500 Ω
Minimum load resistance (voltage output)	10 k Ω
Profibus DPV1 (optional)	
Data rate	Up to 12000 kbit/s with automatic baud rate detection
GSD file	Generic GSD-file provided
Topology	Depending on physical media RS-485: segmented line topology without stubs
Installations	Shielded twisted pair cable Line length depending on physical media and transmission speed
Max. Stations	up to 126 stations per network
Isolation	Galvanically isolated bus electronics
Response speed	Min. 4 ms response delay after read/write commands
Remote IO	Digital inputs and outputs of the instrument can be programmed independently as a Remote IO's of PLC to control them over fieldbus.
Profinet (optional)	
Data rate	100 Mbit/s, full duplex
GSDML file	Generic GSDML-file provided
TCP/IP settings	DHCP or manual IP are assigned over Indface2x PC Software or by keys in programming mode. Device identity customization
Topology	Line, Bus, Star or Tree topology depending on physical media
Installation	Switched Ethernet transmission with shielded twisted pair cables and RJ-45 connectors.
Web client	Available
Isolation	Galvanically isolated bus electronics
Response speed	Min. 4 ms response delay after read/write commands
Remote IO	Digital inputs and outputs of the instrument can be programmed independently as a Remote IO's of PLC to control them over fieldbus.
CANopen (optional)	
Data rate	10 kbit/s – 1 Mbit/s (selectable) kbit/s
EDS file	Generic EDS-file provided
Topology	Line with Trunkline, Dropline structure and Termination at both Ends Line length depending on baud rate 25 – 500 meters.
Installation	2 wire shielded twisted pair cable Alternatively, 4 wire with 24 Volt power over the bus
Max. Stations	Up to 127 stations per network
Isolation	Galvanically isolated bus electronics
Response speed	Min. 4 ms response delay after read/write commands

Remote IO	Digital inputs and outputs of the instrument can be programmed independently as a Remote IO's of PLC to control them over fieldbus.
EtherNet/IP (optional)	
Data rate	10 Mbit/s or 100 Mbit/s, full duplex
EDS file	Generic EDS-file provided
DLR (Device Level Ring)	Available
TCP/IP settings	DHCP or manual IP assign over Indface2x PC Software or by keys in programming mode. Device identity customization
Topology	Line, Bus, Star or Tree topology depending on physical media
Installation	Switched Ethernet transmission with shielded twisted pair cables and RJ-45 connectors.
Web client	Available
Isolation	Galvanically isolated bus electronics
Response speed	Up to 4 ms. response delay after read/write commands.
Remote IO	Digital inputs and outputs of the instrument can be programmed independently as a Remote IO's of PLC to control them over fieldbus.
EtherCAT (optional)	
Data rate	100 Mbit/s, full duplex
ESI file	Generic ESI-file provided
Topology	Line, Tree, Star or Daisy-chain topology depending on physical media
Installation	Switched Ethernet transmission with shielded twisted pair cables and RJ-45 connectors.
Isolation	Galvanically isolated bus electronics
Response speed	Up to 4 ms. response delay after read/write commands.
Remote IO	Digital inputs and outputs of the instrument can be programmed independently as a Remote IO's of PLC to control them over fieldbus.
CC-Link (optional)	
Data rate	156 kbit/s – 10 Mbit/s (selectable)
Topology	Line with Trunkline, Branch structure and Termination at both Ends.
Installation	3 wires shielded twisted pair cable.
Max. Stations	Up to 64 stations per network
Isolation	Galvanically isolated bus electronics
Response speed	Up to 4 ms. response delay after read/write commands
Remote IO	Digital inputs and outputs of the instrument can be programmed independently as a Remote IO's of PLC to control them over fieldbus.
Powerlink (optional)	
Compatibility	Supports Ethernet POWERLINK V2.0 Communication Profile Specification version 1.2.0
Data rate	100 Mbit/s, half duplex
XDD file	XDD-file provided

Ring redundancy	Available
Topology	100% free choice of star, tree, ring or daisy chain
Installation	Switched Ethernet transmission with shielded twisted pair cables and RJ-45 connectors.
Isolation	Galvanically isolated bus electronics
Response speed	Min. 4 ms response delay after read/write commands
Remote IO	Digital inputs and outputs of the instrument can be programmed independently as a Remote IO's of PLC to control them over fieldbus.
CC-Link IE Field (optional)	
Data rate	1 Gbit/s Baud Rate
CSP+ file	Generic CSP+ file provided
Topology	Line, Star, Line/Star mixture or Ring topology depending on physical media
Installation	IEEE802.3 1000Base-T cable, ANSI/TIA/EIA-568-B (Category 5e) compliant 4-pair, balanced-type shield cable, Double-shield type is recommended.
Max. number of networks	Up to 239
Number of connected nodes per network	Master station = 1, Slave station = 120
Isolation	Galvanically isolated bus electronics
Response speed	Up to 4 ms. response delay after read/write commands.
Remote IO	Digital inputs and outputs of the instrument can be programmed independently as a Remote IO's of PLC to control them over fieldbus.
Power Consumption	
	FT-112 Panel 12 – 28 VDC 250 mA + max. 500 mA for fieldbus interfacing FT-112 (D) Panel 12 – 28 VDC 150 mA + max. 500 mA for fieldbus interfacing + load cell currents.
Environment and Enclosure:	
Operation temp. range	Approved scales -10 °C to +40 °C Industrial usage -15 °C to +55 °C
Humidity	80% RH max, non-condensing
Enclosure	Stainless steel front panel and rear panel, aluminum body.
Protection	Front panel IP67
Panel cut size	186 x 92 mm (7.32 x 3.62")
Sizes (W x H x D)	205 x 108 x 112,5mm (8.07 x 4.25 x 4.43")
Weight	1,4 kg (3,07 lb)
Packing sizes (W x H x D)	273 x 190 x 153 mm (10,75 x 7,48 x 6,02")
Weight Packed	2,5 kg (5,51 lb)


2.3 The Front View and Key Functions



Figure 2.1 – Front view of FT-112 Panel





2.3.1 Display

The bright and wide-angle LCD display of the FT-112 Panel instruments is shown below.









The meanings of the announcement symbols on the display:

1		6-digit 22 mm height big weighing display with sign
2		16-digit 8 mm height alphanumeric information display
3		High resolution digit separator.
4	NET	Announces the indicated value is the net weight.
5	B/G	Announces the indicated value is the gross weight.
6		Bar graph

7		Indicates the range of the scale at multi range and multi interval operations.
8	kg	g, kg, t, lb, klb, N, kN units are located on the right of the display.
9	Inputs: Outputs:	Announces the activated inputs and outputs.
10		Announces the instrument is at repair status or call service.
11	>0<	Announces the weight value is in the center of zero range.
12		Announces the weighing is not stable. After stabilization of the weighing, this symbol disappears.
13	PT	Announces the scale is preset tared after entering the specified tare value.
14		Announces the keys are locked.
15	ms	Announces the time unit of the parameter value is millisecond or second.

2.3.2 Key Pad

The keys and the key functions of FT-112 Panel:

	Programmable Function key * This programmable key is set for your easy use in your application.	<i>Page 56, 35, 82, 86, 88, 93, 97,</i>
	Programmable Function key Δ This programmable key is set for your easy use at your application.	
	Identification data ID1 and ID2 keys are used to enter identification data. ID2 key can be programmed for another function, if ID2 is not required.	<i>Page 41, 56</i>
	Totalization. This key is used for totalization of sequential weighing.	<i>Page 94, 58,</i>
	Total This key is used to indicate the total value in totalization. Grand Total Press this key for more than 2 seconds to display Grand Total. Clear total Press this key to clear total or grand total which is displaying.	<i>Page 94, 94, 95, 95</i>
	Unit Change Change to the secondary unit.	<i>Page 35</i>

	<p>Temporary gross weight indication Press this key to read the gross weight temporary until pressing the key again. The display returns to the normal operation automatically after 10 seconds at approved scale.</p>	
	<p>High resolution Press the key to read the weight at high resolution. Press the key again to return to normal operation. The displaying of high-resolution weight ends automatically after 10 seconds at approved scale.</p>	Page 35, 63
	<p>Set point entries Press this key to enter set points or set values of SmartAPP application.</p>	Page 79, 81, 85, 88, 91, 108, 97
	<p>Memory This key is used to access the memory or to save the item data into the memory.</p>	Page 36, 77, 81, 82, 85, 85, 88, 89, 92, 92, 108
	<p>Navigation keys These keys are used to navigate in the memories, entries and programming. The meanings of the navigation keys are;</p> <ul style="list-style-type: none"> Previous parameter. Next digit or parameter. Increase or next block. Decrease or previous block. Enter the parameter to enter data. Save the data after entry. Go to the next parameter. 	Page 41
	<p>Print By pressing this key the weight data is transferred to a printer or to a PC.</p>	Page 41, 114
	<p>Escape Press this key to exit from any entry or from any block at programming.</p>	
	<p>Tare Press this key for taring the scale.</p>	Page 34, 34, 35, 55
	<p>PT The specific tare value can be entered numerically by pressing this key.</p>	Page 34, 35, 55
	<p>Zeroing If the unloaded scale doesn't show zero at gross operation, press this key to compensate zero drift.</p>	Page 33, 64
	<p>Clear Clears the tare and indication return to the gross value.</p>	Page 34, 98,
	<p>Alphanumeric keys Alphanumeric data entry.</p>	
	<p>Delete Deletes last entered digit. Press for more than 2 seconds to clear the data on the display at data entry.</p>	
	<p>Help Press the key consecutively to learn functions of programmable keys.</p>	




2.4 Passwords

RELATED PARAMETERS: Sub-block 26- .




2.4.1 Keylock

FT-112 Panel has the capability to lock the keys to avoid unauthorized interfere. The key(s) which would be locked are programmed in the setup at sub-block 34- . Key lock **password** default is **11**.

Lock the keys:

1. Press  key for more than 2 seconds. [LOCK PASSWORD:] prompt appears on the display.
2. Enter the key lock password. Refer to parameter 261.
3. Press  key.  symbol appears on the display.

Unlock the keys:

1. Press  key for more than 2 seconds. [LOCK PASSWORD:] prompt appears on the display.
2. Enter the key lock password.
3. Press  key.  symbol disappears on the display.

2.4.2 Passwords

RELATED PARAMETERS: Sub-block 26- .

Keylock password

This password can be used to lock the keys and to erase the grand total by authorized person. The default password is **11**. Refer to sub-block 34- and the parameter 325.

User password

This password is used to setup the interface, usage configuration and application related parameters for your application. The default password is **1111**.

Service password

This password is used by trained technical persons to access parameters of the instrument and calibration only. The default password is **1111**.

3 INSTALLATION

PRECAUTION: Read this section carefully before installation of the instrument. Applying the recommendations in this section will increase your system reliability and its long-term performance.

3.1 Recommendations

3.1.1 Environment

The weighing indicator should be placed in an area which is clean, not getting direct sun light if possible, having a temperature between -15 °C and +55 °C and humidity not exceeding 80% non-condensing. All external cables should be installed safely to avoid mechanical damages.

This instrument is very low-level signal measuring instrument. To avoid electrical noise, it should be separated from equipment that produce electrical noise. The instrument body must be connected to the good ground against the electromagnetic disturbances. Load cell cable must be separated from other cables especially from power cables if possible. If there are electrical noise-generating equipment such as heavy load switches, motor control equipment, inductive loads etc., please pay attention to the EMC interference and take all the prevention. Connect parallel reverse diodes to the DC inductive loads like relays, solenoids etc. to minimize voltage peaks on the DC power lines.

3.1.2 Cabling

- All cables coming to the instrument shall be high quality and shielded.
- Distance from load cell cables, interface cables and DC power supply cables to power line cables shall be minimum 30 cm. The separate cable tray usage for these low signal level cables is strongly recommended.
- Shields of all cables should be connected to the grounding screws under terminals as shown at the picture below.




Figure 3.1– The shield connection to the protective earth.

3.1.3 Electrical Connection

- Always remember that FT-112 Panel terminal is very low voltage measuring instrument used in the industrial environment. Your proper installation increases reliability and performance of the instrument.
- Only trained persons should interface the instrument against malfunction at installation.
- If the energy condition of your plant is not good enough, prepare a special power line for DC power supply in the cabinet.
- The quality of your plant grounding will provide weighing accuracy and the safety of FT-112 Panel. If grounding of your plant is not good enough, prepare a special grounding.
- Power off the instrument before connecting or disconnecting any peripheral instrument.
- **The shielded cable usage and ground connection of the cables' shields will increase the immunity of FT-112 Panel against electrical disturbances.**
- All required electrical connections should be done as described in the installation section.
- If you have to service the terminal, turn the power off and wait at least 30 seconds before opening housing.

3.1.4 Location of the Peripheral Connections

The electrical terminals are located on the rear of the instrument as shown in the picture below.




Figure 3.2 – The rear view of the instrument and terminal names.

3.2 Cleaning


Warning. *Disconnect the instrument from power source before start cleaning for your safety.*

FT-112 Panel weighing indicator is designed for using in wet, hygienic and harsh environment. To maintain the instrument, never use harsh abrasive cleaners or solvents. Wipe the instrument with a soft cloth slightly dampened with warm soapy water or with mild detergent.

3.3 Disposal


In conformance with the European Directive 2002/96 EC Waste Electrical and Electronic Equipment (WEEE), this device may not be disposed of with domestic waste. This rule also applies to the non-EU countries, according to their specific regulations. Please dispose of this product in accordance with local regulations at the collecting point specified for electrical and electronic equipment. For your questions, please contact the responsible local authority. Thank you for your attention to environmental protection.

3.4 Housing




3.5 Mechanical Installation


Before starting the installation, prepare the weighing indicator location on the cabinet front. Prepare the Protective Earth (PE) cable to grounding the FT-112 Panel housing. The protective earth should be as good as possible for scale reliability. Use high quality and EMC certified DC power source in the cabinet. Follow the requirements on cabling. Refer to **page 14**.




Cut the panel of the cabinet to install the instrument.



Insert the instrument into the panel after placing the waterproof sealing rubber between the panel and FT-112 Panel.



Place holder parts of the instrument to the both side of the instrument.




Use 2 pcs M4 screws to mount the instrument to the panel after alignment.

3.6 Electrical Connections

3.6.1 Analogue Load Cell Connection (Only FT-112 Panel)

To avoid damages, the load cell wiring should be made carefully before energizing the instrument. Load cell connection schematics are in Figure 4.3


The same polarity sense and excitation pins of the load cell connector **should be short circuited** for 4-wire installation. If you have junction box in your system, use 6 wire cable between indicator and the junction box, and short circuit these pins in junction box for better performance as shown in the Figure 4.3




Pin number	Definition	Description
1	+Exc	+ Excitation
2	+Sen	+ Sense
3	+Sig	+ Signal
4	Shield	Protective Earth
5	-Sig	- Signal
6	-Sen	- Sense
7	-Exc	- Excitation
⏏	Shield	Protective Earth

Table 3.1 – Pin configuration of the analogue load cell terminal.


Protective ground connection of cable shields is done by;



4 wire load cell connection



6 wire load cell connection



Junction box connection.
Wiring between instrument and junction box will be 6 wire.

Figure 3.3 – The analogue load cell and junction box connection.

3.6.2 Digital Load Cell Connection (Only FT-112D)

The digital load cell wiring should be made carefully before energizing to avoid FT-112D and load cells from damages. The instrument cable between the instrument and junction box must be shielded and convenient for high speed RS485 interfacing. The wire diameter of the instrument cable should be selected for maximum 0.5 volt drop between the instrument and junction box.

Pin No.	Definition	Description
1	A	+ RS485 for DLC interfacing
2	B	- RS485 for DLC interfacing
3	- V	Ground
4	NC	Not connected
5	NC	Not connected
6	+V _{Lc}	Power output for DLCs
7	-	Not used
⊥	Shield	Protective Earth

Table 3.2 – Pin configuration of the digital load cell terminal of FT-112D.




Figure 3.4 – The FT-112D connection with junction box




Figure 3.5 – Installation with junction box




Figure 3.6 – Daisy-chain installation

3.6.3 RS232C Serial Port

FT-112 Panel weighing indicator has RS232C serial port which is galvanically isolated from other circuitry to increase the EMC immunity. The usage of this serial port and its specifications are described in the Table 3.3 and its pin configuration is shown in Table 3.4.

Usage	Interfacing with printer, PC, PLC, remote display etc.
Data formats	Continuous, Fast Continuous, Printer, BSI Protocol or Modbus RTU
Baud rate	1200 / 2400 / 4800 / 9600 (Default) / 19200 / 38400 / 57600 bps
Length	7 or 8 (default) bits
Parity	Even, Odd or No (default)
Start / Stop bits	1 start bit and 1 stop bit

Table 3.3 - RS232C Serial Interface Specifications



	Definition	RS232C Pin number
	TXD	1
	RXD	2
	GND	3
		Under the terminal

Table 3.4 – Pin configuration of RS232C terminals

2-wire connection to peripherals: RS 232C serial connection is done with two wires as indicated below in

Figure 3.7. if there is no data entry to the weighing indicator. Printer, remote display etc. connections can be done with 2 wire.




Figure 3.7 – 2 wire RS 232C connection with a printer or PC

3-wire connection to the peripherals: RS232C serial connection is done with three wires as indicated below in Figure 4.8 for bidirectional interfacing. Typical application is bidirectional BSI format interfacing with PC or PLC.




Figure 3.8 – 3 wire RS232C connection with a PC or PLC

3.6.4 RS485 Serial Port

The use of this galvanically isolated serial port and its specifications are described in the Table 3-5 and its pin configuration is shown in Table 3-6. Refer to **page 45** to configure RS485 serial port and **page 109** for details on data formats.

Remember 120-ohm line termination resistors should be installed both ends of the RS485 line.

Usage	Interfacing with Printer, PC, PLC, remote display etc.
Data formats	Continuous, Fast Continuous, Printer, BSI Protocol or Modbus RTU
Baud rate	1200 / 2400 / 4800 / 9600 (Default) / 19200 / 38400 / 57600 bps
Length	7 or 8 (default) bits
Parity	Even, Odd or No (default)
Start / Stop bits	1 start bit and 1 stop bit
Address	Programmable between 01 99
Max quantity	Maximum 31 instruments on the line.
Cable length	Maximum 1000m.

Table 3-5 - RS485 Serial Interface Specifications



	Definition	RS485 Pin number
	A+	4
	B-	5
		Under the terminal

Table 3-6 – Pin configuration of RS485 terminal

RS485 serial connection is done with two wires as indicated below in Figure 3.9.




Figure 3.9 – Multi instrument connection with PLC

3.6.5 RS422 Serial Port

The use of this full duplex serial port and specifications are shown in the Table 3.7 and its pin configuration is shown in Table 3.8. Refer to **page 46** to configure the serial port and **page 109** for details on data formats.

Remember 120-ohm line termination resistors should be installed both ends of the RS422 line.

Usage	Interfacing with Printer, PC, PLC, remote display etc.
Data formats	Continuous, Fast Continuous, Printer, BSI Protocol or Modbus RTU
Baud rate	1200 / 2400 / 4800 / 9600 (Default) / 19200 / 38400 / 57600 bps
Length	7 or 8 (default) bits
Parity	Even, Odd or No (default)
Start / Stop bits	1 start bit and 1 stop bit
Address	Programmable between 01 99
Max quantity	Maximum 10 instruments on the line.
Cable length	Maximum 1000m.

Table 3.7 – RS422 Serial Interface Specifications



	Definition	RS422 Pin No.
	RX+	6
	RX-	7
	TX+	8
	TX-	9
	Under the terminal	

Table 3.8 – Pin configuration of RS422 terminal

RS422 serial connection is done with four wires as shown in Figure 3.9.




Figure 3.10 – RS422 multi-instrument connection with PLC

You may use RS422 port as a 2nd RS485 port after adding 2 short circuits between the terminal pins as shown below.




Figure 3.11 – The second RS485 port usage of RS422 port (half duplex).

3.6.6 Ethernet TCP/IP

The use of the Ethernet port on the main PCB and its data formats are shown in the Table 3.9 and its pin configuration is shown in Table 3.10. Refer to Section 5 of the manual to configure this interface. Use the RJ45 connector with metal body and connect shield of the Ethernet cable to the metal body of the connector.

Usage	Interfacing with Printer, PC, PLC, remote display etc.
Data formats	Continuous, Fast Continuous, Printer, BSI Protocol or Modbus TCP

Table 3.9 – Data formats of Ethernet port


	Pin no	Signal	DIR	Description
	1	TX+	Out	Differential Ethernet transmit data +
	2	TX-	Out	Differential Ethernet transmit data -
	3	RX+	In	Differential Ethernet receive data +
	6	RX-	In	Differential Ethernet receive data -
	4	Not used		Terminated
	5	Not used		Terminated
	7	Not used		Terminated
	8	Not used		Terminated
Body	Shield		Metal body of the RJ45 connector.	

Table 3.10 – Pin configuration of RJ45 Ethernet connector

The HUB connection cabling is a direct connection as shown below:




Figure 3.12 - HUB connection

The PC connection cabling is done via cross cable as shown below. IP address blocks and gateway address of FT-112 Panel and PC should be the same in cross connection.




Figure 3.13 - PC connection with cross cable

Important note: Disconnect Indface2x set up PC software before Ethernet interfacing.

3.6.7 Profibus PB



Figure 3.14 - PLC Connection

PROFIBUS Connector pin configuration (DB9F)

Pin	Signal	Description
1	-	-
2	-	-
3	B Line	Positive RxD / TxD, RS-485 level
4	RTS	Request to send
5	GND Bus	Ground (isolated)
6	+5V Bus Output	+5V termination power (isolated)
7	-	-
8	A Line	Negative RxD / TxD, RS-485 level
9	-	-
Housing	Cable Shield	Ground

3.6.8 Profinet



Figure 3.15 - PLC Connection

PROFINET Connector pin configuration (RJ45)

Pin	Signal	DIR	Description
1	TX+	Out	Differential Ethernet transmit data +
2	TX-	Out	Differential Ethernet transmit data -
3	RX+	In	Differential Ethernet receive data +
6	RX-	In	Differential Ethernet receive data -
4	Not used		Terminated
5	Not used		Terminated
7	Not used		Terminated
8	Not used		Terminated
	Shield		Chassis ground

The HUB connection cabling will be a direct connection as shown below:




Figure 3.16 - HUB connection

The PC connection cabling will be done via cross cable as shown below. IP address blocks and gateway address of weighing indicator and PC should be the same in cross connection.




Figure 3.17 - Cross PC connection

3.6.9 CANopen

CANopen connection is done with four wire as indicated below in Figure 3.18. The data line ends must be terminated with 120-ohm resistors.




Figure 3.18 - PLC Connection

CANopen Connector pin configuration (DB9M)

Pin	Signal	Description
1	-	-
2	CAN_L	-
3	CAN_GND	-
4	-	-
5	CAN_SHIELD	-
6	-	-
7	CAN_H	-
8	-	-
9	-	-
Housing	Cable Shield	-

3.6.10 EtherNET/IP




Figure 3.19 – PLC Connection

EtherNet/IP Connector pin configuration (RJ45)

Pin	Signal	DIR	Description
1	TX+	Out	Differential Ethernet transmit data +
2	TX-	Out	Differential Ethernet transmit data -
3	RX+	In	Differential Ethernet receive data +
6	RX-	In	Differential Ethernet receive data -
4	Not used		Terminated
5	Not used		Terminated
7	Not used		Terminated
8	Not used		Terminated
	Shield		Chassis ground

The HUB connection cabling will be a direct connection as shown below:




Figure 3.20 - HUB connection

The PC connection cabling will be done via cross cable as shown below. IP address blocks and gateway address of weighing indicator and PC should be the same in cross connection.




Figure 3.21 - Cross PC connection

3.6.11 EtherCAT




Figure 3.22 – PLC Connection

EtherCAT Connector pin configuration (RJ45)

Pin	Signal	DIR	Description
1	TX+	Out	Differential Ethernet transmit data +
2	TX-	Out	Differential Ethernet transmit data -
3	RX+	In	Differential Ethernet receive data +
6	RX-	In	Differential Ethernet receive data -
4	Not used		Terminated
5	Not used		Terminated
7	Not used		Terminated
8	Not used		Terminated
	Shield		Chassis ground

The HUB connection cabling will be a direct connection as shown:




Figure 3.23 - HUB connection

3.6.12 CC-Link





Figure 3.24 - PLC Connection

CC-Link Connector pin configuration

Pin	Signal	Description
1	DA	PositiveRS485 Rxd/TxD
2	DB	NegativeRS485 Rxd/TxD
3	DG	Signal ground
4	SLD	Cable Shield
5	FG	Protective Earth



3.6.13 Powerlink



Figure 3.25 - PLC Connection

Powerlink Connector pin configuration (RJ45)

Pin	Signal	DIR	Description
1	TX+	Out	Differential Ethernet transmit data +
2	TX-	Out	Differential Ethernet transmit data -
3	RX+	In	Differential Ethernet receive data +
6	RX-	In	Differential Ethernet receive data -
4	Not used		Terminated
5	Not used		Terminated
7	Not used		Terminated
8	Not used		Terminated
	Shield		Chassis ground

The HUB connection cabling will be a direct connection as shown below:




Figure 3.26 - HUB connection

3.6.14 CC-Link IE



Figure 3.27 - PLC Connection

CC-Link IE Field Connector pin configuration

Pin	Signal	Description
1	TP1+	Transmit/Receive 1 positive
2	TP1-	Transmit/Receive 1 negative
3	TP2+	Transmit/Receive 2 positive
6	TP3+	Transmit/Receive 3 positive
4	TP3-	Transmit/Receive 3 negative
5	TP2-	Transmit/Receive 2 negative
7	TP4+	Transmit/Receive 4 positive
8	TP4-	Transmit/Receive 4 negative
Housing	Shield	Connected to FE through a 1 nF capacitor and a 1 Mohm resistor. Note that the connector shields are separated to prevent ground currents.

3.6.15 USB Port

The micro USB connector is located on the rear of the instrument. The usage of the USB 2.0 and its specifications are shown in the Table 3.11. Refer to **page 47** for USB port configuration.

Usage	Interfacing with PC via USB 2.0
Data formats	Continuous, Fast Continuous, BSI Protocol to PC near the instrument

Table 3.11 – Data formats of the USB port

3.6.16 Installation of Alibi SD card

Alibi memory requires the Alibi SD card at the SD1 card slot on the bottom of the main board as shown in the pictures below. The alibi memory SD card can be ordered from Flintec or his dealer.





Figure 3.28- Location of Alibi SD card slot

Inserting or removing the Alibi SD card

1. Deenergize the instrument and wait 30 seconds before interfering the instrument.
2. Remove 4 pcs M4 screws at corners of the backplane.
3. Draw out the back plane and mainboard from the body of the enclosure. The location of the alibi card is on the rear side of the main board which is named as SD2.
4. Insert the Alibi SD card into the slot until it locks into place. Or remove the SD card by pressing it gently. Do not use screwdriver to install or remove SD card.



5. Place the sealing sticker as indicated at the sealing section.
6. Place the main card into the instrument and mount the backplane to the body.
7. Energize the instrument.

3.6.17 Installation of SD Card


Some features of the FT-112 Panel requires SD card like Modbus RTU / TCP. Its slot is located on the rear of the instrument. These SD cards should be ordered for your use.

Insert the SD card

1. Deenergize the instrument and wait 30 seconds.
2. Insert the SD card into the slot until it locks into place.
3. Energize the instrument. FT-112 Panel read the SD card at power on to initiate its function.

Remove the SD card

1. Deenergize the instrument.
2. Gently press on the SD card to release the lock, then carefully pull the card out.



3. Insert the new SD card as described above, if needed.
4. Energize the instrument 30 seconds later power off.

3.6.18 Digital Inputs

Inputs connection diagram is shown in Figure 3.29.




Figure 3.29 - Connection diagram of digital inputs

3.6.19 Digital Outputs:

FT-112 Panel instrument's digital outputs can be programmed as a free setpoint, as a control output or as a remote output at basic weighing.




Figure 3.30 - Outputs connection diagram

3.6.20 Analogue Output Connection

Analogue connections are done as indicated below in Figure 3.31 and Figure 3.32.




Figure 3.31 - Voltage output connections




Figure 3.32 - Current output connections

3.6.21 Power Source Connection and Grounding

Connect DC power supply of FT-112 Panel to the noise proof power line due to the weighing instrument measures very low signal levels. The quality of the power line and DC power supply will determine the accuracy and the safety of your measuring system. The instrument should not share power lines with noise-generating parts such as heavy load switching relays, motor control equipment, inductive loads, etc. If the condition of the power supply in the plant is poor, prepare a special power line and grounding. Before connecting the power, source check its voltage and be sure that it is the same with the voltage written on the weighing indicator.

Pin number	DC Power Supply
1	0
2	+24 VDC
PE Protective Earth (Grounding)	PE cable to the screw under the power supply terminal

Table 3.12 – Pin configuration of power supply connector.







Figure 3.33 – Power source connection and grounding.

4 FT-112 FUNCTIONS

4.1 Basic Functions

Zeroing

Zeroing corrects the drifts of the unloaded scale from the zero point.

1. Unload the scale.
2. Press  key.
3. Centre of zero appears  symbol on the display.
4. Check the center of zero sign on the left of the display. If it doesn't appear, press the  key once more for correct zeroing.

Zeroing is available in the limited range by zeroing parameter 514, [page 64](#).

Automatic zero-point correction


Zero point is corrected automatically for minor deviations if the change is within the range of limited zeroing range value. Disable this correction at the applications like tank weighing, batching, filling etc. against wrong zeroing at feeding. Refer to Automatic Zero Tracking parameter 515, [page 64](#).

Automatic zero-point correction range is limited together with zeroing range above.

Automatic zeroing at power on

Zero point is corrected automatically at power on the instrument to compensate zero drifts of the scale if the scale is always power on when unloaded. This feature should be disabled for tank, silo, hopper scales etc.

Power on zero has a limited range and the instrument announces [POWER ON ZERO ERR] error prompt in case of out of range.

Press  key to start indication without zeroing and call service. If the range is 3%, the residual drift cannot be displayed. Refer to Power on Zero parameter 513, [page 63](#).

Basic weighing

1. Zeroing the unloaded scale.
2. Place weighing item on the scale.
3. Wait until the motion monitor disappears.
4. Read the weighing result.

If the loading is out of the indication range the prompts below are displayed.



Under of negative indication limit



Over than positive indication limit

Taring

Taring is used to determine a net weight of a material if any tools like containers are needed. The weight of these tools can be eliminated. FT-112 Panel weighing indicator has 2 different taring features.

Subtractive tare

This taring type is the mostly used way which tare value reduce the weighing range in Net as
Maximum Net weight = Scale capacity - Tare weight



Advantages of this taring are smaller capacity load cell requirement, bigger load cell signal range at weighing, temporary gross indication availability, tare weight data on the printout etc.

Additive tare


This taring type is the mostly used way if the tare weight is too heavy against the material weight and the scale division which is required. The scale range is not changed after taring The net weight range is always equal to the scale capacity. The maximum tare is limited and is not transferred to PC or to the printer.

Net weighing in the container

Taring is used to weight material in the container.

1. Place the empty container on to the scale and press  key.
2. The zero display and the NET symbol appear.
3. Check **OK** sign on the display. If it doesn't appear, press the  key once more for correct taring.
4. Add the material into the container and follow its weight in net.

Clearing the tare

Press  key to clear the tare. The NET symbol disappears, and Gross symbol appears on the display together with the gross weight indication. The scale instability will not impact clear the tare.

Automatic taring

The scale tares automatically and NET is displayed, after placing a weight on the empty scale, if this feature is enabled. Refer to parameter 232 at [page 55](#). The weight should be heavier than the value entered to the parameter 518 for automatic taring.


Automatic clear the tare

The tare is automatically cleared after emptying the scale, if this feature is enabled. The scale instability will not impact clear the tare automatically.

Restore status at power on

This function saves the tare status at power off and the instrument operates in Net at power on. This feature is used for tank and silo weighing applications.

Printing

Press  key if a item is on a scale and the weight is stable to print the label. The printout format can be selected from parameter 161. Indface2x PC software is used to program EPL printout data and download to the instrument for free programming the data output or for label printing including barcode. Refer to [page 49](#), and [116](#) for details.

4.2 Advanced Functions


Programmable keys




keys can be programmed to fit the instrument to your application and for easy use.

The programmable functions are high resolution, temporary gross indication, unit change etc. Refer to sub-block 24-, **page 56** to see the availabilities.

High resolution

If you press  key, the weight value is displayed 10 times higher. Press the same key again to end. High resolution is displayed temporarily for 5 seconds at approved scales. High resolution cannot be printed.

Unit change

Pressing the  key, you can change between two units. The unit change is available between kg and lb. Refer to parameters 521.


Dynamic weighing

APPLICATION: *Living stock weighing, weighing of unstable load, unstable industrial weighing systems.*

RELATED PARAMETERS: *Sub-block 33-, page 59.*

The dynamic weighing can be programmed for single weighing or continuous weighing after assigning one of the programmable keys for dynamic weighing. Single weighing is used for dynamic weighing like living animals; continuous dynamic weighing can be used for loads which have very high vibration like reactors with high-speed mixers, conveyors etc.

Single weighing operation:




1. Place container on the scale.
2. Press  key to tare the scale.
3. Load the scale.
4. Press the dynamic weighing key to start dynamic weighing. Or dynamic weighing is started automatically if the load is heavier than 50 divisions. Refer to parameter 331.
5. After the weighing cycle, the dynamic weight value is displayed.
6. Unload the scale or press the dynamic weighing key to reset dynamic weighing operation.

Depends on the operation type selected at parameter 331, the dynamic weighing may start automatically if the load is heavier than minimum weight or may end after unloading the scale (refer to **page 59**).

Specified tare PT (Preset tare)

If you have specified containers, you may enter their weight values numerically using preset tare (PT) for taring the scale. This feature eliminates the taring of empty container to measure the net value in it, to reduce your operation time by weighing only filled containers to get net weight value. To be able to use this feature, it must be enabled first. Refer to **page 55**.









Preset Taring with numeric entry:

1. Press  key.
2. Enter tare value numerically.
3. Press  key for taring or press  key to escape.











Specified tare (PT) memory

If you have specified containers, which are used frequently and if you prefer to enter their weight manually instead of taring every time, you may record their weights into the Preset tare memory. Up to 500 specific tare values can be recorded.







Recording the specific container weight into the preset tare memory

1. Press  key for more than 2 seconds at basic weighing. The [MEMORY] message will appear on the display.
2. Press  key to enter memory. The last entered specific tare code appears as [PT: 111].
3. Press numerical keys to enter the specific tare code. Or press  or  keys to navigate in the memory. Press  key to access PT memory code shown on the display.
4. The previous specific tare value appears on the display. Enter the new value by pressing numeric keys. Press  key to save or press  key to escape.
5. After saving the entry the next memory code will appear. Follow from item 3 to entry PT values into other codes.
6. Press  key to return to the operation.

Recording the indicated weight into the preset tare memory

1. Empty the scale and press  key until  symbol appears on the display.
2. Place the container on the scale.
3. Press  key for more than 2 seconds at basic weighing. The [MEMORY] message will appear on the display.
4. Press  key to enter memory. The last entered specific tare code appears as [PT: 111].
5. Press numerical keys to enter the preset tare memory code. Or press  or  keys to navigate in the memory. Press  key to access PT memory code shown on the display.
6. The previous specific tare value appears on the display. Press  key to save indicated weight to the PT memory.
7. Press  key to confirm.
8. Press  key to return operation.

Taring from the preset tare memory

1. Press  key and  key in sequence at basic weighing to enter PT memory.
2. The last entered preset tare memory code appears.
3. Press numerical keys to enter the preset tare memory code. Or press  or  keys to navigate in the memory.
4. Press  key for specific taring. Or press  key to return operation.

Net sign correction

Some weighing of materials is done by unloading the material from the container. The net sign correction enables always positive net weighing at loading and at unloading the material from scale by switching gross and tare weights, if necessary. Refer to parameter 237 to enable net sign correction.




Enabled net sign correction affects the display and printed data.

Displaying and printout	Net sign correction disabled	Net sign correction enabled
Tare	120.0 kg	30.0 kg
Gross	30.0 kg	120.0 kg
Net	- 90.0 kg	90.0 kg




Date and Time

RELATED PARAMETERS: Parameters 251, 252 and 253.




Date format of the country

1. Enter the programming and go to parameter 251, **page 56**.
2. Press ▲ or ▼ keys to select date format: DMY (DD.MM.YYYY), MDY (MM.DD.YYYYYY) or YMD (YYYY.MM.DD) and press  key to confirm.
3. Press  key until [SAVE : YES] prompt appears.
4. Press  key to save or press ▲ or ▼ keys to select "NO" to return operation without saving.

Date adjust

1. Enter the programming and go to parameter 252, **page 56**.
2. Press numerical keys to enter the date and press  key to confirm.
3. Press  key until [SAVE : YES] prompt appears.
4. Press  key to save or press ▲ or ▼ keys to select "NO" to return operation without saving.

Time adjust

1. Enter the programming and go to parameter 253, **page 56**.
2. Press numerical keys to enter the time and press  key to confirm.
3. Press  key until [SAVE : YES] prompt appears.
4. Press  key to save or press ▲ or ▼ keys to select "NO" to return operation without saving.

Tilt switch

Tilt switch is used to prevent wrong weighing in case of over tilting of platform.

Connect tilt switch to the Input 4 of the instrument and enable tilt switch by setting the parameter 51A.




[DUE TO TILTING] [-----] prompt is displayed in case of over tilting.

Language

RELATED PARAMETERS: Parameter 236.

You can select the operation and printout language of the instrument. The available languages are English, German, French, Italian, Spanish and Turkish. The language of programming is English, which has the parameter code in front of parameter name for easy use.

Language selection

1. Enter the programming and go to parameter 236, **page 55**.
2. Press ▲ or ▼ keys to select language and press  key to confirm.
3. Press  key until [SAVE : YES] prompt appears.
4. Press  key to save or press ▲ or ▼ keys to select "NO" to return operation without saving.

Bar graph at basic weighing

The Bar graph, which is located on the right side of the display, is used for the graphical visualization of the measured value. It changes according to the Gross weight even the scale is displaying in Net. The usage of the scale capacity and the available range are shown on the bar graph. In the example below 70% of the capacity is used and 30% is available.




Minimum tare

You may restrict the taring by entering minimum tare value to the parameter 518. In case of activated automatic taring, the instrument tares automatically if the loading is heavier than minimum tare.

Minimum weight for accurate weighing

The instrument produces data output or enables any feature, like printing, if the loading is heavier than minimum weight. This feature increases the accuracy of your system.

Next verification date

The instrument warns the operator on the following verification or calibration date if date is entered. The warning is disappeared after pressing  key until switch on the instrument again.






4.3 Alibi Memory

RELATED PARAMETERS: Main block 8--.

You can fulfill your weight data recording obligations with the alibi memory in certified operation without having paper archive. The weight data is saved into the alibi memory after every weighing operation together with date and time. The alibi record number may also be found on the printout data.


The alibi memory recording principle is a loop memory. The oldest record will be deleted after the capacity limit 99 999 was reached to overwrite the latest weighing. You can quickly access to the record of specific weighing by entering the suitable search criteria.

Activating Alibi Memory

1. Go to the parameter [8-- METROLOGY] main block in set up.
2. Press  key 2 times to access parameter 811.
3. Press  key after selecting YES in the parameter.
4. Press  key until [SAVE : YES] prompt appears on the display and press  key to save the changes into the memory. [E42 NEW ALIBI] message appears.
5. Press  key to start Alibi memory.

How is the Data Recorded into the Alibi Memory?

After the following actions the transferred data is recorded into the alibi memory:




1. Press  key to print the label,
2. Automatic printing (automatic print data transferring),
3. Interface command ASCII < P > ,
4. BSI commands which request the stable weight,
5. Print commands of fieldbus interfaces,
6. Digital < Print > input.

Recall Data from Alibi Memory

RELATED PARAMETERS: Parameter 813.

You may display the alibi record by selecting the criteria, which are alibi number, date, net weight, gross weight, or tare weight. You also may transfer alibi memory records to your PC.







Access to Alibi records:

1. Go to the parameter [8-- METROLOGY] main block in set up.
2. Press  key 4 times to access parameter 813.
3. Select the suitable criteria by pressing  or  keys which are NUM (Alibi number), DATE (weighing date), NET (net weight), GROS (gross weight), TARE (tare weight) or CN (consecutive number).







Alibi records will be displayed in sequence:

1. Alibi record number
2. Date
3. Time
4. Gross weight
5. Net weight
6. Tare weight
7. Consecutive number





Search with Alibi record number:

1. Press  key after selecting NUM in parameter 813.
2. Press numerical keys to enter alibi number in the printout data and press  key. You may navigate in the alibi memory with  or  keys after entering alibi number.
3. The weighing data in the alibi memory is indicated on the display.
4. Press  key to print this record and the previous nine weighing.
5. Press  key 4 times to return operation.






Search with date:

1. Press  key after selecting DATE in parameter 813.
2. Press numerical keys to enter date in the printout data and press  key. The date format entry should be as in the operation. e.g. date entry should be DDMMYY if parameter 251 is set to DMY. You may navigate in the alibi memory with  or  keys after entering the date.
3. The weighing data in the alibi memory is indicated on the display.
4. Press  key to print this record and the previous nine weighing.
5. Press  key 4 times to return operation.



Search with weight value:

1. Press  key after selecting NET, gross or tare which is suitable in parameter 813.
2. Press numerical keys to enter weight value in the printout data and press  key.
3. The alibi record is indicated on the display.
4. Press  key to print this record and the previous nine weighing.
5. Press  key 4 times to return operation.

Transfer all Alibi records:

1. Go to the parameter [8-- METROLOGY] main block in set up.
2. Press  key 5 times to access parameter 814.
3. Press  or  keys to select PRNT and press  key to start transferring.
4. Or you may stop transferring by pressing  key.






About Alibi Memory:

1. Go to the parameter [8-- METROLOGY] main block in set up.
2. Press  key 6 times to access parameter 815.
3. Press  key to print alibi information.

Format Alibi Memory:

Warning: Alibi memory formatting should be done by authorized person only. Otherwise erasing alibi memory may bring you undesired legal responsibility.







You may need to format alibi memory after installing the used SD card, to erase previous records before starting usage in legal or to erase alibi memory if you don't need previous records legally. This process runs if the calibration switch is at programming position.

1. Go to the parameter [8-- METROLOGY] main block in set up.
2. Press  key 7 times to access parameter 816.
3. Select YES and press  key.
4. The warning prompt [ARE YOU SURE?] appears on the display.
5. Press  key to start formatting or Press  key to escape.
6. Press  key 3 times to return operation.


The empty fields are indicated as [-----] and transferred as [NO RECORD]; and the corrupted records are indicated as [Error] and transferred as [CORRUPTED].

5 PROGRAMMING AND CALIBRATION

You will find the programming and calibration procedure of FT-112 Panel weighing indicator in this section. The arrow on navigation keys indicates the function of the keys in programming menu. The basic meanings of these keys are;

						
Navigation between parameters	Exit from any entry or block or from programming.	Go to previous block or parameter.	Next block.	Previous block.	Go to next block or parameter.	Enter the parameter to edit it.
Parameters' value	Exit with previous value	Move to the left digit.	Next option	Before option	Move to the right digit.	Confirm and go to the next parameter.

A set-up DIP switch is located near the load cell connector at the FT-112 (D) panel rear side as shown in the figure below and its position should be "ON" (downward) to change the metrological related parameters including calibration.





DIP Switch	Description
1	Calibration SW OFF: Locked ON: Set- up
2	Reserve

Figure 5.1- The location of calibration DIP switch.






5.1 Entering to the Programming and Calibration

Enter the programming menu as described below. Legally related parameters can be changed if the calibration dip switch is at ON position. These parameters are marked with **M** symbol in the parameter table in this section. If you will change any legally relate parameter or will perform calibration, set the calibration switch to the ON position before entering to the programming.

Display	Operation
[123.456 kg]	Press  key until [PASSWORD :] prompts shown.
[PASSWORD]	Enter your 4-digit passport. (Default is 1111)
[****]	Press  key.
[1—INTERFACE]	You entered to the programming main menu and the first main block [1—INTERFACE] prompt appears.









5.2 Quick Access to frequently Used Parameter Blocks

The instrument supports fast access feature to the frequently adjusted parameters for easy usage or service. As described in the previous section, if you press the keys below for more than 2 seconds at main block [1—INTERFACE], you will access to the parameter blocks fast.

Fast access key	Function
	Press this key to access the fieldbus parameters, Sub-block [19-].
	Press this key to access application parameters, Sub-block [31-].
	Press this key to access the digital inputs and outputs parameters, Sub-block [35-].
	Press this key to access the calibration, Sub-block [621].
	Press this key to access the diagnostic parameters, Main-block [9--].

5.3 Exit from Programming

Exit from programming after set-up the scale and calibration as described below.


1. Press  key until [SAVE : YES] prompt appear on the display.
2. Press  key to save the changes into the memory or
3. Press  key to change item to [SAVE : NO], press  key to leave programming without saving the changes or
4. Press  key to change item to [SAVE : BACK], press  key to return to the menu or
5. Press  key to change item to [SAVE : TEMP], press  key to store the changes until the power off the instrument.

[WAIT] message will be shown on the display for a little while, and the weighing indicator returns to the weighing mode.

WARNING: Don't forget to switch off the instrument and bring the calibration DIP switch to the position "OFF" before using your scale in trade.

5.4 Programming and Parameters

FT-112 Panel weighing indicator is programmed in seven main blocks, which are serial interface, configuration, application, scale, calibration, metrology, and diagnostic.









Main blocks in the programming menu are displayed like [1-- INTERFACE] and sub-blocks are displayed like [11- RS232C]. Parameters are located in the sub-blocks like [111 FORMAT:CONT].







You can navigate between the blocks by pressing or keys. After reaching the desired block, press key or key to enter. After arriving a parameter, you may change its function by pressing or keys. If the value will be entered to the parameter press numerical keys, then press key and key to enter the next parameter.







For example, to change the Baud rate of RS422 serial interface to 57600;







1. After entering the programming, the [1-- INTERFACE] sub-block prompt appears. Press key.
2. [11- RS232C] prompt appears. Press key until [13- RS422] appears.
3. Press key until [132 BAUD:9600] appears.
4. Press key to change to [132 BAUD:57K6].
5. Press key to enter the next parameter.




Legally related parameters can be changed if the calibration dip switch is at ON position. The values of these parameters limited according to the OIML against wrong set up. Legally related parameters are marked with **M** symbol in the table below.




		NO : Carriage return disable YES : Carriage return enable	
[117	LFEED : YES]	Line feed at continuous formats. NO : Line feed disable YES : Line feed enable	
[118	DELAY : 50]	Data output delay at Modbus and BSI formats; delay between continuous format data. 000 999 milliseconds.	
[119	ADDRESS : 00]	Address of the port 00 99. 00 means data format without address.	
[12-	RS485]	RS 485 SERIAL PORT Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.	
[121	FORMAT : NO]	Data format of the serial port NO : Port is disabled CONT : Continuous data output FAST : High speed continuous data output PRNT : Printout BSI : BSI format for PC, PLC interface MBHL : Modbus RTU High-Low format MBLH : Modbus RTU Low-High format	<i>Page 94, 19, 110</i>
	[FLINTEC]	Press  key to select output format different than Flintec continuous data format while the selection is CONT in the information display. Available functions are shown on the weight display after pressing  key sequentially. Press  key after selecting the data format. Refer to Appendix 5 for details data structure. FLINTEC : Flintec continuous format. HBM : Commonly used by HBM, GSE, PT, Systec, Rinstrum. TOLEDO : Commonly used by Toledo, Mettler Toledo. SYSTEC : Commonly used by Systec. SMA : Commonly used by USA producers, Cardinal, Rice Lake etc. SARTOR : Commonly used by Sartorius. RINSTR : Commonly used by PT, Rinstrum, HBM, GSE. AVERY : Commonly used by Avery E1205. BASTER : Commonly used by Baster. LM2 : Flintec LM2 (BX1 par.000=6)	
[122	BAUD : 9600]	Baud rate 1200 : 1200 19K2 : 19200 2400 : 2400 38K4 : 38400 4800 : 4800 57K6 : 57600 9600 : 9600	
[123	LENGHT : 8]	Data Length 7 : 7 bits 8 : 8 bits	









[124 PARITY : NO]	Parity NO : No parity ODD : Odd parity EVEN : Even parity
[125 CSUM : NO]	Checksum at continuous and BSI formats. NO : Checksum disable YES : Checksum enable
[126 CR : YES]	Carriage return at continuous formats. NO : Carriage return disable YES : Carriage return enable
[127 LFEED : YES]	Line feed at continuous formats. NO : Line feed disable YES : Line feed enable
[128 DELAY : 50]	Data output delay at Modbus and BSI formats; delay between continuous format data. 000 999 milliseconds.
[129 ADDRESS : 01]	Address of the port 00 99. 00 means data format without address.
[13- RS422]	RS 422 SERIAL PORT Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.
[131 FORMAT : NO]	Data format of the serial port <i>Page 94, 19, 110</i> NO : Port is disabled CONT : Continuous data output FAST : High speed continuous data output PRNT : Printout BSI : BSI format for PC, PLC interface MBHL : Modbus RTU High-Low format MBLH : Modbus RTU Low-High format
[<i>FLINTEC</i>]	Press  key to select output format different than Flintec continuous data format while the selection is CONT in the information display. Available functions are shown on the weight display after pressing  key sequentially. Press  key after selecting the data format. Refer to Appendix 5 for details data structure. FLINTEC : Flintec continuous format. HBM : Commonly used by HBM, GSE, PT, Systec, Rinstrum. TOLEDO : Commonly used by Toledo, Mettler Toledo. SYSTEC : Commonly used by Systec. SMA : Commonly used by USA producers, Cardinal, Rice Lake etc. SARTOR : Commonly used by Sartorius. RINSTR : Commonly used by PT, Rinstrum, HBM, GSE. AVERY : Commonly used by Avery E1205. BASTER : Commonly used by Baster. LM2 : Flintec LM2 (BX1 par.000=6)
[132 BAUD : 9600]	Baud rate













	1200 : 1200 2400 : 2400 4800 : 4800 9600 : 9600	19K2 : 19200 38K4 : 38400 57K6 : 57600
[133 LENGHT : 8]	Data Length 7 : 7 bits 8 : 8 bits	
[134 PARITY : NO]	Parity NO : No parity ODD : Odd parity EVEN : Even parity	
[135 CSUM : NO]	Checksum at continuous and BSI formats. NO : Checksum disable YES : Checksum enable	
[136 CR : YES]	Carriage return at continuous formats. NO : Carriage return disable YES : Carriage return enable	
[137 LFEED : YES]	Line feed at continuous formats. NO : Line feed disable YES : Line feed enable	
[138 DELAY : 50]	Data output delay at Modbus and BSI formats; delay between continuous format data. 000 999 milliseconds.	
[139 ADDRESS : 00]	Address of the port 00 99. 00 means data format without address.	
[13A DUBLEX : HALF]	Duplex on the interface HALF : Half duplex (select for RS485) FULL : Full duplex	
[14- USB]	USB Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.	
[141 FORMAT : NO]	Data format of the serial port NO : Port is disabled CONT : Continuous data output FAST : High speed continuous data output BSI : BSI format for PC, PLC interface	<i>Page 94, 19, 110</i>
	Press  key to select output format different than Flintec continuous data format while the selection is CONT in the information display. Available functions are shown on the weight display after pressing  key sequentially. Press  key after selecting the data format. Refer to Appendix 5 for details data structure.	

















[FLINTEC]	FLINTEC : Flintec continuous format. HBM : Commonly used by HBM, GSE, PT, Systec, Rinstrum. TOLEDO : Commonly used by Toledo, Mettler Toledo. SYSTEC : Commonly used by Systec. SMA : Commonly used by USA producers, Cardinal, Rice Lake etc. SARTOR : Commonly used by Sartorius. RINSTR : Commonly used by PT, Rinstrum, HBM, GSE. AVERY : Commonly used by Avery E1205. BASTER : Commonly used by Baster. LM2 : Flintec LM2 (BX1 par.000=6)
[142 CSUM : NO]	Checksum at continuous and BSI formats. NO : Checksum disable YES : Checksum enable
[143 CR : YES]	Carriage return at continuous formats. NO : Carriage return disable YES : Carriage return enable
[144 LFEED : YES]	Line feed at continuous formats. NO : Line feed disable YES : Line feed enable
[145 DELAY : 50]	Data output delay at BSI formats; delay between continuous format data. 000 999 milliseconds.
[15- ETHERNET]	ETHERNET TCP/IP Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.
[151 FORMAT : NO]	Data format of the Ethernet port <i>Page 94, 19, 110</i> NO : Port is disabled CONT : Continuous data output FAST : High speed continuous data output PRNT : Printout BSI : BSI format for PC, PLC interface MBHL : Modbus TCP High-Low format MBLH : Modbus TCP Low-High format
[FLINTEC]	<p>Press  key to select output format different than Flintec continuous data format while the selection is CONT in the information display. Available functions are shown on the weight display after pressing  key sequentially. Press  key after selecting the data format.</p> <p>Refer to Appendix 5 for details data structure.</p> FLINTEC : Flintec continuous format. HBM : Commonly used by HBM, GSE, PT, Systec, Rinstrum. TOLEDO : Commonly used by Toledo, Mettler Toledo. SYSTEC : Commonly used by Systec. SMA : Commonly used by USA producers, Cardinal, Rice Lake etc. SARTOR : Commonly used by Sartorius. RINSTR : Commonly used by PT, Rinstrum, HBM, GSE. AVERY : Commonly used by Avery E1205. BASTER : Commonly used by Baster. LM2 : Flintec LM2 (BX1 par.000=6)





[152 IP : 250]	IP address. Default is 192.168.016.250
[153 ADDRESS : 01]	Address of the port 00 255. 00 means data format without address.
[154 SUBMASK : 000]	Subnet mask address. Default is 255.255.255.000
[155 GATEWAY : 253]	Gateway address. Default is 192.168.016.253
[156 LOCAL P1 : 502]	Local port 1. 000 65535
[157 LOCAL P2 : 503]	Local port 2. 000 65535
[158 LOCAL P3 : 504]	Local port 3. 000 65535
[159 DNS : 222]	DNS address. Default is 208.067.222.222
[15A MACADR :]	MAC address. AA:BB:CC:DD:EE:FF
[15B TIMEOUT : 5]	Inactivity time out. 00 means disable. 01.... 60 sec.
[15C CR-LF : YES]	Carriage return and Line feed at continuous formats. NO : Disable YES : Enable
[15D DELAY : 050]	Data output delay at demand formats; delay between continuous format data. 000 999 milliseconds.
[15E REMOTEIP : 000]	Remote IP address. Default is 0.0.0.0
[15F REMOTEPO : 0]	Remote port. 0 65535
[16- PRINTER]	PRINTER Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.
[161 FORMAT : 26F2]	Data format of the printout <i>Page 94</i> SING : Single line 16F1 : Multiline Format 1 for 16 Character printer 16F2 : Multiline Format 2 for 16 Character printer 26F1 : Multiline Format 1 for 26 Character printer 26F2 : Multiline Format 2 for 26 Character printer EPL : EPL Format

[162 METHOD : KEY]	Printing method KEY : Printing with key LOCK : Print interlock. Only one-time printout, if weight change is more than 10 division. AUTO : Auto print, if the gross load is bigger than MIN WEIGHT and stable. Unload and load the scale for next printing. LOAD : Autoprint if W>MIN WEIGHT and weight change is more than 10d.
[163 PRTMSG : NO]	Display " PRINTING" message at printout NO : Disable YES : Enable
[164 CN : YES]	Ticket number on printout. NO : Disable YES : Enable
[165 DATE : YES]	Date printing on printout. NO : Disable YES : Enable
[166 TIME : YES]	Time printing on printout. NO : Disable YES : Enable
[167 ID1 : N+D]	ID1 printing on printout. NO : Disable DATA : Print ID1 data N+D : Print ID1 name and data
[168 ID2 : N+D]	ID2 printing on printout. NO : Disable DATA : Print ID2 data N+D : Print ID2 name and data
[17- LABEL SETUP]	LABEL SETUP Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.
[171 HEADER1 :]	Header of printout, the first line. <i>Page 115</i> Maximum 20 characters.
[172 HEADER2 :]	Header of printout, the second line. <i>Page 115</i> Maximum 20 characters.
[173 HEADER3 :]	Header of printout, the third line. <i>Page 115</i> Maximum 20 characters.
[174 FOOTER1 :]	Footer of printout, the first line. <i>Page 115</i> Maximum 20 characters.
[175 FOOTER2 :]	Footer of printout, the second line. <i>Page 115</i> Maximum 20 characters.
[176 LF BEFO : +2]	Line feed before printout. : + = Forward , - = Backward : NO,1,2...9 : Line feed quantity before data. Example: +2 means 2-line feed forward.












[177 LF AFTE : +4]	Line feed after printout. : + = Forward, - = Backward : NO,1,2,...9 : Line feed quantity after data. Example: -2 means 2-line feed backward.
[178 FORMFE : NO]	Form feed. NO : Disable YES : Enable
[179 LEFTSP : 3]	Space from left of the label. 0...9
[17A COPY : 1]	Copy quantity. 1...9
[19- ANALOG OUT]	ANALOGUE OUTPUT (Only FT-112 Panel AN) Press  key or  key again to enter this menu. Press  key to return to beginning of the sub-block or press  key to enter the next main-block.
[191 TYPE : 4-20]	Analog output type 4-20 : 4 mA - 20 mA 0-20 : 0 mA - 20 mA 0-10 : 0 VDC- 10 VDC 0-5 : 0 VDC- 5 VDC
[192 MINIMUM : 00.0]	The minimum of the analogue output. Default 00.0 means the minimum output is not drifted. e.g. enter 1.0 to set output to 1.0 volt at 0 kg in 0 -10 V range.
[193 MAXIMUM : 00.0]	The maximum of the analogue output. 00.0 means the maximum output is not drifted. e.g. enter 9.0 to set output to 9.0 volt at Max load in 0 -10 V range.
[194 SOURCE : GROS]	Source of the analogue output GROS : Gross weight INDI : Indicated weight
[195 ZERO ADJ :]	Displays the count value of unloaded scale. Increase or decrease by pressing  or  ; or enter the value by pressing numerical keys to change the unloaded scale output.
[196 SPAN ADJ :]	Displays the count value of the full loaded scale. Increase or decrease by pressing  or  ; or enter the value by pressing numerical keys to change the analogue output gain.
[197 AUTO ADJ : NO]	Set analogue output to calibration range NO : No YES : Automatic adjustment between min and max limits if changed.




[19- PROFIBUS]	<p>PROFIBUS CONFIGURATION (Only FT-112 Panel PB)</p> <p>Press  key or  key again to enter this menu.</p> <p>Press  key to return to beginning of the sub-block or press  key to enter the next main-block.</p>
[191 FORMAT : INTG]	<p>Data format of the Profibus</p> <p>INTG : Signed 32-bit integer, no decimal point implied.</p> <p>FLOA : 32 bit float, decimal point implied.</p>
[192 ADDRESS : 001]	<p>Node address</p> <p>001...125</p>
[19- PROFINET]	<p>PROFINET CONFIGURATION (Only FT-112 Panel PN)</p> <p>Press  key or  key again to enter this menu.</p> <p>Press  key to return to beginning of the sub-block or press  key to enter the next main-block.</p>
[191 FORMAT : INTG]	<p>Data format of the Profinet</p> <p>INTG : Signed 32-bit integer, no decimal point implied.</p> <p>FLOA : 32 bit float, decimal point implied.</p>
[192 IP : 250]	<p>IP address of Ethernet port.</p> <p>Default is 192.168.16.250</p>
[194 SUBMASK : 000]	<p>Subnet mask address of Ethernet port.</p> <p>Default is 255.255.255.000</p>
[195 GATEWAY : 253]	<p>Gateway address.</p> <p>Default is 192.168.16.253</p>
[196 S. NAME : SCAL]	<p>Station (device) name.</p> <p>Default is SCALE-1</p>
[19A MACADR :]	<p>MAC address</p> <p>AA:BB:CC:DD:EE:FF</p>
[19- CANOPEN]	<p>CANOPEN CONFIGURATION (Only FT-112 Panel CO)</p> <p>Press  key or  key again to enter this menu.</p> <p>Press  key to return to beginning of the sub-block or press  key to enter the next main-block.</p>
[191 FORMAT : INTG]	<p>Data format of the CANopen</p> <p>INTG : Signed 32-bit integer, no decimal point implied.</p> <p>FLOA : 32 bit float, decimal point implied.</p>
[192 ADDRESS : 001]	<p>Node address</p> <p>001...127</p>








[19- ETHERNET IP]	ETHERNET/IP CONFIGURATION (Only FT-112 Panel EI) Press  key or  key again to enter this menu. Press  key to return to beginning of the sub-block or press  key to enter the next main-block.
[191 FORMAT : INTG]	Data format of the EtherNet/IP INTG : Signed 32-bit integer, no decimal point implied. FLOA : 32 bit float, decimal point implied.
[192 IP : 250]	IP address of Ethernet port. Default is 192.168.16.250
[194 SUBMASK : 000]	Subnet mask address of Ethernet port. Default is 255.255.255.000
[195 GATEWAY : 253]	Gateway address. Default is 192.168.16.253
[19A MACADR :]	MAC address AA:BB:CC:DD:EE:FF
[19- ETHERCAT]	ETHERCAT CONFIGURATION (Only FT-112 Panel EC) Press  key or  key again to enter this menu. Press  key to return to beginning of the sub-block or press  key to enter the next main-block.
[191 FORMAT : INTG]	Data format of the EtherCAT INTG : Signed 32 bit integer, no decimal point implied. FLOA : 32 bit float, decimal point implied.
[19- CC-LINK]	CC-LINK CONFIGURATION (Only FT-112 Panel CC) Press  key or  key again to enter this menu. Press  key to return to beginning of the sub-block or press  key to enter the next main-block.
[191 FORMAT : INTG]	Data format of the CC-Link INTG : Signed 32 bit integer, no decimal point implied. FLOA : 32 bit float, decimal point implied.
[192 ADDRESS : 001]	Node address 001...64
[193 BAUD : 156K]	Baud rate 156K : 156 kbps 625K : 625 kbps 2.5M : 2.5 Mbps 5M : 5 Mbps 10M : 10 Mbps
[19- POWERLINK]	POWERLINK CONFIGURATION (Only FT-112 Panel PL) Press  key or  key again to enter this menu. Press  key to return to beginning of the sub-block or press  key to enter the next main-block.
[191 FORMAT : INTG]	Data format of the Powerlink INTG : Signed 32 bit integer, no decimal point implied. FLOA : 32 bit float, decimal point implied.
[192 ADDRESS : 001]	Node address 001...239





[19- CC-LINK IE]	CC-LINK IE CONFIGURATION (Only FT-112 Panel IE) Press  key or  key again to enter this menu. Press  key to return to beginning of the sub-block or press  key to enter the next main-block.
[191 FORMAT : INTG]	Data format of the CC-Link IE Field. INTG : Signed 32 bit integer, no decimal point implied. FLOA : 32 bit float, decimal point implied.
[192 STATION : 001]	Station number. 001...120
[193 NETWORK : 001]	Network number. 001...239

[2-- CONFIGURATIO] Configuration Block









[2-- CONFIGURATIO]	CONFIGURATION MAIN BLOCK Press  key sequentially to access this main block, or press  key or  key to enter configuration parameters, or press  key to enter the next block, or press  key to exit from programming.
[21- DSPLY ACUSTI]	DISPLAY AND ACOUSTIC Press  key or  key again to enter this menu. Or press  key to enter the next sub-block.
[211 LIGHT : ON]	Backlight OFF : Backlight disabled. ON : Always bright. AUTO : Automatic backlight to increase the battery life.
[212 COLOR : TURQ]	Backlight color at basic weighing WHIT : White LGRE : Light Green GREE : Green TURQ : Turquoise BLUE : Blue YELL : Yellow AMBE : Amber RED : Red
[213 KEYSOUN : YES]	Key sound NO : Disable YES : Enable
[214 REFRESH : 5]	Display refresh rate X : 1...9 times/sec
[22- INFO DISPLAY]	INFORMATION DISPLAY Press  key or  key again to enter this menu. Or press  key to enter to the next sub-block.
[221 TIME : D+T]	Information data on the right of the alphanumeric display. NO : No clock data on the display. T : Display time, D : Display date, D+T : Display date and time,




[222 DATA : TARE]	<p>Information data on the left of the alphanumeric display.</p> <p>NO : No data TARE : Tare weight is displayed GROS : Gross weight is displayed in Net ID1 : ID1 Data ID2 : ID2 Data TOTA : Total Q+TO : Quantity and total GTOT : Grand Total</p> <p><i>Note: The par 221 is set to NO, if this parameter isn't programmed NO, TARE or GROS.</i></p>
[23- START UP]	<p>START UP</p> <p>Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.</p>
[231 TARING : MULT]	<p>Taring. <i>Page 34</i></p> <p>NO : Disabled. MULT : Tare with key, via serial interface or via digital input. GROS : Tare with key, via serial interface or via digital input only at gross. PT : Preset tare and tare with key or via serial interface. PT-G : Preset tare and tare with key or via serial interface at gross.</p>
[232 AUTOT : NO]	<p>Auto taring. <i>Page 34</i></p> <p>NO : Disabled. YES : Auto tare, if the gross load is bigger than MIN TARE and stable.</p>
[233 AUTO CLR : NO]	<p>Auto clear. <i>Page 34</i></p> <p>NO : Disabled. YES : Auto clear, if the gross load is lower than 10d.</p>
[234 PWRTARE : NO]	<p>Restore Tare at power on</p> <p>NO : Disabled. YES : Tare value is saved at power off and the indication is start in NET after switch on the instrument.</p>
[235 FILTER : MEDI]	<p>Adaptive digital filter.</p> <p>NO : Disable. Fastest weighing; but the most sensitive to environmental vibrations. VLOW : Very low filtering LOW : Low filter MEDI : Medium filter HIGH : High filter VHIG : Very high filter. Slowest and the most stable weighing.</p>
[236 LANGUAGE : ENG]	<p>User language.</p> <p>ENG : English DEU : Deutsch FRA : Français ITA : Italiano ESP : Espagnol TUR : Türkçe</p>
[237 NET SIGN : NO]	<p>Net sign correction at displaying and printing.</p> <p>NO : Disabled. YES : Enabled.</p>







[24- KEY FUNCTION]	PROGRAMMING OF KEY FUNCTIONS Press  key or  key again to enter this menu. Or press  key enter the next sub-block.	
[241 "F1" KEY : SMRT]	The function of * key. NO : Disable SET : Setpoint/ SmartAPP limit value entry SMRT : Start / Stop SmartAPP GTOT : Grand total RPRN : Reprint DYNA : Dynamic weighing start PEAK : PEAK Displaying at basic weighing HOLD : HOLD Displaying at basic weighing LAST : Last measurement displaying UNIT : Unit change	
[242 "F2" KEY : RPRN]	The function of  key. NO : Disable SET : Setpoint/ SmartAPP limit value entry SMRT : Start / Stop SmartAPP GTOT : Grand total RPRN : Reprint DYNA : Dynamic weighing start PEAK : PEAK Displaying at basic weighing HOLD : HOLD Displaying at basic weighing LAST : Last measurement displaying UNIT : Unit change	
[243 ID2 KEY : ID2]	The function of ID2 key. NO : Disable ID2 : ID2 key SET : Setpoint/ SmartAPP limit value entry SMRT : Start / Stop SmartAPP GTOT : Grand total RPRN : Reprint DYNA : Dynamic weighing start PEAK : PEAK Displaying at basic weighing HOLD : HOLD Displaying at basic weighing LAST : Last measurement displaying UNIT : Unit change	
[25- ENTRIES]	ENTRIES Press  key or  key again to enter this menu. Or press  key to enter the next sub-block.	
[251 DATE : DMY]	Date format <i>Page 37</i> DMY : DD.MM.YYYY MDY : MM.DD.YYYY YMD : YYYY.MM.DD	
[252 DATE SET :]	Date setting <i>Page 37</i> XX.XX.XX	
[253 TIME SET :]	Time adjust <i>Page 37</i> HH:MM	
[254 CN :]	Consecutive number <i>Page 115</i> 1...65535	
[255 S. NAME : SCAL]	Scale name.	




	Maximum 16 characters. Default is SCALE-1
[26- PASSWORDS]	<p>PASSWORD ENTRIES</p> <p>Press  key or  key again to enter this menu.</p> <p>Press  key to return to beginning of the sub-block or press  key to enter the next main-block.</p>
[261 KEY LOCK : 11]	Key lock password. <i>Page 13</i> To lock keys and to erase grand total. NEW
[262 USER : 1111]	Set up password. <i>Page 13</i> NEW - CONFIRM
[263 SERVICE : 1111]	Set up password. <i>Page 13</i> NEW - CONFIRM





[3-- APPLICATION] Application Block

[3-- APPLICATION]	<p>APPLICATION RELATED PARAMETERS MAIN BLOCK</p> <p>Press  key sequentially to access this main block, or press  key or  key to enter configuration parameters, or press  key to enter the next block, or press  key to exit from programming.</p>
[31- SMARTAPP]	<p>SMARTAPP OPERATION SET UP</p> <p>Press  key or  key again to enter this menu. Or press  key to enter the next sub-block.</p>
[311 APPLICA : NO]	SmartAPP application. <i>Page 79</i> NO : SmartAPP function is disabled. CHEC : Weight display and SmartAPP will operate as check weighing, <i>Page 84</i> CLAS : Weight display and SmartAPP will operate as classifying <i>Page 80</i> FILL : Weight display and SmartAPP will operate as filling, <i>Page 87</i> PEAK : Weight display and SmartAPP will operate as peak holding, <i>Page 91</i>
[312 LIMITS : TOL]	SmartAPP limits entry type. <i>Page 81, 85, 88</i> VAL : The weight value entry TOL : Absolute deviations from Target % : Percent deviation (relative deviation) from target value.
[313 INFODIS : NO]	Information display at SmartAPP operation NO : No any application ID1T : message ID2T : ID1 data and Target ID2 data and Target
[314 DISPLAY : ALL]	SmartAPP displaying. <i>Page 79</i>

	NO : SmartAPP displaying is disabled. BAR : Only bar graph operates. COLO : Only display color warns the operator. ALL : Bar graph and display color functions are activated.
[315 PEAK DIS : ALL]	Peak displaying at peak hold. <i>Page 91</i> PEAK : Display peaks. LAST : Display the final peak. ALL : Display all peaks .
[316 COLORS : RAAY]	Display color change at SmartAPP operation. RAAY : Red, amber, green, amber, yellow YAAR : Yellow, amber, green, amber, red RBAY : Red, blue, green, amber, yellow YABR : Yellow, amber, green, blue, red
[317 CHANGE : STAB]	The display color changing at classifying and checkweighing. IMME : Immediately change even scale is not stable. STAB : Change if the scale is stable.
[318 ACOUSTI : OKAY]	Acoustic warning NO : Disabled OKAY : One beep if okay OVER : One beep if over CROS : One beep at every limit crossing.
[32- SMART USAGE]	SMARTAPP USAGE Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.
[321 START : AUTO]	Start MANU : SmartAPP starts by pressing key or serial port or digital input. AUTO : SmartAPP starts if the load is heavier than empty range. SAUT : SmartAPP starts automatically while the digital input-1 is active. PORT : SmartAPP starts only with serial port command or with digital input.
[322 FILLING : GROS]	Filling type. GROS : Gross filling. NET : Net filling after taring the scale automatically.
[323 TAREDELA : 0.7]	Taring delay at filling. X.X seconds Automatic taring is done after this delay in net filling.
[324 TOTAL : HORI]	Totalization type <i>Page 36</i> NO : Disabled HORI : Horizontal totalization VERT : Vertical totalization
[325 GT ERASE : MRC]	Grand total erase <i>Page 95</i> MRC : Erase by pressing MRC key and Enter keys during GT displaying. PASS : Erase after entering keylock password.

[326 OUTPUTS : STAB]	Output changing at basic weighing, classifying and checkweighing. (Appears if the option is installed) IMME : Immediately change even scale is not stable. STAB : Change if the scale is stable.
[33- DYNAMIC]	WEIGHING OF UNSTABLE LOADS Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.
[331 OPERATE : NO]	Operation type <i>Page 35</i> NO : Disable KEY : Dynamic weighing starts after repressing the key if W > 50e. SAUT : Dynamic weighing starts automatically if W > 50e. CONT : Continuous dynamic weighing. MINW : Dynamic weighing starts if W > Min Weight. CMIN : Continuous dynamic weighing starts if W > Min Weight.
[332 FILTER : 3.0]	Dynamic filtering time. X.X seconds.
[34- KEY LOCK]	KEY LOCK Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.
[341 UPKEY : USE]	Setpoint key locking USE : Not locked LOCK : Locked
[342 DOWN : USE]	Memory key locking USE : Not locked LOCK : Locked
[343 ENTER : USE]	Enter key locking USE : Not locked LOCK : Locked
[344 * KEY : USE]	* key locking USE : Not locked LOCK : Locked
[345 ID : USE]	ID1 and ID2 keys locking USE : Not locked LOCK : Locked
[346 M+ MRC : USE]	M+ key locking USE : Not locked LOCK : Locked
[347 TARE : USE]	Tare key locking USE : Not locked LOCK : Locked
[348 ZEROING : USE]	Zeroing key locking

	USE : Not locked LOCK : Locked
[349 Δ KEY : USE]	Δ key locking USE : Not locked LOCK : Locked
[34A UNIT : USE]	Unit key locking USE : Not locked LOCK : Locked
[34B G/N KEY : USE]	G/N key locking USE : Not locked LOCK : Locked
[34C PT KEY : USE]	Preset tare key locking USE : Not locked LOCK : Locked
[34D HIGH : USE]	High resolution key locking USE : Not locked LOCK : Locked
[34E CLEAR : USE]	Clear key locking USE : Not locked LOCK : Locked
[35- DIG INPUTS]	DIGITAL INPUTS (appears if option installed) Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.
351 INPUT1 : NO]	Input 1 <i>Page 98,</i> NO : Not used ZERO : Zeroing TARE : Taring CLR : Clear PRNT : Print LOCK : Key lock DYST : Dynamic weighing start DYRE : Dynamic weighing reset PEAK : Basic peak hold at basic weighing HOLD : Hold at basic weighing FBUS : Remote Input over fieldbus or BSI command.
[352 INPUT2 : NO]	Input 2 <i>Page 98,</i> :
[353 INPUT3 : NO]	Input 3 <i>Page 98,</i> :
[354 INPUT4 : NO]	Input 4 <i>Page 98,</i> :









<p>[37- IDENTIFICATI]</p>	<p>IDENTIFICATION DATA</p> <p>Press  key or  key again to enter this menu.</p> <p>Press  key to return to beginning of the sub-block or press  key to enter the next main block.</p>
<p>[371 NAMEDIS : TEMP]</p>	<p>Identification name is displaying after pressing ID key.</p> <p>NO : Identification name is not displayed.</p> <p>YES : Identification name is displayed until pressing enter or any alphanumeric key.</p> <p>TEMP : ID data is displayed after announcing identification name 2 seconds.</p>
<p>[372 ID1 NAME : ID 1]</p>	<p>Identification name entry of ID1 key <i>Page 41</i></p> <p>Maximum 16 characters. Default is ID 1.</p>
<p>[373 ID1 LINK : NO]</p>	<p>Linked memories to ID1 memory <i>Page 78</i></p> <p>NO : No any linked memory.</p> <p>SET : Set memory</p> <p>PT : PT memory.</p> <p>SP : SET and PT memories.</p>
<p>[374 ID2 NAME : ID 2]</p>	<p>Identification name entry of ID2 key <i>Page 41</i></p> <p>Maximum 16 characters. Default is ID2.</p>
<p>[375 ID2 LINK : NO]</p>	<p>Linked memories to ID2 memory <i>Page 78</i></p> <p>NO : No any linked memory.</p> <p>SET : Set memory</p> <p>PT : PT memory.</p> <p>SP : SET and PT memories.</p>





[5-- SCALE] Scale Block









This block is related to the measurement related parameters, which describe the use of the scale. The most important is **parameter 511**, which limits the use of the parameters in main blocks 5, 6 and 8. The selections of this parameter are.

IND	Industrial weighing	Selections of parameters at set up and calibration are free for industrial usage of the instrument.
INDG	Industrial weighing only gross	Auto zeroing, taring and power on zero are disabled. (Recommended for tank /silo weighing in gross.)
INDN	Industrial weighing net (taring can be enabled)	Auto zeroing and power on zero are disabled. (Recommended for tank /silo weighing in gross.)
OIML	Approved scale according to OIML	Metrology related parameters are restricted to limits of OIML R76 and EU type approval of the instrument.
















After setting **parameter 511**, even you set any parameter out of the accepted range of selection of par 511, it is saved in the acceptable limit. For example, if taring is activated at INDG selection, it will be disabled while exiting from set up. For approved scales, set the parameters in main blocks 5, 6 and 8 perform calibration carefully due to sealing of the scale in legal usage.

[5-- SCALE]		SCALE RELATED PARAMETERS MAIN BLOCK Press  key sequentially to access this main block, or press  key or  key to enter configuration parameters, or press  key to enter the next block, or press  key to exit from programming.
[51- SET UP]		SCALE SET UP Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.
[511 APROVAL : IND]	M	Approval IND : Industrial. All parameters can be freely selected. INDG : Industrial weighing of tank, hopper or silo in gross. (Taring, AZTrack and Power on Zero are disabled) INDN : Industrial weighing in Net of tank, hopper or silo. (disabled AZT and Power on Zero, enabled Tare) OIML : OIML approved scale.
[512 HIGHRES : TOGG]	M	High resolution <i>Page 35,</i> TEMP : Temporary indication with key. TOGG : Toggle. Start and end high resolution by pressing key in sequence. ALWA : Always high resolution
[513 PWRZERO : NO]	M	Power on zero. NO : Disable. 2% : ± 2% 2%LK : ± 2%, [POWER ON ZERO ERR] prompt cannot be erased. Call service. 10% : ± %10 15-5 : + %15, - %5 20% : ± %20













[514 ZEROING : 50%]	M	Zeroing range with key. NO : Disable. 2% : ± 2% 3% : ± 3% 20% : ± 20% 50% : ± 50%	Page 33
[515 AZTRACK : 0.5d]	M	Automatic zero tracking. NO : Disable. 0.3d : ± 0,3d 0.5d : ± 0,5d 1d : ± 1d 2d : ± 2d 3d : ± 3d	Page 33
[516 STABLE : 0.5d]	M	Stability detection range. NO : Disable. 0.3d : ± 0,3d 0.5d : ± 0,5d 1d : ± 1d 2d : ± 2d 3d : ± 3d 4d : ± 4d	
[517 STBTIME : 0.7]		Stability time. The scale is accepted as a stable to process, if the scale is stable during this time. 0.1.... 9.9 seconds.	
[518 MIN TARE : 20]		Minimum tare for automatic taring Taring can be done if loading is heavier than MIN TARE.	
[519 MINWEIGT : 20]		Minimum weight to produce printout The printout is produced if the load is heavier than MIN WEIGHT.	
[51A TILT : NO]	M	Tilt switch to prevent wrong weighing results in mobile scales. (Digital Input-4) NO : Not used. OPEN : Normally open contact. CLOS : Normally closed contact.	
52- BUILD]		SCALE BUILD Press  key or  key again to enter this menu. Press  key to enter the next sub-block or press  key to go to the next main block.	
[521 UNIT : KG]	M	The scale unit Select NO, g, kg, t, lb, klb, N or kN.	Page 35
[522 RANGE : SING]	M	Scale range SING : Single Range 2MR : 2 x Multi Range 3MR : 3 x Multi Range 2MI : 2 x Multi Interval 3MI : 3 x Multi Interval	

[523 MAX :]	M	Scale capacity Max and division (d) MAX1/d1 MAX2/d2 MAX3/d3	Enter scale capacity and division after press  key. Capacities and divisions of MR and MI scales are entered as Max1, d1, Max2, d2, Max3, d3.
[524 OVER : 9d]	M	Limit of Indication NO : Over indication after Max 1d : 1 division more than Max 5d : 5 division more than Max 9d : 9 divisions more than Max 2% : 2% more than Max 5% : 5% more than Max	
[525 TARETYPE : SUB]	M	Tare type. SUB : Subtractive tare. Taring reduces the maximum net. ADD : Additive tare. Taring is limited to Max Tare and Net weighing is done up to Max.	
[526 MAXTARE : 0.0]	M	Maximum tare at additive tare. Enter the maximum tare of the scale which is written on the marking label as; T = + XXXX.X at additive tare Default is 0.0 which means no limit.	
53- DLC SETUP]		DIGITAL LOAD CELL SETUP (Only FT-112D) Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.	
[532 QUANTITY : 01]	M	Quantity of digital load cell Enter the quantity of DLC used in the scale. The quantity can be entered between 1 and 30.	
[533 ADDRESSING]	M	Addressing of digital load cells Enter serial number after press  key.	
[54- SHIFT ADJUST]		SHIFT / ECCENTRICITY ADJUSTMENT (Only FT-112D) Press  key or  key again to enter this menu. Press  key to return to beginning of the sub-block or press  key to enter the next main-block.	
[541 METHOD : CELL]	M	Adjustment method CELL : Individual load cell shift adjust PAIR : Sectional pair shift adjustment	
[542 AUTO ADJUST]	M	Automatic Eccentricity Adjustment The eccentricity correction of scale is performed automatically	
[543 MANUAL ADJUS]	M	Manual Adjustment The eccentricity correction of scale is performed manually.	
[544 SET TO 1 : NO]	M	Temporarily set shift constants to 1 NO : Normal operation (entered shift constants are used). YES : Test mode (shift constants are equal to 1).	












[6-- CALB / ADJUST] Calibration and Adjustment Block








[6-- CALIB / ADJUST]	<p>SCALE ZERO AND SPAN SETTING MAIN BLOCK Press  key sequentially to access this main block, or press  key or  key to enter configuration parameters, or press  key to go to the next block, or press  key to exit from programming.</p>
[61- CALIBRATION]	<p>CALIBRATION Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.</p>
[611 TEST WEIGHT]	M Scale calibration with test weight
[612 LINEARIZATIO]	M Multipoint scale calibration to increase linearization
[613 ELECTRONIC]	M eCal electronic calibration without test weight
[62- ADJUSTMENT]	<p>ADJUSTMENTS Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.</p>
[621 ZERO ADJUSTM]	M Zero adjustment
[622 SPAN ADJUSTM]	M Span adjustment
[623 S UNDERLOAD]	M Span adjustment of loaded scale Span adjustment under load Span adjustment with temporary zeroing
[624 GRAVITY CAL]	M Gravity acceleration of the place of the calibration.
[625 GRAVITY USAG]	M Gravity acceleration of the place of the usage.
[63- COEFFICIENTS]	<p>CALIBRATION COEFICIENTS Press  key or  key again to enter this menu. Press  key to go to beginning of the sub-block or press  key to go to the next main block.</p>
[631 LOAD COEFFIC]	M The load weight used at the calibration is indicated here.
[632 ZERO COEFFIC]	M This coefficient is determined the zero point of the scale.
[633 GAIN COEFFIC]	M This coefficient is related with the gain factor of the scale.

[8-- METROLOGY] Metrology Block

<p>[8-- METROLOGY]</p>	<p>METROLOGY MAIN BLOCK Press  key sequentially to access this main block, or press  key or  key to enter configuration parameters, or press  key to go to the next block, or press  key to exit from programming.</p>
<p>[81- ALIBI MEMORY]</p>	<p>ALIBI MEMORY Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.</p>
<p>[811 ALIBI : NO]</p>	<p>M Alibi memory <i>Page 38</i> NO : Disable YES : Enable</p>
<p>[812 PORT : PRNT]</p>	<p>Select the Alibi data transfer port. PRNT : to the printer port. R232 : to the RS232C. USB : to the USB ETH : to the Ethernet TCP/IP.</p>
<p>[813 ACCESS : NUM]</p>	<p>Access to the Alibi memory record <i>Page 39</i> NUM : Search by Alibi number DATE : Search by date NET : Search by net value (absolute) GROS : Search by gross value TARE : Search by tare value CN : Search by Consecutive value</p>
<p>[814 TRANSFER : NO]</p>	<p>Transfer Alibi memory records <i>Page 39</i> NO : No ALL : Transfer alibi memory record to the printer port</p>
<p>[815 ALIBI ABOUT]</p>	<p>Transfer alibi memory information. <i>Page 39</i></p>
<p>[816 FORMAT : NO]</p>	<p>M Format alibi memory SD card. <i>Page 40</i> NO : No YES : Start formatting alibi SD card. <i>Attention : Only authorized person !!!</i></p>
<p>[82- INFORMATION]</p>	<p>METROLOGIC INFORMATION Press  key or  key again to enter this menu. Press  key to go to beginning of the sub-block or press  key to go to the next main block.</p>
<p>[821 CAL COUNTER]</p>	<p>This counter announces interfering quantity to the instrument with service password when calibration switch enabled. Count number increases at exit from set-up mode if service password is used and calibration is enabled to enter set-up mode.</p>
<p>[822 CONFIG COUNT]</p>	<p>This non-resettable and protected counter announces interfering quantity to the instrument. Count number increases at every exit from set-up mode.</p>
<p>[823 NEXT VERIFIC]</p>	<p>Date of the next verification</p>

[9-- DIAGNOSTIC] Diagnostic Block

[9-- DIAGNOSTIC]	<p>DIAGNOSTIC MAIN BLOCK Press  key sequentially to access this main block, or press  key or  key to enter configuration parameters, or press  key to go to the next block, or press  key to exit from programming.</p>
[91- HARDWARETEST]	<p>HARDWARE TESTING Press  key or  key again to enter this menu. Or press  key to enter the next sub-block.</p>
[911 KEY]	Key testing
[912 RS232]	RS232C serial port testing
[913 RS485]	RS485 serial port testing
[914 RS422]	RS422 serial port testing
[915 USB]	USB port testing
[916 IN / OUT]	Digital Input / Output testing
[917 DISPLAY]	Display testing
[918 LC SIGNAL mV]	Load cell signal measuring in millivolt (FT-112)
[918 DLC COUNTS]	Internal count values of the digital Load cell(s) (only FT-112D)
[919 PRINTER]	Printer testing
[92- HISTORY]	<p>HISTORY Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.</p>
[921 PEAK LOAD]	The last 20 peak loads listed in this parameter.
[922 UNDERLOGS]	The last 20 under errors listed in this parameter.
[923 ERROR LOGS]	The last 20 errors listed in this parameter.
[924 ENTRY LOGS]	The last 20 Service/User entry listed in this parameter.


[97- FIRMWARE]	FIRMWARE INFORMATION Press  key or  key again to enter this menu. Or press  key to go to the next sub-block.	
[971 INSTRUMENT]		XX.XX
[972 OPTION]		XX.XX
[973 UPGRADE]	M	Firmware upgrade Call Flintec service or dealer to upgrade.
[974 DLC BOARD]		XX.XX (only FT-112D)
[99- DEFAULT]	DEFAULT LOADING Press  key or  key again to enter this menu. Press  key to return to beginning of the sub-block or press  key to go to the next main block.	
[993 PARAMET DEF]	M	Load parameter's default (Calibration do not change)
[994 FACTORY DEF]	M	Load factory defaults
[995 DEFAULT ADDR]	M	Load default address to digital load cell. (only FT-112D) The default address feature solves the problem and provides access to the load cell functions even if its address and its serial number are not known. <i>WARNING: The DLC must be disconnected from the network and connect as single.</i>

5.5 Calibration




Warning: You cannot change the legally related parameter values and calibration after sealing the instrument in legal usage. Be sure the proper adjustments you done before sealing the scale.

Scale definition

Before the calibration can be performed the capacity and resolution of the scale must be defined.





Press  key at the [523 MAX / d] prompt and set the required capacity and resolution of the scale. Then continue with the following:

Calibration involves emptying the scale then placing a known test weight on an empty platform and allowing FT-112 Panel to capture values for zero and span. Calibration is performed as;

1. Press  key at the [611 TEST WEIGHT] prompt to start the calibration.
2. At the [UNLOAD THE PAN] prompt, remove any weight on the platform, then press  key.
3. The terminal automatically starts to capture zero and the [WAIT] message appears during zero adjustment.
4. The test weight value will be used for the calibration is shown on the display as [LOAD THE SCALE] [XXXXXX] after zero adjustment. Enter the test weight value via numerical keys. A minimum test load requirement is 20% of scale capacity for accurate calibration. FLINTEC recommends test load between 50% to 75% of the capacity.
5. Place the test weight on the scale.
6. Press  key to start span calibration. [WAIT] message will shown on the display 10 seconds while span calibration is being performed.

5.5.1 Linearity Correction



Multipoint calibration in this parameter improves the scale performance.

1. Press  key at the [612 LINEARIZATIO] prompt to start the calibration.
2. At the [UNLOAD THE PAN] prompt, remove any weight on the platform, then press  key.
3. The terminal automatically starts to capture zero and the [WAIT] message appears during zero adjustment.
4. At the [LOAD 1] [XXXXXX] prompt, the test weight value will be used for the first step calibration is shown on the display. A test load requirement is between 35% to 60% of capacity. Load the scale and enter the test weight value via numerical keys.
5. Place the test weights or another practical weight on the scale.
6. Press  key to start span calibration. [WAIT] message will shown on the display 10 seconds while the first span calibration is being performed.
7. At the [LOAD 2] [XXXXXX] prompt, the test weight value will be used for the second step calibration is shown on the display. Place test weight on the platform at least 90% of scale capacity, preferable at scale capacity. Enter the weight value by numerical keys.
8. Press  to start second step span calibration. [WAIT] message will shown on the display 10 seconds while the span calibration is being performed.



5.5.2 Zero and Span Adjustments

In this sub-block you can perform zero adjustment or span adjustment without performing full calibration. Do not perform span calibration if eCal electronic calibration.

Zero Adjustment




1. Press  key at the [621 ZERO ADJUSTM] prompt to start the zero adjustment.
2. At the [UNLOAD THE PAN] prompt, remove any weight on the platform, then press  key.
3. The terminal automatically starts to capture zero and the [WAIT] message appears during zero adjustment.

Span Adjustment

1. Press  key at the [622 SPAN ADJUSTM] prompt to start the span adjustment.
2. At the [LOAD THE SCALE] [XXXXXX] prompt, the test weight value will be used for the calibration shown on the display. Enter the test weight value via numerical keys. A minimum test load requirement is 20% of scale capacity for accurate calibration. FLINTEC recommends test load between 50% to 75% of the capacity.
3. Place the test weights on the scale.
4. Press  to start span calibration. [WAIT] message will shown on the display 10 seconds during span calibration.

Span Adjustment Under Load

This parameter is being used to perform span adjustment of a scale without lifting the load off. This operation is especially used for span adjustment of a tank / silo which are loaded. You can make span adjustment without emptying the tank.

1. Press  key at the [623 S UNDERLOAD] prompt to start the span adjustment under load.
2. [P.ZERO] prompt appears on the display to indicate the scale load will be determined as temporary zero.
3. Press  key and the display will show [WAIT] message during temporary zero adjustment.
4. At the [LOAD THE SCALE] [XXXXXX] prompt, the test weight value will be used for the calibration is shown on the display. Enter the test weight value via numerical keys. A minimum test load requirement is 20% of scale capacity for accurate calibration. FLINTEC recommends test load between 50% to 75% of the capacity. Sum of the preload of the scale and test weight must be less than capacity.
5. Place the test weights on the scale.
6. Press  to start span calibration. [WAIT] message will shown on the display 10 seconds during span calibration.
7. Zero adjustment is recommended after emptying the scale.

5.5.3 eCal Electronic Calibration

IMPORTANT NOTE: The eCal electronic calibration is based on the zero adjustment by entering the dead load value or automatic zero adjustment and span adjustment by entering the load cell data.

WARNING: If the primary unit is not kg, the selected unit should be saved by exit from set-up and then perform e-Cal.

1. Full calibration cancels the eCal performed before.
2. Span adjustment is cancels the eCal performed before.
3. Gravity adjustment cannot be done after eCal.
4. "Span adjustment under load " cannot be done after eCal.
5. Shift adjustment cancelled the eCal performed before.


This parameter lets you to perform calibration without using any test weights. A/D coefficients of the indicator are adjusted in production for increasing eCal accuracy. The calibration coefficients are calculated by scale capacity, total load cell capacity, load cell full scale output and estimated dead load. If the conditions are convenient for zero calibration, you may perform automatic zero adjustment instead of entering estimated preload.

[TOTAL LC CAPACIT] [XXXXXX]

Enter total load cell capacity via numerical keys and press  key to go to the next step.

Example: If the weighing system has 4 pcs 1000 kg load cell, enter 4000.



[AVERAGE LC OUT] [XXXXXX]



Enter load cell output in mV/V via numerical keys. If the weighing system has more than one load cell, calculate the mean value of load cells outputs mV/V indicated on the certificates of the load cells. Press  key to go to the next step.

Example: If load cell outputs are LC1: 2.0010, LC2: 1.9998, LC3:1.9986 and LC4:2.0002, the mean value will be:

Mean of LC outputs = (2.0010 + 1.9998 + 1.9986 + 2.0002) ÷ 4 = 1.9999 mV/V.


[ZERO ADJUST]

If the scale is empty and you want to make automatic zero adjustment instead of entering estimated dead load (see next step), press  key and [UNLOAD THE PAN] appears. Then press  key to start zero calibration after unloading the scale. The display will show [WAIT] message during zero adjustment. The scale must be unloaded and stable. Approximately 10 seconds later electronic calibration will be performed.


If the scale is not empty or you prefer to enter estimated preload value, press the  key before pressing the  key.

[ESTIM DEAD LOAD] [XXXXXX]

Enter the dead load value of the weighing system in current unit by using numerical keys.

Press the  key to go to the next step.

Notes:





Dead load correction: You may change the dead load value after testing the scale and adding the displayed gross weight value of unloaded scale to the dead load value. Do not press  key after switch on the instrument after calibration, and the power on zero and automatic zero tracking should be disabled to determine the dead load error.

Dead load value is cancelled after automatic zero adjustment.

5.5.4 Gravity adjustment

WARNING: This parameter should *ONLY* be used at the scale that will be initially verified in two stages by gravity adjustment in legal metrological applications.

The gravity acceleration values of the place of the calibration and of the place of the usage are entered in this parameter.

1. Press  key to access this parameter.
2. [624 GRAVITY CAL : 9.80255] prompt shown. Enter the gravity acceleration value of the calibration place. Confirm with  key.
3. [625 GRAVITY USAG : 9.80255] prompt shown after pressing  key. Enter the gravity acceleration value of the place of the usage.
4. Confirm with  key.

5.5.5 Calibration coefficients

Calibration coefficients are calculated after calibration and saved into the memory for use until next calibration. Note these coefficients to use them in case of calibration lost. Changing them slightly improves the scale accuracy without recalibration. Entering these values to another indicator may cause slightly reducing the weighing accuracy due to offset differences between two analogue digital circuits.

6 DIGITAL LOAD CELL (DLC)

6.1 Addressing Digital Load cells

IMPORTANT NOTE: You can connect all RC3D load cells to the terminal and address them later.

The following diagram shows the recommended load cell addressing principle. Remember, if pair shift adjustment is selected, 1 and 2, 3 and 4 etc. will be sectional pairs.



















Figure 6.1 - The addressing principle of the digital load cells.

Addressing of RC3D digital load cells

1. Press  key at the [533 ADDRESSING] prompt to start the addressing.
2. The message [WAIT] appears for a short time and then [DLC NUMBER :01] message appears. Here 01 is the address of the DLC.
3. Press  key to enter the serial number of the DLC.
4. After the [SERIAL:] prompt, type the serial number value via numerical keys.
5. Press  key to start addressing the digital load cell. [ADDRESSING DLC] message will shown on the display 10 seconds while addressing is being performed.
6. The following DLC number appears on the display. You may press  key to enter the serial number and you may repeat from item 4 until all DLCs have been addressed.
7. [532 QUANTITY :XY] message appears after addressing all load cells.
8. Press  key to access to Shift adjustment block or press  key until [SAVE : YES] prompt appears on the display and press  key to save the changes into the memory.

Manually Addressing an Individual RC3D digital load cell

The manual addressing of load cell is done to change any load cell or to change the instrument without performing shift adjustment and calibration.

1. Press  key at the [533 ADDRESSING] prompt to start the addressing.
2. The message [WAIT] appears for a short time and then [DLC NUMBER :01] message appears to indicate load cell address.
3. Press  key until appearing the address which the new load cell will install.
4. Connect the new load cell to junction box.
5. Press  key to start address the load cell.
6. Enter the serial number of the load cell. Press  key for addressing the load cell.
7. After the following DLC number has appeared on the display, press  key. [532 QUANTITY :XY] message appears.
8. Press  key to access to Shift adjustment block or press  key until [SAVE : YES] prompt shown on the display and press  key to save the changes into the memory.





Shift adjustment method

The shift adjustment is done to eliminate weight reading differences at placing the load on different positions on the platform. The calibration is required after shift adjustment. Each load cell or each sectional pair should be loaded for eccentricity adjustment. Individual shift adjustment is used to eliminate errors in installations that have excessive eccentricity errors. Typical application of sectional pairs is rolling loads on the platform like truck scales. Sectional pairs adjustment is easier and faster.

Automatic Shift Adjustment

IMPORTANT NOTE: This adjustment must be performed before calibration. Load the scale few times before performing automatic shift adjustment.







Small mismatches in mechanical and electronic gain of the load sensing paths can cause the same test weight to produce slightly different readings, depending on the location of the test weight on the scale. To eliminate these eccentricity errors, shift adjustment is performed as:

1. Press  key at the [542 AUTO ADJUST] prompt to start the shift adjustment.
2. At the [ZERO CALIBRATION] prompt, press  key to go to next step.
3. At [UNLOAD THE PAN] prompt, remove any weight on the platform, then press  key.
4. The terminal automatically starts to capture zero and the [WAIT] message indicating the operation is in progress.
5. After the [LOAD DLC NO : 01] or [LOAD PAIR NO : 01] prompt, place the weight of at least 10% of the DLC capacity as close as possible to the independent load cell or sectional pair 01. Press  key.
6. The terminal automatically starts to capture the values from DLCs and the [WAIT] message indicating the operation is in progress.
7. The following load cell address or pairs number appears on the display and you may repeat from item 5 until all DLCs have been adjusted.
8. After end of adjustment the following sub-block appears.

Manual Shift Adjustment




IMPORTANT NOTE: The shift adjustment must be performed before calibration.

Manual shift adjustment is done to improve the small shift errors manually, to enter shift coefficients of load cells after changing the instrument which eliminates to perform automatic shift adjustment.




1. Press  key at the [543 MANUALADJUS] prompt to start the manual shift adjustment.
2. At the [DLC COEFF :01] and [1.0000] prompts, enter the coefficient by pressing the numerical keys and press  key to go to following item.
3. After entering the value of the last coefficient press  key to check values again or press  key to exit.
4. Press  key until [SAVE : YES] prompt shown on the display. Press  key to save the changes into the memory.

Setting Shift Coefficients of all Load cells to 1

Setting all coefficients to 1 temporary might be needed to give service to the scale without losing the shift coefficients.

1. Press  key at the [544 SET TO 1 : NO] prompt to adjust the parameter.
2. It will be [544 SET TO 1 : YES], press  key until [SAVE : YES] prompt shown on the display.
3. Press  key to save the changes into the memory.

Do not forget to reload coefficients after testing the scale as:

1. Press  key at the [544 SET TO 1 : YES] prompt to adjust the parameter.
2. It will be [544 SET TO 1 : NO], press  key until [SAVE : YES] prompt shown on the display.
3. Press  key to save the changes into the memory.

7 IDENTIFICATIONS

APPLICATION: To enter identification data to the instrument to printout or to transfer the data together with identification data.

RELATED PARAMETERS: Sub-block 37- .



FT-112 Panel weighing indicator has 2 identification keys ID1 and ID2 positioned under the display for storing identification data. Each identification key has an alphanumeric identification name and data. The identification data can be saved into the ID1 and ID2 memories, each has 500 pieces 32-character identification data record size.

The identification data can be entered via keys or selected from ID memory to transfer together with the weight value. The length of identification name can be maximum 16 characters and the length of identification data can be up to 32 characters. ID names are entered in the programming mode as a header of ID.







ID data in the memory can be linked to the PT, SET and/or APW memory records. This feature gives advantage to select the related records automatically by selecting ID from memory. For example, if SET memory is linked to ID1 memory, the 123th record in the SET memory is loaded automatically after loading 123th record from ID1 memory.

The descriptions below are given for ID1 key. The usage of ID2 is the same.





Enter Identification data via alphanumeric keys

1. Press the identification key .
2. Enter the identification data up to 32 digits via alphanumeric keys.
3. Confirm with  key.

Record Identification data into the ID memory

1. Press  key for more than 2 seconds in weighing operation. The [MEMORY] prompt will be displayed.
2. Press  key to enter ID1 memory. The last used memory code appears as [ID1: 123].
3. Enter the memory code numerically and press  key.
4. The ID code and identification data appears on the display.
5. Enter the new alphanumeric ID data up to 32 digits and press  key.
6. The following memory code shown on the display to go on the ID data entry. You may press  key to enter ID data into the following memory or you may repeat the procedure from item 3 to enter the new memory record number.
7. To return the operation press  key.










Select Identification data from ID memory

1. Press the identification key . The ID1 data displayed.
2. Press  key for more than 2 seconds to enter the memory.
3. After the last used code shown [ID1 :123], enter the ID memory code of the item.
4. Press  key to select the identification data, which is displayed for a while. The instrument returns to the operation mode after loading the identification data. If there is any linked memory to the ID memory, the linked memories are selected automatically.
5. Or press  key to return without any select.





Data Entry to the linked memories together with ID memory

You may enter data into the related memories together with data entry to the items from ID memories for easy use as;

For example, if ID1 is interrelated with SET and PT memories by parameter 373, the data entry can be done to the item 111 as described below.

1. Press  key for more than 2 seconds in weighing operation. The [MEMORY] prompt will be displayed.
2. Press  key to enter ID1 memory. [ID1: 001] message appears. The number on the right is the memory code.
3. Enter the code numerically (for example 111) or use  or  keys to navigate in the ID memory.
4. The Identification data in the memory appears on the display after pressing  key. Enter the new alphanumeric ID data up to 32 digits and press  key.
5. The limit values of the item appears [SET 111-SP1] [0.0 kg] on the display. Enter the limit values in sequence.
6. The specific tare of item appears on the display [PT 111:] [0.0 kg]. Enter the new PT value and press  key.
7. The following memory code appears [ID1 112:].
8. Press  key to go on entry or press  key to exit.

Select data from linked memories

1. Press the identification key . The ID1 data appears
2. Press  key to go into the memory.
3. After the last used code appeared [ID1 :123], enter the ID memory code of the item.
4. Press  key to select the identification data and link data to ID1, which are displayed in sequence. The instrument returns to the operation mode after loading the selected item.
5. Or press  key to return without any select.

8 SMARTAPP

APPLICATIONS: Checkweighing, classifying, filling and peak hold.

RELATED PARAMETERS: Sub-blocks 31- and 32-. Parameters 241, 242 or 243.

SmartAPP is a special function, which helps the operator to follow the weighing results on the analog bar and guides the operator by changing the display color in the application. The SmartAPP operation can be programmed for weighing applications: filling, classifying, checkweighing or peak hold.

At SmartAPP operation.

1. The display background color changes to facilitate the usage. For example, the background color changes automatically as red, green, or yellow to indicate too light, in tolerance or too heavy at classifying.
2. The operator can follow the product weight deviation from target on the bar graph.
3. The digital inputs and outputs are set to the programmed application automatically. You can control lambs, flaps, or valves with SmartAPP digital output signals. Refer to **page 96**.

Warning the operator with display colour

At SmartAPP operation, this feature offers the possibility to better recognize the weight ranges by changing the display colours. This feature can help to eliminate operator's mistakes in production or packing line. Refer to **page 58**.

Acoustic warning

At SmartAPP operation, the weighing indicator warns you acoustically. You may select the acoustic warning style in the setup of the instrument. Refer to **page 58**.

Digital inputs and outputs

If one of the SmartAPP applications is selected, digital inputs and outputs are set to the application automatically even they are programmed to the different functions. Digital inputs and outputs may change their status immediately or if the weight is stable. Refer to **page 59**. If there is any non-used port in the application, it can be programmed freely.

9 STANDARD APPLICATIONS

9.1 Classifying

APPLICATION: To evaluate test samples with 5 limits as *too light, light, okay, heavy* or *too heavy*, based on a target weight and specified limit values. The weight display indicates the weight value.

IMPORTANT NOTE: If you need 3 limits instead of 5 limits, enter the same values into two higher limits and into two lower limits as minimum and maximum limits sequentially.

RELATED PARAMETERS: Sub-blocks 31- and 32-. Parameters 241, 242 or 243.

Classifying is used for sorting products into 6 ranges. Classifying can be programmed to start the operation automatically or on demand. The on-demand operation starts by pressing the key or by digital input. Automatic operation starts if the load is heavier than empty range. The scale is unloaded if the weight is in the Empty range.

The classifying can be used at automatic sorting machines for classifying up to 5 ranges, if automatic start or start input features are used.




Figure 9.1 - Timing diagram of automatic classifying operation.












9.1.1 Product Limit values at Classifying

The entry type can be selected as a weight value, deviation from target or percentage of the target, parameter 312. This selection defines the set values' entry names as shown below.











Entry type	Target	Lowest Limit -T2	Low limit -T1	High limit +T1	Highest Limit +T2	Unloaded scale limit
Value	TARGET	-- LOW	-LOW	+HIGH	++HIGH	EMPTY
Deviation	TARGET	-- TOL	-TOL	+TOL	++TOL	EMPTY
Percent %	TARGET	-- TOL	-TOL	+TOL	++TOL	EMPTY

The target (nominal value), low, high and empty range entries should be entered the weight value in unit; Tolerance entries should be entered as deviation from nominal weight in unit or in percentage. The descriptions below are considered the value entry type. Follow the similar way for entry types of deviation or percentage.





The nominal and limits values entry

1. Press the  key.
2. The current target value appears on the display as [TARGET 1250 kg]. Enter the new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
3. The lowest tolerance prompt [--LOW: 1234.6] will show you the current value. Enter new value with numerical keys. Press  key to save it or press  key to return operation without saving.
4. The [-LOW: 1245.6] prompt will show you the current low tolerance. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
5. The [+HIGH: 1255.6] prompt will show you the current high tolerance. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
6. The [++HIGH: 1260.0] prompt will show you the current highest tolerance. Enter new value with numerical keys.
7. The [EMPTY: 100,0] prompt will show you the current empty range of the platform. Enter new value with numerical keys.
8. Press the  key to return the operation after saving the entry or press  key to return operation without saving.

Product record into SET memory

1. Press  key for more than 2 seconds. [MEMORY] prompt appears.
2. Press  key. The last used Set memory code appears [SET :001].
3. Enter the new memory code by pressing the numerical keys and press  key.
4. The target value is shown on the display as [SET 001: TARGET], [1250 kg]. Enter the new target with numerical keys and press the  key.
5. The lowest tolerance prompt [--LOW: 1234.6] appears. Enter new value with numerical keys and press the  key.
6. The low tolerance prompt [-LOW : 1245.6] appears. Enter new value with numerical keys and press the  key.
7. The high tolerance prompt [+HIGH : 1255.6] appears. Enter new value with numerical keys and press the  key.
8. The highest tolerance prompt [++HIGH : 1260.0] appears. Enter new value with numerical keys and press the  key.
9. The [EMPTY : 100,0] prompt appears on the display. Enter new value with numerical keys.
10. Press the  key to go to the following memory after saving it or press  key to return operation without saving.

Select product from SET memory

1. Press  key. The current target value appears on the display as [TARGET: 1250 kg].
2. Press  key for more than 2 seconds to enter Set memory. The last used Set memory code appears on the display as [SET :001].
3. Enter the memory code of the product by pressing the numerical keys and press  key.
4. The selected product limits are loaded for usage after displaying values.
5. Or press  key to exit without selecting the product from memory.

9.1.2 Start and Stop the Classifying

Follow one of the ways described below to start the classifying operation.

1. Function key: If you want to start the classifying operation by pressing key, program one of the function key for smart operation (Refer to parameter 241,242 and 243).
2. Digital input: The digital input-1 can be used to start the classifying operation.
3. Serial interface: Transmit "Start SmartAPP" command via serial interface (Refer to parameter 111, 121, 131, 141 or 151).
4. Automatic classifying operation: If you will use the scale only for classifying and you prefer to activate classifying operation automatically after loading, set the parameter 321 to automatic operation.

To end the classifying operation;

1. Unload the scale or,
2. Disable the operation by pressing the function key, which is programmed as SmartAPP key or,
3. Reset the classifying with digital input-2 or,
4. Send the "Stop SmartAPP" command via serial interface.

9.1.3 SmartAPP at Classifying

The SmartAPP at classifying announces if the load is in tolerances with backlight color, with bar graph on the right side of the display and acoustically. The backlight color changes automatically to indicate the classifying zones, to warn the operator.

The multicolor backlight feature provides operational comfort and reduces operator mistake. The weighing speed increases because of operators' faster and easy perception of colors.



Figure 9.2 - Weight display and toolbar at classifying.

Digital inputs and outputs

If one of the applications is selected, digital inputs and outputs are set according to the selected application requirements automatically even they have been previously set to the different functions.

You can control your scale via these digital inputs and outputs. Non-used inputs and outputs of the application can be programmed freely in the related parameter for any function or as a Remote IO of the PLC to control them over fieldbus.

Inputs / Outputs	Descriptions
Input-1	Start
Input-2	Reset
Input-3	Refer to parameter 353
Input-4	Refer to parameter 354
Output-1	-- Tolerance (very light)
Output-2	- Tolerance (light)
Output-3	OK
Output-4	+ Tolerance (heavy)
Output-5	++ Tolerance (very heavy)

Table 9-1- Digital inputs and outputs of Classifying.

9.2 Checkweighing

APPLICATION: To determine the difference between the target and the actual weight are in tolerance. The weight display indicates the difference value from target. The bar on the left indicates the deviation from target.

RELATED PARAMETERS: Sub-blocks 31- and 32-. Parameters 241, 242 or 243.

Checkweighing operation is used to check if the product weights are in tolerance. The checkweighing can be programmed to start the operation automatically or on demand. The demand operation starts by pressing the function key or by digital input. Automatic operation starts if the load is heavier than Empty range. The scale is accepted unloaded if the weight is in the Empty range.

The checkweighing operation is shown in diagram below;




Figure 9.3 - Timing diagram of checkweighing operation.

9.2.1 Product Limit values at Checkweighing










The entry type can be selected as a weight value, deviation from target or percentage of the target, parameter 312. This selection defines the set values' entry names as shown below.

Entry type	Target	Low limit	High limit	Unloaded scale limit
Value	TARGET	LOW	HIGH	EMPTY
Deviation	TARGET	-TOL	+TOL	EMPTY
Percent %	TARGET	-TOL	+TOL	EMPTY









The target (nominal value), low, high and empty range entries should be entered the weight value in unit; Tolerance entries should be entered as deviation from nominal weight in unit or in percentage.

The descriptions below are considered the value entry type. Follow the similar way for entry types deviation or percentage.





The nominal and limit values entry

1. Press the  key.
2. The current target value appears on the display as [TARGET 1250 kg]. Enter the new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
3. The [LOW : 1245.6] prompt will show the current low tolerance. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
4. The [HIGH : 1255.6] prompt will show the current high tolerance. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
5. The [EMPTY : 100] prompt indicates the current empty range of the platform. Enter new value with numerical keys.
6. Press the  key to return the operation after saving the entry or press  key to return operation without saving.

Product record into SET memory

1. Press  key for more than 2 seconds. [MEMORY] prompt appears.
2. Press  key. The last used Set memory code appears [SET :001].
3. Enter the new memory code by pressing the numerical keys and press  key.
4. The target value appears on the display as [SET 001: TARGET], [1250 kg]. Enter the new target with numerical keys and press the  key.
5. The low tolerance prompt [LOW : 1245.6] appears. Enter new value with numerical keys and press the  key.
6. The high tolerance prompt [HIGH : 1255.6] appears. Enter new value with numerical keys and press the  key.
7. The [EMPTY : 100,0] prompt appears on the display. Enter new value with numerical keys.
8. Press the  key to enter the following memory after saving it or press  key to return operation without saving.

Select product from SET memory

1. Press  key. The current target value appears on the display as [TARGET: 1250 kg].
2. Press  key for more than 2 seconds to enter Set memory. The last used Set memory code appears on the display as [SET :001].
3. Enter the memory code of the product by pressing the numerical keys and press  key.
4. The selected product limits are loaded for usage after displaying values.
5. Or press  key to exit without selecting the product from memory.

9.2.2 Start and Stop the Checkweighing

Follow one of the ways described below to start the checkweighing operation.

1. Function key: If you want to start the checkweighing operation by pressing key, program one of the function key for smart operation (Refer to parameter 241, 242 and 243).
2. Digital input: The digital input-1 can be used to start the checkweighing operation.
3. Serial interface: Transmit "Start SmartAPP" command via serial interface (Refer to parameter 111, 121, 131, 141 or 151).
4. Automatic checkweighing operation: If you will use the scale only for checkweighing and you prefer to activate checkweighing operation automatically after loading, set the parameter 321 to automatic operation.

To end the checkweighing operation.

1. Unload the scale or,
2. Disable the operation by pressing the function key, which is programmed as SmartAPP key or,
3. Reset the checkweighing with digital input-2 or,
4. Send the "Stop SmartAPP" command via serial interface.

9.2.3 SmartAPP at Checkweighing

The SmartAPP at checkweighing announces if the load is in tolerances with backlight color, with bar graph on the right side of the display and acoustically. The backlight color changes automatically to indicate the checkweighing zones, to warn the operator.

The multicolor backlight feature provides operational comfort and reduces operator mistake. The weighing speed increases because of operators' faster and easy perception of colors.




Figure 9.4 - Weight display and toolbar at checkweighing.

Digital inputs and outputs

If one of the applications is selected, digital inputs and outputs are set according to the selected application requirements automatically even they have been previously set to the different functions.

You can control your scale via these digital inputs and outputs. Non-used inputs and outputs of the application can be programmed freely in the related parameter for any function or as a Remote IO of the PLC to control them over fieldbus.

Inputs / Outputs	Descriptions
Input-1	Start
Input-2	Reset
Input-3	Refer to parameter 353
Input-4	Refer to parameter 354
Output-1	- Tolerance (light)
Output-2	OK
Output-3	+ Tolerance (heavy)
Output-4	Refer to parameter 364
Output-5	Refer to parameter 365

Table 9.2 - Digital inputs and outputs of Checkweighing.

9.3 Filling

APPLICATION: Weighing to the target with tolerance monitoring. The weight display indicates the weight value.

RELATED PARAMETERS: Sub-blocks 31- and 32-. Parameters 241, 242 or 243.

Filling application is used for weighing materials into the container. The scale is accepted as loaded if the gross weight is bigger than Empty range.

The Filling operation timing diagram, FT-112 Panel outputs and SmartAPP bar is shown in the Figure 9.5 below.




Figure 9.5 - Timing diagram of filling operation.

9.3.1 Product Entries at Filling

Entry type	Target	Coarse Feeding	Fine feeding	Tare minimum	Tare maximum	Unloaded scale limit
Value	TARGET	COARSE	FINE	TAREMIN	TAREMAX	EMPTY
Deviation	TARGET	COARSE	FINE	TAREMIN	TAREMAX	EMPTY
Percent %	TARGET	COARSE	FINE	TAREMIN	TAREMAX	EMPTY

TARGET: The nominal weight to be filled,

COARSE: Coarse cut off at entry type value or
Coarse = Target - Course cut off at entry types of deviation and ratio,

FINE: Fine cut off at entry type value or
Fine = Target - Fine cut off at entry types of deviation and ratio,

TAREMIN: The minimum of Tare weight,

TAREMAX: The maximum of Tare weight,

EMPTY: The weight range which the scale is accepted unloaded.














Example: If you fill 1000 g into the container at deviation entry type and container weight is between 150g and 190 g, the coarse feeding is up to 900 g and fine feeding is up to 980 g.

Following should be entered:







Target = 1000g, Coarse= 100g, Fine = 20g, Taremin= 150g and Taremax = 190g. Empty value might be 100g.









If the target will increase to 1100g, the change of coarse and fine values at entry types deviation and ratio is not required.

The nominal and limit value entry





1. Press the  key.
2. The current target value appears on the display as [TARGET:1000g]. Enter the new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
3. The current preact value is shown [COARSE : 100g]. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
4. The current dribble value appears [FINE : 20g]. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
5. The minimum tare weight is displayed [TAREMIN : 150g]. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
6. The maximum tare weight is shown as [TAREMAX : 190g]. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
7. The [EMPTY : 100g] prompt indicates the current empty range of the platform. Enter new value with numerical keys.
8. Press the  key to return to the operation after saving the entry or press  key to go back operation without saving the new empty range.

Product record into the SET memory

1. Press  key for more than 2 seconds. [MEMORY] prompt appears.
2. Press  key. The last used Set memory code appears [SET :001].
3. Enter the new memory code by pressing the numerical keys and press  key.
4. The previous target value will appear on the display as [SET001: TARGET], [5.00 kg]. Enter the new value with numerical keys and press the  key.
5. The [COARSE : 1,80] prompt appears on the display. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.

6. The [FINE : 0,20] prompt appears on the display. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
7. The [TAREMIN : 0,60] prompt appears on the display. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
8. The [TAREMAX : 1,20] prompt appears on the display. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
9. The [EMPTY : 1,00] prompt appears on the display. Enter new value with numerical keys.
10. Press the  key to go to the following memory after saving it or press  key to return operation without saving.

Select product from SET memory

1. Press  key. The current target value appears on the display as [TARGET: 1250 kg].
2. Press  key to more than 2 seconds enter Set memory. The last used Set memory code appears on the display as [SET :001].
3. Enter the memory code of the product by pressing the numerical keys and press  key.
4. The selected product limits are loaded for usage after displaying values.
5. Or press  key to exit without saving.

9.3.2 Start and Stop the filling

One of the following ways can be used to start the filling operation.

1. Function key: If you want to start the Filling operation by pressing key, program one of the function keys for SmartAPP (Refer to parameter 241, 242 and 243).
2. Digital input: The digital input-1 can be used to start the filling operation.
3. Serial interface: Transmit "Start SmartAPP" command via serial interface (Refer to parameter 111, 121, 131, 141 or 151).
4. If you will use the scale only for Filling and you prefer to activate Filling operation automatically after loading, set the parameter 321 to automatic filling operation.

To end the filling.

1. Unload the platform,
2. Disable the operation by pressing the function key which is programmed as SmartAPP key or.
3. Reset the filling with digital input-2 or,
4. Send the "Stop SmartAPP" command via serial interface.

9.3.3 SmartAPP at filling

The SmartAPP announces the filling process with backlight color, with bar on the right of the display and acoustically. Refer to parameter 315, [page 58](#) to set up the SmartAPP.




Figure 9.6 - Weight display and toolbar at filling.

Digital inputs and outputs

If one of the applications is selected, digital inputs and outputs are set according to the selected application requirements automatically even they have been previously set to the different functions.

You may control your scale via these digital inputs and outputs. Non-used inputs and outputs of the application can be programmed freely in the related parameter for any function or as a Remote IO of the PLC to control them over fieldbus.

Inputs / Outputs	Descriptions
Input-1	Start
Input-2	Reset
Input-3	Refer to parameter 353
Input-4	Refer to parameter 354
Output-1	Ready
Output-2	Fine
Output-3	Coarse
Output-4	End of Filling
Output-5	Refer to parameter 365

Table 9.3 - Digital inputs and outputs of filling.

9.4 Peak Hold

APPLICATION: Up to 10 broken points of the material are detected at compression and tension testing machines. All peak values of testing can be shown on the display automatically after the testing or by pressing programmed key to the LAST test.

RELATED PARAMETERS: Sub-blocks 31- and 32-. Parameters 241, 242 or 243.

The tension testing process is shown in the diagram below.




Figure 9.7 - Timing diagram of tension test process.

9.4.1 Product entries

Product entries at peak hold are.

Entry type	Start to follow	Reduction ratio for medium peak detecting	Test ending reduction ratio.	Stop testing	Alarm	Unloaded scale limit
Value	FOLLOW	MID DECR	END DECR	STOP	ALARM	EMPTY
Deviation	FOLLOW	MID DECR	END DECR	STOP	ALARM	EMPTY
Percent %	FOLLOW	MID -%	END -%	STOP	ALARM	EMPTY

FOLLOW: The tracing of the force is started from this value.

MID DEC: Minimum force decrease to detect medium peaks.

END DECR: Force decrease to finish the test.














STOP: Stop testing if the force is bigger,

ALARM: Produce alarm signal to warn the operator and/or to stop testing.















EMPTY: Test starts automatically or manually if the force is bigger than.

The MID DECR and END DECR entries can be setup as value or percent (refer to par. 312) and others are always values.





The nominal and limit value entry

1. Press the  key.
2. The current force following force changes to catch the peak appears on the display as [FOLLOW: 100N]. Enter the new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
3. The current decreasing rate to catch the intermediate peak values appears [MID DECR: 25%]. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
4. The current decreasing rate for ending the peak hold process appears [END DECR : 80%]. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
5. The maximum force to stop testing is displayed [STOP: 2000N]. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
6. The alarm output is activated at [ALARM : 2500N]. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
7. The peak hold process is start if the load is heavier than [EMPTY : 50N]. Enter new value with numerical keys.
8. Press the  key to return to the operation after saving the entry or press  key to go back operation without saving the new empty range.

Product record into the SET memory

1. Press  key more than 2 seconds. [MEMORY] prompt appears.
2. Press  key. The last used Set memory code appears [SET :001].
3. Enter the new memory code by pressing the numerical keys and press  key.
4. The previous follow value is shown on the display as [SET 001: FOLLOW], [5.00 N]. Enter the new value with numerical keys and press the  key.
5. The [MID DECR : 20%] prompt appears on the display. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
6. The [END DECR : 50%] prompt appears on the display. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
7. The [STOP : 100,00 N] prompt appears on the display. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
8. The [ALARM : 150,00 N] prompt appears on the display. Enter new value with numerical keys. Press the  key to save it or press  key to return operation without saving.
9. The [EMPTY : 1,00 N] prompt appears on the display. Enter new value with numerical keys. Press the  key to go to the following memory after save it or press  key to return operation without saving.

Select product from SET memory

1. Press  key. The current minimum value to start the following force appears on the display as [FOLLOW: 100 N].
2. Press  key for more than 2 seconds to enter Set memory. The last used Set memory code appears on the display as [SET :001].
3. Enter the memory code of the product by pressing the numerical keys and press  key.
4. The selected product limits are loaded for usage after displaying values.
5. Or press  key to exit without saving.

9.4.2 Start and Stop the peak hold

One of the following ways can be used to start the peak hold operation:

1. Function key: If you want to start the peak hold process by pressing key, program one of the function keys for SmartAPP (Refer to parameter 241, 242 and 243).
2. Digital input: The digital input-1 can be used to start the peak hold.
3. Serial interface: Transmit "Start SmartAPP" command via serial interface (Refer to parameter 111, 121, 131, 141 or 151).
4. If you will use the instrument only for peak hold and you prefer to activate process automatically after loading, set the parameter 321 to automatic operation.

To end the peak hold.

1. End the operation by pressing the function key which is programmed as SmartAPP key or,
2. Reset the process with digital input-2 or,
3. Send the "Stop SmartAPP" command via serial interface.

9.4.3 SmartAPP at peak hold

The SmartAPP announces the peak hold process with backlight color, with bar on the right of the display and acoustically. Refer to parameter 315, [page 58](#) to set up the SmartAPP.




Figure 9.8 - Weight display and toolbar at peak hold.

9.4.4 Digital inputs and outputs

You can control your machine via these digital inputs and outputs. Non-used inputs and outputs of the application can be programmed freely in the related parameter for any function or as a Remote IO of the PLC to control them over fieldbus.


Inputs / Outputs	Descriptions
Input-1	Start
Input-2	Reset
Input-3	Refer to parameter 353
Input-4	Refer to parameter 354
Output-1	Ready
Output-2	Run
Output-3	End of Testing
Output-4	Alarm
Output-5	Refer to parameter 365

Table 9.4 - Digital inputs and outputs of peak hold.

9.5 Totalization







FT-112 Panel can be used for horizontal or vertical totalization operations. Vertical totalization means individual and cumulative weighing of the different materials batched in the same container. The horizontal totalization is used for weighing materials of batch in the separate containers or for totalizing sequential weighing. A preset tare value can be used in totalization.

Totalization weighing is limited with 99 items. Refer to **page 58**.






You can follow the weighted items by pressing  or  keys at total value displaying.

Horizontal totalization

APPLICATION: To accumulate the sequential weighing. Refer to parameter 324.

1. Press to the  key for zeroing the empty scale before loading it.
2. Load the container on to the pan.
3. Press  key for weighing material in net.
4. Add the material into the container.
5. Press  key for totalizing and unload the container.
6. Load the following container on to the pan.
7. Repeat the procedure from item 3 to weigh following materials.
8. Press  key to display the total value as [C 5 MR: 5.003 KG].
9. Press  key for printout totalization ticket or press  key to go on totalization from item 3.

Delete the total

1. Press  key to display the total value.
2. Press  key second time when the total displays.
3. Press  key and [Delete ?] prompt appears.
4. Press  key to delete total and item weights or press  key to exit without delete the total.







Flintec	
www.flintec.com	
Meckesheim, Germany	
Date	23.06.2022
Time	09:16
CN	34
OPERATOR	
JOSEPH SMITH	
MATERIAL	
POLYETHYLENE	
1 Tare	0.102 kg
Net	1.000 kg
2 Tare	0.100 kg
Net	1.001 kg
3 Tare	0.099 kg
Net	1.000 kg
4 Tare	0.100 kg
Net	1.003 kg
5 Tare	0.099 kg
Net	0.999 kg

TOTAL	
Gross	5.503 kg
Tare	0.500 kg
Net	5.003 kg
* Thank you *	






Vertical totalization

APPLICATION: Totalization of the materials batched in the same container. Refer to parameter 324.

IMPORTANT NOTE: The tare parameter should be set to multitare "MULT" for vertical totalization. Refer to parameter 231.

1. Press to the  key for zeroing the empty scale before loading it.
2. Load the container on to the pan.
3. Press  key for weighing material in net. If automatic taring function is activated and if minimum tare weight (parameter 518) is lower than tare weight the scale tares automatically.
4. Add the first material into the container.
5. Press  key for totalizing. The scale will be tarred automatically after saving the item weight.
6. Add the following material into the container. Repeat the item 5 to add the following materials until end of totalization.
7. Press  key to display the total value as [C 8 MR: 4.206 KG]
8. Press  key for printout totalization ticket or press  key to go on totalization from item 3.

Delete the total

1. Press  key to display the total value.
2. Press  key second time when the total displays.
3. Press  key and [Delete ?] prompt appears.
4. Press  key to delete total and item weights or press  key to exit without delete the total.




Flintec	
www.flintec.com	
Meckesheim, Germany	
Date	23.06.2022
Time	09:24
CN	54
OPERATOR	
JOSEPH SMITH	
MATERIAL	
POLYETHYLENE	
Tare	0.201 kg
1 Net	0.599 kg
2 Net	0.604 kg
3 Net	0.600 kg
4 Net	0.600 kg
5 Net	0.600 kg
6 Net	0.499 kg
7 Net	0.402 kg
8 Net	0.302 kg

TOTAL	
Gross	4.407 kg
Tare	0.201 kg
Net	4.206 kg
* Thank you *	





Grand Total

The grand total announces the total of the all weighing on the scale. This function accumulates weighing of items after every printing.

Display the Grand Total

1. Press the  key for more than 2 seconds.
2. The grand total appears on the information display as [GT: 12345678901 kg]
3. Press  key for grand total value printing.
4. Press  key to go back to the operation or 15 seconds later the grand total indication on the display will disappear.

Delete the Grand Total


1. Press the  key for more than 2 seconds.
2. Press  key when the grand total displays.
3. [Delete ?] prompt appears.
4. Enter the key password if programmed. Refer to parameter 325.
5. Press  key to delete or press  key to exit without clearing the total.

10 DIGITAL INPUTS AND OUTPUTS

CONDITION: The Digital I/O option board, analogue output option or one of the fieldbus options should be installed in the weighing indicator, to use digital control inputs and setpoint output signals.

APPLICATION: Digital inputs are used to control the instrument and the digital outputs can be used at basic weighing, checkweighing, classifying, peak holding and filling applications to control gates, valves etc. or to produce alarm. Digital inputs and outputs are set to the classifying, checkweighing, peak holding or filling operations automatically.

RELATED PARAMETERS: Sub-blocks 35- and 36-.

You may enter limit values of the item after pressing  key or you may call them from Memory. Set Memory has 500 pcs item record capacity. Each item has 5 or 6 set entries which depends on the application. This section describes functions of digital ports at basic weighing. These functions are automatically changed to In/Out functions of selected SmartAPP application.

The digital inputs and outputs can be programmed to use them as a Remote IO of PLC over fieldbus additionally to their usage at weighing related functions. Remote IO's of PLC can be used for level control of material tank, conveyor control, solenoid control, alarm etc.


10.1 Basic Weighing

In / Out	Descriptions	Related parameter
Input 1	Zeroing, Taring, Clear, Print, Key lock, Dynamic Start and Reset, peak hold, hold, Remote Input over Fieldbus.	351
Input 2	Zeroing, Taring, Clear, Print, Key lock, Dynamic Start and Reset, peak hold, hold, Remote Input over Fieldbus.	352
Input 3	Zeroing, Taring, Clear, Print, Key lock, Dynamic Start and Reset, peak hold, hold, Remote Input over Fieldbus.	353
Input 4	Zeroing, Taring, Clear, Print, Key lock, Dynamic Start and Reset, peak hold, hold, Remote Input over Fieldbus.	354
Output 1	Various functions for Setpoint1, Zero Range, Stable, Error, Remote output over fieldbus.	361
Output 2	Various functions for Setpoint1, Zero Range, Stable, Error, Remote output over fieldbus.	362
Output 3	Various functions for Setpoint1, Zero Range, Stable, Error, Remote output over fieldbus.	363
Output 4	Various functions for Setpoint1, Zero Range, Stable, Error, Remote output over fieldbus.	364
Output 5	Various functions for Setpoint1, Zero Range, Stable, Error, Remote output over fieldbus.	365





Digital inputs and outputs are set to their functions in sub-blocks 35- and 36- at basic weighing operation. Digital inputs can be programmed for zeroing, taring, print etc. in sub-block 35-. Digital outputs can be programmed for the different functions as described below.

10.2 Application Weighing

In / Out	Weighing	Classifying	Checkweighing	Filling	Peak hold
Input 1	Parameter 351	Start	Start	Start	Start
Input 2	Parameter 352	Reset	Reset	Reset	Reset
Input 3	Parameter 353	Parameter 353	Parameter 353	Parameter 353	Parameter 353
Input 4	Parameter 354	Parameter 354	Parameter 354	Parameter 354	Parameter 354
Output 1	Parameter 361	- - Tolerance	- Tolerance	Ready	Ready
Output 2	Parameter 362	- Tolerance	OK	Fine	Run
Output 3	Parameter 363	OK	+ Tolerance	Coarse	End of testing
Output 4	Parameter 364	+ Tolerance	Parameter 364	End of Filling	Alarm
Output 5	Parameter 365	+ + Tolerance	Parameter 365	Parameter 365	Parameter 365

The  key is used to access the setpoint entry menu. Additionally, one of the function keys can be programmed to access setpoint entry menu easily for frequent usage.

Entry the limit values at basic weighing

1. Press the  key.
2. The setpoint 1 value appears on the display after the weight value is shown [SP 1 1250kg].
3. Enter the new value by numerical keys. You may press  key to enter negative limit value. Press the  key to save it and to go to the next setpoint.
4. Repeat from step 2 for entering following setpoints.
5. FT-112 Panel returns to the operation after displaying setpoint 5 and entering its value,
6. Press  key to return operation at any step.

10.3 Digital inputs

Digital inputs can be used instead of pressing keys for taring, zeroing, clear tare, transfer data etc. as shown below. Basic peak on the display and hold display are the additional input functions at basic weighing. Refer to SmartAPP applications in this manual for digital input functions of selected application.


<p>Key functions via inputs Zeroing, Taring, Clear, Print The key functions are executed via digital inputs. Taring via digital input is shown in the drawing as an example.</p>	
<p>Basic Peak The instrument follows the peak of the loading during the input signal This basic weighing feature is not related with the peak hold application In SmartAPP Not for legal usage. <i>Important Note: This feature is not related with Peak Hold application of SmartAPP. But only for basic peak hold usage at basic weighing mode.</i></p>	
<p>Hold The instrument holds the weight indication during input signal which help the measured value to the operator for a while. Not for legal usage.</p>	
<p>Remote Input over Fieldbus or BSI The digital input(s) can follow PLC as a Remote input, if the instrument is equipped with any fieldbus option. Refer to related fieldbus command table to receive the status of inputs. This usage is independent from the weighing process of the instrument.</p>	

10.4 Digital outputs

Digital outputs can be programmed as free setpoints and used for different functions as shown below. The output(s) can be set as threshold or window additional to the well-known basic output at free programmable setpoints. Refer to SmartAPP applications in this manual for digital output functions of selected application.


S AIN Free setpoint of absolute indicated weight


The status of the digital output changes with comparing the set point value and absolute indicated weight value as shown below.



S IND Free setpoint of indicated weight








The digital output is activated with comparing the set point value and indicated weight value as shown below.






S ANE Free setpoint of absolute net weight


The digital output is activated with comparing the set point value and absolute net weight value as shown below.

<p>Example:</p> <p>if SP1 = 100 kg or</p> <p>SP1 LOW = 100 kg</p> <p>SP1 HIGH = 150 kg.</p>	
<p>BAS-HI Basic, active high Output is high if absolute net weight is heavier than setpoint. (Default)</p>	
<p>BAS-LO Basic, active low Output is low if absolute net weight is heavier than setpoint.</p>	
<p>THR-HI Threshold, active high Output goes to high if absolute net weight is heavier than setpoint high. Returns the low if the weight is less than setpoint low.</p>	
<p>THR-LOW Threshold, active low Output goes to low if absolute net weight is heavier than setpoint high. Returns the high if the weight is less than setpoint low.</p>	
<p>VIN-HI Window, active high Output goes to high if absolute net weight is between setpoint high and setpoint low.</p>	
<p>VIN-LOW Window, active low Output goes to low if absolute net weight is between setpoint high and setpoint low.</p>	

S NET Free setpoint of net weight

The digital output is activated with comparing the set point value and net weight value as shown below.





S GRO Free setpoint of gross weight


The digital output is activated with comparing the set point and weight at gross weight indication as shown below.

<p>Example:</p> <p>if SP1 = 100 kg or</p> <p>SP1 LOW = 100 kg</p> <p>SP1 HIGH = 150 kg.</p>	
<p>BAS-HI Basic, active high Output is high if gross weight is heavier than setpoint. (Default)</p>	
<p>BAS-LO Basic, active low Output is low if gross weight is heavier than setpoint.</p>	
<p>THR-HI Threshold, active high Output goes to high if gross weight is heavier than setpoint high. Returns the low if the weight is less than setpoint low.</p>	
<p>THR-LOW Threshold, active low Output goes to low if gross weight is heavier than setpoint high. Returns the high if the weight is less than setpoint low.</p>	
<p>VIN-HI Window, active high Output goes to high if gross weight is between setpoint high and setpoint low.</p>	
<p>VIN-LOW Window, active low Output goes to low if gross weight is between setpoint high and setpoint low.</p>	

SPC1 Control mode-1

The digital outputs are activated as shown below, if setpoints are set up to Control mode-1 and their values increases constantly from setpoint 1 to the setpoint N.


Digital outputs, which are not used at this mode, can be programmed freely to any other function. For example, if SP5 is not needed to control, it can be programmed to the zero range to produce empty signal.



SPC2 Control mode-2


The digital outputs are activated as shown below, if setpoints are set up to Control mode-2 and their values are increases constantly from setpoint 1 to the setpoint N.

Digital outputs, which are not used at this mode, can be programmed freely to any other function. For example, if SP5 is not needed to control, it can be programmed to the zero range to produce empty signal.




ZR I Zero range of the indicated weight

The digital output is activated if the absolute indicated weight value is in the zero range. Refer to parameter 366 to enter zero range value.



ZR G Zero range of the indicated weight

The digital output is activated if the gross weight value is in the zero range. Refer to parameter 366 to enter zero range value.



Stable

The digital output is activated at the displayed weight value is stable.

Run

The digital output is activated during the weighing indicator is in operation. The output is low in power on cycle and in setup modes.

In Net Mode


The digital output is activated during net weight indication.

Error





The digital output is activated when any Error is announced on the display.

Remote Output over fieldbus or BSI










The digital output(s) can be controlled from PLC as a Remote output if the instrument is equipped with any fieldbus option. Refer to related fieldbus command table to activate or deactivate the outputs. This usage is independent from the weighing process of the instrument.







Entry the limit values at basic weighing

1. Press the  key.
2. The setpoint 1 value appears as shown on the display [SP1 1250 kg].
3. Enter the new value by numerical keys. You may press  key to enter negative limit value. Press the  key to save it and to go to the next setpoint.
4. Repeat from step 2 for entering following setpoints.
5. The indicator returns to the operation after displaying setpoint 5 and entering its value,
6. Press  key to return operation at any step.

Entry setpoint of items into SET memory

1. Press  key for more than 2 seconds. [MEMORY] prompt appears.
2. Press  key. The last used Set memory group number appears as [SET : 111].
3. Enter the new memory code by pressing the numerical keys and press  key to enter the item.
4. The first limit value will appear on the display as [SET 111 - SP1] [10.00 kg]. Enter the new value by numerical keys and press the  key.
5. The following limit value appears as [SET 111 - SP2] [20.00 kg]. Enter new value by numerical keys and press the  key.
6. Repeat step 4 and 5 until entering values to other three limit value of the group.
7. After entering the value of 5th setpoint value press  key to check values again.
8. Or press  key to increase the memory code.
9. Or press  key to decrease the memory code.
10. Or press  key to exit.

Select limits of item from SET memory

1. Press  key. The last used setpoint value appears on the display as [SP1 1250 kg].
2. Press  key. The last used Set memory code appears on the display [SET : 111].
3. Enter the memory code of the item by pressing the numerical keys and press  key.
4. The selected Set memory data is loaded after displaying values.
5. Or press  key to exit without loaded.

Limit values at SmartAPP

Digital inputs and outputs are set to their application related functions automatically if any SmartAPP operation is programmed. The non-used inputs and outputs of the selected SmartAPP application can be programmed to the any function described above.

For example, the Output 5 of the Filling is not used by the Filling application software, and it can be used as zero range output to check the scale unloading.

Refer to SmartAPP section 10.2, **page 97**, for usage of digital inputs and outputs details.

11 SERIAL DATA OUTPUTS

FT-112 Panel weighing indicator has RS232, RS485, RS422, USB and Ethernet interfaces. In this section, you will find the data structure of different type of the data outputs via these serial ports. If you transmit ASCII codes **P(print)**, **Z(zero)**, **T(tare)** or **C(clear)** letters to the serial port of FT-112 Panel; it will act like the related key is pressed.

11.1 Continuous Data Output

Continuous data output of the instrument is transmitted in the following data structure. The serial ports of FT-112 Panel are suitable for bi-directional communication.

CR (Carriage return) and LF (Line feed) codes can be enabled or disabled from response. CHK (Checksum) can be enabled or disabled from both command and response and only continuous data output can be programmed for more than one interface.

The data format of continuous data output is:

	Status			Indicated						Tare								
STX	STA	STB	STC	D5	D4	D3	D2	D1	D0	D5	D4	D3	D2	D1	D0	CR	LF	CHK

The including of the status bytes STA, STB and STC are:

Definition Table for Status A (STA)									
Bits 0, 1 and 2			Bits 3 and 4			Bit 5	Bit 6	Bit 7	
0	1	2	Decimal point	3	4	Increment size	Always 1	Always 1	X
0	0	0	XXXXOO	1	0	X 1			
1	0	0	XXXXXO	0	1	X 2			
0	1	0	XXXXXX	1	1	X 5			
1	1	0	XXXXX.X						
0	0	1	XXXX.XX						
1	0	1	XXX.XXX						
0	1	1	XX.XXXX						
1	1	1	X.XXXXX						

Definition Table for Status B (STB)		
Bit 0	0 = Gross	1 = Net
Bit 1	0 = Weight positive	1 = Weight negative
Bit 2	0 = No Error	1 = Error
Bit 3	0 = Stable	1 = Unstable
Bit 4	Always = 1	
Bit 5	Always = 1	
Bit 6	0 = Not power on zeroed	1 = Zeroed with power on zero
Bit 7	X	

Definition Table for Status C (STC)		
Bit 0	Always 0	
Bit 1	Always 0	
Bit 2	Always 0	
Bit 3	Always 0	
Bit 4	Always 1	
Bit 5	Always 1	
Bit 6	Always 0	
Bit 7	X	



$$\text{CHK (Checksum)} = 0 - (\text{STX} + \text{STATUS A} + \dots + \text{LF})$$

Error Messages: UNDER, OVER, A.OUT, L-VOLT and TILT are represented in Indicated data fields.

Note: The weight data is represented with right aligned and the error messages are represented with left aligned.

11.1.1 Continuous Data Formats

RELATED PARAMETERS: Parameters 111, 121, 131, 141 and 151.

Continuous data output can be programmed to the same common formats besides Flintec continuous format. To select one of the described formats below press the  key sequentially. Press  key to go to the next parameter.

Flintec®

Character number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16	17	18	19	
Description	STX	STA	STB	STC	Indicated weight						Tare weight						CR	LF	CHK	
Example-1	ASCII	☺	}	1	0			0	7	5	0				2	5	0			♠
	Hex	02	7D	31	30	20	20	30	37	35	30	20	20	20	32	35	30	0D	0A	06

Function	Description									
STX	Start of transmission character.									
STA (STATUSA)	Bit 7	Bit 6	Bit 5	Bits 4 and 3			Bits 2,1 and 0			
	Always 0	Always 1	Always 1	4	3	Increment	2	1	0	Decimal point
				0	1	x 1	0	0	0	XXXX00
				1	0	x 2	0	0	1	XXXXX0
				1	1	x 5	0	1	0	XXXXXX
							0	1	1	XXXXX.X
							1	0	0	XXXX.XX
							1	0	1	XXX.XXX
							1	1	0	XX.XXXX
						1	1	1	X.XXXXX	
STB (STATUSB)	Bit 7	Bit 6	Bit 5	Bit 4	Bit 3	Bit 2	Bit 1	Bit 0		
	Always 0	1 = Zeroed with power on zero	Always 1	Always 1	1 = Unstable	1 = Error ⁽⁰⁾	0 = Weight negative	1 = Net		
0 = Not power on zeroed		0 = Stable			0 = No Error	0 = Weight positive	0 = Gross			
STC (STATUSC)	Always 0 as ASCII (30 hex).									

Indicated Weight	These seven characters are a string containing the current weight not including the decimal point.
Tare Weight	These seven characters are a string containing the tare weight not including the decimal point.
CR	Carrige Return.
LF	Line Feed.
CHK	Checksum byte. Checksum calculation is: CHK (Checksum) = 0 - (STX+ STATUS A + + LF)

(1) Error Messages: UNDER, OVER, A.OUT, L-VOLT and TILT are represented in Indicated data fields as left aligned.

HBM®

Description	STX	Sign	Indicated weight							S1	S2	S3	S4	Unit		ETX
Example	☺				0	.	7	5	0	N			1	k	g	♥

Toledo®

Description	STX	A	B	C	Indicated weight							Tare weight			CR	LF	CHK		
Example	☺	}	1	0			0	7	5	0				2	5	0			♠

SysTec®

Description	Status	Indicated weight										SP	Unit		CR	LF
Example	S						0	.	7	5	0		k	g		

SMA

Description	LF	S	R	N	M	F	Indicated weight							Unit		CR		
Example			1	N							0	.	7	5	0	k	g	

Function	Description
LF	Line Feed (0A hex)
S	Z = Centre of zero, O = Over cap, U = Under cap, E = Weight not currently being displayed. " "(space) = None of the above conditions.
R	Range. 1 = First range, 2 = Second range, 3 = Third range.
N	Mode. G = Gross weight, T = Tare weight, N = Net weight, g = Gross weight in increased resolution. n = Net weight in increased resolution.
M	Motion. M = Motion, " "(space) = No motion.

F	Always a space as ASCII (20 hex).
Indicated Weight	These ten characters are a string containing the current weight including the decimal point.
Unit	Unit of weight value are kg, g, lb, klb, N or kN as left aligned.
CR	Carrige Return (OD hex)

Sartorius®

Description	Ignore	Sign	SP	Indicated weight						SP	Unit		CR	LF
Example		+			0	.	7	5	0		k	g		

Rinstrum®

Description	STX	Sign	Indicated weight						ST	ETX
Example	☺			0	.	7	5	0	N	♥

Avery® E1205

Description	STX	Indicated weight						SP	Unit		SP	ST	CR	LF	ETX	
Example	☺			0	.	7	5	0		k	g		N			♥

Baster®

Description	Indicated Weight						LF	
Example			0	.	7	5	0	

LM2

Character number	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15	16
Description	Indicated Weight						Unit		SP	NET			LF	CR		
Example-1				0	.	7	5	0	K	g		N	E	T	L _F	C _R
Example-2			1	.	0	0	0	K	g	L _F	C _R					

Function	Description
Indicated Weight	These eight characters are a string containing the current weight not including the decimal point.
Unit	Unit of weight value are Kg, G, Lb, N or KN as left aligned.
SP	Only sent a space character in Net operation. Otherwise there is no any character.
NET	These three characters are only sent in Net operation. Otherwise there is no any character.
LF	Line Feed (0A hex)
CR	Carrige Return (OD hex)

Registered trademarks

Terms and product names mentioned in this publication are trademarks, registered trademarks or service marks of their respective owners. Use of a term should not be regarded as affecting the validity of any trademark, registered trademark or service mark.

HBM® is a registered trademark of Hottinger Baldwin Messtechnik.

TOLEDO® is a registered trademark of Mettler-Toledo.

SysTec® is a registered trademark of Systemtechnik und Industrieautomation.

Sartorius® is a registered trademark of Sartorius.

Rinstrum® is a registered trademark of Rinstrum.

Avery® is a registered trademark of Avery Weigh-Tronix.

Baster® is a registered trademark of Baster.

11.2 Fast Continuous Data Output


Fast continuous "indicated weight" data output can be used only for the instruments, which can communicate fast. The output rate is related with the baud rate. Use higher baud rate for faster data rate. CR and LF can be enabled. You may reduce the data transfer speed by increasing the delay between data output packages.

The data format of the fast-continuous data output is;
[STX][STATUS][SIGN][WEIGHT VALUE][CR][LF]


Examples:

☺S+000123.4	(weight is stable and 123.4)
☹D+000123.4	(weight is unstable and 123.4)
☺M+000123.4	(Dynamic weighing result is 123.4)
☹-----	(Dynamic weighing in calculating)
☹+	(Over load)
☹-	(Under load)
☹O	(ADC out error)

11.3 Print Mode

The format of the data output in Print mode can be selected in 5 different type forms in the sub-block 16- . Only **one** serial port can be programmed for printing. Print mode data outputs is sent by pressing the  key or by receiving ASCII P command via serial port, or via Ethernet port by setting remote IP and remote port number, refer to parameter 19E and 19F.


SINGLE LINE

You can transmit the printout data in single line format by pressing  key. This format is recommended to send the print data to PC or to any host. The data output structure is;


12.02.2016 14:47 CN: 71 G: 3.007kg T: 1.001kg N: 2.006kg *ALB: 5*

DATE	TIME	ID1 Name	ID1 Data	ID2 Name	ID2 Data	CN	GROSS	PT or TARE	NET	ALB	CR	LF
10	3 5	3 Max. 16	3 Max. 32	3 Max. 16	3 Max. 32	3 9	3 13	3 13	3 13	4 12	1	1

MULTI LINE

You can send the data in multiple line formats as shown in the label given below by pressing  key. The data output including can be programmed with printer parameters. The multiline data output can be programmed for 16-byte narrow printers and for others.


Format for 16-character printer:



16F1 – Includes only Gross or Net weight value

16F2 – Includes Gross or Gross\Tare\Net weight values

Format for minimum 26 or more characters printer:



26F1 – Includes only Gross or Net weight value

26F2 – Includes Gross or Gross\Tare\Net weight values

11.4 EPL Format

The EPL format of the data output in Print mode is selected to print the label data in graphical format EPL.

You can design your label in EPL format by using the printer label design software and Flintec software as describe below.

1. Connect FT-112 Panel weighing indicator to Indface2x set up PC software.
2. Enter EPL print format window. You will find the command table which includes commands to get data from weighing in the label design.
3. Open label design software of the printer. Design your label by using the commands in item 2.
4. Save/Compile/ Convert your design to EPL format in Label design software.
5. Import the EPL file into Flintec set up PC software window.
6. Load this file into weighing indicator.



Figure 11.1- Sample of the label printout of FT-112 Panel which is designed in EPL format.

11.5 BSI Data Structure for Dialog with PC and PLC

New generation FLINTEC weighing indicators launched on the market support the standardized command set BSI data form, depending on the functionality of the instrument. This easy data format gives the reliable and speedy interface advantages with communicating PLC or PC for process control or transactional applications.

BSI is divided into 2 levels.

BSI-BASE	Command sets of basic weighing instruments, e.g. taring, zeroing, setpoint loading.
BSI-PRO	Extension of the command set for professional weighing indicators, e.g. commands related with identification data application related commands.

General Rules:

1.	Commands are only in CAPITAL.
2.	CHK (2 ASCII char) can be enabled or disabled from both command and response.
3.	Weight data and limit values are 8-byte with dot and non-significant zeros on the left.
4.	Headers are 16-byte length.
5.	ID identification data are 32-byte length.
6.	APW at piece weighing are 12-byte length.
7.	Address (2 ASCII char) will be located in the structure, if not 00.

Command format:

A general description of the command is the following:

[ADR][COMMAND][CHK][CR][LF]

Response format with weight:

A general description of the response is the following:

[ADR][COMMAND][STATUS][SIGN][WEIGHT][CHK][CR][LF]

Response format without weight:

[ADR][COMMAND][STATUS][CHK][CR][LF]

Note: CHK, CR and LF will not be shown in below data format descriptions in this section.

Status Table:

The status data in the interfacing are listed below:

A	Ack, the command is operated successfully
D	Dynamic, unstable weight
E	Errors except of H, L, O, +, -.
H	High voltage detected
I	The weight is in range
L	Low voltage detected
M	Mean (Average)
N	Nack, the command couldn't be operated
O	ADC out
S	Stable weight
X	Syntax error (not recognized the received command)
+	Overload
-	Underload

BSI-Base Commands and Responses:

A	Read all weight data immediately
B	Read Gross weight value immediately
C	Clear the tare
G	Read voltage value of DC power supply
I	Read current weight (indicated) value immediately
P	Read the current stable weight value
Q	Load set point values
R	Read set point values
S	Read Status
T	Tare
U	Read digital inputs
V	Read digital outputs
W	Set/Reset digital outputs
X	Read current weight value in increased resolution immediately
Z	Zero

BSI-BASE Command Table:

Description	Command	Response
Read all weight data immediately	[ADR][A]	[ADR][A][STATUS][SIGN][NET W] [SIGN][TARE W] [SIGN] [GROSS W]
Read Gross weight value immediately	[ADR][B]	[ADR][B][STATUS][SIGN][WEIGHT VALUE]
Clear the tare memory	[ADR][C]	[ADR][C][A]
Read voltage value of DC power supply	[ADR][G]	[ADR][G][STATUS][VOLTAGE VALUE]
Read current weight (indicated) value immediately	[ADR][I]	[ADR][I][STATUS][SIGN][WEIGHT VALUE]
Print: Read the stable weight	[ADR][P]	[ADR][P][STATUS][SIGN][WEIGHT VALUE]
Load set points	[ADR][Q][SP No][L][SIGN][SP VALUE]	[ADR][Q][STATUS]
Read set points	[ADR][R][SP No][L]	[ADR][R][STATUS][SIGN][SP VALUE]
Read Status	[ADR][S]	[ADR][S][STATUS-1][STATUS-2] [STATUS-3]
Tare	[ADR][T]	[ADR][T][STATUS]
Read digital inputs	[ADR][U]	[ADR][U][STATUS][Inputs]
Read digital outputs	[ADR][V]	[ADR][V][STATUS][Outputs]
Set/Reset digital outputs	[ADR][W][Outputs]	[ADR][W][STATUS]
Read weight value in increased resolution	[ADR][X]	[ADR][X][STATUS][SIGN][WEIGHT VALUE]
Zero	[ADR][Z]	[ADR][Z][STATUS]

BSI-PRO Commands and Responses:

Description	Command	Response
ID1 name and data write	DA 1 [16d name] [32 digit data]	DAA
ID2 name and data write	DA 2 [16d name] [32 digit data]	DAA
ID1 name write	DH 1 [16 digits name]	DHA
ID1 data write	DI 1 [32 digits data]	DIA
ID2 name write	DH 2 [16 digits name]	DHA
ID2 data write	DI 2 [32 digits data]	DIA
ID1 name and data read	DK 1	DKA [16d name] [32 digits data]

ID2 name and data read	DK 2	DKA [16d name] [32 digits data]
Write SmartAPP and apply	DB+[8 digits Limit-1]+[8d Limit-2] +[8d Limit-3]+[8d Limit-4]+[8d Limit-5]+[8d Limit-6]	DBA
Start dynamic weighing	DD	DDA
Read dynamic weight	DR	DRA [8 digit Weight data]
Reset (to basic weighing)	DE	DEA
Write preset tare and apply	DP+[8 digits PT data]	DPA
Read preset tare	DQ	DOA+[8 digit PT data]
Write APW and apply	DM [12 digits APW data]	DMA
Read APW	DN	DNA [12 digits APW data]
Key lock / unlock	DL 1(0)	DLA
Print the label	DJ	DJA
Read the last printed data	DO	DOA [single line data format]

Checksum Calculation:

CHK is transmitted as two ASCII characters calculated with the Checksum formulation.

Checksum = 0 – (SUM of all response data before CHK)

Example: Read stable current weight data.

BSI Examples: (CHK is enabled and instrument address is 01)

Command: 01P[CHK][CR][LF]

Checksum = 0 – (0x30 + 0x31 + 0x50)
= 0 – 0XB1
= 0x4F
= Char '4' and 'F'

Response: 01PS+000123.4[CHK][CR][LF]

Checksum = 0 – (0x30 + 0x31 + 0x50 + 0x53 + 0x2B + 0x30 + 0x30 + 0x30 + 0x31+ 0x32 + 0x33 +
0x2E + 0x34)
= 0 – 0x02B7
= 0x49
= Char '4' and Char '9'

11.5.1 BSI-Base Commands

A	Read all weight data
----------	----------------------

Command : [ADR][A]
 Response : [ADR][A][STATUS][SIGN][NET W][SIGN][TARE W][SIGN][GROSS W]
 Example :
 Command : 01A
 Response : 01AS+000123.4+000111.1+000234.5
 01AD+000123.4+000111.1+000234.5
 01AO (ADC out error)

Comments:

The response is net, tare and gross weight values or error status.
 All weight data is transmitted immediately after receiving the command.

B	Read Gross weight
----------	-------------------

Command : [ADR][B]
 Response : [ADR][B][STATUS][SIGN][WEIGHT VALUE]
 Example :
 Command : 01B
 Response : 01BS+000123.4 (gross weight is stable and 123.4)
 01BD+000123.4 (gross weight is dynamic and 123.4)
 01B- (under load)

Comments:

The response is the gross weight value (stable or dynamic) or error status.
 Gross weight data is transmitted immediately after receiving command.

C	Clear the tare memory
----------	-----------------------

Command : [ADR][C]
 Response : [ADR][C][A] (Cleared and the scale is in gross mode)

Comments:

The response status is always Ack in weighing or force mode.

G	Read voltage value of DC power supply
----------	---------------------------------------

Command : [ADR][G]
 Response : [ADR][G][STATUS][VOLTAGE VALUE]
 Example :
 Command : 01G
 Response : 01GA234 (Power supply is 23.4 VDC)
 01GA150 (Power supply is 15.0 VDC)

Comments :

Voltage value is 3 byte and sends with 0.1 V increment.

I	Read indicated weight
----------	-----------------------

Command : [ADR][I]
 Response : [ADR][I][STATUS][SIGN][WEIGHT VALUE]
 Example :
 Command : 01I
 Response : 01IS+000123.4 (Weight is stable and 123.4)
 01ID+000123.4 (Weight is dynamic and 123.4)
 01I+ (Overload)

Comments:

Indicated weight value (stable or dynamic) is transmitted immediately.
 The weight value may be in gross or net.

P	Print: Read the stable weight
----------	-------------------------------

Command : [ADR][P]
Response : [ADR][P][STATUS][SIGN][WEIGHT VALUE]
Example :
Command : 01P
Response : 01PS+000123.4 (Weight is stable and 123.4) or
01PN (Could not print)

Comments:
Checks status and it must be stable. Else Nack status is send.
Status can be Stable or Nack.

Q	Load set points
----------	-----------------

Command : [ADR][Q][SET No][L][SIGN][SP VALUE]
Response : [ADR][Q][STATUS]
Example: Command : 01Q01L+000123.4
Response : 01QA (123.4 loaded to SP1)
01QN (Could not loaded)
01QX (Decimal point of SP VALUE is mismatch)

Comments:
SP Number is 2-byte ASCII char. Use 01 for SP1, 02 for SP2 and 03 for SP3.
SP VALUE data is 8-byte ASCII char with dot and non-significant zeros on the left.

R	Read set points
----------	-----------------

Command : [ADR][R][SP No][L]
Response : [ADR][R][STATUS][SIGN][SP VALUE]
Example: Command : 01R01L
Response : 01RA+000123.4 (SP1 is 123.4)
01RN (Could not loaded)

Comments:
SP No is 2-byte ASCII char. Use 01 for SP1, 02 for SP2 and 03 for SP3.
SP VALUE data is 8-byte ASCII char with dot and non-significant zeros on the left.

S	Read Status
----------	-------------

Command : [ADR][S]
Response : [ADR][S][STATUS-1][STATUS-2][STATUS-3]
Example: Command : 01S
Response : 01SSGI (Stable, Gross, In Range)
01SDGL (Dynamic, Gross, Low voltage error)

Comments:
The response includes 3 status information.
STATUS-1 can be Stable or Dynamic.
STATUS-2 can be Gross or Net.
STATUS-3 can be 'In range', 'Out of range', '+ Over', '- Under', 'Low voltage', 'High voltage' or 'Errors'.

T	Tare
----------	------

Command : [ADR][T]
Response : [ADR][T][A] (Taring is done successfully, and scale is in net)
[ADR][T][N] (Taring could not execute)
[ADR][T][X] (Taring is disabled)

Comments:
The tare value is overwritten by the new tare weight value.
Status must be stable in 2 seconds time out delay. If so, Ack is send.
If it cannot be stable in time out delay, Nack is send.

U	Read digital inputs
----------	---------------------

Command : [ADR][U]
 Response : [ADR][U][STATUS][Inputs]
 Example :
 Command : 01U
 Response : 01UA03 (Input 2 and Input 1 are active)
 01UA96 (Input 8,5,3,2 are active)
 01UAFF (All 8 inputs are active)
 01UN (Could not read inputs)

Comments:
 Data length change according to number of digital inputs.
 Inputs are implemented to ASCII char of 4-bit, '1111' inputs are implemented to char 'F'.

INPUTS	IN-8	IN-7	IN-6	IN-5	IN-4	IN-3	IN-2	IN-1
Bit wise	1	0	0	1	0	1	1	0
ASCII	9				6			

V	Read digital outputs
----------	----------------------

Command : [ADR][V]
 Response : [ADR][V][STATUS][Outputs]
 Example:
 Command : 01V
 Response : 01VA03 (Output 2 and Output 1 are active)
 01VA96 (Output 8,5,3,2 are active)
 01VAFF (All 8 outputs are active)
 01VN (Could not read outputs)

Comments :
 Data length change according to number of digital outputs.
 Outputs are implemented to ASCII char of 4-bit, '1111' is implemented to char 'F'.

OUTPUTS	OUT-8	OUT-7	OUT-6	OUT-5	OUT-4	OUT-3	OUT-2	OUT-1
Bit wise	1	0	0	1	0	1	1	0
ASCII	9				6			

W	Write (Set/Reset) digital outputs
----------	-----------------------------------

Command : [ADR][W][Outputs]
 Response : [ADR][W][STATUS]
 Example:
 Command : 01W96
 Response : 01WA (Outputs 8,5,3,2 are activated)
 01WN (Outputs could not be activated)

Comments :
 Data length change according to number of digital outputs.
 Outputs are implemented to ASCII char of 4-bit, '1111' outputs are implemented to char 'F'.
 The parameter of output(s) must be programmed as 'FBUS' for this feature (Page 61).

OUTPUTS	OUT-8	OUT-7	OUT-6	OUT-5	OUT-4	OUT-3	OUT-2	OUT-1
Bit wise	1	0	0	1	0	1	1	0
ASCII	9				6			

X	Read weight value in increased resolution
----------	---

Command : [ADR][X]
 Response : [ADR][X][STATUS][SIGN][WEIGHT VALUE]
 Example : Command : 01X
 Response : 01XS+00123.41 (weight is stable and 123.41) or
 01XD+00123.41 (weight is dynamic and 123.41) or
 01XE (Error)

Comments :
 The response includes weight data with divided the increment to 10.

Z	Zero
----------	------

Command : [ADR][Z]
 Response : [ADR][Z][A] (Zeroed)
 [ADR][Z][N] (Zeroing could not be operated)
 [ADR][Z][X] (Zeroing is disabled)

Comments :
 Zero command cannot work in net weighing.
 Weight must be in zeroing range for all operating modes.
 Status must be stable in 2 seconds time out delay. If so, Ack is send.
 If it cannot be stable in time out delay, Nack is send.

12 OPTIONAL COMMUNICATION

12.1 Analogue Output



IMPORTANT NOTE: The analogue output cable should be shielded. Connect the shield to the protective earth as described in the installation section.

FT-112 Panel has analogue output which is programmable to 4 – 20 mA, 0 – 20 mA, 0 – 5 V or 0 – 10V. Analog output is automatically adjusted to the weighing range after the calibration. The mid value of the analogue output is set to zero load at bipolar usage. The manual analogue output adjustment is available in parameter group 19- .

The analogue output is related with the gross load of the scale. The analogue output signal operates as described next.

Under Zero	When the gross indication drops below zero, the analogue output reduces the analogue output to 0mA or - 4 V to indicate error on the analogue output.
Normal Range	The analogue output will reflect the gross value to the programmed analogue output 4 – 20 mA, 0 – 20 mA, 0 – 5 V or 0 – 10 V.
Over High Limit	When the gross value exceeds the high limit, the analogue signal increase to approximately 24 mA or 11 V and remains there until the weight display is no longer blanked or the analogue signal returns to within range.

The following table indicates the analogue output value if the gross indication is out of the range and if there is any error indication on the display.

Condition (On Display)	4-20 mA output	0-20 mA output	0 – 5 V output	0 – 10 V output
The weight is more than the range ()	24 mA	24 mA	5.5 V	11 V
The weight is under the zero range ()	0 mA	0 mA	-4.0 V	-4.0 V
Error [Err XX]	24 mA	24 mA	5.5 V	11 V
ADC is out of operating range (LC Err)	24 mA	24 mA	5.5 V	11 V

The error data indicated above can be used to follow the errors at PLC.

The connection diagram is described on Page 17.

12.2 Modbus RTU and TCP/IP

IMPORTANT NOTE: *Modbus RTU and Modbus TCP interfaces require Modbus SD card at the SD2 card slot on the rear of the instrument.*

FT-112 Panel controller has a Modbus RTU interface over RS485, RS422 or RS232C serial port and Modbus TCP/IP over Ethernet TCP/IP interface. These interfaces can be programmed to High-Low or Low-High for different type of PLC's. You can find below the difference of these data formats and some companies using these formats. Two types are available as;

After programming RS485, RS422 or RS232C serial port for Modbus RTU, it can be used as a Modbus RTU slave on Modbus RTU network. The Modbus slave address is defined in the RS-485 address (Page 46). Functions code '0x03' (Read Holding Registers), '0x06' (Single Write Register), '0x17' (Read/Write Multiple Registers) and '0x10' (Preset Multiple Registers) are supported.

Please find Modbus information in the web site of <http://www.modbus.org>

Modbus RTU

Modbus RTU High-Low: In two-word registers, the data is stored to the registers in big-endian format. Least significant word is stored to the highest register address; and most significant word is stored to the lowest register address.

Modbus RTU Low-High: In two-word registers, the data is stored to the registers in little-endian format. Least significant word is stored to the lowest register address; and most significant word is stored to the highest register address.

Parameter's set-up:

Set the RS 485 / RS 232C Data Format	: Modbus RTU High-Low or Modbus RTU Low-High
RS-485 Data Length & Parity	: 8 none 1, 8 odd 1 or 8 even 1
RS-485 Address	: 01 to 31

Make the RS485 / RS422 / RS232C parameter settings as defined on **Page 45, 46, 44.**

Modbus TCP/IP

If the instrument is programmed for Modbus TCP/IP, it can be used as a Modbus TCP/IP slave on Ethernet communication network. Functions code '0x03' (Read Holding Registers), '0x06' (Single Write Register), '0x17' (Read/Write Multiple Registers) and '0x10' (Preset Multiple Registers) are supported.

Modbus TCP/IP High-Low: In two-word registers, the data is stored to the registers in big-endian format. Least significant word is stored to the highest register address; and most significant word is stored to the lowest register address.

Modbus TCP/IP Low-High: In two-word registers, the data is stored to the registers in little-endian format. Least significant word is stored to the lowest register address; and most significant word is stored to the highest register address.

Parameter's set-up:

Set Ethernet Data Format	: Modbus TCP/IP High-Low or Modbus TCP/IP Low-High
Ethernet Address	: 01 to 255

Make the Ethernet parameter settings as defined on sub-block 15-.

12.2.1 Modbus Data Structure

Modbus RTU and TCP/IP Command Table.

Address	R/W	Word	Command	Definition		
40001	R	2	Actual weight (Net if the indication is in Net, Peak value or Hold value)			
40003	R/W	2	Tare weight			
40005	R	2	Gross weight			
40007	R	2	Status	Bit	Definition	
				B0	0 – Dynamic is inactive	1 – Dyn weight is calculating
				B1	0 – Weight is actual w.	1 – Weight is dynamic result
				B2	0 – Weight is Stable	1 – Weight is unstable
				B3	0 – Gross mode	1 – Net mode
				B4	0 – Preset tare is passive	1 – Preset tare is active
				B5	0 – Not power on zeroed	1 – Zeroed with pwr on zero
				B6	0 – First Unit (power on)	1 – Second Unit
				B7-B10	Not used	
				B11	0 – Key lock is passive	1 – Key lock is active
				B12	0 – Out of center of zero	1 – Weight is in center of zero
				B13	0 – High res. is passive	1 – High res. is active
				B14	0 – Basic Peak is passive	1 – Basic Peak is active
				B15	0 – Hold is passive	1 – Hold is active
				B16-B26	Not used	
				B27	0 – None	1 – Decimal point is X.XXXX
				B28	0 – None	1 – Decimal point is X.XXX
B29	0 – None	1 – Decimal point is X.XX				
B30	0 – None	1 – Decimal point is X.X				
B31	0 – None	1 – No decimal point				
40009	R	2	Error Status	Bit	Definition	
				B0	0 – No Error	1 – Low voltage det.
				B1	0 – No Error	1 – In programming mode
				B2	0 – No Error	1 – System error
				B3	0 – No Error	1 – ADC under range
				B4	0 – No Error	1 – ADC over range
				B5	0 – No Error	1 – ADC out of range
				B6	0 – No Error	1 – Tilt Switch is active
B7- B31	Not used					
40011	R	2	Heartbeat for connection checking, this value is increased every 100 milliseconds.			
40013	R	2	Last print value			
40015	R/W	2	CN (Label number)	Refer to parameter [254], page 56		
40017	R	2	Quantity of M+			
40019	R	2	Total of M+			
40021	R/W	4	Grand Total			
40025	R/W	2	Commands	Dec	Definition	
				0	None	
				1	Zero	
				2	Tare	
				3	Clear	
				4	Print	

				5	Reprint the last label			
				6	High resolution enable			
				7	High resolution disable			
				8	Unit change (from first to second unit)			
				9	Unit change (from second to first unit)			
				10	Keylock enable			
				11	Keylock disable			
				12	Dynamic Start			
				13	Dynamic Reset			
				14	M+ key usage			
				15	Totalization Print (MRC key and Print key)			
				16	Totalization Cancel.			
				17	SmartAPP Start			
				18	SmartAPP Reset			
				19-23	Not used			
				24	Basic peak enable			
				25	Basic peak disable			
				26	Hold enable			
				27	Hold disable			
40027	R	2	Commands status	0	None			
				1	Command is processing...			
				2	Command is successfully.			
				3	Command failed.			
40029	R/W	12	Reserve					
40041	R	2	Status of Inputs	Bit	Definition			
				B0	Input-1	0 – Passive 1 – Active		
				B1	Input-2			
				B2	Input-3			
B3	Input-4							
40043	R/W	2	Status of Outputs	B0	Output-1	0 – Passive 1 – Active		
				B1	Output-2			
				B2	Output-3			
				B3	Output-4			
				B4	Output-5			
40045	R/W	2	Basic weighing	Filling	Checkweighing	Classifying	Peak holding	
			Setpoint 1(High)	Target	Target	Target	Follow	
40047	R/W	2	Setpoint 2(High)	Coarse	Low	- - Low	Mid Decr.	
40049	R/W	2	Setpoint 3(High)	Fine	High	-Low	End Decr.	
40051	R/W	2	Setpoint 4(High)	TareMin	Empty	+High	Stop	
40053	R/W	2	Setpoint 5(High)	TareMax	Not used	++High	Alarm	
40055	R/W	2	Not used	Empty	Not used	Empty	Empty	
40057	R/W	2	Setpoint 1 Low	Only available for Threshold and Window feature. Refer to sub-block 36-, page 61 to see the availabilities.				
40059	R/W	2	Setpoint 2 Low					
40061	R/W	2	Setpoint 3 Low					
40063	R/W	2	Setpoint 4 Low					
40065	R/W	2	Setpoint 5 Low					

40067	R	2	Only available for Peak hold application. Refer to Section 9.4, page 91.	1 st Peak value	
40069	R	2		2 nd Peak value	
40071	R	2		3 rd Peak value	
40073	R	2		4 th Peak value	
40075	R	2		5 th Peak value	
40077	R	2		6 th Peak value	
40079	R	2		7 th Peak value	
40081	R	2		8 th Peak value	
40083	R	2		9 th Peak value	
40085	R	2		10 th Peak value	
40127	R/W	2	Dynamic filter	Refer to parameter [332], page 59	
40129	R/W	2	Digital filter	Dec	Description
				0	No
				1	Very Low
				2	Low
				3	Medium
				4	High
40131	R/W	2	Power on zero	0	Disable
				1	± 2%
				2	± 2%LK
				3	± %10
				4	+ %15, - %5
				5	± %20
40133	R/W	2	Zeroing Range	0	Disable
				1	± 2%
				2	± 3%
				3	± 20%
				4	± 50%
40135	R/W	2	Auto Zero Tracking	0	Disable
				1	± 0,3d
				2	± 0,5d
				3	± 1d
				4	± 2d
				5	± 3d
40137	R/W	2	Tare	0	No
				1	Multi tare
				2	Tare only at gross
				3	Preset tare
				4	Preset tare at gross
40139	R/W	2	Stability Detection Range	0	± 0,3d
				1	± 0,5d
				2	± 1d
				3	± 2d
				4	± 3d
				5	± 4d
				6	Disable
40141	R/W	2	Stability Time	Refer to parameter [517] on page 64	
40143	R/W	10	Reserve		
40153	R/W	2	Unit	Dec	Description
				0	g (Gram)
				1	kg (Kilogram)
				2	t (Ton)

				3	lb	(Libre)
				4	No unit	(without unit)
				5	N	(Newton)
				6	kN	(Kilonewton)
				7	kLb	(Kilolibre)
40155	R/W	2	Range	0	Single range	
				1	2 x MR	
				2	3 x MR	
				3	2 x MI	
				4	3 x MI	
40157	R/W	2	MAX-1	Refer to parameter [523] on page 65		
40159	R/W	2	Decimal point-1	Dec	Description	
				0	XXXXOO	
				1	XXXXXO	
				2	XXXXXX	
				3	XXXXX.X	
				4	XXXX.XX	
5	XXX.XXX					
40161	R/W	2	Increment-1	Dec	Description	
				0	X 1	
				1	X 2	
				2	X 5	
40163	R/W	2	MAX-2			
40165	R/W	2	Decimal point-2			
40167	R/W	2	Increment-2			
40169	R/W	2	MAX-3			
40171	R/W	2	Decimal point-3			
40173	R/W	2	Increment-3			
40175	R/W	2	Limit of Indication	Dec	Description	
				0	Over indication after Max.	
				1	1 division more than Max.	
				2	5 division more than Max.	
				3	9 division more than Max.	
				4	2% more than Max.	
5	5% more than Max.					
40177	R/W	2	Tare type	0	Subtractive tare	
				1	Additive tare	
40179	R/W	2	Maximum tare	Refer to par. [526] page 65		
40181	R/W	2	Secondary unit	Dec	Description	
				0	g	(Gram)
				1	kg	(Kilogram)
				2	t	(Ton)
				3	lb	(Libre)
				4	No unit	(without unit)
				5	N	(Newton)
				6	kN	(Kilonewton)
7	kLb	(Kilolibre)				
40183	R/W	2	Reserve			
40185	R/W	2	Calibration Commands	Decimal	Definition	
				0	None	

				188	Adjust Zero Calibration command
				220	Adjust Span Calibration command (first, load test weight value to 40187)
				23205	Apply the coefficients of eCal (first, load 40189, 40191 and 40193)
40187	R/W	2	Span Calibration Value		
40189	R/W	2	Total Load Cell capacity for eCal	eCal Coefficient s	
40191	R/W	2	Average mV/V value for eCal		
40193	R/W	2	Dead load value for eCal		
40195	R	2	Calibration Process Status & Errors	Bit	Definition
				B0	Ready for calibration
				B1	Zero calibration in process ...
				B2	Span calibration in process ...
				B3	Calibration Timeout - Restart calibration
				B4	ADC Error - Re-energize the instrument - If shown again, change the board.
				B5	Instrument cannot be calibrating - Check load cell cable - Re-energize the instrument
				B6	Instrument cannot be calibrating - Load cell signal is very low or too high
				B7	Calibration Error - Calibration loading is not enough - Check test weight loading - Check load cell connections
				B8	Calibration load value entry Error - Test weight is too small. Increase the weight
				B9	Scale unstable - Wait until scale become stable - Check grounding wiring
B10	The Calibration switch is not 'On' position. - Check the calibration DIP switch.				
40197	R/W	10	Reserve		
40207	R	2	Voltage of power supply	The value is indicated with 0.1 VDC increment for DC variant.	
40209	R	2	Load cell millivolt value (only FT-112 Panel)	Millivolt value of active scale is indicated with 0.01 mV increment. For example: 2.34 mV is indicated as integer 234 value.	
40211	R/W	2	Load parameter's defaults	Write 0x6BB6 value to load parameter's defaults.	
40213	R/W	2	Load factory defaults	Write 0x7CC7 value to load factory defaults.	
Applications					
40255	R/W	2	Application	Refer to parameter [311] page 57	
				0	No
				1	CHEC
				2	CLAS
				3	FILL
4	PEAK				
40257	R/W	2	Limits	Refer to parameter [312] page 57	

				0	VAL
				1	TOL
				2	%
40259	R/W	2	Information display	Refer to parameter [313] page 57	
				0	NO
				1	ID1T
				2	ID2T
40261	R/W	2	SmartAPP displaying	Refer to parameter [314] page 58	
				0	NO
				1	BAR
				2	COLO
				3	ALL
40263	R/W	2	Display color change	Refer to parameter [316] page 58	
				0	RAAY
				1	YAAR
				2	RBAY
				3	YABR
40265	R/W	2	The display color changing	Refer to parameter [317] page 58	
				0	STAB
				1	IMME
40267	R/W	2	Acoustic warning	Refer to parameter [318] page 58	
				0	NO
				1	OKAY
				2	OVER
				3	CROS
40269	R/W	2	Start method	Refer to parameter [321] page 58	
				0	AUTO
				1	MANU
				2	SAUT
				3	PORT
40271	R/W	2	Filling type	Refer to parameter [322] page 58	
				0	GROS
				1	NET
40273	R/W	2	Taring delay at filling	Refer to parameter [323] page 58	
40275	R/W	2	Totalization type	Refer to parameter [324] page 58	
				0	NO
				1	HORI
				2	VERT
40277	R/W	2	Grand total erase	Refer to parameter [325] page 58	
				0	MRC
				1	PASS
40279	R/W	2	Output changing	Refer to parameter [326] page 59	
				0	STAB
				1	IMME
40281	R/W	2	Peak displaying at peak hold.	Refer to parameter [315] page 58	
				0	PEAK
				1	LAST
				2	ALL

Programming steps of frequent used commands:

Reading a weight value:

1. Read 40009 and 40010.
2. Check error status,
3. If **there isn't any error**, read the weight value (gross, net or tare),
4. If there is an error, check the error code.

Zero Calibration procedure:

1. Check the bit B0 of 40195 which should be '1' to start adjustment.
2. Load the decimal '188' to 40185 to start Zero calibration.
3. Check the bit B1 of 40195 which is '1' during zero calibration process.
4. The bit B0 of 40195 changes to '1' at the end of the Zero calibration.
5. If one of error bits (B3 ~ B10) of 40195 is '1', check error code to understand the calibration error.

Span Calibration procedure:

1. Check the bit B0 of 40195. it should be '1' to start adjustment.
2. First load the span value to 40187-188 and then load the decimal '220' to 40185 to start Span calibration.
3. Check the bit B2 of 40195 which is '1' during span calibration process.
4. The bit B0 of 40195 changes to '1' at the end of the Span calibration.
5. If one of error bits (B3 ~ B10) of 40195 is '1', check error code to understand the calibration error.

EXPLANATION:

Attention: For hardware connection details, please refer to the related hardware descriptions in this manual.

Exception codes:

- 1: Function code is not supported.
- 2: Out of beginning and ending address range.
- 3: Invalid value entrance or wrong byte number.
- 4: Operation error.

Command Examples:

Performing Read and Write operations according (Modbus RTU High-Low) to hex system with the instrument set to address "0x01".

Description	Hex
Request weight data	01,03,00,00,00,02,C4,0B
Answer of request weight (weight value is 100000)	01,03,04,00,01,86,A0,38,4A
Request status data	01,03,00,07,00,02,75,CA
Taring	01,10,00,18,00,02,04,00,00,00,02,72,C4
Request tare data	01,03,00,02,00,02,65,CB
Answer of request tare (tare value is 10000)	01,03,04,00,00,27,10,E0,0F
Zero Command	01,10,00,18,00,02,04,00,00,00,01,32,C5
Request Calibration Status	01,03,00,C2,00,02,65,F7
Answer of request Calibration Status (Instrument is ready for calibration)	01,03,04,00,00,00,01,3B,F3
Zero Calibration	01,10,00,B8,00,02,04,00,00,00,BC,F8,CC
Span Calibration Command with Span value 50000	01,10,00,B8,00,04,08,00,00,00,DC,00,00,C3,50,94,84
Total LC capacity Command with Total LC capacity value 100000	01,10,00,B8,00,06,0C,00,00,00,EC,00,00,00,00,00,01,86,A0,D7,B9
Average mV/V Command with Average mV/V value 1.9999	01,10,00,B8,00,08,10,00,00,00,FA,00,00,00,00,00,00,00,00,00,00,00,00,00,4E,1F,8E,3D
Dead load Command with Dead load value 12345	01,10,00,B8,00,0A,14,00,00,00,AB,00,00,00,00,00,00,00,00,00,00,00,00,00,00,00,30,39,7F,06
Save the coefficients of eCal Command	01,10,00,B8,00,02,04,00,00,5A,A5,03,A6
Read digital inputs	01,03,00,28,00,02,44,03
Answer of digital inputs (Input-2 is active)	01,03,04,00,00,00,02,7B,F2
Read digital outputs	01,03,00,2A,00,02,E5,C3
Answer of digital outputs	01,03,04,00,00,00,04,FB,FO

(Output-3 is Active)	
Read Setpoint-1	01,03,00,2C,00,02,05,C2
Answer of Setpoint-1	01,03,04,00,00,03,E8,FA,8D
Load Set point 1 = 5000	01,10,00,2C,00,02,04,00,00,13,88,FC,B4

12.3 Ethernet TCP/IP

IMPORTANT NOTE: Modbus RTU and Modbus TCP interfaces require Modbus SD card at the SD2 card slot on the rear of the instrument.

Ethernet output of FT-112 Panel is programmable to BSI command set, Continuous data output, Fast continuous data output, Modbus TCP/IP High-Low, Modbus TCP/IP Low-High. The first three data structures, as shown in the table below, are described in the related sections.

Data Format	Description
BSI Command set	Refer to Page 117 .
Continuous	Refer to Page 109, 110 .
Fast Continuous	Refer to Page 110 .
Modbus TCP High-Low	Modbus TCP interfacing. Refer to Page 125 .
Modbus TCP Low-High	Modbus TCP interfacing. Refer to Page 125 .

Table 12-1 - Ethernet output interfacing

You can communicate with FT-112 Panel after programming Ethernet TCP/IP and Modbus TCP related parameters [15-].

12.3.1 Ethernet Parameters

Ethernet parameters can be adjusted by keys in programming mode. Refer to parameter block [15 -].


Parameters	Descriptions
Host Name	Device name of the instrument. Refer to parameter 255.
IP Address	Obtain IP address manually. Refer to parameter 152.
Local Port	Ethernet connection port of the instrument. Refer to parameter 156.
Gateway	Network point that acts as an entrance to another network. Refer to parameter 155.
Subnet Mask	Describes IP address can be used in network. Refer to parameter 154.
Primary DNS	Obtain primary DNS manually. Refer to parameter 159.
Secondary DNS	Obtain secondary DNS manually.
Remote Connection Check Box	Automatic connection to any device on the network. Refer to parameter 15E and 15F. Default is 'Disabled'.
Remote IP Address	IP address of the PC, Printer or Device to be connected automatically. Enter IP address of the remote device.
Remote Port	Ethernet connection point of PC, Printer or Device to be connected automatically. Enter port number of the remote device.
Password	Default password is 123456.
Set Defaults	Sets factory defaults.

Note: For Modbus TCP/IP Data Structure see Table on **Page 126**.

13.1 Profibus DP

In Profibus DPV1 interface, baud rate is detected automatically. Supported baud rates are 9.6 kbps, 19.2 kbps, 45.45 kbps, 93.75 kbps, 187.5 kbps, 500 kbps, 1.5 Mbps, 3 Mbps, 6 Mbps and 12 Mbps. No 'baud rate' instance exists. Refer to Profibus parameters, sub-block 19-, **GSD file** is available on www.flintec.com.

There are two LEDs near the Profibus connector:



1	(A) Operation mode LED
2	(B) Status LED
3	Profibus Connector

(A) Operation mode LED

State	Indication	Comment
Off	Not online /No power	Check power and cable
Green	On-line, data exchange	-
Flashing Green	On-line, clear	-
Flashing Red (2 flash)	PROFIBUS configuration error	Check GSD file configuration.

(B) Status LED

State	Indication	Comment
Off	Not power or not initialized	No power or Profibus module is in initialization state
Green	Initialized	
Flashing Green	Initialized, diagnostic event(s) present	Diagnostic is active
Red	Exception error	There is an exception error

13.1.1 Data Format

Data format of weight value can be programmable for Floating point (IEEE 754) or Integer. Refer to parameter 191.

13.1.2 GSD Configuration

Profibus data consist of 2x Input-2 words and 2x Output-2 words.

The **GSD file** is available in on internet www.flintec.com..

GSD configuration for PLC programmers is shown in Figure 13.1.




Figure 13.1 - GSD Configuration

GSD Configuration	Description
Input 2 words	1 st Dword (FT-112 Panel Output to PLC Input)
Input 2 words	2 nd Dword (FT-112 Panel Output to PLC Input)
Output 2 words	1 st Dword (PLC Output to FT-112 Panel Input)
Output 2 words	2 nd Dword (PLC Output to FT-112 Panel Input)

13.1.3 Profibus DP Data Structure

For the Data Structure for Profibus see Appendix 1, **page 153**

13.2 Profinet


Profinet interface of the weighing instrument can be done via hub switch or serial bus over two Profinet ports.

1. Serial bus connection. You may connect instruments serial to your Profinet bus via two ports.
2. Star connection. If you connect the instrument to your PLC via hub switch, you can use P1 or P2 port on the instrument. You may change the port, if there is any malfunction on a port.

The rate of Profinet interface is 100Mbit and full duplex.

GSDML file is available on www.flintec.com.

There are 4 announcement LEDs on the instrument to indicate the interface status as shown below.



1	(A) Network Status LED
2	(B) Module Status LED
3	Link/Activity LED (port 1)
4	Link/Activity LED (port 2)
5	P1 interface (port 1)
6	P2 interface (port 2)

(A) Network Status LED

LED State	Description	Comment
Off	Not online /No power	Check power and cable
Green	On-line RUN	-
Green, flashing	On-line STOP	-

(B) Module Status LED

LED State	Description	Comment
Off	Not power or not initialized	No power or Profinet module is in initialization state
Green	Normal operation	
Green, 1 flash	Initialized, diagnostic event(s) present	Diagnostic is active
Red	Exception error	There is an exception error
Red, 1 flash	Configuration Error	Check GSDML configuration
Red, 2 flashes	IP Address Error	IP address not set
Red, 3 flashes	Device Name Error	Device name not set
Red, 4 flashes	Internal Module Error	Re-energize the instrument. If shown again, change the board.

In the case of red LED warning, check cabling, configuration, IP address and device name. Power off the instrument and re-energize the instrument 30 seconds later.

LINK/Activity LED

LED State	Description	Comment
Off	No Link	No link, no communication present
Green	Link	Ethernet link established, no communication present
Green, flickering	Activity	Ethernet link established, communication present

13.2.1 Data Format

Data format of weight value can be programmable for Floating point (IEEE 754) or Integer. Refer to parameter [191].

13.2.2 Profinet Parameters

Ethernet parameters can be adjusted by keys in programming mode. Refer to parameter block [15-]. Additionally, Ethernet parameters can be set up by Indface2x PC software over Local Network Area or by Flintec's set up PC software. Both software are available on www.flintec.com .

Note: Station name is 'scale-1' as default.

Parameters	Descriptions
DHCP	Dynamic Host Configuration Protocol automates network parameters if it is enabled.
Host Name	Device name of the instrument. Refer to parameter 196.
IP Address	If DHCP is disabled, obtain IP address manually. Refer to parameter 192.
Gateway	If DHCP is disabled, obtain default gateway manually. Refer to parameter 195.
Subnet Mask	If DHCP is disabled, obtain subnet mask manually. Refer to parameter 194.
Primary DNS	If DHCP is disabled, obtain primary DNS manually. Refer to parameter 199.
Secondary DNS	If DHCP is disabled, obtain secondary DNS manually.
Password	Default password is 123456.

13.2.3 GSDML Configuration

Profinet data consist of 2 pcs Input-2 words and 2 pcs Output-2 words. GSDML configuration for PLC programmers is shown in Figure 13.3.




Figure 13.2 – Location of Hardware catalog




Figure 13.3 - GSDML Configuration

GSDML Configuration	Description
Input 2 word_1	1 st Dword (FT-112 Panel Output to PLC Input)
Input 2 word_2	2 nd Dword (FT-112 Panel Output to PLC Input)
Output 2 word_1	1 st Dword (PLC Output to FT-112 Panel Input)
Output 2 word_2	2 nd Dword (PLC Output to FT-112 Panel Input)

13.2.4 Profinet Data Structure

For the Data Structure for Profinet see Appendix 1, page 153


13.3 CANopen

After setting related parameters you can communicate with FT-112 Panel via CANopen network.

EDS file is available on www.flintec.com.

Automatically detected and supported baud rates are 10 kbps, 50 kbps, 100 kbps, 125 kbps, 250 kbps, 500 kbps, 800 kbps, 1 Mbps, Autobaud (default).

There are 2 LED's near the CANopen connector which are;



1	(A) RUN LED
2	(B) ERROR LED
3	CANopen interface

(A) Run LED

State	Indication	Comment
Off	Not online / No power	Check power and cable
Green	On-line, data exchange	-
Green, blinking	On-line, initializing	-
Green, single flash	Stopped	Check hardware damages
Green, flickering	Auto baudrate detection in progress	-
Red	CANopen configuration error	Check EDS file

(B) Error LED

State	Indication	Comment
Off	-	No power or CANopen module is in initialization state
Red, single flash	Warning limit reached	A bus error counter reached or exceeded its warning level
Red, flickering	LSS	LSS services in progress
Red, double flash	Error count event	A guard- (NMT-Slave or NMT-master) or heartbeat event (Heartbeat consumer) has occurred.
Red	Bus off (Fatal Event)	Bus off.

13.3.1 Data Format

Data format of weight value can be programmable for Floating point (IEEE 754) or Integer. Refer to parameter [191].

13.3.2 EDS Configuration

CANopen data structures consist of TxPDO (64 bit) and RxPDO (64 bit). EDS configuration for PLC programmers is shown in Figure 13.4.




Figure 13.4 - EDS Configuration

EDS Configuration	Description
TxPDO 1 (4 words)	Unsigned Long (FT-112 Panel Output to PLC Input)
RxPDO 1 (4 words)	Unsigned Long (PLC Output to FT-112 Panel Input)

13.3.3 CANopen Data Structure

For the Data Structure for Profinet see Appendix 2, page 164

13.4 EtherNet/IP


EtherNet/IP interface of the weighing instrument can be done via hub switch or serial bus over two EtherNet/IP ports.

1. Serial bus connection of instruments. You may connect instruments serial to your EtherNet/IP bus via two ports.
2. Star connection. If you connect the instrument to your PLC via hub switch, you can use P1 or P2 port on the instrument. You may change the port, if there is any malfunction on port in usage.

The EtherNet/IP interface supports 10/100Mbit, full or half duplex operation.

EDS file for two port EtherNet/IP is available on www.flintec.com

There are 4 announcement LEDs on the instrument to indicate the interface status as shown below.



1	(A) Network Status LED
2	(B) Module Status LED
3	Link/Activity LED (port 1)
4	Link/Activity LED (port 2)
5	P1 interface (port 1)
6	P2 interface (port 2)

(A) Network Status LED

LED State	Description
Off	No IP address
Green	Online, one or more connections established (CIP Class 1 or 3)
Green, flashing	Online, no connections established
Red	Duplicate IP address, FATAL error
Red, flashing	One or more connections timed out (CIP Class 1 or 3)

(B) Module Status LED

LED State	Description
Off	No power
Green	Controlled by a scanner in run state
Green, flashing	Not configured, or scanner in idle state
Red	Major fault (EXCEPTION state, FATAL error etc.)
Red, flashing	Recoverable fault(s)

In the case of red LED warning, check cabling, configuration, IP address and device name. Power off the instrument and reenergize the instrument 30 seconds later.

LINK/Activity LED

LED State	Description
Off	No link, no activity
Green	Link (100 Mbit/s) established
Green, flickering	Activity (100 Mbit/s)
Yellow	Link (10 Mbit/s) established
Yellow, flickering	Activity (10 Mbit/s)

13.4.1 Data Format

Data format of weight value can be programmable for Floating point (IEEE 754) or Integer. Refer to parameter [191].

13.4.2 EtherNet/IP Parameters

Ethernet parameters can be adjusted by keys in programming mode. Refer to parameter block [19-]. Additionally, Ethernet parameters can be set up by Indface2x PC software over Local Network Area or by Flintec’s set up PC software. Both software are available on www.flintec.com .

Parameters	Descriptions
Host Name	Device name of the instrument.
DHCP	Dynamic Host Configuration Protocol automates network parameters if it is enabled.
IP Address	If DHCP is disabled, obtain IP address manually. Refer to parameter 192.
Gateway	If DHCP is disabled, obtain default gateway manually. Refer to parameter 195.
Subnet Mask	If DHCP is disabled, obtain subnet mask manually. Refer to parameter 194.
Primary DNS	If DHCP is disabled, obtain primary DNS manually.
Secondary DNS	If DHCP is disabled, obtain secondary DNS manually.
Password	Default password is 123456.

13.4.3 EDS Configuration

EtherNet/IP data structures consist of 2 pcs Input-2 words and 2 pcs Output-2 words. EDS configuration for PLC programmers is shown in Figure 13.5 and Figure 13.6.




Figure 13.5 – Configuration of module properties without EDS file




Figure 13.6 – Configuration of module properties with EDS file

Data Length	Description
Input 2 words	1 st Dword (FT-112 Panel Output to PLC Input)
Input 2 words	2 nd Dword (FT-112 Panel Output to PLC Input)
Output 2 words	1 st Dword (PLC Output to FT-112 Panel Input)
Output 2 words	2 nd Dword (PLC Output to FT-112 Panel Input)

13.4.4 EtherNet/IP Data Structure

For the Data Structure for EtherNET/IP see Appendix 1, page 153

13.5 EtherCAT


EtherCAT interface of the weighing instrument can be done via hub switch or serial bus over two EtherCAT ports.

1. Serial bus connection of instruments. You may connect instruments serial to your EtherCAT bus via two ports.
2. Star connection. If you connect the instrument to your PLC via hub switch, you can use P1 port on the instrument.

The EtherCAT interface supports 100Mbit, full duplex operation.

ESI file for two port EtherCAT is available on www.flintec.com.

There are 4 announcement LEDs on the instrument to indicate the interface status as shown below. The meanings of these LED's are;



1	(A) RUN LED
2	() ERR LED
3	Link/Activity (IN port) Led
4	Link/Activity (OUT port) Led
5	EtherCAT (IN port)
6	EtherCAT (OUT port)

(A) RN LED

LED State	Description
Off	INIT
Green	OPERATIONAL
Green, blinking	PRE-OPERATIONAL
Green, single flash	SAFE-OPERATIONAL
Red	(Fatal Event)

(B) ERR LED

LED State	Description
Off	No any error (or no power)
Red, blinking	Invalid configuration; State change received from master is not possible due to invalid register or object settings.
Red, single flash	Unsolicited state change; Slave device application has changed the EtherCAT state autonomously.
Red, double flash	Application watchdog timeout
Red	Application controller failure

In the case of red LED warning, check cabling, configuration, IP address and device name. Power off the instrument and reenergize the instrument 30 seconds later.

LINK/Activity LED

LED State	Description
Off	No link, no activity
Green	Link sensed, no activity
Green, flickering	Link sensed, activity exist.

13.5.1 Data Format

Data format of weight value can be programmable for Floating point (IEEE 754) or Integer. Refer to parameter [191].

13.5.2 ESI Configuration

EtherCAT data structures consist of 2 pcs Input-2 words and 2 pcs Output-2 words. ESI configuration for PLC programmers is shown in Figure 13.7.




Figure 13.7 – Configuration of module properties for Beckhoff

Input/Output	Definition	Description
DI TxPDO-Map	SubIndex 001	1 st Dword (<i>FT-112 Panel Output to PLC Input</i>)
	SubIndex 002	2 nd Dword (<i>FT-112 Panel Output to PLC Input</i>)
DO RxPDO-Map	SubIndex 001	1 st Dword (<i>PLC Output to FT-112 Panel Input</i>)
	SubIndex 002	2 nd Dword (<i>PLC Output to FT-112 Panel Input</i>)


13.5.3 EtherCAT Data Structure

For the Data Structure for EtherCAT see Appendix 1, page 153

13.6 CC-Link

After setting related parameters you can communicate with FT-112 Panel via CC-Link network. Supported CC-Link version is v1.10 and baud rates are 156 kbps (default), 625 kbps, 2,5 Mbps, 5 Mbps and 10 Mbps.

There are 2 LEDs near the CC-Link connector which are.



1	(A) RUN LED
2	(B) ERR LED
3	CC-Link interface

(A) Run LED

State	Indication
Off	No network participation, timeout status (no power)
Green	Participating, normal operation
Red	Major fault (FATAL error)

(B) Error LED

State	Indication
Off	No error detected (no power)
Red	Major fault (Exception or FATAL event)
Red, flickering	CRC error (temporary flickering)
Red, flashing	Station Number or Baud rate has changed since startup (flashing)

In the case of red LED warning, check cabling, configuration and station number. Power off the instrument and reenergize the instrument 30 seconds later.

13.6.1 Data Format

Data format of weight value can be programmable for Floating point (IEEE 754) or Integer. Refer to parameter [191].

13.6.2 CC-Link Configuration

The weighing indicator has occupied one station area on CC-Link network and station type of weighing indicator **must be programmed as 'Remote device station' in the PLC software**. CC-Link configuration for PLC programmers is shown in Figure 13.8.




Figure 13.8 – Station information

Input/Output	Definition	Description
Remote Register (RWr)	RWr0, RWr1	1 st Dword Input (<i>FT-112 Panel Output to PLC Input</i>)
	RWr2, RWr3	2 nd Dword Input (<i>FT-112 Panel Output to PLC Inpu</i>)
Remote Input (RX)	RX0 ~ RX31	Not used
Remote Register (RWw)	RWw0, RWw1	1 st Dword Output (<i>PLC Output to FT-112 Panel Input</i>)
	RWw2, RWw3	2 nd Dword Output (<i>PLC Output to FT-112 Panel Input</i>)
Remote Output (RY)	RY0 ~ RY31	Not used

13.6.3 CC-Link Data Structure

For the Data Structure for CC-Link see Appendix 1, [page 153](#)

13.7 Powerlink


Powerlink interface of the weighing instrument can be done via hub switch or serial bus over two Powerlink ports.

1. Serial bus connection of instruments. You may connect instruments serial to your Powerlink bus via two ports.
2. Star connection. If you connect the instrument to your PLC via hub switch, you can use P1 or P2 port on the instrument. You may change the port, if there is any malfunction on port in usage.

The Powerlink interface is 100Mbit and half duplex. XDD file for two ports.

Powerlink is available on www.flintec.com.

There are 4 announcement LEDs on the instrument to indicate the interface status as shown below.



1	(A) Status LED
2	(B) Error LED
3	Link/Activity LED (port 1)
4	Link/Activity LED (port 2)
5	P1 interface (port 1)
6	P2 interface (port 2)

(A) Status LED

LED State	Description
Off	Module is off, initializing, or not active.
Green, fast flashing ^a	NMT_CS_BASIC_ETHERNET Basic Ethernet state: no POWERLINK traffic has been detected.
Green, single flash	NMT_CS_PRE_OPERATIONAL_1. Only asynchronous data.
Green, double flash	NMT_CS_PRE_OPERATIONAL_2. Asynchronous and synchronous data. No PDO data. ^b
Green, triple flash	NMT_CS_READY_TO_OPERATE. Ready to operate. Asynchronous and synchronous data. No PDO data. ^b
Green	NMT_CS_OPERATIONAL. Fully operational. Asynchronous and synchronous data. PDO data is sent and received.
Green, slow flashing ^c	NMT_CS_STOPPED Module stopped (for controlled shutdown, for example). Asynchronous and synchronous data. No PDO data. ^b
Red	If the ERROR LED also is red, a fatal event was encountered.

a. On 50 ms, off 50 ms.

b. Any process data sent is declared not valid and received process data must be ignored in this state.

c. On 200 ms, off 200 ms.

(B) Error LED

LED State	Description
Off	No error
Red	If the STATUS LED is not red, a non-fatal error has been detected. If the STATUS LED is red, a fatal event was encountered.

In the case of red LED warning, check cabling, configuration, IP address and device name. Power off the instrument and reenergize the instrument 30 seconds later.

LINK/Activity LED

LED State	Description
Off	No link.
Green	Link, no traffic.
Green, flashing	Link and traffic.

13.7.1 Data Format

Data format of weight value can be programmable for Floating point (IEEE 754) or Integer. Refer to parameter [191].

13.7.2 XDD Configuration

Powerlink data structures consist of 2 pcs Input-2 words and 2 pcs Output-2 words. XDD configuration for PLC programmers is shown in Figure 13.9.




Figure 13.9 – Configuration of module properties with XDD file

Data Length	Description
_1_Dword_Input_I2001_S01	1 st Dword (FT-112 Panel Output to PLC Input)
_2_Dword_Input_I2001_S02	2 nd Dword (FT-112 Panel Output to PLC Input)
_1_Dword_Output_I2002_S01Out	1 st Dword (PLC Output to FT-112 Panel Input)
_2_Dword_Output_I2002_S02Out	2 nd Dword (PLC Output to FT-112 Panel Input)


13.7.3 Powerlink Data Structure

For the Data Structure for Powerlink see Appendix 1, [page 153](#)

13.8 CC-Link IE Field

After setting related parameters you can communicate with FT-112 Panel via CC-Link network. (in preparation).

There are 2 LED's near the CC-Link connector which are;



1	(A) NS/RUN LED
2	(B) AS/ERROR LED
3	Link/Activity LED (port 1)
4	Link/Activity LED (port 2)
5	P1 interface (port 1)
6	P2 interface (port 2)

(A) NS/RUN LED

State	Indication
Off	No power Operation abnormal
Green	Operation normal
Red	Fatal Event <i>If NS/RUN and AS/ERR turn red, this indicates a fatal event.</i>

(B) AS/ERROR LED

State	Indication
Off	No error detected (or no power)
Red	Error <i>An error occurred in the device. If NS/RUN is off, the device enters state EXCEPTION. If NS/RUN and AS/ERR turn red, this indicates a fatal event.</i>

In the case of red LED warning, check cabling, configuration, and station number. Power off the instrument and reenergize the instrument 30 seconds later.

13.8.1 Data Format

Data format of weight value can be programmable for Floating point (IEEE 754) or Integer. Refer to parameter [191].

13.8.2 CC-Link IE Configuration

The weighing indicator has occupied one station area on CC-Link network and station type of weighing indicator must be programmed as 'Remote device station' in the PLC software. CC-Link configuration for PLC programmers is shown in Figure 13.8.




Figure 13.10 – Station information

Input/Output	Definition	Description
Remote Register (RWr)	RWr0, RWr1	1 st Dword Input (<i>FT-112 Panel Output to PLC Input</i>)
	RWr2, RWr3	2 nd Dword Input (<i>FT-112 Panel Output to PLC Input</i>)
Remote Input (RX)	RX0 ~ RX31	Not used
Remote Register (RWw)	RWw0, RWw1	1 st Dword Output (<i>PLC Output to FT-112 Panel Input</i>)
	RWw2, RWw3	2 nd Dword Output (<i>PLC Output to FT-112 Panel Input</i>)
Remote Output (RY)	RY0 ~ RY31	Not used

13.8.3 CC-Link IE Data Structure

For the Data Structure for Powerlink see Appendix 1, page 153

14 APPENDIX 1: DATA STRUCTURE PROFIBUS, PROFINET, ETHERNET/IP, ETHERCAT, CC-LINK, POWERLINK, CC-LINK IE

FT-112 Panel Output to PLC Input

Bitwise of a Dword:

Dword (Only read)	B31	B30	B29	B28	B27	B26	B25	B24	B23	B22	B21	B20	B19	B18	B17	B16
	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0

1st Dword (INPUT) (RWr0, RWr1)	By default, Actual weight value is represented. To represent other weight or calibration status, refer to next Dword.															
2nd Dword (INPUT) (RWr2, RWr3)				Out 5	Out 4	Out 3	Out 2	Out 1					In 4	In 3	In 2	In 1
	Error codes of FT-112 Panel				Unit		P.Tare	Centre of zero	Gross Net	SD	Read command response					Cmd Flg

FT-112 Panel Output to PLC Input 2nd Dword

Bit Number	2 nd Dword Description			
B31... B24	Digital Outputs	Output bit status (Active = 1)		
B23... B16	Digital Inputs	Input bit status (Active = 1)		
B15... B12	Error Codes of FT-112 Panel	Bin	Dec	Descriptions
		0000	0	No error found
		0001	1	ADC out
		0010	2	ADC over
		0011	3	ADC under
		0100	4	System Error
		0101	5	In programming mode
		0110	6	Low/High Voltage Error
0111	7	Tilt Switch is active		
B11	Unit	0	First unit	
		1	Second unit	
B10	Not used			
B9	Preset Tare	0	Preset tare is passive	
		1	Preset tare is active	
B8	Centre of zero	0	Weight is out of zero range	
		1	Weight is in zero range	
B7	Indication	0	Gross	
		1	Net	
B6	Stability Detection	0	Stable	
		1	Unstable	

B5 ... B1	Read Command Response	Bin	Dec	Descriptions				
		0000 0	0	Actual weight (if the indication is in Net)				
		00001	1	Gross weight				
		00010	2	Tare weight				
		00011	3	ALL Status (Refer to Table 14-1)				
		00100	4	Calibration Status (Refer to Table 14-2)				
		00101	5	Last print value				
		00110	6	Quantity of M+				
		00111 01010	7 10	Not used				
		01011	11	CN (Label number)				
		01100	12	Totalization of M+				
		01101	13	Grand Total				
		01110	14	Not used				
		01111	15	B. weighing	Filling	C. weighing	Classifying	Peak hold
				SetPoint-1	Target	Target	Target	Follow
		10000	16	SetPoint-2	Coarse	Low	--Low	Mid Decr.
		10001	17	SetPoint-3	Fine	High	-Low	End Decr.
		10010	18	SetPoint-4	TareMin	Empty	+High	Stop
		10011	19	SetPoint-5	TareMax	Not used	++High	Alarm
		10100	20	Not used	Empty	Not used	Empty	Empty
		10101	21	SetPoint-1 Low		Only available for Threshold and Window feature. Refer to sub-block 36-, page 61 to see the availabilities.		
		10110	22	SetPoint-2 Low				
		10111	23	SetPoint-3 Low				
		11000	24	SetPoint-4 Low				
		11001	25	SetPoint-5 Low				
		11010 11110	26 30	Not used				
		11111	31	Expanded Commands List (Refer to Table 14-3)				
BO	CMD Flag	Toggles		The command is applied successfully				

ALL Status (always 32 bit integer)

1st Dword (input) descriptions when read command is 'ALL Status'. Refer to 2nd Dword of PLC Output to FT-112 Panel Input.

Bit Number	1 st Dword (input) Description	
B31	0	None
	1	No decimal point
B30	0	None
	1	Decimal point is X.X
B29	0	None
	1	Decimal point is X.XX
B28	0	None
	1	Decimal point is X.XXX
B27	0	None
	1	Decimal point is X.XXXX
B26 ... B16	Not in use	
B15	0	Passive
	1	Active
B14	0	Passive
	1	Active
B13	0	Passive
	1	Active

B12	Centre of zero	0	Weight is out of zero range
		1	Weight is in zero range
B11	Key lock status	0	Passive
		1	Active
B7-B10	Not used		
B6	Unit indication	0	First Unit (power on unit)
		1	Second Unit
B5	Power On Zero	0	Not power on zeroed
		1	Zeroed with power on zero
B4	Preset Tare	0	Preset tare is passive
		1	Preset tare is active
B3	Indication	0	Gross mode
		1	Net mode
B2	Motion Detection	0	Stable
		1	Unstable
B1	Actual Weight or Dynamic Result	0	Weight is actual weight
		1	Weight is dynamic result
B0	Dynamic Operation	0	Dynamic is inactive
		1	Dynamic weight is calculating

Table 14-1– ALL Status table

Calibration Status (always 32 bit integer)

1st Dword (input) descriptions when read command is 'Calibration Status'. Refer to 2nd Dword of PLC Output to FT-112 Panel Input

Bit Number	1 st Dword (input) Description	
B31... B11	Not in use	
B10	0	No Error
	1	The Calibration DIP switch is not 'On' position. - Check the calibration DIP switch.
B9	0	No Error
	1	Scale unstable - Wait until scale become stable - Check grounding wiring
B8	0	No Error
	1	Calibration load value entry Error - Test weight is too small. Increase the weight
B7	0	No Error
	1	Calibration Error - Calibration loading is not enough - Check test weight loading - Check load cell connections
B6	0	No Error
	1	Instrument cannot be calibrating - Load cell signal is very low or too high
B5	0	No Error
	1	Instrument cannot be calibrating - Check load cell cable - Re-energize the instrument
B4	0	No Error
	1	ADC Error - Re-energize the instrument - If shown again, change the board.
B3	0	No Error
	1	Calibration Timeout - Restart calibration

B2	0	None
	1	Span calibration in process ...
B1	0	None
	1	Zero calibration in process ...
B0	0	Not ready for calibration
	1	Ready for calibration

Table 14-2 - Calibration status

PLC Output to FT-112 Panel Input

Bitwise of a Dword:

Dword (R/W)	B31	B30	B29	B28	B27	B26	B25	B24	B23	B22	B21	B20	B19	B18	B17	B16
	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0

1st Dword (OUTPUT) (RWr0, RWr1)	Next Dword defines the usage of this Dword.																			
2nd Dword (OUTPUT) (RWr2, RWr3)				Out 5	Out 4	Out 3	Out 2	Out 1	Expanded Commands List											
	Not in use					Command List				Read Data Selection				New CMD						

PLC Output to FT-112 Panel Input 2nd Dword

Bit Number	2 nd Dword descriptions							
B31...B24	Set / Reset digital outputs							
B23...B16	Expanded Commands List (Refer to Table 14-3)							
B15...B11	Not in use							
B10 ... B6	Command List	Bin	Dec	Commands				
		0000 0	0	None command is activated				
		0000 1	1	Zero				
		0001 0	2	Tare				
		00011	3	Clear				
		0010 0	4	Print				
		00101	5	Adjust zero calibration			Calibration	
		00110	6	Adjust span calibration ⁽¹⁾				
		00111	7	Total Load Cell Capacity ⁽¹⁾			eCal Coefficients	
		0100 0	8	Average mV/V value ⁽¹⁾				
		01001	9	Dead Load value ⁽¹⁾				
		01010	10	Save the coefficients of eCal			Refer to par. [613]	
		01011	11	CN (Label number) ⁽¹⁾				
		01100	12	Preset Tare ⁽¹⁾				
		01101	13	Grand Total				
		01110	14	Not used				
		01111	15	B. weighing	Filling	C. weighing	Classifying	Peak hold
SetPoint-1	Target			Target	Target	Follow		
1000 0	16	SetPoint-2	Coarse	Low	--Low	Mid Decr.		
10001	17	SetPoint-3	Fine	High	-Low	End Decr.		
10010	18	SetPoint-4	TareMin	Empty	+High	Stop		

		10011	19	SetPoint-5	TareMax	Not used	++High	Alarm		
		10100	20	Not used	Empty	Not used	Empty	Empty		
		10101	21	SetPoint-1 Low		Only available for Threshold and Window feature. Refer to sub-block 36-, page 61 to see the availabilities.				
		10110	22	SetPoint-2 Low						
		10111	23	SetPoint-3 Low						
		11000	24	SetPoint-4 Low						
		11001	25	SetPoint-5 Low						
		11010 11110	26 30	Not used						
		11111	31	Use the Expanded Command list (Refer to Table 14-3)						
B5 ... B1	Read Data Selection	0000 0	0	Actual weight (Net if the indication is in Net)						
		0000 1	1	Gross weight						
		0001 0	2	Tare weight						
		00011	3	ALL Status (Refer to Table 14-1)						
		0010 0	4	Calibration Status (Refer to Table 14-2)						
		00101	5	Last print value						
		00110	6	Quantity of M+						
		00111 01010	7 10	Not used						
		01011	11	CN (Label number)						
		01100	12	Totalization of M+						
		01101	13	Grand Total						
		01110	14	Not used						
		01111	15	B. weighing	Filling	C.weighing	Classifying	Peak hold		
				SetPoint-1	Target	Target	Target	Follow		
		1000 0	16	SetPoint-2	Coarse	Low	--Low	Mid Decr.		
		10001	17	SetPoint-3	Fine	High	-Low	End Decr.		
		10010	18	SetPoint-4	TareMin	Empty	+High	Stop		
		10011	19	SetPoint-5	TareMax	Not used	++High	Alarm		
		10100	20	Not used	Empty	Not used	Empty	Empty		
				10101	21	SetPoint-1 Low		Only available for Threshold and Window feature. Refer to sub-block 36-, page 61 to see the availabilities.		
				10110	22	SetPoint-2 Low				
				10111	23	SetPoint-3 Low				
				11000	24	SetPoint-4 Low				
				11001	25	SetPoint-5 Low				
				11010 11110	26 30	Not used				
				11111	31	Use the Expanded Command list (Refer to Table 14-3)				
		BO	New CMD	Toggle		Apply commands which are listed in this table.				

(1) Write this command after writing values to 1st Dword, then apply this command with New CMD

Expanded Command List

Here 1st Dword (Input) is the data receiving from PLC and the "B23... B16" bits describe below.

Bit No	Description						
B23...B16	Expanded Commands List	Bin	Dec	Commands			
		00000000	0	R	Voltage of power supply ⁽²⁾ The value is indicated with 0.1 VDC increment for DC variant.		
		00000001	1	R	Load cell millivolt value ⁽²⁾ (Only FT-112 Panel) Millivolt of active scale is indicated with 0.01 mV increment.		
		00000010	2	R	Command status ⁽²⁾	Dec	Descr. of 1st Dword
						0	None
						1	Command is processing
						2	Command is done
		00000011	3	R/W	Reprint the last label ^{(1) (2)}	0	None
						1	Reprint the last label
		00000100	4	R/W	High resolution ^{(1) (2)}	0	Enable
						1	Disable
		00000101	5	W	Unit change ⁽¹⁾	0	From first to second unit
						1	From second to first unit
		00000110	6	R/W	Key lock ^{(1) (2)}	0	Enable
						1	Disable
		00000111	7	W	Dynamic operation ⁽¹⁾	0	Dynamic reset
						1	Dynamic start
		00001000	8	W	Totalization operation ⁽¹⁾	0	None
						1	M+ key
						2	Totalization Print
						3	Totalization Cancel
		00001001	9	W	SmartAPP operation ⁽¹⁾	0	Reset
						1	Start
		00001010	10	Not used			
		00001011	11	Not used			
		00001100	12	R/W	Basic Peak	0	Enable
						1	Disable
		00001101	13	R/W	Hold	0	Enable
						1	Disable
		00001110	14	Not used			
		00110100	52	Not used			
		00110101	53	R	1 st Peak value ⁽²⁾	Only available for Peak hold application. Refer to Section 9.4, page91.	
00110110	54	R	2 nd Peak value ⁽²⁾				
00110111	55	R	3 rd Peak value ⁽²⁾				
00111000	56	R	4 th Peak value ⁽²⁾				
00111001	57	R	5 th Peak value ⁽²⁾				
00111010	58	R	6 th Peak value ⁽²⁾				
00111011	59	R	7 th Peak value ⁽²⁾				
00111100	60	R	8 th Peak value ⁽²⁾				
00111101	61	R	9 th Peak value ⁽²⁾				
00111110	62	R	10 th Peak value ⁽²⁾				

		00111111	63	R/ W	Dynamic filter ^{(1) (2)}	Refer to par. 332 page 59	
		0100000 0	64	R/ W	Filter ^{(1) (2)}	0	No
						1	Very Low
						2	Low
						3	Medium
						4	High
		5	Very High				
		0100000 1	65	R/ W	Power on zero ^{(1) (2)}	0	Disable
						1	± %2
						2	± %2LK
						3	± %10
						4	+ %15, - %5
		5	± %20				
		0100001 0	66	R/ W	Zeroing Range ⁽¹⁾ ⁽²⁾	0	Disable
						1	± 2%
						2	± 3%
						3	± 20%
						4	± 50%
		0100001 1	67	R/ W	Auto Zero Tracking ^{(1) (2)}	0	Disable
						1	± 0,3d
						2	± 0,5d
						3	± 1d
						4	± 2d
		5	± 3d				
		0100010 0	68	R/ W	Tare ^{(1) (2)}	0	No
						1	Multi tare
						2	Tare only at gross
						3	Preset tare
						4	Preset tare at gross
		0100010 1	69	R/ W	Stability Detection Range ^{(1) (2)}	0	± 0,3d
						1	± 0,5d
						2	± 1d
						3	± 2d
						4	± 3d
						5	± 4d
		6	Disable				
		0100011 0	70	R/ W	Stability Time ^{(1) (2)}	Refer to par. [517] page 64	
		0100011 1	71	R/ W	Unit ^{(1) (2)}	0	g
						1	kg
						2	t
						3	lb
						4	No unit
						5	N
						6	kN
						7	kLb
		0100100 0	72	R/ W	Range ^{(1) (2)}	0	Single range
						1	2 x Multi Range
						2	3 x Multi Range
						3	2 x Multi Interval
						4	3 x Multi Interval
		0100100 1	73	R/ W	Capacity-1 ^{(1) (2)}	Refer to par. 523 on page 65	
		0100101 0	74	R/ W	Decimal point-1 ^{(1) (2)}	0	XXXXOO
						1	XXXXXO

				2	XXXXXX
				3	XXXXX.X
				4	XXXX.XX
				5	XXX.XXX
01001011	75	R/ W	Increment-1 ⁽¹⁾ ⁽²⁾	0	X1
				1	X2
				2	X5
01001100	76	R/ W	Capacity-2 ⁽¹⁾ ⁽²⁾		
01001101	77	R/ W	Decimalpoint-2 ⁽¹⁾ ⁽²⁾		
01001110	78	R/ W	Increment-2 ⁽¹⁾ ⁽²⁾		
01001111	79	R/ W	Capacity-3 ⁽¹⁾ ⁽²⁾		
01010000	80	R/ W	Decimalpoint-3 ⁽¹⁾ ⁽²⁾		
01010001	81	R/ W	Increment-3 ⁽¹⁾ ⁽²⁾		
01010010	82	R/ W	Limit of Indication ⁽¹⁾ ⁽²⁾	0	Over indication after Max
				1	1 division more than Max
				2	5 division more than Max
				3	9 division more than Max
				4	2% more than Max
				5	5% more than Max
01010011	83	R/ W	Tare type ⁽¹⁾ ⁽²⁾	0	Subtractive tare
				1	Additive tare
01010100	84	R/ W	Maximum tare ⁽¹⁾ ⁽²⁾	Refer to par. [526] page 65	
01010101	85	R/ W	Secondary unit ⁽¹⁾ ⁽²⁾	0	g
				1	kg
				2	t
				3	lb
				4	No unit
				5	N
				6	kN
				7	kLb
01010110 01011111	86 95	Not Used			
01100000	96	R/ W	APPLICA ⁽¹⁾ ⁽²⁾ Refer to par. 311 page 57	0	No
				1	CHEC
				2	CLAS
				3	FILL
				4	PEAK
01100001	97	R/ W	LIMITS ⁽¹⁾ ⁽²⁾ Refer to par. 312 page 57	0	VAL
				1	TOL
				2	%
01100010	98	R/ W	INFODIS ⁽¹⁾ ⁽²⁾ Refer to par. 313 page 57	0	No
				1	ID1T
				2	ID2T
01100011	99	R/ W	DISPLAY ⁽¹⁾ ⁽²⁾ Refer to par.	0	No
				1	BAR

				314 page 58	2	COLO
					3	ALL
	01100100	100	R/ W	COLORS ^{(1) (2)} Refer to par. 316 page 58	0	RAAY
					1	YAAR
					2	RBAY
					3	YABR
	01100101	101	R/ W	CHANGE ^{(1) (2)} Refer to par. 317 page 58	0	STAB
					1	IMME
	01100110	102	R/ W	ACOUSTI ^{(1) (2)} Refer to par. 318 page 58	0	No
					1	OKAY
					2	OVER
					3	CROSS
	01100111	103	R/ W	START ^{(1) (2)} Refer to par. 321 page 58	0	AUTO
					1	MANU
					2	SAUT
					3	PORT
	01101000	104	R/ W	FILLING ^{(1) (2)} Refer to par. 322 page 58	0	GROS
					1	NET
	01101001	105	R/ W	TAREDELA ^{(1) (2)}	Refer to par. 323 on page 58	
	01101010	106	R/ W	TOTAL ^{(1) (2)} Refer to par. 324 page 58	0	No
					1	HORI
					2	VERT
	01101011	107	R/ W	GT ERASE ^{(1) (2)} Refer to par. 325 page 58	0	MRC
					1	PASS
	01101100	108	R/ W	OUTPUTS ^{(1) (2)} Refer to par. 326 page 59	0	STAB
					1	IMME
	01101101	109	R/ W	PEAK DIS ^{(1) (2)} Refer to par. 315 page 58	0	PEAK
					1	LAST
					2	ALL

Table 14-3 – Expanded command list

- (1) Write this command after writing values to 1st Dword (Output) then apply this command with New CMD.
(2) To access the related value, read 1st Dword (Input).

Programming steps of frequent used commands

Reading a weight value:

1. Check the B12...B15 bits of 'FT-112 Panel Output to PLC Input 2nd Dword'.
2. If there is not any error, read the weight value (gross, net or tare).

Zero Calibration procedure

1. Check the Bit-0 of Calibration Status. it should be '1'(set) to start adjustment.
2. Write 'Adjust Zero Calibration' command and apply New CMD to start Zero calibration.
3. Check the Bit-1 of Calibration Status. it is '1'(set) during zero calibration process.
4. The Bit-0 of Calibration Status changes to '1'(set) at the end of the Zero calibration.
5. If the Bit-3~Bit-10 of Calibration Status is '1'(set), check the description to understand the calibration error.

Span Calibration procedure

1. Check the Bit-0 of Calibration Status. it should be '1'(set) to start adjustment.
2. Write 'Adjust Span Calibration' command after writing test weight values to 1st Dword, then apply this command with New CMD to start Span calibration.
3. Check the Bit-1 of Calibration Status. it is '1'(set) during span calibration process.
4. The Bit-0 of Calibration Status changes to '1'(set) at the end of the Span calibration.
5. If the Bit-3~Bit-10 of Calibration Status is '1'(set), check the description to understand the calibration error.

15 APPENDIX 2: DATA STRUCTURE - CANOPEN

FT-112 Panel Output to PLC Input

Bitwise of a Dword:

Unsigned Long (Only read)	B63	B62	B61	B60	B59	B58	B57	B56	B55	B54	B53	B52	B51	B50	B49	B48
	B47	B46	B45	B44	B43	B42	B41	B40	B39	B38	B37	B36	B35	B34	B33	B32
	B31	B30	B29	B28	B27	B26	B25	B24	B23	B22	B21	B20	B19	B18	B17	B16
	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0

TxPDO1 (T_UL1)				Out 5	Out 4	Out 3	Out 2	Out 1					In 4	In 3	In 2	In 1
	Error codes of FT-112 Panel				Unit		P.Tare	Centre of zero	Gross Net	SD	Read command response					Cmd Flg
	By default, Actual weight value is represented. To represent other weight or calibration status, refer to B37...B33.															

FT-112 Panel Output to PLC Input 2nd Dword

Bit Number	TxPDO 1 (T_UL1) Description			
B63 ... B56	Digital Outputs	Output bit status (Active = 1)		
B55 ... B48	Digital Inputs	Input bit status (Active = 1)		
B47 ... B44	Error Codes of FT-112 Panel	Bin	Dec	Descriptions
		0000	0	No error found
		0001	1	ADC out
		0010	2	ADC over
		0011	3	ADC under
		0100	4	System Error
		0101	5	In programming mode
		0110	6	Low/High Voltage Error
	0111	7	Tilt Switch is active	
B43	Unit	0	First unit	
		1	Second unit	
B42	Not used			
B41	Preset Tare	0	Preset tare is passive	
		1	Preset tare is active	
B40	Centre of zero	0	Weight is out of zero range	
		1	Weight is in zero range	
B39	Indication	0	Gross	
		1	Net	
B38	Stability Detection	0	Stable	
		1	Unstable	
B37 ... B33	Read Command Response	Bin	Dec	Descriptions
		0000	0	Actual weight (if the indication is in Net)
		00001	1	Gross weight
		00010	2	Tare weight
		00011	3	ALL Status (Refer to Table 15-1)

		00100	4	Calibration Status (Refer to Table 15-2)				
		00101	5	Last print value				
		00110	6	Quantity of M+				
		00111	7	Not used				
		01010	10					
		01011	11	CN (Label number)				
		01100	12	Totalization of M+				
		01101	13	Grand Total				
		01110	14	Not used				
		01111	15	B. weighing	Filling	C. weighing	Classifying	Peak hold
				SetPoint-1	Target	Target	Target	Follow
		10000	16	SetPoint-2	Coarse	Low	--Low	Mid Decr.
		10001	17	SetPoint-3	Fine	High	-Low	End Decr.
		10010	18	SetPoint-4	TareMin	Empty	+High	Stop
		10011	19	SetPoint-5	TareMax	Not used	++High	Alarm
		10100	20	Not used	Empty	Not used	Empty	Empty
		10101	21	SetPoint-1 Low			Only available for Threshold and Window feature. Refer to sub-block 36-, page 61 to see the availabilities.	
		10110	22	SetPoint-2 Low				
		10111	23	SetPoint-3 Low				
		11000	24	SetPoint-4 Low				
		11001	25	SetPoint-5 Low				
		11010	26	Not used				
		11110	30					
		11111	31	Use the Expanded Command list (Refer to Table 15-3)				
B32	CMD Flag	Toggles		The command is applied successfully				
B31...B0	By default, Actual weight value is represented. To represent other weight or calibration status, refer to B37...B33.							

ALL Status (always 32 bit integer)

Low Dword of TXPDO 1(T_UL1) descriptions when read command is 'ALL Status'. Refer to RxPDO 1(R_UL1) of PLC Output to FT-112 Panel Input.

Bit Number	Low Dword of TxPDO 1(T_UL1) Description		
B31	Place of decimal point	0	None
		1	No decimal point
B30		0	None
		1	Decimal point is X.X
B29		0	None
		1	Decimal point is X.XX
B28		0	None
		1	Decimal point is X.XXX
B27		0	None
		1	Decimal point is X.XXXX
B26 ... B16	Not in use		
B15	Hold status	0	Passive
		1	Active
B14	Basic Peak status	0	Passive
		1	Active
B13	High resolution status	0	Passive
		1	Active
B12	Centre of zero	0	Weight is out of zero range
		1	Weight is in zero range
B11	Key lock status	0	Passive
		1	Active
B7-B10	Not used		
B6	Unit indication	0	First Unit (power on unit)
		1	Second Unit
B5	Power On Zero	0	Not power on zeroed
		1	Zeroed with power on zero
B4	Preset Tare	0	Preset tare is passive
		1	Preset tare is active
B3	Indication	0	Gross mode
		1	Net mode
B2	Motion Detection	0	Stable
		1	Unstable
B1	Actual Weight or Dynamic Result	0	Weight is actual weight
		1	Weight is dynamic result
B0	Dynamic Operation	0	Dynamic is inactive
		1	Dynamic weight is calculating

Table 15-1– ALL Status table

Calibration Status (always 32 bit integer)

Low Dword of TxPDO 1(T_UL1) descriptions when read command is 'Calibration Status'. Refer to RxPDO 1(R_UL1) of PLC Output to FT-112 Panel Input.

Bit Number	Low Dword of TxPDO 1(T_UL1) Description	
B31... B11	Not in use	
B10	0	No Error
	1	The Calibration DIP switch is not 'On' position. - Check the calibration DIP switch.
B9	0	No Error
	1	Scale unstable - Wait until scale become stable - Check grounding wiring
B8	0	No Error
	1	Calibration load value entry Error - Test weight is too small. Increase the weight
B7	0	No Error
	1	Calibration Error - Calibration loading is not enough - Check test weight loading - Check load cell connections
B6	0	No Error
	1	Instrument cannot be calibrating - Load cell signal is very low or too high
B5	0	No Error
	1	Instrument cannot be calibrating - Check load cell cable - Re-energize the instrument
B4	0	No Error
	1	ADC Error - Re-energize the instrument - If shown again, change the board.
B3	0	No Error
	1	Calibration Timeout - Restart calibration
B2	0	None
	1	Span calibration in process ...
B1	0	None
	1	Zero calibration in process ...
B0	0	Not ready for calibration
	1	Ready for calibration

Table 15-2 - Calibration status

PLC Output to FT-112 Panel Input

Bitwise of a Dword:

Unsigned Long (R/W)	B63	B62	B61	B60	B59	B58	B57	B56	B55	B54	B53	B52	B51	B50	B49	B48
	B47	B46	B45	B44	B43	B42	B41	B40	B39	B38	B37	B36	B35	B34	B33	B32
	B31	B30	B29	B28	B27	B26	B25	B24	B23	B22	B21	B20	B19	B18	B17	B16
	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1	B0

RxPDO1 (R_UL1)				Out 5	Out 4	Out 3	Out 2	Out 1	Expanded Commands List						
	Not in use				Command List				Read Data Selection				New CMD		
	B37-B33 bits defines the usage of this Dword.														

PLC Output to FT-112 Panel Input RxPDO 1 (R_UL1)

Bit Number	RxPDO 1 (R_UL1) descriptions							
B63 ... B56	Set / Reset digital outputs							
B55 ... B48	Expanded Commands List (Refer to Table 15-3)							
B47 ... B43	Not in use							
B42 ... B38	Command List	Bin	Dec	Commands				
		00000	0	None command is activated				
		00001	1	Zero				
		00010	2	Tare				
		00011	3	Clear				
		00100	4	Print				
		00101	5	Adjust zero calibration			Calibration	
		00110	6	Adjust span calibration ⁽¹⁾				
		00111	7	Total Load Cell Capacity ⁽¹⁾			eCal Coefficients	
		01000	8	Average mV/V value ⁽¹⁾				
		01001	9	Dead Load value ⁽¹⁾				
		01010	10	Save the coefficients of eCal			Refer to par. [613]	
		01011	11	CN (Label number) ⁽¹⁾				
		01100	12	Preset Tare ⁽¹⁾				
		01101	13	Grand Total				
		01110	14	Not used				
		01111	15	B. weighing	Filling	C.weighing	Classifying	Peak hold
				Set Point-1	Target	Target	Target	Follow
10000	16	Set Point-2	Coarse	Low	--Low	Mid Decr.		
10001	17	Set Point-3	Fine	High	-Low	End Decr.		
10010	18	Set Point-4	TareMin	Empty	+High	Stop		

		10011	19	Set Point-5	TareMax	Not used	++High	Alarm		
		10100	20	Not used	Empty	Not used	Empty	Empty		
		10101	21	SetPoint-1 Low		Only available for Threshold and Window feature. Refer to sub-block 36-, page 61 to see the availabilities.				
		10110	22	SetPoint-2 Low						
		10111	23	SetPoint-3 Low						
		11000	24	SetPoint-4 Low						
		11001	25	SetPoint-5 Low						
		11010 11110	26 30	Not used						
		11111	31	Use the Expanded Command list (Refer to Table 15-3)						
B37 ... B33	Read Data Selection	00000	0	Actual weight (if the indication is in Net)						
		00001	1	Gross weight						
		00010	2	Tare weight						
		00011	3	ALL Status (Refer to Table 15-1)						
		00100	4	Calibration Status (Refer to Table 15-2)						
		00101	5	Last print value						
		00110	6	Quantity of M+						
		00111 01010	7 10	Not used						
		01011	11	CN (Label number)						
		01100	12	Quantity of M+						
		01101	13	Grand Total						
		01110	14	Not used						
		01111	15	B. weighing	Filling	C.weighing	Classifying	Peak hold		
				Set Point-1	Target	Target	Target	Follow		
		10000	16	Set Point-2	Coarse	Low	--Low	Mid Decr.		
		10001	17	Set Point-3	Fine	High	-Low	End Decr.		
		10010	18	Set Point-4	TareMin	Empty	+High	Stop		
		10011	19	Set Point-5	TareMax	Not used	++High	Alarm		
		10100	20	Not used	Empty	Not used	Empty	Empty		
				10101	21	SetPoint-1 Low		Only available for Threshold and Window feature. Refer to sub-block 36-, page 61 to see the availabilities.		
				10110	22	SetPoint-2 Low				
				10111	23	SetPoint-3 Low				
				11000	24	SetPoint-4 Low				
				11001	25	SetPoint-5 Low				
				11010 11110	26 30	Not used				
				11111	31	Use the Expanded Command list (Refer to Table 15-3)				
B32	New CMD	Toggle		Apply commands which are listed in this table.						
B31-B0	B37-B33 bits defines the usage of this Dword.									

(1) Write this command after writing values to Low Dword of RxPDO then apply this command with New CMD.

Expanded Command List

The "B48...B55" bits in RxPDO describes below.

Bit No	Description						
B23...B16	Expanded Commands List	Bin	Dec	Commands			
		00000000	0	R	Voltage of power supply ⁽²⁾ The value is indicated with 0.1 VDC increment.		
		00000001	1	R	Load cell millivolt value ⁽²⁾ (Only FT-112 Panel) Millivolt of active scale is indicated with 0.01 mV increment.		
		00000010	2	R	Command status ⁽²⁾	Dec	Descr. of 1st Dword
						0	None
						1	Command is processing
						2	Command is done
		00000011	3	R/W	Reprint the last label ^{(1) (2)}	0	None
						1	Reprint the last label
		00000100	4	R/W	High resolution ^{(1) (2)}	0	Enable
						1	Disable
		00000101	5	W	Unit change ⁽¹⁾	0	From first to second unit
						1	From second to first unit
		00000110	6	R/W	Key lock ^{(1) (2)}	0	Enable
						1	Disable
		00000111	7	W	Dynamic operation ⁽¹⁾	0	Dynamic reset
						1	Dynamic start
		00001000	8	W	Totalization operation ⁽¹⁾	0	None
						1	M+ key
						2	Totalization Print
		00001001	9	W	SmartAPP operation ⁽¹⁾	0	Reset
						1	Start
		00001010	10	Not used			
		00001011	11	Not used			
		00001100	12	R/W	Basic Peak	0	Enable
						1	Disable
		00001101	13	R/W	Hold	0	Enable
						1	Disable
		00001110	14	Not used			
		00110100	52	Not used			
		00110101	53	R	1 st Peak value ⁽²⁾	Only available for Peak hold application. Refer to Section 9.4, page91.	
		00110110	54	R	2 nd Peak value ⁽²⁾		
00110111	55	R	3 rd Peak value ⁽²⁾				
00111000	56	R	4 th Peak value ⁽²⁾				
00111001	57	R	5 th Peak value ⁽²⁾				
00111010	58	R	6 th Peak value ⁽²⁾				
00111011	59	R	7 th Peak value ⁽²⁾				
00111100	60	R	8 th Peak value ⁽²⁾				
00111101	61	R	9 th Peak value ⁽²⁾				
00111110	62	R	10 th Peak value ⁽²⁾				
00111111	63	R/W	Dynamic filter ^{(1) (2)}	Refer to par. 332 page 59			
01000000	64	R/W	Filter ^{(1) (2)}	0	No		
				1	Very Low		
				2	Low		

					3	Medium
					4	High
					5	Very High
	01000001	65	R/W	Power on zero ^{(1) (2)}	0	Disable
					1	± %2
					2	± %2LK
					3	± %10
					4	+ %15, - %5
					5	± %20
	01000010	66	R/W	Zeroing Range ^{(1) (2)}	0	Disable
					1	± 2%
					2	± 3%
					3	± 20%
					4	± 50%
	01000011	67	R/W	Auto Zero Tracking ^{(1) (2)}	0	Disable
					1	± 0,3d
					2	± 0,5d
					3	± 1d
					4	± 2d
					5	± 3d
	01000100	68	R/W	Tare ^{(1) (2)}	0	No
					1	Multi tare
					2	Tare only at gross
					3	Preset tare
					4	Preset tare at gross
	01000101	69	R/W	Stability Detection Range ^{(1) (2)}	0	± 0,3d
					1	± 0,5d
					2	± 1d
					3	± 2d
					4	± 3d
					5	± 4d
					6	Disable
	01000110	70	R/W	Stability Time ^{(1) (2)}	Refer to par. [517] page 64	
	01000111	71	R/W	Unit ^{(1) (2)}	0	g
					1	kg
					2	t
					3	lb
					4	No unit
					5	N
					6	kN
					7	kLb
	01001000	72	R/W	Range ^{(1) (2)}	0	Single range
					1	2 x Multi Range
					2	3 x Multi Range
					3	2 x Multi Interval
					4	3 x Multi Interval
	01001001	73	R/W	Capacity-1 ^{(1) (2)}	Refer to par. 523 on page 65	
	01001010	74	R/W	Decimal point-1 ^{(1) (2)}	0	XXXXOO
					1	XXXXXO
					2	XXXXXX
					3	XXXXX.X
					4	XXXX.XX
					5	XXX.XXX
				Increment-1 ^{(1) (2)}	0	X1

01001011	75			1	X2
				2	X5
01001100	76	R/W	Capacity-2 ^{(1) (2)}		
01001101	77	R/W	Decimalpoint-2 ⁽¹⁾ ₍₂₎		
01001110	78	R/W	Increment-2 ^{(1) (2)}		
01001111	79	R/W	Capacity-3 ^{(1) (2)}		
01010000	80	R/W	Decimalpoint-3 ⁽¹⁾ ₍₂₎		
01010001	81	R/W	Increment-3 ^{(1) (2)}		
01010010	82	R/W	Limit of Indication ^{(1) (2)}	0	Over indication after Max
				1	1 division more than Max
				2	5 division more than Max
				3	9 division more than Max
				4	2% more than Max
				5	5% more than Max
01010011	83	R/W	Tare type ^{(1) (2)}	0	Subtractive tare
				1	Additive tare
01010100	84	R/W	Maximum tare ⁽¹⁾ ₍₂₎	Refer to par. [526] page 65	
01010101	85	R/W	Secondary unit ⁽¹⁾ ₍₂₎	0	g
				1	kg
				2	t
				3	lb
				4	No unit
				5	N
				6	kN
				7	kLb
01010110	86	Not Used			
01011111	95				
01100000	96	R/W	APPLICA ^{(1) (2)} Refer to par. 311 page 57	0	No
				1	CHEC
				2	CLAS
				3	FILL
				4	PEAK
01100001	97	R/W	LIMITS ^{(1) (2)} Refer to par. 312 page 57	0	VAL
				1	TOL
				2	%
01100010	98	R/W	INFODIS ^{(1) (2)} Refer to par. 313 page 57	0	No
				1	ID1T
				2	ID2T
01100011	99	R/W	DISPLAY ^{(1) (2)} Refer to par. 314 page 58	0	No
				1	BAR
				2	COLO
				3	ALL
01100100	100	R/W	COLORS ^{(1) (2)} Refer to par. 316 page 58	0	RAAY
				1	YAAR
				2	RBAY

					3	YABR
01100101	101	R/ W	CHANGE ⁽¹⁾ ⁽²⁾ Refer to par. 317 page 58	0	STAB	
				1	IMME	
01100110	102	R/ W	ACOUSTI ⁽¹⁾ ⁽²⁾ Refer to par. 318 page 58	0	No	
				1	OKAY	
				2	OVER	
				3	CROSS	
01100111	103	R/ W	START ⁽¹⁾ ⁽²⁾ Refer to par. 321 page 58	0	AUTO	
				1	MANU	
				2	SAUT	
				3	PORT	
01101000	104	R/ W	FILLING ⁽¹⁾ ⁽²⁾ Refer to par. 322 page 58	0	GROS	
				1	NET	
01101001	105	R/ W	TAREDELA ⁽¹⁾ ⁽²⁾	Refer to par. 323 on page 58		
01101010	106	R/ W	TOTAL ⁽¹⁾ ⁽²⁾ Refer to par. 324 page 58	0	No	
				1	HORI	
				2	VERT	
01101011	107	R/ W	GT ERASE ⁽¹⁾ ⁽²⁾ Refer to par. 325 page 58	0	MRC	
				1	PASS	
01101100	108	R/ W	OUTPUTS ⁽¹⁾ ⁽²⁾ Refer to par. 326 page 59	0	STAB	
				1	IMME	
01101101	109	R/ W	PEAK DIS ⁽¹⁾ ⁽²⁾ Refer to par. 315 page 58	0	PEAK	
				1	LAST	
				2	ALL	

Table 15-3 - Expanded Command List

(1) Write this command after writing values to Low Dword of RxPDO then apply this command with New CMD.

(2) To access the related value, read Low Dword of TxPDO.

Programming steps of frequent used commands

Reading a weight value:

1. Check the B47...B44 bits of TxPDO 1 (T_UL1).
2. If there is not any error, read the weight value (gross, net or tare).



Zero Calibration procedure:

1. Check the Bit-0 of Calibration Status. it should be '1'(set) to start adjustment.
2. Write 'Adjust Zero Calibration' command and apply New CMD to start Zero calibration.
3. Check the Bit-1 of Calibration Status. it is '1'(set) during zero calibration process.
4. The Bit-0 of Calibration Status changes to '1'(set) at the end of the Zero calibration.
5. If the Bit-3~Bit-10 of Calibration Status is '1'(set), check the description to understand the calibration error.

Span Calibration procedure:




1. Check the Bit-0 of Calibration Status. it should be '1'(set) to start adjustment.
2. Write 'Adjust Span Calibration' command after writing test weight values to Low Dword of RxPDO 1 (R_UL1), then apply this command with New CMD to start Span calibration.
3. Check the Bit-1 of Calibration Status. it is '1'(set) during span calibration process.
4. The Bit-0 of Calibration Status changes to '1'(set) at the end of the Span calibration.
5. If the Bit-3~Bit-10 of Calibration Status is '1'(set), check the description to understand the calibration error.

16 SEALING OF APPROVED SCALE



17 ERROR CODES

FT-112 Panel weighing indicator had been designed as a very reliable and virtually error free instrument. However, if there is an error occurrence, do not attempt to repair the equipment before understanding what caused the error. Note the problems you have with your instrument and the error messages shown on the display. Then try to solve the problem according to the error table given below.

ERROR CODE	DESCRIPTION	THINGS TO DO
	Weight is too low	<ul style="list-style-type: none"> - Check the load - Load cell or instrument could be broken.
	Over Load	
LC Err	Load exceeds the operation range	<ul style="list-style-type: none"> - Check the load - Check the calibration - Load cell or instrument could be broken.
+POWERONZEROERR	Weight is out of power on zero range.	<ul style="list-style-type: none"> - Press  key to start indication Without zeroing and call service.
-POWERONZEROERR		
LOW VOLT PWR OFF	Power source voltage is less than 9 VDC.	<ul style="list-style-type: none"> - Check the power supply voltage.
HIGH VOLT PWROFF	Voltage is more than 30 VDC.	
E01 ADC ERROR	ADC initialization error. ADC could not initialize at power on. ADC or its interface circuitry has a malfunction.	<ul style="list-style-type: none"> - Power off the instrument reenergizes it after 30 seconds. - Check external load cell connection. - Check load cell connector in the instrument. - Change main board or second scale board.
E02 ADC ERROR	ADC conversion error. ADC could not convert the load cell signal. ADC or its load cell connection circuitry may have a malfunction.	
E03 ADC ERROR	ADC data is out of the range. ADC could not convert the load cell signal in range. ADC or its load cell connection circuitry may have a malfunction or load cell excitation voltage is too low.	
E09 DISPLAY COMM	Communication error between display board and main board.	<ul style="list-style-type: none"> - Power off the instrument reenergizes it after 30 seconds. - If not, change main board.
E10 NVM VERSION	NVM version error. Factory default will be loaded.	<ul style="list-style-type: none"> - If you changed the E²ROM (U13) press Enter key. The factory defaults will be loaded. - If not, change main board.
E20 CALIBRATION	Checksum error of calibration coefficients.	<ul style="list-style-type: none"> - Check the scale performance. - Recalibrate the scale. - Change mainboard.
E21 SETUP ERROR	Check sum error of parameters.	<ul style="list-style-type: none"> - Check the scale performance. - Recalibrate the scale. - Change mainboard.
E22 CHECKSUM ERR	Checksum error of the data.	<ul style="list-style-type: none"> - Change E²ROM (U13).
E23 HEADER ERR	Header checksum error.	<ul style="list-style-type: none"> - Press enter key and re-enter the headers. - Change E²ROM (U13).

E24 FOOTNOTE ERR	Footnote checksum error.	<ul style="list-style-type: none"> - Press enter key and re-enter the footers. - Change E²ROM (U13).
E25 FBUS SETUP E	Fieldbus set up error.	<ul style="list-style-type: none"> - Press enter key and re-enter the fieldbus setup. - Change E²ROM (U13).
E26 SETPOINT ERR	Setpoint (limit values) checksum error.	<ul style="list-style-type: none"> - Press enter key and re-enter the setpoint (limit) values. - Change E²ROM (U13).
E28 CLOCK ERROR	Clock error.	<ul style="list-style-type: none"> - Change CR2032 battery. - Change the main board.
E29 ID NAME ERROR	ID header checksum error.	<ul style="list-style-type: none"> - Change main board. - Change E²ROM (U13).
E32 LABEL ERROR	Checksum error of EPL printout format.	<ul style="list-style-type: none"> - Press enter key and re-load the EPL code. - Change E²ROM (U13).
E34 NOT LOADED	ADC output is not changed for the span calibration.	<ul style="list-style-type: none"> - Recalibrate the scale. - Change mainboard.
E35 LC CONNECTIO	The load cell output is decreased after loading.	<ul style="list-style-type: none"> - Check load cell connections. - Check test weight loading.
E36 ADD LOAD	The load is not enough for span calibration.	<ul style="list-style-type: none"> - Recalibrate the scale. - Change mainboard.
E37 UNSTABLE	The load is not stable at calibration.	<ul style="list-style-type: none"> - Wait until scale become stable. - Check grounding wiring. - Recalibrate the scale. - Change mainboard.
E40 NO ALIBI SD	Alibi memory SD card is not installed.	<ul style="list-style-type: none"> - Disable Alibi memory if not required. - Check Alibi SD card. - Change mainboard.
E41 ALIBI FAULT	Alibi SD card has not been supplied from FLINTEC.	<ul style="list-style-type: none"> - Install Flintec Alibi SD card.
E42 NEW ALIBI	Alibi memory serial number error. The new alibi SD card is installed.	<ul style="list-style-type: none"> - Format the alibi memory SD card. Refer to parameter 816.
E43 ALIBI ERROR	Alibi memory could not be initialized.	<ul style="list-style-type: none"> - Check alibi memory SD card - Change main board.
E44 ALIBI CSUM E	Alibi CSUM error.	<ul style="list-style-type: none"> - Check alibi memory records.
E47 ALIBI CSUM E	Alibi information CSUM error.	<ul style="list-style-type: none"> - Change Alibi memory SD card. - Change main board.
E48 ALIBI SD ERR	Wrong SD card at alibi memory.	<ul style="list-style-type: none"> - Order Alibi SD card.
E50 DLC CARD FAI	The DLC Board is broken or not installed.	<ul style="list-style-type: none"> - Re-energize indicator. - Change the DLC Board.
E61 FLASH ERROR	E2PROM Error.	<ul style="list-style-type: none"> - Change main board.
E70 MBSELECT ER	Modbus selection error	<ul style="list-style-type: none"> - Check data format of other interfaces. - Other interfaces should not be Modbus.
E71 TARING ERROR	Tare range error at filling	<ul style="list-style-type: none"> - Check scale stability. - Check tare min and max values.
E72 TARGET ERROR	Target value error at checkweighing.	<ul style="list-style-type: none"> - Check Target value.
E73 TOTAL ERROR	Totalization CSUM error.	<ul style="list-style-type: none"> - Restart totalization after deleting

		<p>before total.</p> <ul style="list-style-type: none"> - Change E²PROM (U13). - Change main board.
E74 TOTAL PRT ER	Totalization data cannot be recorded to the alibi memory.	<ul style="list-style-type: none"> - Check alibi memory SD card. - Change main board.
E75 MODBUS FAULT	The Modbus SD card is not installed in SD2 card slot.	<ul style="list-style-type: none"> - Order Modbus SD card. - Install Flintec Modbus SD card.
E76 QTY OVER 99	Up to 99 items can be totalized.	<ul style="list-style-type: none"> - Press enter key to finalize totalization after printing. - Press MRC key to delete totalization.
E78 NO PT RECORD	Preset tare memory error.	<ul style="list-style-type: none"> - PT is not entered or PT checksum error. - Enter PT. - Call service
E80 VERIFY SCALE	Reverification the scale.	<ul style="list-style-type: none"> - Reverify the scale after checking the scale hardware, load cells, performance etc.
E81 CANNOT ADDR	DLC could not addressed.	<ul style="list-style-type: none"> - Check the DLC connection (RS-485 & Power supply) hardware. - Check the DLC and S/N.
E82 SHIFT ADJUST	Shift adjustment is not available due to load cell coefficients are out of limits.	<ul style="list-style-type: none"> - Check addressing is done correctly. - Check test weight loading on the correct DLC. - Check the load cell installation and scale installation.
E83 DLC COUNT ER	No regular response from load cell	<ul style="list-style-type: none"> - Reenergize the indicator. - Check the DLC connection (RS-485 & Power supply). - Change load cell.
E84 SN NOT MATCH DLC yy ⁽¹⁾	The address and S/N of the load cell do not match.	<ul style="list-style-type: none"> - Check the DLC and S/N. - Reenergize the indicator. - Readdress the DLC.
E85 DLC TIMEOUT DLC yy ⁽¹⁾	Communication time out	<ul style="list-style-type: none"> - Check the DLC connection (RS-485 & Power supply) hardware. - Check the DLC and S/N.
E86 DLC COM ERR DLC yy ⁽¹⁾	Status error of load cell	<ul style="list-style-type: none"> - Change load cell.
E87 DLC UNDER DLC yy ⁽¹⁾	The DLC is under	<ul style="list-style-type: none"> - Check mechanical installation and DLC.
E88 DLC OVER DLC yy ⁽¹⁾	The DLC is over	<ul style="list-style-type: none"> - Check mechanical installation and DLC.
E89 DLC CHKSUM DLC yy ⁽¹⁾	Checksum error	<ul style="list-style-type: none"> - Check termination resistors. - Check the DLC connection (RS-485 & Power supply) hardware.
E90 DLC PWR ERR	Power supply of DLCs could not detected.	<ul style="list-style-type: none"> - Check the main board.

E91 DLC SYSTEM	Internal communication error between the DLC board and the indicator.	<ul style="list-style-type: none"> - Change the DLC board. - Change the main board.
E92 DLC UNMATCH	Capacity of the load cell is different.	<ul style="list-style-type: none"> - Check capacity of the DLC

1) yy = Number/Address of the digital load cell.



www.flintec.com