

**INSTALLATION
AND OPERATION MANUAL**
READ ALL INSTRUCTIONS BEFORE USE



Models:
Metro Super Erecta NK3



Page Intentionally Left Blank



Due to continuous product research and development,
the information contained herein is subject to change without notice.

www.stoddart.com.au

www.stoddart.co.nz

1.0 Introduction

1.1 Your New Metro Product	3
1.2 Australia and New Zealand Warranty	4
1.2.1 Warranty Period	
1.2.2 Warranty Registration	
1.3 General Precautions	4

2.0 Installation

2.1 Product Overview.	5
2.2 Setting Up	6
2.2.1 Handling	
2.2.2 Unpacking	
2.2.3 Positioning	

3.0 Assembly

3.1 Super Erecta Pro Series	7
---------------------------------------	---

4.0 Cleaning and Maintenance

4.1 Super Erecta (Open wire shelving)	17
4.2 Disposal	17
5.0 Troubleshooting	18
5.1.1 Troubleshooting Procedures	

1.1 Your New Metro Product

Thank you for choosing this quality Metro product.

All Metro products are designed and manufactured to meet the needs of food service professionals. By caring for and maintaining this new Metro product in accordance with these instructions, will provide many years of reliable service.

Stoddart is a wholly Australian owned company, which manufactures and/or distributes a comprehensive range of food service equipment for kitchens, food preparation and presentation. Stoddart products are manufactured and engineered to provide excellent results whilst offering value-for-money, ease-of-use and reliability.

Carefully read this instruction booklet, as it contains important advice for safe installation, operation and maintenance. Keep this booklet on hand in a safe place for future reference by other operators or users.

Disclaimer

The manufacturer/distributor cannot be held responsible or liable for any injuries or damages of any kind that occur to persons, units or others, due to abuse and misuse of this unit in regards to installation, removal, operation, servicing or maintenance, or lack of conformity with the instructions indicated in this documentation.

All units made by the manufacturer/distributor are delivered assembled, where possible, and ready to install. Any installation, removal, servicing, maintenance and access or removal of any parts, panels or safety barriers that is not permitted, does not comply in accordance to this documentation, or not performed by a **TRAINED AND AUTHORISED SPECIALIST** will result in the **IMMEDIATE LOSS OF THE WARRANTY.**

The manufacturer/distributor cannot be held responsible or liable for any unauthorised modifications or repairs. All modifications or repairs must be approved by the manufacturer/distributor in writing before initiating. All modifications or repairs performed to this unit must be performed at all times by a **TRAINED AND AUTHORISED SPECIALIST.**

**Stoddart design, manufacture & distribute Food Service Equipment (appliances) exclusively for the commercial market.
This appliance is not designed nor intended for household or domestic use and must not be used for this purpose.**

This product is intended for commercial use, and in line with Australian electrical safety standards the following warnings are provided:

- This product is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning the use of the product by a person responsible for their safety. Children should be supervised to ensure that they do not play with the product
- If the supply cord is damaged, it must be replaced by the manufacturer, its service agent or similarly qualified persons in order to avoid a hazard



Warranty & Registration


1.2 Australia and New Zealand Warranty

1.2.1 Warranty Period

All Stoddart manufactured and distributed products are covered by Stoddart's standard Australia and New Zealand Product Warranty (minimum 12 month on-site parts and labour, terms and conditions apply). Further to this standard warranty, certain products have access to an extended warranty. Full terms, conditions and exclusions can be found using the below Link/QR code.

1.2.2 Warranty Registration

To register your new product, Follow the below Link/QR code.



www.stoddart.com.au/warranty-information



1.3 General Precautions


When using any electrical unit, safety precautions must always be observed.



Our units have been designed for high performance. Therefore, the unit must be used exclusively for the purpose for which it has been designed.

- All units **MUST** be installed according to the procedures stated in the installation section of this manual
- In the case of new personnel, training is to be provided before operating the equipment
- **DO NOT** use this unit for any other purpose than its intended use
- **DO NOT** store explosive substances such as aerosol cans with a flammable propellant in or near this unit
- Keep fingers out of "pinch point" areas
- Unit is not waterproof **DO NOT** use jet sprays, hoses or pour water over/on the exterior of the unit
- Only use this unit with voltage specified on the rating label
- **DO NOT** remove any cover panels that may be on the unit
- **DO NOT** use sharp objects to activate controls
- If any fault is detected, refer to troubleshooting
- The manufacturer declines any liability for damages to persons and/or things due to an improper/wrong and/or unreasonable use of the machine
- Only specifically trained/qualified Technicians (Stoddart, one of our service agents, or a similarly qualified persons) should carry out any and all repairs, maintenance and services

2.1 Product Overview

	WARNING - TIPPING HAZARD
	<ul style="list-style-type: none"> • Do not stand or climb on shelving. • Place heavy objects on lowest shelf. • Distribute weight as evenly as possible. • Do not drop heavy objects on shelves or subject to shock such as forklifts or dollies. • Move mobile units along long axis only.  • 203mm (8") diameter casters must not be used on units less than 533mm (21") wide. • Strictly follow weight capacity guidelines • NEVER exceed 900kg on any stationary storage system or 450kg on any mobile storage system <p>Failure to follow these instructions could result in personal injury or property damage.</p>

	IMPORTANT
	<p>For Best performance: Units over 1270mm high (50") must be assembled with at least three shelves, and preferably four or more. Place shelving on solid and level floors. Level the unit by adjusting the leveling feet. Install bottom shelf as low as possible. NSF requires that the lowest shelf be at least 152mm (6") above the floor. For mobile units: lubricate the casters regularly and replace worn casters immediately.</p>

	CAUTION - WEIGHT CAPACITY
	<p>Shelves 610mm up to 1220mm in length = 360 kg maximum equally distributed. Shelves longer than 1220mm = 270 kg maximum equally distributed. NEVER exceed 900 kg on any Storage System. NEVER exceed 450 kg or three times the caster load rating (whichever is less) on any Storage System. Distribute weight as evenly as possible. See this symbol for specific weight capacities:</p> 

2.2 Setting Up

2.2.1 Handling

- Use suitable means to move the unit;
 - For smaller items use two people
 - For large items a fork lift, pallet trolley or similar (the forks should reach completely beneath the pallet)

2.2.2 Unpacking

- Check the unit for damage before and after unpacking. If unit is damaged, contact the distributor and manufacturer
- Should any item have physical damage, report the details to the freight company and to the agent responsible for the dispatch within seven (7) days of receipt. No claims will be accepted or processed after this period
- The unit is supplied flat packed and will require assembly.
- Remove all protective plastic film, tapes, ties and packers before installing and operating
- Remove shelf transport springs and zipties
- Clean off any remaining residue from the unit using a clean cloth dampened with warm soapy water

2.2.3 Positioning

Super Erecta Pro Stability Guide

Stationary Units (Free-standing without footplates or wall brackets)

Shelf Depth	Maximum Allowable Post Height
356mm	1600mm (63")
457 mm	2184mm (86")
533 mm	2184mm (86")
610 mm	2438mm (96")

*For all stationary units with footplates or wall brackets properly attached to the floor or wall, the maximum allowable post height is 2438mm.

Mobile Units with Stem Casters

Shelf Depth	Maximum Allowable Post Height
356mm	1372mm (54")
457 mm	1880mm (74")
533 mm	1880mm (74")
610 mm	2184mm (86")


Mobile Units with Dolly Platforms

Shelf / Dolly Depth	Maximum Allowable Post Height	
	127mm & 153mm Casters	203mm Casters
457 mm	1660mm (63")	N/A
533 mm	1880mm (74")	1600mm (63")
610 mm	2184mm (86")	1880mm (74")

3.1 Super Erecta Series

STATIONARY UNIT

(Two people required to assemble unit)




3.0 Assembly



3.1 Super Erecta Series

MOBILE UNIT

(Two people required to assemble unit) para ensamblarla)




Due to continuous product research and development, the information contained herein is subject to change without notice.

www.stoddart.com.au

www.stoddart.co.nz


3.1 Super Erecta Series



MOBILE UNIT WITH EXTENDED HANDLE




If installing an Extended/Push Handle, install before step 10 above.



3.0 Assembly




3.1 Super Erecta Series



MOBILE UNIT WITH EXTENDED HANDLE

If installing an Extended/Push Handle, install after step 11 above.



Due to continuous product research and development,
the information contained herein is subject to change without notice.





www.stoddart.com.au

www.stoddart.co.nz

3.1 Super Erecta Series

DOLLY BASE UNIT FROM STATIONARY UNIT

(Two people required to assemble Unit)



3.0 Assembly



3.1 Super Erecta Series

S-Hooks (Stationary units only)

Use S-hooks to join units as shown.

RIGHT ANGLES COMBINATION

"S" Hook Location

END-TO-END

Starter unit (4 Posts) Add-on unit (2 Posts)

Joining Clamps (Solid shelves combinations)

Use Joining Clips to join units as shown.

RIGHT ANGLES COMBINATION

Joining Clamp Location

END-TO-END

Starter unit (4 Posts) Add-on unit (2 Posts)

SHELF DIVIDER

1

REAR

2

PUSH DOWNWARDS

FRONT OF SHELF REAR OF SHELF

3

FRONT OF DIVIDER




Due to continuous product research and development, the information contained herein is subject to change without notice.

www.stoddart.com.au



www.stoddart.co.nz

3.1 Super Erecta Series


LABEL HOLDER





COLOR SHELF MARKERS





FOOT PLATE



POST CLAMPS



LEDGES



* Save this document for future application, load rating and/or safety reference.

4.0 Cleaning

4.1 Super Erecta (Open Wire Shelving)

1. Remove all products.
2. Move shelving unit to outside area or area away from food products. (Note: do not contaminate food product with cleaning chemicals.)
3. Hose shelving unit to loosen grime and dirt.
4. Use water, mild detergent and sponges to clean shelves.
5. Use brushes to clean between wires and remove stubborn residue.
6. Hose off unit again to remove cleaning chemicals and loose dirt.
7. Towel dry unit and move back to original location.
8. Place product back on shelf.

4.2 Disposal

If the appliance is no longer of use, please dispose in an environmentally correct way.

The distributor / retailer can contact their local metal recycling centre to collect the remaining cabinet, shelves, etc.

There may be special requirements or conditions. Information on the disposal of refrigeration appliances can be obtained from:

- Your supplier
- Government authorities (The local council, Ministry of the Environment, etc.)



Discarded electric appliances are recyclable and should not be discarded in the domestic waste! Please actively support us in conserving resources and protecting the environment by returning this appliance to the collection centres (if available).



Dispose of packaging in accordance to applicable legal regulations.

5.0 Troubleshooting

5.1.1 Troubleshooting Procedures

- If any faults/issues occur with the unit, follow the below troubleshooting procedures
- If the troubleshooting procedures do not correct the problem, contact the Stoddart Service Department

Problem	Possible Causes	Possible Corrective Action
	Shelving is not level	<ul style="list-style-type: none">• Ensure each post clip/wedge are on the same post number• Ensure the unit has been positioned on a level floor and posts are the same finished height• Adjust post feet to ensure unit is level
	Mobile units feel ensecure	<ul style="list-style-type: none">• Ensure caster wheels have been fixed securely



Australia

Australian Business Number: 16009690251

Service / Spare Parts


<https://customerservice.stoddart.com.au>

Sales

Tel: 1300 79 1954

Email: sales@stoddart.com.au

Web: www.stoddart.com.au



Customer
Service Portal

New Zealand

New Zealand Business Number: 6837694

Service / Spare Parts


<https://customerservice.stoddart.com.au>

Sales

Tel: 0800 79 1954

Email: sales@stoddart.co.nz

Web: www.stoddart.co.nz



Customer
Service Portal