

Autonics 3-Phase, LED Display Slim Power Controller SPR3 Series

INSTRUCTION MANUAL



Thank you for choosing our Autonics product. Please read the following safety considerations before use.

Safety Considerations

※Please observe all safety considerations for safe and proper product operation to avoid hazards. ※⚠ symbol represents caution due to special circumstances in which hazards may occur.

- Warning** Failure to follow these instructions may result in serious injury or death.
- Caution** Failure to follow these instructions may result in personal injury or product damage.


Warning

- Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss.** (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime/disaster prevention devices, etc.) Failure to follow this instruction may result in fire, personal injury, or economic loss.
- Install on the device panel, and ground to the bolt for grounding separately.** Failure to follow this instruction may result in electric shock or fire.
- Do not connect, repair, or inspect the unit while connected to a power source.** Failure to follow this instruction may result in electric shock or fire.
- Check 'Connections' before wiring.** Failure to follow this instruction may result in fire.
- Do not disassemble or modify the unit.** Failure to follow this instruction may result in electric shock or fire.

Caution

- Use the unit within the rated specifications.** Failure to follow this instruction may result in fire or product damage.
- Use dry cloth to clean the unit, and do not use water or organic solvent.** Failure to follow this instruction may result in electric shock or fire.
- Do not use the unit in the place where flammable/explosive/corrosive gas, humidity, direct sunlight, radiant heat, vibration, impact, or salinity may be present.** Failure to follow this instruction may result in fire or explosion.
- Keep metal chip, dust, and wire residue from flowing into the unit.** Failure to follow this instruction may result in fire or product damage.
- Since leakage current still flows right after turning off the power or in the output OFF status, do not touch the load terminal.** Failure to follow this instruction may result in electric shock.

Ordering Information




※1: Product is not equipped with a rapid fuse inside. Install the suitable fuse for rated load current of the model separately. (The performance of the product is guaranteed only when using the fuse provided by us.)
 ※The above specifications are subject to change and some models may be discontinued without notice.
 ※Be sure to follow cautions written in the instruction manual, user manual, and the technical descriptions (catalog, homepage).

Specifications

Model	SPR3-1	SPR3-2	SPR3-3	SPR3-4
Control phase	3-phase			
Rated load voltage (50/60Hz)	110VAC~	220VAC~	380VAC~	440VAC~
Power supply	100-240VAC~ 50/60Hz			
Min. load current	1A			
Permissible voltage range	90 to 110% of rated voltage			
Power consumption	• Rated load current 25A/35A/50A: max. 14VA • Rated load current 70A: max. 22VA • Rated load current 100A/150A: max. 32VA			
Display method	3-digit 7-segment LED			
Indicator	• Operation indicator/Manual control indicator: green LED • Alarm indicator/output indicator/unit (V, A) indicator: red LED			
Control method	• Phase control: normal control mode, constant current/constant voltage/constant power feedback control mode • Cycle control: fixed cycle control mode • ON/OFF control			
Applied load	• Phase control, ON/OFF control: resistance load, inductive load • Cycle control: resistance load			
Control input	• Auto control: DC4-20mA, 1-5VDC=, ON/OFF contact (no-voltage input), pulse voltage (5-12VDC=) • Manual control: outside adjuster (10kΩ), inside adjuster (output limit)			
Digital input (DI)	RUN/STOP switching, AUTO/MAN switching, RESET			
Output	Alarm	250VAC~ 3A, 30VDC= 3A, 1c resistive load		
Output range	Communication	RS485 communication output (Modbus RTU method), max. connection: 31 units		
Output accuracy	• Phase control: 0 to 98% • Cycle control: 0 to 100% • ON/OFF control: 0%, 100% • Normal control: within ±10% F.S. of rated load voltage • Constant current feedback control: within ±3% F.S. of rated load current • Constant voltage feedback control: within ±3% F.S. of rated load voltage • Constant power feedback control: within ±3% F.S. of rated load power			
Set method	By front keys, by communication			
Functions	Output limit (OUT ADJ.), AUTO/MAN selection, control method selection, RESET, SOFT START, SOFT UP/DOWN, output high/low limit, input correction, input slope correction, monitoring (control input, load voltage/current/power/resistance, power supply frequency, heatsink temperature)			
Alarm	Overcurrent alarm, overvoltage alarm, fuse break alarm, SCR error alarm, heater break alarm, heatsink overheat alarm			
Cooling method	• Rated load current 25A/35A/50A: natural cooling • Rated load current 70A/100A/150A: forced air cooling (with the cooling fan)			
Insulation resistance	Over 200MΩ (at 500VDC megger)			
Dielectric strength	2,000VAC 50/60Hz for 1 min (between input terminals and power terminals)			
Output leakage current	Max. 10mA Arms			
Noise immunity	±2kV the square wave noise (pulse width: 1μs) by the noise simulator			
Memory retention	Approx. 10 years (when using non-volatile semiconductor memory type)			
Vibration	Mechanical	0.75mm amplitude at frequency of 5 to 55Hz in each X, Y, Z direction for 2 hours		
Malfunction	Mechanical	0.5mm amplitude at frequency of 5 to 55Hz in each X, Y, Z direction for 10 min		
Environment	Ambient temp.	-10 to 55°C, storage: -20 to 80°C		
	Ambient humi.	35 to 85%RH, storage: 35 to 85%RH		
Accessory	11-pin connector, insulating barrier: 4			
Approval	CE			
Weight*1	• Rated load current 25A/35A/50A: approx. 4.9kg (approx. 4.1kg) • Rated load current 70A: approx. 5kg (approx. 4.2kg) • Rated load current 100A/150A: approx. 9.7kg (approx. 8.7kg)			

※1: The weight includes packaging. The weight in parenthesis is for unit only.
 ※Environment resistance is rated at no freezing or condensation.

Unit Description





- ① Bracket (except rated load current 100A/150A models)
- ② Indicator

Indicator	Color	Function	
RUN	Operation indicator	Green LED	Turns on in the RUN mode.
MAN	Manual control indicator	Green LED	Turns on when adjusting load output in the manual control mode.
ALM	Alarm indicator	Red LED	Flashes in alarming status.
OUT	Output indicator	Red LED	Turns on when load control outputs.
- ③ Display part: Displays settings of the front display [d1 5] parameter in RUN mode, and displays parameter and setting value in setting mode.
- ④ Unit indicator

Indicator	Display
V	● Resistance, input
A	● Voltage
●	● Current
●	● Power
- ⑤ Alarm output and power input terminals
- ⑥ U, V, W load output terminals
- ⑦ Cooling fan: For models with the rated load current of 70A/100A/150A, a cooling fan is attached.
- ⑧ Heatsink: In case of rated load current 100A/150A models, there are mounting holes on the right/left.
- ⑨ Bolt for grounding (M4)

Connections



※1: This is only for models with RS485 communication output (SPR3-□□□□□).
 ※2: When connecting noise filter and capacitor, it is appropriate for EMC.
 CAP: Rated load voltage 110VAC-220VAC → 1μF/250VAC
 : Rated load voltage 380VAC-440VAC → 0.47μF/500VAC

Rated load current	Specification	Alarm output/power input	Load input/output
25A, 35A, 50A, 70A	Screw	M3	M6
100A, 150A	Tightening torque	0.5N·m	5.5 to 6.0N·m
	Screw	M3	M8
	Tightening torque	0.5N·m	6.5 to 7.0N·m


※Use crimp terminals or terminals of size specified below. (unit: mm)

Terminal type	Terminal number	a	b	c
Input (11-pin)	1 to 11	6 to 7	Max. 1.5	Max. 3.5
Alarm output/power input		Min. 3.0	Max. 6.0	
Load input/output	Rated load current 25A/35A/50A/70A	Min. 6.0	Max. 16.0	
	Rated load current 100A/150A	Min. 8.0	Max. 26.0	

※Connect the specified wire as the rated load current.


Rated load current	Wire specification	
Alarm output/power input	Load input/output	
25A/35A/50A/70A	AWG 18 to 14	AWG 13 to 4
100A/150A	AWG 18 to 14	AWG 4 to 2/0

Dimensions



High Temperature Caution
 While supplying power to the load or right after turning off the power of the load, do not touch the body and heatsink. Failure to follow this instruction may result in a burn due to the high temperature.


Removing the Case



※Specification of case fixing bolts

Rated load current	Spec. of bolts
25A, 35A, 50A, 70A	M3
100A, 150A	M4

Replacement of Fuse



※Specification of fuse fixing bolts

Rated load current	Spec. of bolts
25A, 35A, 50A, 70A	M6
100A	Top: M8
	Bottom: M6
150A	M8


※Recommended fuse specifications
 For replacing the fuse, please use the recommended fuse which has the below specifications. (manufacture: BUSSMANN) (manufacture: HINODE)

Rated load current	Model	Rated load current	Model	Rated load current	Model
25A	50FE	50A	80ET	100A	660GH-160
35A	63ET	70A	100FE	150A	660GH-200

※The performance of the product is guaranteed only when using the fuse provided by us.

Parameter Group

- Hold the **[MODE]** key in RUN mode to enter into parameter group.
- In parameter setting group, press the **[MODE]** key to move to other parameter in the group.
- Press the **[MODE]** key once after changing the setting value, to save the setting value and move to the next parameter.
- When entering to the parameter, press the **[\square]** key to move digit, **[Δ]**, **[\square]** keys to change the setting value.
- If there is no key input for 30 sec while setting SV or the parameters, the new settings are ignored, and the unit will return to RUN mode with previous settings.
- Hold the **[MODE]** key for 3 sec to save the setting value and return to RUN mode after changing the setting value.



Monitoring group

Display	Measuring range	Description	Unit	Factory default
I_n	0 to 100	Displays the present control input as percentage.	%	—
U_u^{*1}	0 to rated voltage range	Displays the present load voltage between U-V line.	V	—
U_v^{*1}		Displays the present load voltage between V-W line.		
U_w^{*1}		Displays the present load voltage between W-U line.		
U_u^{*1}	0 to rated current range	Displays the present load current of U-phase.	A	—
U_v^{*1}		Displays the present load current of V-phase.		
U_w^{*1}		Displays the present load current of W-phase.		
L_p^{*1}	0 to rated power range	Displays the present load power.	kW	—
L_r^{*1}	0 to 100	Displays the present resistance as percentage compared to the set resistance of full load auto recognition.	%	—
t_{HP}	0 to 100	Displays the present temperature of heatsink.	°C	—
F_{r9}	50, 60	Displays the present frequency of power supply.	Hz	—

Load Output Formula

Type	Input	Display	Formula
Auto control (AUTO)	Current	DC4-20mA	I_n Load output [%] = Control input [%] × Output slope (5LP) [%]
	Voltage	1-5VDC	
	RS485 communication	$\square \square \square$	
Manual control (MAN)	Output limit	Inside adjuster	I_{-r} Load output [%] = Inside adjuster [%]
		Outside adjuster	$\bar{n}R_n$ Load output [%] = Outside adjuster [%]
		Inside/outside adjuster	E_{-l} Load output [%] = Inside adjuster [%] × Outside adjuster [%]

Comprehensive Device Management Program [DAQMaster]

DAQMaster is a comprehensive device management software for setting parameters and monitoring processes. DAQMaster can be downloaded from our website at www.autonics.com.

Item	Minimum specifications
System	IBM PC compatible computer with Pentium III or above
Operations	Windows 98/NT/XP/Vista/7/8/10
Memory	256MB+
Hard disk	1GB+ of available hard disk space
VGA	Resolution: 1024x768 or higher
Others	RS232C serial port (9-pin), USB port

User Manual for Communication

For the detail information and instructions, please refer to user manual for communication, and be sure to follow cautions written in the technical descriptions (catalog, homepage). Visit our homepage (www.autonics.com) to download manuals.


RS485 Communication Output

Applicable for models with RS485 communication output through option output (SPR3-□□□□□□). Please refer to 'Ordering Information'.

1. Communication Specifications

Comm. protocol	Modbus RTU	Comm. speed	2400, 4800, 9600, 19200, 38400 bps
Connection method	RS485	Comm. response time	5 to 99ms (default: 20ms)
Application standard	Compliance with EIA RS485	Start bit	1-bit (fixed)
Max. connections	31 units (address: 1 to 99)	Data bit	8-bit (fixed)
Synchronization method	Asynchronous	Parity bit	None, Even, Odd
Comm. method	Two-wire half duplex	Stop bit	1-bit, 2-bit
Comm. distance	Max. 800m		

2. Application of system organization



It is recommended to use Autonics communication converter; SCM-WF48 (Wi-Fi to RS485-USB wireless communication converter, sold separately), SCM-US48l (USB to RS485 converter, sold separately), SCM-38l (RS232C to RS485 converter, sold separately). Please use twisted pair wire, which is suitable for RS485 communication, for SCM-WF48, SCM-US48l and SCM-38l.

Parameter 1 group [PR1]

Display	Setting range	Description	Unit	Factory default
$5-t$	0 to 100	Set SOFT START time.	sec	3
$U-t$	0 to 100	Set SOFT UP time.	sec	3
$d-t$	0 to 100	Set SOFT DOWN time.	sec	3
$L-L$		Set the output low-limit value.	%	0
$H-L$	$0 \leq L-L \leq H-L \leq 100$	Set the output high-limit value.	%	100
$5LP$	0 to 100	In case of auto control (AUTO), set the output slope limit proportional to control input for limit load power.	%	100

Parameter 2 group [PR2]

Display	Setting range	Description	Unit	Factory default
I_{nb} *1	420	Set the control input specification.	—	420
	$1-5$			
	512			
	o/nf			
$\bar{C}-\bar{n}$	o/nf	ON/OFF contact	—	PR
	$\bar{C}o\bar{n}$	RS485 comm.		
	PR	Phase control - Normal		
	$u-f$ *2	Phase control - Constant voltage feedback		
	$\bar{C}-f$ *2	Phase control - Constant current feedback		
	$u-f$ *2	Phase control - Constant power feedback		
$F-\bar{C}$	o/nf	ON/OFF control	—	PR
	$I-r$	Inside adjuster		
	$\bar{n}R_n$ *1	Outside adjuster		
	$E-l$	Inside/outside adjuster		
I_{nb} *1	-99 to 99	Set the compensated input value for the offset between the actual input value and the measured input value.	%	00
$5Pn$ *1	-99 to 99	Set the compensated input slope value between the actual input value 100% and the measured input value 100%.	%	00
$d15$	I_n	Resistance and input	—	I_n
	U_u *2	Load voltage between U-V line		
	U_v *2	Load voltage between V-W line		
	U_w *2	Load voltage between W-U line		
	U_u *2	U-phase load current		
	U_v *2	V-phase load current		
U_w *2	W-phase load current			
L_p *2	Load power			
oCu *2	0 to 120	Set the overcurrent alarm value.	%	120
oCt *2	0 to 100	Set the overcurrent alarm delay time.	sec	5
oou *2	0 to 120	Set the overvoltage alarm value.	%	120
oOt *2	0 to 100	Set the overvoltage alarm delay time.	sec	5
$F-L$ *2	o/f / o/n	It executes 100% control output for 3 sec and the load resistance value recognized automatically as the initial set when the function is ON.	—	o/f
Hbu *2	o/f / 10 to 100	Set the heater break alarm value.	%	10
Rdr *2	01 to 99	Assign the unique address when communicating.	—	01
$bP5$ *2	24, 48, 96, 192, 384	Set the speed of data transmission. Multiply by 100 to read the set value. (e.g.: 96=9600bps)	bps	96
Prt *2	o/n / $lEuE$ / o/odd	A parity bit is a data communication method that adds an additional bit to each character in transmitted data as an indicator used to verify data loss and corruption.	—	o/n
$5tP$ *2	1, 2	Set the number of bits to mark the end of a transmitted data string.	bit	2
rUt *2	5 to 99	Set standby time to prevent communication errors when communicating with a slow master device (PC, PLC, etc.).	ms	20
$\bar{C}nU$ *2	E/nR	Comm. write enables	—	E/nR
	$d5R$	Comm. write disables		
	o/f	Unlock		
LcL	$Lc1$	PR1 lock	—	o/f
	$Lc2$	PR2 lock		
	$Lc3$	PR3 lock		
I_n1	o/n / $YEt5$	If set the parameter to YES, reset all parameters to default. Hold the [\square] , [Δ] keys for 5 sec, to enter parameter reset parameter.	—	o/n

*1: Set the below parameters available depends on the control input.


Type	Input	Display	Input correction [I_{nb}]	Input slope correction [$5Pn$]	Output slope [$5LP$]	Monitoring value [I_n]
Auto control (AUTO)	Current	DC4-20mA	420 ○	○	○	The last control input value 0 to 100%
	Voltage	1-5VDC	$1-5$ ○	○	○	
	pulse voltage	5-12VDC	512 ×	×	○	
	No-voltage	ON/OFF contact	o/nf ×	×	○	
Manual control (MAN)	Output limit	Inside adjuster	I_{-r} ×	×	×	
		Outside adjuster	$\bar{n}R_n$ ×	×	×	
		Inside/outside adjuster	E_{-l} ×	×	×	

*2: Displayed only for feedback control models.
*3: Displayed only for models with RS485 comm. output.

Functions


Output limit (OUT ADJ)

This function will be [Control input (%) × OUT ADJ (%) = Output] and it controls the power supplied into the load. Although control input is 100% (5V or 20mA), the output is the 50% which is proportioned with OUT ADJ.
* This function can not be used for ON/OFF control method.



Output high limit/low limit value [H-L/L-L]

This function is to limit output range to protect load.




SOFT START [5-t]

When the power is supplied, this function is able to protect the load when it controls load (molybdenum, white gold, infrared lamp) with inrush current or the width of rising temperature in big (SV is big). SOFT START set time (T) is the required time that output reaches to 100%, and it is differentiated by OUT ADJ set value.
* This function can not be used for ON/OFF control method.


SOFT UP/DOWN [U-t/Id-t]

Unlike SOFT START which operates only once at supplying power, this function protects load from the inrush current in the RUN mode. When reached to the target output value, operation stops.
* This function can not be used for ON/OFF control method.




Input correction [I_nb]

It compensates the offset between actual input value and measured input value.
E.g.) When input monitoring value is 5% at 4mA in DC4-20mA control input, setting I_{nb} to -5 calibrates the input monitoring value to 0%.



Input slope correction [5Pn]

It compensates the gain of the measured 100% input for actual 100% input value.
Calibrated monitoring value = Monitoring value × $5Pn$ / 100
E.g.) When the input monitoring value is 99% at 4mA in DC4-20mA control input, setting $5Pn$ to 1 calibrates the input monitoring value to 100%.



RUN/STOP switching

RUN/STOP status of the power controller can be switched with the external RUN/STOP contact. In the RUN mode, the operation indicator on the front turns on.



AUTO/MANUAL selection

Operation mode (auto control/manual control) of the power controller can be selected with the external AUTO/MAN contact. In the manual control mode, the manual control indicator on the front turns on.



RESET

In the event of system anomalies and alarms, RESET input restarts the power controller. (Parameters are not initialized.) Or, hold the **[\square]**, **[Δ]** keys for 2 sec, to operates RESET.



Alarm

Type	Display	Priority	Operation	Clear alarm
SCR error alarm *1	$5Cr$	1	• Error message flashes. • Alarm indicator (ALM) flashes. • Alarm output turns ON	• Output stops. (SCR OFF)
Overcurrent alarm *1	$o-C$	2		
Heatsink overheat alarm	tEn	4		• Re-supply the power • RESET • Switch to STOP mode
Overvoltage alarm *1	$o-u$	5		
Fuse break alarm	FUS	3		• Automatically cleared when returning within the setting range
Heater break alarm *1	$H-b$	6		

*1: This is only for feedback control models.
*2: When multiple alarms occur at the same time, the highest priority error message will be displayed based on priority.

1) SCR error alarm

Even though output is 0%, if the current of 10% or more of the rated load current flows for over 3 sec continuously, SCR error alarm occurs.

2) Overcurrent alarm

This function protects the load from overcurrent. If the current flows over the overcurrent alarm setting value [oCu] and setting delay time [oCt], overcurrent alarm occurs.

3) Heatsink overheat alarm

When the temperature of a heatsink is over 85°C, heatsink overheat alarm occurs.

4) Overvoltage alarm

This function protects the load from overvoltage. If the current flows over the overvoltage alarm setting value [oou] and setting delay time [oOt], overvoltage alarm occurs.


5) Heater break alarm

Comparing the full load resistance value and the current load resistance value, if the current load resistivity is maintained under the setting value [Hbu] for over 3 sec continuously, heater break alarm occurs. This alarm operates when control output is over 10% and load current is over 10% of the rated current. Output does not stop and operates normally.


$$\text{Current load resistivity}(\%) = \frac{\text{Full load resistance value}}{\text{Current load resistance value}} \times 100$$

Derating Curve


Rated load current 25A




Rated load current 35A




Rated load current 50A




Rated load current 70A



Rated load current 100A



Rated load current 150A



Cautions during Use

- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
- Use the product, after 3 sec of supplying power.
- Before use, set the mode and function according to the specification. Especially, be cautious that the product does not operate when OUT ADJ. is set to 0%. Since changing the mode/parameter during operation may result in malfunction, set the mode and function after disconnecting load output.
- Re-supply the power to the unit after the unit is discharged completely. Failure to follow this instruction may result in malfunction.
- To ensure the reliability of the product, install the product on the panel or metal surface vertically to the ground.
- Install the unit in the well ventilated place.
- While supplying power to the load or right after turning off the power of the load, do not touch the body and heat sink. Failure to follow this instruction may result in a burn due to the high temperature.
- Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.
- Do not wire to terminals which are not used.
- Since inter element can be damaged when using with coil load, inductive load, etc., the inrush current must be under the rated load current.
- Do not use near the equipment which generates strong magnetic force or high frequency noise.
- This unit may be used in the following environments.
 - Indoors (in the environment condition rated in 'Specifications')
 - Altitude max. 2,000m
 - Pollution degree 2
 - Installation category III

Major Products

- Photoelectric Sensors
- Fiber Optic Sensors
- Door Sensors
- Door Side Sensors
- Area Sensors
- Proximity Sensors
- Pressure Sensors
- Rotary Encoders
- Connector/sockets
- Switching Mode Power Supplies
- Control Switches/Lamps/Buzzers
- I/O Terminal Blocks & Cables
- Stepper Motors/Drivers/Motion Controllers
- Graphic/Logic Panels
- Field Network Devices
- Laser Marking System (Fiber, CO₂, Nd: YAG)
- Laser Welding/Cutting System
- Temperature Controllers
- Temperature/Humidity Transducers
- SSRs/Power Controllers
- Counters
- Timers
- Panel Meters
- Tachometer/Pulse (Rate) Meters
- Display Units
- Sensor Controllers

Autonics Corporation
<http://www.autonics.com>

HEADQUARTERS:
18, Bansong-ro 513beon-gil, Haeundae-gu, Busan, South Korea, 48002
TEL: 82-51-519-3232
E-mail: sales@autonics.com