DIN Rail Mount Switching Mode Power Supply

Features

Line-up

- DIN rail type mount and screw mount methods
- Efficient power conversion
 - : high conversion efficiency up to 92% with LLC circuit (SPB-240)
 - : stable power supply with minimal noise and ripple
- · Space efficient design
- : slim and compact size for maximum space efficiency
- : uniform depth size (except SPB-015/030) for neat and tidy installation
- · Safety and user-friendly features
- : terminal protection cover (SPB-060/120/180/240)
- : easy wiring with rising clamp terminal (SPB-015/030) spb-015/030 spb-060 spb-120
- : inrush current prevention, output overcurrent
- prevention, output overvoltage prevention,
- output short-circuit protection, circuit overheating protection
- : low output voltage indicator (red LED), output indicator (green LED)
- Output power: 15W, 30W, 60W, 120W, 180W, 240W



Series Series Series


SPB-18 Series SPB-240 Series

Please read "Safety Considerations" in operation manual before using.





Ordering Information



Specifications

Model			SPB -015 -05	SPB -015 -12	SPB -015 -24	SPB -030 -05	SPB -030 -12	SPB -030 -24	SPB -060 -12	SPB -060 -24	SPB -060 -48	SPB -120 -12	SPB -120 -24	SPB -120 -48	SPB -180 -24	SPB -180 -48	SPB -240 -12	SPB -240 -24	SPB -240 -48
Output power			15W	15.6V	1	25W	30W	31.2W	60W		62.4W	96W	120W		180W	182.4W	240W		
	Voltage		100-240VAC~ (permissible voltage: 85-264VAC~/120-370VDC==)																
condition	Frequency		50/60	Hz															
	Efficiency ^{×1} (typical)	100VAC \sim	77%	80%	83%	77%	82%	84%	81%	84%	85%	82%	85%	85%	89%	89%	87%	89%	89%
		240VAC \sim	76%	79%	82%	78%	83%	85%	83%	86%	87%	85%	88%	88%	92%	92%	90%	92%	92%
	Power factor*1		_			_						Min. 0.9			Min. 0.9		Min. 0.9		
put	Max. current consumption*1		0.4A		0.8A			1.6A			1.9A			3.0 A		3.8A			
ln	Current consumption ^{*1} (typical)	100VAC~	0.35A	0.35A	0.34A	0.56A	0.63A	0.63A	1.24A	1.21A	1.19A	1.19A	1.49A	1.43A	2.03A	2.04A	2.76A	2.71A	2.73A
		240VAC \sim	0.19A	0.19A	0.19A	0.30A	0.35A	0.35A	0.66A	0.65A	0.64A	0.52A	0.61A	0.61A	0.83A	0.84A	1.14A	1.12A	1.13A
Po	wer factor correc	_			_	_						Built-in			Built-in		Built-in		
	Voltage		5VDC=	12VDC=	24VDC=	5VDC=	12VDC=	24VDC=	12VDC=	24VDC=	48VDC=	12VDC=	24VDC=	48VDC=	24VDC==	48VDC=	12VDC=	24VDC=	48VDC=
cteristics	Current		3A	1.3A	0.65A	5A	2.5A	1.3A	5A	2.5A	1.3A	8A	5A	2.5A	7.5A	3.8A	20A	10A	5A
	Voltage adjustment range ^{*2}		Max. ±10%			Max. ±10%			Max. ±5%			Max. ±5%			Max. ±5%		Max. ±5%		
	Input variation*3		Max. ±0.5%			Max. ±0.5%			Max. ±0.5%			Max. ±0.5%			Max. ±0.5%		Max. ±0.5%		
lac lac	Load variation		Max. ±1%			Max. ±1%			Max. ±1%			Max. ±1%			Max. ±1%		Max. ±1%		
ut chara	Ripple& Ripple noise*1,*4				Max. ±1.5% Max. ±1%			Max. ±1%			Max. ±1%			Max. ±1%		Max. ±1.5% Max. ±1%		±1%	
Output	Start-up time*1	100VAC \sim	500ms	550ms	650ms	600ms	550ms	550ms	520ms	550ms	1200ms	1200ms	1200ms	1200ms	87ms	75ms	75ms	87ms	75ms
O	(typical)	240VAC \sim	550ms	550ms	650ms	600ms	550ms	550ms	530ms	550ms	400ms	400ms	400ms	400ms	56ms	45ms	45ms	56ms	45ms
	Hold time*1	100VAC∼	24ms	25ms	25ms	20ms	15ms	15ms	15ms	14ms	15ms	98ms	75ms	87ms	36ms	25ms	33ms	36ms	25ms
	(typical)	240VAC~	190ms	190ms	190ms	130ms	110ms	110ms	100ms	110ms	108ms	97ms	43ms	86ms	36ms	25ms	33ms	36ms	25ms

X1: It is for 100% load.

P-12 Autonics

^{*2:} The output voltage adjuster (V.ADJ) should be used within voltage adjustment range.

X3: It is for the rated input voltage 100-240VAC (85-264VAC), and 100% load.

^{*4:} It is for the rated input voltage 100-240VAC


DIN Rail Mount Type Switching Mode Power Supply

Specifications

Model		SPB -015 -05	SPB -015 -12	SPB -015 -24	SPB -030 -05	SPB -030 -12	SPB -030 -24	SPB -060 -12	SPB -060 -24	I -	SPB -120 -12	SPB -120 -24	SPB -120 -48	SPB -180 -24	SPB -180 -48	SPB -240 -12	SPB -240 -24	SPB -240 -48	
Ir	Inrush current protection (typical)	100VAC∼	7A	7A	7A	7A	7A	6A	13A	14A	10A	9A	11A	10A	8A	8A	8A	8A	8A
٠,١,		240VAC~	32A	30A	31A	29A	31A	29A	19A	17A	37A	37A	36A	37A	25A	26A	22A	25A	26A
ĕ	Over-current protection**4		105 to 160%			105 to 160%			105 to 160%			105 to	105 to 160%			160%	105 to 160%		
Protecti	Over-voltage protection		_			_			_							58.0V ±10%			
	Output low-voltage indicate									20.0V ±10%									
Indicator										ge indi									
Insulation resistance			Over	100ΜΩ	(at 50	0VDC	megge	er betw	een al	l input	termina	als and	outpu	t termii	nals)				
Dielectric strength			3,000VAC 50/60Hz for 1 min (between all input terminals and output terminals)																
			1,500VAC 50/60Hz for 1 min (between all input terminals and F.G.)																
Vibration			0.75mm amplitude at frequency 10 to 55Hz (for 1 min) in each X, Y, Z direction for 2 hour																
Shock			300m/s² (approx. 30G) in each X, Y, Z direction for 3 times																
EMS			Conforms to EN61000-6-2																
EMI			Conforms to EN61000-6-4																
Safety standards			EN60950, EN50178																
Environ Ambient temp.**5			-10 to 50°C, storage: -25 to 65°C (surrounding air temp.: max. 40°C)																
me	ent Ambien	t humi.	25 to 85%RH, storage: 25 to 90%RH																
Input cable			24 to 1 rial: Cu	-		24 to 19 rial: Cu	-	_	21 to 19 rial: Cu		_	21 to 19 rial: Cu			1 to 19 ial: Cu)				
Terminal tightening torque		0.3 to	0.5N·r	n	0.3 to	0.5N·n	n	0.7 to	0.9N·n	n	0.7 to	0.9N·r	n	0.7 to	0.9N·m	0.7 to	0.9N·n	n	
Protection		IP20 (IEC st	andard)			•						•		•			
Approval			C€ .@) us usten		€ :@) US USTED		(E () us usteo		(€ .@) us ustro		CE @) us lasten	CE @)us libteo	
Weight ^{×6}			x. 202 x. 129			x. 249 x. 176	_		x. 347 x. 274	_		x. 570 x. 466	_	Approx (approx	i. 609g k. 505g)	Appro (appro	,	_	

^{※5:} Refer to '■ Output Derating Curve by Ambient Temperature'.

Output Derating Curve by Ambient Temperature



Over-Heating Protection


If the inner temperature of the switching element is around 140°C by overheat, it stops switching operation and becomes open state. Output voltage is not output.

Installation

O DIN rail mounting


• Mounting to DIN rail

Put the unit on the part ⓐ of the rail before press it to the direction ⓑ.



Removing from DIN rail

Put a screw driver into the part © before push it downward.



(A) Photoelectric Sensors

(B) Fiber Optic Sensors

(C) Door/Area Sensors

(D) Proximity Sensors

(E) Pressure Sensors

(F) Rotary

(G) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets

(H) Temperature Controllers

(I) SSRs / Power Controllers

(J)

(K)

L) anel

(M) Tacho / Speed / Pulse

(N) Display Units

(O) Sensor Controllers

(P) Switching Mode Power Supplies

(Q) Stepper Motor & Drivers

> (R) Graphic/ Logic Panels

Field Network Devices

(T) Software


Autonics P-13

X6: The weight includes packaging. The weight in parenthesis is for unit only.


XEnvironment resistance is rated at no freezing or condensation.

Block Diagram


• SPB-015/030/060 Series



SPB-120 Series




SPB-180/240 Series



■ Wiring Diagram/Unit Description

SPB-015/030 Series




Wiring Diagram

- 1. Output power [+V] terminal
- 2. Output power [-V] terminal
- 3. Input power [L] terminal
- 4. Input power [N] terminal
- 5. Frame ground [F.G.] terminal

Unit Description

- A. Output (DC ON) indicator (green)
- B. Output low voltage (DC LOW) indicator (red)
- C. Output voltage adjuster (V.ADJ)

SPB-060/120/180/240 Series




XSPB-015/060 Series has an output power [+V] terminal (1) and an output power [-V] terminal (2).


DIN Rail Mount Type Switching Mode Power Supply

Dimensions

SPB-015 Series



SPB-030 Series



0

(unit: mm)

(A) Photoelectric Sensors

(C) Door/Area Sensors

(D) Proximity Sensors

(G) Connectors/ Connector Cables/ Sensor Distribution Boxes/Sockets


(I) SSRs / Power Controllers

110


(M) Tacho / Speed / Pulse Meters

(N) Display Units


(R) Graphic/ Logic Panels




SPB-060 Series





SPB-120/180 Series





SPB-240 Series





P-15 **Autonics**

Proper Usage

- Cautions for operating
- This product does not have the function for parallel or series operation.
- The output current must be used within the rated specification.

If over-current is applied to the product, over-current protection is operating.

It causes shorten the life cycle of the product.

- The output voltage must be used within the rated output specification.
- For the product, which has the control function for over-voltage, if making the output voltage adjuster (V.ADJ) to over rated voltage, the function starts to work.
- This product has the function of over-heating protection.

The over-heating protection operates when the product has over-heating condition.


The product normally operates if the load is removed for over 5 minutes.

- In case of the SPB-015/030/060, it does not have the harmonics suppression and power factor improvement circuit. To improve harmonics suppression and power factor, install the additional device.
- In case of the SPB-015/030/060, it uses condenser rectification, and power factor is within 0.4 to 0.6 range. To use a abinet panel or a electric transformer, select input power capacity of this product as below formula.

Input apparent power [VA] = $\frac{\text{Output active power [W]}}{\text{Power factor} \times \text{Efficiency}}$

- This product is provided with a noise filter, but noise is variable according to operating conditions such as installation environment and wiring.
- When the inner fuse is damaged, replace the fuse of same specification.
- Cautions for mounting
- Mount this product on the surface of metal panel vertically for the reliability.
- Please mount this product at a well-ventilated place in order to increase the heat radiation efficiency.
- Mounting

When installing more than two power supplies, min. 20mm distance is required to radiate heat effectively. Assure min. 75mm distance of the upper or the lower product and mount the products as following figure.



- Dielectric or insulation resistance test when this unit is installed in the control panel.
- Separate the unit completely from a control panel circuit.
- · Short all terminals of the unit.
- Caution for connecting the input power terminal

Connect input line(AC) to the input terminal correctly.

When you connect this to the other terminal, it may cause damage to the power supply.

- Do not use the unit in the following environments.
- · Environments with high vibration or shock.
- Environments with strong alkalis or acids.
- Environments with exposure to direct sunlight.
- Near machinery which produce strong magnetic force or electric noise.
- This unit may be used in the following environments.
- Indoors
- Max. altitude: 2,000m
- Pollution degree 2
- Installation category II