



# HIOKI

---

---

INSTRUCTION MANUAL

## 9624-50

# PQA-HiVIEW PRO

HIOKI E. E. CORPORATION

---

---



---

# User's License Agreement

**Important** Please read the following agreement carefully. This user's license agreement (hereafter referred to as Agreement) is a legal contract between the software user (individual or institution) and HIOKI E. E. CORPORATION (hereafter referred to as HIOKI). The term "software" includes any related electronic documentation and computer software and media, as well as any printed matter (such as the Instruction Manual).  
By installing, reproducing, or using the software, you, the Licensee, agree to accept the license terms set forth in this Agreement.

---

This software is protected by copyright laws, international copyright agreements, as well as non-corporate laws. The software is a licensed product, and is not sold to the user.

## 1. License

This Agreement grants you, the Licensee, a license to install a single copy of the software on a specified computer system.

## 2. Explanation of other rights and restrictions

- 1. Restrictions on reverse engineering, decompiling, and disassembling:  
You may not reverse engineer, decompile, or disassemble the software.
  - 2. Separation of components:  
This software is licensed for use as a single product. You may not separate the components for use on multiple computer systems.
  - 3. Loaning:  
You may not loan or lease the software.
  - 4. Transfer of software:  
You may transfer full rights in accordance with this Agreement. However, if you do so, you may not retain any copy of the software, but must transfer the software in its entirety (all components, media, related documentation such as the Instruction Manual, and this Agreement), and must ensure that the receiver of the software agrees with the terms set forth in this Agreement.
  - 5. Cancellation:  
In the event that the terms and conditions set forth in this Agreement are violated, HIOKI retains the right to cancel this Agreement without compromise of any of its other rights. In this event, you must destroy all copies of the software and its components.
-

---

### **3. Copyright**

The title and copyright rights concerning the software's related documentation, such as the Instruction Manual and copies of the software, are the property of HIOKI and other licensors, and are protected by copyright laws and international agreement regulations. Accordingly, you must treat the software as you would any other copyrighted document. However, you are permitted to make copies as indicated in (A) and (B) below provided such copies are not intended for use other than back-up purposes.

- (1) You may make a single copy of the software.
- (2) You may install this software on a single computer. However, you may not reproduce the documentation supplied with the software, such as the Instruction Manual.

### **4. Dual media software**

You may receive the same software on more than one type of media. However, regardless of the type and size of media provided, you may only use one media type and only on a single computer. You must not use or install the other media on any other computer. Furthermore, except when transferring the software as stipulated above, you may not loan, lease, or transfer the other media to any other user.

### **5. Warranty**

- 1. HIOKI reserves the right to make changes to the software specifications without any prior warning. If HIOKI releases a new version of the software, it will provide registered users with information about the revised software.
  - 2. If the software does not operate in accordance with the supplied Instruction Manual, or the software media or Instruction Manual are damaged in any way, you have one year from the date of purchase to apply for either an exchange or repair at HIOKI's discretion.
  - 3. In no event will HIOKI be liable for any damages resulting from fire, earthquake, or actions of a third party under the conditions stated in item number 2 above, or for any damage caused as a result of your using the software incorrectly or under unusual circumstances. Further, the warranty is invalid if the following occurs:
    - (1) Damage incurred through transport, moving, droppage, or any other kind of impact after you purchased the software.
    - (2) Damage incurred through any form of alteration, unwarranted servicing, or any other type of mistreatment.
  - 4. In the event that the software is exchanged or repaired, the period of warranty expires on the latest occurring date out of the day stated in the original warranty, and exactly 6 months from the day the exchanged/repaired software is returned to you.
  - 5. Regardless of the grounds for making a legal claim, HIOKI and its licensors will not be liable for any damage incurred (including, but not limited to: lost profits, suspension of business, loss of data or lost savings) unstated in the warranty terms for the use of this software. This is true even if HIOKI is notified of the possibility of such damages. In any event, HIOKI's liability shall be limited only to replacing defective software with software that is not defective
-

---



---

# Contents

---

<b>Introduction .....</b>	<b>1</b>
Confirming Package Contents and Handling the CD .....	1
Symbols and Terminology .....	2
<b>Chapter 1</b>	
<b>Overview .....</b>	<b>3</b>
<b>Product Overview and Features .....</b>	<b>3</b>
<b>Operation Flowchart .....</b>	<b>4</b>
<b>Chapter 2</b>	
<b>Setup .....</b>	<b>5</b>
<b>Hardware and OS Requirements (System Configuration).....</b>	<b>5</b>
<b>Installing the 9624-50 PQA-HiView Pro Program .....</b>	<b>6</b>
<b>Uninstalling the Program.....</b>	<b>9</b>
<b>Chapter 3</b>	
<b>Basic Operations .....</b>	<b>11</b>
<b>Starting and Closing the Program .....</b>	<b>11</b>
Starting the Program .....	11
Closing the Program .....	12
<b>Loading Data.....</b>	<b>13</b>
File Types .....	13
Loading Data .....	14
<b>Viewing Measurement Data .....</b>	<b>16</b>
Screens .....	16
Changing Windows .....	17
Window List .....	18
<b>Viewing Event Phenomena.....</b>	<b>19</b>

---

<b>Viewing Measurement Data as Numerical Values (Cursor Measurement) .....</b>	<b>21</b>
<b>Viewing Measurement Settings.....</b>	<b>23</b>
<b>Printing Measurement Data .....</b>	<b>24</b>
<b>Arranging Windows (Window Layout).....</b>	<b>26</b>
<b>Copying a Display Image to the Clipboard .....</b>	<b>27</b>
<b>Generating Reports .....</b>	<b>28</b>
Report Output Items .....	32
Report Printout Example .....	33
<b>Storing Measurement Data in a CSV File .....</b>	<b>35</b>
Convert Time-Series Data to CSV Format .....	35
Converting Waveform Data to CSV Format .....	38
Converting Demand Data to CSV Format .....	39
Before Converting Harmonic Voltage Measurement Data (EN50160 Mode) to CSV Format (Hioki 3196 only) .....	40
Making Use of CSV File Data (Practical Applications) .....	41
<b>Downloading Measurement Data from the Power Quality Analyzer (LAN Download Function) .....</b>	<b>44</b>
<b>Saving and Loading Settings Files .....</b>	<b>46</b>
About Settings Files .....	46
Specify the Save Destination for the Settings File Beforehand	46
Saving a Compound File .....	47
Loading a Compound File .....	47
 <b>Chapter 4</b>	
<b>Analyzing Measurement Data from the Hioki 3196 .....</b>	<b>49</b>
<b>Hioki 3196 Measurement Data Window Layout .....</b>	<b>49</b>
Window Display .....	49
Menu Bar Operations .....	50
Tool Bar Operations .....	53
<b>Switching Modes .....</b>	<b>55</b>

---

<b>Viewing a Time Series Graph</b> .....	[TIME PLOT]	<b>56</b>
Opening and Switching Time Plot Windows .....		56
Viewing RMS Fluctuations .....	[TIME PLOT – RMS]	58
Viewing Voltage Fluctuations .....	[TIME PLOT – VOLTAGE]	59
Viewing Harmonic Fluctuations .....	[TIME PLOT – HARMONICS]	60
Viewing Inter-Harmonic Fluctuations .....	[TIME PLOT – INTERHARM]	61
<b>Viewing Events as a List</b> .....	[EVENT LIST]	<b>62</b>
<b>Viewing Event Measurement Data</b> .....	[EVENT DATA]	<b>63</b>
Opening and Switching Event Data Windows .....		63
Viewing Event Details .....	[Event details]	64
Viewing Voltage/Current Waveforms .....	[VOLTAGE/CURRENT]	65
Viewing Voltage/Transient Waveforms .....	[VOLTAGE/TRANSIENT]	66
Viewing Voltage Waveforms .....	[VOLTAGE]	67
Viewing Current Waveforms .....	[CURRENT]	68
Viewing the Vector Display .....	[VECTOR]	69
Viewing the DMM Display .....	[DMM]	70
Viewing Harmonics on a Bar Graph .....	[HARMONICS BAR GRAPH]	71
Viewing Harmonics in a List .....	[HARMONICS LIST]	72
<b>Viewing Voltage Fluctuation Details</b> .....	[Voltage Fluctuation Event Graph]	<b>73</b>
<b>Viewing Energy Consumption</b> ...	[Integrated Power Window]	<b>74</b>
<b>Viewing a Demand Graph</b> .....	[Demand Window]	<b>75</b>
<b>Testing Measurement Data Conformance</b> .....	[ITIC]	<b>76</b>
Setting Tolerances (Making a User-Defined Curve) .....		77
Curve Tables (Reference) .....		79
<b>Viewing a Delta V10 Flicker Graph</b> .....	[Delta V10 Flicker Window]	<b>80</b>
<b>Viewing an IEC Flicker Graph</b> .....	[IEC Flicker Window]	<b>81</b>
<b>Viewing Setting Conditions for Measurement Data</b> .....	[SYSTEM]	<b>82</b>

---

<b>Viewing EN50160 Mode Measurement Data.....</b>	<b>83</b>
Overview Window .....	83
Harmonic Window .....	85
Signaling Window .....	86
Measurement Result Classification Window .....	87

## **Chapter 5**

### **Analyzing Measurement Data from the Hioki 3197 91**

<b>Hioki 3197 Measurement Data Window Layout .....</b>	<b>91</b>
Window Display .....	91
Menu Bar Operations .....	92
Tool Bar Operations .....	95
<b>Viewing a Time Series Graph..... [TIME PLOT]</b>	<b>96</b>
Opening and Switching Time Plot Windows .....	96
Viewing RMS Fluctuations .....	[TIME PLOT – RMS] 98
Viewing Voltage Fluctuations.....	[TIME PLOT – VOLTAGE] 99
<b>Viewing Events as a List.....[EVENT LIST]</b>	<b>100</b>
<b>Viewing Event Measurement Data..... [EVENT DATA]</b>	<b>101</b>
Opening and Switching Event Data Windows .....	101
Viewing Event Details .....	[Event details] 102
Viewing Voltage/Current Waveforms ..	[VOLTAGE/CURRENT] 103
Viewing Voltage Waveforms .....	[VOLTAGE] 104
Viewing Current Waveforms .....	[CURRENT] 105
<b>Viewing Voltage Fluctuation Details</b>	
..... [Voltage Fluctuation Event Graph]	<b>106</b>
<b>Viewing an Inrush Current Graph</b>	
..... [Inrush Current Event Graph]	<b>107</b>
<b>Viewing Energy Consumption .. [Integrated Power Window]</b>	<b>108</b>
<b>Viewing a Demand Graph .....</b>	<b>[Demand Window] 109</b>
<b>Viewing Setting Conditions for Measurement Data</b>	
..... [SYSTEM]	<b>110</b>



<b>Chapter 6</b>	
<b>Specifications</b>	<b>111</b>
General Specifications.....	111
Hioki 3196 Function Specifications and Calculation Formulas.....	111
Hioki 3197 Function Specifications.....	119
<b>Appendix</b>	<b>A 1</b>
Appendix 13196 Data-header Composition .....	A 1
Appendix 23197 Data-header Composition .....	A 5
<b>Index</b>	<b>Index 1</b>

---



## Introduction

Thank you for purchasing the HIOKI "Model 9624-50 PQA-HiVIEW PRO." To obtain maximum performance from the instrument, please read this manual carefully, and keep it handy for future reference.

The 9624-50 PQA-HiVIEW PRO is a PC program for use with the Model 3196 and 3197 Power Quality Analyzers.

### Registered trademarks

- Microsoft, Windows and Excel and registered trademarks of Microsoft Corporation in the USA.
- Pentium is a registered trademark of Intel Corporation in the USA.

## Confirming Package Contents and Handling the CD

When you receive the software, inspect it carefully to ensure that no damage occurred during shipping.

If damage is evident, or if it fails to operate according to the specifications, contact your dealer or Hioki representative.



9624-50 PQA-HiVIEW PRO  
Program Software (CD)



Instruction Manual

### **CAUTION**

#### CD Handling Precautions

Follow these precautions to ensure safe operation and to obtain the full benefits of the various functions.

- Always hold the disc by the edges, so as not to make fingerprints on the disc or scratch the printing.
- Never touch the recorded side of the disc. Do not place the disc directly on anything hard.
- Do not wet the disc with volatile alcohol or water, as there is a possibility of the label printing disappearing.
- To write on the disc label surface, use a spirit-based felt pen. Do not use a ball-point pen or hard-tipped pen, because there is a danger of scratching the surface and corrupting the data. Do not use adhesive labels.
- Do not expose the disc directly to the sun's rays, or keep it in conditions of high temperature or humidity, as there is a danger of warping, with consequent loss of data.
- To remove dirt, dust, or fingerprints from the disc, wipe with a dry cloth, or use a CD cleaner. Always wipe spherical from the inside to the outside, and do not wipe with circular movements. Never use abrasives or solvent cleaners.
- Hioki shall not be held liable for any problems with a computer system that arises from the use of this CD, or for any problem related to the purchase of a Hioki product.

In the interests of ongoing product developments, there may be minor discrepancies between screen displays and the operating instructions, and in the data conversion process.

## Symbols and Terminology

The following symbols in this manual indicate the relative importance of cautions and warnings.

### Symbols



Indicates that incorrect operation presents a possibility of injury to the user or damage to the instrument.



Indicates advisory items related to performance or correct operation of the instrument.

(p. )

Indicates the location of reference information.

\*

Indicates that descriptive information is provided below.

### Mouse Operation Terminology

<b>Click</b>	Press and quickly release the left button of the mouse.
<b>Right-click</b>	Press and quickly release the right button of the mouse.
<b>Double click</b>	Quickly click the left button of the mouse twice.
<b>Drag</b>	While holding down the left button of the mouse, move the mouse and then release the left button to deposit the chosen item in the desired position.
<b>Activate</b>	Click on a window on the screen to activate that window.

### Other Terminology

- Unless otherwise specified, "Windows" represents Windows 2000, or Windows XP.
- Dialog box represents a Windows dialog box.
- Menus, dialogs, buttons in a dialog, and other names on the screen are indicated in brackets.
- Example: **File-Open** indicates that you should click **File** in the menu bar, and then click **Open** in the displayed pull-down menu.

# Overview

# Chapter 1

## Product Overview and Features

The Hioki 9624-50 PQA-HiView Pro is a software application for analyzing binary-format measurement data from the Hioki 3196 and 3197 Power Quality Analyzers on a computer.


The PQA-HiView Pro can load and read only binary data recorded with the Hioki 3196 and 3197 Power Quality Analyzers.

It cannot read text or CSV data.

The 9624-50 PQA-HiView Pro offers the following functions.


### Display and Analyze Measurement Data (p. 16)

Display and analyze measurement data in the same way as on the Power Quality Analyzers.



### Print Displayed Windows (p. 24) and Copying (p. 27)

Print and copy displayed windows for use in other applications.



### Generate Measurement Data Reports (p. 28)


Print any measurement as a report. You can also save it as a rich text format file, and use it in other applications.



### Display Measurement and Calculation Values (Maximum, Minimum and Average) (p. 21)

Use the A/B cursors to view maximum, minimum and average values within any time span.

VOLTAGE/CURRENT WAVEFORM [No.15 08/08 08:31:53.915 1 rms CH1 IN]											
		Calculation between A and B cursor		Copy							
cursor		U1		U2		U3		U4		I1	
A	08/08 08:31:51.951	0.2613k	-0.2367k	-0.0219k	0.0003k	0.95	-22.12				
B	08/08 08:31:53.988	0.2027k	0.0773k	-0.2797k	0.0003k	64.13	-66.16				
00:00:00.037		0.0586k	0.3161k	-0.2581k	0.0000k	63.27	44.05				
MAX values											
AVE values											
MIN values											



### Convert Measurement Data to CSV Format (p. 35)


Convert any span of measurement data to CSV format. Load converted files into computer spreadsheet programs.

9624-50_sample.csv										
	A	B	C	D	E					
1	Date	Time	Umax1	Umax2	Umin1	Un				
2	2006/3/8	4:51:32	1.05E+02	1.05E+02	1.03E+02	1				
3	2006/3/8	5:21:32	1.05E+02	1.05E+02	1.04E+02	1				
4	2006/3/8	5:51:32	1.05E+02	1.05E+02	1.01E+02	1				
5	2006/3/8	6:21:32	1.05E+02	1.07E+02	9.98E+01	9				
6	2006/3/8	6:51:32	1.05E+02	1.07E+02	9.83E+01	9				
7	2006/3/8	7:21:32	1.07E+02	1.05E+02	1.04E+02	9				

### Calculate Demand and Energy Consumption

#### Hioki 3196(p. 74), Hioki 3197(p. 108)

From the measurement data, calculate maximum and average demand values, and energy consumption.



### (Hioki 3196 only)

#### Download measurement data from the 3196 Power Quality Analyzer (p. 44)

Connect the Hioki 3196 to a computer via LAN to download data from its internal memory and data files from the 3196's PC Card.


### Display measurement data in EN50160 mode (p. 83)

#### Judge anomalies according to the ITIC (CBEMA) Curve\* (p. 76)

\* Commonly used in the USA, the ITIC Curve is a standard for evaluating voltage anomalies by specifying a range of acceptable tolerance. A "User-Defined Curve" can be optionally defined for voltage anomaly evaluation.

# Operation Flowchart

First things to do after purchasing



# Setup

# Chapter 2

## Hardware and OS Requirements (System Configuration)

The 9624-50 PQA-HiView Pro requires the following hardware and software. Please verify your system configuration.

<b>Computer Type</b>	PC/AT compatible
<b>Operating System</b>	English version of any of the following operating systems: <ul style="list-style-type: none"><li>• Microsoft Windows 2000</li><li>• Microsoft Windows XP</li></ul>
<b>Memory</b>	At least 128 MB
<b>Hard Disk</b>	At least 128 MB free space
<b>Display</b>	XGA (1024 x 768 dots) or higher
<b>Disk System</b>	CD-ROM drive (Used only for installation)
<b>Printer</b>	Required for report printing on the computer. Either color or monochrome can be used, but the fastest possible printing is recommended.

**NOTE**

For some models, proper operation cannot be guaranteed even when the above requirements are satisfied.

# 6

## Installing the 9624-50 PQA-HiView Pro Program

### Installing the 9624-50 PQA-HiView Pro Program

Install the program by the following procedure.

Windows XP or Windows 2000 should be installed by your Systems Administrator.

Example: Installing on Windows XP

Note: screen messages may differ slightly depending on the operating system.


**NOTE** Installation may not be possible when other applications are running. Before installing, close all applications that you can. When an anti-virus program is running, installation may not be possible even when no virus exists. In this case, change your anti-virus program settings as necessary to allow installation to proceed.

**1** Start the computer.


Close all running programs.

**2** Insert the program CD into the CD-ROM drive.

**3** Double click **My Computer** to open it, then double click the CD-ROM icon.




**4** In the English folder, double click **Setup.exe** (the extension may not be displayed) to start the installer.






- 5 In the installer, click **Next** and confirm the installation destination.



Next




Next

The installation destination folder can be changed on this screen.

To change the installation destination, click **Change** to select another folder. There is normally no need to change it.

If you are not changing the installation destination, click **Next**.


### To change the installation destination




Select the installation folder in the Path field.

## Installing the 9624-50 PQA-HiView Pro Program


### 6 Click **Install** to start installing.




Installation starts.



Progress is displayed during installation.  
To interrupt installation in progress,  
click **Cancel**.



Select a folder for the program.



Click **Finish** to finish installation.

**Installation finished**


### 7 Remove the CD from the CD-ROM drive.

Refer to Chapter 3, "Basic Operations" (p. 11) for the next procedure.

# Uninstalling the Program

Use the following procedure to uninstall the program.


- 1 From the Windows **Start** menu, select the **Control Panel**, and double click **Add or Remove Programs**.




- 2 Select **9624-50 PQA-HiView Pro** and click the **Change/Remove** (or **Remove**) button



- 3 Click **Yes**.



- 4 Click **Finish**.



The 9624-50 PQA-HiView Pro program is uninstalled.

The uninstall procedure is finished.

# 10

## *Uninstalling the Program*


---

---


# Basic Operations Chapter 3

## Starting and Closing the Program

### Starting the Program



Open the Windows **Start** menu and click **All Programs – HIOKI – HIOKI 9624-50 – 9624-50**.



The main screen, entitled HIOKI 9624-50 PQA-HiVIEW PRO, appears.

# 12


## Starting and Closing the Program

### Closing the Program

The program can be closed by any of the following methods.


#### Method 1

From the menu bar, click **File – Exit**



#### Method 2

Click the Close button (  ) at the top right corner of the window



## Loading Data

Measurement data recorded with the Hioki 3196 or 3197 Power Quality Analyzer can be loaded by the PQA-HiView Pro program.

However, it can load only binary format measurement data. Text and CSV format data cannot be loaded.

To load measurement data:

### 3196

You can insert a PC Card with stored measurement data into a PC Card reader connected to the computer, or transfer the measurement data over LAN to the computer, and then load it.

**See:** "Downloading Measurement Data from the Power Quality Analyzer (LAN Download Function)" (p. 44)

### 3197

You can use the special-purpose application program bundled with the Hioki 3197 to download the measurement data, and the load it.

**See:** The instructions (PDF) for the special-purpose application program on the CD-R supplied with the Hioki 3197


## File Types

The data to be loaded is specified by its folder.


The following data files can be loaded from that folder.

File Contents		File Extension	3196	3197
Setting data		.SET	●	●
TIME PLOT data		.ITV	●	●
Event data	Lists	.EVT	●	●
	Voltage/current waveforms		●	●
	Numerical values		●	—
Flicker data (Delta V10, IEC)		.FLC	●	—
Transient over voltage waveform data		.TRN	●	—
Event voltage fluctuation data		.WDU	●	●
EN50160 data		EN50160.EN	●	—
EN50160 event data		EVENT.EN	●	—
Inrush current graph data		.INR	—	●
Demand graph data		.DEM	—	●

### Loading Data

- 1 Click the  (Open button), or select **File – Open** on the menu bar.  
The Open dialog box appears.

- 2 Select the folder containing the measurement data from the 3196 or 3197 to be loaded.




Measurement data from the 3196 or 3197 is stored in folders named as follows:

**B + date + serial number (8 digits)**

Example: **B 6 0 4 0 3 0 2**

				2 <sup>nd</sup> folder				
			April 3					
			Year 2006					
								Binary data

- 3 Click the **OK** button to load the selected data.




The loaded data is displayed on screen. Refer to the following for the details of each screen.

**See:** "Analyzing Measurement Data from the Hioki 3196" (p. 49)  
"Analyzing Measurement Data from the Hioki 3197" (p. 91)

### Analyzing Two Types of Measurement Data

Two instances of the PQA-HiView Pro program can be started and run at the same time. This is convenient for comparing measurement data from the Hioki 3196 with that from the 3197.





**NOTE**

- New measurement data can still be loaded even after data has already been loaded. However, only most-recently loaded data can be displayed.
- Reading a folder containing a large amount of data may take some time. The time required to read the data depends on the computer system.

**Estimated Loading Time**

(Example) To load measurement data into the PQA-HiView Pro from a Flash ATA card inserted in the computer.

Loading time: About 1 minute

Loading conditions:

- Computer System Configuration

Computer	400-MHz Pentium II
OS	Microsoft Windows 2000 Professional
Memory	128 MB

- Measurement Data

Capacity	256 MB
ITV files	TIME PLOT(ALL DATA, MAX/MIN/AVE)
EVT files	1000 items (all transients)

---

# Viewing Measurement Data

## Screens

This section describes the program's windows. The windows for the Hioki 3196 and 3197 are slightly different. Refer to the window content descriptions for details.

See: "Hioki 3196 Measurement Data Window Layout " (p. 49)  
 "Hioki 3197 Measurement Data Window Layout " (p. 91)

When the Model 9624-50 starts up, the main screen appears. Measurement data windows are displayed on the main screen.

Example: After loading measurement data from Hioki 3196

**Menu bar**  
 Read data folder

**Window tool bar**  
 You can change the content displayed in the measurement windows, and magnify or reduce waveform views.

**Scroll bar**  
 You can scroll each window.

**Minimize**  
**Maximize**  
**Close**

**Menu bar**  
 File Edit View Window TIME PLOT Option Help

**Tool bar (standard)**  
 U unb CH1 all Ydiv x50 Tdiv 10k/div

**Tool bar (window)**  
 Click the icons to open different windows for viewing measurement data, or to show and hide windows.

**EVENT LIST**

No.	Date	Time	Event Ca...	CH	IN...	WDU
1	08/08	16:49:15.405	Ext (Stop)			
2	08/08	08:35:49.532	I rms	CH1	OUT	
3	08/08	08:35:49.132	I rms	CH1	IN	
4	08/08	08:34:11.759	I peak-	CH2	OUT	
5	08/08	08:34:11.559	I rms	CH1	OUT	
6	08/08	08:34:11.359	I rms	CH1	IN	
7	08/08	08:33:10.950	I peak+	CH1	OUT	
8	08/08	08:33:10.750	I rms	CH1	OUT	
9	08/08	08:33:10.550	I rms	CH1	IN	
10	08/08	08:32:27.523	I peak-	CH2	OUT	
11	08/08	08:32:27.323	I rms	CH1	OUT	
12	08/08	08:32:27.123	I rms	CH1	IN	
13	08/08	08:31:54.315	I peak+	CH1	OUT	
14	08/08	08:31:54.115	I rms	CH1	OUT WDU	
15	08/08	08:31:53.915	I rms	CH1	IN	
16	08/08	08:31:19.910	I rms	CH1	OUT WDU	
17	08/08	08:31:19.510	I rms	CH1	IN	
18	08/08	08:30:52.310	I rms	CH1	OUT	
19	08/08	08:30:51.909	I rms	CH1	IN	
20	08/08	08:29:57.697	I rms	CH1	OUT	

**TIME PLOT - RMS U unb**  
 0.40 %/div MIN MAX AVE

**VOLTAGE CURRENT WAVEFORM [No.9 08/08 08:33:10.550 I rms CH1 IN]**  
 CH1-3: 100.00 V/div CH4: 100.00 V/div CH1 CH2 CH3 -4  
 CH1-3: 50.00 A/div CH4: 50.000 A/div

**Status bar**  
 Shows the current status and information about each window. Move the mouse over the tool bar to see tool descriptions.

**Measurement windows**  
 Windows can be changed from the menu bar or from the tool bar (for displaying windows).


**Pop-Up menu**  
 Appears when you right click on each window. Operations are the same as on the menu bar.

## Changing Windows


You can change the selected window to a different window.

- 1 If the window you want to display is not already the active window, click it to make it active, or select it from the **Window** menu.

The selected window type is displayed to the right of the Window menu item.




- 2 Click an item to the right of the Window menu item, and select the window to switch to from the pull-down menu.



When a Time Plot window is active in step 1 above

The active window is replaced.

You can also select from the pop-up menu.



A pop-up menu appears when you right click on a window.

Click the window you want to activate.  
Items that are not selectable are grayed out.

## Window List

## Windows for analyzing data from the 3196

Window Name	See Page	
Event List Window	(p. 62)	
Time Plot	RMS	(p. 58)
	Voltage	(p. 59)
	Harmonics (Harmonic Fluctuations)	(p. 60)
	Interharm (Inter-Harmonic Fluctuations)	(p. 61)
Event Data Window	Event details	(p. 64)
	Voltage/Current	(p. 65)
	Voltage/Transient	(p. 66)
	Voltage	(p. 67)
	Current	(p. 68)
	Vector	(p. 69)
	DMM	(p. 70)
	Harmonics Bar Graph	(p. 71)
	Harmonics List	(p. 72)
ITIC Window	Tolerance Curve	(p. 76)
Delta V10 Flicker Window	(p. 80)	
IEC Flicker Window	(p. 81)	
Voltage Fluctuation Event Graph	(p. 73)	
Integrated Power Window	(p. 74)	
Demand Window	(p. 75)	
EN50160 Window	Overview	(p. 83)
	Harmonic	(p. 85)
	Signaling	(p. 86)
	Measurement Result Classification	(p. 87)
System Window	(p. 82)	

## Windows for analyzing data from the 3197








Window Name	See Page	
Event List Window	(p. 100)	
Time Plot	RMS	(p. 98)
	Voltage	(p. 99)
Event Data Window	Event details	(p. 102)
	Voltage/Current	(p. 103)
	Voltage	(p. 104)
	Current	(p. 105)
Voltage Fluctuation Event Graph	(p. 106)	
Inrush Current Event Graph	(p. 107)	
Integrated Power Window	(p. 108)	
Demand Window	(p. 109)	
System Window	(p. 110)	

# Viewing Event Phenomena

An event name or marker is displayed in each window at the location where an event has occurred (Event Marker function).


Each displayed window is interlinked, so by clicking an event's name or marker, you can view other characteristics related to that event in other windows.

Measurement data from the Hioki 3196 is displayed differently than that from the 3197.


Event Viewing Windows	Event Display		
	Event Occurrence	Voltage Fluctuation Graph (WDU event)	Inrush Current Graph (INRUSH event, Hioki 3197 only)
<b>Event List Window</b>	Event Category items indicate the contents of events.		
		The WDU column shows WDU events.	The INRUSH column shows INRUSH events.
<b>Time Plot Window</b>	 (Red) Event markers are displayed at the times that event occurred.	 (Blue) Event markers are displayed at the times when voltage fluctuations occurred.	 (Pink) Event markers are displayed at the times that inrush current occurred.
<b>Voltage Fluctuation Event Window</b>	Displays the message, "Specified file xxx does not exist."	Displays the waveform for the event selected in another window.	
<b>Inrush Current Graph Window (Hioki 3197 only)</b>			
<b>Event Data Window</b>	Displays the waveform for the event selected in another window. Event markers  (yellow-green) are displayed at event occurrences.		
<b>ITIC Window (Hioki 3196 only)</b>	_____	 (CH1: Red)  (CH2: Yellow-Green)  (CH3: Blue)	_____

## Example: Viewing event phenomena in a Time Plot window

Event Marker



The selected event marker becomes hollow.



When multiple event markers overlap

Click on overlapping event markers to display a menu on the graph.

Select an event marker from the menu.

If more than 30 event markers overlap, they are displayed in sub-menus of up to 30 markers each.

Example: Graph of a voltage fluctuation event (WDU) in measurement data from Hioki 3196

### Event List Window

**Event Content** Click to display the event graph.

No.	Date Time	Event Ca	CH	IN...	W	U
1	08/09 18:28:22.096	Ext (Stop)				
2	08/04 19:07:17.631	Dip	CH1	IN	W	WDU
3	08/04 15:45:05.600	Dip	CH1	IN	W	WDU

WDU Indicates that a voltage fluctuation event graph exists

INRUSH Indicates that an inrush current graph exists (Hioki 3197 only)

**To view the same event phenomenon in other windows:**  
 Activate the window and click the desired event item, or select it with the up- or down-arrow keys on the keyboard. In the Event List, the selected event is indicated by a gray background.

### TIME PLOT Window

**(Event Markers)**

- ▼ (Blue) Voltage fluctuation event (WDU) occurrence
- ▼ (Pink) Inrush current event (INRUSH) occurrence (Hioki 3197 only)
- ▼ (Red) An event occurrence other than the above types

**To view the same event phenomenon in other windows:**  
 Activate the window and click the desired event marker, or select it with the up- or down-arrow keys on the keyboard. The selected event marker becomes hollow (▽).

**Event List Window**

**TIME PLOT Window**

**Voltage Fluctuation Event Graph Window**

**Event Data Window**  
 Displays the waveform for the event selected in another window.

**ITIC Window (Hioki 3196 only)**

### ITIC Window (Hioki 3196 only)

**(Event Markers)**  
**Event Occurrences**

- ◆ (Red) Event occurrence on CH1
- ◆ (Yellow-Green) Event occurrence on CH2
- ◆ (Blue) Event occurrence on CH3

**To view the same event phenomenon in other windows:**  
 Activate the window and click the desired event marker. The selected event marker blinks.

### Voltage Fluctuation Event Window

**(Event Marker)**  
**Event Occurrence**

- ▼ (Blue) Voltage fluctuation event (WDU) occurrence
- ▼ (Pink) Inrush current event (INRUSH) occurrence (Hioki 3197 only)
- ▼ (Red) An event occurrence other than the above types

**Displays the graph for the event selected in another window.**  
 When an inrush current event marker is selected in another window, the inrush current screen appears (Hioki 3197 only).


## Viewing Measurement Data as Numerical Values (Cursor Measurement)

The values measured at the A and B cursor positions (cursor values) can be displayed numerically. Maximum, minimum and average values within a span of measurement data (between cursors) can also be checked by demarcating the span with the cursors.

Measurement values can be confirmed in the A/B cursor dialog. An image of the displayed numerical values can be copied to other applications.

Windows supporting cursor measurement: Waveform and Graph windows


Example: Viewing measurement values in a Time Plot window.

- 1 Click the  (A and B cursors) button, or select **A and B cursor** in the **Window** menu.

You can also right click and select from the pop-up menu.

The A/B cursors appear in the window, and a dialog box indicates values at the cursor positions. Displayed contents differ according to the type of data displayed.


- 2 Click the A or B cursor button in the dialog box to select the cursor to move.



The values at the cursor positions in the active window are displayed.

- 3 To view the values at a particular point, activate the relevant window, and either click that point or press the left/right arrow keys to move the cursor to it.

To find the maximum, minimum and average values within a span, move the A/B cursors to demarcate the span.



**Viewing Measurement Data as Numerical Values (Cursor Measurement)**

**4** Confirm the measurement values in the dialog.

Time and numerical values at A and B cursor locations

Differences between A and B data (B - A)

		MIN	MAX	AVE
A	09/01 15:55:00	6.469k	6.535k	6.508k
B	09/03 10:15:00	6.476k	6.619k	6.546k
	1 18:25:00	0.006k	0.084k	0.038k
	MAX values	6.665k	6.747k	6.697k
	AVE values	6.555k	6.638k	6.600k
	MIN values	6.339k	6.514k	6.484k

**Viewing Maximum, Minimum and Average Values**

**5** Click the **Calculation between A and B cursor** button.  
 Maximum, minimum and average values between A/B cursors are displayed.

Maximum

Average

Minimum

		MIN	MAX	AVE
A	09/01 15:55:00	6.469k	6.535k	6.508k
B	09/03 10:15:00	6.476k	6.619k	6.546k
	1 18:25:00	0.006k	0.084k	0.038k
	MAX values	6.665k	6.747k	6.697k
	AVE values	6.555k	6.638k	6.600k
	MIN values	6.339k	6.514k	6.484k

**Copying a Dialog Box Image to the Clipboard**

**6** Click the **Copy** button.

**7** Open a document in another application program such as Microsoft Word or Excel, and insert the image using an **Insert** or **Paste** operation.

For further details, see the Help file for your application program.

Document - WordPad

File Edit View Insert Format Help

Arial 10 Western B

		MIN	MAX	AVE
A	09/01 15:55:00	6.469k	6.535k	6.508k
B	09/03 10:15:00	6.476k	6.619k	6.546k
	1 18:25:00	0.006k	0.084k	0.038k
	MAX values	6.665k	6.747k	6.697k
	AVE values	6.555k	6.638k	6.600k
	MIN values	6.339k	6.514k	6.484k



## Viewing Measurement Settings

Instrument settings recorded on the Hioki 3196 or 3197 can be viewed in the Settings window. Of course, the settings cannot be changed here.


The Settings window can only be displayed when a SET file is loaded.

In addition, the EN50160 setting tab is not displayed unless EN50160 data is loaded (Hioki 3196 only).

Refer to the window content descriptions for details.


**See:** 3196 measurement data: "Viewing Setting Conditions for Measurement Data [SYSTEM]" (p. 82)

3197 measurement data: "Viewing Setting Conditions for Measurement Data [SYSTEM]" (p. 110)


- 1 Click the  (Settings Icon) button or select **View – SYSTEM** from the menu bar.  
The Settings window appears.

- 2 Select the tabs to view each setting.

**Example: Hioki 3196 Settings Window**



**Example: Hioki 3197 Settings Window**



# Printing Measurement Data

Each display screen can be printed out. In addition, all open Time Plot windows can be printed together on one page.

### 1 Activate a window to be printed, and display the area to print.

The qualification for printing is that whatever is displayed will be printed as it appears. Maximize windows for clearest printing of large quantities of data.

### 2 Click the (Print) button or select **File – Print** from the menu bar.

The Print Setup dialog box opens.

### 3 Select the items you need to print, and click the **Print** button.

#### To print a logo or comment in the Logo field (p. 25)

Select the logo or text to be printed.

- Unselected: The field will be blank.
- HIOKI Logo: Select an image file to print. If no file name is selected, the HIOKI logo is printed.
- Text: The field will contain your entered text.

#### To print the time and date or comment in the Time field (p. 25)

Select the content to be printed.

- Unselected: The field will be blank.
- Time: The printing time will be printed.
- Text: The field will contain your entered text.


Select to include maximum, minimum and average values and channel information in the printout.

Selects the printing destination.

Starts printing.

Shows a preview of the printout.

Cancels printing.



#### To print comments in the Comment field (p. 25)

Enter the contents to be printed (up to three lines). To load the contents of a text file, click the Load a comment file button.


### Printout Example

#### Sample of an Event Waveform Printout

Paper setting: A4

Printing orientation: Landscape


The window type is automatically printed here.



# Arranging Windows (Window Layout)

All currently open windows can be displayed by arranging the application's windows.

Click the  (Tile) button or select **Window – Tile** from the menu bar.



# Copying a Display Image to the Clipboard

Any image data can be copied to the clipboard and then pasted into an application such as Microsoft Word and Excel.

You can also copy and paste measurement values displayed in the A/B cursor dialog (p. 22).

## 1 Activate the window to be copied.


If copying the DMM or Harmonic List to Microsoft Word or Excel, select the range to copy.

DMM [No.1 09/03 10:18:53.183 Ext (Stop)]					
POWER	VOLTAGE		CURRENT		
Freq	59.959 Hz				
P1	8.601kW	U1	6.553kV	I1	1.5385 A
P2	7.836kW	U2	6.522kV	I2	1.3779 A
Psum	16.44kW	U4	0.008kV	I4	0.0000 A
S1	10.082kVA	THD-U1	1.43 %	THD-I1	7.22 %
S2	8.987kVA	THD-U2	0.96 %	THD-I2	4.60 %
Ssum	16.51kVA	THD-U4	----	THD-I4	----
Q1	5.260kvar	Upk+1	9.082kV	Ipk+1	2.325 A
Q2	-4.399kvar	Upk+2	9.192kV	Ipk+2	2.028 A
Qsum	0.86kvar	Upk+4	0.021kV	Ipk+4	0.018 A
PF1	0.8531	Upk-1	-9.078kV	Ipk-1	-2.327 A

## 2 Click the (Copy) button or select **Edit – Copy** from the menu bar.

## 3 Paste the copied image into your destination program.

An example of five windows pasted into Microsoft Word



## Generating Reports

Reports are generated from loaded measurement data, and can be printed out or saved as rich text format (.rtf) files.

Rich text format files can be loaded and edited in application programs such as Wordpad (supplied with Windows), or Microsoft Word.

Reports can be generated by three methods.

Report Generation Method	Details
<b>Generate report contents automatically (Auto)</b>	Report contents are generated without selecting output items. Items that can be output with auto report generation are limited.
<b>Generate report with specified contents (Custom Settings)*</b>	Report contents are generated by selecting output items. Note that for transient waveforms, the Transient Waveform selection is available only when Worst Case is selected.
<b>Generate report with specified detailed contents (Detailed Settings)*</b>	Report contents are generated from selected details of each output item and channel.

\* Report generation settings can be saved and reloaded as settings files.

See "Report Output Items" (p. 32) for the items available for output in reports.



### 1 Confirm the span of data to be used in generating the report.

When the report wizard starts, the measurement data span is determined automatically from the current display state and position of the cursors in the window.

Set the A/B cursor locations if you want the report to specify a particular waveform span.

**See:** "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

If the A/B cursors are not enabled, the report is automatically generated using all loaded measurement data.



### 2 Click the (Report Wizard) button or select **File – Report Wizard** from the menu bar.

The Report Wizard – Start Page dialog box opens.

The Report Wizard cannot be started unless a window is already open.

### 3 Make settings in the Start Page dialog box.

1. Select a report generation method.
2. Set the starting and ending times of the data span to be reported.  
(These are automatically set to match the loaded data when the Report Wizard starts, but you can change them here.)
3. If report output is to include a demand graph, set the demand time span here.
4. Make settings for printing as occasion demands.  
(Comments and other information can be printed in the Logo, Time and Comment fields, shown below.)
5. Click Next.

If Auto is selected: The Report Wizard – Last Page dialog box opens.

If Custom Settings is selected: The Report Wizard – Individual Setting Page dialog box opens.(p. 30)

If Detailed Settings is selected: The Report Wizard – Detailed Setting Page dialog box opens.(p. 31)

**1 Click**

**2 Select**

**3 Select**

**4 Select**

**5 Click**

**Logo Field Output Settings**

- Unselected: The field will be blank.
- HIOKI Logo: Select an image file for output. If no file name is selected, the HIOKI logo is output.
- Text: The field will contain your entered text.

The logo is output only when printing. Logo data cannot be output to a rich text format file.


**Starting Page No.**  
Specify the number for the first page of report output.

**Comment Field Output Settings**  
Enter the contents to be output (up to three lines).  
To load the contents of a text file, click the Load a comment file button.

#### Time Field Output Settings

- Unselected: The field will be blank.
- Time: Outputs the time of report generation.
- Text: The field will contain your entered text.

Logo Field                                  Time Field                                  Comment Field



Printout Example


**4** In the Last Page dialog, select whether to save or print the report.

**Prints a report.**

Opens the Print dialog for you to make printer settings and print.

**Saves a report to a rich text format file.**

Opens the Save RTF File dialog where you can specify the save destination and name.



**Preview**

Displays a preview of print-out contents before printing.

**Page Setup**


Displays the Print dialog. Printer and paper selections can be made here.

### Selecting Custom Settings

Make settings in the Individual Setting Page dialog box.

1. Select those items to be output in the report.  
Note that Transient Waveform can be selected only when Worst Case is selected.
2. Click Next.  
The Report Wizard – Last Page dialog box opens.

**Dialog Example for Hioki 3196**



Settings can be saved and reloaded later. For your convenience, you can save your report selections as a Report Wizard Settings file that you can simply reload whenever you want to create another report with the same settings. The Report Wizard Settings file contains all custom and detailed report output settings.



Selecting Detailed Settings

Make settings in the Detail Setting Page dialog box.

1. Select those items to be output in the report.
2. Click Next.  
The pages of displayed setting items depend on the loaded measurement data.

3196		3197	
Page	Setting Items	Page	Setting Items
1/4	Voltage Fluctuations, RMS Fluctuations	1/2	Voltage Fluctuations, RMS Fluctuations
2/4	Harmonic Fluctuations	2/2	Demand, Integrated Power
3/4	Interharmonic Fluctuations		
4/4	IEC Flicker, Demand, Integrated Power		

3. Click Next.  
The Report Wizard – Last Page dialog box opens.(p. 30)

Example: Voltage and RMS fluctuations in the Hioki 3196 dialog (page 1/4)

**1 Select**

Select graph plotting of thresholds and reference traces.

**Graph plotting methods are selectable:**

- Single  
All channels are plotted on one graph, and output on one page.
- Division  
One graph is divided into sections for each channel, and all channel sections are arranged and output on one page.
- Separate  
Each channel is plotted on a separate graph, and output as one graph per page.

Loads the settings (SET) file, after which threshold data can be entered as the reference line value.

Report output graph colors can be selected. The Color Setting dialog box opens. Graph colors set here are applied only to graphs output in reports.

Report Wizard Setting File Save... Load...

**2 Click**

Printout Example: (p. 34)

## Report Output Items

\*1. Report output items are fixed for Auto report generation, but are selectable for Custom Settings or Detailed Settings report generation.

\*2. Transient Waveform can be selected only when Worst Case is selected.


\*3. Output for each channel can be set independently.

●: Can be output, ×: Cannot be output

Report Output Item	3196 <sup>*1</sup>			3197 <sup>*1</sup>			Output Contents
	Auto	Custom	Detailed	Auto	Custom	Detailed	
RMS Voltage Fluctuation Graph	●	●	● <sup>*3</sup>	●	●	● <sup>*3</sup>	Outputs a graph of rms voltage fluctuation that can be displayed in a Time Plot window.
RMS Current Fluctuation Graph	×	●	● <sup>*3</sup>	×	●	● <sup>*3</sup>	Outputs a graph of rms current fluctuation that can be displayed in a Time Plot window.
Voltage Fluctuation, RMS Fluctuation, Energy Consumption Graph, Demand Graph	×	×	● <sup>*3</sup>	×	×	● <sup>*3</sup>	Outputs a graph of Energy Consumption and demand that can be displayed in a Time Plot window.
Harmonic Fluctuations, Inter-harmonic Fluctuations, Flicker Graph	×	×	● <sup>*3</sup>				Outputs a graph of Flicker that can be displayed in a Time Plot window.
Voltage Total Harmonic Distortion Level Graph	●	●	● <sup>*3</sup>	●	●	● <sup>*3</sup>	Outputs a graph of voltage total harmonic distortion levels that can be displayed in a Time Plot window.
Current Total Harmonic Distortion Level Graph	×	●	● <sup>*3</sup>				Outputs a graph of current total harmonic distortion levels that can be displayed in a Time Plot window.
EN50160 Overview	●	●	×				Outputs the contents displayed in the EN50160 Overview window.
EN50160 Signaling	●	●	×				Outputs the contents displayed in the EN50160 Signaling window.
EN50160 Harmonics	×	●	×				Outputs the contents displayed in the EN50160 Harmonics window.
EN50160 Measurement Result Classification	×	●	×				Outputs an EN50169 measurement result classification table.
Worst Case	●	●	×	●	●	×	Outputs the five worst-case values for each voltage swell, dip, interruption and transient event within the reporting span. The worst-case values are maximum voltage swell, maximum continuous voltage swell duration, minimum voltage dip, maximum continuous voltage dip duration, maximum continuous voltage interruption duration and maximum transient value.
Transient Waveform *2	×	●	×				Outputs the worst-case transient waveform.
Maximum/ Minimum List	●	●	×	●	●	×	Outputs a list of voltage fluctuations (each channel separately), rms fluctuations (voltage and current on each channel separately), frequency, and maximum and minimum values of active, reactive and apparent power within the reporting span.
Detailed List of All Events	●	●	×	●	●	×	Outputs a list of all events and event details. The order of the output list can be set to either chronological or priority sequence in the Event List window.
All Event Waveforms	●	●	×	●	●	×	Outputs all event waveforms.
Settings List	×	●	×	×	●	×	Outputs a list of settings for the currently loaded data. These are the settings displayed in the Settings window when you select View – SYSTEM from the menu bar.

Report Printout Example

Auto Settings



Worst Case  
 Measurement from a HICKI 3196 PQA  
 2003/007 C:\HICKI3196\Building  
 Wing: 3P3W3M, Frequency: 60Hz  
 Nominal Voltage: line to line 6.6kV

2003/08/05 12:00:00 - 2003/08/10 12:00:00


No. of Dips in the Period: 30  
 Minimum Value of Dip:

Worst	CH	Voltage Value	Event Period	Date Time
1	CH3	4.7080kV	00:00:00 108	2003/08/06 16:21:41.555
2	CH2	4.8443kV	00:00:00 058	2003/08/05 19:27:11.744
3	CH2	5.5014kV	00:00:00 125	2003/08/05 16:21:41.573
4	CH1	5.6869kV	00:00:00 068	2003/08/06 16:21:41.530
5	CH2	5.6892kV	00:00:00 133	2003/08/06 17:46:54.763

Longest Period of Dip:

Worst	CH	Voltage Value	Event Period	Date Time
1	CH2	5.6892kV	00:00:00 133	2003/08/06 17:46:54.763
2	CH2	5.5014kV	00:00:00 125	2003/08/05 16:21:41.573
3	CH3	5.7187kV	00:00:00 125	2003/08/06 17:46:54.763
4	CH3	4.7080kV	00:00:00 108	2003/08/05 16:21:41.555
5	CH1	5.7933kV	00:00:00 108	2003/08/06 17:46:54.755

No. of Swells in the Period: 0  
 No. of Interruptions in the Period: 0  
 No. of Transients in the Period: 0



List of Max/Min Values  
 Measurement from a HICKI 3196 PQA  
 2003/007 C:\HICKI3196\Building  
 Wing: 3P3W3M, Frequency: 60Hz  
 Nominal Voltage: line to line 6.6kV

2003/08/05 12:00:00 - 2003/08/10 12:00:00

VOLTAGE U rms U Reference 6.6000k[V]

CH	MIN[V]	MAX[V]
CH1	5.847k	6.824k
CH2	4.844k	6.774k
CH3	4.708k	6.807k

RMS U

CH	MIN[V]	MAX[V]
CH1	6.000k	6.815k
CH2	5.992k	6.766k
CH3	6.038k	6.759k
CH4	0.000k	0.000k

I

CH	MIN[A]	MAX[A]
CH1	0.000	0.000
CH2	0.000	0.000
CH3	0.000	0.085
CH4	0.000	0.000

Freq

CH	MIN[Hz]	MAX[Hz]
CH1	59.825	60.166

POWER P


CH	MIN[W]	MAX[W]
CH1	0.000	0.000M
CH2	0.000	0.000
CH3	0.000	0.000M
sum	0.00000M	0.00000M

S



CH	MIN[VA]	MAX[VA]
CH1	0.000	0.000
CH2	0.000	0.000
CH3	0.000	0.32k
sum	0.00000M	0.00000M

Q



CH	MIN[var]	MAX[var]
CH1	-0.00k	0.00k
CH2	-0.00k	0.00k
CH3	-0.31k	0.32k
sum	-0.00000M	0.00000M



### Custom Settings



### Detailed Settings



## Storing Measurement Data in a CSV File

Measurement data (in binary format) can be converted to CSV format.

Data converted to CSV format can be used in spreadsheet programs such as Excel.

**See:** "Making Use of CSV File Data (Practical Applications)" (p. 41)

The format of CSV format files is the same for both the Hioki 3196 and 3197 Power Quality Analyzers. Refer to the "Appendix" (p. A1) and the instruments' instruction manuals for file format details.

### Convertible Data


●: Convertible, -: Non-Convertible

Conversion Procedure	Window	Hioki 3196	Hioki 3197
Convert time-series data to CSV format (for the span demarcated by A/B cursors) (p. 35)	Time Plot	●	●
	Flicker Graph	●	—
	Voltage Fluctuation Event	●	●
	Inrush Current Graph	—	●
	Integrated Power	●	●
Convert waveform data to CSV format (p. 38)	Voltage/Current Waveform	●	●
	Voltage/Transient Waveform	●	—
	Voltage Event Waveform	●	●
	Current Event Waveform	●	●
Convert demand data to CSV format (p. 39)	Demand	●	●

## Convert Time-Series Data to CSV Format

- 1 Activate the window with the data to be converted.

### Demarcate the span for conversion


- 2 Click the  (A and B cursor) button, or select **A and B cursor** in the **Window** menu.

You can also right click and select from the pop-up menu.

The A/B cursors appear in the window, and a dialog box indicates values at the cursor positions.

Displayed contents differ according to the type of data displayed.

- 3 Click the A or B cursor button in the dialog box to select the cursor to move.



The values at the cursor positions in the currently selected (active) window are displayed.


## Storing Measurement Data in a CSV File

- 4 Click the point where you want to move the cursor, or press the right- or left-arrow key on the keyboard to move the cursor.

Using the same procedure, move the other cursor as needed.

Between A and B cursors

Cursor A: Light Blue  
Cursor B: Purple



### Select the items to be converted to CSV format

- 5 From the **File** menu, select **Save the active data as a CSV file**.

You can also right click and select from the pop-up menu.


The Select Data for CSV Conversion dialog box opens.  
Displayed contents differ according to the type of data displayed.

**6** Select the check boxes of the items to be converted to CSV format.


**Example**

Shows the number of currently selected measurement items (up to 256 items)


**Time Plot Window Example**




**Example**




**Integrated Power Window Example**



**IEC Flicker Window Example**



**Inrush Current Window Example**




The number of selected measurement items displayed at the upper right of the Select Data for CSV Conversion dialog cannot exceed 256. Microsoft Excel is unable to load more than 256 items in one CSV format data file.

**7** Click the **OK** button.

The Save As dialog box opens.

**8** Select the save destination and enter the name of the file to save.



## Converting Waveform Data to CSV Format

- 1 Open the window with the waveform to be converted.

See: "Loading Data" (p. 14)

- 2 **To convert an event waveform**

Make the Event Waveform window active, and select **Save the active data as a CSV file – Event waveform data** from the **File** menu.

- 2 **To convert transient waveform data (Hioki 3196 only)**


Make the Voltage/Transient Waveform window active, and select **Save the active data as a CSV file – Event transient waveform data** from the **File** menu.

You can also right click and select from the pop-up menu.  
The Select Data for CSV Conversion dialog box opens.

- 3 Select the check boxes of the items to be converted to CSV format.

**Example**


Shows the number of currently selected measurement items



- 4 Click the **OK** button.

The Save As dialog box opens.

- 5 Select the save destination and enter the name of the file to save.






## Converting Demand Data to CSV Format

- 1 Make the Demand window active, and select **Save the active data as a CSV file** from the **File** menu.

The Select Data for CSV Conversion dialog box opens.

- 2 Select the check boxes of the items to be converted to CSV format.


Shows the number of currently selected measurement items



- 3 Click the **OK** button.

The Save As dialog box opens.

- 4 Select the save destination and enter the name of the file to save.



### Before Converting Harmonic Voltage Measurement Data (EN50160 Mode) to CSV Format (Hioki 3196 only)

For EN50160 mode measurements with the Hioki 3196, harmonic voltage (as opposed to inter-harmonic voltage) content is recorded as a percentage (of Uref) relative to the nominal voltage. This harmonic voltage can be converted from percentage of the nominal voltage (% of Uref) to percentage of the fundamental waveform voltage (% of Ufnd) and saved in CSV format.

---

**1** Switch to EN50160 mode.

**See:** "Switching Modes" (p. 55)


---

**2** Select **Convert harmonic % to CSV** in the **Option** menu.

The Convert harmonic % to CSV dialog box opens.

---

**3** Select the check box, and click the **OK** button.



## Making Use of CSV File Data (Practical Applications)




This section describes the procedure to create a graph with Microsoft Excel using a converted CSV file. This example uses Microsoft Excel 2000.

### 1 Open the converted CSV file with Excel.

Either double click the converted CSV file, or click File – Open in Excel and select the CSV file. The file contents appear.


### 2 Convert measurement data to display as normal numerical values.

Click the upper left cell of the measurement data, then while holding the Shift key on the keyboard, click the lower right cell of the measurement data to select it. Set the format of the selected cells to Number display.



### Format – Cells

Select Cell in the Format menu. The Format Cells dialog box appears.





Select Number to display numerical values.

**Storing Measurement Data in a CSV File**


**3** Select the range you want to graph.

Click the upper left cell of the measurement data, then while holding the Shift key on the keyboard, click the lower right cell of the desired measurement data to select the range.




**4** Select **Chart** in the **Insert** menu.

The Chart Wizard starts.




**5** Select the **Line** for the Chart type, and click **Next**.

You can click **Press and Hold to View Sample** to see how the generated graph will look.



## 6 Click the **Next** button.


Refer to the Excel Help for the functions available in the window below.



## 7 Customize your graph as occasion demands, and click the **Finish** button.


Refer to the Excel Help for the functions available in the window below.

In this example, a title and labels for the X and Y axes are added.



## 8 Save your result as a file or copy to Microsoft Word or Excel.

Example edited with Microsoft Word.




# Downloading Measurement Data from the Power Quality Analyzer (LAN Download Function) (Hioki 3196 only)

You can download data from the Hioki 3196's internal memory and data files from its PC Card by connecting it to the computer via LAN.


Refer to Section 11.2, "Control and Monitoring Using the LAN Interface" in the Hioki 3196 Power Quality Analyzer Detailed Instruction Manual for the LAN settings.

## Before Connecting the Hioki 3196 to the LAN

**NOTE** Confirm that the 3196 SETTING or ANALYZING display is selected.  
Making connections and downloading are not possible when the 3196 display is WAITING (awaiting measurement) or RECORDING.

**1** Click the  (Download) button or select **File – Download** from the menu bar.

The Download dialog box opens.



IP Address



Interrupt connection process.

Refresh the data file list.

Error Message

Hioki 3196 internal memory and PC Card file list

Check whether data exists in the Hioki 3196 internal memory.

: No data  
: Data exists

Download the selected folder, and open it in the PQA-Hi-View Pro.

Download selected data.

1 object(s) selected

2.71MB


Indicates the number of currently selected objects

Indicates the total size of currently selected objects

**2** Enter the IP address of the Hioki 3196 to be connected.

A history is retained of the last ten connected IP addresses.

Click  to display this history.




## Downloading Measurement Data from the Power Quality Analyzer (LAN Download Function)

- 3** Click the  (Update) button.

Connection is established to the Hioki 3196, and the data file list is refreshed.

When refreshing is complete, the Hioki 3196 internal memory and PC Card data files are displayed in the data file list.

- 4** Select a data file to download from the data file list.



- 5** Click the **Download** button.

The Choose dialog box opens.

- 6** Select the save destination and, if everything is ready, start downloading.

After downloading, to open a data file with the PQA-HiView Pro, select a folder with "B" appended to the front.

## Saving and Loading Settings Files

### About Settings Files

The PQA-HiView Pro can save and reload the following settings as a single settings file. After saving a settings file, you can reload it to view data or create reports using the same settings as when the file was saved. The types of settings files that can be saved are different for the Hioki 3196 and 3197.

The procedure described here is for saving and loading compound files. Refer to the indicated reference pages for the procedures to save and load discrete (non-compound) files.


Settings File	File Extension	File Contents	3196	3197	Reference
Report Wizard Settings File	.RPF	(Report Wizard Window) Report output item settings can be saved.	●	●	(p. 28)
User-Defined Curve Settings File	.UCV	(Curve Editing Window) Upper and lower limit curves can be edited and saved.	●	–	(p. 78)
Measurement Result Classification Settings File	.ESP	(EN50160 Measurement Result Classification Editor Window) Different classification tables for EN50160 measurement results can be edited and saved.	●	–	(p. 88)
Compound File (This file type combines all three of the above file types, although the Hioki 3197 supports only the Report Wizard Settings File data.)	.QAP	All data defined for the User-Defined Curve file, Measurement Result Classification file and Report Wizard Settings file are stored together.	●	–	(p. 47)

### Specify the Save Destination for the Settings File Beforehand

The default save destination is the My Documents folder. By specifying another save destination before saving the settings file, all settings files will be saved to the new destination in the future.

- 1 Select **Option – Change of Setting Data Storage Folder** from the menu bar.

The Open dialog box opens.




- 2 Select the folder in which to save settings files, and click the **OK** button.




## Saving a Compound File

The data for each type of settings file is combined and stored in a single file.

- 1 Click the  (Save Integrated Files) button or select **File – Save Integrated Files** from the menu bar.


The Save dialog box opens.




- 2 Enter the file name to be saved in the dialog, and click **Save**.

The current settings are saved in the specified file.

## Loading a Compound File

- 1 Click the  (Open Integrated Files) button or select **File – Open Integrated Files** from the menu bar.

The Open dialog box opens.



- 2 Select the name of the file to open in the dialog, and click **Open**.

The settings loaded from the file are applied to each setting item.




# Analyzing Measurement Data from the Hioki 3196

## Chapter 4

### Hioki 3196 Measurement Data Window Layout

#### Window Display

The Measurement Data window appears when data is loaded.



Any window can be displayed using the menu or tool bar. A window can also be changed by right clicking within it and selecting another window to display from the pop-up menu.


**See:** "Menu Bar Operations" (p. 50), "Tool Bar Operations" (p. 53)  
"Changing Windows" (p. 17)

Two display modes are available for analyzing Hioki 3196 measurement data: normal mode and EN50160 display mode.

**See:** "Switching Modes" (p. 55)

### Menu Bar Operations

Clicking a menu item displays one of the pull-down menus shown below. Items not available for the current window are grayed out.



#### 1 File


Click **File** and select from the pull-down menu.

The same operations are available on the tool bar (p. 53).

	<b>Open</b>		Opens a file. (p. 14)
	<b>Recent folder</b>		Displays recently used folders.
	<b>Download</b>		Downloads data from internal memory of the 3196 or PC card via LAN. (p. 44)
	<b>Close</b>		Closes the currently active window.
	<b>Report Wizard</b>		Sets the conditions for creating a report. (p. 28)
	<b>Print</b>		Prints the currently active window. (p. 24)
	<b>Save the active data as a CSV file</b>		Saves the loaded data as a CSV format file. (p. 35)
	<b>Open Integrated Files</b>		Loads a settings file for the PQA-HiView Pro. (p. 47)
	<b>Save Integrated Files</b>		Saves a setting file for the 9624-50. (p. 47)
	<b>Currently-used Integrated Files</b>		Displays recently used compound files.
	<b>Exit</b>		Closes the PQA-HiView Pro program. (p. 12)

#### 2 Edit

Click **Edit** and select from the pull-down menu.




The same operations are available on the tool bar (p. 53).












<b>Copy</b>		Displays can be copied to the clipboard. (p. 27)
-------------	--	--

### 3 View

Click **View** and select the window or items to display from the pull-down menu.

The same operations are available on the tool bar (p. 53).




<b>Tool Bar</b>		Shows or hides the standard tool bar (top) and window tool bar (left).	
<b>EVENT LIST Window</b>		Opens the event list window. You can re-order the displayed list by selecting <b>Sort by Time (-)</b> , <b>Sort by Time (+)</b> or <b>Sort by Priority</b> .	(p. 62)
<b>EVENT DATA Window</b>		Opens the event details window. You can select the following window data types: <ul style="list-style-type: none"> <li>• Event Details Window</li> <li>• Voltage/Current Waveform Window</li> <li>• Voltage/Transient Waveform Window</li> <li>• Voltage Waveform Window</li> <li>• Current Waveform Window</li> <li>• Vector Window</li> <li>• DMM Window</li> <li>• Harmonic Bar Graph Window</li> <li>• Harmonic List Window</li> </ul>	(p. 63)
<b>ITIC Window</b>		Opens the ITIC Window. An EVT file containing voltage swell, dip or interruption data must be loaded in order to display this window.	(p. 76)
<b>Open new TIME PLOT Window</b>		Opens up to four new TIME PLOT windows. You can select the following window data types: <ul style="list-style-type: none"> <li>• RMS Window</li> <li>• Voltage Window</li> <li>• Harmonics Window</li> <li>• Interharmonics Window</li> </ul>	(p. 56)
<b>Delta V10 Flicker Window</b>		Opens the Delta V10 Flicker Window. (An FLC file of Delta V10 flicker data must be loaded in order to display this window)	(p. 80)
<b>IEC Flicker Window</b>		Opens the IEC Flicker Window. (An FLC file of IEC flicker data must be loaded in order to display this window)	(p. 81)
<b>Voltage Fluctuation Event Graph</b>		Opens the Voltage Fluctuation Event Window. (A WDU file of the voltage fluctuation event graph for the selected event must be loaded in order to display this window)	(p. 73)
<b>Integrated Power Window</b>		The Energy Consumption opening dialog is displayed, and after setting, the Integrated Power window appears.	(p. 74)
<b>Demand Window</b>		The Demand opening dialog is displayed, and after setting, the Demand Window appears.	(p. 75)
<b>EN50160</b>		Switches between normal and EN50160 display modes.	(p. 55)
<b>SYSTEM</b>		Displays the settings on the Hioki 3196.	(p. 82)



### 4 Window

Click **Window** and select from the pull-down menu. This menu includes the names of the currently displayed windows.


#### Normal display mode



The same operations are available on the tool bar (p. 53).

<b>Title</b>		Arranges display of all open windows. (p. 26)
<b>A and B cursor</b>		Select to demarcate a span or view values at cursor positions. (p. 21)

#### EN50160 display mode



### 5 EVENT LIST/ EVENT DATA/ TIME PLOT/ ITIC

The menu displayed depends on the selected window. Click **EVENT LIST**, **EVENT DATA**, **TIME PLOT** or **ITIC** to select a window from the corresponding pull-down menu. You can also right click and select a window to switch to from the pop-up menu.




<b>Sort by Time (-)</b>	
<b>Sort by Time (+)</b>	(p. 62)
<b>Sort by Priority</b>	



<b>Limit Value Curve</b>	(p. 76)
--------------------------	---------



<b>RMS</b>	(p. 58)
<b>VOLTAGE</b>	(p. 59)
<b>HARMONICS</b> (Harmonic Fluctuations)	(p. 60)
<b>INTERHARM</b> (Inter-Harmonic Fluctuations)	(p. 61)



<b>Event details</b>	(p. 64)
<b>VOLTAGE/CURRENT</b>	(p. 65)
<b>VOLTAGE/TRANSIENT</b>	(p. 66)
<b>VOLTAGE</b>	(p. 67)
<b>CURRENT</b>	(p. 68)
<b>VECTOR</b>	(p. 69)
<b>DMM</b>	(p. 70)
<b>HARMONICS BAR GRAPH</b>	(p. 71)
<b>HARMONICS LIST</b>	(p. 72)

## 6 Option

Click **Option** and select from the pull-down menu.

Option	<b>Change of Setting Data Storage Folder</b>	Select this to specify the save destination for settings files. (p. 46)
Change of Setting Data Storage Folder...		
Convert harmonic % to CSV...	<b>Convert harmonic % to CSV</b>	Select this to convert measured harmonic voltage values from percentage of the nominal voltage to percentage of the fundamental waveform voltage when saving data to CSV format. (EN50160 data only) (p. 40)


## 7 Help

Click **Help** and select from the pull-down menu.

Help	Displays version information for the Hioki 9624-50 PQA-HiView Pro program.
Version of 9624-50 PQA-HIVIEW PRO...	

## Tool Bar Operations


### Tool bar (standard)



1		<b>Open</b>	(p. 14)
2		<b>Download</b>	(p. 44)
3		<b>Report Wizard</b>	(p. 28)
4		<b>Print</b>	(p. 24)
5		<b>Copy</b>	(p. 27)
6		<b>Open Integrated file</b>	(p. 47)
7		<b>Save Integrated file</b>	(p. 47)
8		<b>Tile</b>	(p. 26)
9		<b>A and B cursors</b>	(p. 21)
10		<b>Switch to EN50160 Window</b>	(p. 55)

### Tool bar (window)

---



1		Show/hide EVENT LIST Window	(p. 62)
2		Show/hide EVENT DATA Window	(p. 63)
3		Show/hide ITIC Window	(p. 76)
4		Open new TIME PLOT Window	(p. 56)
5		Open Delta V10 Flicker Window	(p. 80)
6		Open IEC Flicker Window	(p. 81)
7		Open Voltage Fluctuation Event Graph	(p. 73)
8		Open Integrated Power Window	(p. 74)
9		Open Demand Window	(p. 75)
10		Open EN50160 Overview Window	(p. 83)
11		Open EN50160 Harmonic Window	(p. 85)
12		Open EN50160 Measurement Result Classification Window	(p. 87)
13		Open EN50160 Signaling Window	(p. 86)
14		View system settings	(p. 82)





# Switching Modes


Two switchable display modes are provided for Hioki 3196 measurement data: Normal display mode and EN50160 display mode.

Window layouts are similar to the screens on the Hioki 3196 Power Quality Analyzer, for easy analysis.

The Normal display mode is initially enabled when data is loaded.


Click  to toggle between Normal and EN50160 display modes.

The  tool appears pressed when the EN50160 display mode is enabled.


 **Normal Display Mode**

Windows:  
 TIME PLOT, Event List, Event Data, ITIC, Delta V10 Flicker, IEC Flicker, Event Voltage Fluctuation, Integrated Power Value, and Demand

**Event List window (p. 62)    Time Plot Window (p. 56)**




**ITIC window (p. 76)    Event data window (p. 63)**  
 You can switch the Event Data window to the Harmonic or DMM window. (Right click inside the window and select a window to switch to from the pop-up menu.)

 **EN50160 Display Mode**

Windows:  
 EN50160 data (Overview, Harmonic, Signaling, and Measurement result classification)

**Overview window (p. 83)    Harmonic window (p. 85)**



**Signaling window (p. 86)    Measurement Result Classification window (p. 87)**

**The EN50160 display mode is available only when an EN50160 file has been loaded.**

## Viewing a Time Series Graph

[TIME PLOT]

Data measured with the Hioki 3196 Power Quality Analyzer can be displayed as a time series graph (Time Plot window). The program's Time Plot windows correspond to each Time Plot screen on the Hioki 3196.

If the Hioki 3196 has a high-capacity PC Card installed when measuring, long-term recording data may be difficult to display on the instrument's screen (when "Memory full: LOOP" is selected on the SYSTEM – RECORDING screen).

This kind of long-term time plot data can be analyzed with the PQA-HiView Pro.

The following types of Time Plot windows can be displayed up to four windows at a time.


- RMS Window (p. 58)
- VOLTAGE Window (p. 59)
- HARMONICS Window (p. 60)
- INTERHARM (Interharmonics) Window (p. 61)

### Opening and Switching Time Plot Windows

- 1 Load the measurement data.


See: "Loading Data" (p. 14)

To display a Time Plot window, the loaded data must include an ITV file.

- 2 Click the  (Open Time Plot Window) button or select **View – Open new TIME PLOT window** from the menu bar.

A Time Plot Window opens.

You can open up to four windows by clicking the button or selecting from the menu bar repeatedly.



Click an event marker to view an event phenomenon in the other windows.

See: "Viewing Event Phenomena" (p. 19)

Scrolls the window

Move a scroll box or click within the scroll bar.

When scrolling horizontally, all open Time Plot windows scroll together.

### Switching Windows

- 3 Activate the Time Plot window to be switched, and select the desired window to display from the **TIME PLOT** menu.

You can also right click and select from the pop-up menu.

The windows available for selection depend on the data type that was selected on the SYSTEM – MAIN – RECORDING screen of the Hioki 3196.

### Viewing Measurement Data as Numerical Values (Cursor Measurement)

- 4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

**See:** "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)


---

### Viewing RMS Fluctuations

### [TIME PLOT – RMS]


- 1 Open a Time Plot window.  
 See: "Opening and Switching Time Plot Windows" (p. 56)

- 2 Activate the Time Plot window and select **RMS** from the **TIME PLOT** menu.  
 You can also right click and select from the pop-up menu.  
 The RMS window opens.



### Changing Displayed Contents

- 3 When the RMS window is active, it's own tool bar is displayed.  
 Select the items you want to change from the pull-down menus in the RMS window's tool bar.




## Viewing Voltage Fluctuations

## [TIME PLOT – VOLTAGE]

- 1 Open a Time Plot window.  
See: "Opening and Switching Time Plot Windows" (p. 56)

- 2 Activate the Time Plot window and select **VOLTAGE** from the **TIME PLOT** menu.  
You can also right click and select from the pop-up menu.  
The Voltage window opens.

U1 (Red)  
U2 (Yellow-Green)  
U3 (Blue)




Scrolls the window

Voltage fluctuation data consists of pairs of maximum and minimum values for every measurement interval. Therefore, expanding the horizontal scale reveals the data as a series of vertical lines between each pair of maximum and minimum values at each measurement interval. There is no horizontal line through the space between measurement intervals.

### Changing Displayed Contents

- 3 When the Voltage window is active, it's own tool bar is displayed.  
Select the items you want to change from the pull-down menus in the Voltage window's tool bar.




Viewing Harmonic Fluctuations [TIME PLOT – HARMONICS]

1 Open a Time Plot window.  
 See: "Opening and Switching Time Plot Windows" (p. 56)

2 Activate the Time Plot window and select **HARMONICS** from the **TIME PLOT** menu.  
 You can also right click and select from the pop-up menu.  
 The HARMONICS window opens.

Colors and displayed harmonic orders can be set from the tool bar.




Scrolls the window

Harmonic data that was recorded with the MAX/MIN/AVE recording data type setting consists of maximum, minimum and average values for every measurement interval. Therefore, expanding the horizontal scale reveals the data as a series of vertical lines between each pair of maximum and minimum values at each measurement interval. There is no horizontal line through the space between measurement intervals.

Settings that existed at the time of recording can be confirmed from the Settings window. (p. 82)  
 Data from 400 Hz measurements can be analyzed up to the 10<sup>th</sup> harmonic order.

Changing Displayed Contents

3 When the Harmonics window is active, it's own tool bar is displayed.  
 Select the items you want to change from the pull-down menus in the Harmonics window's tool bar.



Displayed Harmonic Orders  
 Up to six harmonic orders (from 1 to 50) can be selected for display together.  
 The vertical axis has a fixed logarithmic scale.


## Viewing Inter-Harmonic Fluctuations

## [TIME PLOT – INTERHARM]

- 1 Open a Time Plot window.  
See: "Opening and Switching Time Plot Windows" (p. 56)

- 2 Activate the Time Plot window and select **INTERHARM** from the **TIME PLOT** menu.  
You can also right click and select from the pop-up menu.  
The INTERHARM window opens.

Colors and displayed harmonic orders can be set from the tool bar.




Scrolls the window

Inter-harmonic data that was recorded with the MAX/MIN/AVE recording data type setting consists of maximum, minimum and average values for every measurement interval. Therefore, expanding the horizontal scale reveals the data as a series of vertical lines between each pair of maximum and minimum values at each measurement interval. There is no horizontal line through the space between measurement intervals.

Settings that existed at the time of recording can be confirmed from the Settings window. (p. 82)

### Changing Displayed Contents

- 3 When the Interharm window is active, it's own tool bar is displayed.  
Select the items you want to change from the pull-down menus in the Interharm window's tool bar.



Displayed Inter-Harmonic Orders

Up to six inter-harmonic orders (from 0.1 to 49.5) can be selected for display together.

The vertical axis has a fixed logarithmic scale.

## Viewing Events as a List

**[EVENT LIST]**

Event occurrences within data measured with the Hioki 3196 can be displayed as a list (the Event List window).

The Event List window is equivalent to the EVENT – LIST screen on the Hioki 3196.

You can re-order the displayed list by selecting **Sort by Time (-)**, **Sort by Time (+)** or **Sort by Priority**.


### 1 Load the measurement data.

**See:** "Loading Data" (p. 14)

To display the Event List window, the loaded data must include an EVT file.

### 2 Click the (Show/hide EVENT LIST window) button or select **View – EVENT LIST Window** from the menu bar.

The Event List window opens.



Click an event, or select using the up/down arrow keys on the keyboard to view the event phenomenon in other windows.

**See:** "Viewing Event Phenomena" (p. 19)

Indicates whether a graph of the event exists.

WDU: Indicates that an voltage fluctuation event graph exists. (p. 73)

## Re-Ordering the Display of Events

### 3 Make the Event List window active, and select **Sort by Time (-)**, **Sort by Time (+)** or **Sort by Priority** from the **EVENT LIST** menu.

You can also right click and select from the pop-up menu.

The list is re-ordered according to your selection.



## Viewing Event Measurement Data

[EVENT DATA]

Data measured with the Hioki 3196 upon the occurrence of an event can be displayed as a graph (Event Data window).

The Event Data window is equivalent to the VIEW screen displayed when you select an event in the Event List on the Hioki 3196 and press the ENTER key.

The Event Data window can be switched between the following nine types.


- Event details Window (p. 64)
- VOLTAGE/CURRENT Window (p. 65)
- VOLTAGE/TRANSIENT Window (p. 66)
- VOLTAGE Window (p. 67)
- CURRENT Window (p. 68)
- VECTOR Window (p. 69)
- DMM Window (p. 70)
- HARMONICS BAR GRAPH Window (p. 71)
- HARMONICS LIST Window (p. 72)

In this manual, the above windows are collectively called “Event Data windows”.


### Opening and Switching Event Data Windows

- 1 Load the measurement data.

See: "Loading Data" (p. 14)

- 2 Click the  (Show/hide EVENT DATA window) button or select **View – EVENT DATA Window** from the menu bar.

The Event data window opens.



Event data window

Click an event marker or an event in the Event List to display a graph of the event.

See: "Viewing Event Phenomena" (p. 19)

### Switching Windows

- 3 Activate the Event Data window and select the desired window from the **EVENT DATA** menu.

You can also right click and select from the pop-up menu.

## Viewing Event Details


[Event details]

- 1 Open the Event Data window.  
See: "Opening and Switching Event Data Windows" (p. 63)

- 2 Activate the Event Data window and select **Event details** from the **EVENT DATA** menu.  
You can also right click and select from the pop-up menu.

The Event details window opens.

When you select an event in the Event List window, multiple event contents associated with that event occurrence are displayed.



Date	Time	Event Category	
2002/03/12	11:34:30.744	Dip CH1 OUT	0.20 V 00:00:26.051
2002/03/12	11:34:30.744	U rms CH1 OUT	00:00:26.201
2002/03/12	11:34:30.744	U-THD CH1 OUT	00:00:26.201
2002/03/12	11:34:30.744	Wave CH1	
2002/03/12	11:34:30.760	Wave CH1	
2002/03/12	11:34:30.777	Wave CH1	
2002/03/12	11:34:30.794	Wave CH1	
2002/03/12	11:34:30.810	Wave CH1	
2002/03/12	11:34:30.827	Wave CH1	
2002/03/12	11:34:30.844	Wave CH1	
2002/03/12	11:34:30.860	Wave CH1	
2002/03/12	11:34:30.877	Wave CH1	
2002/03/12	11:34:30.894	Wave CH1	
2002/03/12	11:34:30.911	Wave CH1	
2002/03/12	11:34:30.927	Wave CH1	


## Viewing Voltage/Current Waveforms

## [VOLTAGE/CURRENT]

- 1 Open the Event Data window.  
See: "Opening and Switching Event Data Windows" (p. 63)


- 2 Activate the Event Data window and select the **VOLTAGE/CURRENT** window from the **EVENT DATA** menu.

You can also right click and select from the pop-up menu.  
The Voltage/Current Waveform window opens.



## Changing Displayed Contents

- 3 Select the items you want to change from the pull-down menus in the Event Data window's tool bar.



## Viewing Measurement Data as Numerical Values (Cursor Measurement)

- 4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.


See: "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

Time and numerical values at A and B cursor locations

	U1	U2	U3	U4	I1	I2	I3	I4	
A	08/08 08:31:53.951	0.2613k	-0.2387k	-0.0216k	0.0003k	0.85	-22.12	21.42	0.10
B	08/08 08:31:53.988	0.2027k	0.0773k	-0.2797k	0.0003k	64.13	-66.16	2.18	0.07
	00:00:00.037	-0.0586k	0.3161k	-0.2581k	0.0000k	63.27	-44.05	-19.24	-0.03
	MAX values								
	AVE values								
	MIN values								

Differences between A and B data (B - A)

The time difference between cursors is calculated using internal data resolution of less than 0.001 seconds, but the last digit (0.001 s) may not be exact.



Viewing Voltage/Transient Waveforms

[VOLTAGE/TRANSIENT]

1 Open the Event Data window.

See: "Opening and Switching Event Data Windows" (p. 63)

The Voltage/Transient window can only be displayed when a TRN file is loaded.

2 Activate the Event Data window and select the **VOLTAGE/TRANSIENT** window from the **EVENT DATA** menu.

You can also right click and select from the pop-up menu.

The Voltage/Transient Waveform window opens.

Window tool bar

CH1 (Red)  
CH2 (Yellow-Green)  
CH3 (Blue)  
CH4 (Light Blue)

Transient waveform analysis is performed for 4096  $\mu$ s.

Click to display the waveform to the left or right of the transient.

Voltage waveform

Transient waveform (Magnified)

Scrolls the window

Changing Displayed Contents

3 Select the items you want to change from the pull-down menus in the Voltage/Transient Waveform window's tool bar.

Y-axis scale of voltage waveform

X-axis scale of waveform

X-axis scale of transient waveform

Y-axis scale of transient waveform

Viewing Measurement Data as Numerical Values (Cursor Measurement)

4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

See: "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)


Time and numerical values at A and B cursor locations

	U1	U4	
A	1950.0 $\mu$ s	0.1477k	0.0000k
B	2350.0 $\mu$ s	-0.2004k	0.0000k
	400.0 $\mu$ s	-0.3480k	0.0000k
MAX values			
AVE values			
MIN values			

Differences between A and B data (B - A)

Time data is 0  $\mu$ s at the left end of the transient data, and 4096  $\mu$ s at the right end.

Between A and B cursors



Cursor A (Light Blue)

Cursor B (Purple)

## Viewing Voltage Waveforms

[VOLTAGE]

- 1 Open the Event Data window.

**See:** "Opening and Switching Event Data Windows" (p. 63)

- 2 Activate the Event Data window and select the **VOLTAGE** window from the **EVENT DATA** menu.

You can also right click and select from the pop-up menu.

The Voltage window opens.

Window tool bar


CH1 (Red)

CH2 (Yellow-Green)

CH3 (Blue)

CH4 (Light Blue)

Up to 14 cycles (50 Hz),  
16 cycles (60 Hz) or 112  
cycles (400 Hz) can be  
analyzed.



Scrolls the window

### Changing Displayed Contents

- 3 Select the items you want to change from the pull-down menus in the Voltage window's tool bar.



Y-axis scale of voltage waveform

X-axis scale of waveform

### Viewing Measurement Data as Numerical Values (Cursor Measurement)

- 4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

**See:** "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

## Viewing Current Waveforms

[CURRENT]

**1** Open the Event Data window.

**See:** "Opening and Switching Event Data Windows" (p. 63)

**2** Activate the Event Data window and select the **CURRENT** window from the **EVENT DATA** menu.


You can also right click and select from the pop-up menu.

The Current window opens.

Window tool bar

CH1 (Red)  
CH2 (Yellow-Green)  
CH3 (Blue)  
CH4 (Light Blue)

Up to 14 cycles (50 Hz),  
16 cycles (60 Hz) or 112 cy-  
cles (400 Hz) can be ana-  
lyzed.



Scrolls the window

**Changing Displayed Contents****3** Select the items you want to change from the pull-down menus in the Current window's tool bar.

Y-axis scale of current waveform

X-axis scale of waveform

**Viewing Measurement Data as Numerical Values (Cursor Measurement)****4** Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

**See:** "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

## Viewing the Vector Display

[VECTOR]

**1** Open the Event Data window.



See: "Opening and Switching Event Data Windows" (p. 63)

**2** Activate the Event Data window and select the **VECTOR** window from the **EVENT DATA** menu.

You can also right click and select from the pop-up menu.

The Vector window opens.

In addition to the voltage and current data displayed on the screen of the Hioki 3196, calculated values of positive-, negative- and zero-phase voltage and current are displayed (for 3P4W wiring measurements only).

**Changing Displayed Contents****3** Select the items you want to change from the pull-down menus in the Vector window's tool bar.

Viewing the DMM Display

[DMM]

1 Open the Event Data window.

See: "Opening and Switching Event Data Windows" (p. 63)

2 Activate the Event Data window and select the **DMM** window from the **EVENT DATA** menu. You can also right click and select from the pop-up menu. The DMM window opens.

POWER	VOLTAGE		CURRENT	
Freq	60.001 Hz			
P1	3.558kW	U1	202.98 V	I1 41.365 A
P2	3.715kW	U2	205.94 V	I2 43.244 A
P3	3.548kW	U3	202.42 V	I3 42.001 A
Psum	10.818kW	U4	0.00 V	I4 0.000 A
S1	4.815kVA	THD-U1	0.72 %	THD-I1 2.83 %
S2	5.124kVA	THD-U2	0.88 %	THD-I2 2.06 %
S3	4.958kVA	THD-U3	0.85 %	THD-I3 2.41 %
Ssum	14.898kVA	THD-U4	----	THD-I4 488.93 %
Q1	3.244kvar	Upk+1	290.51 V	Ipk+1 74.28 A
Q2	3.530kvar	Upk+2	295.79 V	Ipk+2 80.56 A
Q3	3.467kvar	Upk+3	288.19 V	Ipk+3 70.27 A
Qsum	10.241kvar	Upk+4	0.95 V	Ipk+4 0.17 A
PF1	0.7389	Upk-1	-289.78 V	Ipk-1 -71.19 A
PF2	0.7249	Upk-2	-295.43 V	Ipk-2 -73.94 A
PF3	0.7150	Upk-3	-288.79 V	Ipk-3 -80.48 A
PFsum	0.7262	Upk-4	-0.11 V	Ipk-4 -0.04 A
	Uave	203.78 V	KF1	1.01
	Uunb	1.13 %	KF2	1.00
			KF3	1.01
			KF4	-----
	lave			42.203 A
	lunb			5.01 %

Copying Selected Data to Another Application

3 Select the range to be copied with your mouse, then select **Edit – Copy** from the menu bar. As text data with tab separators, you can paste it directly into Microsoft Excel.

POWER	VOLTAGE		CURRENT	
Freq	59.998 Hz			
P1	2.517kW	U1	202.63 V	I1 25.729 A
P2	2.658kW	U2	205.22 V	I2 27.632 A
P3	2.403kW	U3	201.63 V	I3 25.582 A
Psum	7.584kW	U4	0.00 V	I4 0.000 A
S1	2.587kVA	THD-U1	0.89 %	THD-I1 0.65 %
S2	3.257kVA	THD-U2	1.12 %	THD-I2 1.21 %
S3	3.088kVA	THD-U3	1.03 %	THD-I3 1.39 %
Ssum	8.261kVA	THD-U4	----	THD-I4 -----
Q1	1.898kvar	Upk+1	285.37 V	Ipk+1 36.83 A
Q2	1.900kvar	Upk+2	288.64 V	Ipk+2 39.47 A
Q3	1.801kvar	Upk+3	283.76 V	Ipk+3 36.40 A
Qsum	5.398kvar	Upk+4	0.92 V	Ipk+4 0.20 A
PF1	0.8428	Upk-1	-284.24 V	Ipk-1 -36.58 A
PF2	0.8136	Upk-2	-287.76 V	Ipk-2 -39.18 A
PF3	0.8009	Upk-3	-283.25 V	Ipk-3 -36.04 A
PFsum	0.8189	Upk-4	-0.11 V	Ipk-4 -0.04 A
	Uave	203.16 V	KF1	1.00
	Uunb	1.10 %	KF2	1.01
			KF3	1.01
			KF4	-----
	lave			5.01 %
	lunb			5.01 %

Specified Range



POWER								
A	B	C	D	E	F	G	H	I
1	POWER		VOLTAGE		CURRENT			
2	Freq	6.00E+01 Hz						
3	P1	2.52E+03 W	U1	2.03E+02 V	I1	2.57E+01 A		
4	P2	2.66E+03 W	U2	2.05E+02 V	I2	2.76E+01 A		
5	P3	2.41E+03 W	U3	2.02E+02 V	I3	2.56E+01 A		
6	Psum	7.58E+03 W	U4	0.00E+00 V	I4	0.00E+00 A		
7	S1	2.99E+03 VA	THD-U1	8.90E-01 %	THD-I1	8.60E-01 %		
8	S2	3.27E+03 VA	THD-U2	1.12E+00 %	THD-I2	1.21E+00 %		
9	S3	3.01E+03 VA	THD-U3	1.03E+00 %	THD-I3	1.38E+00 %		
10	Ssum	9.26E+03 VA	THD-U4	-----	THD-I4	-----		
11	Q1	1.61E+03 var	Upk+1	2.85E+02 V	Ipk+1	3.68E+01 A		
12	Q2	1.90E+03 var	Upk+2	2.89E+02 V	Ipk+2	3.95E+01 A		
13	Q3	1.80E+03 var	Upk+3	2.84E+02 V	Ipk+3	3.64E+01 A		
14	Qsum	5.31E+03 var	Upk+4	9.20E-01 V	Ipk+4	2.00E-01 A		
15	PF1	8.43E-01	Upk-1	-2.84E+02 V	Ipk-1	-3.66E+01 A		
16	PF2	8.14E-01	Upk-2	-2.88E+02 V	Ipk-2	-3.92E+01 A		
17	PF3	8.01E-01	Upk-3	-2.83E+02 V	Ipk-3	-3.60E+01 A		
18	PFsum	8.19E-01	Upk-4	-1.10E-01 V	Ipk-4	-4.00E-02 A		
19		Uave	2.03E+02 V		KF1	1.00E+00		
20		Uunb	1.10E+00 %		KF2	1.01E+00		
21					KF3	1.01E+00		
22					KF4	-----		
23		lave				2.63E+01 A		
24		lunb				5.01E+00 %		

Copied to Excel




Viewing Harmonics on a Bar Graph

[HARMONICS BAR GRAPH]


- 1 Open the Event Data window.  
See: "Opening and Switching Event Data Windows" (p. 63)

- 2 Activate the Event Data window and select the **HARMONICS BAR GRAPH** window from the **EVENT DATA** menu.  
You can also right click and select from the pop-up menu.  
The Harmonics Bar Graph window opens.



Changing Displayed Contents

- 3 Select the items you want to change from the pull-down menus in the Harmonics Bar Graph window's tool bar.



Viewing Harmonics in a List [HARMONICS LIST]

1 Open the Event Data window.  
 See: "Opening and Switching Event Data Windows" (p. 63)

2 Activate the Event Data window and select the **HARMONICS LIST** window from the **EVENT DATA** menu.

You can also right click and select from the pop-up menu.  
 The Harmonics List window opens.


Window tool bar

Order	(V)	Order	(V)	Order	(V)
1	105.02	18	0.01	35	0.09
2	0.06	19	0.11	36	0.01
3	1.19	20	0.03	37	0.06
4	0.06	21	0.07	38	0.00
5	1.59	22	0.03	39	0.02
6	0.02	23	0.06	40	0.01
7	0.60	24	0.01	41	0.04
8	0.03	25	0.07	42	0.01
9	0.27	26	0.02	43	0.04
10	0.04	27	0.07	44	0.01
11	0.07	28	0.01	45	0.01
12	0.01	29	0.05	46	0.00
13	0.28	30	0.02	47	0.02
14	0.01	31	0.09	48	0.00
15	0.15	32	0.02	49	0.01

Data from 400 Hz measurements can be analyzed up to the 10<sup>th</sup> harmonic order.

Changing Displayed Contents

3 Select the items you want to change from the pull-down menus in the Harmonics List window's tool bar.



Copying Selected Data to Another Application

4 Select the range to be copied with your mouse, then select **Edit – Copy** from the menu bar. As text data with tab separators, you can paste it directly into Microsoft Excel.

Order	(V)	Order	(V)	Order	(V)
1	97.73	18	0.01	35	0.08
2	0.11	19	0.09	36	0.00
3	0.52	20	0.01	37	0.06
4	0.06	21	0.14	38	0.01
5	1.29	22	0.01	39	0.04
6	0.01	23	0.06	40	0.01
7	0.73	24	0.01	41	0.03
8	0.07	25	0.02	42	0.01
9	0.27	26	0.01	43	0.01
10	0.03	27	0.04	44	0.04
11	0.25	28	0.01	45	0.03
12	0.02	29	0.04	46	0.03
13	0.08	30	0.01	47	0.02
14	0.01	31	0.10	48	0.01
15	0.06	32	0.01	49	0.02
16	0.01	33	0.13	50	0.01
17	0.12	34	0.01	THD	1.69 (%)

Specified Range



Order	(V)	Order	(V)	Order	(V)
1	97.73	18	0.01	35	0.08
2	0.11	19	0.09	36	0
3	0.52	20	0.01	37	0.06
4	0.06	21	0.14	38	0.01
5	1.29	22	0.01	39	0.04
6	0.01	23	0.06	40	0.01
7	0.73	24	0.01	41	0.03
8	0.07	25	0.02	42	0.01
9	0.27	26	0.01	43	0.01
10	0.03	27	0.04	44	0.04
11	0.25	28	0.01	45	0.03
12	0.02	29	0.04	46	0.03
13	0.08	30	0.01	47	0.02
14	0.01	31	0.1	48	0.01
15	0.06	32	0.01	49	0.02
16	0.01	33	0.13	50	0.01
17	0.12	34	0.01	THD	1.69 (%)

Copied to Excel


## Viewing Voltage Fluctuation Details

### [Voltage Fluctuation Event Graph]


Voltage fluctuation phenomena (swells, dips and interruptions) that occurred within data measured by the Hioki 3196 can be displayed graphically (in the Voltage Fluctuation Event Graph window). This window is equivalent to the VOLTAGE – EVENT (TIME PLOT) screen on the Hioki 3196. A Voltage Fluctuation Event Graph can be displayed only when an Event file (WDU file) is loaded. Event files can be confirmed in the Event List (p. 62). A Voltage Fluctuation Event Graph is a 10-second time series graph of rms voltage calculated over one half-cycle-shifted waveform.

- 1 Load the measurement data.

See: "Loading Data" (p. 14)


- 2 Click the  (Open Voltage Fluctuation Event Graph) button or select **View – Voltage Fluctuation Event Graph** from the menu bar.

The Voltage Fluctuation Event Graph window opens.



### Changing Displayed Contents

- 3 Select the items you want to change from the pull-down menus in the Voltage Fluctuation Event Graph window's tool bar.



### Viewing Measurement Data as Numerical Values (Cursor Measurement)


- 4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.  
See: "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)


### Viewing Other Event Phenomena

- 5 Click any WDU event marker in the Event List or Time Plot window.  
A Voltage Fluctuation Event Graph window appears for the selected event.  
If there is no WDU file for the selected event, "Specified WDU file not present" appears.

## Viewing Energy Consumption [Integrated Power Window]


Energy consumption measured with the Hioki 3196 Power Quality Analyzer can be displayed as a time series graph (Integrated Power window).

- 1 Load the measurement data.  
See: "Loading Data" (p. 14)
- 2 Click the  (Open Integrated Power window) button or select **View – Integrated Power Window** from the menu bar.  
The Start Integration dialog box opens.
- 3 Set the starting time and span for analysis, and click the **OK** button.



Calculation of energy consumption as an integrated power value begins. When calculation finishes, the Integrated Power window opens.

If the specified starting time is not within the measurement span, energy consumption calculation does not start.



### Changing Displayed Contents

- 4 Select the items you want to change from the pull-down menus in the Integrated Power window's tool bar.



### Viewing Measurement Data as Numerical Values (Cursor Measurement)

- 5 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.  
See: "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

When the A/B Cursor dialog is open, A/B cursor movement has priority over the usual screen cursor.


## Viewing a Demand Graph

[Demand Window]

Data measured with the Hioki 3196 Power Quality Analyzer can be displayed as a demand graph (Demand window).


- 1 Load the measurement data.

See: "Loading Data" (p. 14)

- 2 Click the  (Open Demand window) button or select **View – Demand Window** from the menu bar.

The Start Demand Calculation dialog box opens.

- 3 Set the starting time, demand period and analysis time span, and click the **OK** button.




Demand calculation starts. When calculation finishes, the Demand window opens.

If the specified starting time is not within the measurement span, demand calculation does not start.

Window tool bar

Indicates maximum and average demand values, load factor, and the demand value at the cursor position



Average demand value

Scrolls the window

### Changing Displayed Contents

- 4 Select the items you want to change from the pull-down menus in the Demand window's tool bar.



X-axis scale

# Testing Measurement Data Conformance

[ITIC]

Voltage swell, dip and interruption data are displayed on a graph and judged against upper and lower limit curves (tolerance curves).

The graph plots percentage of nominal voltage (vertical axis) against time (in seconds, horizontal axis).

Event	Time [s]	Percent Nominal Voltage [%]
Voltage Swell	Continuous Swell Duration	Maximum Swell Voltage
Voltage Dip	Dip Duration	Residual Voltage (Dip Voltage Minimum)
Interruption	Continuous Interruption Duration	Residual Voltage (Interruption Voltage Minimum)

Two types of tolerance curves are available: the ITIC Curve used mainly in the USA, and a user-defined curve which can be set as needed.


See: "About CBEMA and ITIC Curves" (p. 77)

## 1 Load the measurement data.

See: "Loading Data" (p. 14)

To display a tolerance curve, a EVT file containing voltage swell, dip or interruption data must be loaded.

## 2 Click the (Open ITIC window) button or select **View – ITIC Window** from the menu bar. The ITIC window opens.



Total number of events above the upper curve threshold (up to 2000% on the vertical axis)

Total number of events below the lower curve threshold

Total number of events on all current selected channels

Window tool bar

Vertical axis: Percent Nominal Voltage [%]

Event Markers

- CH1 ◆ (Red)
- CH2 ◆ (Yellow-Green)
- CH3 ◆ (Blue)

Total number of events with duration exceeding 1000 s (not displayed if no event exceeds 1000 s)

Upper-limit curve

Lower-limit curve

Horizontal Axis: Elapsed Time [s]

Click an event marker to view an event phenomenon in the other windows.

Scrolls the window


ITIC window statistics: Total Events: 15, Upper Violations: 0, Lower Violations: 0, Longer Events: 2

See: "Viewing Event Phenomena" (p. 19)

The event marker for the selected event blinks. When "all CH" is selected for the channel on this window's tool bar, multiple event markers blink if an event occurred on multiple channels at the same time.

## Changing Displayed Contents

- Select the items you want to change from the pull-down menus in the ITIC window's tool bar.



### NOTE

#### About CBEMA and ITIC Curves

Mainly used in the USA, both curves are tolerance ranges for judging rms voltage fluctuations according to voltage swell, dip and interruption events.

The CBEMA Curve was created by the Computer Business Equipment Manufacturers Association. Later, CBEMA established a Working Group called the ITIC (Information Technology Industry Council), which created the ITIC Curve. Use of the CBEMA Curve in applications is now being replaced with the ITIC Curve.

## Setting Tolerances (Making a User-Defined Curve)


Tolerance limits can be set freely.

To make user settings, select **User** (User-Defined Curve) as the Curve item on the tool bar in the ITIC window. A user-defined curve is a convenient way to provide a SEMI Curve (p. 79) for tolerance judgments.

- Select the **User** Curve setting on the ITIC window tool bar.

- Select **ITIC – Tolerance Curve** from the menu bar.

You can also right click and select from the pop-up menu.  
The Curve Editor appears.



### 3 Enter numerical values in the upper and lower limit fields.

Up to 20 decimal values can be entered in the x(s) and y(%) fields to define upper and lower curve limits. Milli-second values can be entered for x(s) by appending an "m" unit designator. Enter values on consecutive lines to reach the edge of the graph.

**See:** "Curve Tables (Reference)" (p. 79)

User-Defined Curve Range

x(s): 1 ms to 1000 s

y(%): 0 to 2000

Click here to display a sample graph of the data entered for a user-defined curve.

Click here to set ITIC Curve data ("ITIC Curve Chart" (p. 79)).

Click **Save** to display the Save dialog for saving your entered user-defined curve data. User-defined curves can be saved with any file name.

**To load a previously saved user-defined curve**

Click **Open** and select a file to load.

Closes the Curve Editor without changing the user-defined curve.

### 4 Click the **OK** button.

The curve with the specified contents appears in the ITIC window.



## Curve Tables (Reference)

## ITIC Curve Chart

Upper limit curve		Lower limit curve	
x [ s ]	y [ % ]	x [ s ]	y [ % ]
1 m	200	20 m	0
3 m	140	20 m	70
3 m	120	500 m	70
500 m	120	500 m	80
500 m	110	10	80
1000	110	10	90
		1000	90

## SEMI Curve Chart

Upper limit curve		Lower limit curve	
x [ s ]	y [ % ]	x [ s ]	y [ % ]
		20 m	0
		20 m	50
		200 m	50
		200 m	70
		500 m	70
		500 m	80
		10	80
		10	90
		1000	90

SEMI curve is made by the SEMI (Semiconductor Equipment and Materials International). It judges the voltage dip and interruption only, and has easier limit than the ITIC curve between 20ms and 200ms.

There is no upper limit curve in the SEMI curve, but we recommend using the upper limit value; x:1m, y:200 and x:1000, y:200.

## CISPR24 Curve Chart

Upper limit curve		Lower limit curve	
x [ s ]	y [ % ]	x [ s ]	y [ % ]
		20 m	30
		500 m	30
		500 m	95
		5	95
		5	100
		1000	100

Per operating judgment standard C

## Viewing a Delta V10 Flicker Graph

[Delta V10 Flicker Window]

Data measured with the Hioki 3196 Power Quality Analyzer can be displayed as a flicker graph (Delta V10 Flicker window).

The Delta V10 Flicker window is equivalent to the Delta V10 Flicker Graph (TIME PLOT) screen on the Hioki 3196.


### 1 Load the measurement data.

See: "Loading Data" (p. 14)

The Delta V10 Flicker window can be displayed only when an FLC file containing Delta V10 Flicker data is loaded.


### 2 Click the (Open Delta V10 Flicker window) button or select **View – Delta V10 Flicker Window** from the menu bar.

The Delta V10 Flicker window opens.



## Changing Displayed Contents

### 3 Select the items you want to change from the pull-down menus in the Delta V10 Flicker window's tool bar.



## Viewing Measurement Data as Numerical Values (Cursor Measurement)

### 4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

See: "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

## Viewing an IEC Flicker Graph

[IEC Flicker Window]


Data measured with the Hioki 3196 Power Quality Analyzer can be displayed as flicker graph (IEC Flicker window).

The IEC Flicker window is equivalent to the IEC Flicker Graph (TIME PLOT) screen on the Hioki 3196.


- 1 Load the measurement data.

**See:** "Loading Data" (p. 14)

The IEC Flicker window can be displayed only when an FLC file containing IEC Flicker data is loaded.


- 2 Click the  (Open IEC Flicker Window) button or select **View – IEC Flicker Window** from the menu bar.

The IEC Flicker window opens.



### Changing Displayed Contents

- 3 Select the items you want to change from the pull-down menus in the IEC Flicker window's tool bar.



### Viewing Measurement Data as Numerical Values (Cursor Measurement)

- 4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

**See:** "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

# Viewing Setting Conditions for Measurement Data

[SYSTEM]

The settings associated with the currently loaded data can be viewed in the Settings window. The Settings window is equivalent to the SYSTEM screen on the Hioki 3196.

## 1 Load the measurement data.


**See:** "Loading Data" (p. 14)

The Settings window can only be displayed when an SET file is loaded.

In addition, the EN50160 setting tabs are not displayed unless EN50160 data is included in the loaded data.

## 2 Click the (View system settings) button or select **View – SYSTEM** from the menu bar. The System window opens.

## 3 Select the tabs to view each setting.



## Correspondence Between Tabs and Hioki 3196 Setting Screens

PQA-HiView Pro Tab Name	Hioki 3196 Settings Screen
<b>Measurement</b>	SYSTEM-DF2-MAIN Measurement and Partial Recording
<b>Voltage Events</b>	SYSTEM-DF3-EVENT-VOLTAGE
<b>Power Events</b>	SYSTEM-DF3-EVENT-POWER
<b>Voltage Harmonics</b>	SYSTEM-DF3-EVENT-HARMONICS
<b>Current Harmonics</b>	SYSTEM-DF3-EVENT-HARMONICS
<b>Power Harmonics</b>	SYSTEM-DF3-EVENT-HARMONICS
<b>Harmonic Phase Difference</b>	SYSTEM-DF3-EVENT-HARMONICS
<b>EN50160 (1)</b>	EVENT-DF4-EN50160-Setting1 (When EN50160 measurement is enabled)
<b>EN50160 (2)</b>	EVENT-DF4-EN50160-Setting2 (When EN50160 measurement is enabled)
<b>EN50160 (3)</b>	EVENT-DF4-EN50160-Setting3 (When EN50160 measurement is enabled)

## Viewing EN50160 Mode Measurement Data


Data measured on the Hioki 3196 with the EN50160 function enabled can be displayed in the EN50160 window.

This window is equivalent to the EVENT – EN50160 screens (Overview, Harmonic, Signaling and Events screens) on the Hioki 3196.

The EN50160 mode provides the following four windows:


- Overview Window (p. 83)
- Harmonic Window (p. 85)
- Signaling Window (p. 86)
- Measurement Result Classification Window (p. 87)

### Overview Window

- 1 Click the  (Open EN50160 Overview Window) button, or select **View – EN50160** from the menu bar to activate the EN50160 mode.


**See:** "Switching Modes" (p. 55)

When the EN50160 mode is activated, the button appears pressed, and the View – EN50160 item in the menu has a check mark.

- 2 Click the  (Open EN50160 Overview window) button or select **View – Overview** from the menu bar.

The Overview window opens.

Window tool bar




The Good% value can be changed. (p. 84)

		Good%
Display From : 09/05 11:40 To : 09/02 11:30		
Freq.A	100.0%	99.5
Freq.B	100.0%	100.0
Vvari.A	CH1 99.9%	95.0
	CH2 99.9%	
	CH3 99.9%	
Vvari.B	CH1 99.9%	100.0
	CH2 99.9%	
	CH3 99.9%	
Flicker	CH1 100.0%	95.0
	CH2 100.0%	
	CH3 100.0%	
Unbalance	99.9%	95.0
THD	CH1 99.9%	95.0
	CH2 99.9%	
	CH3 99.9%	
Harmonic	CH1 99.9%	95.0
	CH2 99.9%	
	CH3 99.9%	

**Changing Displayed Contents**

**3** Select the items you want to change from the pull-down menus in the Overview window's tool bar.



You can select the data time span to display.

<b>All</b>	Display data for all times available in the EN data file.
<b>Specific</b>	Display data from the specified starting date for the specified span (Period).


Select whether to include other (flagged) data when a statistical voltage swell, dip or interruption occurs.

<b>Including flagging data</b>	Includes flagged data in statistics
<b>Excluding flagging data</b>	Excludes flagged data from statistics

Reference: When a voltage swell, dip or interruption event occurs, other parameter data (such as frequency) might interfere with the reliability of the occurrence data. In that case, other data can be flagged so that when a voltage swell, dip or interruption event occurs, the other data can be excluded from the statistics to improve reliability.


**Changing the Good% value**

**4** Click the Good% setting area.  
The Change Good% dialog box opens.




**5** Enter a new value for the Good%, and click the **OK** button.  
The entered Good% value is reflected in the Overview window.

## Harmonic Window

- 1 Click the  (Switch to EN50160 Window) button, or select **View – EN50160** from the menu bar to activate the EN50160 mode.

**See:** "Switching Modes" (p. 55)


When the EN50160 mode is activated, the button appears pressed, and the View – EN50160 item in the menu has a check mark.

- 2 Click the  (Open EN50160 Harmonic window) button or select **View – Harmonic** from the menu bar.

The Harmonic window opens.

Window tool bar

Shows the display starting date, span (period) and flag status (reflecting the settings in the Overview window)




## Changing Displayed Contents

- 3 Select the items you want to change from the pull-down menus in the Harmonic window's tool bar.




Orders from the 2<sup>nd</sup> to the 50<sup>th</sup> can be selected. The first order is not selectable.

## Signaling Window


- 1 Click the  (Switch to EN50160 Window) button, or select **View – EN50160** from the menu bar to activate the EN50160 mode.

**See:** "Switching Modes" (p. 55)

When the EN50160 mode is activated, the button appears pressed, and the View – EN50160 item in the menu has a check mark.


- 2 Click the  (Open EN50160 Signaling window) button or select **View – Signaling** from the menu bar.

The Signaling window opens.




## Changing Displayed Contents

- 3 Select the items you want to change from the pull-down menus in the Signaling window's tool bar.



## Changing the Good% value

- 4 Click the Good% location.  
The Change Good% dialog box opens.




- 5 Enter a new value for the Good%, and click the **OK** button.  
The entered Good% value is reflected in the Signaling window.




## Measurement Result Classification Window

Results can be classified as needed, and saved.

- 1 Click the  (Switch to EN50160 Window) button, or select **View – EN50160** from the menu bar to activate the EN50160 mode.

**See:** "Switching Modes" (p. 55)

When the EN50160 mode is activated, the button appears pressed, and the View – EN50160 item in the menu has a check mark.


- 2 Click the  (Open EN50160 Measurement Result Classification window) button or select **View – Measurement Result Classification** from the menu bar.

The Measurement Result Classification window opens.

Display Starting Date and Span (Period)  
(reflecting the settings in the Overview window)

You can edit the table's time span and voltage classifications.

**See:** "Changing Measurement Result Classifications" (p. 87)



Dip or Swell voltage u (% of Uref)	Duration t [s]							
	0.5cyc < t ≤ 100m	100m < t ≤ 500m	500m < t ≤ 1	1 < t ≤ 3	3 < t ≤ 20	20 < t ≤ 60	60 < t ≤ 180	180 < t
180 < u	0	0	0	0	0	0	0	0
160 < u ≤ 180	0	0	0	0	0	0	0	0
140 < u ≤ 160	0	0	0	0	0	0	0	0
120 < u ≤ 140	0	0	0	0	0	0	0	0
110 < u ≤ 120	0	0	0	0	0	0	0	0
70 ≤ u < 90	4	1	0	0	0	0	0	0
40 ≤ u < 70	0	0	0	0	0	0	0	0
10 ≤ u < 40	0	0	0	0	0	0	0	0
1 ≤ u < 10	0	0	0	0	0	0	0	0
u < 1	0	0	0	0	0	0	0	0

Indicates the number of voltage swell, voltage dip, and interruption occurrence in red.

### Voltage u

In the event of a voltage swell, Voltage u represents the maximum swell voltage (% of nominal voltage).  
In the event of a voltage dip or interruption, Voltage u represents the residual voltage (% of nominal voltage).

### Duration

Represents the duration of a voltage swell, voltage dip, or interruption.

**See:** "Three-Phase RMS Voltage Fluctuation Graph" (p. 89)

## Changing Measurement Result Classifications


- 3 Make the Measurement Result Classification window active and select **Measurement Result Classification – Editor of Measurement Result Classification**.

You can also right click and select from the pop-up menu.  
The Measurement Result Classification editor window opens.




### Three-Phase RMS Voltage Fluctuation Graph


#### Swell



#### Dip



#### Interruption






# Analyzing Measurement Data from the Hioki 3197

## Chapter 5

### Hioki 3197 Measurement Data Window Layout

#### Window Display

The Measurement Data window appears when measurement data is loaded.




Any window can be displayed using the menu or tool bar. A window can also be changed by right clicking within it and selecting another window to display from the pop-up menu.

**See:** "Menu Bar Operations" (p. 92), "Tool Bar Operations" (p. 95)  
"Changing Windows" (p. 17)

### Menu Bar Operations

Clicking a menu item displays one of the pull-down menus shown below. Items not available for the current window are grayed out.



#### 1 File .....

Click **File** and select from the pull-down menu.

The same operations are available on the tool bar (p. 95).

<b>Open</b>		Opens a file. (p. 14)
<b>Recent folder</b>		Displays recently used folders.
<b>Download</b>		Downloads data from internal memory of the 3196 or PC card via LAN. (p. 44)
<b>Close</b>		Closes the currently active window.
<b>Report Wizard</b>		Sets the conditions for creating a report. (p. 28)
<b>Print</b>		Prints the currently active window. (p. 24)
<b>Save the active data as a CSV file</b>		Saves the loaded data as a CSV format file. (p. 35)
<b>Open Integrated Files</b>		Opens a setting file for the 9624-50. (p. 47)
<b>Save Integrated Files</b>		Saves a setting file for the 9624-50. (p. 47)
<b>Currently-used Integrated Files</b>		Displays recently used compound files.
<b>Exit</b>		Closes the PQA-HiView Pro program. (p. 12)

#### 2 Edit .....

Click **Edit** and select from the pull-down menu.










The same operations are available on the tool bar (p. 95).

<b>Copy</b>		Displays can be copied to the clipboard. (p. 27)
-------------	--	--

### 3 View

Click **View** and select the window or items to display from the pull-down menu.



The same operations are available on the tool bar (p. 95).

View	Tool Bar		
<ul style="list-style-type: none"> <li>✓ EVENT LIST Window</li> <li>✓ EVENT DATA Window</li> <li>ITIC Window</li> </ul>	<b>Tool Bar</b>		Shows or hides the standard tool bar (top) and window tool bar (left).
<ul style="list-style-type: none"> <li>Open new TIME PLOT Window</li> <li>Delta V10 Flicker Window</li> <li>IEC Flicker Window</li> <li>Voltage Fluctuation Event Graph</li> <li>Inrush Current Event Graph</li> </ul>	<b>EVENT LIST Window</b>		Opens the event list window. To re-order the displayed list, select <b>Sort by Time (-)</b> or <b>Sort by Time (+)</b> (p. 100)
<ul style="list-style-type: none"> <li>Integrated Power Window...</li> <li>Demand Window...</li> </ul>	<b>EVENT DATA Window</b>		Opens the event details window. You can select the following window data types: <ul style="list-style-type: none"> <li>• Event Details Window (p. 101)</li> <li>• Voltage/Current Waveform Window</li> <li>• Voltage Waveform Window</li> <li>• Current Waveform Window</li> </ul>
ENS0160      Ctrl	<b>Open new TIME PLOT Window</b>		Opens up to four new TIME PLOT windows. You can select the following window data types: <ul style="list-style-type: none"> <li>• RMS Window (p. 96)</li> <li>• Voltage Window</li> </ul>
SYSTEM...	<b>Voltage Fluctuation Event Graph</b>		Opens the Voltage Fluctuation Event Window. (A WDU file of the voltage fluctuation event graph for the selected event must be loaded in order to display this window) (p. 106)
	<b>Inrush Current Event Graph</b>		Opens the Inrush Current Graph window. (An INR file of the inrush current graph must exist for the selected event in order to display this window) (p. 107)
	<b>Integrated Power Window</b>		Opens the Integrated Power window. (p. 108)
	<b>Demand Window</b>		Opens the Demand window. (p. 109)
	<b>SYSTEM</b>		Displays the settings on the Hioki 3197. (p. 110)

### 4 Window

Click **Window** and select from the pull-down menu.  
 This menu includes the names of the currently displayed windows.

The same operations are available on the tool bar (p. 95).

Window		
Tile	<b>Title</b>	 Arranges display of all open windows. (p. 26)
A and B cursor...	<b>A and B cursor</b>	 Select to demarcate a span or view values at cursor positions. (p. 21)
<input checked="" type="checkbox"/> 1 TIME PLOT - RMS U, CH1 <input type="checkbox"/> 2 Event details [No.1 02/14 09:19:08.12] <input type="checkbox"/> 3 EVENT LIST		

### 5 EVENT LIST/ EVENT DATA/ TIME PLOT

The menu displayed depends on the selected window.  
 Click **EVENT LIST**, **EVENT DATA** or **TIME PLOT** to select a window from the corresponding pull-down menu.  
 You can also right click and select a window to switch to from the pop-up menu.

<b>EVENT LIST</b> Sort by Time (-) <input checked="" type="checkbox"/> Sort by Time (+) Sort by Priority	<b>Sort by Time (-)</b> <b>Sort by Time (+)</b> (p. 100)	<b>EVENT DATA</b> <input checked="" type="checkbox"/> Event details VOLTAGE/CURRENT VOLTAGE/TRANSIENT VOLTAGE CURRENT VECTOR DIMM HARMONICS BAR GRAPH HARMONICS LIST	<b>Event details</b> (p. 102) <b>VOLTAGE/CURRENT</b> (p. 103) <b>VOLTAGE</b> (p. 104) <b>CURRENT</b> (p. 105)
<b>TIME PLOT</b> <input checked="" type="checkbox"/> RMS VOLTAGE HARMONICS INTERHARM	<b>RMS</b> (p. 98) <b>VOLTAGE</b> (p. 99)		

### 6 Help


Click **Help** and select from the pull-down menu.

<b>Help</b> Version of 9624-50 PQA-HIVIEW PRO...	Displays version information for the Hioki 9624-50 PQA-HiView Pro program.
---	--




## Tool Bar Operations

### Tool bar (standard)



1		<b>Open</b>	(p. 14)	6		<b>Open Integrated file</b>	(p. 47)
2		<b>Download</b>	(p. 44)	7		<b>Save Integrated file</b>	(p. 47)
3		<b>Report Wizard</b>	(p. 28)	8		<b>Tile</b>	(p. 26)
4		<b>Print</b>	(p. 24)	9		<b>A and B cursors</b>	(p. 21)
5		<b>Copy</b>	(p. 27)				

### Tool bar (window)



1		<b>Show/hide EVENT LIST Window</b>	(p. 100)
2		<b>Show/hide EVENT DATA Window</b>	(p. 101)
3		<b>Open new TIME PLOT Window</b>	(p. 96)
4		<b>Open Voltage Fluctuation Event Graph</b>	(p. 106)
5		<b>Open the Inrush Current Graph window</b>	(p. 107)
6		<b>Open Integrated Power Window</b>	(p. 108)
7		<b>Open Demand Window</b>	(p. 109)
8		<b>View system settings</b>	(p. 110)

## Viewing a Time Series Graph

[TIME PLOT]

Data measured with the Hioki 3197 Power Quality Analyzer can be displayed as a time series graph (Time Plot window). The program's Time Plot windows correspond to each Time Plot screen on the Hioki 3197.

The following two types of Time Plot windows can be displayed and switched, with up to four displayed at a time.


- RMS Window (p. 98)
- VOLTAGE Window(p. 99)

### Opening and Switching Time Plot Windows

- 1 Load the measurement data.


See: "Loading Data" (p. 14)

To display a Time Plot window, the loaded data must include an ITV file.

- 2 Click the  (Open Time Plot Window) button or select **View – Open new TIME PLOT window** from the menu bar.

A Time Plot Window opens.

You can open up to four windows by clicking the button or selecting from the menu bar repeatedly.



Click an event marker to view an event phenomenon in the other windows.

See: "Viewing Event Phenomena" (p. 19)

Scrolls the window

Move a scroll box or click within the scroll bar.

When scrolling horizontally, all open Time Plot windows scroll together.

### Switching Windows

- 3 Activate the Time Plot window to be switched, and select the desired window to display from the **TIME PLOT** menu.

You can also right click and select from the pop-up menu.

### Viewing Measurement Data as Numerical Values (Cursor Measurement)

- 4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.


**See:** "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

---

Viewing RMS Fluctuations [TIME PLOT – RMS]


1 Open a Time Plot window.  
 See: "Opening and Switching Time Plot Windows" (p. 96)

2 Activate the Time Plot window and select **RMS** from the **TIME PLOT** menu.  
 You can also right click and select from the pop-up menu.  
 The RMS window opens.



Changing Displayed Contents

3 When the RMS window is active, it's own tool bar is displayed.  
 Select the items you want to change from the pull-down menus in the RMS window's tool bar.




## Viewing Voltage Fluctuations

## [TIME PLOT – VOLTAGE]

- 1 Open a Time Plot window.  
See: "Opening and Switching Time Plot Windows" (p. 96)

- 2 Activate the Time Plot window and select **VOLTAGE** from the **TIME PLOT** menu.  
You can also right click and select from the pop-up menu.  
The Voltage window opens.

CH1 (Red)  
CH2 (Yellow-Green)  
CH3 (Blue)




Scrolls the window

Voltage fluctuation data consists of pairs of maximum and minimum values for every measurement interval. Therefore, expanding the horizontal scale reveals the data as a series of vertical lines between each pair of maximum and minimum values at each measurement interval. There is no horizontal line through the space between measurement intervals.

### Changing Displayed Contents

- 3 When the Voltage window is active, it's own tool bar is displayed.  
Select the items you want to change from the pull-down menus in the Voltage window's tool bar.



## Viewing Events as a List

[EVENT LIST]

Data measured with the Hioki 3197 Power Quality Analyzer can be displayed in a list (in the Event List window).

The Event List window is equivalent to the EVENT – LIST screen on the Hioki 3197.

To re-order the displayed list, select **Sort by Time (-)** or **Sort by Time (+)**.


### 1 Load the measurement data.

**See:** "Loading Data" (p. 14)

To display the Event List window, the loaded data must include an EVT file.

### 2 Click the (Show/hide EVENT LIST window) button or select **View – EVENT LIST Window** from the menu bar.

The Event List window opens.



No.	Date Time	Event Cat.	CH	IN...	WDU	INRUSH
1	07/12 10:35:39...	Ext (Start)				
2	07/12 10:35:48...	Inrush			WDU	INRUSH
3	07/12 10:35:48...	Dip	CH1	OU		
4	07/12 10:36:25...	Inrush			WDU	
5	07/12 10:36:39...	Ext(Timer)				
6	07/12 10:36:58...	Ext(Manual)				
7	07/12 10:37:00...	Ext(Manual)				
8	07/12 10:37:18...	Inrush			WDU	
9	07/12 10:37:18...	Dip	CH1	OUT		
10	07/12 10:37:21...	Ext(Manual)				
11	07/12 10:37:24...	Ext(Manual)				
12	07/12 10:37:26...	Ext(Manual)				
13	07/12 10:37:39...	Ext(Timer)				
14	07/12 10:37:44...	Ext (Stop)				

Indicates whether a graph of the event exists.

- WDU  
Indicates that an voltage fluctuation event graph exists. (p. 106)
- INRUSH  
Indicates that an inrush current graph exists. (p. 107)

Click an event, or select using the up/down arrow keys on the keyboard to view the event phenomenon in other windows.

**See:** "Viewing Event Phenomena" (p. 19)

Shows the event type.

## Re-Ordering the Display of Events

### 3 Activate the Event List window and select **Sort by Time (-)** or **Sort by Time (+)** from the **EVENT LIST** menu.

You can also right click and select from the pop-up menu.

The list is re-ordered according to your selection.

## Viewing Event Measurement Data

[EVENT DATA]

Data measured with the Hioki 3197 upon the occurrence of an event can be displayed as a graph and listed in the Event Data window.

The Event Data window is equivalent to the EVENT screen on the Hioki 3197.

The Event Data window can be switched between the following four types.


- Event details Window (p. 102)
- VOLTAGE/CURRENT Window (p. 103)
- VOLTAGE Window (p. 104)
- CURRENT Window (p. 105)

In this manual, the above windows are collectively called “Event Data windows”.


### Opening and Switching Event Data Windows

- 1 Load the measurement data.

See: "Loading Data" (p. 14)

- 2 Click the  (Show/hide EVENT DATA window) button or select **View – EVENT DATA Window** from the menu bar.

The Event data window opens.



Click an event marker or an event in the Event List to display a graph of the event.

See: "Viewing Event Phenomena" (p. 19)

### Switching Windows

- 3 Activate the Event Data window and select the desired window from the **EVENT DATA** menu.

You can also right click and select from the pop-up menu.





Viewing Voltage/Current Waveforms

[VOLTAGE/CURRENT]

1 Open the Event Data window.  
 See: "Opening and Switching Event Data Windows" (p. 101)

2 Activate the Event Data window and select the **VOLTAGE/CURRENT** window from the **EVENT DATA** menu.

You can also right click and select from the pop-up menu.  
 The Voltage/Current Waveform window opens.

Window tool bar

CH1 (Red)  
 CH2 (Yellow-Green)  
 CH3 (Blue)

Up to 14 cycles (50 Hz) or 16 cycles (60 Hz) can be analyzed.

Voltage waveform

Current waveform

Scrolls the window

Changing Displayed Contents

3 Select the items you want to change from the pull-down menus in the Event Data window's tool bar.

Y-axis scale of voltage waveform

Y-axis scale of current waveform

X-axis scale of waveform

Viewing Measurement Data as Numerical Values (Cursor Measurement)

4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

See: "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

Time and numerical values at A and B cursor locations

	U1	U2	U3	I1	I2	I3	I4
A	00:00:00:31:53:951	0.2613k	-0.2307k	-0.0216k	0.0003k	0.65	-22.12
B	08/08/08:31:53:988	0.2027k	0.0773k	-0.2797k	0.0003k	64.13	-66.16
	00:00:00:037	-0.0566k	0.3161k	-0.2581k	0.0000k	63.27	-44.05
						-19.24	-0.03

MAX values  
 AVE values  
 MIN values

Differences between A and B data (B - A)

The time difference between cursors is calculated using internal data resolution of less than 0.001 seconds, but the last digit (0.001 s) may not be exact.

Between A and B cursors

Cursor A (Light Blue)

Cursor B (Purple)

### Viewing Voltage Waveforms

### [VOLTAGE]

**1** Open the Event Data window.

**See:** "Opening and Switching Event Data Windows" (p. 101)


**2** Activate the Event Data window and select the **VOLTAGE** window from the **EVENT DATA** menu.

You can also right click and select from the pop-up menu.  
The Voltage window opens.

Window tool bar

CH1 (Red)  
CH2 (Yellow-Green)  
CH3 (Blue)

Up to 14 cycles (50 Hz) or  
16 cycles (60 Hz) can be  
analyzed.



Scrolls the window

### Changing Displayed Contents

**3** Select the items you want to change from the pull-down menus in the Voltage window's tool bar.



Y-axis scale of voltage waveform

X-axis scale of waveform

### Viewing Measurement Data as Numerical Values (Cursor Measurement)

**4** Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

**See:** "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

## Viewing Current Waveforms

[CURRENT]

- 1 Open the Event Data window.  
See: "Opening and Switching Event Data Windows" (p. 101)

- 2 Activate the Event Data window and select the **CURRENT** window from the **EVENT DATA** menu.


You can also right click and select from the pop-up menu.

The Current window opens

Window tool bar

CH1 (Red)  
CH2 (Yellow-Green)  
CH3 (Blue )  
CH4 (Light Blue )

Up to 14 cycles (50 Hz) or  
16 cycles (60 Hz) can be  
analyzed.



Scrolls the window

## Changing Displayed Contents

- 3 Select the items you want to change from the pull-down menus in the Current window's tool bar.



Y-axis scale of current waveform

X-axis scale of waveform

## Viewing Measurement Data as Numerical Values (Cursor Measurement)

- 4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

See: "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

## Viewing Voltage Fluctuation Details

### [Voltage Fluctuation Event Graph]

Voltage fluctuation phenomena (swells, dips and interruptions) that occurred within data measured by the Hioki 3197 can be displayed graphically (in the Voltage Fluctuation Event Graph window).

This window is equivalent to the EVENT-RMS WAVE screen on the Hioki 3197.

A Voltage Fluctuation Event Graph can be displayed only when an Event file (WDU file) is loaded.

Event files can be confirmed in the Event List (p. 100).

A Voltage Fluctuation Event Graph is a 3-second time series graph of rms voltage calculated over one half-cycle-shifted waveform.

#### 1 Load the measurement data.


See: "Loading Data" (p. 14)

#### 2 Click the (Open Voltage Fluctuation Event Graph) button or select **View – Voltage Fluctuation Event Graph** from the menu bar.

The Voltage Fluctuation Event Graph window opens.

Window tool bar


CH1 (Red)  
CH2 (Yellow-Green)  
CH3 (Blue)



Scrolls the window

### Changing Displayed Contents

#### 3 Select the items you want to change from the pull-down menus in the Voltage Fluctuation Event Graph window's tool bar.



### Viewing Measurement Data as Numerical Values (Cursor Measurement)

#### 4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

See: "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

### Viewing Other Event Phenomena

#### 5 Click any WDU event marker in the Event List or Time Plot window.

A Voltage Fluctuation Event Graph window appears for the selected event.

If there is no WDU file for the selected event, "Specified WDU file not present" appears.

## Viewing an Inrush Current Graph


### [Inrush Current Event Graph]

Data measured with the Hioki 3197 Power Quality Analyzer when an inrush current event occurs can be displayed as a graph (Inrush Current Event Graph). The Inrush Current Event Graph window is equivalent to the EVENT-INRUSH screen on the Hioki 3197.

The inrush current graph can be displayed only when an event (INR) file is loaded. Event files can be confirmed in the Event List (p. 100). This is a 30-second time series graph of rms current calculated every half cycle.

- 1 Load the measurement data.


See: "Loading Data" (p. 14)

- 2 Click the  (Open Inrush Current Event Graph) button or select **View – Inrush Current Event Graph** from the menu bar.

The Inrush Current Event Graph window opens.

Window tool bar


CH1 (Red)  
CH2 (Yellow-Green)  
CH3 (Blue)



Scrolls the window

### Changing Displayed Contents

- 3 Select the items you want to change from the pull-down menus in the Inrush Current Event Graph window's tool bar.



### Viewing Measurement Data as Numerical Values (Cursor Measurement)

- 4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

See: "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

### Viewing Other Event Phenomena

- 5 Click any INRUSH event marker in the Event List or Time Plot window.

An Inrush Current Event Graph window appears for the selected event.

If there is no INR file for the selected event, "Specified INR file not present" appears.


## Viewing Energy Consumption [Integrated Power Window]

Energy consumption measured with the Hioki 3197 Power Quality Analyzer can be displayed as a time series graph (Integrated Power window).


The Integrated Power window is equivalent to the TIMEPLOT-ENERGY screen on the Hioki 3197.

- 1 Load the measurement data.

See: "Loading Data" (p. 14)


- 2 Click the  (Open Integrated Power window) button or select **View – Integrated Power Window** from the menu bar.

The Integrated Power window opens.



### Changing Displayed Contents

- 3 Select the items you want to change from the pull-down menus in the Integrated Power window's tool bar.



### Viewing Measurement Data as Numerical Values (Cursor Measurement)

- 4 Measurement values can be confirmed using the cursors. In addition, the minimum, maximum and average values over any span can be displayed.

See: "Viewing Measurement Data as Numerical Values (Cursor Measurement)" (p. 21)

When the A/B Cursor dialog is open, A/B cursor movement has priority over the usual screen cursor.

## Viewing a Demand Graph

[Demand Window]

Data measured with the Hioki 3197 Power Quality Analyzer can be displayed as a demand graph (Demand window).

The Demand window is equivalent to the TIMEPLOT-DEMAND screen on the Hioki 3197.


### 1 Load the measurement data.

See: "Loading Data" (p. 14)

If the measurement duration of the loaded data is too short, the Demand window cannot be displayed.


### 2 Click the (Open Demand window) button or select **View – Demand Window** from the menu bar.

The Demand window opens.



## Changing Displayed Contents

### 3 Select the items you want to change from the pull-down menus in the Demand window's tool bar



## To change the cursor position

### 4 Click the point where you want to move the cursor, or press the right- or left-arrow key on the keyboard to move the cursor.

Maximum and average demand values, load factor, and the demand value at the cursor position are shown.

# Viewing Setting Conditions for Measurement Data


[SYSTEM]

The settings associated with the currently loaded data can be viewed in the Settings window. The Settings window is equivalent to the SYSTEM screen on the Hioki 3197.


**1** Load the measurement data.

**See:** "Loading Data" (p. 14)

The Settings window can only be displayed when an SET file is loaded.

**2** Click the  (View system settings) button or select **View – SYSTEM** from the menu bar. The System window opens.

**3** Select the tabs to view each setting.



### Correspondence Between Tabs and Hioki 3197 Setting Screens

PQA-HiView Pro Tab Name	Hioki 3197 Settings Screen
Measurement	SYSTEM measurement settings and some recording events
Event	Event portion of SYSTEM recording events



# Specifications

# Chapter 6

## General Specifications

Supported Model

- Model 3196 Power Quality Analyzer
- Model 3197 Power Quality Analyzer

Supplied Media                      One CD-R disc

Accessories                              Instruction Manual

## Hioki 3196 Function Specifications and Calculation Formulas

### Data Reading Functions

Reading Data                      Binary data recorded by the 3196

- SET files..... Setting data
- ITV files ..... TIME PLOT data
- EVT files..... Event data (lists, voltage/current waveforms, numerical values)
- FLC files..... Flicker data (Delta V10, IEC)
- TRN files ..... Transient over voltage waveform data
- WDU files ..... Event voltage fluctuation data
- EN50160.EN files..... EN50160 data
- EVENT.EN files..... EN50160 event data

Reading Method                      Reads the above file types in folder units

Maximum Data Capacity              528 MB

**Data Display Functions****■ SYSTEM Display Function**

Screen Display	SYSTEM (Settings) content display
----------------	-----------------------------------

**■ TIME PLOT Display Function**

Screen Display	Display of one to four of the following screens 1. RMS fluctuation 2. Voltage fluctuation 3. Harmonics fluctuation 4. Interharmonics fluctuation
Number of Display Screens	Up to four
Cursor Function	A and B cursors (specify an interval for calculations)
Event Marker Function	Uses the marker to indicate where an event has occurred (selectable using the cursor key).

**■ EVENT List Display Function**

Screen Display	EVENT list content display
Display Method Selection	Chronological or priority order
WDU Display Function	Displays "WDU" for a selected event with event voltage fluctuation data.

**■ EVENT Data Display Function**

Display Function	Displays the event data selected on the Event list display screen (Synchronized switch-over) Displays the event marker data selected on the TIME PLOT display screen (Synchronized switch-over)
Screen Display	One of the following six screen displays <ol style="list-style-type: none"> <li>1. Event details displays Detailed event data is displayed.</li> <li>2. Waveform displays Voltage/current waveforms, 4-channel voltage waveforms, 4-channel current waveforms, Voltage/transient waveforms</li> <li>3. Vector displays RMS or Harmonic Phase Angle display</li> <li>4. DMM displays Power, Voltage or Current display</li> <li>5. Harmonics Bar Graph displays RMS or Phase Angle display</li> <li>6. Harmonics List display RMS or Phase Angle display</li> </ol>
Cursor Function	A and B cursors on the waveform display window (specify an interval for calculations)
Zero/Positive/Negative Phase Calculation Function	Simultaneously displays the voltage and current of zero/positive/negative phase sequence components in the vector window when analyzing 3P4W line data.
Event Marker Function	Uses the marker to indicate where an event has occurred on the waveform display screen.

**■ Flicker Graph Display Function**

Screen Display	Displays the Delta V10 flicker graph or IEC flicker graph (The graph to be displayed depends on the data saved.)
Cursor Function	A and B cursors (specify an interval for calculations)

**■ Event Voltage Fluctuation Graph Display Function**

Screen Display	Displays the WDU event data selected on the Event list window. Displays the WDU event marker data selected on the TIME PLOT window.
Cursor Function	A and B cursors (specify an interval for calculations)
Event Marker Function	Uses the marker to indicate where an event has occurred

**Integrated Power Calculation Function****■ Settings**

Analysis Start Time	Year, month, day, hour, minute and second settings
Analysis Period	1 to 31 days

**■ Display Method and Calculation Items**

Screen Display	Integrated Power Value (consumed value + returned value) [Wh]
Numerical Display	Displays the following values within the analysis period Maximum integrated power value (the last integrated power value within an analysis period)
Cursor Function	The following cursor functions are available <ul style="list-style-type: none"> <li>• Normal cursor (displays integrated power value at cursor position)</li> <li>• A and B cursors (specify an interval for calculations)</li> </ul>

**Demand Calculation Function****■ Settings**

Analysis Start Time	Year, month, day, hour, minute and second settings
Demand Period	5, 10, 15 or 30 minutes, or 1, 2, 3, 6 or 12 hours (can be set to the measurement interval of the 3196, or longer)
Analysis Period	1 to 31 days

**■ Display Method and Calculation Items**

Screen Display	Demand graph (consumption values only)
Numerical Display	Displays the following values within the analysis period <ul style="list-style-type: none"> <li>• AVE Demand value (average demand within the analysis period)</li> <li>• MAX Demand value (peak demand within the analysis period)</li> <li>• Load factor (average demand / maximum demand x 100[%])</li> </ul>
Cursor Function	Normal cursor (displays demand value at cursor position)

## ITIC Curve Display Function

Display Function	Plots points for the events below on the limit curve. <ol style="list-style-type: none"> <li>Points to indicate the duration of swell and maximum swell voltage</li> <li>Points to indicate the duration of dip and residual voltage</li> <li>Points to indicate the duration of interruption and residual voltage</li> </ol>																																				
Percent of Nominal Voltage	Calculates the proportion of maximum swell voltage or residual voltage to nominal voltage in percentage. Percent of nominal voltage = Peak value / UReference x 100 UReference: Nominal voltage Peak value: Maximum swell voltage in case of swell or residual voltage in case of dip/interruption																																				
Violation Count Display	Number of upper-limit violations, number of lower-limit violations, and total number of events																																				
Limit Curve Selection	ITIC curve, user-defined curve (e.g., arbitrary curve) ITIC curve values <table border="1" data-bbox="577 788 1430 1122"> <thead> <tr> <th colspan="2">Upper Limit Curve</th> <th colspan="2">Lower Limit Curve</th> </tr> <tr> <th>Horizontal axis [s]</th> <th>Vertical axis [%]</th> <th>Horizontal axis [s]</th> <th>Vertical axis [%]</th> </tr> </thead> <tbody> <tr> <td>1 m</td> <td>200</td> <td>20 m</td> <td>0</td> </tr> <tr> <td>3 m</td> <td>140</td> <td>20 m</td> <td>70</td> </tr> <tr> <td>3 m</td> <td>120</td> <td>500 m</td> <td>70</td> </tr> <tr> <td>500 m</td> <td>120</td> <td>500 m</td> <td>80</td> </tr> <tr> <td>500 m</td> <td>110</td> <td>10</td> <td>80</td> </tr> <tr> <td>1000</td> <td>110</td> <td>10</td> <td>90</td> </tr> <tr> <td>—</td> <td>—</td> <td>1000</td> <td>90</td> </tr> </tbody> </table>	Upper Limit Curve		Lower Limit Curve		Horizontal axis [s]	Vertical axis [%]	Horizontal axis [s]	Vertical axis [%]	1 m	200	20 m	0	3 m	140	20 m	70	3 m	120	500 m	70	500 m	120	500 m	80	500 m	110	10	80	1000	110	10	90	—	—	1000	90
Upper Limit Curve		Lower Limit Curve																																			
Horizontal axis [s]	Vertical axis [%]	Horizontal axis [s]	Vertical axis [%]																																		
1 m	200	20 m	0																																		
3 m	140	20 m	70																																		
3 m	120	500 m	70																																		
500 m	120	500 m	80																																		
500 m	110	10	80																																		
1000	110	10	90																																		
—	—	1000	90																																		

## EN50160 Data Viewer Function

Screen Display	EN50160 windows 1 to 4 below are displayed simultaneously. <ol style="list-style-type: none"> <li>Overview window Corresponds to the EVENT-EN50160-Over View window of the 3196.</li> <li>Harmonic window Corresponds to the EVENT-EN50160-Harmonics window of the 3196.</li> <li>Measurement result classification window Corresponds to the EVENT-EN50160-Events window of the 3196.</li> <li>Signaling details window Corresponds to the EVENT-EN50160-Signaling window of the 3196.</li> </ol>
Screen Switching	Note that you must switch the normal display mode into the EN50160 display mode by pressing the EN button once.

## Copy Function

Copy Contents	Save various windows as BMP files
---------------	-----------------------------------

**Print Function**

Printing Format	Screen Image printing
Printing Paper Sizes	A4 and Letter
Print Preview	Provided
Simultaneous Printing	Logo/Model, time (with selectable text to print)
Marker Simultaneous Printing	MAX/MIN/AVE, channel, order (with printing turned ON/OFF)

**CSV Format Conversion Function**

Convertible Screens	TIME PLOT window, Event waveform window, Flicker graph window, Event voltage fluctuation window, Demand window, Integrated power value window
Specific Conversions	<ol style="list-style-type: none"> <li>1. Range specified with A and B cursors (TIME PLOT window, Flicker graph window, Event voltage fluctuation window, Integrated power value window)</li> <li>2. Full range (Event waveform window, Demand window)</li> </ol>
Conversion Items	The conversion items, channels, and MAX/ MIN/ AVE can be selected.

**Select Text Function**

Text Selectable Windows	DMM window, Harmonics list window
Copying	Saves data in the selected range as tab-delimited text.

**Download via LAN**

Communications Method	HTTP
Connection Method	LAN connection using Ethernet

## Report Creation Function

Output Format	Prints out a report containing information set with the report wizard or saves it in a Rich Text format file.			
Report Generation Methods	Report Output Items	Automatic (Fixed Output)	Individual Setting (Selectable)	Detail Setting (Selectable)
	RMS voltage fluctuation graph in Time Plot window	●	●	●
	RMS current fluctuation graph in Time Plot window	×	●	●
	Voltage fluctuation, RMS fluctuation, harmonic fluctuation, inter-harmonic fluctuation in Time Plot window	×	×	●
	Flicker graph, energy consumption graph, demand graph	×	×	●
	Total harmonic voltage distortion graph in Time Plot window	●	●	●
	Total harmonic current distortion graph in Time Plot window	×	●	●
	EN50160 Overview data	●	●	×
	EN50160 Signaling data	●	●	×
	EN50160 Harmonic data	×	●	×
	EN50160 measurement result classification data	×	●	×
	Worst case	●	●	×
	Transient waveform	×	●*	×
	Max/min list	●	●	×
	All-event waveform	●	●	×
	All-event detail list	●	●	×
	Setting list	×	●	×

\*. Transient waveform is selectable only when worst case is selected.

## Setting Save Function

Files to Save	<ul style="list-style-type: none"> <li>• User-defined curve file</li> <li>• Setting file for sorting measurement results</li> <li>• Setting file for report wizard</li> <li>• Integrated file (combining the three files above)</li> </ul>
---------------	--

### Calculation Formulas

#### ■ Integrated Power WH [Wh]

$$WH = \frac{\sum_{n=1}^N (P_{sum})}{k}$$

*N*: integrated sample count  
*n*: sample count

- *k* = constant for per-hour conversion

Intervals	1 seconds	3 seconds	15 seconds	30 seconds	1 minutes	5 minutes	10 minutes	15 minutes	30 minutes	1 hours	2 hours
<i>k</i>	3600	1200	240	120	60	12	6	4	2	1	0.5

- *P<sub>sum</sub>* = the average value during each interval
- This integrated power value includes both consumed power (+ values) and returned power (- values).

#### ■ Demand Power [W]

$$Dem = \frac{\sum_{d=1}^D (P_{sum+})}{D}$$

*D*: Count of average values of each interval within the demand period  
*d*: Count of samples

- *P<sub>sum+</sub>* = the average value of each interval calculated by adding consumed power (+ values) as is, and 0 for returned power (- values).

#### ■ Positive, Negative, and Zero Phase Calculation

$$\text{Component} = \frac{1}{3} \sqrt{\frac{(V1 \cdot \cos(\alpha) + V2 \cdot \cos(\beta + seq2) + V3 \cdot \cos(r + seq3))^2 + (V1 \cdot \sin(\alpha) + V2 \cdot \sin(\beta + seq2) + V3 \cdot \sin(r + seq3))^2}{}}$$

Zero phase: *seq2* = 0°, *seq3* = 0°

Positive phase: *seq2* = 120°, *seq3* = 240°

Negative phase: *seq2* = 240°, *seq3* = 120°

Voltage component:

*V1* = *U1*, *V2* = *U2*, *V3* = *U3*,

*α* = Phase angle of *U1*, *β* = Phase angle of *U2*, *γ* = Phase angle of *U3*

Current component:

*V1* = *I1*, *V2* = *I2*, *V3* = *I3*,

*α* = Phase angle of *I1*, *β* = Phase angle of *I2*, *γ* = Phase angle of *I3*

#### ■ Depth of Event [%] in ITIC Window or Measurement result classification Window

The depth is calculated as the proportion of peak voltage to nominal voltage.

Percent of nominal voltage = Peak value / *U<sub>Reference</sub>* x 100

Peak value: Peak voltage of the event

*U<sub>Reference</sub>*: Nominal voltage



# Hioki 3197 Function Specifications

## Data Reading Functions

Reading Data	Binary data recorded by the 3197 SET files..... Setting data ITV files ..... TIME PLOT data EVT files..... Event data (list and voltage/current waveforms) WDU files ..... Event voltage fluctuation data INR files..... Inrush current graph data DEM files..... Demand graph data
Reading Method	Reads the above file types in folder units
Maximum Data Capacity	4 MB

## Data Display Functions

### ■ SYSTEM Display Function

Screen Display	SYSTEM (Settings) content display
----------------	-----------------------------------

### ■ TIME PLOT Display Function

Screen Display	Displays the following windows 1. RMS fluctuation 2. Voltage fluctuation
Number of Display Screens	Up to four
Cursor Function	A and B cursors (specify an interval for calculations)
Event Marker Function	Uses the marker to indicate where an event has occurred (selectable using the cursor key).

### ■ Energy Consumption Display Function

Screen Display	Energy Consumption graph
Displayed Items	WP+, WP-, WQ LAG, WQ LEAD
Numerical Display	Maximum energy consumption during measurement
Cursor Function	Normal cursor (indicates energy consumption at cursor position)

**■ Demand Display Functions**

Screen Display	Demand Graph
Displayed Items	Pdem+, Pdem-, Qdem LAG, Qdem LEAD
Numerical Display	Maximum demand value during measurement, average demand during measurement
Cursor Function	Normal cursor (indicates demand at cursor position)

**■ EVENT List Display Function**

Screen Display	EVENT list content display
Display Method Selection	Chronological
WDU Display Function	Displays "WDU" for a selected event with event voltage fluctuation data.
INRUSH Display Function	Displays "INRUSH" for a selected event with event inrush current data.

**■ EVENT Data Display Function**

Display Function	Displays the event data selected on the Event list display screen (Synchronized switch-over) Displays the event marker data selected on the TIME PLOT display screen (Synchronized switch-over)
Screen Display	One of the following screen displays 1. Event details displays Detailed event data is displayed. 2. Waveform displays Voltage/current waveforms, voltage waveforms, current waveforms
Cursor Function	A and B cursors on the waveform display window (specify an interval for calculations)
Event Marker Function	Uses the marker to indicate where an event has occurred on the waveform display screen.

**■ Event Voltage Fluctuation Graph Display Function**

Screen Display	Displays the WDU event data selected on the Event list window. Displays the WDU event marker data selected on the TIME PLOT window.
Cursor Function	A and B cursors (specify an interval for calculations)
Event Marker Function	Uses the marker to indicate where an event has occurred

**■ Inrush Graph Display Function**

Screen Display	Displays the INRUSH event data selected on the Event list window. Displays the INRUSH event marker data selected on the TIME PLOT window.
Cursor Function	A and B cursors (specify an interval for calculations)
Event Marker Function	Uses the marker to indicate where an event has occurred

## Copy Function

Copy Contents	Save various windows as BMP files
---------------	-----------------------------------

## Print Function

Printing Format	Screen Image printing
Printing Paper Sizes	A4 and Letter
Print Preview	Provided
Simultaneous Printing	Logo/Model, time (with selectable text to print)
Marker Simultaneous Printing	MAX/MIN/AVE, channel (with printing turned ON/OFF)

## CSV Format Conversion Function

Convertible Screens	TIME PLOT window, Event waveform window, Event voltage fluctuation window, Inrush Current Event Graph window, Demand window, Integrated power value window
Specific Conversions	<ol style="list-style-type: none"> <li>1. Range specified with A and B cursors (TIME PLOT window, Event voltage fluctuation window, Inrush Current Event Graph window, Integrated power value window)</li> <li>2. Full range (Event waveform window, Demand window)</li> </ol>
Conversion Items	The conversion items, channels, and MAX/ MIN/ AVE can be selected.

**Report Creation Function**

Output Format	Prints out a report containing information set with the report wizard or saves it in a Rich Text format file.			
Report Generation Methods	Report Output Items	Automatic (Fixed Output)	Individual Setting (Selectable)	Detail Setting (Selectable)
	RMS voltage fluctuation graph in TIME PLOT window	●	●	●
	RMS current fluctuation graph in TIME PLOT window	×	●	●
	Voltage fluctuation and RMS fluctuation in TIME PLOT window	×	×	●
	Flicker graph and demand graph	×	×	●
	Total harmonic voltage distortion graph in TIME PLOT window	●	●	●
	Worst case	●	●	×
	Max/min list	●	●	×
	All-event waveform	●	●	×
	All-event detail list	●	●	×
	Setting list	×	●	×

**Setting Save Function**

Files to Save	<ul style="list-style-type: none"> <li>• Setting file for report wizard</li> <li>• Integrated file</li> </ul>
---------------	---

# Appendix

## Appendix 1 3196 Data-header Composition

### Text Time-sequence Data-header Composition

Remark: Each item is separated by a comma (,).

Classification	Header	Explanation	
Date and Time	Date	Date	2001/8/20
	Time	Time	8:12:00
Voltage fluctuation*	Umax1,...,Umax3	Max. value of voltage fluctuation	CH1 - CH3
	Umin1,...,Umin3	Min. value of voltage fluctuation	CH1 - CH3
RMS value fluctuation Maximum value	MaxFreq	Frequency	
	MaxUrms1,...,MaxUrms4	RMS voltage value	CH1 - CH4
	MaxU+peak1,...,MaxU+peak4	Voltage waveform peak (+)	CH1 - CH4
	MaxU-peak1,...,MaxU-peak4	Voltage waveform peak (-)	CH1 - CH4
	MaxIrms1,...,MaxIrms4	RMS current value	CH1 - CH4
	MaxI+peak1,...,MaxI+peak4	Current waveform peak (+)	CH1 - CH4
	MaxI-peak1,...,MaxI-peak4	Current waveform peak (-)	CH1 - CH4
	MaxUave	Average RMS voltage value	ave
	MaxIave	Average RMS current value	ave
	MaxP1,...,MaxP3	Active power	CH1 - CH3
	MaxPsum	Sum of active power	sum
	MaxS1,...,MaxS3	Apparent power	CH1 - CH3
	MaxSsum	Sum of apparent power	sum
	MaxQ1,...,MaxQ3	Reactive power	CH1 - CH3
	MaxQsum	Sum of reactive power	sum
	MaxPF1,...,MaxPF3	Power factor/Displacement power factor	CH1 - CH3
	MaxPFsum	Sum of Power factor/Displacement power factor	sum
	MaxKF1,...,MaxKF4	K factor	CH1 - CH4
	MaxUunb	Voltage unbalance factor	
	MaxIunb	Current unbalance factor	
	MaxUthd1,...,MaxUthd4	Total harmonic voltage distortion factor	CH1 - CH4
	MaxIthd1,...,MaxIthd4	Total harmonic current distortion factor	CH1 - CH4
	MaxU1(1),...,MaxU4(50)	Harmonic voltage	CH1 - CH4 1st - 50th
	MaxI1(1),...,MaxI4(50)	Harmonic current	CH1 - CH4 1st - 50th
	MaxP1(1),...,MaxP3(50)	Harmonic power	CH1 - CH3 1st - 50th
	MaxPhase1(1),...,MaxPhase3(50)	Harmonic voltage-current phase difference	CH1 - CH3 1st - 50th
	MaxPsum(1),...,MaxPsum(50)	Sum of harmonic power	sum 1st - 50th
	MaxPhasesum(1),...,MaxPhasesum(50)	Sum of harmonic voltage-current phase difference	sum 1st - 50th
	MaxUtihd1,...,MaxUtihd4	Total harmonic voltage distortion factor	CH1 - CH4
	MaxItihd1,...,MaxItihd4	Total harmonic current distortion factor	CH1 - CH4
MaxU1(0.5),...,MaxU4(49.5)	Inter-harmonic voltage	CH1 - CH4 0.5 - 49.5th	
MaxI1(0.5),...,MaxI4(49.5)	Inter-harmonic current	CH1 - CH4 0.5 - 49.5th	

\*: When  $\Delta U$  is selected as the voltage recording setting, Umax1, .....Umax3 becomes dUmax1, .....dUmax3, and Umin1, .....Umin3 becomes dUmin1, .....dUmin3.

**Appendix 1 3196 Data-header Composition**

Classification	Header	Explanation
RMS value fluctuation Minimum value	MinFreq	Frequency
	MinUrms1,...,MinUrms4	RMS voltage value CH1 - CH4
	MinU+peak1,...,MinU+peak4	Voltage waveform peak (+) CH1 - CH4
	MinU-peak1,...,MinU-peak4	Voltage waveform peak (-) CH1 - CH4
	MinIrms1,...,MinIrms4	RMS current value CH1 - CH4
	MinI+peak1,...,MinI+peak4	Current waveform peak (+) CH1 - CH4
	MinI-peak1,...,MinI-peak4	Current waveform peak (-) CH1 - CH4
	MinUave	Average RMS voltage value ave
	MinIave	Average RMS current value ave
	MinP1,...,MinP3	Active power CH1 - CH3
	MinPsum	Sum of active power sum
	MinS1,...,MinS3	Apparent power CH1 - CH3
	MinSsum	Sum of apparent power sum
	MinQ1,...,MinQ3	Reactive power CH1 - CH3
	MinQsum	Sum of reactive power sum
	MinPF1,...,MinPF3	Power factor/Displacement power factor CH1 - CH3
	MinPFsum	Sum of Power factor/Displacement power factor sum
	MinKF1,...,MinKF4	K factor CH1 - CH4
	MinUunb	Voltage unbalance factor
	MinIunb	Current unbalance factor
	MinUthd1,...,MinUthd4	Total harmonic voltage distortion factor CH1 - CH4
	MinIthd1,...,MinIthd4	Total harmonic current distortion factor CH1 - CH4
	MinU1(1),...,MinU4(50)	Harmonic voltage CH1 - CH4 1st - 50th
	MinI1(1),...,MinI4(50)	Harmonic current CH1 - CH4 1st - 50th
	MinP1(1),...,MinP3(50)	Harmonic power CH1 - CH3 1st - 50th
	MinPhase1(1),...,MinPhase3(50)	Harmonic voltage-current phase difference CH1 - CH3 1st - 50th
	MinPsum(1),...,MinPsum(50)	Sum of harmonic power sum 1st - 50th
	MinPhasesum(1),...,MinPhasesum(50)	Sum of harmonic voltage-current phase difference sum 1st - 50th
	MinUtihd1,...,MinUtihd4	Total harmonic voltage distortion factor CH1 - CH4
	MinItihd1,...,MinItihd4	Total harmonic current distortion factor CH1 - CH4
	MinU1(0.5),...,MinU4(49.5)	Inter-harmonic voltage CH1 - CH4 0.5 - 49.5th
	MinI1(0.5),...,MinI4(49.5)	Inter-harmonic current CH1 - CH4 0.5 - 49.5th

## Appendix 1 3196 Data-header Composition

Classification	Header	Explanation
RMS value fluctuation Average value	AveFreq	Frequency
	AveUrms1,....,AveUrms4	RMS voltage value CH1 - CH4
	AveU+peak1,....,AveU+peak4	Voltage waveform peak (+) CH1 - CH4
	AveU-peak1,....,AveU-peak4	Voltage waveform peak (-) CH1 - CH4
	Avelrms1,....,Avelrms4	RMS current value CH1 - CH4
	Avel+peak1,....,Avel+peak4	Current waveform peak (+) CH1 - CH4
	Avel-peak1,....,Avel-peak4	Current waveform peak (-) CH1 - CH4
	AveUave	Average RMS voltage value ave
	Avelave	Average RMS current value ave
	AveP1,....,AveP3	Active power CH1 - CH3
	AvePsum	Sum of active power sum
	AveS1,....,AveS3	Apparent power CH1 - CH3
	AveSsum	Sum of apparent power sum
	AveQ1,....,AveQ3	Reactive power CH1 - CH3
	AveQsum	Sum of reactive power sum
	AvePF1,....,AvePF3	Power factor/Displacement power factor CH1 - CH3
	AvePFsum	Sum of Power factor/Displacement power factor sum
	AveKF1,....,AveKF4	K factor CH1 - CH4
	AveUunb	Voltage unbalance factor
	Avelunb	Current unbalance factor
	AveUthd1,....,AveUthd4	Total harmonic voltage distortion factor CH1 - CH4
	Avelthd1,....,Avelthd4	Total harmonic current distortion factor CH1 - CH4
	AveU1(1),....,AveU4(50)	Harmonic voltage CH1 - CH4 1st - 50th
	Avel1(1),....,Avel4(50)	Harmonic current CH1 - CH4 1st - 50th
	AveP1(1),....,AveP3(50)	Harmonic power CH1 - CH3 1st - 50th
	AvePhase1(1),....,AvePhase3(50)	Harmonic voltage-current phase difference CH1 - CH3 1st - 50th
	AvePsum(1),....,AvePsum(50)	Sum of harmonic power sum 1st - 50th
	AvePhasesum(1),....,AvePhasesum(50)	Sum of harmonic voltage-current phase difference sum 1st - 50th
	AveUtihd1,....,AveUtihd4	Total harmonic voltage distortion factor CH1 - CH4
	Aveltihd1,....,Aveltihd4	Total harmonic current distortion factor CH1 - CH4
AveU1(0.5),....,AveU4(49.5)	Inter-harmonic voltage CH1 - CH4 0.5 - 49.5th	
Avel1(0.5),....,Avel4(49.5)	Inter-harmonic current CH1 - CH4 0.5 - 49.5th	

**Appendix 1 3196 Data-header Composition****Delta V10 Flicker Text Time-sequence Data-header Composition**

Classification	Header	Explanation	Example
Date and Time	Date	Date	2001/11/02
	Time	Time	17:19:00
Delta V10	dv10	Delta V10 instantaneous value	0.081
	max	Delta V10 total maximum value	0.158
	dv10max	Delta V10 maximum value for one hour	0.000
	dv10max4	Delta V10 fourth largest value for one hour	0.000
	dv10ave	Delta V10 average value for one hour	0.000

**IEC Flicker Text Time-sequence Data-header Composition**

Classification	Header	Explanation	Example
Date and Time	Date	Date	2002/3/5
	Time	Time	15:24:15
Pst, Plt	Pst 1	CH1 Pst	0.325
	Pst 2	CH2 Pst	0.386
	Pst 3	CH3 Pst	0.358
	Plt 1	CH1 Plt	0.325
	Plt 2	CH2 Plt	0.386
	Plt 3	CH3 Plt	0.358



## Appendix 2 3197 Data-header Composition

Classification	Header	Explanation
Date Time Status	Date	Date
	Time	Time
	Status	Status
TIME PLOT DIP/SWELL	Umax1, Umax2, Umax3	Voltage Maximum value
	Umin1, Umin2, Umin3	Voltage Minimum value
TIME PLOT RMS Maximum Values	MaxFreq	Frequency
	MaxUrms1, MaxUrms2, MaxUrms3	Voltage
	MaxU+peak1, MaxU+peak2, MaxU+peak3	Voltage Waveform Peak+
	MaxU-peak1, MaxU-peak2, MaxU-peak3	Voltage Waveform Peak-
	MaxIrms1, MaxIrms2, MaxIrms3, MaxIrms4	Current
	MaxI+peak1, MaxI+peak2, MaxI+peak3, MaxI+peak4	Current Waveform Peak+
	MaxI-peak1, MaxI-peak2, MaxI-peak3, MaxI-peak4	Current Waveform Peak-
	MaxUave	Voltage for 3phase
	MaxIave	Current for 3phase
	MaxPsum, MaxSsum, MaxQsum	Active Power, Apparent Power, Reactive Power
	MaxPFsum, MaxUunb	Power Factor
	MaxUthd1, MaxUthd2, MaxUthd3	Total Harmonic Voltage Distortion Ratio
TIME PLOT RMS Minimum Values	MinFreq	Frequency
	MinUrms1, MinUrms2, MinUrms3	Voltage
	MinU+peak1, MinU+peak2, MinU+peak3	Voltage Waveform Peak+
	MinU-peak1, MinU-peak2, MinU-peak3	Voltage Waveform Peak-
	MinIrms1, MinIrms2, MinIrms3, MinIrms4	Current
	MinI+peak1, MinI+peak2, MinI+peak3, MinI+peak4	Current Waveform Peak+
	MinI-peak1, MinI-peak2, MinI-peak3, MinI-peak4	Current Waveform Peak-
	MinUave	Voltage for 3phase
	MinIave	Current for 3phase
	MinPsum, MinSsum, MinQsum	Active Power, Apparent Power, Reactive Power
	MinPFsum, MinUunb	Power Factor
	MinUthd1, MinUthd2, MinUthd3	Total Harmonic Voltage Distortion Ratio
TIME PLOT RMS Average Values	AveFreq	Frequency
	AveUrms1, AveUrms2, AveUrms3	Voltage
	AveU+peak1, AveU+peak2, AveU+peak3	Voltage Waveform Peak+
	AveU-peak1, AveU-peak2, AveU-peak3	Voltage Waveform Peak-
	AveIrms1, AveIrms2, AveIrms3, AveIrms4	Current
	AveI+peak1, AveI+peak2, AveI+peak3, AveI+peak4	Current Waveform Peak+
	AveI-peak1, AveI-peak2, AveI-peak3, AveI-peak4	Current Waveform Peak-
	AveUave	Voltage for 3phase
	AveIave	Current for 3phase
	AvePsum, AveSsum, AveQsum	Active Power, Apparent Power, Reactive Power
	AvePFsum, AveUunb	Power Factor
	AveUthd1, AveUthd2, AveUthd3	Total Harmonic Voltage Distortion Ratio
TIME PLOT Energy Quadergy	WP+, WP-	Energy (Delivered, Received)
	WQ_LAG, WQ_LEAD	Quadergy (Lagging, Leading)



# Index

## C

CISPR24 Curve .....	79
Clipboard .....	22, 27
Closing the Program .....	12
Comment field .....	24
CSV file .....	35
Current Waveforms .....	68, 105
Cursor Measurement .....	21
Custom Settings .....	30

## D

Delta V10 Flicker .....	80
Demand .....	75, 109
Detailed Settings .....	31
Display modes .....	55
DMM display .....	70
Downloading .....	44

## E

EN50160 mode .....	83
Event Data .....	63, 101
Event details .....	64, 102
Event List .....	62, 100

## H

Harmonic Fluctuations .....	60
Harmonics Bar Graph .....	71
Harmonics List .....	72

## I

IEC Flicker .....	81
Inrush Current .....	107
Installing .....	4, 6
Integrated Power .....	74, 108
Inter-Harmonic Fluctuations .....	61
ITIC .....	76
ITIC Curve .....	79

## L

LAN .....	44
Loading data .....	13

## M

Measurement Result Classification .....	87
Measurement windows .....	16
Menu bar .....	16, 50, 92

## P

Pop-Up menu .....	16
Printing .....	24

## R

Report	
Generating Reports .....	28
Output Items .....	32
Printout Example .....	33
Report Wizard .....	28
RMS Fluctuations .....	58, 98

## S

Screens .....	16
Scroll bar .....	16
SEMI Curve .....	79
Settings Files .....	46
Starting the Program .....	11
Status bar .....	16
System .....	82, 110

## T

Time Series Graph .....	56, 96
Tolerance Curve .....	77
Tool bar .....	16, 53, 95
Tool bar (window) .....	16

## U

Uninstalling .....	9
User-Defined Curve .....	77

## V

Vector Display .....	69
Voltage Fluctuation Event Graph .....	73, 106
Voltage Fluctuations .....	59, 99
Voltage Waveforms .....	67, 104
Voltage/Current .....	65, 103

## Index **2**

### ***Index***

---

---

Voltage/Transient ..... 66

### **W**

---

Window Layout ..... 26

HIOKI 9624-50 PQA-HiVIEW PRO  
Instruction Manual

Publication date: November 2006 Edition 1

Edited and published by HIOKI E.E. CORPORATION  
Technical Support Section

All inquiries to International Sales and Marketing Department  
81 Koizumi, Ueda, Nagano, 386-1192, Japan

TEL: +81-268-28-0562 / FAX: +81-268-28-0568

E-mail: [os-com@hioki.co.jp](mailto:os-com@hioki.co.jp)

URL <http://www.hioki.co.jp/>

Printed in Japan 9624C981-00

- 
- 
- All reasonable care has been taken in the production of this manual, but if you find any points which are unclear or in error, please contact your supplier or the International Sales and Marketing Department at HIOKI headquarters.
  - In the interests of product development, the contents of this manual are subject to revision without prior notice.
  - Unauthorized reproduction or copying of this manual is prohibited.
- 
-

# HIOKI

---

HIOKI E. E. CORPORATION

## HEAD OFFICE

81 Koizumi, Ueda, Nagano 386-1192, Japan

TEL +81-268-28-0562 / FAX +81-268-28-0568

E-mail: [os-com@hioki.co.jp](mailto:os-com@hioki.co.jp) / URL <http://www.hioki.co.jp/>

## HIOKI USA CORPORATION

6 Corporate Drive, Cranbury, NJ 08512, USA

TEL +1-609-409-9109 / FAX +1-609-409-9108

---

9624C981-00 06-11H



Printed on recycled paper

---

**T**  **USA**  
**Equipment**  
**.NET**™  
**1-877-742-TEST (8378)**