



CAN/ LIN Bus Decoder App

GDS 2000A Series
With DS2-8LA or DS2-16LA Module

USER MANUAL
GW INSTEK PART NO.



ISO-9001 CERTIFIED MANUFACTURER

GW INSTEK

This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will Corporation.

The information in this manual was correct at the time of printing. However, Good Will continues to improve its products and therefore reserves the right to change the specifications, equipment, and maintenance procedures at any time without notice.

Good Will Instrument Co., Ltd.
No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.

Table of Contents

I NSTALL THE SOFTWARE	2
U NINSTALL THE SOFTWARE.....	4
H OW TO USE THE SOFTWARE	6
Select a Bus Decoder Type.....	6
How to Trigger on the CAN Bus Decoder.....	7
How to Trigger on the LIN Bus Decoder	11
A PPENDIX.....	15
CAN Bus Decode Display Information:.....	15
LIN Bus Decode Display Information:	15


INSTALL THE SOFTWARE

Step

1. Make sure the optional module “DS2-8LA” or “DS2-16LA” is installed in the GDS-2000A.

2. Make sure firmware version is V1.18 or higher.

3. Insert the USB memory stick with the CAN_LinBus.gz into the USB port on the front panel.




4. Press the *Utility* key.




5. Select *File Utilities* from the bottom menu.



- Use the *Variable* knob to select the USB memory stick and then press the *Select* button.



- Use the *Variable* knob to select CAN_LinBus.gz and then press the *Select* button to select it.



- Press the *Select* button again to start installation.



- The installation is complete when a message showing "Please turn off the oscilloscope and turn on again" is displayed.

U NINSTALL THE SOFTWARE

Step


1. Press the *Test* key on the front panel



2. Press the *APP* button from the bottom menu.



3. Use the *Variable* knob to select the CAN Lin Bus APP.



4. Press the *Uninstall* button from the side menu.



5. Press the *Uninstall* button from side menu again to start the uninstallation process.



6. Uninstallation process is complete when a message showing "Please turn off the oscilloscope and turn on again" appears.

HOW TO USE THE SOFTWARE



Select a Bus Decoder Type

Step

1. Press the *B* key on the front panel.



2. Select the *Bus Type* button from the side menu. You can select *CAN* or *LIN* as the bus decoder.




How to Trigger on the CAN Bus Decoder

Step




1. Press the *Trigger Menu* key on the front panel.




2. Press the *Type* button from the bottom menu.




3. Press the *Others* button from the side menu and then select the *Bus* using the *Variable* knob and *Select* key.




4. Press the *Trigger On* button from the lower menu and then select the desired *Trigger ON* condition using the *Variable* knob and *Select* key.




5. If the *Type of Frame* option is selected as the Trigger On condition, press the *Frame Type* button from the lower menu to select the desired frame type.




6. Select a frame type from the side menu.



- If the *Identifier* option is selected as the Trigger On condition, press the *Identifier* button from the lower menu.





- Select the Format from the side menu.




- Press the *Identifier* button from the side menu.



- Enter a binary or hex value with the *Variable* knob and *Select* key.




- Press the *Direction* button from the lower menu and select the desired direction.



- If *Data* option is selected as the Trigger On condition, press the *Data* button from the lower menu.



- Select the desired parameters from the side menu.




How to Trigger on the LIN Bus Decoder

Step


1. Press the *Trigger Menu* key on the front panel.




2. Press the *Type* button from the bottom menu.




3. Press the *Others* button from the side menu and then select Bus using the *Variable* knob and *Select* key.



4. Press the *Trigger On* button from the lower menu and then select the desired *Trigger ON* condition using the *Variable* knob and *Select* key.



5. If *Identifier*, *Data*, *Identifier* or *Identifier & Data* is selected as the Trigger On condition, press the *Identifier* or *Data* button from the lower menu.




6. Select the desired parameters from the corresponding side menu.

- If the *Error* option is selected as the Trigger On condition, select the desired parameters from the corresponding side menu.










Trigger On
Error

Error Type
Sync












APPENDIX

CAN Bus Decode Display Information:

Field	Description
Start of frame	 Start of frame is shown as a white left bracket.
Identifier	 The Identifier field is shown as a yellow box.
DLC (data length control)	 The DLC field is shown as a purple box.
Data	 The Data field is shown as a cyan box.
CRC	 The CRC field is shown as an orange box.
Missing Ack	 Missing Acknowledge is shown as a red exclamation symbol.
End of frame	 End of frame is shown as a white right bracket.
Bit stuffing error	 Bit stuffing error is shown as a red box.
Error frame and Overland	 Error frame and Overland are shown as a purple box.

LIN Bus Decode Display Information:

Field	Description
Start of frame	 Start of frame is shown as a white left bracket.
Break and Sync	 The Break and Sync fields are shown as a purple box.
Identifier and Parity	 The Identifier and Parity fields are shown a yellow box.

Data	 The Data field is shown as a cyan box.
Checksum and Wakeup	 The Checksum and Wakeup fields are shown as a purple box.
End of frame	 End of frame is shown as a white right bracket.
Error type	 Error type is shown as a red box.
Sync, Parity, Checksum	  When a check sum error happens, the checksum field turns into an Error type field.

