

M130 – T/C Calibrator

Instruction Manual Z1017-IR

E.O. 6566 Sept. 2008

**M130 – THERMOCOUPLE CALIBRATOR
USER MANUAL**



Meriam Process Technologies' M130 is a handheld calibrator for thermocouple (T/C) measurement or simulation. Eight T/C types are supported referencing NIST175 and ITS90 standards. Temperature can be displayed in selectable engineering units of °C, °F, °R, K

Table of Contents

Introduction	3
User Interface.....	4
Keypad Functions	4
ON/OFF Key	4
BACKLIGHT Key.....	4
SETUP Key	4
FUNCTION Key	5
UNITS Key.....	5
ENTER Key.....	5
INCREMENT (+) Group Keys.....	5
DECREMENT (–) Group Keys	6
Liquid Crystal Display (LCD)	6
Functional Modes and States	7
T/C Measurement	8
T/C Simulation (Manual).....	9
T/C Simulation (Auto)	9
MEAS SETUP	10
SIM (MANUAL) SETUP.....	11
SIM (AUTO) SETUP	12
Engineering Units Select	14
Record Mode	14
OFF Timer	15
Zeroing the M130	15
Specifications.....	16
T/C Measurement & Simulation Accuracy Table.....	17
Certification	18
Changing the Batteries.....	18
User Connections.....	20
Contact Information.....	21

Introduction

Thank you for purchasing this Meriam product. Meriam has been providing innovative, reliable, cost-effective measurement and calibration solutions since 1911.

The M130 Thermocouple calibrator has been designed using the latest technology to provide reliable accuracy throughout its entire operating temperature range, dependable operation, and exceptional battery life.

The compact design makes the unit easy to carry and the intuitive user interface makes it easy to use.

Temperature measurements/simulations are displayed on a large, easy-to-read liquid crystal display (LCD). This unit has two backlights: a green backlight which is user activated to improve readability in low light conditions, and an automatic red backlight which indicates an over-range condition.

Twelve keys provide access to the functional modes and menus, including Measure, Simulate, Setup, Run, Record, Edit, and Backlight activation. A list of these functions is printed on the back of the case.

User Interface**Keypad Functions****ON/OFF Key**

The ON/OFF key, represented by the standard ON/OFF symbol, turns the M130 ON or OFF (note: the ON/OFF key must be held until the display turns on or off). Upon power on, the M130 will perform a self-test, displaying the Meriam product ID, and all segments for approximately 1-2 seconds, then go into the mode in use when unit was powered off. The firmware version is displayed at the end of the self-test.

BACKLIGHT Key

The BACKLIGHT key, represented by the standard light-bulb symbol, turns the green display backlight on and off. The backlight will remain on for approximately 20 seconds if not manually turned off. To override the auto shut off timer, press and hold the BACKLIGHT key to turn the backlight on. After holding the key for approximately 2 seconds, the backlight will flash off and back on. Release the key now and the backlight will remain on until manually turned off or until power is cycled.

SETUP Key

The SETUP key enters or exits the setup mode and is also used to go back one menu level. The SETUP icon is displayed while in the setup mode. Setup menus are shown in the bottom (alpha-numeric) row of the LCD. The SETUP key also ends simulation activities.

FUNCTION Key

The FUNCTION key, represented by the FUNC symbol, selects one of 3 functional modes: Measure, Simulate (manual), or Simulate (auto), and displays the corresponding icons (MEAS, SIM). This key can also be used to advance one menu item or will advance to next recorded value while in RECORD view mode.

UNITS Key

The UNITS key selects the engineering unit of measurement/simulation desired for temperature probes: °F, °C, °R, and K. The UNITS function is only available when the M130 is actively measuring or simulating temperature signals. This key is also used to go back one menu item in SETUP or back to the previous recorded value while in VIEW mode.

ENTER Key

The ENTER key accepts the currently displayed item/value during setup activities. During active simulation activity, the ENTER key toggles between T/C type with temperature unit information and % of range.

INCREMENT (+) Group Keys

The three keys beneath this symbol allow the user to scroll through edit selections when EDIT icon is lit. The keys are also used to increment numeric values. For this function, the narrow band signifies fine adjustment, the medium band signifies medium adjustment, and the wide band signifies coarse

adjustment for changing the values. The positive sign (+) indicates the Group Keys will increment the displayed value.


DECREMENT (-) Group Keys



The three keys beneath this symbol allow the user to scroll through edit selections when EDIT icon is lit. The keys are also used to decrement numeric simulation values. For this function, the narrow band signifies fine adjustment, the medium band signifies medium adjustment, and the wide band signifies coarse adjustment for changing the values. The negative sign (-) indicates the Group Keys will decrement the displayed value.

In addition, when the narrow band and wide band areas are pressed simultaneously (HOME) the unit will return to the Measure mode default position.

Liquid Crystal Display (LCD)



The LCD displays:

- current Functional Mode and/or state via icons along top of display
- primary measurements via the large middle segments
- menu items and additional information via the bottom alpha-numeric segments

The LCD incorporates two backlights:

- a green backlight which is user activated via the BACKLIGHT key
- a red backlight which is automatically activated during an over-range/under-range condition.

During an over-range/under-range condition, the red backlight will over-ride the green backlight if it was already on. Once the condition is corrected, the green backlight will be restored to its previous state (assuming the backlight auto-off timer did not expire).

- Notes:
1. The backlight should be turned off when not needed to conserve battery power.
 2. The backlight will be automatically disabled when the M130 reaches battery mode.

Functional Modes and States

The M130 supports measurement and simulation activities using the following **Functional Modes**:

1. Measure - temperature units or measure mV; MEAS icon shown at top of display
2. Simulate, Manual - simulate fixed values of temperature units or mV; SIM icon shown at top of display
3. Simulate, Auto - simulate step or ramp output functions in temperature units or mV; SIM icon shown at top of display

Each Functional Mode has three possible **States**:

1. Run - active measurement or simulation; MEAS or SIM icon shown at top of display
2. Setup – access navigation menus; MEAS & SETUP or SIM & SETUP icons shown at top of display
3. Edit Setup - edit a parameter within a navigation menu; “EDIT, MEAS & SETUP” or “EDIT, SIM & SETUP” icons shown at top of display

The M130 will power up in its previous functional mode when turned ON. Example: if previous use was SIM (Auto), then next power up will default to SIM (Auto). Simulation will restart when user confirms the desired setup and presses the ENTER key (two times).

See the table below for functional modes, states and key functions.

FUNCTIONAL MODES, STATES, AND KEY FUNCTIONS			
Keys	Run	Setup	Edit Setup
	MEAS or SIM	MEAS SETUP or SIM SETUP	EDIT MEAS SETUP, or EDIT SIM SETUP
SETUP	Enters Setup state, or ends simulation activity	Back one menu level, or exits Setup state	Discards changes and exits Edit Setup state
FUNC ►	Next Functional mode	Next menu item	---
◄ UNITS	Next engineering unit	Previous menu item	---
ENTER	Toggles lower display line between TC type / temp. unit and % of range (SIM only)	Selects menu item	Saves changes and exits Edit Setup state
Increment (+) Group	MEAS: --- SIM Manual: Change values	---	Change value
Decrement (-) Group	MEAS: --- SIM Manual: Change values	---	Change value

T/C Measurement

- When the M130 is turned on the display defaults to the previous mode it was in with the previous T/C type and Unit. To change the mode press the FUNC ► key until the Measure mode is obtained. Once in Measure mode, press the ◄ UNITS key until the desired unit is obtained.
- Press the SETUP key to enter the initial setup menu for the current functional mode. To go back one menu item press the ◄ UNITS key. To advance the menu, press the FUNC ► key. SETUP key also backs out of the Setup state and returns to the Measure mode.

- ENTER key accepts the menu item to edit and saves the selection. During the SETUP EDIT state the ◀ UNITS key goes back one increment value, and the FUNC ▶ key advances one increment value.
- T/C measurements can be recorded to memory either manually or automatically. See the Record Mode section of this manual for more information.
- When an over-range/under-range message is displayed, the M130 is measuring values outside the specified range for a particular T/C type (See the T/C Measurement Accuracy Table for specified ranges). The red backlight will illuminate and “----” will be displayed.
- If a thermocouple has not been connected to the unit “T/C OPEN” will be displayed.

T/C Simulation (Manual)

- When unit is turned on the display defaults to the previous mode with the last T/C type and Units chosen. To enter the Simulation Manual mode press the FUNC ▶ key until SIM MANUAL appears, then press the SETUP key.

T/C Simulation (Auto)

- When unit is turned on the display defaults to the previous mode with the last T/C type and Units chosen. To enter the Simulation Auto mode press the FUNC ▶ key until SIM AUTO appears, then press the SETUP key.

MEAS SETUP: Measure Mode Setup menu structure

T/C TYPE	select ENTER to access submenus
mV	engineering units are mV
B	engineering units are temperature only
E	engineering units are temperature only
J	engineering units are temperature only
K	engineering units are temperature only
N	engineering units are temperature only
R	engineering units are temperature only
S	engineering units are temperature only
T	engineering units are temperature only
OFF TMR	select ENTER to access submenus
30 MIN	shuts off in 30 min without new key stroke
OFF	must use ON/OFF key to shut off
F RECAL	select ENTER to access submenu
ZERO	set zero. See “Zeroing the M130” section
VIEW	view previously recorded values
RECORD	select ENTER to access submenus
MANUAL	press ENTER button to record values
AUTO	values automatically recorded every 5 seconds

Note: Main and submenus are continuous scrolling menus. Use ◀ or ▶ to scroll through the menus.

SIM (MANUAL) SETUP: Simulation Mode's Manual menu structure

VALUE	
ADJUST	Press ENTER & use increment or decrement group keys to set a numeric value, press ENTER to start
UNITS	Select desired unit of simulation
C	engineering units are °C
F	engineering units are °F
R	engineering units are °R
K	engineering units are K
TC TYPE	Select T/C type or mV
mV	engineering units are mV
B	engineering units are temperature only
E	engineering units are temperature only
J	engineering units are temperature only
K	engineering units are temperature only
N	engineering units are temperature only
R	engineering units are temperature only
S	engineering units are temperature only
T	engineering units are temperature only
0 – 100	Outputs 0% and 100% of setup
START	Starts 0% of range; ENTER toggles to 100%, 0%...
UNITS	Edit units corresponding to 0 – 100, same as above
TC TYPE	Select T/C type, same as above
URV	Upper Range Value for T/C and unit selected press enter & use +/- keys
LRV	Lower Range Value for T/C and unit selected press enter & use +/- keys
STEP 25%	Outputs 0, 25, 50, 75 and 100% of setup below
START	Starts 0%, ENTER increases 25% to 100% & back
UNITS	Edit unit for STEP 25%, same as above
TC	Select T/C type, same as above
URV	Upper Range Value for T/C and unit selected press enter & use +/- keys
LRV	Lower Range Value for T/C and unit selected press enter & use +/- keys

- Notes: 1. Main and submenus are continuous, scrolling menus. Use ◀ or ▶ to scroll through the menus.
2. Use SETUP key to discontinue simulation activity.

SIM (AUTO) SETUP: Simulation Mode's Manual menu structure

AUTO	Press SETUP to enter
A.STEP 1	Title of Auto Step 1 simulation; setup saved here for subsequent re-use
START	Starts A.STEP 1
UNITS	Select desired unit of simulation
C	engineering units are °C
F	engineering units are °F
R	engineering units are °R
K	engineering units are K
TC TYPE	Select T/C type or mV
mV	engineering units are mV only
B	engineering units are temperature only
E	engineering units are temperature only
J	engineering units are temperature only
K	engineering units are temperature only
N	engineering units are temperature only
R	engineering units are temperature only
S	engineering units are temperature only
T	engineering units are temperature only
URV	Upper Range Value for T/C and unit selected, press enter & use +/- keys
LRV	Lower Range Value for T/C and unit selected, press enter & use +/- keys
STEPS	Input number of steps desired for test
UP	press enter & use + / - keys
DOWN	press enter & use + / - keys
DWELL	Select desired dwell time for test points
Manual	Manually advance simulation
5 SEC.	Auto advance simulation every 5 seconds
10 SEC.	Auto advance simulation every 10 seconds
A.STEP 2	same as A.STEP 1 above
A.STEP 3	same as A.STEP 1 above
A.RAMP 1	Title of Auto Ramp 1 simulation; setup saved here for subsequent re-use
START	Starts A.RAMP 1
UNITS	Select desired unit of simulation
C	engineering units are °C
F	engineering units are °F
R	engineering units are °R

K	engineering units are K
TC TYPE	Select T/C type or mV
mV	engineering units are mV only
B	engineering units are temperature only
E	engineering units are temperature only
J	engineering units are temperature only
K	engineering units are temperature only
N	engineering units are temperature only
R	engineering units are temperature only
S	engineering units are temperature only
T	engineering units are temperature only
URV	Upper Range Value for T/C and unit selected, press enter & use +/- keys
LRV	Lower Range Value for T/C and unit selected, press enter & use +/- keys
UP TIME	Select desired ramp time from LRV to URV, press enter & use +/- keys
DN TIME	Select desired ramp time from URV to LRV, press enter & use +/- keys
DELAY	Select desired start delay time for test, press enter & use +/- keys

A.RAMP 2

same as A.RAMP 1 above

A. RAMP 3

same as A.RAMP 1 above

- Note:
1. Main and submenus are continuous, scrolling menus. Use ◀ or ▶ to scroll through the menus.
 2. Use SETUP key to discontinue simulation activity.

Engineering Units Select

Engineering Units are conveniently selected when actively measuring or in Manual Simulation mode. Press the ◀ UNITS key to display any of the following: °C, °F, °R, K. NOTE: to display mV units, select the mV option under MEAS SETUP / TC TYPE. The ◀ UNITS key will not change display units for this TC TYPE.

Record Mode

The M130 can store up to 240 temperature measurements in a single record (REC) session. For maximum flexibility, a REC session can be:

- Automatic - the current value is automatically stored every 5 seconds, for up to 20 minutes.
- Manual - the current value is stored every time the Enter key is pressed, up to 240 times.

Both types of REC sessions can store between 1 and 240 measurements. The measurement data is preserved in non-volatile memory until another REC session is started.

RECORD Data:

To start a **manual** record session from Measure Mode, press SETUP key and then ◀ or ▶ key until RECORD is displayed. Press ENTER and then ◀ or ▶ key until MANUAL is displayed. Press ENTER. Previously stored information is deleted and M130 enters Record Manual Mode. The REC icon flashes in upper right. Press Enter to save a displayed value to memory. Pressing SETUP key ends the session.

To start an **automatic** record session from Measure Mode, press SETUP key and then ◀ or ▶ key until RECORD is displayed. Press ENTER and then ◀ or ▶ key until AUTO is displayed. Press ENTER. Previously stored information is deleted and M130 enters Record Auto Mode. The REC icon flashes in upper right. Values are stored every 5 seconds until the SETUP key is pressed to end the session or 240 values are saved.

REC is displayed on the lower display line each time a sample is stored. After 240 measurements have been recorded or the SETUP key is pressed, the REC

session will stop and the RECORD Data mode will automatically exit to Measure Mode.

VIEW Recorded Data:

To view the results of a REC session from Measure Mode, press SETUP key and then ◀ or ▶ key until VIEW is displayed. Press ENTER. The REC icon is shown in upper right. Display will show recorded value 1 of X (1/X). Pressing ENTER will toggle to show the T/C type and engineering unit. The ◀ or ▶ key moves to previous or next recorded value, respectively.

OFF Timer

To help conserve battery life, the M130 can be programmed to shut off automatically after 30 minutes of keypad inactivity. From Measure Mode, press SETUP and then ◀ or ▶ key until OFF TMR is displayed. Press the ENTER key and use + or – key to display OFF or 30 MIN from menu. Press ENTER key to save selection. Press SETUP again to return to Measure Mode.

Zeroing the M130

Preparation: Allow the M130 and supplied Shorting Plug (p/n Z9A83) to soak at room temperature for 30 minutes in a controlled temperature environment. Record the room temperature immediately prior to zeroing.

Zeroing: From Measure Mode, press SETUP once and then the ◀ or ▶ key until F RECAL is displayed. Press the ENTER key to display ZERO. Press ENTER to start ZERO process. Display will show SHORT. Install the Shorting Plug (white, mini-T/C connector with internal copper short) on the M130's connection and press ENTER key. Display will show BUSY.

When ZERO is successfully completed, the message "ZERO PASSED" is briefly displayed and the M130 is automatically returned to the Measure Mode. Remove the Shorting Plug. The new temperature reference for the M130 will be the ambient temperature recorded prior to zeroing. (Note: factory reference temperature is 23°C.)

If the ZERO is unsuccessful, the message "ZERO FAILED" will be displayed briefly. In this case, check to be sure the Shorting Plug is properly installed and repeat the ZERO process. If "ZERO FAILED" appears again contact Meriam for technical support.

Specifications

Type and Range: T/C types B, E, J, K, N, R, S, T & milli-volts Milli-volts range -15mV to +80.00 mV
T/C Measurement & Simulation Accuracy: See Table below mV Accuracy: 0.005% of reading $\pm 6\mu\text{V}$ mV Temp. Effect: $\pm 2\mu\text{V}/^\circ\text{C}$ (Factory Ref. Temp. = 23°C) Cold Junction Effect: $\pm 0.05^\circ\text{C}/^\circ\text{C}$ Cold Junction Accuracy: $\pm 0.1^\circ\text{C}$ at 25°C
T/C Resolution: T/C types E, J, K, N, T: 0.1°C T/C types B, R, S: 1°C mV: 0.001 mV ($1\mu\text{V}$)
Temperature: Storage = -40°C to $+85^\circ\text{C}$ (-40°F to $+185^\circ\text{F}$) Operating = -10°C to $+50^\circ\text{C}$ (14°F to $+122^\circ\text{F}$)
Humidity: 10% to 90% Rh
Connection: Measure: standard mini-T/C connector Simulate: standard mini-T/C connector Zero: supplied mini-T/C connector with internal copper short
Maximum Input Voltage: 30VDC
Battery Type: 3 x AA battery, field replaceable.
Battery Operation: >100 hours continuous use without the backlight for measure or simulation modes, 1 year shelf life, low battery warning at approximately 2 hours remaining run time.
Enclosure: (6.5" $\times$ 3.2" $\times$ 1.1") Polycarbonate, Permanently Static Dissipative, ESD Protection Enclosure with Boot: (6.8" $\times$ 3.5" $\times$ 1.3")

T/C Measurement & Simulation Accuracy Table*

Find T/C type in left column and follow the row across to the temperature range of interest. Then follow the column up to determine the potential error in degrees C.

T/C Type	±3.0° C	±2.0° C	±1.0° C	±0.5° C	±0.4° C	±0.3° C	±0.2° C	±0.1° C
E						-200 to -179°C	-179 to 15°C	15 to 1000°C
J						-200 to -165°C	-165 to 1200°C	
K					-200 to 1372°C			
N						-200 to 110°C	110 to 1300°C	
T					-200 to -168°C	-168 to -86°C	-86 to 346°C	346 to 400°C
R		-50 to 27°C	27 to 736°C	736 to 1768°C				
S		-50 to 25°C	25 to 1179°C	1179 to 1768°C				
B	250 to 295°C	295 to 605°C	605 to 1301°C	1301 to 1820°C				

*Notes: 1. Accuracy stated above applies to all T/C measurements and all manual (non-ramp) T/C simulations.
2. Cold junction effect at 25° C included in above table.

Certification

The M130 is EMI/ESD compliant to the test specification EN61326.

The M130 is for general purpose use only. Do not use in potentially hazardous atmospheres.



Changing the Batteries

The M130 is powered by three, 1.5 volt AA size batteries. The “BAT” icon in upper left of display will activate when battery output drops below a threshold level. Approximately 2 hours of life remain from that point.

Replace all three AA batteries at the same time for best performance.

To replace the batteries, locate the battery compartment at the lower rear of the M130. Remove the screws located at the top center and bottom center of the battery cover by turning them counterclockwise until fully disengaged from the M130 base. Remove the cover. **Do not remove the pink anti-static foam that is attached to the inside of the battery cover. This foam is necessary to properly secure the batteries under specified shock and vibration conditions.**

Remove the batteries by pulling the positive side first straight out of the battery compartment. Note the positive (+) and negative (–) battery polarity markings at the bottom of the compartment, as shown below.



Install the three batteries by sliding them into the bottom of the battery slots, positive (+) end first, making sure the polarity markings on the batteries align with the markings molded into the battery compartment. When a battery is installed with the polarity reversed, the stand-offs prevent the negative battery terminal from contacting the positive terminal in the battery compartment. The unit will not power up in this condition; to correct, simply reverse the battery to correct the polarity.

With the batteries secured in the battery compartment, replace the compartment cover. The cover has only one orientation for correct alignment. The “WARNING DO NOT OPEN IN EXPLOSIVE ATMOSPHERE” statement on the battery cover must be visible and aligned in the approximate middle of the M130 case. To secure the cover, torque the screws clockwise to 1.6 in-lbs. Do not over tighten.

User Connections

Connection: Standard mini-T/C Connector (Measure and Simulate)

Warning: The copper receiver blades of the mini-T/C connector in the M130 can be damaged if the mating plugs are misaligned during installation. Take care to properly align the mating plug prior to pressing it into the M130's connector.



Contact Information

If the M130 is damaged, it should be returned to the factory for servicing. Contact the Meriam Process Technologies representative in your area or call the factory at the numbers listed below for a Return Material Authorization (RMA) number.

Meriam Process Technologies
10920 Madison Ave.
Cleveland, OH 44102
Ph. (216) 281-1100 FAX (216) 281-0228

If certificate of NIST traceability is required, please be sure to request this service at time of repair.

www.meriam.com

Page 21 of 21



205 Westwood Ave
Long Branch, NJ 07740
1-877-742-TEST (8378)
Fax: (732) 222-7088
salesteam@Tequipment.NET