

KIMP23 remote printer for classes 210 and 310 portable instrument



Technical features

Dimensions (without protective cover) : 85.5 mm x 150 mm x 55 mm
Weight (without protective cover) : 400 g
Operating temperature : from 0 to 50 °C
Storage temperature : from -20 to +60 °C

Print values during the measurement

- Press **On/Off** button of the printer to turn it on.
- Press **"Imprim"** function key of the portable instrument on the measurement screen.
Measurement results are printing on the ticket.
- Press **On/Off** button when printing is finished to turn the printer off.



In order to have a correct printing, infrared sensors of the printer and portable instrument must be face each other (see pictures above).



KIMP23 remote printer for classes 210 and 310 portable instrument



Technical features

Dimensions (without protective cover) : 85.5 mm x 150 mm x 55 mm
Weight (without protective cover) : 400 g
Operating temperature : from 0 to 50 °C
Storage temperature : from -20 to +60 °C

Print values during the measurement

- Press **On/Off** button of the printer to turn it on.
- Press **"Imprim"** function key of the portable instrument on the measurement screen.
Measurement results are printing on the ticket.
- Press **On/Off** button when printing is finished to turn the printer off.




In order to have a correct printing, infrared sensors of the printer and portable instrument must be face each other (see pictures above).




Change the paper roll

- > Raise the upper part of the printer pulling up the transparent part.
- > Put a new paper roll (Both sides of the paper are different : the brightest side is the printed side and must faced the user).
- > Pull up about 0.50 cm of paper.
- > Close the upper part of the printer.



Change the batteries

- > Remove the protective cover of the printer.
- > Remove the batteries cover.
- > Remove the used batteries.
- > Put some new 1.5V LR6 AA batteries observing proper polarity.
- > Put the battery cover.



LED indications

The LED above the On/Off button has several meanings :

- > Continuous green : printer turned on and ready to operate
- > Sequence of one flash : paper is missing or there is not any paper out the printer → put a paper roll or let 0.5 cm of paper out
- > Sequence of 2 flashes : thermal too hot → let the head cool down
- > Sequence of 3 flashes : discharged → change batteries


www.kimo.fr

EXPORT DEPARTMENT
Boulevard de Beaubourg - Emerainville - BP 48
77312 MARNE LA VALLEE CEDEX 2
Tel : + 33.1.60.06.69.25 - Fax : + 33.1.60.06.69.29




Change the paper roll

- > Raise the upper part of the printer pulling up the transparent part.
- > Put a new paper roll (Both sides of the paper are different : the brightest side is the printed side and must faced the user).
- > Pull up about 0.50 cm of paper.
- > Close the upper part of the printer.



Change the batteries

- > Remove the protective cover of the printer.
- > Remove the batteries cover.
- > Remove the used batteries.
- > Put some new 1.5V LR6 AA batteries observing proper polarity.
- > Put the battery cover.



LED indications

The LED above the On/Off button has several meanings :

- > Continuous green : printer turned on and ready to operate
- > Sequence of one flash : paper is missing or there is not any paper out the printer → put a paper roll or let 0.5 cm of paper out
- > Sequence of 2 flashes : thermal too hot → let the head cool down
- > Sequence of 3 flashes : discharged → change batteries

www.kimo.fr

EXPORT DEPARTMENT
Boulevard de Beaubourg - Emerainville - BP 48
77312 MARNE LA VALLEE CEDEX 2
Tel : + 33.1.60.06.69.25 - Fax : + 33.1.60.06.69.29

