

**UM Series
Uni-Lift® NEMA C-Face Electric Motors**

L3000 Rev. A 04/10

1.0 IMPORTANT RECEIVING INSTRUCTIONS

Visually inspect all components for shipping damage. Shipping damage is **not** covered by warranty. If shipping damage is found, notify carrier at once. The carrier is responsible for all repair and replacement costs resulting from damage in shipment.

2.0 SAFETY



WARNING: Lockout power to electric motor before beginning installation procedures or before performing any adjustments, maintenance or repairs. Be certain that the motor cannot be automatically started. Failure to observe these precautions may result in serious personal injury or death!

- Follow appropriate safety precautions to avoid personal injury or property damage during motor installation and operation. Enerpac cannot be responsible for damage or injury resulting from unsafe product use, lack of maintenance or incorrect product and/or system operation.
- The UM Series motor does not contain a brake and is not a locking or load holding device. Contact Enerpac if an integral motor brake is required for your application.
- The UM Series motor is not explosion proof, and must not be used in environments which require an explosion proof motor. If needed, an explosion proof motor can be special ordered from Enerpac.
- Be sure that motor is wired for proper voltage. See motor nameplate for wiring instructions.
- Stay clear of moving and rotating parts driven by the motor. Install guards as required (See additional information in Section 3.0).
- Contact Enerpac before incorporating Uni-Lift® products into a man lift or other people moving device (special design requirements apply).

3.0 INSTALLATION

- The motor is manufactured by an Enerpac approved supplier. Manufacturer's instructions may be packed inside the shipping carton. If present, read and follow these instructions during installation procedures.
- The motor must be properly sized for the Uni-Lift® actuator model being used. Be sure that the motor is specified in accordance with the stated requirements and precautions contained in the *Enerpac Uni-Lift® Actuators Catalog #E500*.
- Be certain that the motor coupling (if used) is properly installed and that the coupling set screws are tight.
- Check that the motor is securely mounted and properly aligned. Be sure mounting bolts are tight.
- Install limit switches (sold separately) as required.

IMPORTANT: Enerpac recommends the use of limit switches or other appropriate controls to stop the motor when the actuator has reached its fully extended or retracted position. The use of solid mechanical stops alone is not recommended. Their continued



use can cause severe damage to the Uni-Lift® actuator and other components in the system. Limit switches are available from Enerpac as accessories.

- Be certain that the motor is properly wired and grounded in accordance with all applicable codes and regulations. Allow only trained and qualified electricians to wire and install the motor, limit switches and other related electrical equipment.
- Comply with and adhere to all applicable safety codes for your area, such as: building codes, elevator codes, AISC Steel Construction specifications, and applicable regulations and standards (including OSHA Title 29, Chapter 1910-219 and ANSI B15.1). **Note:** Applicable safety codes, regulations and standards will vary depending on country and local requirements.
- Test for proper operation before placing the Uni-Lift® system into service. Check for any indications of misalignment, binding or loose components. Verify proper shaft rotation.
- Contact Enerpac or your Enerpac distributor there are any questions or concerns regarding installation of the motor or any related equipment.

4.0 MAINTENANCE

- Permanently lubricated motors will not require additional lubrication under normal conditions. If the motor is equipped with grease fittings, perform lubrication in accordance with the motor manufacturer's recommendations.
- Keep the motor clean. Periodically wipe it down to remove any loose dirt or grease. Remove any dust or dirt from motor fan vents (if present).
- Periodically check the motor mounting bolts for tightness.
- If problems such as excessive heat or unusual noises are noticed, stop operation immediately. Determine the cause(s) of the problem and take appropriate corrective action(s) before resuming operation.
- Do not attempt to disassemble the motor. Disassembly, modification or tampering will void warranty. Inspection and repairs should be performed only by an authorized manufacturer's service center.

5.0 WARRANTY

- Electric motors are covered by the motor manufacturer's standard warranty (Enerpac warranty is NOT applicable).

Enerpac Worldwide Locations

◆ e-mail: info@enerpac.com

◆ internet: www.enerpac.com

Africa

ENERPAC Middle East FZE
Office 423, JAFZA 15
P.O. Box 18004
Jebel Ali, Dubai
United Arab Emirates
Tel: +971 (0)4 8872686
Fax: +971 (0)4 8872687

Australia, New Zealand Actuant Australia Ltd.

Block V Unit 3
Regents Park Estate
391 Park Road
Regents Park NSW 2143
(P.O. Box 261) Australia
Tel: +61 297 438 988
Fax: +61 297 438 648

Brazil

Power Packer do Brasil Ltda.
Rua dos Inocentes, 587
04764-050 - Sao Paulo (SP)
Tel: +55 11 5687 2211
Fax: +55 11 5686 5583
Toll Free in Brazil:
Tel: 0800 891 5770
vendasbrasil@enerpac.com

Canada

Actuant Canada Corporation
6615 Ordan Drive, Unit 14-15
Mississauga, Ontario L5T 1X2
Tel: +1 905 564 5749
Fax: +1 905 564 0305
Toll Free:
Tel: +1 800 268 4987
Fax: +1 800 461 2456
Technical Inquiries:
techservices@enerpac.com

China

Actuant Industries Co. Ltd.
No. 6 Nanjing Road
Taicang Economic Dep Zone
Jiangsu, China
Tel: +86 0512 5328 7529
+86 0512 5328 7500 7529
Fax: +86 0512 5335 9690

Actuant China Ltd. (Peking)

709B Diyang Building
Xin No. 2
Dong San Huan North Rd.
Beijing City
100028 China
Tel: +86 10 845 36166
Fax: +86 10 845 36220

France, Switzerland francophone

ACTUANT - ENERPAC
France S.A., ZA de Courtaboeuf
32, avenue de la Baltique
91140 Villebon / Yvette
France
Tel: +33 1 60 13 68 68
Fax: +33 1 69 20 37 50

Germany, Austria, Switzerland, Greece, Baltic States, Central and Eastern Europe

ENERPAC GmbH
P.O. Box 300113
D-40401 Düsseldorf
Willstätterstrasse13
D-40549 Düsseldorf
Germany
Tel: +49 211 471 490
Fax: +49 211 471 49 28

India

ENERPAC Hydraulics
(India) Pvt. Ltd.
No. 1A,
Peenya Industrial Area,
IInd Phase
Bangalore, 560 058 India
Tel: +91 80 40 792 777
Fax: +91 80 40 792 792

Italy

ENERPAC S.p.A.
Via Canova 4
20094 Corsico (Milano)
Tel: +39 02 4861 111
Fax: +39 02 4860 1288

Japan

Applied Power Japan LTD KK
Besshochou 85-7
Kita-ku,
Saitama-shi 331-0821
Japan
Tel: +81 48 662 4911
Fax: +81 48 662 4955

Middle East, Turkey and Caspian Sea

ENERPAC Middle East FZE
Office 423, JAFZA 15
P.O. Box 18004
Jebel Ali, Dubai
United Arab Emirates
Tel: +971 (0)4 8872686
Fax: +971 (0)4 8872687

Russia and CIS (excl. Caspian Sea Countries)

Actuant LLC
Admiral Makarov Street 8
125212 Moscow, Russia
Tel: +7-495-9809091
Fax: +7-495-9809092

Sweden, Denmark, Norway, Finland and Iceland

ENERPAC Scandinavia AB
Fabriksgatan 7
412 50 Gothenburg
Sweden
Tel: +46 31 7990281
Fax: +46 31 7990010
scandinavianinquiries@enerpac.com

Singapore

Actuant Asia Pte. Ltd.
37C, Benoi Road Pioneer Lot,
Singapore 627796
Tel: +65 68 63 0611
Fax: +65 64 84 5669
Toll Free: +1800 363 7722
Technical Inquiries:
tech.service-sg@enerpac.com

South Korea

Actuant Korea Ltd.
3Ba 717,
Shihwa Industrial Complex
Jungwang-Dong, Shihung-Shi,
Kyunggi-Do
Republic of Korea 429-450
Tel: +82 31 434 4506
Fax: +82 31 434 4507

Spain and Portugal

ENERPAC SPAIN, S.L.
Avda. Los Frailes, 40 – Nave C
& D
Pol. Ind. Los Frailes
28814 DAGANZO DE ARRIBA
(Madrid)
Spain
Tel: +34 91 884 86 06
Fax: +34 91 884 86 11

Sweden, Denmark, Norway, Finland and Iceland

Enerpac Scandinavia AB
Fabriksgatan 7
412 50 Gothenburg
Sweden
Tel: +46 (0) 31 7990281
Fax: +46 (0) 31 7990010
Inquiries:
Scandinavianinquiries@enerpac.com

The Netherlands, Belgium, Luxembourg

ENERPAC B.V.
Galvanistraat 115, 6716 AE Ede
P.O. Box 8097, 6710 AB Ede
The Netherlands
Tel: +31 318 535 800
Fax: +31 318 525 613
+31 318 535 848
beneluxinquiries@enerpac.com
Technical Inquiries Europe:
techsupport.europe@enerpac.com

United Kingdom, Ireland Enerpac Ltd

Bentley Road South
Darlaston, West Midlands
WS10 8LQ, United Kingdom
Tel: +44 (0)121 50 50 787
Fax: +44 (0)121 50 50 799

USA, Latin America and Caribbean

ENERPAC
P.O. Box 3241
6100 N. Baker Road
Milwaukee, WI 53209 USA
Tel: +1 262 781 6600
Fax: +1 262 783 9562

User inquiries:

+1 800 433 2766

Inquiries/orders:

+1 800 558 0530

Technical Inquiries:

techservices@enerpac.com

ENERPAC

704 W. Simonds
Dallas, TX 75159 USA
Tel: +1 972 287 2390
Fax: +1 972 287 4469

09/30/09

All Enerpac products are guaranteed against defects in workmanship and materials for as long as you own them. For your nearest authorized Enerpac Service Center, visit us at www.enerpac.com