

# Fox Thermal Instruments, Inc.

**THERMAL MASS FLOW METER & TEMPERATURE TRANSMITTER**



***Model FT1***



## Notice

*This publication must be read in its entirety before performing any operation. Failure to understand and follow these instructions could result in serious personal injury and/or damage to the equipment. Should this equipment require repair or adjustment beyond the procedures given herein, contact the factory at:*

**FOX THERMAL INSTRUMENTS, INC.  
399 RESERVATION ROAD  
MARINA, CA 93933  
TELEPHONE: 831-384-4300  
FAX: 831-337-5787  
EMAIL: [SERVICE@FOXTHERMALINSTRUMENTS.COM](mailto:SERVICE@FOXTHERMALINSTRUMENTS.COM)**

**Download Technical Data Sheets from our website:  
[www.foxthermalinstruments.com](http://www.foxthermalinstruments.com)**

**Fox Thermal Instruments believes that the information provided herein is accurate; however, be advised that the information contained herein is NOT a guarantee for satisfactory results. Specifically, this information is neither a warranty nor guarantee, expressed or implied, regarding performance, merchantability, fitness, or any other matter with respect to the products; nor recommendation for the use of the product/process information in conflict with any patent. Please note that Fox Thermal Instruments, Inc. reserves the right to change and/or improve the product design and specification without notice.**



**Fox FT1 Manuals:**  
• **Fox FT1 View™ Manual**

*All Fox Manuals and software available in English only.*


# Table Of Contents

|                                                                |         |
|----------------------------------------------------------------|---------|
| 1. Introduction                                                | Page 4  |
| a. Menu Trees                                                  | Page 4  |
| b. Quick Start Guide                                           | Page 12 |
| 2. Installation (Mechanical)                                   | Page 16 |
| a. Installation Depth                                          | Page 18 |
| b. Orientation of Flowmeter                                    | Page 19 |
| c. Rotating the Probe/Enclosure                                | Page 20 |
| d. Sensor Elements                                             | Page 20 |
| e. Changing the Orientation of the Display                     | Page 22 |
| f. Mounting Instructions                                       | Page 20 |
| 3. Wiring (Electrical)                                         | Page 21 |
| a. General Wiring                                              | Page 22 |
| b. Input Power                                                 | Page 22 |
| c. Signal Wiring                                               | Page 23 |
| d. Pulse/Alarm Wiring (optional feature)                       | Page 25 |
| e. RS485 Wiring: Modbus RTU or BACnet MS/TP (optional feature) | Page 27 |
| 4. Operation (Standard Operation)                              | Page 28 |
| a. Start Up                                                    | Page 28 |
| b. Programming                                                 | Page 30 |
| c. Zero CAL-CHECK®                                             | Page 46 |
| d. Gas-SelectX®                                                | Page 50 |
| 5. Communication Protocols                                     | Page 55 |
| a. RS485 Modbus RTU Introduction                               | Page 55 |
| b. FT1 Commands Supported by Modbus                            | Page 56 |
| c. Modbus Programming                                          | Page 60 |
| d. BACnet MS/TP Introduction                                   | Page 63 |
| e. BACnet MS/TP Programming                                    | Page 66 |
| 6. Maintenance                                                 | Page 68 |
| a. Precautions                                                 | Page 68 |
| b. General                                                     | Page 69 |
| c. Troubleshooting                                             | Page 70 |
| 7. Appendices                                                  | Page 75 |
| a. Specifications                                              | Page 75 |
| b. Agency Approvals                                            | Page 77 |
| c. Dimensions                                                  | Page 78 |
| d. Warranty                                                    | Page 79 |
| e. Returning your meter                                        | Page 80 |
| 8. Glossary of Terms and Abbreviations                         | Page 82 |
| 9. Index                                                       | Page 83 |

## Introduction: Menu Trees

### Main Menu


Fig. 1.1: FT1 Menu Tree - Main Menu



## Introduction: Menu Trees

## Digital Output


Fig. 1.2: FT1 Menu Tree - Digital Output



(See Flow Menu 2, p. 7, for more alarm settings)

## Flow Menu 1


*Fig. 1.3: FT1 Menu Tree - Flow Menu 1*



## Introduction: Menu Trees

## Flow Menu 2


Fig. 1.4: FT1 Menu Tree - Flow Menu 2



# Introduction: Menu Trees

## Display Menu

Fig. 1.5: FT1 Menu Tree - Display Menu




### Note: All readings updated every second

- Flo Rate = Flow rate of process gas
- Total = Total flow of process gas
- Elps = Elapsed time since reset of flow total
- Temp = Temperature of process gas
- Alarm = Notification of errors; diagnostic errors

# Introduction: Menu Trees

## Zero CAL-CHECK® Menu


Fig. 1.6: FT1 Menu Tree - Zero CAL-CHECK® Menu



## Introduction: Menu Trees

## Gas-SelectX® Menu

Fig. 1.7: FT1 Menu Tree - Gas-SelectX® Menu




The most recent list of available gases can be found on the Fox website:  
[www.foxthermalinstruments.com](http://www.foxthermalinstruments.com)

# Introduction: Menu Trees


## Engineering Display

Fig. 1.8: FT1 Menu Tree - Engineering Display


Enter: Press F1 & F2 at the same time  
Press F4 to return to normal mode



F1 Key



F2 Key








F3 & F4 pressed at the same time will  
initiate a "Total" reset

# Introduction: Quick Start Guide

Use the table and images below as a guide while using the worksheet on the next page to record your notes.

**Note:** Please read the entire Quick-start procedure before beginning installation.

|    |                                                                                                                                                                                                                                                                                                                 |                                                                                                                                                                                                                                                                                                           |
|----|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 1. | Record inside diameter (ID). Ensure the actual pipe ID matches the pipe ID shown on the factory calibration certificate. If IDs do not match, refer to p. 41.                                                                                                                                                   |                                                                                                                                                                                                                         |
| 2. | Record upstream and downstream straight-pipe requirements based on Pipe ID.<br>[refer to p. 17 for more information]                                                                                                                                                                                            |                                                                                                                                                                                                                         |
| 3. | a. The Flow Direction Indicator must point in the direction of flow.<br>b. The Indicator can also be used to change the orientation of the housing for a better view of the meter's display. Note that the 2 set screws must be loosened before the housing will turn.<br>[refer to p. 18 for more information] | <br><b>FLOW</b> →<br><b>INDICATOR:</b><br>- POINT IN DIRECTION OF FLOW<br>- REMOVE TO ROTATE HOUSING ±90°, ±180°<br>- REPLACE INDICATOR WHEN DONE<br><b>LOOSEN HOUSING WITH 2 FRONT SET SCREWS, RETIGHTEN WHEN DONE</b> |
| 4. | Ensure correct probe depth setting. If using 1 1/2" size pipe, please see note on p. 18.                                                                                                                                                                                                                        |                                                                                                                                                                                                                        |
| 5. | Open the housing. If needed, the orientation of display can be rotated in 90° increments for a better view of the display in tight installations.<br>[refer to p. 19 for more information]                                                                                                                      | <br><b>ACCESS DISPLAY BY UNSCREWING COVER</b><br><b>REMOVE SCREWS ON DISPLAY TO ROTATE DISPLAY ±180°</b>                                                                                                              |
| 6. | Ensure power wiring and 4 to 20mA wiring properly connected<br>[refer to p. 22 - p. 24 for more information]                                                                                                                                                                                                    |                                                                                                                                                                                                                       |
| 7. | Verify you have the proper output signal wiring setup based on model type (Pulse/Alarm or communication protocol)<br>[refer to p. 25 - p. 27 for more information]                                                                                                                                              |                                                                                                                                                                                                                       |
| 8. | Power on the flow meter                                                                                                                                                                                                                                                                                         |                                                                                                                                                                                                                       |
| 9. | Check the remaining flow meter settings by accessing the meter settings either through the front panel of the display or by using the FT1 View™ software tool. Record the settings in the spaces given for items A - E on the following page.                                                                   |                                                                                                                                                                                                                                                                                                           |

# Introduction: Quick Start Guide

Before powering on your meter, use this worksheet to record your notes.

|                                                                                                                                                                                             | Item to verify                                                                                                   | Serial Number:  | Serial Number:  | Serial Number:  | Serial Number:  |
|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------|-----------------|-----------------|-----------------|-----------------|
| 1.                                                                                                                                                                                          | What is the Pipe ID?                                                                                             | ID =            | ID =            | ID =            | ID =            |
| 2.                                                                                                                                                                                          | Calculate the Upstream/<br>Downstream straight-pipe<br>requirements                                              | UP =<br>DN =    | UP =<br>DN =    | UP =<br>DN =    | UP =<br>DN =    |
| 3.                                                                                                                                                                                          | a. Is the flow indicator<br>pointed in direction of flow?<br>b. Must the housing be<br>rotated for easy viewing? | Y / N<br>Y / N  | Y / N<br>Y / N  | Y / N<br>Y / N  | Y / N<br>Y / N  |
| 4.                                                                                                                                                                                          | Is the probe depth setting<br>correct?                                                                           | Y / N           | Y / N           | Y / N           | Y / N           |
| 5.                                                                                                                                                                                          | Have you rotated the display<br>for easier viewing?                                                              | Y / N           | Y / N           | Y / N           | Y / N           |
| 6.                                                                                                                                                                                          | Verify proper power wiring<br>setup                                                                              |                 |                 |                 |                 |
| 7.                                                                                                                                                                                          | Verify proper output wiring<br>setup                                                                             |                 |                 |                 |                 |
| <p>After powering on your meter, check items A - E below by accessing the meter settings either through the front panel of the meter's display or by using the FT1 View™ software tool.</p> |                                                                                                                  |                 |                 |                 |                 |
| A.                                                                                                                                                                                          | Which flow units have been<br>set in meter? (SCFM, KG/H,<br>etc..)                                               |                 |                 |                 |                 |
| B.                                                                                                                                                                                          | Correct values for reference<br>temperature and pressure?                                                        | Y / N           | Y / N           | Y / N           | Y / N           |
| C.                                                                                                                                                                                          | Confirm the pipe ID listed<br>above same as "Pipe_id="                                                           |                 |                 |                 |                 |
| D.                                                                                                                                                                                          | Verify the 4mA and 20mA<br>meter settings                                                                        | 4mA =<br>20mA = | 4mA =<br>20mA = | 4mA =<br>20mA = | 4mA =<br>20mA = |
| E.                                                                                                                                                                                          | Confirm the correct gas is<br>selected for your application<br>in the Gas-SelectX® menu                          |                 |                 |                 |                 |

Your Notes:

If you are experiencing any problems after completing this procedure, please call the Fox Service Department at 831-384-4300 to review this information.

# Introduction

## Welcome

Thank you for purchasing the Model FT1 Thermal Gas Mass Flow Meter from Fox Thermal Instruments. The Model FT1 is one of the most technically advanced flow meters in the world. Extensive engineering effort has been invested to deliver advanced features, accurate measurement performance and outstanding reliability.

This Instruction Manual contains the electrical and mechanical installation instructions as well as details for programming, maintaining and troubleshooting the meter. This manual is divided into the following sections: Introduction, Installation, Wiring, Operation, Maintenance, Troubleshooting, Appendices, Glossary and Index.

## Product Description

### Theory of Operation

The Model FT1 is an innovative Thermal Mass Gas Flow Meter and Temperature Transmitter. It is microprocessor-based and field programmable. The FT1 thermal sensor operates on the law that gases absorb heat. A heated sensor placed in an air or gas stream transfers heat in proportion to the stream's mass velocity. There are two sensor elements. One sensor element detects the gas temperature and a second element is maintained at a constant temperature above the gas temperature. The energy applied to the heated sensor to maintain a constant temperature differential (constant  $\Delta T$ ) is directly proportional to the mass flow velocity. The FT1 flow meter maintains accurate flow measurement over a large temperature and pressure range.

## Mass Flow

### Mass Flow

The Model FT1 measures mass flow; an advantage over other flow meters which measure volumetric flow rate. Volumetric flow is incomplete because temperature and pressure are unknown and must be measured separately. For example, the mass flow of a gas depends on its temperature and pressure. As temperature and pressure changes, the gas volume changes but not its mass. Therefore a device measuring mass flow is independent of temperature and pressure changes. The Model FT1 provides a direct measurement of gas flow in Mass units (kg/hr, lb/hr), standard units (SCFM, SLPM) or normal units (NM3/hr, NLPM) with no additional temperature or pressure measurements required.

## Flow Calibration

### Flow Calibration

The Fox Calibration Lab maintains instrument calibration data on every flow meter. Calibration files include details on process conditions, customer gas, line size and other information. All NIST-traceable equipment utilized for the calibration procedure is identified on the Calibration Certificate, which is sent with every flow meter.

## DDC-Sensor™ Technology

### DDC-Sensor™ Technology Description

The Fox DDC-Sensor™ is a new state of the art sensor technology used in the Fox Model FT1 Thermal Gas Flow Meter. The DDC-Sensor™, a Direct Digitally Controlled sensor, is unlike other thermal flow sensors available on the market. Instead of using traditional analog circuitry, the DDC-Sensor™ is interfaced directly to the FT1 microprocessor for more speed and programmability. The DDC-Sensor™ quickly and accurately responds to changes in process variables by utilizing the microprocessor to determine mass flow rate, totalized flow, and temperature.

# Introduction

Fox's DDC-Sensor™ provides a technology platform for calculating accurate gas correlations. The FT1 correlation algorithms allow the meter to be calibrated on a single gas in the factory while providing the user the ability to select other gases in the Gas-SelectX® gas menu. Fox's Model FT1 with its DDC-Sensor™ and state-of-the-art correlation algorithms provide an accurate, multi-gas-capable thermal gas flow meter.

## I/O Description

### I/O Description

The FT1 features a galvanically isolated 4 to 20mA analog output and a second output for pulse, RS485 Modbus RTU, or BACnet MS/TP. There is also a USB port for interfacing with a laptop or computer. The 4 to 20mA output can be configured for flow rate or process gas temperature and can be scaled by the user. The pulse output can be used for pulse or alarm, is programmable to represent flow rate and can be scaled for maximum flow/maximum frequency, units-per-pulse or pulse-per-units. The maximum frequency is 100 Hz.


FT1 View™ interfaces to the USB port and is a free PC-based software program that displays flow meter readings and permits flow meter configuration. The software is available for download on the Fox website. Industry standard communication options are available including optional RS485 Modbus RTU or BACnet MS/TP.

## Display

### FT1 Functional Diagram

An on-board 2 line x 16 character backlit LCD display shows flow rate, total flow, elapsed time, process gas temperature, and alarms. The display is also used in conjunction with the Configuration Panel for field configuration of flow meter settings such as 4 to 20mA scaling, frequency output scaling, pipe area, zero flow cutoff, flow filtering or dampening, display configurations, diagnostics, and alarm limits.

Fig. 1.9: FT1 Function Diagram



## Installation: General

### Installation - Model FT1 Flow Meter

#### Scope

This section describes how to install the Fox Model FT1 Flow Meter and how to get started:

1. Determine lateral position on the pipe
2. Sensor installation depth
3. Sensor orientation in relation to sensor length and direction of flow
4. Proper tightening of compression fitting for mounting meter

Installation procedures must be performed using a combination of the end user's best engineering practices, in compliance with local codes, and manufacturer's recommendations.



#### General Precautions

The following general precautions should be observed:

1. Exercise care when handling the flow meter to avoid damaging the probe, sensor or enclosure.
2. The enclosure cover must be closed except during installation or configuration.
3. Mounting FT1 in direct sunlight can cause the temperature inside the enclosure to increase beyond design limits, resulting in failure of LCD display and reduced component life. It is recommended that a sunshade be installed to avoid direct sunlight (see maximum enclosure operating temperature specification).
4. Ensure the flow direction indicator/pointer for the meter is in line with the direction of flow in the pipe.
5. Do not install the FT1 enclosure near an igniter, igniter-controller or switching equipment.
6. Do not install an external power supply in a cabinet containing an igniter controller or switching equipment.
7. For accurate flow measurement: review flow meter placement instructions before installation to ensure a proper flow profile in the pipe.
8. For safety reasons, Teflon ferrules are only appropriate for applications with pressures of 60 psig or less. At higher pressures, use of a Teflon ferrule risks unwanted probe movement or ejection of the probe from the pipe. For all applications above 60 psig, the standard stainless steel ferrule is required.

# Installation: Insertion Type

## Insertion Flow Meter Lateral Placement



### Instructions for Insertion Flow Meter Lateral Placement

Install the Model FT1 Insertion style flow meter so that it is far enough away from bends in the pipe, obstructions, or changes in line sizes to ensure a consistent flow profile. Fifteen diameters of straight pipe upstream and ten downstream are required.

For example, a 2" pipe would require 30" upstream and 20" downstream, but a 4" pipe would require 60" upstream and 40" downstream.

Note: The probe diameter is  $\frac{3}{4}$ ".

Fig. 2.1: Upstream and Downstream Pipe IDs for Insertion Meters



Note: An irregular flow profile may affect sensor accuracy.

### Special Conditions of Use:

- Consult the manufacturer if dimensional information on the flameproof joints is necessary.
- Follow the manufacturer's instructions to reduce the potential of an electrostatic charging hazard.


# Installation: Insertion Type

## Installation Depth

### Installation Depth

The installation depth of the sensor in the pipe is dependent on the pipe size. To get the most accurate reading, proper placement of the sensor window within the pipe is necessary. As shown in Fig 2.2, the end of the sensor window should be 0.73" (18.5 mm) past the center line of the pipe.

Fig. 2.2: Cross Section of Insertion Sensor Depth in Pipe



**Note:** For 1½" (40mm) pipes, insert the probe fully so that it reaches the bottom inside of the pipe, then lift up 0.1" (3mm) for proper depth setting.

## Rotating the Enclosure

### Rotating the Enclosure


The Model FT1 has been designed to allow the enclosure to rotate into four positions to allow better display views. To rotate the enclosure, first loosen the two set screws near the Flow Direction Indicator. Then unscrew and remove the Flow Direction Indicator to allow the enclosure to swivel into the desired position. Then screw the Flow Direction Indicator back into its place, ensure that it points in the direction of flow, and tighten the set screws.

## Installation: Insertion Type

Sensor  
Orientation -  
Direction of  
Flow

*Fig. 2.3: Orientation of Flow Meter*

Install the meter with the flow direction indicator pointing in the direction of flow in the pipe.




Changing  
Display  
Orientation

### Changing the Orientation of the FT1 Display


The display can be rotated in 90° increments for optimum viewing of the screen. First, open the enclosure by unscrewing the enclosure cap and loosen the two captive phillips screws to open the display assembly. Detach the display board from the metal shield by loosening the three screws on the back of the round shield. Rotate the display board to the desired orientation. Ensure that the display cable is routed flat and straight through the display hinge to prevent binding. Reattach the display board to the metal shield by tightening the three screws. Close the display assembly and secure it to the enclosure with the two captive screws. Finally, install the enclosure cover back on the front of the enclosure.

*Fig. 2.4 - Accessing Wiring Terminals or Rotating the Display*

Loosen these two screws to open the display and access wiring terminals.



Loosen these three screws to rotate the display in 90° increments ( $\pm 180^\circ$ ).




# Installation: Insertion Type

## Sensor Orientation - Sensor Elements

### Sensor Elements

Every FT1 flowmeter is equipped with equal length sensor elements. To be sure that the flowmeter elements are lined up correctly in the process stream, please refer to Figure 2.3 and be sure that the Flow Direction Indicator is pointing in the direction of flow in the pipe.

Fig. 2.5: Sensor Elements



Note: Rotational misalignment should not exceed  $\pm 5^\circ$ .




## Mounting Probe

### Mounting Instructions - Compression Fittings

The Model FT1 is mounted through a  $\frac{3}{4}$ " hole and a  $\frac{3}{4}$ " female NPT half coupling provided in the customer's pipe. Insertion style flow meters are not designed for use in pipes smaller than  $1\frac{1}{2}$ ".

- Install the compression fitting into the  $\frac{3}{4}$ -inch female NPT half coupling.
- When installing in a 2" pipe or larger, install the end of the probe 0.73" (18.5 mm) past the center line of the pipe and tighten the compression fitting nut (refer to figure 2.2 on p. 18).
- When installing into a  $1\frac{1}{2}$ " pipe carefully install the probe into the pipe until it touches the opposite wall and pull back 0.1". Tighten the compression fitting nut.
- While holding the fitting body steady, tighten the nut one and one-quarter ( $1\frac{1}{4}$ ) turn to the 9 o'clock position. See Figure 2.5.

Fig. 2.6: Proper Tightening of the Compression Fitting Nut



## Wiring: General



### Scope

**Caution:** Do not tighten compression fitting without .1" distance from wall or damage to probe will occur.

**Caution:** Once the compression fitting ferrule is locked onto the probe, the probe can be removed or rotated, but the insertion depth is locked in place.

**Note:** Do not overtighten the compression fitting.

### Wiring Instructions

To wire the FT1, unscrew and remove the enclosure cap. If the meter has the display option, loosen the two captive screws on the display assembly and rotate it open to access the wiring terminals. Connect the power and signal wires to the terminal blocks according to the label and instructions on the following pages.

Cut all wires as short as allowable for a minimum service loop. Obtain the correct length for the FT1 wires using one of these methods:

- Trim the wires to extend 2 inches out of the enclosure after the conduit and wires are routed to the FT1.
- Trim the wires to extend 5 inches from the end of the conduit before attaching them to the FT1.

### Precautions



### Wiring Precautions

- **WARNING - DO NOT OPEN THE ENCLOSURE WHEN ENERGIZED OR AN EXPLOSIVE ATMOSPHERE IS PRESENT.**
- All plumbing and electrical installations of flow meters must be in compliance with local codes, the end user's best engineering practices, and manufacturer's recommendations.
- Do not install the FT1 enclosure near an igniter, igniter-controller or switching equipment to eliminate the possibility of noise interference.
- Do not install an external power supply in a cabinet containing an igniter controller or switching equipment.
- This flow meter contains components that can be damaged by static electricity. You must discharge yourself by touching a grounded steel pipe or other grounded metal prior to working inside this flow meter.
- Close any unused conduit entries using suitably certified plugs

### Power Wiring

#### Power Wiring

For wiring the 12 to 28VDC power, use stranded copper wire, no larger than 16-gauge. Twisted pair shielded cable is recommended. Supply connection wiring must be rated for at least 90°C.

### Grounding

#### Grounding

The enclosure must be properly grounded with a quality earth ground. 16 gauge, stranded wire is recommended.

### Signal Wiring

#### Signal Wiring

For signal and serial communication wiring, the recommended wire gauge is 18 to 22 AWG. Always use twisted pair shielded cable.



## Wiring: Input Power

### Power Input Wiring

#### Power Input Requirements: 12 to 28VDC Supply


External DC power supply must provide 12 to 28VDC (10 to 30VDC full input power range) at 6 Watts minimum.

(With 12VDC power, the FT1 can use up to 500mA. With 24VDC power, the FT1 can use up to 250mA.)

A 20 Watt or greater power supply is recommended.

The enclosure must be properly grounded with a quality earth ground. Sixteen (16) gauge, stranded wire, is recommended for power and earth ground.

Fig. 3.1: Connections for 12 to 28VDC Supply



#### Caution:

- Supply connection wiring must be rated for at least 90°C.

# Wiring: Signal Wiring




4 to 20mA Loop  
Power Provided  
by Customer  
(Recommended)

## 4 to 20mA Output Wiring: Customer-Supplied Power Source

Bring the 4 to 20mA wiring in through either conduit hub. Connect 4 to 20mA wiring as shown in the diagram below.

Fig. 3.2: 4 to 20mA Output Wiring for Customer-Supplied Power Source



### Important Notes:

- When using a 12 volt power supply, the load resistor on the 4 to 20mA output must be 125 ohms or less to operate properly.
- When using 24 volt power, the load resistor is typically 250 ohms. A 250 ohm resistor in the 4 to 20mA circuit will result in a 1 to 5 volt signal to the PLC or DCS.
- When using a 24 volt power supply, the load resistor on the 4 to 20mA output must be 600 ohms or less.
- Some PLC and DCS equipment have built in load resistors, please refer to the technical manuals of such equipment.




## Wiring: Signal Wiring

4 to 20mA  
Loop Power  
Provided by FT1

### 4 to 20mA Output Wiring: Loop Power Provided by FT1

Bring the 4 to 20mA wiring in through either conduit hub. Connect the 4 to 20mA as shown in the diagram below.

Fig. 3.3: 4 to 20mA Output Wiring for Loop Power Provided by FT1



### Important Notes:

- When using a 12 volt power supply, the load resistor on the 4 to 20mA output must be 125 ohms or less to operate properly.
- When using 24 volt power, the load resistor is typically 250 ohms. A 250 ohm resistor in the 4 to 20mA circuit will result in a 1 to 5 volt signal to the PLC or DCS.
- When using a 24 volt power supply, the load resistor on the 4 to 20mA output must be 600 ohms or less.
- Some PLC and DCS equipment have built in load resistors, please refer to the technical manuals of such equipment.

## Wiring: Pulse/Alarm Wiring




### Pulse/Alarm Output Wiring:

#### Pulse/Alarm Output Wiring: Customer Supplied Power Source (Recommended)

Bring pulse/alarm wiring in through either conduit hub. Connect as shown in the diagram below. The pulse/alarm output is an open collector circuit capable of sinking a maximum of 10mA of current. Pulse or alarm selection is programmed using the display or FT1 View™. Only one option, pulse or alarm, can be active at a time.

Fig. 3.4: Pulse/Alarm Output Isolated (Recommended)



#### Important Notes:

- The FT1 Pulse/Alarm output is typically used to drive digital circuitry or solid-state relays. The output of a solid state relay may, in turn, operate loads such as electromechanical relays or alarm indicators.
- The maximum load current of the Pulse/Alarm output is 10mA. Choose a load resistance that provides approximately 10mA with the power supply operating voltage.
- When the output is configured for Alarm and an alarm is not active, the output will be on (0 volts output). When an alarm is active, the output will be off (12 to 28 volts output).
- In order to use the Pulse/Alarm feature on the Model FT1, this feature must be chosen when the meter is ordered from the factory. Pulse output not available with meters ordered with RS485 Modbus RTU or BACnet MS/TP.




## Wiring: Pulse/Alarm Wiring

### Pulse/Alarm Output Wiring

#### Pulse/Alarm Output Wiring: Power Provided by FT1

Bring pulse/alarm wiring in through either conduit hub. Connect as shown in the diagram below. The pulse/alarm output is an open collector circuit capable of sinking a maximum of 10mA of current. Pulse or alarm selection is programmed using the display or FT1 View™. Only one option, pulse or alarm, can be active at a time.

Fig. 3.5: Pulse/Alarm Output Power Provided by FT1



#### Important Notes:

- The FT1 Pulse/Alarm output is typically used to drive digital circuitry or solid-state relays. The output of a solid state relay may, in turn, operate loads such as electromechanical relays or alarm indicators.
- The maximum load current of the Pulse/Alarm output is 10mA. Choose a load resistance that provides approximately 10mA with the power supply operating voltage.
- When the output is configured for Alarm and an alarm is not active, the output will be on (0 volts output). When an alarm is active, the output will be off (12 to 28 volts output).
- In order to use the Pulse/Alarm feature on the Model FT1, this feature must be chosen when the meter is ordered from the factory. Pulse output not available with meters ordered with RS485 Modbus RTU or BACnet MS/TP.

## Wiring: RS485 Modbus RTU or BACnet MS/TP



## RS485 Wiring

**RS485 Wiring for RS485 Modbus RTU or BACnet MS/TP**


Wiring connections are made as shown in the diagram below for Modbus communication.

**Termination Resistor**

Connect a termination resistor across the receive/transmit signals of the last device on the communication line. To connect the 121 ohm termination resistor on the FT1, set jumper W1 to the TERM position.

Disconnect the termination resistor on all other external RS485 devices. The termination resistor of the FT1 is disconnected by setting jumper W1 to the OPEN position.

Fig. 3.6: RS485 Wiring

**Important Note:**

- In order to use the RS485 feature on the Model FT1, this feature must be chosen when the meter is ordered from the factory. Modbus RTU and BACnet MS/TP are not available with meters ordered with the Pulse/Alarm option.
- W1 jumper will either be in the open or terminated position. It should be in the terminated position on the last meter in the series.



## Operation: Start Up

### Start Up Sequence

#### Start Up Sequence

The program automatically enters the Run/Measure mode after power up. The screen will show the software version of the FT1 during power up.

### USB Interface

#### USB Interface

The USB interface is a standard feature which allows communication with a PC to monitor readings and configure settings. FT1 View™, is a free application program from Fox that connects to the USB interface and allows data monitoring, configuration setting, data logging to Excel, and an option to save and recall FT1 configuration data.


### FT1 Display

#### FT1 Display and Configuration Panel

The FT1 has a 2 line x 16 character display with 4 mechanical buttons. The meter can be programmed by using the display and configuration panel. The configuration panel can be accessed by removing the FT1 cap. Be sure to replace the cap after you are done configuring the FT1.



Fig. 4.1: FT1 Display and Configuration Panel



# Operation: Display Screens

## Display Screens

### Measurement Mode Display Screens

In the measurement mode, there are four different display screens (display 1, 2, 3 and a prompt screen to enter the programming mode). Two display screens are user programmable (refer to Display Setup p. 35). Scrolling through the display is accomplished by pressing the F1 or F2 key to view the next or previous screen.


## Engineering Menu Screens

Pressing the F1 and F2 keys at the same time enters the Engineering Menu screens (display 10 through 26). Key F4 is used to exit to Display screen #1.

## Reset Total Screen

Pressing the F3 and F4 keys at the same time brings up the Reset Total screen (see p. 42) prompt.

Fig. 4.2: FT1 Measurement Mode Display Screen Navigation



## Operation: Programming

### Programming by Display

#### Data Entry using the Display and Configuration Panel

There are 2 basic types of menu entries: one for changing value or string and one for selecting from a selection list.

#### Value or String

#### To Change a Value or String :

VALUE = 0.91234  
CHG OK

F1 F2 F3 F4

Press **CHG (F1)** key to change the value, **OK (F4)** to accept the value.

VALUE = 0.91234  
UP DN NXT OK

F1 F2 F3 F4

Press the **UP (F1)** or **DN (F2)** key to select a new digit or character, the cursor points to the selected digit. Press **NXT (F3)** to select the next digit and **OK (F4)** to accept the entry.

#### Selecting from a List To Select from a List:

FLO UNT = SCFM  
NXT OK

F1 F2 F3 F4

Press **NXT (F1)** key repeatedly until the correct selection is made and **OK (F4)** key to accept the entry.

### Enter Programming Mode

#### Entering the Programming Mode

To enter the programming mode and access the Main Menu, press the **F1** or **F2** key in the normal running mode until the following screen is shown:

SET PARAMETERS ?  
No Yes

F1 F2 F3 F4

Press **YES (F4)** and the following screen will prompt user to enter password:

PASWD:\_  
UP DN NXT OK

F1 F2 F3 F4

## Operation: Programming

### Programming by Display

Enter the correct password, then follow the instructions for changing a value as specified on page p. 30. The default Level 1 password is “1234”.

If the wrong password is entered, the message “Wrong Password” will display and then return to the programming entry screen.

### Main Menu

#### Main Menu

If the password is accepted, the Main Menu screen will be shown:

|           |     |     |      |
|-----------|-----|-----|------|
| MAIN MENU |     |     |      |
| I/O       | FLO | DSP | EXIT |
| F1        | F2  | F3  | F4   |

This is the Main Menu screen for the programming mode.

Press **EXIT (F4)** repeatedly until “Normal Mode” is seen briefly to exit the programming mode.

### Analog 4 to 20mA Output

#### Analog 4 to 20mA Output

The following menu allows the scaling of the analog 4 to 20mA output.

From the Main Menu, press **I/O (F1)** and then in the next screen press **420 (F3)**.

|     |     |      |
|-----|-----|------|
| SET | I/O |      |
| COM | 420 | EXIT |
| F1  | F2  | F3   |

 or
 

|     |     |      |
|-----|-----|------|
| SET | I/O |      |
| OUT | 420 | EXIT |
| F1  | F2  | F3   |

The 4 to 20mA output is programmable for flow or temperature:

|         |    |
|---------|----|
| mA=Flow |    |
| NXT     | OK |
| F1      | F2 |

Selections for the 4 to 20mA output are:

Flow  
Temp

Select **NXT (F1)** to select Flow or Temperature and then press **OK (F4)**.

|                   |    |
|-------------------|----|
| 20 mA = 3500 SCFM |    |
| CHG               | OK |
| F1                | F2 |

Enter the value for the 20mA and press **OK (F4)** key to accept the setting.

## Operation: Programming

Programming  
by Display

Then the following screen will display:

|               |    |
|---------------|----|
| 4 mA = 0 SCFM |    |
| CHG           | OK |

F1
F2
F3
F4

Enter the value for the 4mA and press **OK (F4)**.

Note: 4mA is normally set to 0.



|                    |    |
|--------------------|----|
| mA Fault = Not use |    |
| NXT                | OK |

F1
F2
F3
F4

This menu allows the user to select an alarm fault level on the 4 to 20mA output. The alarm is activated when a serious issue is detected preventing the calculation of the correct flow rate. The 3.6mA and 21mA alarm outputs are related to the NAMUR alarm feature.

The options are:

mA Fault=3.6 mA (Force the 4 to 20mA signal to 3.6mA on alarm)

mA Fault=21 mA (Force the 4 to 20mA signal to 21mA on alarm)

mA Fault=Not use (4 to 20mA signal alarm fault not used)

From any screen, press **(F4)** repeatedly until "Normal Mode" is seen briefly to exit the programming mode.



Pulse/alarm  
Output

Note: When the flow rate exceeds the programmed value for the 20mA set point, the analog output will stay at 20mA and an alarm code will be generated.

### Pulse/alarm Output

If the Pulse/alarm feature was purchased as the second output for the Model FT1, it can be accessed from the main menu, press **I/O (F1)**.

|     |     |      |
|-----|-----|------|
| SET | I/O |      |
| PUL | 420 | EXIT |

F1
F2
F3
F4

Press **PUL (F1)** to select the pulse output. The following screen will show:

|             |    |
|-------------|----|
| OUT = Pulse |    |
| NXT         | OK |

F1
F2
F3
F4

Press **NEXT (F1)** to cycle through output options until you have the selection for "OUT=Pulse" and press **OK (F4)**.

# Operation: Programming

## Programming by Display

The pulse output can be configured in one of three ways:

1. Specifying how many pulses per unit, P/U (i.e., 10 pulses per SCF)
2. Specifying how many flow units total per pulse, U/P (i.e., 0.1 SCF per pulse)
3. Specifying a maximum frequency to a defined maximum value of flow rate

All of these approaches are equivalent.

|              |     |     |      |
|--------------|-----|-----|------|
| Pulse OUTPUT |     |     |      |
| P/U          | U/P | FEQ | EXIT |
| F1           | F2  | F3  | F4   |

Use **P/U (F1)** to enter pulse per unit, **U/P (F2)** for unit per pulse or **FEQ (F3)** to enter the flow and maximum frequency to scale the pulse/alarm output.

Note: When data is entered with any of the three described methods, the other values will be re-calculated according to the settings.



### Pulse per Unit

#### Entering data in Pulse per Unit:

From the Pulse/alarm Output Menu above, press **P/U (F1)** and the following screen will show:

|             |    |
|-------------|----|
| PLS/UNT = 2 |    |
| CHG         | OK |
| F1          | F2 |
| F3          | F4 |

Press **CHG (F1)** to change the setting and then **OK (F4)** to accept entry.

The value entered is in pulse per selected flow unit total (i.e., 2 pulses per SCF).

### Unit per Pulse

#### Entering data in Unit per Pulse:

From the Pulse/alarm Output Menu, press **U/P (F2)** and the following screen will show:

|               |    |
|---------------|----|
| UNT/PLS = 0.5 |    |
| CHG           | OK |
| F1            | F2 |
| F3            | F4 |

Press **CHG (F1)** to change the setting and then **OK (F4)** to accept entry.

The value entered is in unit per pulse (i.e. 0.5 flow unit total per pulse)

### Max Flow and Frequency

#### Entering data with flow and maximum frequency:

From the Pulse/alarm Output Menu on p. 34, press **FEQ (F3)** and the following screen will show:

## Operation: Programming

Programming  
by Display

MaxFreq=100 Hz  
CHG OK

F1 F2 F3 F4

Enter the maximum pulse rate (frequency) and press **OK (F4)**.

Caution: Maximum pulse rate (frequency) cannot exceed 100 Hz.

The next screen will show:

MaxFlo=5000 SCFM  
CHG OK

F1 F2 F3 F4

Note: If the flow rate exceeds the maximum pulse rate (frequency), the output will stay at 100 Hz and the FT1 will issue an alarm code.



Alarm Output

### Alarm Output

If the Pulse/alarm feature was purchased as the second output for the Model FT1, press **I/O (F1)** key from the Main Menu screen.

The screen will show:.

|     |     |     |      |
|-----|-----|-----|------|
|     | SET | I/O |      |
| PUL |     | 420 | EXIT |

F1 F2 F3 F4

Then press **PUL (F1)** and the screen may show:

OUT = HiFloAlm  
NXT OK

F1 F2 F3 F4

Then press **NXT (F1)** to select the correct alarm and press **OK (F4)**.

Selections are:

Not used

Pulse

HiFloAlm = High Flow Alarm

LoFloAlm = Low Flow Alarm

HiTempAlm = High Temperature Alarm

LoTempAlm = Low Temperature Alarm

When the output is set to Alarm and there is no alarm condition, the output will be on (0 volts). When an alarm is active, the output is turned off (12 to 24 volts).

# Operation: Programming

## Programming by Display

HiFloAlm=500 SCFM  
CHG OK

F1 F2 F3 F4

Enter the value for the limit by pressing **CHG (F1)** and then **OK (F4)**.

Note: There is only one output to operate as a pulse output or an alarm output. Both cannot operate at the same time.



## Serial Communication

### Serial Communication Settings

If RS485 Communication feature was purchased as the second output for the Model FT1, the Serial communication settings can be programmed by pressing **I/O (F1)** key from the Main Menu. The screen will show:

SET I/O  
COM 420 EXIT

F1 F2 F3 F4

Press **COM (F1)** to select Serial communication. The screen may show:

Comm=Modbus  
NXT OK

F1 F2 F3 F4

Options for serial communication are:

None  
MODBUS  
BACNET



## Display Setup

### Display Setup

Remember, there are four display screens that you can cycle through in normal operating mode (see Figure 4.2 on p. 29). Two of the four display screens are fixed and cannot be changed (displays #3 & 4). The other two screens are programmable to show the information that you prefer and is discussed in this section.

#### Display #1

DSP1L1  
DSP1L2

F1 F2 F3 F4

#### Display #2

DSP2L1  
DSP2L2

F1 F2 F3 F4

## Operation: Programming

Programming  
by Display

Selections are:

|        |                   |
|--------|-------------------|
| DSP1L1 | Display 1, Line 1 |
| DSP1L2 | Display 1, Line 2 |
| DSP2L1 | Display 2, Line 1 |
| DSP2L2 | Display 2, Line 2 |

### Programming Display Screens #1 & 2

#### To Program Display Screens #1 & 2:

From the Main Menu press **DSP (F3)** to select the display menu:

|                  |     |      |
|------------------|-----|------|
| DISPLAY/PASSWORD |     |      |
| DSP              | PSW | EXIT |

Press **DSP (F1)** key. The display will show:

|                   |    |
|-------------------|----|
| DSP1L1 = Flo rate |    |
| NXT               | OK |

These are the selections for the display #1 line #1.

Selections are:

|          |                      |
|----------|----------------------|
| Flo rate | Flow rate            |
| Total    | Total mass or volume |
| Elps     | Elapsed time         |
| Temp     | Temperature          |
| Alarm    | Error codes          |

When the selection is correct, press **OK (F4)** to accept. The display will then go through the same process for all 4 lines of the 2 programmable displays (DSP1L1, DSP1L2, DSP2L1 and DSP2L2).

After the last line of display 2 is accepted, the display will show the following menu:

|                 |    |
|-----------------|----|
| ALTERNATE = Off |    |
| NXT             | OK |

This menu allows you to alternate between menu display 1 and 2 every few seconds.

Selections are: On or Off

Press **OK (F4)** to accept selection.

Press **EXIT (F4)** repeatedly until "Normal Mode" is seen briefly to exit the programming mode.

# Operation: Programming

## Programming by Display

### Password

#### Password

There are two user level passwords, only **Level 1** is programmable and gives access to all the normal settings. The second password is used to allow access to calibration factors and should normally never be changed unless advised by the Fox service department, or to set a new password in the event that the user forgets the **Level 1** password.


Default **Level 1** password is “1234”, and **Level 2** password is “9111”.

The **Level 1** programmable password can be disabled by setting it to “0”.


From the Main Menu press **DSP (F3)** to select the display menu:

## Programming Password

### To Program the Password:



Press **PSW (F3)** key to select password.



This screen displays the current **Level 1** password.

Press **CHG (F1)** key to change the password and enter new value.

Press **OK (F4)** to accept new data and exit programming by pressing **EXIT (F4)** key repeatedly until out of the programming mode.

Note: Password can be number or letter characters up to 4 digits.



## Units Settings Menu

### Units Settings Menu

This menu is used to set the units for flow, temperature, and pressure. Reference temperature and reference pressure settings can be accessed also.

These values will be set at Fox using information supplied by the customer. These values can be changed to match a new application. The units setting is accessed from the Main Menu.

To access the Unit Settings Menu:

# Operation: Programming

Programming  
by Display

|           |     |     |      |
|-----------|-----|-----|------|
| MAIN MENU |     |     |      |
| I/O       | FLO | DSP | EXIT |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

Press **FLO (F2)**:

|             |     |     |      |
|-------------|-----|-----|------|
| FLOW MENU 1 |     |     |      |
| DGN         | UNT | FM2 | EXIT |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

Flow Units

Press **UNT (F2)** for Unit selection.

The screen will show:

|            |    |
|------------|----|
| FLO = SCFM |    |
| NXT        | OK |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

Press **NXT (F1)** to change selection and **OK (F4)** to accept.



Note: The totalizer (total flow measured) will roll over when reaching a certain value. The maximum value is dependent on the flow units selected (see Totalizer Rollover p. 42).

Selections for flow units are:

|       |                |                |
|-------|----------------|----------------|
| SCFM  | LBS/M          | MSCFD (MCFD)   |
| SCFH  | LBS/S          | SM3/H          |
| NM3/H | NLPH           | MT/H           |
| NM3/M | NLPM           | NM3/D          |
| KG/H  | MMSCFD (MMCFD) | MMSCFM (MMCFM) |
| KG/M  | LBS/D          | SCFD           |
| KG/S  | SLPM           | MCFD (MSCFD)   |
| LBS/H | NLPS           | SM3/M          |
|       |                | SM3/D          |



## WARNING:

The FT1 re-calculates area, 4 and 20mA values, maximum flow for the pulse output and zero flow cutoff when changing flow units.

# Operation: Programming

## Programming by Display

### Temperature Units

After pressing **OK (F4)** to accept the Flow unit the display will prompt for the temperature unit setting:

|                |  |    |
|----------------|--|----|
| TMP UNT= Deg F |  | OK |
| NXT            |  |    |

F1
F2
F3
F4

Press **NXT (F1)** to change selection and **OK (F4)** to accept.

Selections for Temperature units are:

Deg C

Deg F

### Reference Temperature

After pressing **OK (F4)** to accept the temperature unit setting, the display will prompt for temperature reference in selected unit.

|                |  |    |
|----------------|--|----|
| TmpRef = 60 °F |  | OK |
| CHG            |  |    |

F1
F2
F3
F4

Press **CHG (F1)** to change the reference and **OK (F4)** to accept.

### Pressure Units

After pressing **OK (F4)** to accept the reference temperature, the display will prompt for the reference pressure unit selection:

|                |  |    |
|----------------|--|----|
| PRES UNT= Psia |  | OK |
| NXT            |  |    |

F1
F2
F3
F4

Press **NXT (F1)** to select next entry and OK (F4) to accept.

Selections are:

mmHG      Millimeters of mercury (absolute)

Psia      Pounds per square inch absolute

bara      Bar absolute

### Reference Pressure

After the pressure unit selection is made, the display will show a menu to enter the reference pressure:

|               |  |    |
|---------------|--|----|
| PresRef= 14.7 |  | OK |
| CHG           |  |    |

F1
F2
F3
F4

Press **CHG (F1)** to change it and **OK (F4)** to accept.

## Operation: Programming

### Programming by Display

#### Density

After the reference pressure is accepted, the FT1 will recalculate and display gas density at user's reference temperature and pressure:

|                    |    |       |
|--------------------|----|-------|
| DNS = 1.2930 KG/m3 |    | OK    |
| F1                 | F2 | F3 F4 |

The gas density is for information only. Press **OK (F4)** to continue.

### Flow Parameters

#### Flow Parameters

This is the menu used to set various flow parameter values. They are:  
Flow cutoff, pipe diameter, filter, high and low alarm for flow and temperature.

|           |     |     |      |
|-----------|-----|-----|------|
| MAIN MENU |     |     |      |
| I/O       | FLO | DSP | EXIT |
| F1        | F2  | F3  | F4   |

The menu is accessed from the Main Menu by pressing **FLO (F2)**:

|             |     |     |      |
|-------------|-----|-----|------|
| FLOW MENU 1 |     |     |      |
| DGN         | UNT | FM2 | EXIT |
| F1          | F2  | F3  | F4   |

Then press **FM2 (F3)**:

|             |     |     |      |
|-------------|-----|-----|------|
| FLOW MENU 2 |     |     |      |
| GAS         | SPC | PRM | EXIT |
| F1          | F2  | F3  | F4   |

Note: The **SPC** function key will only appear and be accessible from a **Level 2** password.

Then press **PRM (F3)**.

### Flow Cutoff

The first parameter is **Flow Cutoff**:

|                   |    |       |
|-------------------|----|-------|
| CUTOFF = 2.0 SCFM |    | OK    |
| CHG               |    |       |
| F1                | F2 | F3 F4 |

Enter the value for the low flow cutoff and then press **OK (F4)**.

When the flow rate falls below the zero flow cutoff, the flow meter will display a flow value of zero.



# Operation: Programming

## Programming by Display

### Pipe Diameter

To set the **Pipe Diameter**

Pipe\_id = 3.068 In  
 CHG OK

F1
F2
F3
F4

Enter the pipe diameter in inches or **millimeters** and then press **OK (F4)**.

Use millimeters for metric flow unit selections and inches for English flow unit selections. If the pipe/duct is a square or rectangle, the hydraulic diameter (equivalent value for a round pipe) must be entered for the pipe ID.

### Filter Value

The **Filter Value** is entered in seconds. The allowable time constant range is 0.8 to 10 seconds. The filter time interval is proportional to the dampening.

Enter the filter value and then press **OK (F4)**.

FILTER = 0.8 sec  
 CHG OK

F1
F2
F3
F4

### High Flow Rate Alarm

To set the parameters for a **High Flow Rate Alarm**:

HiFloAlm = 1234 SCFM  
 CHG OK

F1
F2
F3
F4

This is the upper flow limit alarm value that can be associated with the alarm output. An alarm code is generated when the flow value exceeds this limit. If no checking is needed, this value should be set to zero.

Press **OK (F4)** to accept the value.

### Low Flow Rate Alarm

To set the parameters for a **Low Flow Rate Alarm**:

LoFloAlm = 100 SCFM  
 CHG OK

F1
F2
F3
F4

This is the lower flow limit alarm value that can be associated with the alarm output. An alarm code is generated when the flow value is below this limit. If no checking is needed, this value should be set to zero.

Press **OK (F4)** to accept the value.

## Operation: Programming

### Programming by Display

#### High Temp Alarm

To set the parameters for a **High Temperature Alarm**:

|                  |    |
|------------------|----|
| HiTmpAlm = 200 F |    |
| CHG              | OK |

F1
F2
F3
F4

This is the upper temperature limit alarm value that can be associated with the alarm output. An alarm code is generated when the temperature value exceeds this limit. If no checking is needed, this value should be set to zero.

Press **OK (F4)** to accept the value.

#### Low Temp Alarm

To set the parameters for a **Low Temperature Alarm**:

|                 |    |
|-----------------|----|
| LoTmpAlm = 20 F |    |
| CHG             | OK |

F1
F2
F3
F4

This is the lower temperature limit alarm value that can be associated with the alarm output. An alarm code is generated when the temperature value is below this limit. If no checking is needed, this value should be set to zero.

Press **OK (F4)** to accept the value.



#### Reset Total

Note: If the programming menu was entered with a **Level 2** password, then more menus will be shown concerning factory-set parameters that should not be changed.

#### Reset Total and Elapsed Time

Enter the flow totalizer and elapsed time screen by pressing the **F3** and **F4** keys at the same time in the normal running mode (password required).

|               |     |
|---------------|-----|
| RESET TOTAL ? |     |
| NO            | YES |

F1
F2
F3
F4

Press **YES (F4)** to reset total and elapsed time. Press **NO (F1)** to cancel.



#### Totalizer Rollover

**Totalizer Rollover:** The FT1 has an automatic roll-over function. The total flow count of the FT1 will roll over after the following values:

|                  |                |
|------------------|----------------|
| Most flow units: | 99,999,999,999 |
| MSCFD:           | 999,999,999    |
| MMSCFM:          | 9,999,999      |
| MMSCFD:          | 999,999        |

# Operation: Programming


## Programming by Display

### K Factor


#### K Factor

The K FACTOR allows the user to adjust the meter's calibration. The Fox flow meter increases the calculated flow rate by the K Factor. This results in a direct scaling of the meter's output across the entire full range.

The K Factor parameter is accessed from the "Flow Menu 2" menu by entering a **Level 2** password "9111" and pressing the **SPC** key (**F2**).



The following screen will be displayed:



Press **CHG (F1)**. Add the correction factor and press OK (**F4**).

For Example:

If you want the flow meter to read 5% higher, enter 5.0%.

If you want the flow meter to read 5% lower, enter -5.0%.


If an existing K Factor is present, add the additional K Factor to the existing value.

Upon pressing **OK (F4)**, an option to restore the database will follow.

### Restore Database

#### Restore Database

In case of user error, the ability to restore the meter to the original factory settings can be achieved in this menu. The display will show:



Press **YES (F1)** ONLY if you want to restore your database to the initial factory setting that the meter was shipped with. All current user-entered settings will be overwritten.

The green LP3 LED will flash at a faster pace until the recall is performed. The "RESET CRC" screen will follow "RESTORE DATABASE".

Upon pressing **OK (F4)**, an option to reset the NVRAM CRC will follow.

# Operation: Programming

## Programming by Display

### Reset CRC

#### Reset CRC

If the NVRAM CRC check fails (Error Code 36), the programmed settings values will need to be verified and corrected before clearing the error. Call Fox Customer Service if you need assistance.

|            |    |
|------------|----|
| RESET CRC? |    |
| YES        | NO |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

Press **YES (F1) ONLY** if you want to reset the CRC and generate a new CRC value.

### Non-Resettable Totalizer



#### Non-Resettable Totalizer Activation

Regulations in some geographic locations require that flow totalizers be non-resettable. The FT1 can conform to these regulations.

**WARNING:** Once the non-resettable totalizer (NRT) has been activated on an FT1 flow meter, the change cannot be undone. The non-resettable totalizer is only recommended for applications that require it.

After it has been enabled, your FT1's totalizer and elapsed time counters will be non-resettable.

|          |    |
|----------|----|
| SET NRT? |    |
| YES      | NO |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

Press **YES (F1) ONLY** if you want to set the NRT.

|               |    |
|---------------|----|
| ARE YOU SURE? |    |
| YES           | NO |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

If you are certain you want to activate the Non-resettable totalizer, select **YES (F1)**.

### Simulation



#### Simulation

This menu allows for simulation of flow rate and temperature. It should only be used for testing and demonstration purposes. **Make sure to return all of these simulation values to zero, before returning to the normal mode of operation.**

**Caution:** If the 4 to 20mA and/or the pulse/alarm outputs are connected to controllers, set the controllers to "manual". This will ensure that the simulated signals do not cause false controller action.

The menu is accessible from the main programming menu by pressing **FLO**, and **DGN (F1)**:

# Operation: Programming

## Programming by Display

FLOW MENU 1  
DGN UNT FM2 EXIT

F1 F2 F3 F4

Pressing **DGN (F1)** will show:

DIAGNOSTIC  
SIM ZRO EXIT

F1 F2 F3 F4

Pressing **SIM (F1)** will show:

Simulate Flow?  
YES NO

F1 F2 F3 F4

Press **YES (F1)** to continue.

FloSim = 0 SCFM  
CHG OK

F1 F2 F3 F4

Enter the value and then press **OK (F4)**.

Note: Enter zero to disable this feature.

Simulate Temp?  
YES NO

F1 F2 F3 F4

Press **YES (F1)** to continue.

TmpSim = 0 C  
CHG OK

F1 F2 F3 F4

Enter the value and then press **OK (F4)**.

Note: Enter zero to disable this feature.

ENABLE SIM?  
YES NO

F1 F2 F3 F4

Press **YES (F1)** to start the simulation mode, otherwise press **NO (F4)**. Upon pressing either key, the program will return to the FLOW MENU 1 screen.

Note: Simulation Mode will be cleared if the power is cycled.

## Operation: Zero CAL-CHECK®

### Calibration

#### **Calibration of the Fox Model FT1 Thermal Flow Meter**

To ensure that all Fox flow meters meet specified performance parameters and provide accurate, repeatable measurements in the field, all calibrations are performed with NIST-traceable flow standards. Each meter is shipped from the factory with a Fox Calibration Certificate.

### Calibration Validation

#### **Calibration Validation**

Calibration Validation allows our customers to validate the accuracy and functionality of the meter in the field with a push of a button. By performing a simple test, the operator can verify that the meter is running accurately.

Zero CAL-CHECK® ensures the repeatability, functionality of the sensor and its associated signal processing circuitry, and cleanliness of the sensor.

Fox has developed the Zero CAL-CHECK® Calibration Validation to help our customers avoid sending the meter back for annual or biennial re-calibrations.

#### **Zero CAL-CHECK® Calibration Validation Test**


The Zero CAL-CHECK® test is used to ensure that the flow meter still retains its original NIST-traceable calibration at zero flow. If zero flow can be established, the sensor does not need to be removed and the procedure can be done in the pipe. Alternatively, a clean, dry bottle can be used to create a “no flow” condition out of the pipe.

Note: If the Zero CAL-CHECK® test is performed using the Fox FT1 View™ Software, at the completion of the test, a Zero CAL-CHECK® Certificate may be printed for a record of the test. This certificate will display a pass/fail result.

# Operation: Zero CAL-CHECK®

## Zero CAL-CHECK®

Fig. 4.3: Normal Mode vs. Zero CAL-CHECK® Mode



## Achieving Zero Flow - In-Situ (In the Pipe)

### Techniques for Achieving Zero Flow - In the Pipe

In-situ (in the pipe) Zero CAL-CHECK® testing can be achieved by a pipe bypass (valving-off). If space allows, redirect the flow through a bypass pipe section or valve off the meter in order to isolate the meter's sensor in the place where it has been installed. While the flow is redirected, the Zero CAL-CHECK® test can be performed. Once the test is complete, the valves to the bypass may be closed and flow may be directed back to the meter's sensor where flow monitoring can continue as normal.

## Achieving Zero Flow - Out of Pipe

### Achieving Zero Flow - Out of Pipe

If space limitations prevent in-situ testing at zero flow as listed above, then Out of Pipe testing must be performed.

With this configuration, the meter must be removed from the process, the test performed, and then the meter returned to the process after testing has been completed.

Due to the high sensitivity of the DDC-Sensor™, it is necessary to isolate the sensor once the meter has been removed from the pipe. This can be achieved with a closed container in order to isolate the sensor and achieve the "no flow" condition necessary to perform the Zero CAL-CHECK® test. If the Zero CAL-CHECK® test is to be performed out of the pipe, the meter must be set upside-down (probe pointing up) and a clean dry plastic bottle placed back over the sensor to achieve the factory baseline that the meter has been set with.

## Operation: Zero CAL-CHECK®

Performing  
Zero CAL-  
CHECK® Test**Performing the Zero CAL-CHECK® Calibration Validation Test**

The Zero CAL-CHECK® test must be performed at zero flow to ensure a valid test result. This test is used to confirm that the flow meter still retains its original NIST-traceable calibration at zero flow and that the sensor is free of film or residue that may affect readings. The test takes less than 5 minutes to complete. At the conclusion of the test, a Pass or Fail message will be displayed. Press **F4** at the conclusion of the test to return to normal measuring mode or to terminate the test.

Press **FLO (F2)** from the main menu. The display will show:

|             |     |     |      |
|-------------|-----|-----|------|
| FLOW MENU 1 |     |     |      |
| DGN         | UNT | FM2 | EXIT |
| F1          | F2  | F3  | F4   |

Press **DGN (F1)**. The display will show:

|            |     |      |
|------------|-----|------|
| DIAGNOSTIC |     |      |
| SIM        | ZRO | EXIT |
| F1         | F2  | F3   |
| F4         |     |      |

Press **ZRO (F2)**. The display will show:

|               |      |
|---------------|------|
| ZERO CHK MENU |      |
| VER           | EXIT |
| F1            | F2   |
| F3            | F4   |

Press **VER (F1)** key to continue.

|             |    |
|-------------|----|
| VERIFY ZRO? |    |
| YES         | NO |
| F1          | F2 |
| F3          | F4 |

Press **YES (F1)** key to continue.



NOTE: For accurate readings and best test results, perform a visual inspection of sensor window for damage/deformity and condition of sensor elements before starting the test.

# Operation: Zero CAL-CHECK®

## Performing Zero CAL- CHECK® Test



Process Zero and  
Stable? YES EXIT

F1

F2

F3

F4

**WARNING:** You must ensure that there is a no flow condition before proceeding. If you are performing the test in a bottle, be sure to isolate the sensor in a closed container - any air movement (even from a fan) may result in a false "fail" result.

Once process is stable, press **YES (F3)** key to begin the Zero CAL-CHECK®.

Verifying ZRO  
y.yyy T=xx

F1

F2

F3

F4

This test will take less than 5 minutes. The T=xx is a count down timer indicating how much time is left to finish the test.

ZRO=2.321  
Fail

OK

F1

F2

F3

F4

OR

ZRO=0.911  
Warning

OK

F1

F2

F3

F4

OR

ZRO=0.259  
Pass

OK

F1

F2

F3

F4

Upon test completion, the final value will be displayed along with the test result. The test result may be:

- Pass < 0.80
- Warning > 0.80 < 1.0
- Fail > 1.0

If a "Warning" or "Fail" result is displayed, Fox recommends that the probe be removed from the pipe, the sensor cleaned, and the test be performed again. If the test was performed in the pipe the first time, perform the test in a bottle for the re-test.

If a "Warning" or "Fail" result is displayed after performing the test a second time, please call Fox Service at (831) 384-4300 for assistance.

## Operation: Gas-SelectX®

Accessing  
Gas-SelectX®  
Menu**Accessing the Gas-SelectX® Gas Selection Menu Feature**

This menu allows the user to select a gas or gas mix from a pre-calibrated list of gases/gas mixtures available on the Fox Model FT1 Flowmeter. Gases and gas mixes available in the Gas-SelectX® feature include:

- Methane
- Carbon Dioxide (CO2)
- Nitrogen
- Air
- Natural Gas\*
- Argon
- Propane
- Helium
- Oxygen
- Butane
- Hydrogen
- Gas Mix\*\*


*\*Natural gas refers to pipeline-quality dry natural gas, whereas naturally occurring gas from oil fields constitutes a special mixed gas requiring a special calibration. Natural Gas is not available in the 3-Gas Mix feature. Contact Fox for further information.*

*\*\*The molar mass of the gas mixes are programmable in 1% increments. Any three gases available in the Gas-SelectX® menu may be used in any proportion equaling 100%*

Note: For the latest gas and gas mix menu, visit the Fox Website:  
[www.foxthermalinstruments.com](http://www.foxthermalinstruments.com)

After installing your FT1 flowmeter, power up the device. When the meter finishes initializing, it will begin to monitor flow in the gas and flow units assigned at the factory.

The display will show the information similar to the example below. Follow these instructions to access the Gas-SelectX® feature:



To enter the programming mode from the normal monitoring mode and access the Gas-SelectX® menu, press the **F1** or **F2** key repeatedly until the following screen is shown:



# Operation: Gas-SelectX®

## Accessing Gas-SelectX® Menu

|                 |     |  |  |
|-----------------|-----|--|--|
| SET PARAMETERS? |     |  |  |
| NO              | YES |  |  |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

Press **YES (F4)** and the following screen will prompt the user to enter the password if it is active:

|         |    |     |    |
|---------|----|-----|----|
| PASWD:_ |    |     |    |
| UP      | DN | NXT | OK |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

Enter the correct password and press **OK (F4)** to enter it.

Note: Default password is 1234.

After entering the correct password, the following is displayed:

|           |     |     |      |
|-----------|-----|-----|------|
| MAIN MENU |     |     |      |
| I/O       | FLO | DSP | EXIT |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

Press **FLO (F2)** to enter Flow Menu 1.

|             |     |     |      |
|-------------|-----|-----|------|
| FLOW MENU 1 |     |     |      |
| DGN         | UNT | FM2 | EXIT |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

Press **FM2 (F3)** to get to Flow Menu 2.

|             |     |     |      |
|-------------|-----|-----|------|
| FLOW MENU 2 |     |     |      |
| GAS         | SPC | PRM | EXIT |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

Press **GAS (F1)** to access the Gas-SelectX® feature. The display may show:

|             |      |  |  |
|-------------|------|--|--|
| GAS=Methane |      |  |  |
| NXT         | EXIT |  |  |

|    |    |    |    |
|----|----|----|----|
| F1 | F2 | F3 | F4 |
|----|----|----|----|

## Operation: Gas-SelectX®

## Choosing a Gas

From this screen, the user will be able to access two aspects of the Gas-SelectX® menu:

1. Pure Gas = Choosing from a list of available gases, or
2. Gas Mix = Programming a specific mixture of three gases

**Choosing a Gas from the Gas-SelectX® Menu**

The Gas-SelectX® menu will show one of the available gases/gas mixtures:

|         |      |
|---------|------|
| GAS=Air |      |
| NXT     | EXIT |

F1
F2
F3
F4

Press **NXT (F1)** to choose from a list of gases. Choices are:

- Methane
- CO2 = Carbon Dioxide
- Nitrogen
- Air
- Natural Gas (\*see definition p. 50)
- Argon
- Propane
- Helium
- Oxygen
- Butane
- Hydrogen
- Gas Mix = Mix of any of the three gases above; proportions must equal 100%

To choose any pure gas, cycle through until the correct gas is displayed and press **OK (F4)** to choose the gas.

To create a gas mix, choose Gas Mix from the list and press **OK (F4)**.

|              |    |
|--------------|----|
| GAS= Gas Mix |    |
| NXT          | OK |

F1
F2
F3
F4

The screen will show:

|            |    |
|------------|----|
| Methane=0% |    |
| CHG        | OK |

F1
F2
F3
F4

This screen shows the percentage of the gas mixture allocated to Air. In this case, it shows 0%. To program the specific mixture of Methane, press **CHG (F1)**.

# Operation: Gas-SelectX®

## Choosing a Gas

Methane=30%  
UP DN OK

F1 F2 F3 F4

To set the percentage of methane in the gas mix, press **UP (F1)** or **DN (F2)**.

Once the desired methane percentage is displayed, press **OK (F4)**. The display will move to the view of the concentration of each of the subsequent list of gases: Carbon Dioxide (CO2), Nitrogen, Air, Natural Gas, Argon, Propane, Helium, Oxygen, Butane, and Hydrogen (in that order).

CO2=0%  
CHG OK

F1 F2 F3 F4

Once the desired gas percentages are programmed, press **OK (F4)**. One of the following messages will appear:

Gas Mix (100%) OK

F1 F2 F3 F4

Shows only if no error is detected. Pressing OK allows exit to menu.

Err: Mix=(110%) OK

F1 F2 F3 F4

Shows only if gas mix does not equal 100%. Pressing OK returns to gas entry.

Err: Max 3 gas OK

F1 F2 F3 F4

Shows only if too many gases are selected. Only three gases are allowed. Pressing OK returns to gas entry.

Once the 'Gas Mix (100%)' message appears, you have successfully programmed the gas mix in Gas-SelectX® and can exit. Press **OK (F4)** to set the mixture.




### NOTE:

- Gas mix must equal 100%
- If the gas mix only contains 2 gases, set all remaining gas percentages to 0.

## Operation: Gas-SelectX<sup>®</sup>

### Choosing a Gas

The FT1 will begin to monitor flow based on the pre-calibrated algorithm for the gas selected in the Gas-SelectX<sup>®</sup> feature. The screen will show the flow in units and the total flow similar to the example below:



From normal operating mode, the gas selection can be seen on display 3 (see p. 29).

# Modbus Introduction

## Modbus Introduction

### Scope

This portion of the manual describes the Modbus implementation using RS485 serial communication physical layer for the Fox Thermal Instruments FT1 Mass flow meter based on the Modicon Modbus Protocol (PI-MBUS-300 Rev. J).

## Modbus Protocol

### Modbus Protocol

MODBUS Protocol is an application layer messaging protocol that provides client/server communications between devices. MODBUS is a request/reply protocol and offers services specified by function codes.

The size of the MODBUS Protocol Data Unit is limited by the size constraint inherited from the first MODBUS implementation on Serial Line network (max. RS485 Application Data Unit = 256 bytes).

Therefore, MODBUS PDU for serial line communication = 256 – Server address (1 byte) – CRC (2 bytes) = 253 bytes.

RS485 ADU = 253 + Server address (1 byte) + CRC (2 bytes) = 256 bytes.

For more information on MODBUS go to the web site <http://www.modbus.org/>.

### Command Request:

<Meter Address> <Function code> <Register start address high> <Register start address low> <Register count high> <Register count low> <CRC high> <CRC low>

### Command Response:

<Meter Address> <Function code> <Data byte count> <Data register high> <Data register low> ... <Data register high> <Data register low> <CRC high> <CRC low>

Note: The data shown in brackets < > represents one byte of data.



## FT1 Commands Supported by Modbus

### FT1 Commands Supported

#### FT1 Commands Supported

The FT1 supports the following commands:

- 1) Command 03: Read holding registers
- 2) Command 04: Read input register.
- 3) Command 06: Preset single register

#### Read Holding Registers (command 03)

This command reads the basic variable from the FT1 and has the following format:

Request:

<Meter Address> <Command code=03> <Register start address high>  
<Register start address low> <Register count high> <Register count low>  
<CRC high> <CRC low>

Response:

<Meter Address> <Command code=03> <Byte count> <Data high> <Data low> ... <Data high> <Data low> <CRC high> <CRC low>

Example:

Request data register at starting address 0x0000 and specifying only 1 register

<0x01> <0x03> <0x00> <0x00> <0x00> <0x01> <0x0a> <0x84>

Response:

<0x01> <0x03> <0x02> <xx> <xx> <CRC high> <CRC low>

Where xx xx is the data register value.

Table 5.1: FT1 Modbus Holding Registers

| Register Address | Modbus Address | Data Type                | Scaling | Comment                            |
|------------------|----------------|--------------------------|---------|------------------------------------|
| 0x00             | 40001          | Flow in Eng units (low)  | No      | Mass flow in selected units        |
| 0x01             | 40002          | Flow in Eng units (high) | No      |                                    |
| 0x02             | 40003          | Total (low)              | No      | Total in selected units            |
| 0x03             | 40004          | Total (High)             | No      |                                    |
| 0x04             | 40005          | Temperature (low)        | *10     | Temperature in selected units * 10 |
| 0x05             | 40006          | Temperature (high)       | *10     |                                    |
| 0x06             | 40007          | Elapsed time (low)       | *10     | Elapsed time in hours * 10         |
| 0x07             | 40008          | Elapsed time (high)      | *10     |                                    |
| 0x08             | 40009          | Spare/not used           |         |                                    |
| 0x09             | 40010          | Spare/not used           |         |                                    |
| 0x0A             | 40011          | Flow in Eng units * 10   | 10      | Mass flow in selected units * 10   |
| 0x0B             | 40012          | Flow in Eng units *100   | 100     | Mass flow in selected units * 100  |
| 0x0C             | 40013          | Total *100               | 100     | Total in selected units * 100      |

## FT1 Commands Supported by Modbus

| Register Address | Modbus Address | Data Type                                            | Scaling | Comment                       |
|------------------|----------------|------------------------------------------------------|---------|-------------------------------|
| 0x0D             | 40014          | Spare/ Not used                                      |         |                               |
| 0x0E             | 40015          | Spare/ Not used                                      |         |                               |
| 0x0F             | 40016          | Status                                               | No      | Status                        |
| 0x10             | 40017          | Status 2                                             | No      |                               |
| 0x11             | 40018          | Control Register (Write Only)                        | No      | Control Register              |
| 0x12             | 40019          | Spare/ Not used                                      |         |                               |
| 0x13             | 40020          | Flow in Eng units (float, upper 16 bits)             | No      | Mass flow in selected units   |
| 0x14             | 40021          | Flow in Eng units (float, lower 16 bits)             | No      | Mass flow in selected units   |
| 0x15             | 40022          | Total in Eng units (float, upper 16 bits)            | No      | Total in selected units       |
| 0x16             | 40023          | Total in Eng units (float, lower 16 bits)            | No      | Total in selected units       |
| 0x17             | 40024          | Spare/ Not used                                      |         |                               |
| 0x18             | 40025          | Spare/ Not used                                      |         |                               |
| 0x19             | 40026          | Temperature in selected units (float, upper 16 bits) | No      | Temperature in selected units |
| 0x1A             | 40027          | Temperature in selected units (float, lower 16 bits) | No      | Temperature in selected units |
| 0x1B             | 40028          | Elapsed time in hours (float, upper 16 bits)         | No      | Elapsed time in hours         |
| 0x1C             | 40029          | Elapsed time in hours (float, lower 16 bits)         | No      | Elapsed time in hours         |
| 0x1D             | 40030          | Zero CAL-CHECK (float, upper 16 bits)                | No      |                               |
| 0x1E             | 40031          | Zero CAL-CHECK (float, lower 16 bits)                | No      |                               |
| 0x1F             | 40032          | Spare/ Not used                                      |         |                               |
| 0x20             | 40033          | Spare/ Not used                                      |         |                               |
| 0x21             | 40034          | Spare/ Not used                                      |         |                               |
| 0x22             | 40035          | Spare/ Not used                                      |         |                               |
| 0x23             | 40036          | Spare/ Not used                                      |         |                               |



Note: Registers A, B & C are provided to get more resolution for low flow and total. When value exceeds the 16 bit registers, they will be frozen with all 16 bits set.

## FT1 Commands Supported by Modbus

### Read Input Register

#### Read Input Register (FT1 Status, Command 04)

This command is used to report the FT1 status information.

#### Request:

<Meter Address> <Command code=04> <Register address =0> <Register address =0> <Register count =0> <Register count =1> <CRC high> <CRC low>

#### Response:

<Meter Address> <Command code=04> <Byte count =2> <Status High> <Status Low> <CRC high> <CRC low>

Table 5.2: Status Bits Definitions for Command 04, Modbus Address 30001

| Bit | Definition                                   | Comment                                   |
|-----|----------------------------------------------|-------------------------------------------|
| 0   | Power up indication                          | Cleared when out of the power up sequence |
| 1   | Flow rate reached high limit threshold       | Set limit to zero to disable              |
| 2   | Flow rate reached low limit threshold        | Set limit to zero to disable              |
| 3   | Temperature reached high limit threshold     | Set limit to zero to disable              |
| 4   | Temperature reached low limit threshold      | Set limit to zero to disable              |
| 5   | Sensor reading is out of range               | Check sensor wiring                       |
| 6   | Gas mix error                                | Gas mix must total 100%                   |
| 7   | Incorrect Settings                           | Check settings                            |
| 8   | In simulation mode                           | Set simulation value to 0 to disable      |
| 9   | Pulse/alarm output is out of range           | Check pulse/alarm output settings         |
| 10  | Analog 4-20 mA for flow/temp is out of range | Check analog output settings              |
| 11  | Not used                                     | Not used                                  |
| 12  | Not used                                     | Not used                                  |
| 13  | Not used                                     | Not used                                  |
| 14  | CRC error                                    | Check parameters and reset CRC            |
| 15  | Error in Total                               | Reset total to clear alarm                |

Table 5.3: Status 2 Bits Definitions for Command 04, Modbus Address 30002

| Bit | Definition                | Comment  |
|-----|---------------------------|----------|
| 0   | Pulse hardware detected   |          |
| 1   | Busy                      | Busy     |
| 2   | Not used                  | Not used |
| 3   | Not used                  | Not used |
| 4   | Zero CAL-CHECK in process |          |
| 5   | Zero CAL-CHECK fail       |          |
| 6   | Zero CAL-CHECK aborted    |          |
| 7   | Zero CAL-CHECK warning    |          |

## FT1 Commands Supported by Modbus

### Preset Single Register

#### **Preset Single Register (Command 06)**

This command is used to perform miscellaneous functions such as clearing the totalizer and elapsed time. The register address is Modbus=40018 and the data to write is described below.

Request:

<Meter Address> <Command code=06> <Register address high=0x00>  
<Register address low=0x11> <Register data high=0x00> <Register data low=0x02> <CRC high> <CRC low>

Response:

<Meter Address> <Command code=06> <Register address =0x00>  
<Register address =0x11> <Register data=0x00> <Register data =0x02>  
<CRC high> <CRC low>

Reset Total:

Address = 40018, data = 0x02

This command is used to clear the Totalizer and elapsed time registers

## Modbus Programming

## Programming

**Enter the Programming Mode - RS485 Modbus RTU**

Press the **F1** or the **F2** key repeatedly, in the normal running mode, until the following screen is shown. This enters the programming mode:

|                 |     |
|-----------------|-----|
| SET PARAMETERS? |     |
| NO              | YES |

F1
F2
F3
F4

Press **YES (F4)** and then the following screen will prompt the user to enter the password if enabled:

|          |    |     |    |
|----------|----|-----|----|
| PASWD: _ |    |     |    |
| UP       | DN | NXT | OK |

F1
F2
F3
F4

Enter the correct password. Default password for Level 1 is 1234.

Press the **UP (F1)** or **DN (F2)** key to select a new digit or character, the cursor points to the selected digit. Press **NXT (F3)** to select the next digit and **OK (F4)** to accept the entry.

If the wrong password is entered, the message “Wrong Password” will be displayed for a few seconds and then return to the programming entry screen. If the password is accepted, the following screen will be shown:

|           |     |     |      |
|-----------|-----|-----|------|
| MAIN MENU |     |     |      |
| I/O       | FLO | DSP | EXIT |

F1
F2
F3
F4

This is the Main Menu for the programming mode. To exit the programming mode, press **EXIT (F4)** repeatedly until “Normal Mode” is seen briefly.

# Modbus Programming

## Modbus Communication Parameters

### Communication Protocol and Parameters

To program the communication parameters, start at the Main Menu:

|           |     |     |      |
|-----------|-----|-----|------|
| MAIN MENU |     |     |      |
| I/O       | FLO | DSP | EXIT |
| F1        | F2  | F3  | F4   |

Then press **I/O (F1)** to set Inputs/Outputs:

|         |    |     |      |
|---------|----|-----|------|
| SET I/O |    |     |      |
| COM     |    | 420 | EXIT |
| F1      | F2 | F3  | F4   |

Then press **COM (F1)** to select communication parameters.

Set Bus protocol for Modbus:

|             |    |       |
|-------------|----|-------|
| Comm=Modbus |    |       |
| NXT         |    | OK    |
| F1          | F2 | F3 F4 |

Press **NXT (F1)** repeatedly until Modbus is selected as shown and then press **OK (F4)** to accept the setting.

The following communication parameters are only available for MODBUS:

|           |    |       |
|-----------|----|-------|
| Baud=9600 |    |       |
| NXT       |    | OK    |
| F1        | F2 | F3 F4 |

Press **NXT (F1)** repeatedly until the correct selection is shown and then press **OK (F4)** to accept the setting.

Selections are:

- "115200"
- "76800"
- "57600"
- "38400"
- "19200"
- "9600"
- "4800"
- "2400"
- "1200"

## Modbus Programming

Modbus  
Communication  
Parameters

Parity=EVEN  
NXT OK

F1

F2

F3

F4

Press **NXT (F1)** repeatedly until the correct selection is shown and then press **OK (F4)** to accept the setting.

Selections are: "NONE"  
"ODD"  
"EVEN"

Address=02  
CHG OK

F1

F2

F3

F4

Press **CHG (F1)** to change the address and then press **OK (F4)** to accept the setting.

Selections are between 01 and 247.

Note: Power cycle is required for the new settings to take effect.



## BACnet Introduction

### BACnet Introduction

#### Scope

This portion of the manual describes the BACnet MS/TP implementation using RS485 serial communication physical layer for the Fox Thermal Instruments FT1 Mass flow meter.

### BACnet Protocol

#### BACnet Protocol

BACnet MS/TP (Building Automation and Control Network /Master Slave Token Passing) is a data link layer protocol designed for communication between devices in building automation control systems. The protocol is based on devices, objects, properties, and services. Information inside a BACnet device is organized into a series of objects. Properties allow the data from the object to be written or read. The actions that a BACnet device uses to interact with another device are the services.

The FT1 Device profile: BACnet Smart Sensor (B-SS)

FT1 supports the following device binding methods:

|                                                                                           |
|-------------------------------------------------------------------------------------------|
| Receive Who-Is, send I-Am (BIBB DM-DDB-B)<br>Receive Who-Has, send I-Have (BIBB DM-DOB-B) |
|-------------------------------------------------------------------------------------------|

Objects for FT1:

|                                                                                                                                                     |
|-----------------------------------------------------------------------------------------------------------------------------------------------------|
| Analog Input 1 = Flow<br>Analog Input 2 = Gas Temperature<br>Analog Input 3 = Total Flow / Reset Total<br>Analog Input 4 = Elapsed Time since reset |
|-----------------------------------------------------------------------------------------------------------------------------------------------------|

## BACnet Protocol

BACnet Protocol Device object property identifiers and restrictions: (properties that are writable)

|                     |                  |
|---------------------|------------------|
| Object _ Name       | < 10 bytes       |
| Object _ Identifier | Device Type only |
| Max _ info _ Frames | < =255           |
| Max _ Master        | < =127           |

BACnet Interoperability Building Blocks (BIBB'S) provide function capabilities for data exchange between devices.

FT1 BIBB's supported:

DS-RP-B Read Property  
 DS-WP-B Write Property  
 DM-DDB-B Dynamic Device Binding  
 DM-DOB-B Dynamic Object Binding  
 DM-DCC-B Device Communication Control  
 DS-RPM-B ReadPropertyMultiple  
 DM-RD-B Reinitialize Device

MS/TP baud rates:

9600, 19200, 38400, 57600, 76800, 115200

FT1 Character sets supported:

ANSI X3.4, UTF-8

Fox Thermal Instruments BACnet vendor ID: 650

For more information about BACnet visit <http://www.bacnet.org/>.

# BACnet Programming

## BACnet Programming

### Enter the Programming Mode - BACnet MS/TP

Press the F1 or the F2 key repeatedly, in the normal running mode, until the following screen is shown. This enters the programming mode:

|                 |     |
|-----------------|-----|
| SET PARAMETERS? |     |
| NO              | YES |

F1

F2

F3

F4

Press **YES (F4)** and then the following screen will prompt the user to enter the password if enabled:

|         |    |     |    |
|---------|----|-----|----|
| PASWD:_ |    |     |    |
| UP      | DN | NXT | OK |

F1

F2

F3

F4

Enter the correct password. Default password for Level 1 is 1234.

### Communication Protocol and Parameters

To program the communication parameters, press **I/O (F1)** key from the main menu.

|           |     |     |      |
|-----------|-----|-----|------|
| MAIN MENU |     |     |      |
| I/O       | FLO | DSP | EXIT |

F1

F2

F3

F4

This is the main menu for the programming mode. To exit the programming mode, press **EXIT (F4)** repeatedly until "Normal Mode" is seen briefly. Choose I/O (F1) to access the communication output.

|         |     |      |
|---------|-----|------|
| SET I/O |     |      |
| COM     | 420 | EXIT |

F1

F2

F3

F4

Then press **COM (F1)** to select communication parameters

Set Bus protocol for BACnet:

|             |    |
|-------------|----|
| Comm=BACnet |    |
| NXT         | OK |

F1

F2

F3

F4

Press **NXT (F1)** until BACnet is selected as shown and then press **OK (F4)** to accept the setting.

# BACnet Programming

## BACnet Communication Parameters

Baud=9600  
NXT OK

F1 F2 F3 F4

Press **NXT (F1)** repeatedly until the correct selection is shown and then press **OK (F4)** to accept the setting.

Selections are: "9600"  
"19200"  
"38400"  
"57600"  
"76800"  
"115200"

Next select the MS/TP Mac address. The selection is from 0-127. Please note that only one device can be on a MS/TP Mac address.

MAC\_ADD=23  
CHG OK

F1 F2 F3 F4

Next select the MS/TP Max Master using **CHG (F1)**. The selection is from 0-127. Press **OK (F4)** to accept the setting.

MAX\_MASTER=127  
CHG OK

F1 F2 F3 F4

Next input the device object instance using **CHG (F1)**. Selection is from 0-4194303. Press **OK (F4)** to accept the setting.

ID=12531  
CHG OK

F1 F2 F3 F4

# BACnet Programming

## BACnet Communication Parameters

Next enter the device object name (9 characters maximum) using **CHG (F1)**. Press **OK (F4)** to accept the setting.

NAME=FT1\_FLOW  
CHG OK

F1

F2

F3

F4



Note: Power cycle is required for the new settings to take effect.

## Maintenance: Precautions

### Precautions



#### **PRECAUTIONS**

**WARNING!** BEFORE ATTEMPTING ANY MAINTENANCE, TAKE THE NECESSARY SAFETY PRECAUTIONS BEFORE REMOVING THE PROBE FROM THE DUCT (EXAMPLE: PURGE LINES OF TOXIC AND/OR EXPLOSIVE GAS, DEPRESSURIZE, ETC...).

**WARNING!** EXPLOSION HAZARD. DO NOT REMOVE OR REPLACE COMPONENTS OR FUSES UNLESS POWER HAS BEEN DISCONNECTED WHEN A FLAMMABLE OR COMBUSTIBLE ATMOSPHERE IS PRESENT.

**WARNING!** EXPLOSION HAZARD. DO NOT DISCONNECT EQUIPMENT WHEN A FLAMMABLE OR COMBUSTIBLE ATMOSPHERE IS PRESENT.

#### **Access to Electronics**

Accessing electronics is not normally required for maintenance purposes. If a loose connection is suspected, unscrew the cap of the meter, unscrew the two phillips captive screws through the display and open the display assembly to access the wiring terminations.

**CAUTION:** BE SURE POWER TO METER IS SWITCHED OFF BEFORE ATTEMPTING TO ACCESS ELECTRONICS. If there is a problem and a loose connection is not found, please contact Fox Customer Service for technical assistance at (831) 384-4300.

## Maintenance: General

### Maintenance

#### Broken or Damaged Probe

If the sensor is broken or damaged, the probe and electronics must be returned to the factory. A new sensor will be installed and calibrated. Refer to "Returning Your Meter" on p. 80.

#### Flow Calibration and Calibration Validation

To ensure continued high accuracy of your Model FT1 Flow Meter, Fox Thermal Instruments Inc. provides a full NIST traceable calibration. It is recommended that the meter be returned to Fox for a calibration check in our NIST traceable labs after two years of operation to maintain absolute accuracy. It is recommended that the meter's accuracy be checked annually by performing the Zero CAL-CHECK® Calibration Validation test.

#### Fuse Replacement

**Warning!** Turn input power OFF before removing or installing a fuse. Use only recommended fuse replacements.

Verify the fuse is defective by measuring it with an Ohm Meter (Two replacement fuses are provided with each unit). Replacement fuse is Littelfuse part number 0454.750MR

#### To replace the fuse:

The fuse F1 is located near the power terminal block and can be removed by using tweezers or needle-nose pliers.

#### Sensor Cleaning

The sensor is insensitive to small amounts of residue, but continued use in dirty environments will necessitate periodic cleaning. To inspect the sensor, remove power from electronics and remove the unit from the pipe or duct, exposing the sensor elements. If they are visibly dirty, clean them with water or alcohol (ethanol) using an appropriate brush until they appear clean again. Even though the sensor elements are rugged, avoid touching them with any solid object and use a light touch while cleaning them.



# Troubleshooting: General

## Troubleshooting



### Troubleshooting

**Caution!** The electronics and sensor supplied by Fox are calibrated as a single precision mass flow meter. Interchanging sensors will decrease the accuracy of the flow meter. If you experience any problem with your Model FT1 Flow meter, call Fox Customer Service Department, Technical Assistance at (831) 384-4300.

| Problem                    | Possible Cause(s)                                       | Action(s)                                                                                                                                                                                                       |
|----------------------------|---------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Display Error              | 1. Loose ribbon cable/<br>damaged ribbon cable          | 1. Visual inspection.<br>2. Cycle the power to reset the meter.                                                                                                                                                 |
| Flow measurement seems low | 1. Probe not oriented properly<br>2. Sensor dirty       | 1. Orient probe per installation sections: Insertion (p. 17),<br>2. Clean sensor (p. 69)                                                                                                                        |
| Unit will not power-up     | 1. No power input<br>2. Bad fuse<br>3. Bad Power supply | 1. Check fuse (F1) located next to TS1 on main board.<br>2. Check for correct power supply voltage at TS1 on main board.<br><br>If fuse is OK and unit still won't power up, call Fox for additional assistance |



## Troubleshooting: General

| Problem                                    | Possible Cause                                                                                                                                                                                                                                   | Action                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|--------------------------------------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Meter does not initialize                  | 1. Electromechanical interference                                                                                                                                                                                                                | <ol style="list-style-type: none"> <li>1. Check meter power cycles.</li> <li>2. Press and release F1 and F2 at the same time; the display will enter Engineering screens.</li> <li>3. Press F1 to get to screen #23; record power cycle value.</li> <li>4. Press F4 to return to normal operation; monitor meter until problem returns.</li> <li>5. Return to screen #23 to see if power cycles have increased; microprocessor is resetting due to EMI electrical noise entering the meter.</li> <li>6. Check Power input and output cables grounding and routing.</li> </ol>                                                                                    |
| Flow measurement is erratic or fluctuating | <ol style="list-style-type: none"> <li>1. Very turbulent flow</li> <li>2. Sensor dirty</li> <li>3. Sensor broken</li> <li>4. Probe not mounted securely</li> <li>5. Malfunction in flow meter</li> <li>6. Meter installed incorrectly</li> </ol> | <ol style="list-style-type: none"> <li>1. Increase dampening (see filter settings in "Flow Parameters" on p. 40)</li> <li>2. Clean sensor (Refer to Maintenance section, p. 69)</li> <li>3. Return flow meter to Fox for repair (Refer to p. 80 for shipping instructions)</li> <li>4. Remount probe (see Installation section, p. 17); must be mounted securely without vibration. If vibration persists, choose a new mounting location without vibration.</li> <li>5. Return flow meter to Fox for repair (Refer to p. 80 for shipping instructions)</li> <li>6. Re-install meter according to instructions (Refer to installation section, p. 17)</li> </ol> |



## Troubleshooting: Zero CAL-CHECK®

Troubleshooting  
Zero CAL-CHECK®**Troubleshooting Zero CAL-CHECK®**

If the FT1 Meter fails a Zero CAL-CHECK® Calibration Validation test, there are a few reasons that could be the cause:

1. The sensor may be dirty or damaged
  - Visually inspect the meter for damage. If damage is found, meter may need to be serviced. Contact Fox Technical Assistance at 831-384-4300 for more information
  - Try cleaning the sensor and try the test again
  - If the meter fails again, move to #2
2. The sensor may not be properly covered/isolated
  - Out of Pipe:
    - Wind currents (fans in room included) could be affecting the sensor
    - Be sure to use a clean dry plastic bottle to isolate the sensor
  - In Pipe:
    - Make sure that there is a "no flow" or zero flow condition on the meter's sensor
  - Try the test again
  - If the meter fails again, move to #3
3. The meter may not have stabilized properly
  - Make sure the meter is not being affected by vibration or other movement
  - Allow the meter to stabilize without being moved or touched for 15 minutes
  - Try the test again
  - If the meter fails again, contact Fox Technical Assistance at 831-384-4300



# Troubleshooting: Installation Problems

## Installation Problems

### Installation Problems

The following is a summary listing of problems that may be encountered with the installation of the FT1 Thermal Mass Flow Meter.

1. *Improper wiring connections for power and/or 4 to 20mA output signal.*  
The FT1 requires a separate power source for the main board and the 4 to 20mA output signals. Two wires supply 24VDC power to the main board. Two wires are used for the 4 to 20mA output signals. Refer to Figure 3.3 and Figure 3.4 (p. 24, p. 25). Also refer to "Wiring Precautions" in Wiring section (p. 21) for further guidance.
2. *Inadequate power source.*  
The FT1 requires 12 to 28VDC at up to 6 Watts to operate. A 20 Watt power supply is recommended for powering the FT1 to ensure it operates properly under all conditions. If the voltage supplied at the input terminals of the FT1 is not within the range of 10VDC to 30VDC, a variety of problems can occur including a dim display, inaccurate flow readings or faulty 4 to 20mA, pulse and communication interface.
3. *Flow measurement seems inaccurate.*
  - Check to ensure that the flow meter is installed so that the Flow Direction Indicator below the electronics housing is properly pointing in the direction of flow. Refer to Figure 2.3 (p. 19). If not, change orientation of meter.
  - Check that the insertion depth of the sensor/probe is correct. The end of the probe should be adjusted as per Figure 2.2 (p. 18).
  - Ensure that there are a minimum of fifteen diameters of straight pipe upstream of the sensor and ten diameters downstream. If complex flow disturbances are upstream of the sensor, extension of the straight pipe may be required to ensure accurate flow measurement. Contact Fox for assistance.
  - Ensure that pipe inside diameter in the meter matches data on the Fox Calibration Certificate. The pipe inside diameter is programmed into the flow meter through the front panel (see Flow Parameters, p. 40).
4. *Erratic flow reading (especially a flow reading spiking high).*  
This may be a symptom of moisture in the flow stream. Fox flow meters are designed to work in relatively dry gas applications only. Contact Fox to discuss resolutions to this problem.
5. *Flow meter is not responding to flow.*
  - Check to ensure adequate power is supplied to the flow meter. If things appear to be correct, perform this functional test before calling Fox. Carefully remove the probe and sensor from the pipe. For those flow meters with a display - and if the display is reading zero - blow on the sensor to see if a response occurs. If nothing happens, take a damp rag or sponge and place it in contact with the sensor. A reading should occur. Contact Fox Customer Service with this information.
6. *Display and/or 4 to 20mA signal reading above zero flow when no flow is occurring in the pipe.*  
If the reading is less than 5% of full scale, it is likely this is a normal condition caused by convection flow created by the heated sensor. It does not mean that the zero of the instrument is improperly set. The Fox sensor is extremely sensitive to gas flow and can even read the small flow caused by convection. If this is an unacceptable condition, please contact Fox Customer Service for alternatives.



## Troubleshooting: Alarm Codes

### Alarm Codes

#### Alarm Codes

Information to diagnose and clear alarm codes is on p. 7 under the Menu Tree section. Enter password (9111) and follow the block diagram to get to the section affected by the error code.

| Alarm Code | Reason                        | Action                                                                                                                                                                                                                        |
|------------|-------------------------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| 13         | Flow rate above high limits   | Refer to the FLOW MENU 2 section on p. 40 of this Manual to verify limit is within range. Check ALM = HiFloAlm under PRM.                                                                                                     |
| 14         | Flow rate below low limits    | Refer to the FLOW MENU 2 section on p. 40 of this Manual to verify limit is within range. Check ALM = LoFloAlm under PRM.                                                                                                     |
| 15         | Temperature above high limits | Refer to the FLOW MENU 2 section on p. 40 of this Manual to verify limit is within range. Check ALM = HiTempAlm under PRM.                                                                                                    |
| 16         | Temperature below low limits  | Refer to the FLOW MENU 2 section on p. 40 of this Manual to verify limit is within range. Check ALM = LoTempAlm                                                                                                               |
| 22         | Sensor out of range           | Refer to the ENGINEERING DISPLAY MENU on p. 11 of this Manual and the Fox factory Calibration Certificate to check CSV voltage. Compare Display 10 value to Calibration Certificate CSV voltage and verify it's within range. |
| 23         | Gas mix error                 | Gas mix must equal 100%.                                                                                                                                                                                                      |
| 24         | Check settings                | One or more internal settings are corrupted or out of spec. Contact Fox Service for instructions to verify settings.                                                                                                          |
| 25         | Simulation mode               | Meter is in Simulation Mode. Refer to the FLOW MENU 1 section on p. 44 of this Manual. Use the SIM Section under Diagnostics to return to normal operation.                                                                   |
| 26         | Pulse/alarm output over range | Refer to the DIGITAL OUTPUT MENU on p. 5 of this Manual. Verify the Pulse/alarm Output settings are within limits.                                                                                                            |
| 32         | 4 to 20mA is out of range     | Refer to the MAIN MENU on p. 4 of this Manual. Use the Set I/O section to verify range limits.                                                                                                                                |
| 34         | Busy                          | Meter is recalculating new parameters.                                                                                                                                                                                        |
| 36         | Database CRC Error            | Refer to the Reset CRC section on p. 44 of this manual. Verify the programmed values are verified and corrected before clearing the error. Contact Fox Service Department for possible causes.                                |



## Appendices: Specifications

### Performance & Operating Specs

#### Performance Specs

##### Flow Accuracy:

Air:  $\pm 1\%$  of reading  $\pm 0.5\%$  of full scale

Other gases:  $\pm 1.5\%$  of reading  $\pm 0.5\%$  of full scale

Accuracy specification applies to customer's selected flow range

Maximum range: 15 to 15,000 SFPM (0.07 to 71 NMPS)

Minimum range: 15 to 1,000 SFPM (0.07 to 4.7 NMPS)

Straight, unobstructed pipe requirement:

15 diameters upstream; 10 downstream

Flow Repeatability:  $\pm 0.2\%$  of full scale

Flow Response Time: 0.8 seconds (one time constant)

Temperature Accuracy:  $\pm 1^\circ \text{F}$  ( $\pm 0.6^\circ \text{C}$ )

##### Calibration:

Factory Calibration to NIST traceable standards

Zero CAL-CHECK<sup>®</sup>: In situ, operator-initiated calibration validation

#### Operating Specs

##### Gas-SelectX<sup>®</sup> Gas Selections:

Methane, Carbon Dioxide (CO<sub>2</sub>), Nitrogen, Air, Natural Gas, Argon, Propane, Helium, Oxygen, Butane, Hydrogen, 3 gas mix, and more available soon. See the Fox website for more information on availability of current gases.

##### Units of Measurement (field selectable):

SCFM, SCFH, NM<sup>3</sup>/M, NM<sup>3</sup>/H, NM<sup>3</sup>/D, NLPS, NLPM, NLPH, MCFD, MSCFD, SCFD, MMSCFD, MMSCFM, SM<sup>3</sup>/D, SM<sup>3</sup>/H, SM<sup>3</sup>/M, LB/S, LB/M, LB/H, LB/D, KG/S, KG/M, KG/H, SLPM, MT/H

##### Flow Velocity Range:

15 to 15,000 SFPM (0.07 to 71 NMPS)

Turndown: up to 1000:1; 100:1 typical

| Flow Ranges   |          |                     |
|---------------|----------|---------------------|
| Pipe Diameter | SCFM     | NM <sup>3</sup> /hr |
| 1.5" (40mm)   | 0-210    | 0-330               |
| 2" (50mm)     | 0-350    | 0-550               |
| 3" (80mm)     | 0-770    | 0-1,210             |
| 4" (100mm)    | 0-1,330  | 0-2,100             |
| 6" (150mm)    | 0-3,000  | 0-4,730             |
| 8" (200mm)    | 0-5,210  | 0-8,220             |
| 12" (300mm)   | 0-11,700 | 0-18,450            |

Note: To determine if the FT1 will operate accurately in other pipe sizes, divide the maximum flow rate by the pipe area. The application is acceptable if the resulting velocity is within the velocity range above. Check Fox website for velocity calculator.



## Appendices: Specifications

### Operating Specs

Gas Pressure (maximum): 300 psig (20.7 barg)\*

\*Note: When teflon ferrule option ordered, gas pressure is 60psig (4.1 barg) maximum



Relative Humidity: Non-condensing

Note: Condensing liquids contacting the sensor can cause erratic flow indication.



Temperature:

DDC-Sensor™: -40 to 250°F (-40 to 121°C)

Enclosure: -40 to 158°F (-40 to 70°C)\*

\*Note: Display dims below -4°F (-20°C), function returns once temperature rises again.

Input Power: 12 to 28VDC, 6 watts max. (CE requirement)

Full Input Power Range: 10 to 30VDC.

A 20 Watt or greater power supply is recommended to power the FT1.

Outputs:

Channel 1:

Standard isolated 4 to 20mA output configured to indicate either flow or temperature; fault indication per NAMUR NE43.

The 4 to 20mA load resistance must be 125 ohms or less when operating on 12 volt power and 600 ohms or less on 24 volt power.

Channel 2:

FT1 can be ordered with either the pulse output or serial communication option.

- Pulse option: Isolated open collector output rated for 5 to 24VDC, 10mA maximum load, 0 to 100Hz (the pulse output can be configured to either transmit a 0 to 100Hz signal proportional to flow rate or an on/off alarm).
- Serial communication option: Isolated RS485 Modbus RTU or BACnet MS/TP.

USB Communication:

Isolated USB 2.0 for interfacing with a laptop or computer is standard.

FT1 View™: A free PC-based software tool that provides complete configuration, remote process monitoring, and data logging functions through USB communication.

4 to 20mA and Pulse Verification:

Simulation mode used to align 4 to 20mA output and pulse output (if ordered) with the input to customer's PLC/DCS.

## Appendices: Specifications

### Physical Specs

#### Physical Specs

Sensor material:

316 stainless steel

Enclosure:

NEMA 4, aluminum, dual ¾" FNPT conduit entries.

Flow Meter Installation:

Fox-supplied compression fitting connects to customer-supplied ¾" female coupling welded to pipe.

### Agency Approvals

#### Agency Approvals

CE Mark: Approved

EMC Directive; 2014/30/EU

Emissions and Immunity Testing: EN61326-1:2013

FM (U.S.) and FMc (Canada): Pending

Class I, Division 1, Groups B,C,D; Class II, Division 1, Groups E,F,G; and Class III, Division 1; T3C, Ta = - 40° to 70°; Class 1, Zone 1, AEx/Ex d IIB + H2 T4; Ta = -20° C to 70° C; Type 4, IP67

ATEX (EU): Pending

II 2 G Ex d IIB + H2 T4; Gb Ta = - 20° C to 70° C; IP67

II 2 D Ex tb IIIC T135° C; Db Ta = - 20° C to 70° C; IP67

IECEX (Global): Pending

Ex d IIB + H2 T4; Gb Ta = - 20° C to 70° C; IP67

Ex tb IIIC T135° C; Db Ta = - 20° C to 70° C IP67

# Appendices: Dimensions

Local with  
Retractor

Fig. 7.1 Insertion Meter Dimensions  
Measurements shown in inches (millimeters).




Table 7.1 Insertion Meter with 316 stainless steel probe

| Probe Size   | Probe Size | Dimension "LL"         |
|--------------|------------|------------------------|
| [model code] | [inches]   | [inches / millimeters] |
| 06l          | 6"         | 6.0" (152 mm)          |
| 09l          | 9"         | 9.0" (229 mm)          |
| 12l          | 12"        | 12.0" (305 mm)         |
| 15l          | 15"        | 15.0" (381 mm)         |
| 18l          | 18"        | 18.0" (457 mm)         |
| 24l          | 24"        | 24.0" (610 mm)         |
| 30l          | 30"        | 30.0" (762 mm)         |
| 36l          | 36"        | 36.0" (914 mm)         |

## Appendices: Warranty

### Warranty

#### **Warranty**

(a) FOX warrants that the products furnished under this Agreement will be free from defects in material and workmanship for a period of one year from the date of shipment. The customer shall provide notice of any defect to FOX, within one week after the Customer's discovery of such defect. The sole obligation and liability of FOX, under this warranty shall be repair or replace, at its option, without cost to the Customer, the defective product or part.

(b) Upon request by FOX, the product or part claimed to be defective shall immediately be returned at the Customer's expense to FOX. Replaced or repaired products or parts will be shipped to the Customer at the expense of FOX. FOX shall have the right of final determination as to the existence and cause of defect.

(c) There shall be no warranty or liability for any products or parts that have been subject to misuse, accident, negligence, failure of electric power or modifications by the Customer without the written approval of FOX. Final determination of warranty eligibility shall be made by FOX. If a warranty claim is considered invalid for any reason, the Customer will be charged for services performed and expenses incurred by FOX, in handling and shipping the returned unit.

(d) The liability of FOX shall be limited to replacing or repairing, at its option, any defective parts which are returned. Labor and related expenses incurred to install replacement parts are not covered by this warranty.

(e) As to replacement parts supplied or repairs made during the original warranty period, the warranty period for the replacement or repaired part shall terminate with the termination of the warranty period of the original product or part.

(f) The use of these products is under exclusive control of the purchaser and FOX specifically denies any responsibility for the calibration of units and/or accuracy of work performed or the safety of the system in which FOX products is used. EXTERNAL SAFETY DEVICES MUST BE USED WITH THIS EQUIPMENT.

(g) No warranty is made with respect to custom equipment or products produced to Buyer's specifications except as specifically stated in writing by FOX and contained in the agreement.

(h) THE FOREGOING WARRANTY CONSTITUTES THE SOLE LIABILITY OF FOX, AND THE CUSTOMER'S SOLE REMEDY WITH RESPECT TO THE PRODUCTS AND IS IN LIEU OF ALL OTHER WARRANTIES, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE, LIABILITIES, AND REMEDIES. EXCEPT AS THUS PROVIDED, FOX, DISCLAIMS ALL WARRANTIES, EXPRESS OR IMPLIED, INCLUDING ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

## Appendices: Returning Your Meter

### Returning Your Meter

#### Returning Your Meter

The Fox Thermal Instruments, Inc. Customer Service Department (PH: 831- 384-4300 or FAX: 831-337-5787) can help you through the process of returning a meter for service.

If it becomes necessary to return a Fox flow meter for service or recalibration, please follow these steps:

1. A Return Material Authorization (RMA) Number must be obtained from the Fox Customer Service Department prior to returning any Fox meter(s).
2. Please have your meter's serial number(s) available.
3. Read and complete the Fox RMA Customer Information Form. Be sure to initial the decontamination statement as well as provide complete return shipping instructions (we cannot deliver to post office boxes).
4. The entire flow meter must be returned, including all electronics (unless specifically instructed to do otherwise). **ALL** serial numbers must match their corresponding meters. This is especially necessary when returning flow body models.
5. Clean and decontaminate all wetted parts before returning to Fox.
6. Ship the meter to the following address:  
Fox Thermal Instruments, Inc.  
399 Reservation Road  
Marina, CA 93933  
Attn: Service Dept.  
[RMA Number]



**Note:** Be sure to review all of the information on the Customer Information Form before sending your meter to the Fox Customer Service Department. The Fox Shipping/Receiving Department cannot accept meters that have not been prepared appropriately.

## Appendices: Returning Your Meter

---

### What to Expect During Servicing

#### **What to expect while your meter is being serviced**

Depending on the type of service required when returning your Fox meter, there are varying turnover times for servicing a meter. The average time needed to service the meter is 7-10 days (not including shipping or peak production times).

If you have already shipped your meter to Fox for servicing and would like to check the status of your meter, please fill out our online Service Order Status form located at [www.foxthermalinstruments.com](http://www.foxthermalinstruments.com) and you will hear from a Customer Service Rep within 1 business day of your requested update.

Rush recalibration service is available for a fee. Restrictions apply.

**Glossary of Terms and Definitions**

|                 |                                                |                    |                                   |
|-----------------|------------------------------------------------|--------------------|-----------------------------------|
| AWG             | American Wire Gauge                            | NPT                | National Pipe Thread              |
| Bara            | Bar absolute                                   | PDA                | Personal hand held computer       |
| CTC             | Contact                                        | PC                 | Personal Computer                 |
| CAL             | Calibration                                    | P/U                | Pulse per Unit                    |
| CHG             | Change                                         | PIP A <sup>2</sup> | Pipe Area                         |
| COM             | Communication                                  | PLC                | Programmable Logic Controller     |
| CSV             | Current Sense Voltage                          | PRM                | Parameters                        |
| DC              | Direct Current                                 | PRS                | Pressure                          |
| DN              | Down                                           | PSIA               | Pounds per Square Inch Absolute   |
| DSP             | Display                                        | Pt                 | Point                             |
| ELP             | Elapsed time                                   | PSW                | Password                          |
| Feq             | Frequency                                      | SIM                | Simulation                        |
| Ft <sup>2</sup> | Square Feet                                    | SCF                | Standard Cubic Feet               |
| I/O             | Input/Output                                   | SCFM               | Standard Cubic Feet per Minute    |
| INP             | Input                                          | SCFH               | Standard Cubic Feet per Hour      |
| IR              | Infrared (IR Buttons = optical switches)       | SCFD               | Standard Cubic Feet per Day       |
| LB              | Pound                                          | SPC                | Special Control                   |
| LB/D            | Pound per Day                                  | STP                | Standard Temperature and Pressure |
| LB/H            | Pound per Hour                                 | TMP                | Temperature                       |
| LB/M            | Pound per Minute                               | TSI                | Internal Variable                 |
| LB/S            | Pound per Second                               | TSV                | Internal Variable                 |
| LCD             | Liquid Crystal Display                         | UNT                | Unit                              |
| KG              | Kilogram                                       | U/P                | Unit per Pulse                    |
| KG/H            | Kilogram per Hour                              | 420                | 4 to 20mA output                  |
| KG/M            | Kilogram per Minute                            |                    |                                   |
| KG/S            | Kilogram per Second                            |                    |                                   |
| M <sup>2</sup>  | Square Meter                                   |                    |                                   |
| mmHG            | Pressure in millimeters of mercury             |                    |                                   |
| MMSCFD          | Million Standard Cubic Feet per Day            |                    |                                   |
| MXFLO           | Maximum Flow                                   |                    |                                   |
| NEMA            | National Electrical Manufactures Association   |                    |                                   |
| NIST            | National Institute of Standards and Technology |                    |                                   |
| NL              | Normal Liter                                   |                    |                                   |
| NLPH            | Normal Liter per Hour                          |                    |                                   |
| NLPM            | Normal Liter per Minute                        |                    |                                   |
| NM3             | Normal cubic Meter                             |                    |                                   |
| NM3/H           | Normal cubic Meter per Hour                    |                    |                                   |
| NM3/M           | Normal cubic Meter per Minute                  |                    |                                   |

## Index

## Index

Access to Electronics, p. 21  
 Alarm Codes, p. 74  
 Alarm wiring, p. 25  
 Analog 4 to 20mA output, p. 31  
 Breakage or Damage of Probe, p. 69  
 Dimension Details, p. 78  
 Discrete output setting, p. 34  
 Display Screens, p. 29  
 Display Setup, p. 35  
 Engineering Screens, p. 11  
 Entering the programming mode, p. 30  
 Equal length sensors, p. 20  
 Filter value, p. 41  
 Flow Meter Placement, p. 17  
 Flow Units, p. 37  
 Pulse/alarm Output, p. 32  
 Fuse Replacement, p. 69  
 Glossary, p. 82  
 Installation,  
     Compression Fitting - Insertion, p. 21  
     General Precautions, p. 16  
     Lateral Placement, p. 17  
     Mounting, p. 17  
     Orientation of Meter - Insertion, p. 19  
 Introduction, p. 14  
 K Factor, p. 43  
 Level 2 password, p. 37  
 Local Display, p. 15  
 Local Input Wiring, p. 22  
 Mass Flow, p. 14  
 Measurement Mode, p. 29  
 Menu Tree,  
     Digital Output, p. 5  
     Display Menu, p. 8  
     Engineering Display, p. 9  
     Gas-SelectX®, p. 10  
     Main Menu, p. 4  
     Flow Menu 1, p. 6  
     Flow Menu 2, p. 7  
     Zero CAL-CHECK® Menu, p. 9  
 Mounting meter, p. 17  
 Orientation of meter - Insertion type, p. 19  
 Password  
     Level 1, p. 37  
     Level 2, p. 37  
     Programming, p. 37  
 Power Input Wiring, p. 22  
 Preventative Maintenance, p. 69  
 Product Description, p. 14

## Programming

Analog 4 to 20mA Output, p. 31  
 Alarm Output, p. 34  
 Changing values or strings, p. 30  
 Display Setup, p. 35  
 Filter value, p. 41  
 Flow cutoff, p. 40  
 Flow Parameters, p. 40  
 Flow and maximum pulse/alarm, p. 33  
 High Alarm Limit value, p. 41  
 Pulse/alarm Output, p. 32  
 K Factor, p. 43  
 Low Alarm Limit value, p. 41  
 Password, p. 37  
 Pipe Diameter, p. 41  
 Programming Mode, p. 30  
 Pulse-per-unit, p. 33  
 Restore Database, p. 43  
 Reset CRC, p. 44  
 Reset Total/Elapsed Time, p. 42  
 Selecting from a list, p. 30  
 Serial Communication, p. 35  
 Simulation, p. 44  
 Unit-per-pulse, p. 33  
 Unit settings, p. 37  
 Using the Local Display, p. 30  
 Replacements Fuses, p. 69  
 Restore Database, p. 43  
 Reset Total/Elapsed Time, p. 42  
 Return Procedure, p. 80  
 Sensor Cleaning, p. 69  
 Sensor Orientation, p. 19  
 Simulation Mode, p. 44  
 Theory of Operation, p. 14  
 To program the display, p. 36  
 Totalizer Rollover, p. 42  
 Troubleshooting, p. 70  
     Alarm Codes, p. 74  
     General, p. 71  
     Installation Problems, p. 73  
 USB Interface, p. 28  
 Warranty, p. 79  
 Wiring  
     Alarms, p. 25  
     Pulse/Alarm Outputs, p. 25  
     Grounding, p. 21  
     Input - Local, p. 22  
     Instructions, p. 21  
     Local meters, p. 22  
     Power Input, p. 22  
     Precautions, p. 21



**Wiring**



**Definition of Terms**



**Troubleshooting Tips**



**Information**



**Caution - (refer to accompanying documents):  
Please follow the specified instructions and  
general safety practices.**



**Indicates compliance with the WEEE Directive.  
Please dispose of the product in accordance  
with local regulations and conventions.**



**Indicates compliance with the applicable  
European Union Directives for Safety and  
EMC (Electromagnetic Compatibility Directive  
2014/30/EU).**