

# RM3544-01

# HIOKI

# RM3545, RM3545-01, RM3545-02

# RM3545A-1, RM3545A-2

# RM3546

## Communication Command Instruction Manual

# RESISTANCE METER



Check for the latest edition and other language versions.



- ✓ This command manual provides information to help you program the HIOKI Resistance Meter Series: RM3544, RM3545, RM3545A, and RM3546.
- ✓ For information on the remote interface configuration of the resistance meters, please refer to the main unit's instruction manual.
- ✓ Although all reasonable care has been taken in the production of this instruction manual, should you find any points which are unclear or in error, please contact your local distributor or HIOKI's website. (<https://www.hioki.com/contact>)
- ✓ The material contained in this document is subject to being changed, without notice, in future editions.
- ✓ Unauthorized copying and replication of the contents of this instruction manual are strictly prohibited.

# Contents

1 Introduction.....	1
Message Format.....	1
Output Queue and Input Buffer .....	5
Status Byte Register .....	6
Event Registers .....	8
Initialization Items .....	11
Command Execution Time .....	12
About Communication Errors .....	12
2 Message List .....	13
3 Message Reference .....	23
Message Reference Interpretation .....	23
Standard Commands.....	24
(1) System Data Command .....	24
*IDN	
(2) Internal Operation Command .....	24
*RST	
*TST	
(3) Synchronization Commands .....	25
*OPC	
*WAI	
(4) Status and Event Control Commands.....	25
*CLS	
*ESE	
*ESR	
*SRE	
*STB	
*TRG	
Device-Specific Commands .....	27
(1) Event Status Register.....	27
:ESE0	
:ESR0	
:ESE1	
:ESR1	
(2) Reading Measured Values .....	28
:FETCh	
:FETCh:TEMPerature	
:READ	
:MEASure:RESistance	
:MEASure:RESistance:LP	
:MEASure:TEMPerature	
:ABORt	
(3) Zero Adjustment .....	33
:ADJust	
:ADJust:CLEar	
:ADJust:STATe	
:ADJust:ENABle	
(4) Measurement Speed .....	35
:SAMPle:RATE	
(5) Averaging Function.....	35
:CALCulate:AVERAge:STATe	
:CALCulate:AVERAge:COUNT	
(6) Comparator.....	35
:CALCulate:LIMit:STATe	
:CALCulate:LIMit:BEEPer	
:CALCulate:LIMit:MODE	
:CALCulate:LIMit:UPPer	
:CALCulate:LIMit:LOWer	
:CALCulate:LIMit:REFerence	
:CALCulate:LIMit:PERCent	

	<b>:CALCulate:LIMit:RESult</b>	
	<b>:CALCulate:LIMit:JUDGe:CONDition</b>	
	<b>:CALCulate:LIMit:JUDGe</b>	
	<b>:CALCulate:LIMit:JUDGe:TOTal</b>	
(7)	BIN Function <b>RM3545</b> <b>RM3545A</b> <b>RM3546</b>	38
	<b>:CALCulate:BIN:STATe</b>	
	<b>:CALCulate:BIN:ENABle</b>	
	<b>:CALCulate:BIN:MODE</b>	
	<b>:CALCulate:BIN:UPPer</b>	
	<b>:CALCulate:BIN:LOWer</b>	
	<b>:CALCulate:BIN:REFerence</b>	
	<b>:CALCulate:BIN:PERCent</b>	
	<b>:CALCulate:BIN:RESult</b>	
(8)	Statistical Functions <b>RM3545</b> <b>RM3545A</b> <b>RM3546</b>	40
	<b>:CALCulate:STATistics:STATe</b>	
	<b>:CALCulate:STATistics:CLEar</b>	
	<b>:CALCulate:STATistics:NUMBer?</b>	
	<b>:CALCulate:STATistics:MEAN?</b>	
	<b>:CALCulate:STATistics:MAXimum?</b>	
	<b>:CALCulate:STATistics:MINimum?</b>	
	<b>:CALCulate:STATistics:LIMit?</b>	
	<b>:CALCulate:STATistics:BIN?</b>	
	<b>:CALCulate:STATistics:DEVIation?</b>	
	<b>:CALCulate:STATistics:CP?</b>	
(9)	Scaling	41
	<b>:CALCulate:SCALing:STATe</b>	
	<b>:CALCulate:SCALing:PARAmeterA</b>	
	<b>:CALCulate:SCALing:PARAmeterB</b>	
	<b>:CALCulate:SCALing:UNIT</b>	
(10)	Temperature Conversion ( $\Delta T$ ) <b>RM3545</b> <b>RM3545A</b> <b>RM3546</b>	42
	<b>:CALCulate:TCONversion:DELTA:STATe</b>	
	<b>:CALCulate:TCONversion:DELTA:PARAmeter</b>	
(11)	Temperature Correction (TC)	43
	<b>:CALCulate:TCORrect:STATe</b>	
	<b>:CALCulate:TCORrect:PARAmeter</b>	
(12)	Advanced Temperature Correction (A-TC) <b>RM3546</b>	43
	<b>:ATC:TCORrect:STATe</b>	
	<b>:ATC:TCORrect:PARAmeter</b>	
	<b>:ATC:TCONversion:DELTA:PARAmeter</b>	
	<b>:ATC:TERMinal</b>	
	<b>:ATC:RATE</b>	
	<b>:ATC:RANGe:AUTO</b>	
	<b>:ATC:RANGe</b>	
	<b>:ATC:DELAy:AUTO</b>	
	<b>:ATC:DELAy</b>	
	<b>:ATC:AVERAge:STATe</b>	
	<b>:ATC:AVERAge:COUNT</b>	
	<b>:ATC:AOVC</b>	
	<b>:ATC:PR:STATe</b>	
	<b>:ATC:CURREnt</b>	
	<b>:ATC:CONTActcheck</b>	
	<b>:ATC:CIMProve</b>	
(13)	Reading Measured Values in Advanced Temperature Correction (A-TC) <b>RM3546</b>	47
	<b>:ATC:FETCh?</b>	
	<b>:ATC:READ?</b>	
	<b>:ATC:INITiate</b>	
(14)	LCD Settings	49
	<b>:DISPLay:CONTRast</b>	
	<b>:DISPLay:BACKlight</b>	
(15)	Memory Functions <b>RM3545</b> <b>RM3545A</b> <b>RM3546</b>	49
	<b>:MEMORy:STATe</b>	

	<b>:MEMory:CLEar</b>	
	<b>:MEMory:COUNT</b>	
	<b>:MEMory:DATA</b>	
(16)	Hold	50
	[:SENSe:]HOLD:AUTO	
	[:SENSe:]HOLD:STATe	
	[:SENSe:]HOLD:OFF	
(17)	Multiplexer Settings <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span>	51
	[:SENSe:]WIRE	
	[:SENSe:]SCAN:MODE	
	[:SENSe:]SCAN:STATe	
	[:SENSe:]SCAN:RESet	
	[:SENSe:]SCAN:FAIL:STOP	
	[:SENSe:]SCAN:DATA	
	[:SENSe:]FRONTcheck?	
	[:SENSe:]CH	
	[:SENSe:]CH:STATe	
	[:SENSe:]CH:AVAIrable	
	[:SENSe:]INSTrument	
	[:SENSe:]TERMinal	
(18)	Multiplexer Channel Reset <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span>	54
	[:SENSe:]CHRReset	
(19)	Low-Power Resistance Measurement <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span>	55
	[:SENSe:]RESistance:LP:STATe	
(20)	Pure Resistance measurement <span>RM3545A</span> <span>RM3546</span>	55
	[:SENSe:]RESistance:PR:STATe	
(21)	Measurement Range	56
	[:SENSe:]RESistance:RANGe	
	[:SENSe:]RESistance:RANGe:AUTO	
	[:SENSe:]RESistance:LP:RANGe	
(22)	100MΩ Range High Precision Function <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span>	57
	[:SENSe:]RESistance:PRECision	
(23)	Switching Measurement Current <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span>	58
	[:SENSe:]RESistance:CURRent	
(24)	Offset Voltage Compensation Function (OVC) <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span>	58
	[:SENSe:]RESistance:OVC	
(25)	Advanced Offset Voltage Compensation Function (A-OVC) <span>RM3546</span>	59
	[:SENSe:]RESistance:AOVC	
(26)	Contact Improver <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span>	59
	[:SENSe:]RESistance:CIMProve	
(27)	Current Error Mode	59
	[:SENSe:]RESistance:ERRor:CURRentcheck	
	[:SENSe:]RESistance:ERRor:OVER	
(28)	Contact Check <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span>	60
	[:SENSe:]RESistance:CONTactcheck	
	[:SENSe:]RESistance:LP:CONTactcheck	
(29)	Setting Number of Digits	60
	[:SENSe:]RESistance:DIGits	
(30)	Temperature Measurement (Analog Input) <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span>	61
	[:SENSe:]TEMPerature:SENSor	
	[:SENSe:]TEMPerature:PARAmeter	
(31)	Triggering	62
	:INITiate:CONTInuous	
	:INITiate[:IMMediate]	
	:TRIGger:SOURce	
	:TRIGger:EDGE	
(32)	Delay <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span>	66
	:TRIGger:DELay	
	:TRIGger:DELay:AUTO	
(33)	Self-Calibration <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span>	66

<b>:SYSTEM:CALibration</b>	
<b>:SYSTEM:CALibration:AUTO</b>	
(34) Saving and Reading Measurement Conditions.....	67
<b>:SYSTEM:PANel:SAVE/:LOAD</b>	
<b>:SYSTEM:PANel:NAME</b>	
<b>:SYSTEM:PANel:CLEar</b>	
(35) Absolute Value Display.....	68
<b>:SYSTEM:ABSolute</b>	
(36) Key-Lock.....	68
<b>:SYSTEM:KLOCK</b>	
(37) Line Frequency.....	68
<b>:SYSTEM:LFRequency</b>	
(38) Clock <span style="border: 1px solid black; padding: 0 2px;">RM3545</span> <span style="border: 1px solid black; padding: 0 2px;">RM3545A</span> <span style="border: 1px solid black; padding: 0 2px;">RM3546</span> .....	69
<b>:SYSTEM:DATE</b>	
<b>:SYSTEM:TIME</b>	
(39) Key Beeper.....	69
<b>:SYSTEM:BEEPer:STATe</b>	
(40) Communications Settings.....	70
<b>:SYSTEM:LOCAl</b>	
<b>:SYSTEM:DATAout</b>	
<b>:SYSTEM:HEADer</b>	
<b>:SYSTEM:TERMinator</b>	
<b>:SYSTEM:COMMunicate</b>	
<b>:SYSTEM:COMMunicate:MONitor</b>	
<b>:SYSTEM:COMMunicate:LAN:IPADdress</b>	
<b>:SYSTEM:COMMunicate:LAN:SMASK</b>	
<b>:SYSTEM:COMMunicate:LAN:GATeway</b>	
<b>:SYSTEM:COMMunicate:LAN:CONTRol</b>	
<b>:SYSTEM:COMMunicate:LAN:MAC?</b>	
<b>:SYSTEM:COMMunicate:LAN:UPDate</b>	
<b>:SYSTEM:COMMunicate:RS232C:SPEED</b>	
(41) System Reset.....	73
<b>:SYSTEM:RESet</b>	
(42) EXT I/O.....	73
<b>:IO:MODE?</b>	
<b>:IO:INPut?</b>	
<b>:IO:OUTPut</b>	
<b>:IO:FILTer:STATe</b>	
<b>:IO:FILTer:TIME</b>	
<b>:IO:JUDGe:MODE</b>	
<b>:IO:EOM:MODE</b>	
<b>:IO:EOM:PULSe</b>	
(43) Multiplexer Unit <span style="border: 1px solid black; padding: 0 2px;">RM3545</span> <span style="border: 1px solid black; padding: 0 2px;">RM3545A</span> <span style="border: 1px solid black; padding: 0 2px;">RM3546</span> .....	74
<b>:UNIT:IDN</b>	
<b>:UNIT:SCOunt</b>	
<b>:UNIT:TEST</b>	
4 Multiplexer Commands.....	76
Multiplexer Settings.....	76
Multiplexer Measurement.....	77
5 Data Exporting Methods.....	80
6 Examples of communication commands.....	83
■ Confirmation before measurement.....	83
■ Setting measurement conditions.....	83
■ Simple resistance measurement.....	83
■ Resistance measurement using computer keys.....	83
■ Measurement by external trigger 1.....	84
■ Measurement by external trigger 2.....	84
■ LAN communication setting example <span style="border: 1px solid black; padding: 0 2px;">RM3545A</span> <span style="border: 1px solid black; padding: 0 2px;">RM3546</span> .....	84
■ Example of Advanced Temperature Correction (A-TC) <span style="border: 1px solid black; padding: 0 2px;">RM3546</span> .....	84
7 Sample Programs.....	87
Using Visual Basic.....	87

Using Visual C# .....	95
8 Device Compliance Statement [GP-IB].....	104



## ■ Response Messages

When a query message is received, its syntax is checked and a response message is generated.

The **:SYSTEM:HEADer** command determines whether headers are prefixed to response messages.

Header ON **:SENSE:RESISTANCE:RANGE 100.000E+03**

Header OFF **100.000E+03**

(The current resistance measurement range is 100kΩ)

At power-on, Header OFF is selected.

If an error occurs when a query message is received, no response message is generated for that query.

Some query message has no header, such as **:FETCH?** and **:CALCulate:LIMit:RESult?**.

## ■ Command Syntax

Command names are chosen to mnemonically represent their function, and can be abbreviated. The full command name is called the “long form”, and the abbreviated name is called the “short form”. The command references in this manual indicate the short form in upper-case letters, extended to the long form in lower case letters. The commands are not case-sensitive.

**ADJUST?** OK (long form)

**ADJ?** OK (short form)

**ADJU?** Error

**AD?** Error

Response messages generated by the instrument are in long form and in upper case letters.

## ■ Headers

Headers must always be prefixed to program messages.

### (1) Command Program Headers

There are three types of commands: Simple, Compound, and Standard.

- **Headers for Simple Commands**

This header type is a sequence of letters and digits

**:ESE0**

- **Headers for Compound Commands**

These headers consist of multiple simple command type headers separated by colons “:”

**:SAMPLE:RATE**

- **Headers for Standard Commands**

This header type begins with an asterisk “\*”, indicating that it is a standard command defined by IEEE 488.2.

**\*RST**

### (2) Query Program Header

The following commands are used to request results of operations/measured values/the current setting states.

As shown by the following examples, a query is formed by appending a question mark “?” after a program header.

**:FETCh?**

**:CALCulate:LIMit:REFerence?**

Characters within square brackets [ ] may be omitted.

**[ :SENSe:]RESistance:RANGe**



Either form is valid

**:SENSe:RESistance:RANGe**  
**RESistance:RANGe**

## ■ Message Terminators

This instrument recognizes the following message terminators (delimiters):

[RS-232C/USB/LAN]

- CR
- CR+LF

[GP-IB]

- LF
- CR+LF
- EOI
- LF with EOI

Response message terminator can be selected from the below.

For information on settings, see “Delimiter Setting” (p. 70).

[RS-232C/USB/LAN]

- CR+LF

[GP-IB]

- LF with EOI (default setting)
- CR+LF with EOI

## ■ Separators

### (1) Message Unit Separator

Multiple messages can be written in one line by separating them with semicolons “;”

**:SYSTEM:LFREQUENCY 60;\*IDN?**

- When messages are combined in this way and if one command contains an error, subsequent messages will not be processed.
- A query message must be the last item in a line. No messages can follow a query message.

### (2) Header Separator

In a message consisting of both a header and data, the header is separated from the data by a space “ ” (ASCII code 20H).

**:SYSTEM:HEADER OFF**

### (3) Data Separator

In a message containing multiple data items, commas are required to separate the data items from one another.

**:CALCulate:LIMit:BEEPer IN,1,0**

## ■ Data Formats

The instrument uses character data, decimal numeric data and character string data depending on the command. Make sure that the data is provided in the specified format.

### (1) Character Data

Character data always begins with an alphabetic character, and subsequent characters may be either alphabetic or numeric. Character data is not case-sensitive, although response messages from the instrument are only upper case. When command data portion lists `<1/0/ON/OFF>`, "1" corresponds to "ON" and "0" corresponds to "OFF". The both alphabetic string and numeric data are interchangeable.

**:SYSTEM:HEADER OFF**

### (2) Decimal Numeric Data

Numerical data formats include NR1, NR2, and NR3 formats. The instrument accepts both signed and unsigned numbers, respectively. For unsigned numbers, the instrument treats them as positive numbers. If the precision of the value exceeds the range of the instrument, it will be rounded off.

- NR1 Integer data (e.g.: +12, -23, 34)
- NR2 Fixed-point data (e.g.: +1.23, -23.45, 3.456)
- NR3 Floating-point exponential representation data (e.g.: +1.0E-2, -2.3E+4)

The term "NRf format" includes all three of the above numeric decimal formats.

The instrument accepts NRf format data. The format of response data is specified for each command, and the data is sent in that format.

Note: A "+" sign is returned as a space (ASCII code 20H).

**:ESE0 106**

**:FETCH?**

**+106.5710E+03**

### (3) Character string data

- Character string data is enclosed by quotation marks.
- This type of data consists of 8-bit ASCII characters.
- Characters that cannot be handled by the instrument are replaced with a parameter error.
- As for quotation marks, the sender uses double quotes (") only, while the receiver receives both double quotes and single quotes (').

**:SYSTem:PANel:NAME 1, "PANEL\_01"**

### [GP-IB]

The instrument does not fully support IEEE 488.2. As much as possible, please use the data formats shown in the Reference section.

Also, be careful to avoid constructing single commands line that could overflow the input buffer or output queue.

## ■ Compound Command Header Omission

Compound commands that have a common leading part (e.g., **:CALCulate:LIMit:REFeRence** and **:CALCulate:LIMit:PERCent**) can omit the common part (here, **:CALCulate:LIMit:**) only if they are written in succession.

This common portion is called the “current path”, and until this is cleared, subsequent commands will be regarded as their current paths are omitted.

This usage of the current path is shown in the following example:

### Full expression

**:CALCulate:LIMit:REFeRence 1.0E+3;:CALCulate:LIMit:PERCent 1.0**

### Compacted expression

**:CALCulate:LIMit:REFeRence 1.0E+3;PERCent 1.0**



This portion becomes the current path, and can be omitted from the messages immediately following.

A 'Current path' is cleared in the following cases: when the power is turned on, when a reset operation is performed via key input, when a colon ':' is detected at the first header, or when a message terminator is detected.

Standard command messages can be executed regardless of the current path. They have no effect upon the current path.

A colon ":" is not required at the first header on a Simple or Compound command. However, to avoid confusion with abbreviated forms and to prevent operational mistakes, we recommend always placing a colon at the first header.

## Output Queue and Input Buffer

### ■ Output Queue

Response messages are stored in the output queue until they were read by the controller. The output queue is also cleared in the following circumstances:

- The instruments are powered on.
- Device clear [GP-IB]
- When a query error occurred

The output queue size is 64 bytes. If response messages overflow the storage size, a query error is generated and the output queue is cleared.

Also, with GP-IB, if a new message is received while data remains in the output queue, the output queue is cleared and a query error is generated.

### ■ Input Buffer

The input buffer size is 256 bytes.

If more than 256 bytes of data are sent and the input buffer becomes full, the USB and GP-IB communication will enter WAITING state until the input buffer becomes available.


The RS-232C and LAN interface will not accept data beyond 256 bytes.

Note: The length of each command line must be less than 256 bytes.

## Status Byte Register

[GP-IB]

This instrument implements the status model specified in IEEE 488.2 for the parts related to serial polling by the service request function. An "event" is a condition that causes a service request to be generated.



Overview of Service Request Occurrence

The Status Byte Register contains information from the Event Register and the Output Queue. The Service Request Enable Register allows you to select the necessary information from this information. When the selected information is set, bit 6 (MSS Master Summary Status Bit) of the Status Byte Register is set, generating an SRQ (Service Request) message, which causes a service request.

**Note:SRQ (Service Request) is a GP-IB function only. However, STB (Status Byte Register) information can be acquired with RS-232C/USB/LAN using the \*STB? command.**

[RS-232C/USB/LAN]

RS-232C/USB/LAN does not provide a function for issuing service requests. Still, SRER setup and STB reading are available.

## ■ Status Byte Register (STB)

The Status Byte Register is an 8-bit register that is output from the instrument to the controller when a serial poll is performed. If any bit in the Status Byte Register, among the enabled Service Request Enable Register, changes from '0' to '1', the MSS bit will become '1'. At the same time, the SRQ bit will also change to "1," and a service request will occur.

The SRQ bit is always synchronized with a service request. Normally, it is only read when polled and is cleared at the same time. The MSS bit can only be read with the **\*STB?** query; however, it is not cleared until the event is cleared with the **\*CLS** or other commands.

<b>Bit 7</b>		unused
<b>Bit 6</b>	SRQ	Set to 1 when a service request is dispatched.
	MSS	This is the logical sum of the other bits of the Status Byte Register.
<b>Bit 5</b>	ESB	Standard Event Status (logical sum) bit This is logical sum of the Standard Event Status Register.
<b>Bit 4</b>	MAV	Message available Indicates that a message is present in the output queue.
<b>Bit 3</b>		unused
<b>Bit 2</b>		unused
<b>Bit 1</b>	ESB1	Event Status (logical sum) bit 1 This is the logical sum of Event Status Register 1.
<b>Bit 0</b>	ESB0	Event Status (logical sum) bit 0 This is the logical sum of Event Status Register 0.

## ■ Service Request Enable Register (SRER)

When each bit in the Service Request Enable Register is set to "1", the corresponding bit in the Status Byte Register becomes available.

## Event Registers

### ■ Standard Event Status Register (SESR)

The Standard Event Status Register is an 8-bit register. If any bit in the Standard Event Status Register is set to 1 (after masking by the Standard Event Status Enable Register), bit 5 (ESB) of the Status Byte Register is set to 1.

See: “Standard Event Status Register (SESR) and Standard Event Status Enable Register (SESER)” (p.9)

The Standard Event Status Register is cleared in the following situations:


- When a **\*CLS** command is executed
- When an event register query (**\*ESR?**) is executed
- When the instrument is powered on

Bit 7	PON	<b>Power-On Flag</b> Set to 1 when the power is turned on, or upon recovery from an outage.
Bit 6	URQ	<b>User Request</b> unused
Bit 5	CME	<b>Command error (The command to the message terminator is ignored.)</b> This bit is set to 1 when a received command contains a syntactic or semantic error: <ul style="list-style-type: none"> <li>• Program header error</li> <li>• Incorrect number of data parameters</li> <li>• Invalid parameter format</li> <li>• Received a command not supported by the instrument</li> </ul>
Bit 4	EXE	<b>Execution Error</b> This bit is set to 1 when a received command cannot be executed for some reason. <ul style="list-style-type: none"> <li>• The specified data value is outside of the set range</li> <li>• The specified setting data cannot be set</li> <li>• Execution is prevented by some other operation being performed</li> </ul>
Bit 3	(unused) DDE	<b>Not used by this instrument</b> <b>Device-Dependent Error</b> This bit is set to 1 when a command cannot be executed due to some reason other than a command error, a query error or an execution error.
Bit 2	QYE	<b>Query Error (the output queue is cleared)</b> This bit is set to 1 when a query error is detected by the output queue control. <ul style="list-style-type: none"> <li>• When an attempt has been made to read an empty output queue (GP-IB only)</li> <li>• When the data overflows the output queue</li> <li>• When data in the output queue has been lost</li> <li>• When the next command is received while there is data in the output queue</li> </ul>
Bit 1	RQC (unused)	<b>Request Control</b>
Bit 0	OPC	<b>Operation Complete</b> This bit is set to 1 in response to an <b>*OPC</b> command. <ul style="list-style-type: none"> <li>• It indicates the completion of operations of all messages up to the <b>*OPC</b> command</li> </ul>

## ■ Standard Event Status Enable Register (SESER)

Setting any bit of the Standard Event Status Enable Register to 1 enables access to the corresponding bit of the Standard Event Status Register.

Standard Event Status Register (SESR) and Standard Event Status Enable Register (SESER)



## ■ Device-Specific Event Status Registers (ESR0 and ESR1)

The instruments provide two Event Status Registers for controlling events. Each event register is an 8-bit register. [RM3545](#) [RM3545A](#) [RM3546](#) Event Status Register 1 is available only for RM3545/RM3545A/RM3546.

If any bit in the Status Byte Register, among the enabled Service Request Enable Register, changes from '0' to '1', the following register will be set:

- For Event Status Register 0, bit 0 (ESB0) of the Status Byte Register (STB) is set to 1.
- For Event Status Register 1, bit 1 (ESB1) of the Status Byte Register (STB) is set to 1.

Event Status Registers 0 and 1 are cleared in the following situations:

- When a **\*CLS** command is executed
- When an Event Status Register query (**:ESR0?** or **:ESR1?**) is executed
- When the instrument is powered on


**Event Status Register 0 (ESR0)**

Bit 7	OutBIN	Out of BIN <a href="#">RM3545</a> <a href="#">RM3545A</a> <a href="#">RM3546</a>
Bit 6	OvrRng	Out-of-Range
Bit 5	ERR	Measurement Fault
Bit 4	Hi	High Comparator Result
Bit 3	IN	IN Comparator Result
Bit 2	Lo	Low Comparator Result
Bit 1	INDEX	End of Reading
Bit 0	EOM	End of Measurement

**Event Status Register 1 (ESR1) [RM3545](#) [RM3545A](#) [RM3546](#)**

Bit 7		Unused
Bit 6		Unused
Bit 5	PROTECT	Over-voltage/temperature Protection <a href="#">RM3546</a>
Bit 4	NO UNIT	Multiplexer Unit Not Inserted, Terminal Setting Error
Bit 3	SW.ERR	Multiplexer Relay Hot Switching Prevention Function Fault
Bit 2	CURR	Current Monitor Fault
Bit 1	CONTACT TERM.A	Contact Check – A side Fault
Bit 0	CONTACT TERM.B	Contact Check – B side Fault

Event Status Registers 0 (ESR0) and 1 (ESR1), and Event Status Enable Registers 0 (ESER0) and 1 (ESER1)



## ■ Register Reading and Writing

Register	Read	Write
Status Byte Register	<b>*STB?</b>	-
Service Request Enable Register	<b>*SRE?</b>	<b>*SRE</b>
Standard Event Status Register	<b>*ESR?</b>	-
Standard Event Status Enable Register	<b>*ESE?</b>	<b>*ESE</b>
Event Status Register 0	<b>:ESR0?</b>	-
Event Status Enable Register 0	<b>:ESE0?</b>	<b>:ESE0</b>
Event Status Register 1	<b>:ESR1?</b>	-
Event Status Enable Register 1	<b>:ESE1?</b>	<b>:ESE1</b>

## ■ GP-IB Commands(RM3545-01)

The following commands can be used for performing interface functions.

Command	Description
GTL	Go To Local Cancels the Remote state and enters the Local state.
LLO	Local Lock Out Disables all keys, including the Local key.
DCL	Device CLear Clears the input buffer and the output queue.
SDC	Selected Device Clear Clears the input buffer and the output queue.
GET	Group Execute Trigger When an external trigger (trigger source <EXTERNAL>) occurs, processes one sample.

## Initialization Items

Item	Initialization Method	At Power-on	Key Reset	*RST Com-mand	Device Clear (GP-IB only)	*CLS Com-mand	Factory Default
LAN setting RM3545A RM3546	IP address	-	0.0.0.0	-	-	-	0.0.0.0
	Subnet mask		255.255.255.0				255.255.255.0
	Gateway		0.0.0.0				0.0.0.0
	Communications command port number		23				23
GP-IB Address RM3545-01		-	1	-	-	-	1
RS-232C setting (baud rate)		-	9600	-	-	-	9600
Device-specific functions (range, etc.)		-	●	●	-	-	●
Output Queue		●	●	-	●	-	●
Input buffer		●	●	-	●	-	●
Status Byte Register		●	●	-	●*1	●*2	●
Event registers		●*3	●	-	-	●	●
Enable register		●	●	-	-	-	●
Current path		●	●	-	●	-	●
Headers on/off		OFF	OFF	OFF	-	-	OFF

Response message terminator (GP-IB) <b>[RM3545-01]</b>	LF+EOI	LF+EOI	-	-	-	LF+EOI
Response message separator	;	;	;	-	-	;

\*1. Only the MAV bit (bit 4) is cleared.

\*2. All bits except the MAV bit are cleared.

\*3. Except the PON bit (bit 7).

## Command Execution Time

Command execution time indicates the time for analyzing and processing long form commands.

However, execution time for the commands with data is defined according to the data format specified in the <data portion>, and for query commands it is the time when the header is ON.

- Display delays may occur depending on the frequency of communication processes and process contents.
- All commands except **\*TRG** and **:INIT** are processed sequentially.
- In communications with the controller, time must be added for data transmission. USB, LAN and GP-IB transfer time depends on the controller.

The RS-232C transfer time, with start bit 1, data length 8, no parity, and stop bit 1, has a total of 10-bit. When the transfer speed (baud rate) setting is N bps, the general result will be as follows:

Transfer time T [1 character/sec] = Baud rate N [bps]/10 [bits]

Since a measurement value is 11 characters, a 1 data transfer time will be 11/T.

(Example) For 9600 bps,  $11/(9600/10)$  = Approx. 11 ms

- Wait until measurements stabilize after a change before using a setting command.

Command	Execution time (except communication time)	
	RM3544	RM3545, RM3545A, RM3546
<b>*RST</b>	700 ms or less	1.5s or less
<b>:RESistance:RANGe</b>	300 ms or less	100 ms or less
<b>:SAMPlE:RATE</b>	200 ms or less	30 ms or less
<b>[[:SENSE:]CH</b>	-	50 ms or less *1
<b>:ADJust?</b>	600 ms or less *2	
<b>:FETCh?</b>	5 ms or less	
<b>:READ?</b>	Measurement time + 15 ms or less	
<b>:SYSTem:PANel:LOAD</b>	500 ms or less	Panel 1 to 30:100 ms or less Panel 31 to 38:200 ms or less
<b>:SYSTem:CALibration</b>	-	400ms or less
<b>*TST?</b>	1 s or less	
<b>:UNIT:TEST?</b>	3s or less	
Commands other than those above	10 ms or less	

\*1 If there is a counter-electromotive force, such as a transformer, the switching takes longer due to the hot switching prevention function for the relay. The hot switching prevention function is canceled when the counter-electromotive force is lost or a maximum 1 second + delay set value elapses.

\*2 Manual range, for one channel

## About Communication Errors

An error occurs when messages are executed in the following cases:

- **Command Error**  
When message syntax (spelling) is invalid  
When the data format in a command or query is invalid
- **Query Error**  
When the response message exceeds 64 bytes
- **Execution Error**  
When invalid character or numeric data is present

## 2 Message List

Message [: Omissible]	Data Formats [: Omissible ( ): Response data	Description	Corresponding Model				
			RM 3544	RM3545 By channel	RM3545A / RM3546	By channel	
<b>Standard Commands</b>							
*IDN?	(<Manufacturer name>,<Model name>,<Serial number>,<Software version>)	Queries the Device ID.	√	√	-	√	-
*RST		Initializes the device.	√	√	-	√	-
*TST?	(0 to 3)	Initiates a self-test and queries the result.	√	√	-	√	-
*OPC		Requests an SRQ after execution completion.	√	√	-	√	-
*OPC?	(1)	Queries execution completion.	√	√	-	√	-
*WAI		Wait for operations to finish.	√	√	-	√	-
*CLS		Clears the event registers and the Status Byte Register.	√	√	-	√	-
*ESE	0 to 255	Sets the Standard Event Status Enable Register.	√	√	-	√	-
*ESE?	0 to 255	Queries the Standard Event Status Enable Register.	√	√	-	√	-
*ESR?	0 to 255	Queries the Standard Event Status Register.	√	√	-	√	-
*SRE	0 to 255	Sets the Service Request Enable Register.	√	√	-	√	-
*SRE?	(0 to 255)	Queries the Service Request Enable Register.	√	√	-	√	-
*STB?	(0 to 255)	Queries the Status Byte Register.	√	√	-	√	-
*TRG		Executes one sampling.	√	√	-	√	-
<b>Event Registers</b>							
:ESE0	0 to 255	Sets the Event Status Enable Register 0.	√	√	-	√	-
:ESE0?	(0 to 255)	Queries the Event Status Enable Register 0.	√	√	-	√	-
:ESR0?	(0 to 255)	Queries the Event Status Register 0.	√	√	-	√	-
:ESE1	0 to 255	Sets the Event Status Enable Register 1.	√	√	-	√	-
:ESE1?	(0 to 255)	Queries the Event Status Enable Register 1.	√	√	-	√	-
:ESR1?	(0 to 255)	Queries the Event Status Register 1.	√	√	-	√	-
<b>Reading Measured Values</b>							
:FETCh?	RM3544:[<LIMit>] (<Measurement value> [ ,<HI/IN/LO/OFF/ERR>]) RM3545/RM3545A/RM3546 :[<LIMit/JUDGe/LIMJdge>,< Channel number>](Measured value>,[<HI/IN/LO/OFF/ERR >][<PASS/FAIL/OFF/ERR>]	Reads the most recent measurement. • When data has been omitted: Reads the measurement value only. • When data has been set to LIMit: Reads the measurement value and comparator result.  • When data has been set to JUDGe: Reads the measured value and PASS/FAIL result. • When data has been set to LIMJdge: Reads the measured value, and comparator and PASS/FAIL results.	√	√	√	√	√
:FETCh:TEMPerature?	(<Temperature measurement value>)	Reads the temperature measurement value.	√	√	-	√	-
:READ?	RM3544:(<Measurement value>) RM3545/RM3545A/RM3546 :<NDATa/JUDGe> For scanning OFF/STEP:(< Measured value>) For AUTO scanning:[<	Waits for trigger and reads the measured value. RM3545/RM3545A/RM3546: Responds with the total judgment or PASS/FAIL result only if NDATa is included in the data formats.	√	√	-	√	-

Message [: Omissible]	Data Formats [: Omissible ( ): Response data	Description	Corresponding Model				
			RM 3544	RM3545		RM3545A / RM3546	
					By channel		By channel
	Measured value>, <Measured value> ...<Measured value>] [<PASS/FAIL/OFF/ERR>]	Adds and responds with the total judgment if JUDGE is included in the data formats.					
:MEASure:RESistance?	[<Expected measurement value>](measurement value)	Presets to the specified resistance measurement range; then measures.	√	√	-	√	-
:MEASure:RESistance:LP?	[<Expected measurement value>](measurement value)	Presets to the specified Low-Power Resistance measurement range; then measures.	-	√	-	√	-
:MEASure:TEMPerature?	(<Temperature measurement value>)	Reads the temperature measurement value.	√	√	-	√	-
:ABORt		:READ /Scan measurement / Scan zero adjustment is aborted (forcibly terminated).	√	√	-	√	-

### Zero Adjustment

:ADJust?	(0/1)	Executes zero adjustment.	√	√	-	√	-
:ADJust:CLEar		Clears zero adjustment.	√	√	√	√	√
:ADJust:STATe?	(ON/OFF)	Queries the zero adjustment execution state.	-	√	√	√	√
:ADJust:ENABle	1/0/ON/OFF	Sets the scan zero adjustment execution (execution error for [:SENSe:]CH FRONT).	-	√	√	√	√
:ADJust:ENABle?	(ON/OFF)	Queries the scan zero adjustment execution (execution error for [:SENSe:]CH FRONT).	-	√	√	√	√

### Measurement Speed

:SAMPlE:RATE	RM3544:FAST/MEDIUM/SLOW RM3545/RM3545A/RM3546 :FAST/MEDIUM/SLOW1/SLOW2	Sets the measurement speed.	√	√	√	√	√
:SAMPlE:RATE?	RM3544:(FAST/MEDIUM/SLOW) RM3545/RM3545A/RM3546 :(FAST/MEDIUM/SLOW1/SLOW2)	Queries the measurement speed.	√	√	√	√	√

### Averaging Functions

:CALCulate:AVERage:STATe	1/0/ON/OFF	Sets the averaging function execution.	√	√	√	√	√
:CALCulate:AVERage:STATe?	(ON/OFF)	Queries the averaging function execution.	√	√	√	√	√
:CALCulate:AVERage:COUNT	2 to 100	Sets the average count.	√	√	√	√	√
:CALCulate:AVERage:COUNT?	(2 to 100)	Queries the average count.	√	√	√	√	√

### Comparator

:CALCulate:LIMit:STATe	1/0/ON/OFF	Sets the comparator operating state.	√	√	√	√	√
:CALCulate:LIMit:STATe?	(ON/OFF)	Queries the comparator operating state.	√	√	√	√	√
:CALCulate:LIMit:BEEPer	RM3544:<HI/IN/LO>,<0 to 3 (Type)>,<0 to 5 (Count)> RM3545/RM3545A/RM3546 :<HI/IN/LO/PASS/FAIL>,<0 to 3 (Type)>,<0 to 5 (Count)>	Sets the beep sound.	√	√	√	√	√
:CALCulate:LIMit:BEEPer?	RM3544:<HI/IN/LO>(<HI/IN/LO>,<0 to 3 (Type)>,<0 to 5 (Count)>) RM3545/RM3545A/RM3546 :<HI/IN/LO/PASS/FAIL>(<HI/IN/LO>,<0 to 3 (Type)>,<0 to 5 (Count)>)	Queries the beep sound.	√	√	√	√	√
:CALCulate:LIMit:MODE	ABSolute/REFerence	Sets the judgment mode.	√	√	√	√	√
:CALCulate:LIMit:MODE?	(ABSOLUTE/REFERENCE)	Queries the judgment mode.	√	√	√	√	√
:CALCulate:LIMit:UPPer	<Upper threshold>	Sets the upper threshold.	√	√	√	√	√
:CALCulate:LIMit:UPPer?	(<Upper threshold>)	Queries the upper threshold.	√	√	√	√	√
:CALCulate:LIMit:LOWer	<Lower threshold>	Sets the lower threshold.	√	√	√	√	√
:CALCulate:LIMit:LOWer?	(<Lower threshold>)	Queries the lower threshold.	√	√	√	√	√

Message [: Omissible]	Data Formats [: Omissible ( ): Response data	Description	Corresponding Model				
			RM 3544	RM3545		RM3545A / RM3546	
				By channel	By channel	By channel	By channel
:CALCulate:LIMit:REFEreNce	<Reference resistance>	Sets the reference resistance. (Channel 1 can be set for commands other than [:SENSe:]CH FRONT.)	√	√	√	√	√
:CALCulate:LIMit:REFEreNce?	(<Reference resistance>)	Queries the reference resistance. (Response may be Channel1 for commands other than [:SENSe:]CH FRONT.)	√	√	√	√	√
:CALCulate:LIMit:PERCent	<Range [%]>	Sets the judgment range.	√	√	√	√	√
:CALCulate:LIMit:PERCent?	(<Range [%]>)	Queries the judgment range.	√	√	√	√	√
:CALCulate:LIMit:RESult?	[<Channel number>] (HI/IN/LO/OFF/ERR)	Queries the comparator result.	√	√	√	√	√
:CALCulate:LIMit:JUDGe:CON Dition	OFF/IN/HI/LO/HILO/ALL	Sets the PASS judgment conditions.	-	√	√	√	√
:CALCulate:LIMit:JUDGe:CON Dition?	(OFF/IN/HI/LO/HILO/ALL)	Queries the PASS judgment conditions.	-	√	√	√	√
:CALCulate:LIMit:JUDGe?	[<Channel number>] (PASS/FAIL/OFF/ERR)	Queries the PASS/FAIL result.	-	√	√	√	√
:CALCulate:LIMit:JUDGe:TOTAl ?	(PASS/FAIL/OFF/ERR)	Queries the total judgment result.	-	√	√	√	√

**BIN Functions**

:CALCulate:BIN:STATe	1/0/ON/OFF	Sets the measurement execution.	-	√	-	√	-
:CALCulate:BIN:STATe?	(ON/OFF)	Queries the BIN measurement execution.	-	√	-	√	-
:CALCulate:BIN:ENABle	<Mask pattern>	Sets the mask pattern.	-	√	-	√	-
:CALCulate:BIN:ENABle?	(<Mask pattern>)	Queries the mask pattern.	-	√	-	√	-
:CALCulate:BIN:MODE	<BINNo.>,<ABSolute/REFe rence>	Sets the judgment mode.	-	√	-	√	-
:CALCulate:BIN:MODE?	<BINNo.>(<ABSOLUTE/RE FERENCE>)	Queries the judgment mode.	-	√	-	√	-
:CALCulate:BIN:UPPer	<BINNo.>,<Upper threshold>	Sets the upper threshold.	-	√	-	√	-
:CALCulate:BIN:UPPer?	<BINNo.>(<Upper threshold>)	Queries the upper threshold.	-	√	-	√	-
:CALCulate:BIN:LOWer	<BINNo.>,<Lower threshold>	Sets the lower threshold.	-	√	-	√	-
:CALCulate:BIN:LOWer?	<BINNo.>(<Lower threshold>)	Queries the lower threshold.	-	√	-	√	-
:CALCulate:BIN:REFe rence	<BINNo.>,<Reference resistance>	Sets the reference resistance.	-	√	-	√	-
:CALCulate:BIN:REFe rence?	<BINNo.>(<Reference resistance>)	Queries the reference resistance.	-	√	-	√	-
:CALCulate:BIN:PERCent	<BINNo.>,<Range [%]>	Sets the judgment range.	-	√	-	√	-
:CALCulate:BIN:PERCent?	<BINNo.>(<Range [%]>)	Queries the judgment range.	-	√	-	√	-
:CALCulate:BIN:RESult?	0 to 1023	Queries the comparator result.	-	√	-	√	-

**Statistical Functions**

:CALCulate:STATistics:STATe	1/0/ON/OFF	Sets the statistical calculation function execution.	-	√	-	√	-
:CALCulate:STATistics:STATe?	(ON/OFF)	Queries the statistical calculation function execution.	-	√	-	√	-
:CALCulate:STATistics:CLEar	Clear Statistical Calculation Result		-	√	-	√	-
:CALCulate:STATistics:NUMBe r?	(<Total data count>,<Valid data count>)	Queries the data count.	-	√	-	√	-
:CALCulate:STATistics:MEAN?	(<Mean>)	Queries the mean value.	-	√	-	√	-
:CALCulate:STATistics:MAXimu m?	(<Maximum value>,<Data no.>)	Queries the maximum value.	-	√	-	√	-
:CALCulate:STATistics:MINimu m?	(<Minimum value>,<Data no.>)	Queries the minimum value.	-	√	-	√	-
:CALCulate:STATistics:LIMit?	(<Hi count>,<IN count>,<Lo count>,<Measurement fault count>)	Queries the comparator results.	-	√	-	√	-
:CALCulate:STATistics:BIN?	(<BIN0 count>,...,<BIN9 count>,<OUT count>, <Measurement fault count>)	Queries the BIN result.	-	√	-	√	-
:CALCulate:STATistics:DEVIati on?	(< $\sigma$ >,< $\sigma$ -1>)	Queries the standard deviation.	-	√	-	√	-

Message [: Omissible]	Data Formats [: Omissible ( ): Response data	Description	Corresponding Model				
			RM 3544	RM3545		RM3545A / RM3546	
				By channel		By channel	
:CALCulate:STATistics:CP?	<Cp>,<Cpk>	Queries the process capability indices.	-	√	-	√	-

**Scaling**

:CALCulate:SCALing:STATe	1/0/ON/OFF	Sets the scaling function execution.	√	√	√	√	√
:CALCulate:SCALing:STATe?	(ON/OFF)	Queries the scaling function execution.	√	√	√	√	√
:CALCulate:SCALing:PARAmeterA	<0.2000E-3 to 2.0000E+3>	Sets the scaling gain.	√	√	√	√	√
:CALCulate:SCALing:PARAmeterA?	(0.2000E-3 to 2.0000E+3)	Queries the scaling gain.	√	√	√	√	√
:CALCulate:SCALing:PARAmeterB	RM3544:<0.0000E-9 to ±1.0000E+9> RM3545:<0.0000E-9 to ±9.0000E+9>	Sets the scaling offset.	√	√	√	√	√
:CALCulate:SCALing:PARAmeterB?	RM3544: (0.0000E-9 to ±1.0000E+9) RM3545: (0.0000E-9 to ±9.0000E+9)	Queries the scaling offset.	√	√	√	√	√
:CALCulate:SCALing:UNIT	<OFF/OHM/Any unit>	Sets the scaling unit.	√	√	√	√	√
:CALCulate:SCALing:UNIT?	(OFF/OHM/Any unit)	Queries the scaling unit.	√	√	√	√	√

**Temperature Conversion (ΔT)**

:CALCulate:TCONversion:DELTA:STATe	1/0/ON/OFF	Sets the temperature conversion execution.	-	√	√	√	√
:CALCulate:TCONversion:DELTA:STATe?	(ON/OFF)	Queries the temperature conversion execution.	-	√	√	√	√
:CALCulate:TCONversion:DELTA:PARAmeter	<Initial resistance>,<Initial temperature>,<Constant>	Sets the temperature conversion constant.	-	√	√	√	√
:CALCulate:TCONversion:DELTA:PARAmeter?	(<Initial resistance>,<Initial temperature>,<Constant>)	Queries the temperature conversion constant.	-	√	√	√	√

**Temperature Correction (TC)**

:CALCulate:TCORrect:STATe	1/0/ON/OFF	Sets the temperature correction execution.	√	√	√	√	√
:CALCulate:TCORrect:STATe?	(ON/OFF)	Queries the temperature correction execution.	√	√	√	√	√
:CALCulate:TCORrect:PARAmeter	<Reference temperature>,<Temperature coefficient>	Sets the temperature correction constant.	√	√	√	√	√
:CALCulate:TCORrect:PARAmeter?	(<Reference temperature>,<Temperature coefficient>)	Queries the temperature correction constant.	√	√	√	√	√

**Advanced Temperature Correction (A-TC) [RM3546]**

:ATC:TCORrect:STATe	1/0/ON/OFF	Sets the advanced temperature correction execution	-	-	-	√	√
:ATC:TCORrect:STATe?	(ON/OFF)	Queries the advanced temperature correction execution	-	-	-	√	√
:ATC:TCORrect:PARAmeter	<Reference temperature>,<Temperature coefficient>	Sets the constant for welding points	-	-	-	√	√
:ATC:TCORrect:PARAmeter?	(<Reference temperature>,<Temperature coefficient>)	Queries the constant for welding points	-	-	-	√	√
:ATC:TCONversion:DELTA:PARAmeter	<Resistance value>,<Reference temperature>,<Temperature coefficient>	Sets the constant for temperature measurement points	-	-	-	√	√
:ATC:TCONversion:DELTA:PARAmeter?	(<Resistance value>,<Reference temperature>,<Temperature coefficient>)	Queries the constant for temperature measurement points	-	-	-	√	√
:ATC:TERMinal	<Unit No>,<A Terminal Number>,<B Terminal Number>	Sets the connection for temperature measurement points	-	-	-	√	√
:ATC:TERMinal?	(<Unit No>,<A Terminal Number>,<B Terminal Number>)	Queries the connection for temperature measurement points	-	-	-	√	√
:ATC:RATE	FAST/MEDium/SLOW1/SLOW2	Sets the measurement speed for temperature measurement	-	-	-	√	√

Message [: Omissible	Data Formats [: Omissible ( ): Response data	Description	Corresponding Model				
			RM 3544	RM3545		RM3545A / RM3546	
					By channel		By channel
:ATC:RATE?	(FAST/MEDIUM/SLOW1/SLOW2)	Queries the measurement speed for temperature measurement	-	-	-	√	√
:ATC:RANGE:AUTO	1/0/ON/OFF	Sets the AUTO range for temperature measurement	-	-	-	√	√
:ATC:RANGE:AUTO?	(ON/OFF)	Queries the AUTO range for temperature measurement	-	-	-	√	√
:ATC:RANGE	0 to 1200E+6	Sets the range for temperature measurement	-	-	-	√	√
:ATC:RANGE?	(1000.000E-6 to 1000.000E+6)	Queries the range for temperature measurement	-	-	-	√	√
:ATC:DELAY:AUTO	1/0/ON/OFF	Sets the preset for delay time in temperature measurement	-	-	-	√	√
:ATC:DELAY:AUTO?	(ON/OFF)	Queries the preset for delay time in temperature measurement	-	-	-	√	√
:ATC:DELAY	<Delay time>	Sets the custom delay time for temperature measurement	-	-	-	√	√
:ATC:DELAY?	(0 to 9.999)	Queries the custom delay time for temperature measurement	-	-	-	√	√
:ATC:AVERAGE:STATE	1/0/ON/OFF	Sets the averaging for temperature measurement	-	-	-	√	√
:ATC:AVERAGE:STATE?	(ON/OFF)	Queries the averaging for temperature measurement	-	-	-	√	√
:ATC:AVERAGE:COUNT	2 to 100	Sets the number of averages for temperature measurement	-	-	-	√	√
:ATC:AVERAGE:COUNT?	(2 to 100)	Queries the number of averages for temperature measurement	-	-	-	√	√
:ATC:AOVC	1/0/ON/OFF	Sets the advanced offset voltage compensation for temperature measurement	-	-	-	√	√
:ATC:AOVC?	(ON/OFF)	Queries the advanced offset voltage compensation for temperature measurement	-	-	-	√	√
:ATC:PR:STATE	1/0/ON/OFF	Sets the pure resistance mode for temperature measurement	-	-	-	√	√
:ATC:PR:STATE?	(ON/OFF)	Queries the pure resistance mode for temperature measurement	-	-	-	√	√
:ATC:CURRENT	HIGH/LOW	Sets the measurement current for temperature measurement	-	-	-	√	√
:ATC:CURRENT?	(1A/0.1A)	Queries the measurement current for temperature measurement	-	-	-	√	√
:ATC:CONTACTCHECK	1/0/ON/OFF	Sets the contact check for temperature measurement	-	-	-	√	√
:ATC:CONTACTCHECK?	(ON/OFF)	Queries the contact check for temperature measurement	-	-	-	√	√
:ATC:CIMPROVE	1/0/ON/OFF	Sets the probe contact improvement for temperature measurement	-	-	-	√	√
:ATC:CIMPROVE?	(ON/OFF)	Queries the probe contact improvement for temperature measurement	-	-	-	√	√

**Reading measurement values of Advanced Temperature Correction (A-TC) [RM3546]**

:ATC:FETCH?	[ATC/ATCR/R/T] <Channel Number>, (<Resistance Value /Temperature: Response differs in the data section>)	Reading the last measurement value using A-TC  When data is omitted: Returns the same response as A-TC. When data is ATC: <Corrected resistance value>, <Uncorrected resistance value>, <Uncorrected temperature> When data is ATCR: <Corrected resistance value> When data is R: <Uncorrected resistance value> When data is T: <Uncorrected temperature>	-	-	-	√	√
-------------	--	--	---	---	---	---	---

Message [:]: Omissible	Data Formats [:]: Omissible ( ): Response data	Description	Corresponding Model				
			RM 3544	RM3545		RM3545A / RM3546	
					By channel		By channel
:ATC:READ?	[ATC/ATCR/R/T] <Channel Number>, (<Resistance Value /Temperature: Response differs in the data section>)	Start A-TC measurement and read the measurement values after completion  When data is omitted: Returns the same response as A-TC. When data is ATC: <Corrected resistance value>, <Uncorrected resistance value>, <Uncorrected temperature> When data is ATCR: <Corrected resistance value> When data is R: <Uncorrected resistance value> When data is T: <Uncorrected temperature>	-	-	-	√	√
:ATC:INITiate		Start A-TC Measurement	-	-	-	√	√
<b>LCD Settings</b>							
:DISPlay:CONTRast	<0 to 100>	Sets the contrast.	√	√	-	√	-
:DISPlay:CONTRast?	(0 to 100)	Queries the contrast.	√	√	-	√	-
:DISPlay:BACKlight	<0 to 100>	Sets the backlight brightness.	√	√	-	√	-
:DISPlay:BACKlight?	(0 to 100)	Queries the backlight brightness.	√	√	-	√	-
<b>Memory Function</b>							
:MEMory:STATe	1/0/ON/OFF	Sets the memory mode.	-	√	-	√	-
:MEMory:STATe?	(ON/OFF)	Queries the memory mode.	-	√	-	√	-
:MEMory:CLEar		Clears the memory data.	-	√	-	√	-
:MEMory:COUNT?	(0 to 50)	Queries the number of measurements stored in memory.	-	√	-	√	-
:MEMory:DATA?	<Measurement value>,<Measurement value>,...,<Measurement value>	Reads the measurements stored in memory.	-	√	-	√	-
<b>Hold</b>							
[:SENSe:]HOLD:AUTO	1/0/ON/OFF	Sets the auto hold execution.	√	√	-	√	-
[:SENSe:]HOLD:AUTO?	(ON/OFF)	Queries the auto hold execution.	√	√	-	√	-
[:SENSe:]HOLD:STATe?	(ON/OFF)	Queries the hold state.	√	√	-	√	-
[:SENSe:]HOLD:OFF		Cancels hold.	√	√	-	√	-
<b>Multiplexer Settings</b>							
[:SENSe:]WIRE	4/2/W4/W2	Sets the measurement method.	-	√	-	√	-
[:SENSe:]WIRE?	(W4/W2)	Queries the measurement method.	-	√	-	√	-
[:SENSe:]SCAN:MODE	OFF/AUTO/STEP	Sets the scanning function.	-	√	-	√	-
[:SENSe:]SCAN:MODE?	(OFF/AUTO/STEP)	Queries the scanning function.	-	√	-	√	-
[:SENSe:]SCAN:STATe?	(1/0)	Queries the scanning execution state.	-	√	-	√	-
[:SENSe:]SCAN:RESet		Initializes the scan channel and measured value or judgment value.	-	√	-	√	-
[:SENSe:]SCAN:FAIL:STOP	1/0/ON/OFF	Sets the scan fail stop.	-	√	-	√	-
[:SENSe:]SCAN:FAIL:STOP?	(ON/OFF)	Queries the scan fail stop.	-	√	-	√	-
[:SENSe:]SCAN:DATA?	<Measured value>,<Measured value> ...,<Measured value>	Reads the scanned measured data in a batch.	-	√	-	√	-
[:SENSe:]FRONTcheck?	(1/0)	Queries the front measurement terminal connection.	-	√	-	√	-
[:SENSe:]CH	FRONT/0/<Channel number>	Sets the channel switching.	-	√	-	√	-
[:SENSe:]CH?	(FRONT/<Channel number>)	Queries the channel switching.	-	√	-	√	-
[:SENSe:]CH:STATe	<1/0/ON/OFF>,<Channel number>]	Sets the channel for the multiplexer to be used (execution error when the front measurement terminal is used).	-	√	√	√	√
[:SENSe:]CH:STATe?	[<Channel number>] (ON/OFF)	Queries the channel for the multiplexer to be used (execution error when the front measurement terminal is used).	-	√	√	√	√
[:SENSe:]CH:AVAIlable?	(Number of channels)	Queries the number of channels for the multiplexer to be used.	-	√	-	√	-

Message [:]: Omissible	Data Formats [:]: Omissible ( ): Response data	Description	Corresponding Model				
			RM 3544	RM3545		RM3545A / RM3546	
					By channel		By channel
[:SENSe:]INSTrument	INTernal/EXTernal	Sets the use of external equipment (execution error when the front measurement terminal is used).	-	√	√	√	√
[:SENSe:]INSTrument?	(INTERNAL/EXTERNAL)	Queries the use of external equipment (execution error when the front measurement terminal is used).	-	√	√	√	√
[:SENSe:]TERMinal	<Unit number>,<A terminal number>,<B terminal number>	Sets the allocation of terminals for the multiplexer (the current flows from terminal B to terminal A, execution error when the front measurement terminal is used).	-	√	√	√	√
[:SENSe:]TERMinal?	(<Unit number>,<A terminal number>,<B terminal number>)	Queries the allocation of terminals for the multiplexer (the current flows from terminal B to terminal A, execution error when the front measurement terminal is used).	-	√	√	√	√
<b>Multiplexer Channel Reset</b>							
[:SENSe:]CHReset		Resets the multiplexer channel settings including the measurement conditions.	-	√	-	√	-
<b>Low-Power Resistance Measurement</b>							
[:SENSe:]RESistance:LP:STATe	1/0/ON/OFF	Sets the Low-Power Resistance measurement.	-	√	√	√	√
[:SENSe:]RESistance:LP:STATe?	(ON/OFF)	Queries the Low-Power Resistance measurement.	-	√	√	√	√
<b>Pure Resistance Measurement</b>							
[:SENSe:]RESistance:PR:STATe	1/0/ON/OFF	Sets the Pure Resistance measurement.	-	-	-	√	√
[:SENSe:]RESistance:PR:STATe?	(ON/OFF)	Queries the Pure Power Resistance measurement.	-	-	-	√	√
<b>Measurement Range</b>							
[:SENSe:]RESistance:RANGe	RM3544:0 to 3.5E+6 RM3545/RM3545A/RM3546:0 to 1200E+6	Sets the resistance measurement range.	√	√	√	√	√
[:SENSe:]RESistance:RANGe?	RM3544:(30.000E-3 to 3.0000E+6) RM3545:(10.00000E-3 to 1000.0000E+6) RM3545A/RM3546:(1000.000E-6 to 1000.0000E+6)	Queries the resistance measurement range.	√	√	√	√	√
[:SENSe:]RESistance:RANGe:AUTO	1/0/ON/OFF	Sets the resistance measurement AUTO range.	√	√	√	√	√
[:SENSe:]RESistance:RANGe:AUTO?	(ON/OFF)	Queries the resistance measurement AUTO range.	√	√	√	√	√
[:SENSe:]RESistance:LP:RANGe	0 to 1000E+0	Sets the Low-Power Resistance measurement range.	-	√	√	√	√
[:SENSe:]RESistance:LP:RANGe?	(1000.00E-3 to 1000.00E+0)	Queries the Low-Power Resistance measurement range.	-	√	√	√	√
<b>100MΩ Range High Precision Function</b>							
[:SENSe:]RESistance:PRECision	1/0/ON/OFF	Sets the 100MΩ range high precision function.	-	√	√	√	√
[:SENSe:]RESistance:PRECision?	(ON/OFF)	Queries the 100MΩ high precision function.	-	√	√	√	√
<b>Switching Measurement Current</b>							
[:SENSe:]RESistance:CURREnt	HIGH/LOW	Sets the measurement current.	-	√	√	√	√
[:SENSe:]RESistance:CURREnt?	(HIGH/LOW)	Queries the measurement current.	-	√	√	√	√
<b>Offset Voltage Compensation Function (OVC)</b>							
[:SENSe:]RESistance:OVC	1/0/ON/OFF	Sets the Offset Voltage compensation function execution.	-	√	√	√	√
[:SENSe:]RESistance:OVC?	(ON/OFF)	Queries the Offset Voltage Compensation function execution.	-	√	√	√	√

Message [:]: Omissible	Data Formats [:]: Omissible ( ): Response data	Description	Corresponding Model				
			RM 3544	RM3545		RM3545A / RM3546	
				By channel		By channel	
<b>Advanced Offset Voltage Compensation Function (A-OVC)</b>			RM3546				
[[:SENSe:]]RESistance:AOVC	1/0/ON/OFF	Sets the Advanced Offset Voltage Compensation function execution.	-	-	-	√	√
[[:SENSe:]]RESistance:AOVC?	(ON/OFF)	Queries the Advanced Offset Voltage Compensation function execution.	-	-	-	√	√
<b>Contact Improver</b>							
[[:SENSe:]]RESistance:CIMProve	ON/OFF/1/0	Sets the Contact Improver.	-	√	√	√	√
[[:SENSe:]]RESistance:CIMProve?	(ON/OFF)	Queries the Contact Improver.	-	√	√	√	√
<b>Current Error Mode</b>							
[[:SENSe:]]RESistance:ERRor:CURRentcheck	ERRor/OVER	Sets the current error mode.	√	√	√	√	√
[[:SENSe:]]RESistance:ERRor:CURRentcheck?	(ERRor/OVER)	Queries the current error mode.	√	√	√	√	√
[[:SENSe:]]RESistance:ERRor:OVER	ERRor/NORMal	Setting the overrange external Err terminal	-	-	-	√	-
[[:SENSe:]]RESistance:ERRor:OVER?	(ERRor/NORMal)	Queries the overrange external Err terminal	-	-	-	√	-
<b>Contact Check</b>							
[[:SENSe:]]RESistance:CONtactcheck	ON/OFF/1/0	Sets the resistance measurement contact check.	-	√	√	√	√
[[:SENSe:]]RESistance:CONtactcheck?	(ON/OFF)	Queries the resistance measurement contact check.	-	√	√	√	√
[[:SENSe:]]RESistance:LP:CONtactcheck	ON/OFF/1/0	Sets the Low-Power Resistance measurement contact check.	-	√	√	√	√
[[:SENSe:]]RESistance:LP:CONtactcheck?	(ON/OFF)	Queries the Low-Power Resistance measurement contact check.	-	√	√	√	√
<b>Setting Number of Digits</b>							
[[:SENSe:]]RESistance:DIGits	RM3544:4/5 RM3545/RM3545A/RM3546:5/6/7	Sets the measurement value's number of digits.	√	√	-	√	-
[[:SENSe:]]RESistance:DIGits?	RM3544:(4/5) RM3545/RM3545A/RM3546:(5/6/7)	Queries the measurement value's number of digits.	√	√	-	√	-
<b>Temperature Measurement (Analog Input)</b>							
[[:SENSe:]]TEMPerature:SENSor	THERMistor/ANALog	Sets the temperature sensor.	-	√	-	√	-
[[:SENSe:]]TEMPerature:SENSor?	(THERMISTOR/ANALOG)	Queries the temperature sensor.	-	√	-	√	-
[[:SENSe:]]TEMPerature:PARAmeter	<V1>,<T1>,<V2>,<T2>	Sets the analog input scaling constants.	-	√	-	√	-
[[:SENSe:]]TEMPerature:PARAmeter?	(<V1>,<T1>,<V2>,<T2>)	Queries the analog input scaling constants.	-	√	-	√	-
<b>Trigger</b>							
:INITiate:CONTInuous	1/0/ON/OFF	Sets the continuous measurement.	√	√	-	√	-
:INITiate:CONTInuous?	(ON/OFF)	Queries the continuous measurement.	√	√	-	√	-
:INITiate[:IMMEDIATE]		Initiates the trigger wait state.	√	√	-	√	-
:TRIGger:SOURce	IMMEDIATE/EXTernal	Sets the trigger source.	√	√	-	√	-
:TRIGger:SOURce?	(IMMEDIATE/EXTERNAL)	Queries the trigger source.	√	√	-	√	-
:TRIGger:EDGE	1/0/ON/OFF	Sets the trigger logic (ON edge/OFF edge).	√	√	-	√	-
:TRIGger:EDGE?	(ON/OFF)	Queries the trigger logic (ON edge/OFF edge).	√	√	-	√	-
<b>Delay</b>							
:TRIGger:DELay	<Delay time>	Sets the delay time.	-	√	√	√	√
:TRIGger:DELay?	(0 to 9.999)	Queries the delay time.	-	√	√	√	√
:TRIGger:DELay:AUTO	1/0/ON/OFF	Sets the preset delay.	-	√	√	√	√
:TRIGger:DELay:AUTO?	(ON/OFF)	Queries the preset delay.	-	√	√	√	√
<b>Self-Calibration</b>							
:SYSTem:CALibration		Executes self-calibration.	-	√	-	√	-
:SYSTem:CALibration:AUTO	1/0/ON/OFF	Sets the automatic self-calibration.	-		-		-
:SYSTem:CALibration:AUTO?	(ON/OFF)	Queries the automatic self-calibration.	-	√	-	√	-

Message [: Omissible]	Data Formats [: Omissible ( ): Response data	Description	Corresponding Model				
			RM 3544	RM3545		RM3545A / RM3546	
				By channel		By channel	
<b>Saving and Reading Measurement Conditions</b>							
:SYSTem:PANel:SAVE	<TableNo>	Saves the panel.	√	√	-	√	-
:SYSTem:PANel:LOAD	<TableNo>, <Zero adjustment load=1/0/ON/OFF>	Reads the panel.	√	√	-	√	-
:SYSTem:PANel:NAME	<TableNo>, <Panel name>	Sets the panel name.	√	√	-	√	-
:SYSTem:PANel:NAME?	<TableNo> (<Panel name>)	Obtains the panel name.	√	√	-	√	-
:SYSTem:PANel:CLEar	<TableNo>	Clears the panel.	√	√	-	√	-
<b>Absolute Value Display</b>							
:SYSTem:ABSolute	1/0/ON/OFF	Sets for absolute value display	-	-	-	√	-
:SYSTem:ABSolute?	(ON/MENU/OFF)	Queries for absolute value display	-	-	-	√	-
<b>Key-Lock</b>							
:SYSTem:KLOCK	1/0/ON/OFF	Sets the key-lock.	√	√	-	√	-
:SYSTem:KLOCK?	(ON/MENU/OFF)	Queries the key-lock.	√	√	-	√	-
<b>Line Frequency</b>							
:SYSTem:LFRequency	AUTO/50/60	Sets the AC line frequency.	√	√	-	√	-
:SYSTem:LFRequency?	(AUTO/50/60)	Queries the AC line frequency.	√	√	-	√	-
<b>Clock</b>							
:SYSTem:DATE	<Year>, <Month>, <Day>	Sets the system date.	-	√	-	√	-
:SYSTem:DATE?	(<Year>, <Month>, <Day>)	Queries the system date.	-	√	-	√	-
:SYSTem:TIME	<Hour>, <Minute>, <Second>	Sets the system time.	-	√	-	√	-
:SYSTem:TIME?	(<Hour>, <Minute>, <Second>)	Queries the system time.	-	√	-	√	-
<b>Key Beeper</b>							
:SYSTem:BEEPer:STATE	1/0/ON/OFF	Sets the key beeper.	√	√	-	√	-
:SYSTem:BEEPer:STATE?	(ON/OFF)	Queries the key beeper.	√	√	-	√	-
<b>Communications Settings</b>							
:SYSTem:LOCal		Enables the local control state.	√	√	-	√	-
:SYSTem:DATAout	1/0/ON/OFF	Sets the measurement-synchronized data output.	√	√	-	√	-
:SYSTem:DATAout?	(ON/OFF)	Queries the measurement-synchronized data output.	√	√	-	√	-
:SYSTem:HEADer	1/0/ON/OFF	Sets the header presence.	√	√	-	√	-
:SYSTem:HEADer?	(ON/OFF)	Queries the header presence.	√	√	-	√	-
:SYSTem:TERMinator	0/1	Sets the command delimiter.	-	√	-	√	-
:SYSTem:TERMinator?	(0/1)	Queries the command delimiter.	-	√	-	√	-
:SYSTem:COMMunicate	USB/LAN/RS232c/PRINter	Sets the Communication interface	-	-	-	√	-
:SYSTem:COMMunicate?	(USB/LAN/RS232C/PRINter)	Queries the Communication interface	-	-	-	√	-
:SYSTem:COMMunicate:MONitor	1/0/ON/OFF	Sets the Communication monitor	-	-	-	√	-
:SYSTem:COMMunicate:MONitor?	(ON/OFF)	Queries the Communication monitor	-	-	-	√	-
:SYSTem:COMMunicate:LAN:IPADdress	IP address	Sets the IP address	-	-	-	√	-
:SYSTem:COMMunicate:LAN:IPADdress?	(IP address)	Queries the IP address	-	-	-	√	-
:SYSTem:COMMunicate:LAN:SMASK	Sub-net mask	Sets the Sub-net mask for LAN	-	-	-	√	-
:SYSTem:COMMunicate:LAN:SMASK?	(Sub-net mask)	Queries the Sub-net mask for LAN	-	-	-	√	-
:SYSTem:COMMunicate:LAN:GATeway	Gateway	Sets the Gateway for LAN	-	-	-	√	-
:SYSTem:COMMunicate:LAN:GATeway?	(Gateway)	Queries the Gateway for LAN	-	-	-	√	-
:SYSTem:COMMunicate:LAN:CONTrol	Port NO.	Sets the LAN port number	-	-	-	√	-
:SYSTem:COMMunicate:LAN:CONTrol?	(Port NO.)	Queries the LAN port number	-	-	-	√	-
:SYSTem:COMMunicate:LAN:MAC?	(MAC address)	Queries the MAC address for LAN	-	-	-	√	-
:SYSTem:COMMunicate:LAN:UPDate		Update LAN settings	-	-	-	√	-

Message [ ]: Omissible	Data Formats [ ]: Omissible ( ): Response data	Description	Corresponding Model					
			RM 3544	RM3545		RM3545A / RM3546		
				By channel		By channel		
:SYSTem:COMMunicate:RS23 2C:SPEED	Baud rate	Sets the RS-232C communication speed	-	-	-	√	-	
:SYSTem:COMMunicate:RS23 2C:SPEED?	(9600/19200/38400/115200)	Queries the RS-232C communication speed	-	-	-	√	-	
<b>System Reset</b>								
:SYSTem:RESet	Baud rate	Executes reset, including the saved data on measurement conditions.	√	√	-	√	-	
<b>EXT I/O</b>								
:IO:MODE?	(NPN/PNP)	Queries the NPN/PNP switch status.	√	√	-	√	-	
:IO:INPut?	(0 to 3)	Executes the external I/O input.	√	√	-	√	-	
:IO:OUTPut	0 to 7	Executes the external I/O output.	√	√	-	√	-	
:IO:FILTer:STATe	1/0/ON/OFF	Sets the TRIG/PRINT signal filter function execution.	√	√	-	√	-	
:IO:FILTer:STATe?	(ON/OFF)	Queries the TRIG/PRINT signal filter function execution.	√	√	-	√	-	
:IO:FILTer:TIME	<0.050 to 0.500>	Sets the TRIG/PRINT signal filter time.	√	√	-	√	-	
:IO:FILTer:TIME?	(0.050 to 0.500)	Queries the TRIG/PRINT signal filter time.	√	√	-	√	-	
:IO:JUDGe:MODE	JUDGe/BCD	Selects the judgment mode/BCD mode.	√	√	-	√	-	
:IO:JUDGe:MODE?	(JUDGE/BCD)	Queries the judgment mode/BCD mode.	√	√	-	√	-	
:IO:EOM:MODE	<HOLD/PULSe>	Sets the EOM output mode.	√	√	-	√	-	
:IO:EOM:MODE?	(<HOLD/PULSE>)	Queries the EOM output mode.	√	√	-	√	-	
:IO:EOM:PULSe	<Pulse width>	Sets the EOM pulse width.	√	√	-	√	-	
:IO:EOM:PULSe?	(0.001 to 0.100)	Queries the EOM pulse width.	√	√	-	√	-	
<b>Multiplexer Unit</b>								
:UNIT:IDN?	<Unit number> (<Model name>, <Serial number>)	Queries the unit.	-	√	-	√	-	
:UNIT:SCOunt?	<Unit number> (<Relay count>)	Queries the relay usage count.	-	√	-	√	-	
:UNIT:TEST?	<Unit number> (<0 to 8>)	Queries the unit test and result.	-	√	-	√	-	

# 3 Message Reference

## Message Reference Interpretation

< >: Indicates the contents (character or numeric parameters) of the data portion of a message. Character parameters are returned as all capital letters.

**Numeric Parameters:**


- NRf Number format may be any of NR1, NR2 and NR3
- NR1 Integer data (e.g.: +12, -23, 34)
- NR2 Fixed-point data (e.g.: +1.23, -23.45, 3.456)
- NR3 Floating-point exponential representation data (e.g.: +1.0E-2, -2.3E+4)

Shows the command description.

Shows the message syntax. Explains the command data or response message. Describes the message.

Shows an example of an actual command application. (Normally described with HEADER OFF [except the HEADER command itself].)

Read/Write the Standard Event Status Enable Register (SESER)																									
<b>Syntax</b>	Command <b>*ESE &lt;0 to 255 (NR1)&gt;</b> Query <b>*ESE?</b>																								
<b>Description</b>	Response <b>&lt;0 to 255 (NR1)&gt;</b> Command The SESER mask is set to the numerical value 0 to 255. The initial value (at power-on) is 0. Query The contents of the SESER, as set by the *ESE command, are returned as an NR1 value (0 to 255).																								
	<table style="margin-left: auto; margin-right: auto;"> <tr> <td>128</td><td>64</td><td>32</td><td>16</td><td>8</td><td>4</td><td>2</td><td>1</td> </tr> <tr> <td>bit 7</td><td>bit 6</td><td>bit 5</td><td>bit 4</td><td>bit 3</td><td>bit 2</td><td>bit 1</td><td>bit 0</td> </tr> <tr> <td>PON</td><td>URQ</td><td>CME</td><td>EXE</td><td>DDE</td><td>QYE</td><td>RQC</td><td>OPC</td> </tr> </table>	128	64	32	16	8	4	2	1	bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0	PON	URQ	CME	EXE	DDE	QYE	RQC	OPC
128	64	32	16	8	4	2	1																		
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0																		
PON	URQ	CME	EXE	DDE	QYE	RQC	OPC																		
<b>Example</b>	<b>*ESE 36</b> (Sets bits 5 and 2 of SESER)																								



## Standard Commands

### (1) System Data Command

#### Query Device ID (Identification Code)

**Syntax** Query **\*IDN?**  
 Response <Manufacturer name>, <Model name>, <Serial number>, <Software version>

**Example** **\*IDN?**  
 HIOKI, RM3545, 123456789, V1.00  
 The Device ID is HIOKI RM3545, 123456789, software version 1.00. The <Model name> includes the following devices in addition to the example RM3544-01, RM3545-01, RM3545-02, RM3545A-1, RM3545A-2 and RM3546.

**Note** The response message has no header.

### (2) Internal Operation Command

#### Initialize Device

**Syntax** Command **\*RST**

**Description** Command Resets the instrument to its initial state.

**Note** The communications state is not initialized.  
 RM3545 RM3545A RM3546 An execution error occurs during scanning.

#### Execute Self-Test and Query Result

**Syntax** Query **\*TST?**  
 Response <0 to 15 (NR1)>  
 128 64 32 16 8 4 2 1  
 bit 7 bit 6 bit 5 bit 4 bit 3 bit 2 bit 1 bit 0

unused	unused	unused	unused	Blown FUSE	memory	CPU RAM	CPU ROM
--------	--------	--------	--------	------------	--------	---------	---------

**Description** Perform the instrument self-test and return the result as NR1 value 0 to 15. Returns zero when no error occurs.

**Example** **\*TST?**  
 4  
 A memory error occurred. Correct measurement may not be possible. Obtain repair before further use.

**Note** RM3545 RM3545A RM3546 An execution error occurs during scanning.

### (3) Synchronization Commands

#### Set OPC bit of SESR when Finished with All Pending Operations

---

**Syntax** Command **\*OPC**

**Description** Sets OPC bit 0 of the Standard Event Status Register (SESR) when all commands prior to \*OPC have finished processing.

#### Respond with ASCII "1" when Finished with All Pending Operations

---

**Syntax** Query **\*OPC?**  
Response **1**

**Description** Responds with ASCII "1" when all commands prior to \*OPC have finished processing.

#### Wait for Pending Commands to Finish

---

**Syntax** Command **\*WAI**

**Description** The instrument waits until all prior commands finish before executing any subsequent commands.

### (4) Status and Event Control Commands

#### Clear Event Register, Status Byte Register (Except Output Queue)

---

**Syntax** Command **\*CLS**

**Description** Clears the event status registers. The Status Byte Register bits corresponding to the event status registers are also cleared. (SESR, ESR0, ESR1)

**Note** [RS-232C/USB/LAN] The output queue is unaffected.  
[GP-IB] The output queue, various enable registers and MAV bit 4 of the Status Byte Register are unaffected.

#### Read/Write Standard Event Status Enable Register (SESER)

---

**Syntax** Command **\*ESE <0 to 255 (NR1)>**  
Query **\*ESE?**  
Response **<0 to 255 (NR1)>**

**Description** Command The SESER mask is set to the numerical value 0 to 255. The initial value (at power-on) is 0.  
Query The contents of the SESER, as set by the \*ESE command, are returned as an NR1 value (0 to 255).

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
PON	URQ	CME	EXE	DDE	QYE	RQC	OPC

**Example** \*ESE 36  
(Sets bits 5 and 2 of SESER)

## Read and Clear Standard Event Status Register (SESR)

**Syntax** Query **\*ESR?**  
Response <0 to 255 (NR1)>

**Description** Returns the contents of the SESR as an NR1 value from 0 to 255, then clears register contents.

The response message has no header.

[RS-232C/USB/LAN]

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
PON	unused	CME	EXE	DDE	QYE	unused	OPC

[GP-IB]

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
PON	URQ	CME	EXE	DDE	QYE	RQC	OPC

**Example** \*ESR?

32

Bit 5 of the SESR has been set to 1.

## Write and Read Standard Event Status Enable Register (SRER)

**Syntax** Command **\*SRE** <0 to 255 (NR1)>  
Query **\*SRE?**  
Response <0 to 255 (NR1)>

**Description** Command The SRER mask is set to the numerical value 0 to 255. Although NRf numerical values are accepted, values to the right of the decimal are rounded to the nearest integer. Bit 6 and unused bits 2, 3 and 7 are ignored. The data is initialized to zero at power-on.

Query The contents of the SRER, as set by the \*SRE command, are returned as an NR1 value (0 to 255). Bit 6 and unused bits 2, 3 and 7 always return as zero.

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
unused	0	ESB	MAV	unused	unused	ESB1	ESB0

**Example** \*SRE

33

Set SRER bits 0 and 5 to 1.

\*SRE?

33

SRER bits 0 and 5 have been set to 1.

## Read Status Byte and MSS Bit

**Syntax** Query **\*STB?**  
Response <0 to 255 (NR1)>

**Description** The contents of the STB are returned as an NR1 value (0 to 255).  
The response message has no header.

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
unused	MSS	ESB	MAV	unused	unused	ESB1	ESB0

**Example** **\*STB?**  
**16**  
STB bit 4 has been set to 1.

## Request a Sample

**Syntax** Command **\*TRG**

**Description** Performs one measurement when external triggering (trigger source <EXTERNAL>) is enabled.  
When Statistical Calculation is ON, imports calculation data. [RM3545](#) [RM3545A](#) [RM3546](#)  
When the memory function is enabled, the measured value is stored. [RM3545](#)  
[RM3545A](#) [RM3546](#)  
It may be necessary to insert wait processing after panel load or range selection. Wait time depends on Measurement target.

**Example** **:TRIG:SOUR EXT;\*TRG**

## Device-Specific Commands

### (1) Event Status Register

#### Set and Query Device-Specific Event Status Enable Register ESER0

**Syntax** Command **:ESE0** <0 to 255 (NR1)>  
Query **:ESE0?**  
Response <0 to 255 (NR1)>

**Description** Command Sets the mask pattern in Event Status Enable Register 0 (ESER0) for the Event Status Register.

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
OutBIN	OvrRng	ERR	Hi	IN	Lo	INDEX	EOM

**Note** Data initializes to zero at power-on.  
OvrRng and ERR can not be Changed by [RES:ERR:CURR OVER](#).

## Read Device-Specific Event Status Register ESR0

**Syntax** Query **:ESR0?**  
Response <0 to 255 (NR1)>

**Note** Executing **ESR0?** clears the contents of ESR0.

## Set and Query Device-Specific Event Status Enable Register ESER1 RM3545 RM3545A

RM3546

**Syntax** Command **:ESE1** <0 to 255 (NR1)>  
Query **:ESE1?**  
Response <0 to 255 (NR1)>

**Description** Command Sets the mask pattern in Event Status Enable Register 1 (ESER1) for the Event Status Register.

128	64	32	16	8	4	2	1
bit 7	bit 6	bit 5	bit 4	bit 3	bit 2	bit 1	bit 0
unused	unused	PROT	NO UNIT	SW.ERR	CURR	CONTACT A	CONTACT B

Overvoltage Protection: PROT (bit 5) is only for RM3546.

Data initializes to zero at power-on.

## Read Device-Specific Event Status Registers ESR1 RM3545 RM3545A RM3546

**Syntax** Query **:ESR1?**  
Response <0 to 255 (NR1)>

**Note** Executing **ESR1?** clears the contents of ESR1.

## (2) Reading Measured Values

### Measurement Value Formats

\* Resistance (absolute value display: unit  $\Omega$ )

RM3544

Measurement Range	Measured Value	$\pm$ OvrRng	Measurement Fault
30m $\Omega$	$\pm$ 00 . 000 E-03	$\pm$ 10.000E+19	10.000E+29
300m $\Omega$	$\pm$ 000 . 00 E-03	$\pm$ 100.00E+18	100.00E+28
3 $\Omega$	$\pm$ 0 . 0000 E+00	$\pm$ 1.0000E+20	1.0000E+30
30 $\Omega$	$\pm$ 00 . 000 E+00	$\pm$ 10.000E+19	10.000E+29
300 $\Omega$	$\pm$ 000 . 00 E+00	$\pm$ 100.00E+18	100.00E+28
3k $\Omega$	$\pm$ 0 . 0000 E+03	$\pm$ 1.0000E+20	1.0000E+30
30k $\Omega$	$\pm$ 00 . 000 E+03	$\pm$ 10.000E+19	10.000E+29
300k $\Omega$	$\pm$ 000 . 00 E+03	$\pm$ 100.00E+18	100.00E+28
3M $\Omega$	$\pm$ 0 . 0000 E+06	$\pm$ 1.0000E+20	1.0000E+30

RM3545 RM3545A RM3546

Low-Power	Measurement Range	Measured Value	±OvrRng	Measurement Fault
OFF	1000μΩ	± □□□□.□□□ E-06	±1000.000E+17	1000.000E+27
	10mΩ	± □□.□□□□□ E-03	±10.00000E+19	10.00000E+29
	100mΩ	± □□□.□□□□ E-03	±100.0000E+18	100.0000E+28
	1000mΩ	± □□□□.□□□ E-03	±1000.000E+17	1000.000E+27
	10Ω	± □□.□□□□□ E+00	±10.00000E+19	10.00000E+29
	100Ω	± □□□.□□□□ E+00	±100.0000E+18	100.0000E+28
	1000Ω	± □□□□.□□□ E+00	±1000.000E+17	1000.000E+27
	10kΩ	± □□.□□□□□ E+03	±10.00000E+19	10.00000E+29
	100kΩ	± □□□.□□□□ E+03	±100.0000E+18	100.0000E+28
	1000kΩ	± □□□□.□□□ E+03	±1000.000E+17	1000.000E+27
	10MΩ	± □□.□□□□□ E+06	±10.00000E+19	10.00000E+29
	100MΩ	± □□□.□□□□ E+06	±100.0000E+18	100.0000E+28
	1000MΩ	± □□□□.□□□ E+06	±1000.000E+17	1000.000E+27
ON	1000mΩ	± □□□□.□□ E-03	±1000.00E+17	1000.00E+27
	10Ω	± □□.□□□□□ E+00	±10.0000E+19	10.0000E+29
	100Ω	± □□□.□□□□ E+00	±100.000E+18	100.000E+28
	1000Ω	± □□□□.□□ E+00	±1000.00E+17	1000.00E+27

Note: • The decimal point position and exponent part will change according to the scaling gain.

For information on scaling, see the instrument's instruction manual.

- When the displayed number of digits has changed, the undisplayed digits will become 0. The number of characters in the measurement value format will not change.
- 1000μΩ range are only available in RM3545A and RM3546.
- Resistance (relative value display: unit %)

RM3544

Measured Value	±OvrRng	Measurement Fault
± □□□.□□ E+00	±100.00E+18	100.00E+28

RM3545 RM3545A RM3546

Measured Value	±OvrRng	Measurement Fault
± □□□.□□□ E+00	±100.000E+18	100.000E+28

- Temperature / Temperature conversion display (unit °C)

Z2001 temperature sensor

Measured Value	±OvrRng	Measurement Fault
± □□.□ E+00	±10.0E+19	10.0E+29

Analog output thermometer

Temperature conversion display

Measured Value	±OvrRng	Measurement Fault
± □□□.□ E+00	±100.0E+18	100.0E+28

Note: For positive measured values, a space (ASCII 20H) represents the sign.

Time to receive measured values is different for the :FETCh? and :READ? commands.

See: Data Exporting Methods (p.80), Triggering (p.62)

Also see "4 Multiplexer Commands (p.76)" for the multiplexer unit.

## Read Most Recent Measurement

**Syntax** Query `:FETCh? [LIMit] RM3544`  
`:FETCh? [<LIMit/JUDGe/LIMJdgc>]`  
`<Channel number> RM3545 RM3545A RM3546`  
 <Channel number> = 1 to 42

Response `RM3544`  
`<Measurement value> [, <HI/IN/LO/OFF/ERR>]`  
`RM3545 RM3545A RM3546`  
`<Measurement value> [, <HI/IN/LO/OFF/ERR>]`  
`[, <PASS/FAIL/OFF/ERR>]`  
 See: "Measurement Value Formats" (p.28)

**Description** Reads the most recent measurement. No trigger occurs.  
 See: Data Exporting Methods (p.80), Triggering (p.62)

Data and response are as follows.

data	Response
omitted	Reads the measurement value only.
LIMit	Reads the measurement value and comparator result.
JUDGe <span style="border: 1px solid black; padding: 0 2px;">RM3545</span>	Reads the measurement value and PASS/FAIL result.
LIMJdgc <span style="border: 1px solid black; padding: 0 2px;">RM3545</span> <span style="border: 1px solid black; padding: 0 2px;">RM3545A</span> <span style="border: 1px solid black; padding: 0 2px;">RM3546</span>	Reads the measurement value, comparator result and PASS/FAIL result.

RM3545 RM3545A RM3546

By assigning a channel number to the data, the value of the channel number is read. If a measurement has not been performed, the value for a measurement fault is returned. The channel number is not returned. If the channel number is omitted, the measured value of the current channel is read.

The correspondence between "Judgment" and their response is as follows.

Judgment	Response
Hi	HI
IN	IN
Lo	LO
Comparator not used	OFF
Measurement Fault	ERR

**Example** (RM3544 examples)

`:FETC?`  
`102.50E-03`  
`:FETC? LIM`  
`102.50E-03, HI`

(RM3545, RM3545A, RM3546 examples)

`:FETC?`  
`1023.579E-03`  
`:FETC? LIM`  
`1023.579E-03, IN`

(Examples when the RM3545-02 multiplexer is used)

`:FETC?` ... Obtains the measured value of the current channel.  
`1023.579E-03`  
`:FETC? LIMJ` ... Obtains the current measured value and judgment.  
`1023.579E-03,IN,PASS`  
`:FETC? 10` ...Obtains the measured value of Channel 10.  
`1023.579E-00`  
`:FETC? LIMJ,10` ...Obtains the measured value of Channel 10 and judgment.  
`1023.579E-03,IN,PASS`

**Note** If a measurement has not been performed, the value for a measurement fault is returned. RM3545 RM3545A RM3546

In the following cases, an execution error occurs.

- When the front terminal is used or the scanning function is OFF, JUDGe or LIMJdgc is selected as the data.
- When the front terminal is used, a channel number is specified for the data.
- During auto scanning

## Read Temperature Measurement Value

<b>Syntax</b>	Query	<b>:FETCh:TEMPerature?</b>
	Response	<Measurement value> See: "Measurement Value Formats" (p.28)
<b>Description</b>	Reads the last (most recent) temperature measurement value. Performs the same operation as :MEASure:TEMPerature?.	
<b>Example</b>	:FETC:TEMP? 25.1E+00	

## Measure (Await Triggers and Read Measurements)

<b>Syntax</b>	Query	<b>:READ?</b>	RM3544
		<b>:READ? [&lt;NDATa/JUDGe&gt;]</b>	RM3545 RM3545A RM3546
	Response	RM3544 <Measurement value> RM3545 RM3545A RM3546	

The response varies depending on the scanning function or command

data portion. Data and response are as follows.

Scanning function	Data	Response
<b>OFF</b>	None	Reads the measured value only. <Measured value>
<b>AUTO</b>	Omitted	Reads only the measured values of all channels. <Measured value>, <Measured value>, ... <Measured value>
	NDATa	Reads the total judgment only. <Total judgment result>
	JUDGe	Reads the measured values and total judgment results of all channels. <Measured value>, <Measured value>, ... <Measured value>, <Total judgment result>
<b>STEP</b>	None	Reads only the measured value of the current channel. <Measured value>

<Total judgment result> = <PASS/FAIL/OFF/ERR>

See: "Measurement Value Formats" (p.28)

**Description** Switches from the Idle State to the Trigger Wait State, then reads the next measured value. With the auto range enabled, the most suitable range is selected before measurement.

See: "5 Data Exporting Methods" (p.80), Triggering (p.62)

Trigger Source	Operation
IMMediate	Triggers and reads the measured value.
EXTernal	Triggers by TRIG signal input, and continuously reads the measured values.

RM3545 RM3545A RM3546

When the scanning function is set to AUTO or STEP, the Trigger Wait State is entered and scanning begins after a trigger is detected.

The following operations are performed according to the scanning function.

Scanning function	Operation
AUTO	All channels are measured when a trigger is received. After all the channels are measured, a response is returned. The measured values at the time of scanning completion are separated by commas (",") and returned. Only the data with [:SENSe:]STATe ON is returned. The number of data items is the same as the channel count that can be obtained using a [:SENSe:]CH:AVAIable? query. If a measurement has not been performed, the value for a measurement fault is returned.
STEP	One channel is measured when a trigger is received. A response is returned after one channel is measured.

**Note**

- Automatically switches to `:INITiate:CONTinuous OFF` when this message is received.
- The next command does not execute until measurement is finished. However, `*TRG` and `:ABORt` are received.
- If a trigger is input with the `*TRG` command, an external trigger (trigger source `<EXTERNAL>`) is enabled and a command is sent. With GP-IB, after the command is sent and then after allowing a wait time corresponding to the sampling time, specify the talker.
- With an external trigger (trigger source `<EXTERNAL>`), the measurement value's response will be doubled when the data output function is ON. When using, switch the data output function OFF.
- It may be necessary to insert wait processing after panel load or range selection. Wait time depends on Measurement target.
- `RM3545` `RM3545A` `RM3546` An execution error occurs during auto scanning.

**Resistance Measurement in the range corresponding to expected measurement values** `RM3545` `RM3545A` `RM3546`

<b>Syntax</b>	Query	<code>:MEASure:RESistance? &lt;Expected measurement value&gt;</code> <code>&lt;Expected measurement value&gt; = 0 to 1200E+06</code>
	Response	<code>&lt;Measurement value&gt;</code> See: "Measurement Value Formats" (p.28)
<b>Description</b>	When an expected measurement value is specified, the corresponding measurement range will be set. When no values are specified, the device will operate in auto-ranging.	
	The MEASURE command operates as follows: <ol style="list-style-type: none"> <li>1. Disables continuous measurement of the trigger system.</li> <li>2. Enables the internal trigger (trigger source <code>&lt;IMMEDIATE&gt;</code>).</li> <li>3. Switches Low-Power Resistance measurement to OFF.</li> <li>4. Moves to the specified range.</li> <li>5. Executes one-time trigger.</li> <li>6. Reads the measurement value.</li> </ol>	
	The MEASURE command executes the following commands internally: <code>RES:LP:STAT OFF</code> <code>RES:RANG &lt;Expected measurement value&gt;</code> (If the <code>&lt;Expected measurement value&gt;</code> is not present, then <code>:RANG:AUTO ON</code> ) <code>:INIT:CONT OFF</code> <code>:TRIG:SOUR IMM</code> <code>:READ?</code>	
<b>Example</b>	Query	<code>:MEAS:RES?</code> <code>150.1124E+03</code>

- Note**
- When the scaling function is being used, set the `<expected value>` to the value that existed prior to scaling (value in the range being used).
  - If a transformer, coil, or other sample is inductive, measurement data may be returned before values have stabilized in auto range. In this case, either specify the range and measure, or utilize the delay function.
  - An execution error occurs when the auto range is turned ON if the comparator function and BIN measurement function are ON.
  - When the scanning function is set to STEP or AUTO, an execution error occurs.

## Low-Power Resistance Measurement in the range corresponding to expected measurement values. [RM3545](#) [RM3545A](#) [RM3546](#)

---

<b>Syntax</b>	Query	<b>:MEASure:RESistance:LP?</b> <Expected measurement value> <Expected measurement value> = 0 to 1200E+00
	Response	<Measurement value> See: "Measurement Value Formats" (p.28)
<b>Description</b>	When an expected measurement value is specified, the corresponding measurement range will be set. When no values are specified, the device will operate in auto-ranging.	
	<p>The MEASURE command operates as follows:</p> <ol style="list-style-type: none"> <li>1. Disables continuous measurement of the trigger system.</li> <li>2. Enables internal trigger (trigger source &lt;IMMEDIATE&gt;).</li> <li>3. Switches Low-Power Resistance measurement to ON.</li> <li>4. Moves to the specified range.</li> <li>5. Executes one-time trigger.</li> <li>6. Reads the measurement value.</li> </ol> <p>The MEASURE command executes the following commands internally:</p> <pre>RES:LP:STAT ON RES:LP:RANG &lt;Expected measurement value&gt; (If the &lt;Expected measurement value&gt; is not present, then :RANG:LP:AUTO ON) :INIT:CONT OFF :TRIG:SOUR IMM :READ?</pre>	
<b>Example</b>	<pre>:MEAS:RES:LP? 104.140E+00</pre>	

- Note**
- When the scaling function is being used, set the <expected value> to the value that existed prior to scaling (value in the range being used).
  - If a transformer, coil, or other sample is inductive, measurement data may be returned before values have stabilized in auto range. At such time, either specify the range and measure, or utilize the delay function.
  - An execution error occurs when the auto range is turned ON if the comparator function and BIN measurement function are ON.
  - When the scanning function is set to STEP or AUTO, an execution error occurs.

## Read Temperature Measurement Value

---

<b>Syntax</b>	Query	<b>:MEASure:TEMPerature?</b>
	Response	<Measurement value> See: "Measurement Value Formats" (p.28)
<b>Description</b>	Reads the last (most recent) temperature measurement value. Performs the same operation as <a href="#">:FETCh:TEMPerature?</a> .	
<b>Example</b>	<pre>:MEAS:TEMP? 25.1E+00</pre>	

## Abort Measurement

---

<b>Syntax</b>	Query	<b>:ABORt</b>
<b>Description</b>	Executes <a href="#">:READ</a> /Scan measurement/Scan zero adjustment is abort (forced ermination).	
<b>Example</b>	<pre>:READ? :ABOR Executes an abort.</pre>	
<b>Note</b>	An abort cannot be executed as the instrument waits until all prior commands finish if the query is sent after <a href="#">*WAI</a> command.	

### (3) Zero Adjustment

RM3545 RM3545A RM3546 An execution error occurs during scanning.

### Execute Zero Adjustment

---

**Syntax** Query **:ADJust?**

Response <0/1>

0 = Indicates zero adjustment succeeded.

1 = Indicates that zero adjustment has failed. For information on zero adjustment, see the instrument instruction manual.

**Description** RM3545 RM3545A RM3546

Executes scan zero adjustment (performs zero adjustment for the channels with **:ADJust:ENABLE ON**) if the scanning function of the multiplexer is set to STEP or AUTO. Zero adjustment is performed only for the current channel if the scanning function is OFF. Scan zero adjustment can be aborted using **:ABORT**.

### Clear Zero Adjustment

---

**Syntax** Command **:ADJust:CLear**

**Description** Clears any zero-adjustment offset.

**Example** **ADJ:CLE**

**Note** RM3545 RM3545A RM3546

When the multiplexer is used, zero adjustment for the current channel is canceled.

### Query Zero Adjustment Execution State RM3545 RM3545A RM3546

---

**Syntax** Query **:ADJust:STATe?**

Response <ON/OFF>

**Example** CH 10  
:ADJ:STAT?  
ON

### Set and Query Scan Zero Adjustment Execution RM3545 RM3545A RM3546

---

**Syntax** Command **:ADJust:ENABle** <1/0/ON/OFF>

Query **:ADJust:ENABe?**

Response <ON/OFF>

**Example** CH 10  
:ADJ:ENAB ON  
:ADJ:ENAB?  
ON

#### (4) Measurement Speed

RM3545 RM3545A RM3546 An execution error occurs during scanning.

##### Set and Query Measurement Speed

<b>Syntax</b>	Command	<b>:SAMPle:RATE</b> <Measurement speed> <span>RM3544</span> <Measurement speed>=FAST/MEDIUm/SLOW SLOW1/SLOW2 are handled the same as with SLOW. <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span> <Measurement speed>= FAST/MEDIUm/SLOW1 /SLOW2 SLOW is handled the same as with SLOW2.
	Query	<b>:SAMPle:RATE?</b>
	Response	<span>RM3544</span> <Measurement speed>=FAST/MEDIUm/SLOW <span>RM3545</span> <span>RM3545A</span> <span>RM3546</span> <Measurement speed>= FAST/MEDIUm/SLOW1 /SLOW2

**Example** :SAMP:RATE MED  
 :SAMP:RATE?  
 MEDIUM

#### (5) Averaging Function

RM3545 RM3545A RM3546 An execution error occurs during scanning.

##### Execute and Query Averaging Function

<b>Syntax</b>	Command	<b>:CALCulate:AVERage:STATe</b> <1/0/ON/OFF>
	Query	<b>:CALCulate:AVERage:STATe?</b>
	Response	<ON/OFF>

**Example** :CALC:AVER:STAT ON  
 :CALC:AVER:STAT?  
 ON

##### Set and Query Average Count

<b>Syntax</b>	Command	<b>:CALCulate:AVERage:COUNt</b> <Count>
	Query	<b>:CALCulate:AVERage:COUNt?</b>
	Response	<Count (NR1)> = 2 to 100

**Example** :CALC:AVER:COUN 10  
 :CALC:AVER:COUN?  
 10

#### (6) Comparator

- When making comparator settings by commands, the measurement range is not automatically selected.

##### Execute and Query Comparator

<b>Syntax</b>	Command	<b>:CALCulate:LIMit:STATe</b> <1/0/ON/OFF>
	Query	<b>:CALCulate:LIMit:STATe?</b>
	Response	<ON/OFF>

**Example** :CALC:LIM:STAT ON  
 :CALC:LIM:STAT?  
 ON

**Note** When the comparator is executed, the auto range , the temperature conversion function and BIN function enter the OFF state.

RM3545 RM3545A RM3546 An execution error occurs during scanning.

### Set and Query Beeper

---

**Syntax** Command :CALCulate:LIMit:BEEPer <Condition>,<Type>,<Count>  
 Query :CALCulate:LIMit:BEEPer? <Condition>  
 Response <Condition>,<Type>,<Count>  
 <Condition> = RM3544 HI/ IN /LO  
RM3545 RM3545A RM3546 HI/ IN /LO /PASS/ FAIL  
 <Type> = 0: Buzzer OFF, 1 to 3: Type 1 to 3  
 <Count> = 0: Continuous, 1 to 5: Count [times]

**Example** :CALC:LIM:BEEP IN,1,0  
 :CALC:LIM:BEEP? IN  
 IN,1,0

**Note** RM3545 RM3545A RM3546 An execution error occurs during scanning.

### Set and Query Judgment Mode

---

**Syntax** Command :CALCulate:LIMit:MODE <ABSolute/REFerence>  
 Query :CALCulate:LIMit:MODE?  
 Response <ABSOLUTE/REFERENCE>  
 <ABSOLUTE> = Upper threshold/Lower threshold comparison  
 <REFERENCE> = Reference percentage/tolerance comparison

**Example** :CALC:LIM:MODE ABS  
 :CALC:LIM:MODE?  
 ABSOLUTE

**Note** RM3545 RM3545A RM3546 An execution error occurs during scanning.

### Set and Query ABS Mode Upper Comparator Threshold Values

---

**Syntax** Command :CALCulate:LIMit:UPPer <Upper threshold>  
 Query :CALCulate:LIMit:UPPer?  
 Response <Upper threshold[Ω]>  
RM3544 <Upper threshold[Ω]> = 0 to 1E+9 (NR3)  
RM3545 RM3545A RM3546 <Upper threshold[Ω]> = 0 to 9E+9 (NR3)

**Example** :CALC:LIM:UPP 1.0  
 The upper threshold is 1.0Ω (regardless of range).

**Note** The value will be 0 when the upper threshold is less than 1E-9.  
RM3545 RM3545A RM3546 An execution error occurs during scanning.

### Set and Query ABS Mode Lower Comparator Threshold Values

---

**Syntax** Command :CALCulate:LIMit:LOWer <Lower threshold>  
 Query :CALCulate:LIMit:LOWer?  
 Response <Lower threshold[Ω]>  
RM3544 <Lower threshold[Ω]> = 0 to 1E+9 (NR3)  
RM3545 RM3545A RM3546 <Lower threshold[Ω]> = 0 to 9E+9 (NR3)

**Example** :CALC:LIM:LOW 0.9  
 The lower threshold is 0.9Ω (regardless of range).

**Note** The value will be 0 when the lower threshold is less than 1E-9.  
RM3545 RM3545A RM3546 An execution error occurs during scanning.

## Set and Query REF% Mode Reference Resistance

**Syntax** Command **:CALCulate:LIMit:REFerence** <Reference Resistance>  
 Query **:CALCulate:LIMit:REFerence?**  
 Response <Reference Resistance[Ω]>  
 RM3544 <Reference Resistance[Ω]> = 1E-9 to 1E+9 (NR3)  
 RM3545 RM3545A RM3546 <Reference Resistance[Ω]> = 1E-9 to 9E+9 (NR3)/CH1  
 Channel 1 can be set as a reference value when the multiplexer is used.

**Example** **:CALC:LIM:REF 1.2E+3**

The reference resistance is 1.2kΩ (regardless of range).

**Note** When the reference resistance is less than 1E-9, an execution error occurs.  
 RM3545 RM3545A RM3546 An execution error occurs during scanning.

## Set and Query REF% Mode Judgment Range

**Syntax** Command **:CALCulate:LIMit:PERCent** <Range[%]>  
 Query **:CALCulate:LIMit:PERCent?**  
 Response <Range[%]>  
 RM3544 <Range[%]> = 0 to 99.99 (NR2)  
 RM3545 RM3545A RM3546  
 <Range[%]> = 0 to 99.999 (NR2)

**Example** **:CALC:LIM:PERC 1.5**

**Note** RM3545 RM3545A RM3546 An execution error occurs during scanning.

## Query Judgment Result

**Syntax** Query **:CALCulate:LIMit:RESult?** RM3544  
**:CALCulate:LIMit:RESult?** [<Channel number>]  
 RM3545 RM3545A RM3546 <Channel number> = 1 to 42  
 Response <HI/IN/LO/OFF/ERR>

**Description** RM3545 RM3545A RM3546

The comparator result of the channel number is read by assigning a channel number to the data.

If a measurement has not been performed, **ERR** is returned. The channel number is not returned. If the channel number is omitted, the comparator result of the current channel is read.

**Example** **:CALC:LIM:RES?** ... Obtains the comparator result of the current channel.

HI

**:CALC:LIM:RES? 10** ... Obtains the comparator result of Channel 10.

IN

## Set and Query PASS Judgment Condition RM3545 RM3545A RM3546

**Syntax** Command **:CALCulate:LIMit:JUDGe:CONDition** <Condition>  
 Query **:CALCulate:LIMit:JUDGe:CONDition?**  
 Response <Condition>  
 <Condition> = OFF/IN/HI/LO/HILO/ALL

**Example** **:CALC:LIM:JUDG:COND IN**  
**:CALC:LIM:JUDG:COND?**  
 IN

**Note** An execution error occurs during scanning.

**Query PASS/FAIL Result** RM3545 RM3545A RM3546

**Syntax** Query **:CALCulate:LIMit:JUDGe?** [**<Channel number>**]  
 <Channel number> = 1 to 42  
 Response **<PASS/FAIL/OFF/ERR>**

**Description** The PASS/FAIL result of the channel number is read by assigning a channel number to the data. If a measurement has not been performed, **OFF** is returned. The channel number is not returned. If the channel number is omitted, the comparator result of the current channel is read.

**Example** **:CALC:LIM:JUDG?** ... Obtains the PASS/FAIL result of the current channel.  
**PASS**  
**:CALC:LIM:JUDG? 10** ... Obtains the PASS/FAIL result of Channel 10.  
**FAIL**

**Note** When the front terminal is used or the scanning function is OFF, an execution error occurs.

**Query Total Judgment Result** RM3545 RM3545A RM3546

**Syntax** Query **:CALCulate:LIMit:JUDGe:TOTal?**  
 Response **<PASS/FAIL/OFF/ERR>**

**Example** **:CALC:LIM:JUDG:TOT?**  
**PASS**

**Note** When the front terminal is used or the scanning function is OFF, an execution error occurs. An execution error occurs during scanning. If a measurement has not been performed, **OFF** is returned.

**(7) BIN Function** RM3545 RM3545A RM3546

An execution error occurs during scanning.

**Execute and Query BIN Measurement**

**Syntax** Command **:CALCulate:BIN:STATe** **<1/0/ON/OFF>**  
 Query **:CALCulate:BIN:STATe?**  
 Response **<ON/OFF>**

**Example** **:CALC:BIN:STAT ON**  
**:CALC:BIN:STAT?**  
**ON**

**Note** When the BIN function is executed, the comparator function, auto range, and temperature conversion function all switch to OFF. In addition, the front terminal is used as a measurement terminal.

**Set Mask Pattern**

**Syntax** Command **:CALCulate:BIN:ENABle** **<Mask pattern>**  
 Query **:CALCulate:BIN:ENABle?**  
 Response **<Mask pattern (NR1)>** = 0 to 1023 (decimal number)  
 "1" will be the BIN number bit used to execute the BIN measurement.

512	256	128	64	32	16	8	4	2	1
bit9	bit8	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
BIN9	BIN8	BIN7	BIN6	BIN5	BIN4	BIN3	BIN2	BIN1	BIN0

**Example** **:CALC:BIN:ENAB 15**  
 BIN0 to BIN3 can be used.

---

## Set and Query Judgment Mode

---

**Syntax** Command **:CALCulate:BIN:MODE** <BIN No.>, <ABSolute/REFerence>  
 Query **:CALCulate:BIN:MODE?** <BIN No.>  
 Response <ABSOLUTE/REFERENCE>  
 <BIN No.> = 0 to 9  
 <ABSOLUTE> = Upper threshold/Lower threshold comparison  
 <REFERENCE> = Reference percentage/tolerance comparison

**Example** :CALC:BIN:MODE 0,ABS  
 :CALC:BIN:MODE? 0  
 ABSOLUTE

---

## Set and Query ABS Mode Upper Comparator Threshold Values

---

**Syntax** Command **:CALCulate:BIN:UPPer** <BIN No.>, <Upper threshold>  
 Query **:CALCulate:BIN:UPPer?** <BIN No.>  
 Response <Upper threshold[Ω]>  
 <Upper threshold[Ω]> = 0 to 9E+9 (NR3)

**Example** :CALC:BIN:UPPer 0,1.0  
 The upper threshold is 1.0Ω (regardless of range).

**Note** The value will be 0 when the upper threshold is less than 1E-9.

---

## Set and Query ABS Mode Lower Comparator Threshold Values

---

**Syntax** Command **:CALCulate:BIN:LOWer** <BIN No.>, <Lower threshold>  
 Query **:CALCulate:BIN:LOWer?**  
 Response <Lower threshold[Ω]>  
 <Lower threshold[Ω]> = 0 to 9E+9 (NR3)

**Example** :CALC:BIN:LOW 0,0.9  
 The lower threshold is 0.9Ω (regardless of range).

**Note** The value will be 0 when the lower threshold is less than 1E-9.

---

## Set and Query REF% Mode Reference Resistance

---

**Syntax** Command **:CALCulate:BIN:REFerence** <BIN No.>, <Reference Resistance>  
 Query **:CALCulate:BIN:REFerence?** <BIN No.>  
 Response <Reference Resistance[Ω]>  
 <BIN No.> = 0 to 9  
 <Reference Resistance[Ω]> = 1E-9 to 9E+9 (NR3)

**Example** :CALC:BIN:REF 0,1.2E+3  
 The reference resistance is 1.2kΩ (regardless of range).

**Note** When the reference resistance is less than 1E-9, a command error occurs.

---

## Set and Query REF% Mode Judgment Range

---

**Syntax** Command **:CALCulate:BIN:PERCent** <BIN No.>, <Range[%]>  
 Query **:CALCulate:BIN:PERCent?** <BIN No.>  
 Response <Range[%]>  
 <BIN No.> = 0 to 9  
 <Range[%]> = 0 to 99.999 (NR2)

**Example** :CALC:BIN:PERC 0,1.5

## Query Judgment Result

**Syntax** Query **:CALCulate:BIN:RESult?**  
 Response **<Result (NR1)> = 0 to 1024 (decimal number)**  
 "1" will be the BIN number bit for the PASS with BIN measurement.

1024

bit10	bit9	bit8	bit7	bit6	bit5
OB	BIN9	BIN8	BIN7	BIN6	BIN5
	bit4	bit3	bit2	bit1	bit0
	BIN4	BIN3	BIN2	BIN1	BIN0

**Example** **:CALC:BIN:RES?**  
**128**  
 BIN7 is PASS.

## (8) Statistical Functions RM3545 RM3545A RM3546

- A data sample can be taken by the following three methods:
    1. Press the [ENTER] key.
    2. Input the TRIG signal from EXT I/O.
    3. Send a \*TRG command.
  - The **:CALCulate:STATistics:STATe** command does not clear calculation results.
  - When the valid data count is 0,  $\sigma_{n-1}$  returns 0.
  - Even if the calculation results are cleared, the statistical calculation function does not switch to OFF.
  - The upper threshold of Cp and Cpk is 99.99. If Cp or Cpk exceeds 99.99, the value 99.99 is returned.
- An execution error occurs during scanning.

## Execute Statistical Calculation

**Syntax** Command **:CALCulate:STATistics:STATe <1/0/ON/OFF>**  
 Query **:CALCulate:STATistics:STATe?**  
 Response **<ON/OFF>**

**Example** **:CALC:STAT:STAT ON**  
**:CALC:STAT:STAT?**  
**ON**

**Note** When the statistical calculation function is executed, the temperature conversion function switches to OFF.  
 In addition, the front terminal is used as a measurement terminal.

## Clear Statistical Calculation Results

**Syntax** Command **:CALCulate:STATistics:CLEar**

## Query Data Count

**Syntax** Query **:CALCulate:STATistics:NUMBer?**  
 Response **<Total data count (NR1)>, <Valid data count (NR1)>**  
 Data count = 0 to 30000

**Example** **:CALC:STAT:NUMB?**  
**23456,23449**

## Query Mean Value

**Syntax** Query **:CALCulate:STATistics:MEAN?**  
 Response **<Mean[Q] (NR3)>**

**Example** **:CALC:STAT:MEAN?**  
**11.4859E+03**

---

### Query Maximum Value

**Syntax** Query **:CALCulate:STATistics:MAXimum?**  
 Response <Maximum value[Q] (NR3)>,<Data No. of Maximum value (NR1)>

**Example** :CALC:STAT:MAX?  
 12.4859E+03,1124

---

### Query Minimum Value

**Syntax** Query **:CALCulate:STATistics:MINimum?**  
 Response <Minimum value[Q] (NR3)>,<Data No. of Minimum value (NR1)>

**Example** :CALC:STAT:MIN?  
 10.4859E+03,1125

---

### Query Comparator Results

**Syntax** Query **:CALCulate:STATistics:LIMit?**  
 Response <Hi count (NR1)>,<IN count (NR1)>,<Lo count (NR1)>,  
 <Measurement fault count (NR1)>,<Out-of-range count (NR1)>

**Example** :CALC:STAT:BIN?  
 1516,9310,737,16,5

---

### Query BIN Result

**Syntax** Query **:CALCulate:STATistics:BIN?**  
 Response <BIN0 count (NR1)>,...<BIN9 count (NR1)>,<OUT count (NR1)>,  
 <Measurement fault count (NR1)>

**Example** :CALC:STAT:BIN?  
 1516,9310,10,10,10,10,10,10,10,10,100,737,16

---

### Query Standard Deviation

**Syntax** Query **:CALCulate:STATistics:DEViation?**  
 Response < $\sigma_n$ [Q] (NR3)>,< $\sigma_{n-1}$ [Q] (NR3)>

**Example** :CALC:STAT:DEV?  
 0.0159E-3,0.0161E-3

---

### Query Process Capability Indices

**Syntax** Query **:CALCulate:STATistics:CP?**  
 Response <Cp (NR2)>,<Cpk (NR2)>

**Example** CALC:STAT:CP?  
 0.86,0.14

## (9) Scaling

RM3545 RM3545A RM3546 An execution error occurs during scanning.

---

### Execute and Query Scaling Function

**Syntax** Command **:CALCulate:SCALing:STATe** <1/0/ON/OFF>  
 Query **:CALCulate:SCALing:STATe?**  
 Response <ON/OFF>

**Example** :CALC:SCAL:STAT ON  
 :CALC:SCAL:STAT?  
 ON

**Note** When the scaling function is turned ON, the Advanced Temperature Correction is turned OFF.

### Set and Query Scaling Correction Coefficient

<b>Syntax</b>	Command	<b>:CALCulate:SCALing:PARAmeterA</b> <Correction coefficient>
	Query	<b>:CALCulate:SCALing:PARAmeterA?</b>
	Response	<Correction coefficient (NR3)> <Correction coefficient> = 0.2000E-03 to 1.9999E+03
<b>Example</b>		:CALC:SCAL:PARA 2E+00
		:CALC:SCAL:PARA?
		0.2000E+00

### Set and Query Scaling Offset

<b>Syntax</b>	Command	<b>:CALCulate:SCALing:PARAmeterB</b> <Offset>
	Query	<b>:CALCulate:SCALing:PARAmeterB?</b>
	Response	<Offset [Ω]> <span style="border: 1px solid black; padding: 2px;">RM3544</span> <Offset> = -1.0000E+09~1.0000E+09 <span style="border: 1px solid black; padding: 2px;">RM3545</span> <span style="border: 1px solid black; padding: 2px;">RM3545A</span> <span style="border: 1px solid black; padding: 2px;">RM3546</span> <Offset> = -1.0000E+09~9.0000E+09
<b>Example</b>		:CALC:SCAL:PARB 1E+03
		:CALC:SCAL:PARB?
		1.0000E+03
<b>Note</b>	When the offset is less than +/-1E-9, "0" will result.	

### Set and Query Scaling Unit

<b>Syntax</b>	Command	<b>:CALCulate:SCALing:UNIT</b> <Unit>
	Query	<b>:CALCulate:SCALing:UNIT?</b>
	Response	<Unit> <Unit> = OFF(no unit)/OHM[Ω]/Any unit (any unit is character string data:maximum 3 characters) For information on character string data, see Data Formats. (p.4)
<b>Example</b>		:CALC:SCAL:UNIT "m"
		:CALC:SCAL:UNIT?
		"m"

### (10) Temperature Conversion (ΔT) RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

### Execute and Query Temperature Conversion (ΔT)

<b>Syntax</b>	Command	<b>:CALCulate:TCONversion:DELTA:STATe</b> <1/0/ON/OFF>
	Query	<b>:CALCulate:TCONversion:DELTA:STATe?</b>
	Response	<ON/OFF>
<b>Example</b>		:CALC:TCON:DELT:STAT ON
		:CALC:TCON:DELT:STAT ON?
		ON
<b>Note</b>	When the temperature conversion function is executed, the comparator function, temperature correction function, BIN function, and statistical calculation function switch to OFF.	

### Set and Query Temperature Conversion (ΔT)

<b>Syntax</b>	Command	<b>:CALCulate:TCONversion:DELTA:PARAmeter</b> <Initial resistance>,<Initial temperature>,<Constant>
	Query	<b>:CALCulate:TCONversion:DELTA:PARAmeter?</b>
	Response	<Initial resistance[Ω]>,<Initial temperature[°C]>,<Constant[°C]> <Initial resistance[Ω]> = 0 to 9000.000E+6 (NR3) <Initial temperature[°C]> = -10.0 to 99.9 (NR2) <Constant[°C]> = -999.9 to 999.9 (NR2)
<b>Example</b>		:CALC:TCON:DELT:PAR 100,20,235
		:CALC:TCON:DELT:PAR?
		100.000E+0,20.0E+0,235.0

**(11) Temperature Correction (TC)**

**RM3545** **RM3545A** **RM3546** If executed while the Scan measurement is in progress, Err032 occurs.

**Execute and Query Temperature Correction (TC)**

**Syntax** Command **:CALCulate:TCORrect:STATe** <1/0/ON/OFF>  
 Query **:CALCulate:TCORrect:STATe?**  
 Response <ON/OFF>

**Example** :CALC:TCOR:STAT ON  
 :CALC:TCOR:STAT?  
 ON

**Note** **RM3545** **RM3545A** **RM3546** When the temperature correction function is executed, the temperature conversion function switches to OFF.

**Set and Query Temperature Correction (TC)**

**Syntax** Command **:CALCulate:TCORrect:PARAmeter**  
 <Reference temperature>,<Temperature coefficient>  
 Query **:CALCulate:TCORrect:PARAmeter?**  
 Response <Reference temperature [°C]>,<Temperature coefficient [ppm/°C]>  
 <Reference temperature[°C]> = -10.0 to 99.9 (NR2)

**Example** **RM3544**  
 <Temperature coefficient [ppm/°C]> = -9999 to 9999 (NR1)  
**RM3545** **RM3545A** **RM3546**  
 <Temperature coefficient [ppm/°C]> = -99999 to 99999 (NR1)  
 :CALC:TCOR:PAR 20,3930  
 :CALC:TCOR:PAR?  
 70.0,4500

**(12) Advanced Temperature Correction (A-TC)** **RM3546****Set and Query Advanced Temperature Correction (A-TC)**

**Syntax** Command **:ATC:TCORrect:STATe** <1/0/ON/OFF>  
 Query **:ATC:TCORrect:STATe?**  
 Response <ON/OFF>

**Example** :ATC:TCOR:STAT ON  
 :ATC:TCOR:STAT?  
 ON

**Note** When the Advanced Temperature Correction (A-TC) is set to ON, the temperature conversion, temperature correction, and scaling function are set to "OFF".

**Set and Query Reference temperature and Temperature Coefficient for Weld location**

**Syntax** Command **:ATC:TCORrect:PARAmeter**  
 <Reference temperature>,<Temperature coefficient>  
 Query **:ATC:TCORrect:PARAmeter?**  
 Response <Reference temperature [°C]>,<Temperature coefficient [ppm/°C]>  
 <Reference temperature[°C]> = -10.0 to 99.9 (NR2)  
 <Temperature coefficient [ppm/°C]> = -99999 to 99999 (NR1)

**Example** :ATC:TCOR:PAR 23,3800  
 :ATC:TCOR:PAR?  
 23.0,3800

### Set and Query Resistance value, Reference Temperature, and Temperature coefficient for Temperature Measurement area

---

**Syntax** Command **:ATC:TCONversion:DELTA:PARAmeter** <Resistance Value>,<Reference temperature>,<Temperature coefficient>  
 Query **:ATC:TCONversion:DELTA:PARAmeter?**  
 Response <Resistance Value>,<Reference temperature>,<Temperature coefficient>  
 <Resistance Value [Ω]> = 0.001E-6 to 9000.000E+6 (NR3)  
 <Reference temperature[°C]> = -10.0 to 99.9 (NR2)  
 <Temperature coefficient [ppm/°C]> = -99999 to 99999 (NR1)

**Example** **:ATC:TCON:DELT:PAR 16.5E-3,23,4000**  
**:ATC:TCON:DELT:PAR?**  
**1.650000E-02,23.0,4000**

### Set and Query Z3003 pin allocation for Temperature measurement area

---

**Syntax** Command **:ATC:TERMinal** <Unit No>, <Terminal A Number>, <Terminal B Number>  
 Query **:ATC:TERMinal?**  
 Response <Unit No>, <Terminal A Number>, <Terminal B Number>  
 <Unit No> = 1 / 2 (NR1)  
 <Terminal A Number> = 1 to 10 (NR1)  
 <Terminal B Number> = 1 to 10 (NR1)

**Example** **:ATC :TERM 1,1,1**  
**:ATC :TERM?**  
**1,1,1**

### Set and Query Measurement speed for Temperature measurement area

---

**Syntax** Command **:ATC:RATE** < Measurement Speed >  
 <Measurement Speed> = FAST / MEDium / SLOW1 / SLOW2  
 SLOW is treated the same as SLOW2.

Query **:ATC:RATE?**  
 Response <Measurement Speed> = FAST / MEDium / SLOW1 / SLOW2

**Example** **:ATC:RATE MED**  
**:ATC:RATE?**  
**MEDIUM**

A

### Set and Query AUTO-ranging for Temperature measurement area

---

**Syntax** Command **:ATC:RANGe:AUTO** <1/0/ON/OFF>  
 Query **:ATC:RANGe:AUTO?**  
 Response <ON/OFF>

**Example** **:ATC:RANG:AUTO ON**  
**:ATC:RANG:AUTO?**  
**ON**

---

### Set and Query Measurement range for Temperature measurement area

---

**Syntax** Command **:ATC:RANGe** <Expected Measurement Value>  
 Query **:ATC:RANGe?**  
 Response <Measurement Range (NR3)>  
 <Expected Measurement Value> = 0 to 1200E+06  
 <Measurement Range (NR3)> = 1000.000E-6 /10.00000E-3/ 100.0000E-3/  
 1000.000E-3/ 10.00000E+0/100.0000E+0/  
 1000.000E+0/ 10.00000E+3/100.0000E+3/  
 1000.000E+3/10.00000E+6/100.0000E+6/  
 1000.000E+6

**Example** :ATC:RANG 56E-3

The 100 mΩ range is going to be selected for the temperature measurement.

:ATC:RANG?

100.0000E-3

**Note** When the multiplexer measurement method is 2-wire, the range cannot be set to 10Ω or lower.

---

### Set and Query Preset delay for Temperature measurement area

---

**Syntax** Command **:ATC:DELay:AUTO** <1/0/ON/OFF>  
 Query **:ATC:DELay:AUTO?**  
 Response <ON/OFF>

**Example** :ATC:DEL:AUTO ON

:ATC:DEL:AUTO?

ON

---

### Set and Query User-set delay time for Temperature measurement area

---

**Syntax** Command **:ATC:DELay** <Delay Time>  
 Query **:ATC:DELay?**  
 Response <Delay Time>  
 <Delay Time> = 0 to 9.999 (NR2) [seconds]

**Example** :ATC:DEL 0.015

:ATC:DEL?

0.015

---

### Set and Query Averaging Function for Temperature measurement area

---

**Syntax** Command **:ATC:AVERAge:STATe** <1/0/ON/OFF>  
 Query **:ATC:AVERAge:STATe?**  
 Response <ON/OFF>

**Example** :ATC:AVER:STAT ON

:ATC:AVER:STAT?

ON

---

### Set and Query Averaging iterations for Temperature measurement area

---

**Syntax** Command **:ATC:AVERAge:COUNt** <Count>  
 Query **:ATC:AVERAge:COUNt?**  
 Response <Count (NR1)> = 2 to 100

**Example** :ATC:AVER:COUN 4

:ATC:AVER:COUN?

4

---

### Set and Query Advanced Offset Voltage Compensation (A-OVC) for Temperature measurement area

---

**Syntax** Command    **:ATC:AOVC** <1/0/ON/OFF>  
 Query           **:ATC:AOVC?**  
 Response        <ON/OFF>

**Example**    **:ATC:AOVC ON**  
               **:ATC:AOVC?**  
               **ON**

---

### Set and Query Pure Resistance Mode (PR) for Temperature Measurement area

---

**Syntax** Command    **:ATC:PR:STATe** <1/0/ON/OFF>  
 Query           **:ATC:PR:STATe?**  
 Response        <ON/OFF>

**Example**    **:ATC:PR:STAT ON**  
               **:ATC:PR:STAT?**  
               **ON**

---

### Set and Query Measurement Current for Temperature Measurement area

---

**Syntax** Command    **:ATC:CURRent** <HIGH/LOW>  
 Query           **:ATC:CURRent?**  
 Response        <1A/0.1A>

**Example**    **:ATC:CURR HIGH**  
               **:ATC:CURR?**  
               **1A**

---

### Set and Query Contact Check for Temperature Measurement area

---

**Syntax** Command    **:ATC:CONtactcheck** <1/0/ON/OFF>  
 Query           **:ATC:CONtactcheck?**  
 Response        <ON/OFF>

**Example**    **:ATC:CONT ON**  
               **:ATC:CONT?**  
               **ON**

---

### Set and Query Contact Check for Temperature Measurement area

---

**Syntax** Command    **:ATC:CIMProve** <1/0/ON/OFF>  
 Query           **:ATC:CIMProve?**  
 Response        <ON/OFF>

**Example**    **:ATC:CIMP ON**  
               **:ATC:CIMP?**  
               **ON**

**(13) Reading Measured Values in Advanced Temperature Correction (A-TC)** RM3546**Reading the Last Measurement Value in Advanced Temperature Correction (A-TC)**

**Syntax** Query **:ATC:FETCh?** <ATC/ATCR/R/T>  
 Response <Channel Number>, <Resistance Value/Temperature>  
 The content of the response following <Channel Number> corresponds to the arguments of the data section.

**Description** Reading the last (most recent) measurement value in the Advanced Temperature Correction (A-TC).

The correspondence between the arguments and their responses is as follows:

Argument	Response
Omission	Processed as "ATC"
ATC	Returns the measurement values of the welding points before and after correction: <Channel Number>, <Resistance Value After Correction>, <Resistance Value Before Correction>, <Temperature Before Correction>
ATCR	Returns the measurement values of the welding points after correction: <Channel Number>, <Resistance Value After Correction>
R	Returns the measurement values of the welding points before correction: <Channel Number>, <Resistance Value Before Correction>
T	Returns the measurement values of the welding points before correction: <Channel Number>, <Temperature Before Correction>

The configuration for A-TC (p.84)

**Example** **ATC:FETCh? ATC**  
**1,100.000E-06, 139.300E-06, 100.00E+00**

**NOTE** The execution error (Err:032) will occur in the following cases:  
 The MUX (Multiplexer) is OFF  
 During scanning

## Reading measurement values with Advanced Temperature Correction (A-TC)

**Syntax** Query **:ATC:READ?** <ATC/ATCR/R/T>  
 Response <Channel Number>, <Resistance Value/Temperature>  
 The content of the response following <Channel Number> corresponds to the arguments of the data section.

**Description** Initiating the A-TC function and reading the measurement values after the measurement is completed.

The correspondence between the arguments and their responses is as follows:

argument	response
Omission	The same as the argument ATC
ATC	Returns the measurement values of the welding points before and after correction: <Channel Number>, <Resistance Value After Correction>, <Resistance Value Before Correction>, <Temperature Before Correction>
ATCR	Returns the measurement values of the welding points after correction: <Channel Number>, <Resistance Value After Correction>
R	Returns the measurement values of the welding points before correction: <Channel Number>, <Resistance Value Before Correction>
T	Returns the measurement values of the welding points before correction: <Channel Number>, <Temperature Before Correction>

The configuration for A-TC(p.84)

**Example** **ATC:READ? ATC**  
**1,100.000E-06, 139.300E-06, 100.00E+00**

**NOTE** The execution error (Err:032) will occur in the following cases:  
 The MUX (Multiplexer) is OFF  
 The scan function is set to Auto or Step  
 When obtaining corrected measurement values with the scan function set to Auto or Step, please use :READ?.

## Starting measurement in Advanced Temperature Correction (A-TC).

**Syntax** Command **:ATC:INITiate**

**Description** Start the A-TC measurement and wait for it to complete.  
 The configuration method for A-TC(p.84)

**Example** **:ATC:INITiate**

**NOTE** The execution error (Err:032) will occur in the following cases:  
 The MUX (Multiplexer) is OFF  
 The scan function is set to Auto or Step  
 When obtaining corrected measurement values with the scan function set to Auto or Step, please use :READ?.

## (14) LCD Settings

RM3545 RM3545A RM3546 If executed while the Scan measurement is in progress, Err032 occurs.

### Set and Query Contrast

---

**Syntax** Command    :**DISPlay:CONTRast** <0 to 100>  
 Query            :**DISPlay:CONTRast?**  
 Response        <0 to 100 (NR1)>

**Example**    :**DISP:CONT** 80  
               :**DISP:CONT?**  
               80

### Set and Query Backlight

---

**Syntax** Command    :**DISPlay:BACKlight** <0 to 100>  
 Query            :**DISPlay:BACKlight?**  
 Response        <0 to 100 (NR1)>

**Example**    :**DISP:BACK** 50  
               :**DISP:BACK?**  
               50

## (15) Memory Functions RM3545 RM3545A RM3546

You can save and load up to 50 measurement data entries. This function cannot be used when a multiplexer is used. An execution error occurs.

This is enabled only with a remote command.

Measurement values are entered in memory through the [ENTER] key, TRIG signal, and \*TRG command.

### Set and Query Memory Functions

---

**Syntax** Command    :**MEMory:STATe** <1/0/ON/OFF>  
 Query            :**MEMory:STATe?**  
 Response        <ON/OFF>

**Note**        Changing the memory mode setting erases the stored data.

**Example**    :**MEM:STAT** ON  
               :**MEM:STAT?**  
               ON

### Clear Memory Data

---

**Syntax** Command    :**MEMory:CLEAr**  
**Example**    :**MEM:CLE**

### Query Memory Data Count

---

**Syntax** Query        :**MEMory:COUNt?**  
 Response        <Memory data count (NR1) > = 0 to 50

**Example**    :**MEM:COUN?**  
               3

---

## Read Memory Data

**Syntax** Query **:MEMory:DATA?**  
 Response <Measurement value>,<Measurement value>,...,  
 <Measurement value>

**Description** Measured values transferred from memory are separated by commas (“,”). The number of stored measurement values to be exported can be acquired by the **:MEMory:COUNT?** query.  
 See: “Measurement Value Formats” (p.28)

**Note** When fifty (50) measurement values have been entered into memory, no additional measurement values can be stored until the memory content is cleared.

## (16) Hold

RM3545 RM3545A RM3546 If executed while the Scan measurement is in progress, Err032 occurs.

---

## Execute and Query Auto Hold

**Syntax** Command **[:SENSe:]HOLD:AUTO <1/0/ON/OFF >**  
 Query **[:SENSe:]HOLD:AUTO?**  
 Response <ON/OFF>

**Example** HOLD:AUTO ON  
 HOLD:AUTO?  
 ON

**Note** When auto hold is executed, **:INITIATE:CONTINUOUS ON** and internal trigger (trigger source <IMMEDIATE>) are enabled.

---

## Query Auto Hold State

**Syntax** Query **[:SENSe:]HOLD:STATe?**  
 Response <ON/OFF>

**Description** Queries the current hold state.  
 <ON> = HOLD indicator on the screen turns on, and hold is executed.  
 <OFF> = HOLD indicator on the screen turns off, and hold is not executed.

**Example** HOLD:STAT?  
 ON

---

## Cancel Hold

**Syntax** Command **[:SENSe:]HOLD:OFF**

**Description** Cancels the hold state. (HOLD indicator on the screen turns off.)

**Example** HOLD:OFF

**(17) Multiplexer Settings** RM3545 RM3545A RM3546

- Also see “4 Multiplexer Commands (p.76)” for the multiplexer unit.

**Set and Query Measurement Method**


---

<b>Syntax</b>	Command	<b>[[:SENSE:]]WIRE &lt;4/2/W4/W2&gt;</b>
	Query	<b>[[:SENSE:]]WIRE?</b>
	Response	<b>&lt;W4/W2&gt;</b>

<4/W4> = 4-wire type  
<2/W2> = 2-wire type

**Example**    **WIRE W4**  
                  **WIRE?**  
                  **W4**

**Note**        When the measurement method is switched, the multiplexer channel reset is activated. The multiplexer settings including the measurement conditions are reset. Make sure to determine the measurement method before measuring each channel. An execution error occurs during scanning.

**Set and Query Scanning Function**


---

<b>Syntax</b>	Command	<b>[[:SENSE:]]SCAN:MODE &lt;OFF/AUTO/STEP&gt;</b>
	Query	<b>[[:SENSE:]]SCAN:MODE?</b>
	Response	<b>&lt;OFF/AUTO/STEP&gt;</b>

**Example**    **SCAN:MODE:AUTO**  
                  **SCAN:MODE?**  
                  **AUTO**

**Note**        An execution error occurs during scanning.

**Query Scanning Execution State**


---

<b>Syntax</b>	Query	<b>[[:SENSE:]]SCAN:STATe?</b>
	Response	<b>&lt;0/1/2 (NR1)&gt;</b>

**Description**    Responds with whether scanning is being executed or not.  
 0 is returned when the scanning function is OFF or scanning is paused.  
 1 is returned during auto scanning or step scanning.  
 2 is returned during the scanning and the measuring.

**Example**        **(During step scanning)**  
                  **SCAN:STAT?**  
                  **1**  
                  **\*TRG**  
                  **SCAN:STAT?**  
                  **1**  
                  **\*TRG**  
                  **SCAN:STAT?**  
                  **0**

---

### Initialize Scan Channel and Measured Value or Judgment Value

**Syntax** Command `[:SENSe:]SCAN:RESet`

**Description** Returns the scan channel to the initial channel. Also, the measured value and judgment value are cleared and the instrument is set to the non-measurement state.

---

### Set and Query Scan Fail Stop

**Syntax** Command `[:SENSe:]SCAN:FAIL:STOP <1/0/ON/OFF>`  
 Query `[:SENSe:]SCAN:FAIL:STOP?`  
 Response `<ON/OFF>`

**Example** `:SCAN:FAIL:STOP ON`  
`:SCAN:FAIL:STOP?`  
`ON`

**Note** An execution error occurs during scanning.

---

### Read Scanned Measurement Data in a Batch

**Syntax** Query `[:SENSe:]SCAN:DATA?`  
 Response `<Measured value>,<Measured value>, ...<Measured value>`

**Description** The measured values at the time of scanning completion are separated by commas (","),. Only the data with `[:SENSe:]STATe ON` is returned. The number of data items is the same as the channel count that can be obtained using a `[:SENSe:]CH:AVAIrable?` query. If a measurement has not been performed, the value for a measurement fault is returned. See: "Measurement Value Formats" (p.28)

**Example** `CH:AVA?`  
`3`  
`SCAN:DATA?`  
`1023.579E-00,1000.000E-03, 100.0000E-03`

**Note** An execution error occurs during scanning.

---

### Query Connected to The Front Measurement Terminal

**Syntax** Query `[:SENSe:]FRONTcheck?`  
 Response `<1/0 (NR1)>`

`<0>` = A test lead is not connected to the front measurement terminal.  
`<1>` = A test lead is connected to the front measurement terminal.

**Description** If a test lead is connected to the front terminal, the data cannot be displayed properly when a measurement is performed using a multiplexer. When there is a possibility that a test lead may be connected to the front terminal, make sure to check that the response is 0.

**Example** Check the front measurement terminal.  
`FRON?`  
`0`  
 Measurement  
`READ?`  
`1020.000E-03, 100.000E-03, 100.000E-03`

**Note** An execution error occurs during scanning.

## Set and Query Channel Switching

---

**Syntax** Command `[:SENSe:]CH <FRONT/0/Channel number>`  
 Query `[:SENSe:]CH?`  
 Response `<FRONT/Channel number>`  
 <FRONT><0> = The front terminal is used as a measurement terminal.  
 <Channel number> = 1 to 42 (NR1) (The measurement terminal is used as a multiplexer.)

**Description** Sets the switching of the multiplexer channel and queries the current channel. The measurement conditions, measurement, and comparator result of each channel need to be set and obtained after the channel is switched.  
 See: "4 Multiplexer Commands (p.76)".

**Example** The front terminal is used.  
`CH FRON`  
`CH?`  
`FRONT`  
 Check the front measurement terminal.  
`FRON?`  
`0`  
 Use a multiplexer and switch the channel to 10.  
`CH 10`  
`CH?`  
`10`

**Note** When the channel is not set to the front terminal, the statistical calculation function and memory function switch to OFF.  
 If a test lead is connected to the front terminal, the data cannot be displayed properly when a measurement is performed using a multiplexer. When there is a possibility that a test lead may be connected to the front terminal, make sure to check that the response to the `[:SENSe:]FRONTcheck?` command is 0.  
 An execution error occurs during scanning.

## Set and Query Multiplexer Channel

---

**Syntax** Command `[:SENSe:]CH:STATe <1/0/ON/OFF>[,<Channel number>]`  
 Query `[:SENSe:]CH:STATe? [<Channel number>]`  
 Response `<ON/OFF>`  
 <Channel number> = 1 to 42 (NR1)

**Example** `CH:STAT ON,10`  
`CH:STAT? 10`  
`ON`

**Note** An execution error occurs during scanning.

## Query Multiplexer Channel Count

---

**Syntax** Query `[:SENSe:]CH:AVAIable?`  
 Response `<Channel count (NR1)>`

**Description** Only the number of the channels with `[:SENSe:]CH:STATe ON` is returned.

**Example** `CH:AVA?`  
`20`

**Note** An execution error occurs during scanning.

## Setting and Query Multiplexer channel pin assignment

---

**Syntax** Command **[[:SENSe:]INSTrument <INTernal/EXTernal>**  
 Query **[[:SENSe:]INSTrument?**  
 Response **<INTernal/ EXTernal>**  
 <INTernal> = Measurement using RM3545, RM3545A and RM3546  
 <EXTernal> = Measurement using external equipment (multiplexer EX terminal is used.)

**Example** CH 10  
 INST INT  
 INST?  
 INT

**Note** When the front terminal is used, an execution error occurs.  
 An execution error occurs during scanning.

## Set and Query Allocation of Multiplexer Channel Terminals

---

**Syntax** Command **[[:SENSe:]TERMinal <Unit number>,<A terminal number>,<B terminal number>**  
 Query **[[:SENSe:]TERMinal?**  
 Response **<Unit number>,<A terminal number>,<B terminal number>**  
 <Unit number> = 1/2 (NR1)  
 <Terminal A number> = 1 to 10 (NR1) for 4-wire type, 1 to 21 (NR1) for 2-wire type  
 <Terminal B number> = 1 to 10 (NR1) for 4-wire type, 1 to 21 (NR1) for 2-wire type

**Example** CH 10  
 TERM 1,1,2  
 TERM?  
 1,1,2

**Note** When the front terminal is used, an execution error occurs.  
 The measurement current flows from terminal B to terminal A.  
 An execution error occurs during scanning.

### (18) Multiplexer Channel Reset RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

### Execute Multiplexer Channel Reset

---

**Syntax** Command **[[:SENSe:]CHReset**

**Description** Initializes the multiplexer channel settings including the measurement conditions.

**Note** An execution error occurs when the front terminal is used as a measurement terminal or during scanning.

**(19) Low-Power Resistance Measurement** RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

**Set and Query Low-Power Resistance Measurement**

---

<b>Syntax</b>	Command	<b>[[:SENSE:]RESistance:LP:STATe &lt;1/0/ON/OFF&gt;</b>
	Query	<b>[[:SENSE:]RESistance:LP:STATe?</b>
	Response	<b>&lt;ON/OFF&gt;</b>

**Example**    **RES:LP:STAT ON**  
 Selects the Low-Power Resistance measurement.  
**RES:LP:STAT?**  
**OFF**  
 The Resistance measurement has been selected.

**(20) Pure Resistance measurement** RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

**Set and Query Low-Power Resistance Measurement**

---

<b>Syntax</b>	Command	<b>[[:SENSE:]RESistance:PR:STATe &lt;1/0/ON/OFF&gt;</b>
	Query	<b>[[:SENSE:]RESistance:PR:STATe?</b>
	Response	<b>&lt;ON/OFF&gt;</b>

**Example**    **RES:LP:STAT ON**  
 Selects the Pure Resistance measurement.  
**RES:LP:STAT?**  
**OFF**  
 The Resistance measurement has been selected.

**(21) Measurement Range**

**RM3545** **RM3545A** **RM3546** If executed while the Scan measurement is in progress, Err032 occurs.

**Set and Query Resistance Measurement Range**

**Syntax** Command **[[:SENSE:]RESistance:RANGe** <Expected measurement value>  
 Query **[[:SENSE:]RESistance:RANGe?**  
 Response <Measurement Range (NR3)>

**RM3544**

<Expected measurement value> = 0 to 3.5E+06

<Measurement Range (NR3)> = 30.000E-3/ 300.00E-3/ 3.0000E+0/  
 30.000E+0/300.00E+0/ 3.0000E+3/  
 30.000E+3/ 300.00E+3/3.0000E+6

**RM3545** **RM3545A** **RM3546**

<Expected measurement value> = 0 to 1200E+06

<Measurement Range (NR3)> = 1000. 000E-6 \*1/  
 10.00000E-3/100.0000E-3/1000.000E-3/  
 10.00000E+0/100.0000E+0/1000.000E+0/  
 10.00000E+3/100.0000E+3/1000.000E+3/  
 10.00000E+6/100.0000E+6/1000.000E+6

\*1 : RM3545A and RM3546 only

**Description** Command

Enter the expected measurement value. The instrument is set to the most suitable range for measuring the given numerical value data. When the scaling function is being used, set the <Expected measurement value> to the value that existed prior to scaling (value in range being used).

When a range is set, the auto-range function will be automatically turned off.

## Query

Queries the measurement range setting.

The setting will be that of Low-Power OFF. For the Low-Power ON setting, use:

**[[:SENSE:]RESistance:LP:RANGe**

**[[:SENSE:]RESistance:LP:RANGe?**

**Example** **RES:RANG 95**

**RM3544** Sets the Resistance measurement to the 300Ω range.

**RM3545** **RM3545A** **RM3546** Sets the Resistance measurement to the □ 100Ω range.

**Note** **RM3545** **RM3545A** **RM3546** When the multiplexer measurement method is the 2-line type, the measurement range is not set to 10Ω or less.

**Set and Query Resistance Measurement Auto Range**

**Syntax** Command **[[:SENSE:]RESistance:RANGe:AUTO** <1/0/ON/OFF>  
 Query **[[:SENSE:]RESistance:RANGe:AUTO?**  
 Response <ON/OFF>

**Description** The auto range setting will be the same for Low-Power OFF/ON.

**Example** **RES:RANG:AUTO OFF**  
**RES:RANG:AUTO?**  
**OFF**

**Note** An execution error occurs when the auto range is turned ON if the comparator function and BIN measurement function are ON.

---

**Set and Query Low-Power Resistance Measurement Range** RM3545 RM3545A


---

**Syntax**

Command	<b>[:SENSe:]RESistance:LP:RANGe</b> <Expected measurement value>
Query	<b>[:SENSe:]RESistance:LP:RANGe?</b>
Response	<Measurement Range (NR3)>
	<Expected measurement value> = 0 to 1200E+00
	<Measurement Range (NR3)> = 1000.00E-03/10.0000E+00/100.000E+00/1000.00E+00

**Description****Command**

Enter the expected measurement value. The instrument is set to the most suitable range for measuring the given numerical value data. When the scaling function is being used, set the <Expected measurement value> to the value that existed prior to scaling (value in range being used).

**Query**

Queries the measurement range setting.

The setting will be that of Low-Power ON. For the Low-Power OFF setting, use:

**[:SENSe:]RESistance:RANGe**

**[:SENSe:]RESistance:RANGe?**

**Example** **RES:LP:RANG?**  
**1000.00E+00**

Low-Power Resistance measurement has been set to the 1000mΩ range.

**(22) 100MΩ Range High Precision Function** RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

---

**Set and Query 100MΩ Range High Precision Function** RM3545 RM3545A RM3546


---

**Syntax**

Command	<b>[:SENSe:]RESistance:PRECision</b> <1/0/ON/OFF>
Query	<b>[:SENSe:]RESistance:PRECision?</b>
Response	<ON/OFF>

**Description**

The 100MΩ range becomes the high precision mode. The 1000MΩ range cannot be used when the high precision function is ON.

**Example** **:RES:PREC ON**  
**:RES:PREC?**  
**ON**

**(23) Switching Measurement Current** RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

**Set and Query Measurement Current** RM3545 RM3545A RM3546

**Syntax** Command **[:SENSe:]RESistance:CURRent <HIGH/LOW>**  
 Query **[:SENSe:]RESistance:CURRent?**  
 Response **<HIGH/LOW>**

**Description** The measurement current will be as shown in the table below.

Range	Measurement Current		Compatible models		
	High	Low	RM3545	RM3545A	RM3546
1000 $\mu\Omega$	1 A	500 mA*2	–	√ (High only)	√
PR1000 $\mu\Omega$ *1			–	√ (High only)	√
10 m $\Omega$	1 A	500 mA*2	√ (High only)	√ (High only)	√
PR10 m $\Omega$ *1			–	√ (High only)	√
100 m $\Omega$	1 A	100 mA	√	√	√
PR100 m $\Omega$ *1		–	√ (High only)	√ (High only)	
1000 m $\Omega$	100 mA	10 mA	√	√	√
10 $\Omega$	10 mA	1 mA	√	√	√
100 $\Omega$	10 mA	1 mA	√	√	√

\*1 : PR mode is RM3545A and RM3546 only

\*2 : 500 mA is RM3546 only

**Example** **[:RES:CURR HIGH]**  
**[:RES:CURR?]**  
**HIGH**

**(24) Offset Voltage Compensation Function (OVC)** RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

**Set and Query Offset Voltage Compensation Function (OVC)**

**Syntax** Command **[:SENSe:]RESistance:OVC <1/0/ON/OFF>**  
 Query **[:SENSe:]RESistance:OVC?**  
 Response **<ON/OFF>**

**Example** **RES:OVC ON**  
**RES:OVC?**  
**ON**

**Note** When Low-Power is ON, the query response will definitely be ON.

**(25) Advanced Offset Voltage Compensation Function (A-OVC)** RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

**Set and Query Offset Advanced Voltage Compensation Function (A-OVC)**

<b>Syntax</b>	Command	<b><code>[:SENSe:]RESistance:AOVC &lt;1/0/ON/OFF&gt;</code></b>
	Query	<b><code>[:SENSe:]RESistance:AOVC?</code></b>
	Response	<b><code>&lt;ON/OFF&gt;</code></b>

**Example**    `RES:OVC ON`  
               `RES:OVC?`  
               `ON`

**Note**        When in Low-Power Resistance Measurement mode, the OVC function is forcibly turned ON. The response to the query will also be ON.

**(26) Contact Improver** RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

**Set and Query Contact Improver Operating Mode**

<b>Syntax</b>	Command	<b><code>[:SENSe:]RESistance:CIMProve &lt;1/0/ON/OFF&gt;</code></b>
	Query	<b><code>[:SENSe:]RESistance:CIMProve?</code></b>
	Response	<b><code>&lt;ON/OFF&gt;</code></b>

**Example**    `RES:CIMP ON`  
               `RES:CIMP?`  
               `ON`

**Note**        When in Low-Power Resistance Measurement mode, the OVC function is forcibly turned ON. The response to the query will also be ON.

**(27) Current Error Mode**

If executed while the Scan measurement is in progress, Err032 occurs.

**Set and Query Current Error Mode**

<b>Syntax</b>	Command	<b><code>[:SENSe:]RESistance:ERRor:CURRentcheck &lt;ERRor/OVER&gt;</code></b>
	Query	<b><code>[:SENSe:]RESistance:ERRor:CURRentcheck?</code></b>
	Response	<b><code>&lt;ERROR/OVER&gt;</code></b>

**Example**    `RES:ERR:CURR ERR`  
               `RES:ERR:CURR?`  
               `ERROR`

`<ERROR>` = Current error  
`<OVER>` = Out-of-range

**Set and Query Overrange external Err terminal** RM3545A RM3546

<b>Syntax</b>	Command	<b><code>:SENSe:RESistance:ERRor:OVER &lt;ERRor/NORMal&gt;</code></b>
	Query	<b><code>:SENSe:RESistance:ERRor:OVER?</code></b>
	Response	<b><code>&lt;ERRor/NORMal&gt;</code></b>

`<ERRor>` = External Err terminal output when over range  
`<NORMal>` = External Err terminal does not output when over range

**Description Note**    Use when you want to distinguish between over range and Hi/Lo during judgment.  
                           \*`RST` command does not revert to default.  
                           `:SYSTEM:RESet` returns to default.

**(28) Contact Check** RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs. Contact check errors can be checked using the event status register. (p.27)

**Set and Query Resistance Measurement Contact Check**

<b>Syntax</b>	Command	<b><code>[:SENSe:]RESistance:CONtactcheck &lt;1/0/ON/OFF&gt;</code></b>
	Query	<b><code>[:SENSe:]RESistance:CONtactcheck?</code></b>
	Response	<code>&lt;ON/OFF&gt;</code>

**Description** The setting will be that of Low-Power OFF. For the Low-Power ON setting, use:  
`[:SENSe:]RESistance:LP:CONtactcheck`  
`[:SENSe:]RESistance:LP:CONtactcheck?`

**Example** `RES:CONT ON`  
`RES:CONT?`  
`ON`

**Note** Contact check cannot be ON when the multiplexer measurement method is the 2-wire type. An execution error occurs.

**Set and Query Low-Power Resistance Measurement Contact Check**

<b>Syntax</b>	Command	<b><code>[:SENSe:]RESistance:LP:CONtactcheck &lt;1/0/ON/OFF&gt;</code></b>
	Query	<b><code>[:SENSe:]RESistance:LP:CONtactcheck?</code></b>
	Response	<code>&lt;ON/OFF&gt;</code>

**Description** The setting will be that of Low-Power ON. For the Low-Power OFF setting, use:  
`[:SENSe:]RESistance:CONtactcheck`  
`[:SENSe:]RESistance:CONtactcheck?`

**Example** `RES:LP:CONT ON`  
`RES:LP:CONT?`  
`ON`

**(29) Setting Number of Digits**

RM3545 RM3545A RM3546 If executed while the Scan measurement is in progress, Err032 occurs.

**Set and Query Measurement Value's Number of Digits**

<b>Syntax</b>	Command	<b><code>[:SENSe:]RESistance:DIgIts &lt;Number of digits&gt;</code></b>
	Query	<b><code>[:SENSe:]RESistance:DIgIts?</code></b>
	Response	<code>&lt;Number of digits&gt;</code>

**Example** RM3544 `<Number of digits> = 4/5 (NR1)`  
RM3545 RM3545A RM3546 `<Number of digits> = 5/6/7 (NR1)`  
`:RES:DIg 5`  
`:RES:DIg?`  
`5`

**Note** When Low-Power is ON, six (6) digits will actually be displayed even when the number of digits is set to seven (7).

**(30) Temperature Measurement (Analog Input)** RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

**Select and Query Temperature Sensor**


---

**Syntax** Command **[:SENSe:]TEMPerature:SENSor <THERmistor/ANALog>**  
 Query **[:SENSe:]TEMPerature:SENSor?**  
 Response **<THERMISTOR/ANALOG>**  
 <THERMISTOR> = Z2001 temperature sensor is used as the temperature sensor.  
 <ANALOG> = Analog output thermometer is used as the temperature sensor.

**Example** TEMP:SENS ANAL  
 TEMP:SENS?  
 ANALOG

**Set and Query Analog Input Parameters**


---

**Syntax** Command **[:SENSe:]TEMPerature:PARAmeter  
<V1>,<T1>,<V2>,<T2>**  
 Query **[:SENSe:]TEMPerature:PARAmeter?**  
 Response **<V1>,<T1>,<V2>,<T2>**  
 <V1> = 0 to 2.00 (NR2).....Reference voltage 1 [V]  
 <T1> = -99.9 to 999.9 (NR2).....Reference temperature 1 [°C]  
 <V2> = 0 to 2.00 (NR2).....Reference voltage 2 [V]  
 <T2> = -99.9 to 999.9 (NR2).....Reference temperature 2 [°C]

**Example** TEMP:PAR 0,-10,2,100  
 TEMP:PAR?  
 0.00,0.00,1.00,100.0  
 0°C is displayed with 0 V, and 100°C is displayed with 1 V.

### (31) Triggering


Relationship between Trigger Source and Continuous Measurement Operation

Operation depends on the continuous measurement setting (`:INITIATE:CONTINUOUS`) (p.65) and the trigger source setting (`:TRIGGER:SOURCE`) (p.65) as follows.

See: "4 Data Exporting Methods" (p.80)

Also see "4 Multiplexer Commands (p.76)" for the multiplexer unit.

- `RM3544`, `RM3545`, `RM3545A` and `RM3546` When the front measurement terminal is used or the scanning function is set to OFF (`:SENSE:SCAN:MODE OFF`)



- RM3545 RM3545A RM3546 When the scanning function is set to AUTO (:SENSE:SCAN:MODE AUTO)

Measurement flow		Continuous Measurement Command-Specific Settings	
		:INITIATE:CONTINUOUS ON	:INITIATE:CONTINUOUS OFF
Trigger Source	:TRIGGER:SOURCE IMM		<p>Triggered by :INITIATE (or :READ?) command.</p> <pre> graph TD     A[Idle State] -- ":INITIATE:IMMEDIATE or :READ?" --&gt; B[Channel 1 measurement]     B --&gt; C[Channel 2 measurement]     C --&gt; D[...]     D --&gt; E[Channel n measurement]     E --&gt; A         </pre>
	:TRIGGER:SOURCE EXT	<p>Triggered by TRIG signal, [ENTER] key, or *TRG command. After measurement, enters the Trigger Wait State.</p> <pre> graph TD     A[Trigger Wait State] -- "TRIG signal, [ENTER] key, or *TRG" --&gt; B[Channel 1 measurement]     B --&gt; C[Channel 2 measurement]     C --&gt; D[...]     D --&gt; E[Channel n measurement]     E --&gt; A         </pre>	<p>Issue :INITIATE (or :READ?) command to enter the Trigger Wait State. Triggered by TRIG signal.</p> <pre> graph TD     A[Idle State] -- ":INITIATE:IMMEDIATE or :READ?" --&gt; B[Trigger Wait State]     B -- "TRIG signal" --&gt; C[Channel 1 measurement]     C --&gt; D[Channel 2 measurement]     D --&gt; E[...]     E --&gt; F[Channel n measurement]     F --&gt; A         </pre>

- RM3545 RM3545A RM3546 When the scanning function is set to STEP (:SENSE:SCAN:MODE STEP)

Measurement flow		Continuous Measurement Command-Specific Settings	
		:INITIATE:CONTINUOUS ON	:INITIATE:CONTINUOUS OFF
Trigger Source	:TRIGGER:SOURCE IMM		<p>Triggered by :INITIATE (or :READ?) command.</p>
	:TRIGGER:SOURCE EXT	<p>Triggered by TRIG signal, [ENTER] key, or *TRG command. After measurement, enters the Trigger Wait State.</p>	<p>Issue :INITIATE (or :READ?) command to enter the Trigger Wait State. Triggered by TRIG signal.</p>

The :INITIATE:CONTINUOUS OFF is can only be set by Remote command.

If this has been set to OFF, when operation is returned to the Local state or power is turned off, the :INITIATE:CONTINUOUS ON state occurs when power is turned back on.

See "Return to Local Control" (p.70) or Exporting measured values: "Data Exporting Methods" (p.80)

## Set and Query Continuous Measurement

---

**Syntax** Command **:INITiate:CONTInuous** <1/0/ON/OFF>  
 Query **:INITiate:CONTInuous?**  
 Response <ON/OFF>  
 <ON> = Continuous Measurement Enabled  
 <OFF> = Continuous Measurement Disabled

**Description**

- Continuous Measurement Enabled:  
After measurement, enters the Trigger Wait State. When there is an internal trigger (trigger source <IMMEDIATE>), the next trigger is promptly generated and enters a free run state.
- Continuous Measurement Disabled:  
After measurement, enters the Idle State instead of the Trigger Wait State.
- Triggering is ignored in the Idle State. Executing :INITiate[:IMMediate] enables the Trigger Wait State.
- Continuous measurement is enabled upon exiting from the Remote State.

**Example** :INIT:CONT OFF  
 :INIT:CONT?  
 ON

**Note** RM3545 RM3545A RM3546  
 If executed while the Scan measurement is in progress, Err032 occurs.

## Set Trigger Wait

---

**Syntax** Command **:INITiate[:IMMediate]**

**Description** Switches triggering from the Idle State to the Trigger Wait State.

**Example** Disable continuous measurement, and read one value for each trigger event.  
 Sending  
**:TRIG:SOUR IMM** ..... Trigger immediately when entering Trigger Wait State.  
**:INIT:CONT OFF** ..... Disables continuous measurement.  
**:INIT** ..... Enable Trigger Wait. Trigger immediately upon :TRIG:SOUR IMM.

**Note**

- When this message is received, automatically switches to **:INITiate:CONTInuous OFF**.
- When there is an internal trigger (trigger source <IMMEDIATE>), triggering promptly occurs and enters the idle state.
- When there is an external trigger (trigger source <EXTERNAL>), the external trigger wait state is entered. When a trigger is received, a single measurement is performed and enters the idle state.

## Set and Query Trigger Source

---

**Syntax** Command **:TRIGger:SOURce** <IMMediate/EXTernal>  
 Query **:TRIGger:SOURce?**  
 Response <IMMEDIATE/EXTERNAL>  
 <IMMEDIATE> = Internal triggering  
 <EXTERNAL> = External triggering

**Example** :TRIG:SOUR IMM  
 :TRIG:SOUR?  
 IMMEDIATE

**Note** RM3545 RM3545A RM3546  
 If executed while the Scan measurement is in progress, Err032 occurs.

### Set and Query Trigger Signal Logic

---

**Syntax** Command **:TRIGger:EDGE** <1/0/ON/OFF>  
 Query **:TRIGger:EDGE?**  
 Response <ON/OFF>  
 <ON> = ON edge (OFF→ON)  
 <OFF> = OFF edge (ON→OFF)

**Example** :TRIG:EDGE ON  
 :TRIG:EDGE?  
 ON

**Note** RM3545 RM3545A RM3546 An execution error occurs during scanning.

### (32) Delay RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

### Set and Query Delay

---

**Syntax** Command **:TRIGger:DELAy** <Delay time>  
 Query **:TRIGger:DELAy?**  
 Response <Delay time>  
 <Delay time> = 0 to 9.999 (NR2) [sec]

**Example** :TRIG:DEL 0.01  
 :TRIG:DEL?  
 0.010

**Note** When the delay is at the default setting (:TRIGger:DELAy:AUTO ON), setting values are invalid (disabled). When setting the delay, be sure to turn the default setting OFF.

### Set and Query Preset Delay

---

**Syntax** Command **:TRIGger:DELAy:AUTO** <1/0/ON/OFF>  
 Query **:TRIGger:DELAy:AUTO?**  
 Response <ON/OFF>

**Setting** When the auto delay (preset setting) is set to ON, the delay will be the value specified internally.  
 When set to OFF, the set delay value (:TRIGger:DELAy <delay time>) will govern.

**Example** :TRIG:DEL:AUTO ON  
 :TRIG:DEL:AUTO?  
 ON

### (33) Self-Calibration RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

### Execute Self-Calibration

---

**Syntax** Command **:SYSTem:CALibration**

**Note** If this command is received while measuring, self-calibration executes after the measurement is finished.

## Execute and Set Self-Calibration

---

**Syntax** Command **:SYSTem:CALibration:AUTO** <1/0/ON/OFF>  
 Query **:SYSTem:CALibration:AUTO?**  
 Response <ON/OFF>  
 <ON> = AUTO Self-Calibration selected  
 <OFF> = MANUAL Self-Calibration selected

**Example** :SYST:CAL:AUTO OFF  
 :SYST:CAL:AUTO?  
 OFF

## (34) Saving and Reading Measurement Conditions

RM3545 RM3545A RM3546 If executed while the Scan measurement is in progress, Err032 occurs.

### Save and Read Measurement Conditions

---

**Syntax** Command **:SYSTEM:PANel:SAVE** <Table No>  
**:SYSTEM:PANel:LOAD** <Table No>,<Zero adjustment load>  
RM3544 <Table No> = 1 to 10 (NR1)  
RM3545 RM3545A RM3546  
 <Table No> = 1 to 30 (NR1) (When the front terminal is used as a  
 measurement terminal.)/31 to 38 (NR1)  
 (When the multiplexer is used as a measurement terminal.)  
 <Zero adjustment load> = 1/0/ON/OFF  
 <ON> = Zero adjustment value is also read during panel loading.  
 <OFF> = Zero adjustment is not read during panel loading.

**Example** :SYST:PAN:SAVE 10  
 :SYST:PAN:LOAD 5,OFF

**Note** When the measurement conditions for the Table No. have already been saved and **:SYSTEM:PANel:SAVE** is executed, the measurement conditions will be overwritten.  
 When the Table No. that does not have the measurement conditions is specified and **:SYSTEM: PANel:LOAD** is executed., an execution error will occur.  
RM3545 RM3545A RM3546 When the front terminal is used as a measurement terminal, the measurement conditions cannot be saved to 31 to 38. When the multiplexer is used, the measurement conditions cannot be saved to 1 to 30. When a test lead is connected to the front measurement terminal, cannot be read to 31 to 38. An execution error occurs in either case.

### Set and Query Panel Name

---

**Syntax** Command **:SYSTEM:PANel:NAME** <Table No>,<Panel name (character string data: maximum 10 characters)>  
 Query **:SYSTEM:PANel:NAME?** <Table No>  
 Response <Table No>,<Panel name (character string data: maximum 10 characters)>  
RM3544 <Table No> = 1 to 10 (NR1)  
RM3545 RM3545A RM3546 <Table No> = 1 to 38 (NR1)  
 For information on character string data, see Data Formats. (p.4)

**Example** :SYST:PAN:NAME 1,"PANEL\_1"  
 :SYST:PAN:NAME? 1  
 1,"PANEL\_1"

## Clear Panel

---

**Syntax** Command **:SYSTem:Panel:CLEar** <Table No>  
 RM3544 <Table No> = 1 to 10 (NR1)  
 RM3545 RM3545A RM3546 <Table No> = 1 to 38 (NR1)

**Example** :SYST:PAN:CLE 10

## (35) Absolute Value Display

### Set and Query Absolute Value Display

---

**Syntax** Command **:SYSTem:ABSolute** <1/0/ON/OFF>  
 Query **:SYSTem:ABSolute?**  
 Response <ON/OFF>

**Example** :SYST:ABS ON  
 :SYST:ABS?  
 ON

## (36) Key-Lock

RM3545 RM3545A RM3546 If executed while the Scan measurement is in progress, Err032 occurs.

### Set and Query Key-Lock State

---

**Syntax** Command **:SYSTem:KLOCK** <1/0/ON/OFF>  
 Query **:SYSTem:KLOCK?**  
 Response <ON/MENU/OFF>

**Description** Switches to FULL key-lock state. (Prohibits all setting changes by key operation.)  
 MENU is returned during MENU key-lock state. the scanning and the measuring.

**Example** :SYST:KLOC ON  
 :SYST:KLOCK?  
 ON

## (37) Line Frequency

RM3545 RM3545A RM3546 If executed while the Scan measurement is in progress, Err032 occurs.

### Set and Query Line Frequency

---

**Syntax** Command **:SYSTem:LFRequency** <AUTO/50/60>  
 Query **:SYSTem:LFRequency?**  
 Response <AUTO/50/60>

**Example** :SYST:LFR 50  
 :SYST:LFR?  
 50

**(38) Clock** RM3545 RM3545A RM3546

If executed while the Scan measurement is in progress, Err032 occurs.

**Set and Query System Date**


---

**Syntax** Command    :**SYSTem:DATE** <Year>,<Month>,<Day>  
 Query            :**SYSTem:DATE?**  
 Response        <Year>,<Month>,<Day>  
                   <Year> = 00 to 99 (NR1)  
                   <Month> = 01 to 12 (NR1)  
                   <Day> = 01 to 31 (NR1)

**Description** Sets and queries the date of the real-time system clock.

**Example**    :**SYST:DATE 13,01,10**  
 Sets the date to January 10, 2013.  
               :**SYST:DATE?**  
               **13,12,10**

The date is December 10, 2013.  
**Note**        Attempting to set an out-of-range numerical value returns an execution error.  
 Attempting to set a non-existent date (such as 13,06,31) returns an execution error.

**Set and Query System Time**


---

**Syntax** Command    :**SYSTem:TIME** <Hour>,<Minute>,<Second>  
 Query            :**SYSTem:TIME?**  
 Response        <Hour>,<Minute>,<Second>  
                   <Hour> = 00 to 23 (NR1)  
                   <Minute> = 00 to 59 (NR1)  
                   <Second> = 00 to 59 (NR1)

**Description** Sets the time of the real-time system clock.

**Example**    :**SYST:TIME 08,25,00**  
 Sets the time to 8:25 and 00 seconds.  
               :**SYST:TIME?**  
               **23,09,53**

The time is 23:09 and 53 seconds.  
**Note**        Attempting to set an out-of-range numerical value returns an execution error.  
 Attempting to set a non-existent time (such as 09,06,71) returns an execution error.

**(39) Key Beeper**

RM3545 RM3545A RM3546 If executed while the Scan measurement is in progress, Err032 occurs.

**Set and Query Key Beeper**


---

**Syntax** Command    :**SYSTem:BEEPer:STATe** <1/0/ON/OFF>  
 Query            :**SYSTem:BEEPer:STATe?**  
 Response        <ON/OFF>

**Example**    :**SYST:BEEP:STAT ON**  
               :**SYST:BEEP:STAT?**  
               **ON**

**(40) Communications Settings**

**RM3545** **RM3545A** **RM3546** If executed while the Scan measurement is in progress, Err032 occurs.

**Return to Local Control**


---

<b>Syntax</b>	Command	<b>:SYSTem:LOCal</b>
<b>Description</b>	Disables communications remote control and re-enables local control. The panel keys are re-enabled.	
<b>Example</b>	<b>:SYST:LOC</b>	

**Set and Query Measurement-Synchronized Data Output [RS-232C/USB/LAN]**


---

<b>Syntax</b>	Command	<b>:SYSTem:DATAout &lt;1/0/ON/OFF&gt;</b>
	Query	<b>:SYSTem:DATAout?</b>
	Response	<b>&lt;ON/OFF&gt;</b>
<b>Description</b>	<p>&lt;ON&gt; = With an external trigger (trigger source &lt;EXTERNAL&gt;), measurement values are automatically sent when trigger measurements are completed. When there is an internal trigger (trigger source &lt;IMMEDIATE&gt;), measurement values are automatically sent when the [ENTER] key is pressed and TRIG signal have been input.</p> <p>&lt;OFF&gt; = Measured values are not automatically sent.</p>	
<b>Note</b>	This command is not applicable to the GP-IB Interface.	

**Set and Query Header Presence**


---

<b>Syntax</b>	Command	<b>:SYSTem:HEADer &lt;1/0/ON/OFF&gt;</b>
	Query	<b>:SYSTem:HEADer?</b>
	Response	<b>&lt;ON/OFF&gt;</b>
<b>Example</b>	<b>:SYST:HEAD ON</b> <b>:SYST:HEAD?</b> <b>:SYSTEM:HEADER ON</b> <b>:SYST:HEAD OFF</b> <b>:SYST:HEAD?</b> <b>OFF</b>	

**Note** When turning the power on or after the \*RST command, this is initialized to OFF (no header).

**Set and Query Delimiter**


---

<b>Syntax</b>	Command	<b>:SYSTem:TERMinator &lt;0/1&gt;</b>
	Query	<b>:SYSTem:TERMinator?</b>
	Response	<b>&lt;0/1&gt;</b>
	<p>&lt;0&gt; = LF+EOI          &lt;1&gt; = CR, LF+EOI</p>	
<b>Example</b>	<b>:SYST:TERM 1</b> <b>:SYST:TERM?</b> <b>0</b>	

**Note**

- At power-on, this is set to 0 (LF+EOI).
- The RS-232C/USB/LAN delimiter is fixed as CR+LF.

---

## Set and Query Communication interface

---

**Syntax** Command :**SYSTem:COMMunicate** <USB/LAN/RS232c/PRINter>  
 Query :**SYSTem:COMMunicate?**  
 Response <USB/LAN/RS232C/PRINTER>  
 <USB> = USB  
 <LAN> = LAN RM3545A RM3546  
 <RS232c> = RS232C  
 <PRINter> = PRINTER(RS232C)

**Description** Configure and inquire about communication interfaces  
**Example** :**SYST:COMM** USB  
 :**SYST:COMM?**  
 USB

**Note** Changes the interface upon receiving a command.  
 (Communication during command will be disconnected)

---

## Set and Query Command Monitor

---

**Syntax** Command :**SYSTem:COMMunicate:MONitor** <1/0/ON/OFF>  
 Query :**SYSTem:COMMunicate:MONitor?**  
 Response <ON/ OFF>  
 <1/ON> = display ON  
 <0/OFF> =display OFF

**Description** Configure the command monitor.  
**Note**

---

## Set and Query IP Address RM3545A RM3546

---

**Syntax** Command :**SYSTem:COMMunicate:LAN:IPADdress** <IP address>  
 Query :**SYSTem:COMMunicate:LAN:IPADdress?**  
 Response <IP address>  
 <IP address> = nnn,nnn,nnn,nnn

**Description** Sets and queries the LAN IP address.  
**Example** :**SYST:COMM:LAN:IPAD** 192,168,1,2  
 :**SYST:COMM:LAN:UPD**  
 :**SYST:COMM:LAN:IPAD?**  
 192,168,1,2

**Note** Updates are reflected when you run ":**SYSTem:COMMunicate:LAN:UPDate**"  
 Parameter separator is ",". Please do not separate with "."

---

## Set and Query LAN sub-net mask RM3545A RM3546

---

**Syntax** Command :**SYSTem:COMMunicate:LAN:SMASK** <subnet mask>  
 Query :**SYSTem:COMMunicate:LAN:SMASK?**  
 Response <subnet mask>  
 <subnet mask> = nnn,nnn,nnn,nnn

**Description** Sets and queries the LAN subnet mask.  
**Example** :**SYST:COMM:LAN:SMAS** 255,255,0,0  
 :**SYST:COMM:LAN:UPD**  
 :**SYST:COMM:LAN:SMAS?**  
 255,255,0,0

**Note** Updates are reflected when you run ":**SYSTem:COMMunicate:LAN:UPDate**"  
 Parameter separator is ",". Please do not separate with "."

**Set and Query LAN gateway** RM3545A RM3546

**Syntax** Command **:SYSTem:COMMunicate:LAN:GATeway** <gateway>  
 Query **:SYSTem:COMMunicate:LAN:GATeway?**  
 Response <gateway>  
 <gateway> = nnn,nnn,nnn,nnn

**Description** Sets and queries the LAN gateway.  
**Example** :SYST:COMM:LAN:GAT 192,168,1,1  
 :SYST:COMM:LAN:UPD  
 :SYST:COMM:LAN:GAT?  
 192,168,1,1

**Note** Updates are reflected when you run ":SYSTem:COMMunicate:LAN:UPDate"  
 Parameter separator is ",". Please do not separate with "."

**Set and Query LAN port** RM3545A RM3546

**Syntax** Command **:SYSTem:COMMunicate:LAN:CONTRol** <port NO.>  
 Query **:SYSTem:COMMunicate:LAN:CONTRol?**  
 Response <port NO.>  
 <port No.> = 11~65535(80 is excluded)

**Description** Sets and queries the LAN port number.  
**Example** :SYST:COMM:LAN:CONT 3545  
 :SYST:COMM:LAN:UPD  
 :SYST:COMM:LAN:CONT?  
 3545

**Note** Updates are reflected when you run ":SYSTem:COMMunicate:LAN:UPDate"

**Query MAC address** RM3545A RM3546

**Syntax** Query **:SYSTem:COMMunicate:LAN:MAC?**  
 Response <MAC address>

**Description** It will respond with the LAN MAC address as a hexadecimal string separated by hyphens.  
**Example** :SYST:COMM:LAN:MAC?  
 "00-01-67-07-03-85"

**Update LAN settings** RM3545A RM3546

**Syntax** Command **:SYSTem:COMMunicate:LAN:UPDate**  
**Description** If you change the LAN IP address, subnet mask, gateway, or port using a command, it will be reflected using this command.  
**Note** If communicating via LAN, the connection will be disconnected.

**Set and Query RS-232C Communication speed** RM3545A RM3546

**Syntax** Command **:SYSTem:COMMunicate:RS232C:SPEED** <baud rate>  
 Query **:SYSTem:COMMunicate:RS232C:SPEED?**  
 Response <baud rate>  
 <baud rate> = 9600/19200/38400/115200 (NR1)

**Description** Change and inquire about RS-232C communication speed.  
**Example** :SYST:COMM:RS232C 9600  
 :SYST:COMM:RS232C:SPEED?  
 9600

**(41) System Reset**

**RM3545** **RM3545A** **RM3546** If executed while the Scan measurement is in progress, Err032 occurs.

**Execute System Reset**

**Syntax** Command **:SYSTem:RESet**

**Description** Initializes all except communications and clock settings. After initialization, panel data, too, is initialized.

**(42) EXT I/O**

**RM3545** **RM3545A** **RM3546** If executed while the Scan measurement is in progress, Err032 occurs.

**Query NPN/PNP Switch Status**

**Syntax** Query **:IO:MODE?**  
Response **<NPN/PNP>**

**Example** **:IO:MODE?**  
**NPN**

**External I/O Input**

**Syntax** Query **:IO:INPut?**  
Response **0 to 3 (NR1)**

**Description** Reads the ON edge of TRIG of the EXT I/O and the PRINT terminal, and then clears them. (If the trigger signal edge has the OFF edge setting, the TRIG terminal reads the OFF edge.)  
When the edge is detected, the bits are set. When reading is performed through this query, it is cleared to 0. Also, input by key is also detected in the same manner as signals.

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
	-	-	-	-	-	-	PRINT	TRIG
Pin No.	-	-	-	-	-	-	26	1

See the instrument instruction manual regarding external control (EXT I/O) as well.

**Note** While the filter setting of the input signal is ON, the edge after the set filter time will be read.

**External I/O Output**

**Syntax** Command **:IO:OUTPut <Output data 0 to 7>**

**Description** When the judgment output mode is selected with the EXT I/O output mode, any 3-bit data can be output from the EXT I/O terminal.

	bit7	bit6	bit5	bit4	bit3	bit2	bit1	bit0
	-	-	-	-	-	OUT2	OUT1	OUT0
Pin No.	-	-	-	-	-	19	37	18

See the instrument instruction manual regarding external control (EXT I/O) as well.

**Execute and Query TRIG/PRINT Signal's Filter Function**

**Syntax** Command **:IO:FILTER:STATE <1/0/ON/OFF>**  
Query **:IO:FILTER:STATE?**  
Response **<ON/OFF>**

**Example** **:IO:FILT:STAT ON**  
**:IO:FILT:STAT?**  
**ON**

### Set and Query TRIG/PRINT Signal's Filter Time

---

**Syntax** Command **:IO:FILTer:TIME** <Filter time>  
 Query **:IO:FILTer:TIME?**  
 Response <Filter time>  
 <Filter time> = 0.05 to 0.50 (NR2) [sec]

**Example** **:IO:FILT:TIME 0.1**  
**:IO:FILT:TIME?**  
**0.10**

### Set and Query Judgment Mode/BCD Mode

---

**Syntax** Command **:IO:JUDGe:MODE** <JUDge/BCD>  
 Query **:IO:JUDGe:MODE?**  
 Response <JUDGE/BCD>  
 <JUDGE> = Judgment mode  
 <BCD> = BCD mode

**Example** **:IO:JUDG:MODE BCD**  
**:IO:JUDG:MODE?**  
**BCD**

### Set and Query EOM Output Method

---

**Syntax** Command **:IO:EOM:MODE** <HOLD/PULSe>  
 Query **:IO:EOM:MODE?**  
 Response <HOLD/ PULSE>  
 <HOLD> = Holds the EOM signal until measurement starts by the next trigger signal.  
 <PULSE> = Sets EOM=OFF according to the specified pulse width.

**Example** **:IO:EOM:MODE PULS**  
**:IO:EOM:MODE?**  
**PULSE**

### Set and Query EOM Pulse Width

---

**Syntax** Command **:IO:EOM:PULSe** <Pulse width>  
 Query **:IO:EOM:PULSe?**  
 Response <Pulse width (NR2)>  
 <Pulse width> = 0.001 to 0.100 (NR2) [sec]

**Example** **:IO:EOM:PULS 0.005**  
**:IO:EOM:PULS?**  
**0.005**

### (43) Multiplexer Unit RM3545 RM3545A RM3546

- Also see 4 Multiplexer Commands (p.76)" for the multiplexer unit.  
 If executed while the Scan measurement is in progress, Err032 occurs.

### Query Unit

---

**Syntax** Query **:UNIT:IDN?** <Unit number>  
 <Unit number> = 1/2  
 Response <Model name>,<Serial number>  
 If the unit is not inserted: <Model name> = NONE

**Example** **:UNIT:IDN? 1**  
**Z3003,123456789**

## Query Relay Usage Count

**Syntax** Query **:UNIT:SCOut?** <Unit number>  
 <Unit number> = 1/2  
 Response <Relay count (NR1)>

**Description** Responds with the count of the relay with the highest usage count of all the relays for each unit.  
 -1 is returned if the unit is not inserted and an execution error occurs.

**Example** :UNIT:SCO? 1  
 10000

## Query Multiplexer Unit Test Execution and Result

**Syntax** Query **:UNIT:TEST?** <Unit number>  
 <Unit number> = 1/2  
 Response <0 to 8 (NR1)>

128	64	32	16	8	4	2	1
bit7	bit6	bit5	bit7	bit3	bit2	bit1	bit0
Unused	Unused	Unused	Unused	NO UNIT	Blown FUSE	FRONT ERR	UNIT ERR

**Description** Performs a multiplexer test and responds with the result in NR1 number (0 to 4).  
 0 is returned if there is no error.  
 UNIT ERR(1)  
 Multiplexer short circuit resistance check error  
 FRONT ERR(2)  
 When a test lead is connected to the front measurement terminal. Remove the test lead and execute the test again.  
 Blown FUSE (4)  
 The fuse on the back of the instrument for measurement terminal protection has been blown. Replace the fuse and execute the test again.  
 NO UNIT(8)  
 The unit is not inserted. Insert the unit and execute the test again.  
 For information on unit test, see the instrument instruction manual.

**Example** :UNIT:TEST? 1  
 0

**Note** [RM3545](#) [RM3545A](#) [RM3546](#)  
 If executed while the Scan measurement is in progress, Err032 occurs.

## 4 Multiplexer Commands

RM3545

RM3545A

RM3546

### Multiplexer Settings

There are two types of multiplexer commands, commands for individual channels and those common to all channels. The commands for individual channels are applied to the current channel. When specifying a channel, it is necessary to switch the channel in advance.

Check Message List to see the type of each command.

For example, `[[:SENSe:]RESistance:RANGe]` is a command for individual channels and `[[:SENSe:]RESistance:DIGits]` is a command common to all channels. An example of command communication is shown below.

<code>CH?</code>	
<code>5</code>	The current channel number is 5.
<code>RES:RANG?</code>	
<code>1</code>	The resistance range of Channel 5 is 1Ω.
<code>RES:DIG?</code>	
<code>7</code>	The number of digits is 7 and this is common to all channels.
<code>CH 3</code>	Switches the channel number to 3.
<code>RES:RANG 10</code>	Switches the resistance range of Channel 3 to 10Ω.
<code>RES:DIG 6</code>	The number of digits is 6 and this is common to all channels.

The state after command execution is as follows.

- Current channel: 3
- State of each channel

Channel	Measurement range	Number of digits
3	10Ω range	6
5	1Ω range	

Example A1: Setting all channels in a batch

<code>CH:STAT ON,1</code>	Channel 1 is used.
<code>CH:STAT ON,2</code>	Channel 2 is used.
<code>CH:STAT ON,3</code>	Channel 3 is used.
<code>CH 1</code>	Channel 1 settings
<code>TERM 1,1,2</code>	Measures between Unit 1 TERM 1 and TERM 2.
<code>RES:RANG 10E-03</code>	Sets the range.
<code>:CALC:LIM:STAT ON</code>	Sets the comparator.
<code>:CALC:LIM:UPP 10E-03</code>	
<code>:CALC:LIM:LOW 1E-03</code>	
<code>:CALC:LIM:JUDG:COND IN</code>	
<code>CH 2</code>	Channel 2 settings
<code>TERM 1,3,4</code>	Measures between Unit 1 TERM 3 and TERM 4
<code>RES:RANG 10E-03</code>	Sets the range.
<code>:CALC:LIM:STAT ON</code>	Sets the comparator.
<code>:CALC:LIM:UPP 8E-03</code>	
<code>:CALC:LIM:LOW 3E-03</code>	
<code>:CALC:LIM:JUDG:COND IN</code>	

Example A2: Performing a measurement while switching the terminal

:INIT:CONT ON	Continuous measurement ON
:TRIG:SOUR IMM	Internal trigger
SCAN:MODE OFF	Scan OFF
CH:STAT ON,1	Channel 1 is used.
CH 1	Channel 1 settings
TERM 1,1,2	Measures between Unit 1 TERM 1 and TERM 2.
:FETC?	
10.00000E+00	
TERM 1,3,4	Measures between Unit 1 TERM 3 and TERM 4.
:FETC?	
20.00000E+00	
TERM 1,5,6	Measures between Unit 1 TERM 5 and TERM 6.
:FETC?	
30.00000E+00	

## Multiplexer Measurement

Using a multiplexer, a measurement can be performed in various ways when the scanning function, trigger source, and continuous measurement are combined.

See: Triggering (p.62), "4 Data Exporting Methods" (p.80)

- (1) Performing a measurement while the channel is switched by a command without using the scanning function

Example B1-1 Activating the trigger using a command with continuous measurement OFF

SCAN:MODE OFF	Scan OFF
:TRIG:SOUR IMM	Internal trigger
:INIT:CONT OFF	Continuous measurement OFF
CH:STAT ON,1	Selects the channel to be used.
CH:STAT ON,2	
CH 1	Switches the channel.
:READ?	Reads the measured value.
1020.000E-03	
CH 2	Switches the channel.
:READ?	Reads the measured value.
100.000E-03	

- (2) Executing scanning using a command

Example B2-1 When the scanning function is set to AUTO (SCAN:MODE AUTO)

SCAN:MODE:AUTO	Scanning function: AUTO
:TRIG:SOUR IMM	Internal trigger (continuous measurement OFF)
CH:STAT ON,1	Selects the channel to be used.
CH:STAT ON,2	
:READ?	Executes scanning (all channels measured).
1020.000E-03, 100.000E-03	Reads the measured values of all channels.
:CALC:LIM:RES? 1	Obtains the comparator result of each channel.
HI	
:CALC:LIM:RES? 2	
IN	
:CALC:LIM:JUDG? 1	Obtains the PASS/FAIL result of each channel.
FAIL	
:CALC:LIM:JUDG? 2	
PASS	
:CALC:LIM:JUDG:TOT?	Obtains the total judgment result.
FAIL	
:READ? NDAT	Executes scanning (all channels measured).
FAIL	Reads the total judgment result.

<code>:READ? JUDG 1020.000E-03, 100.000E-03,FAIL</code>	Executes scanning (all channels measured). Reads the measured values of all channels and total judgment result.
---	--

Example B2-2 When the scanning function is set to STEP ([SCAN:MODE STEP](#))

<code>SCAN:MODE STEP</code>	Scanning function: STEP
<code>:TRIG:SOUR IMM</code>	Internal trigger (continuous measurement OFF)
<code>CH:STAT ON,1</code>	Selects the channel to be used.
<code>CH:STAT ON,2</code>	
<code>:READ? 1020.000E-03</code>	Measures Channel 1 and reads the measured value.
<code>:CALC:LIM:RES? HI</code>	Reads the comparator result of Channel 1.
<code>:CALC:LIM: JUDG? FAIL</code>	Reads the PASS/FAIL result of Channel 1.
<code>:READ? 100.000E-03</code>	Measures Channel 2 and reads the measured value.
<code>:CALC:LIM:RES? IN</code>	Reads the comparator result of Channel 2.
<code>:CALC:LIM:JUDG? PASS</code>	Reads the PASS/FAIL result of Channel 2.
<code>:CALC:LIM:JUDG:TOT? FAIL</code>	Obtains the total judgment result.
<code>SCAN:RES</code>	Clears the measured value and switches to Channel 1.

(3) Executing scanning using an external trigger

Example B3-1 When the scanning function is set to AUTO ([SCAN:MODE AUTO](#))

<code>SCAN:MODE:AUTO</code>	Scanning function: AUTO
<code>:TRIG:SOUR EXT</code>	External trigger
<code>CH:STAT ON,1</code>	Selects the channel to be used.
<code>CH:STAT ON,2</code>	
<code>:READ?</code>	Waits for a trigger (continuous measurement OFF).
(External trigger input)	
<code>1020.000E-03, 100.000E-03</code>	Reads the measured values of all channels.
<code>SCAN:MODE AUTO</code>	Scanning function: AUTO
<code>:TRIG:SOUR EXT</code>	External trigger
<code>:INIT:CONT ON</code>	Continuous measurement ON
<code>CH:STAT ON,1</code>	Selects the channel to be used.
<code>CH:STAT ON,2</code>	
<code>CH:STAT ON,3</code>	
(External trigger input)	Executes scanning.
<code>:FETC? 1</code>	Reads the measured values and judgment values of all channels.
<code>1020.000E-03</code>	
<code>:FETC? LIM,2</code>	
<code>100.000E-03,HI</code>	
<code>:FETC? JUDG,3</code>	
<code>100.000E-03,PASS</code>	Reads the measured values of all channels.
<code>:SCAN:DATA?</code>	
<code>1020.000E-03, 100.000E-03, 100.000E-03</code>	

Example B3-2 When the scanning function is set to STEP ([SCAN:MODE STEP](#))

<pre> SCAN:MODE STEP :TRIG:SOUR IMM CH:STAT ON,1 CH:STAT ON,2 :READ? (External trigger input) 1020.000E-03 :READ? (External trigger input) 100.000E-03 SCAN:RES </pre>	<p>Scanning function: STEP Internal trigger (continuous measurement OFF) Selects the channel to be used.</p> <p>Measures Channel 1.</p> <p>Reads the measured value of Channel 2.</p> <p>Measures Channel 2.</p> <p>Reads the measured value of Channel 2.</p> <p>Clears the measured value and switches to Channel 1.</p>
<pre> SCAN:MODE STEP :TRIG:SOUR EXT :INIT:CONT ON CH:STAT ON,1 CH:STAT ON,2 CH:STAT ON,3 (External trigger input) :FETC? 1020.000E-03 (External trigger input) :FETC? LIM 100.000E-03,HI (External trigger input) :FETC? JUDG 100.000E-03,PASS SCAN:RES </pre>	<p>Scanning function: STEP External trigger Continuous measurement ON Selects the channel to be used.</p> <p>Measures Channel 1.</p> <p>Reads the measured value of Channel 1.</p> <p>Measures Channel 2.</p> <p>Reads the measured value and comparator result of Channel 2.</p> <p>Measures Channel 3.</p> <p>Reads the measured value and PASS/FAIL result of Channel 3.</p> <p>Clears the measured value and switches to Channel 1.</p>
<pre> SCAN:MODE STEP :TRIG:SOUR EXT :INIT:CONT ON CH:STAT ON,1 CH:STAT ON,2 CH:STAT ON,3 (External trigger input) (External trigger input) (External trigger input) :FETC? 1 1020.000E-03 :FETC? LIM,2 100.000E-03,HI :FETC? JUDG,3 100.000E-03,PASS :SCAN:DATA? 1020.000E-03, 100.000E-03, 100.000E-03 SCAN:RES </pre>	<p>Scanning function: STEP External trigger Continuous measurement ON Selects the channel to be used.</p> <p>Measures Channel 1.</p> <p>Measures Channel 2.</p> <p>Measures Channel 3.</p> <p>Reads the measured values and judgment values of all channels.</p> <p>Reads the measured values of all channels.</p> <p>Clears the measured value and switches to Channel 1.</p>

## 5 Data Exporting Methods

### Basic Data Exporting Methods

Flexible data exporting is available depending on the application.

#### Export Free-Run Data

---

Default Setting	<b>:INITiate:CONTInuous ON</b> (continuous measurement enable) <b>:TRIGger:SOURce IMMEDIATE</b> (internal triggering)
Exporting	<b>:FETCh?</b> Imports the most recent measurement. <b>RM3545</b> <b>RM3545A</b> <b>RM3546</b> When the scanning function is set to AUTO or STEP, free-run data cannot be exported.

#### Export by Controller (PC, PLC) Triggering

---


Default Setting	<b>:INITiate:CONTInuous OFF</b> (continuous measurement disable) <b>:TRIGger:SOURce IMMEDIATE</b> (internal triggering)
Exporting	<b>:READ?</b> A trigger occurs, and a measurement is performed and the result is transferred. <b>RM3545</b> <b>RM3545A</b> <b>RM3546</b> When the scanning function is set to AUTO or STEP, scanning begins when :READ? is received (a trigger is not required separately).
Note	When :READ? is sent, <b>:INITiate:CONTInuous OFF</b> automatically occurs.

#### Export by Pressing [ENTER] Key or Applying TRIG Signal

---


Default Setting	<b>:INITiate:CONTInuous OFF</b> (continuous measurement disable) <b>:TRIGger:SOURce EXT</b> (external triggering)
Exporting	<b>:READ?</b> When triggered by the [ENTER] Key or TRIG signal, a measurement is performed and the result is transferred.
Note	When :READ? is sent, <b>:INITiate:CONTInuous OFF</b> automatically occurs.

## Using the :FETCh? Command during Continuous Measurement with Internal Triggering



This is the simplest method for exporting measured values. It is ideal when measurement (tact) time is not limited, and when external synchronization is not needed. After connecting to the measurement target, wait for twice the measurement time before exporting the measured value.


## Using the :READ? Command while Continuous Measurement is Disabled



Use this method to measure (and export) synchronously with the controller (PC, PLC) or external trigger signal. Measurement time can be minimized.


Using the **:FETCh?** Command when the Scanning Function is Set to AUTO or STEP [RM3545](#) [RM3545A](#)  
[RM3546](#)

When the scanning function is set to AUTO or STEP, the measured value of any channel is obtained with the **:FETCh?** command after scanning.



Using the **SCAN:DATA?** Command when the Scanning Function is Set to AUTO or STEP [RM3545](#)  
[RM3545A](#) [RM3546](#)

When the scanning function is set to AUTO or STEP, the measured values of all channels are obtained with the **SCAN:DATA?** command after scanning.



## 6 Examples of communication commands

This section introduces the communication commands used when controlling the instrument using the communication function.

When sending a command, it is necessary to add a message terminator (CR+LF, etc.), but this notation is omitted in this explanation. Similarly, the terminator (CR+LF) added to the response is also omitted.

You can also download sample programs compatible with various programming languages from our website. Please refer to this when creating communication programs for measuring instruments. Please search for [Sample program for communication with HIOKI products](#) on an internet search site.

### Confirmation before measurement

This is an example of checking the status of the device and acquiring information about the device before measurement.

	Content	Send from controller to instrument	Example of response of this device
1	Communication confirmation	*IDN?	HIOKI, RM3545A-2, 230822756, V1.00
2	Check date	:SYST:DATE?	23,10,1
3	Check the time	:SYST:TIME?	12,34,56
4	Self-test confirmation	*TST?	0

### Setting measurement conditions

Set measurement conditions.

- Range: 1000mΩ
- Sampling: FAST
- Trigger: EXTERNAL
- Comparator: ON, ABS mode, Upper limit 1000mΩ, lower limit 500mΩ, Sound the buzzer on Hi and Lo

	Content	Send from controller to instrument	Example of response of this device
1	Set measurement range to 1000mΩ	:RES:RANG 1E+0	
2	Set sampling to FAST	:SAMP:RATE FAST	
3	Select external trigger	:TRIG:SOUR EXT	
4	Continuous measurement ON	:INIT:CONT ON	
5	Comparator ABS mode	:CALC:LIM:MODE ABS	
6	IN buzzer OFF	:CALC:LIM:BEEP IN,0,0	
7	Hi buzzer type 1 continuous	:CALC:LIM:BEEP HI,1,0	
8	Lo buzzer type 1 continuous	:CALC:LIM:BEEP LO,1,0	
9	Upper limit value 1Ω	:CALC:LIM:UPP 1E+0	
10	Lower limit value 0.5Ω	:CALC:LIM:LOW 0.5E+0	
11	Comparator ON	:CALC:LIM:STAT ON	

### Simple resistance measurement

Capture 10 measurements and save as a text file.

	Content	Send from controller to instrument	Example of response of this device
1	Select internal trigger	:TRIG:SOUR IMM	
2	Continuous measurement ON	:INIT:CONT ON	
3	Get the latest measurements	:FETCH?	(measured value)
4	Save (measured value) to text file		
5	Repeat steps 3 and 4 10 times		

### Resistance measurement using computer keys

Measure and import data using computer keystrokes and save as a text file.

	Content	Send from controller to instrument	Example of response of this device
1	Select internal trigger	:TRIG:SOUR IMM	
2	Continuous measurement OFF	:INIT:CONT OFF	
3	(Waiting for computer key input)		
4	Get measured value after measurement	:READ?	(measured value)
5	Save (measured value) to text file		
6	Repeat steps 3 to 5		

### ■ Measurement by external trigger 1

Measure and import data using an external trigger ([ENTER] key, TRIG signal input) or computer key input, and save it as a text file.

	Content	Send from controller to instrument	Example of response of this device
1	Select external trigger	:TRIG:SOUR EXT	
2	Continuous measurement OFF	:INIT:CONT OFF	
3	Get measured value after measurement	:READ?	
4	(send external trigger or trigger command)	*TRG	(measured value)
5	Save (measured value) to text file		
6	Repeat steps 3 to 5		

### ■ Measurement by external trigger 2

Capture data using an external trigger ([ENTER] key, TRIG signal input) and save it as a text file. (The main unit is in continuous measurement mode, and the latest measured value is acquired at the timing of trigger input.)

	Content	Send from controller to instrument	Example of response of this device
1	Select internal trigger	:TRIG:SOUR IMM	
2	Continuous measurement ON	:INIT:CONT ON	
3	Clear external I/O trigger input confirmation	:IO:INP?	1
4	Wait for external I/O trigger input	:IO:INP?	1
5	Get the latest measurements	:FETCH?	(measured value)
6	Save (measured value) to text file		
7	Repeat steps 4 to 6		

### ■ LAN communication setting example [RM3545A](#) [RM3546](#)

This is an example of setting the IP address, port number, etc.

	Content	Send from controller to instrument	Example of response of this device
1	IP address settings	:SYST:COMM:LAN:IPAD 172,16,1,100	
2	Setting the subnet mask	:SYST:COMM:LAN:SMASK 255,255,255,0	
3	Setting the default gateway	:SYST:COMM:LAN:GAT 172,16,1,1	
4	Setting the port number	:SYST:COMM:LAN:CONT 523	
5	Confirming LAN settings (LAN restart)	:SYST:COMM:LAN:UPD	
6	Check IP address	:SYST:COMM:LAN:IPAD?	172,16,1,100
7	Check subnet mask	:SYST:COMM:LAN:SMASK?	255,255,255,0
8	Checking the default gateway	:SYST:COMM:LAN:GAT?	172,16,1,1
9	Check port number	:SYST:COMM:LAN:CONT?	523

### ■ Example of Advanced Temperature Correction (A-TC) [RM3546](#)

This is an example of the settings and measurement value acquisition when the scan function is OFF.

	Content	Send from controller to instrument	Example of response of this device
1	Channel Settings	:CH 1	
2	CH1 ON	:CH:STAT ON,1	
3	SCAN Settings	:SCAN:MODE OFF	
4	A-TC ON	:ATC:TCOR:STAT ON	
5	Weld Location Terminal Assignment Settings	:TERM 1,1,1	
6	Weld Location Constant Settings	:ATC:TCOR:PAR 20,3930	
7	Weld Location Range Settings	:RES:RANG:AUTO ON	
8	Weld Location Speed Settings	:SAMP:RATE MED	
9	Weld Location Averaging Settings	:CALC:AVER:STAT ON	
10	Weld Location Averaging Count Settings	:CALC:AVER:COUN 2	
11	Weld Location A-OVC ON	:RES:AQVC ON	
12	Temperature Measurement Terminal Assignment Settings	:ATC:TERM 1,2,2	

13	Temperature Measurement Constant Settings	:ATC:TCOR:DELTA:PAR 100.000E-6,20,3930	
14	Temperature Measurement Range Settings	:ATC:RANG:AUTO ON	
15	Temperature Measurement Speed Settings	:ATC:RATE MED	
16	Temperature Measurement Averaging Settings	:ATC:AVER:STAT ON	
17	Temperature Measurement Averaging Count Settings	:ATC:AVER:COUN 2	
18	Temperature Measurement A-OVC ON	:ATC:AOVC ON	
19	Start A-TC Measurement and Read Measurement Values	:ATC:READ? ATC or :ATC:INIT :ATC:FETCh? ATC	1,100.000E-06, 139.300E-06, 100.00E+00

This is an example of the settings and measurement value acquisition when the scan function is set to AUTO.

	Content	Send from controller to instrument	Example of response of this device
1	Channel Settings	:CH 1	
2	CH1 ON (Following CH1 settings)	:CH:STAT ON,1	
3	A-TC ON	:ATC:TCOR:STAT ON	
4	Weld Location Terminal Assignment Settings	:TERM 1,1,1	
5	Weld Location Constant Settings	:ATC:TCOR:PAR 20,3930	
6	Weld Location Range Settings	:RES:RANG:AUTO ON	
7	Weld Location Speed Settings	:SAMP:RATE MED	
8	Weld Location Averaging Settings	:CALC:AVER:STAT ON	
9	Weld Location Averaging Count Settings	:CALC:AVER:COUN 2	
10	Weld Location A-OVC ON	:RES:AOVC ON	
11	Temperature Measurement Terminal Assignment Settings	:ATC:TERM 1,2,2	
12	Temperature Measurement Constant Settings	:ATC:TCOR:DELTA:PAR 100.000E-6,20,3930	
13	Temperature Measurement Range Settings	:ATC:RANG:AUTO ON	
14	Temperature Measurement Speed Settings	:ATC:RATE MED	
15	Temperature Measurement Averaging Settings	:ATC:AVER:STAT ON	
16	Temperature Measurement Averaging Count Settings	:ATC:AVER:COUN 2	
17	Temperature Measurement A-OVC ON	:ATC:AOVC ON	
18	Channel Settings	:CH 2	
19	CH2 ON (Following CH2 settings)	:CH:STAT ON,2	
20	A-TC ON	:ATC:TCOR:STAT ON	
21	Weld Location Terminal Assignment Settings	:TERM 1,3,3	
22	Weld Location Constant Settings	:ATC:TCOR:PAR 20,3930	
23	Weld Location Range Settings	:RES:RANG:AUTO ON	
24	Weld Location Speed Settings	:SAMP:RATE MED	
25	Weld Location Averaging Settings	:CALC:AVER:STAT ON	
26	Weld Location Averaging Count Settings	:CALC:AVER:COUN 2	
27	Weld Location A-OVC ON	:RES:AOVC ON	
28	Temperature Measurement Terminal Assignment Settings	:ATC:TERM 1,4,4	

---

---

29	Temperature Measurement Constant Settings	:ATC:TCON:DELT:PAR 100.000E-6,20,3930	
30	Temperature Measurement Range Settings	:ATC:RANG:AUTO ON	
31	Temperature Measurement Speed Settings	:ATC:RATE MED	
32	Temperature Measurement Averaging Settings	:ATC:AVER:STAT ON	
33	Temperature Measurement Averaging Count Settings	:ATC:AVER:COUN 2	
34	Temperature Measurement A-OVC ON	:ATC:AQVC ON	
35	SCAN Settings	:SCAN:MODE Auto	
36	Execute Measurement and Acquire Measurement Values (Only the resistance values corrected by A-TC are output.)	:READ?	100.000E-06,200.000E-06

## 7 Sample Programs

### Using Visual Basic

These programs can be created using Visual Basic 2022.


Describes an example of how to use the Visual Basic 2022 to operate from a Computer via RS-232C/USB, incorporate measurement values, and save measurement values to a file.

Visual Basic 2022 is referred to as VB2022 hereafter.


Note: Depending on the environment of the PC and VB2022, the procedure may differ slightly from the one described here. For a detailed explanation on how to use VB2022, refer to the instruction manual or Help of VB2022.

#### 1. Create a new project.

1. Startup Visual Studio.
2. Select [Create a new project].




3. Select [Visual Basic]-[Windows]-[Desktop]-[Windows Forms App (.NET Framework)] from the templates.




4. Click [Next].

5. Click [Create].




## 2. Place a button.

1. Click [Button] from [Common Controls] of [Toolbox].




2. Drag and drop the button onto the form layout screen.

3. Change [Text] to "Start Measurement" from the Properties window.




4. The [Start Measurement] is placed on the form.




### 3. Place a serial communication component.

1. Click [SerialPort] from [Components] of [Toolbox].




2. Drag and drop the [SerialPort] component onto the form layout screen.




3. Change [PortName] to the port name to use for communication from the properties window.

Check the port to use for communication beforehand.




#### 4. Describe the code.


1. Double-click the placed button to display the code editor.



2. Enter the sample program into the code editor.



3. Select [Save All] from the [File] menu.



Shown below is a sample program which uses VB2022 to enact RS-232C/USB communication, set the instrument measurement conditions, read measurement results and then save them to file.

The sample program will be written in the following manner.

Description of creation procedure	Description in sample program
Button created to begin measurement	Button1

When the [Begin Measurement] button is pressed, the instrument performs 10 measurements and writes the measurement values to a "data.csv" file.

When the [X] button is pressed, the program closes.

The following program is written entirely in [Form1] code.

```
Imports System.IO.Ports

Public Class Form1
    'Perform process when Button1 is pressed
    Private Sub Button1_Click(sender As Object, e As EventArgs) Handles Button1.Click
        Dim recvstr As String
        Dim i As Integer
        Try
            Button1.Enabled = False 'Disable buttons during communication
            SerialPort1.NewLine = vbCrLf 'Terminator setting
            SerialPort1.ReadTimeout = 2000 '2 seconds time out
            SerialPort1.Open() 'Open a port
            SendSetting(SerialPort1) 'Instrument settings
            FileOpen(1, "data.csv", OpenMode.Output) 'Create text file to be saved
            For i = 1 To 10
                SerialPort1.WriteLine(":FETCH?")
                'Begin measurement and read measurement results command
                recvstr = SerialPort1.ReadLine() 'Read measurement results
                WriteLine(1, recvstr) 'Write to file
            Next i
            FileClose(1) 'Close file
            SerialPort1.Close() 'Close port
            Button1.Enabled = True
        Catch ex As Exception
            MessageBox.Show(ex.Message, "Error", MessageBoxButtons.OK, MessageBoxIcon.Error)
        End Try
    End Sub

    'Set measurement conditions
    Private Sub SendSetting(ByVal sp As SerialPort)
        Try
            sp.WriteLine(":TRIG:SOUR IMM") 'Select internal triggering
            sp.WriteLine(":INIT:CONT ON") 'Continuous measurement ON
        Catch ex As Exception
            MessageBox.Show(ex.Message, "Error", MessageBoxButtons.OK, MessageBoxIcon.Error)
        End Try
    End Sub
End Class
```

## Using Visual C#

These programs can be created using Visual C# 2022.


Describes an example of how to use the Visual C# 2022 to operate from a Computer via LAN, incorporate measurement values, and save measurement values to a file.

Visual Basic C# 2022 is referred to as CS2022 hereafter.


Note: Depending on the environment of the PC and CS2022, the procedure may differ slightly from the one described here. For a detailed explanation on how to use CS2022, refer to the instruction manual or Help of CS2022.

### 1. Create a new project.

1. Startup Visual Studio.
2. Select [Create a new project].




3. Select [C#]-[Windows]-[Desktop]-[Windows Forms App (.NET Framework)] from the templates.




4. Click [Next].

5. Click [Create].




## 2. Place a button.

1. Click [Button] from [Common Controls] of [Toolbox].




2. Drag and drop the button onto the form layout screen.

3. Change [Text] to "Start Measurement" from the Properties window.




4. The [Start Measurement] is placed on the form.




#### 4. Describe the code.


1. Double-click the placed button to display the code editor.



## 2. Enter the sample program into the code editor.



## 3. Select [Save All] from the [File] menu.



Shown below is a sample program which uses CS2022 to enact LAN communication, set the instrument measurement conditions, read measurement results and then save them to file.

The sample program will be written in the following manner.

Description of creation procedure	Description in sample program
Button created to begin measurement	button1

When the [Begin Measurement] button is pressed, the instrument performs 10 measurements and writes the measurement values to a "data.csv" file.

When the [X] button is pressed, the program closes.

The following program is written entirely in [Form1] code.

```
using System;
using System.Diagnostics;
using System.IO;
using System.Net;
using System.Net.Sockets;
using System.Reflection;
using System.Text;
using System.Windows.Forms;

namespace WindowsFormsAppl
{
    public partial class Form1 : Form
    {
        private TcpClient LanSocket;           // LAN socket
        private String MsgBuf = "";           // Received data
        private const long Timeout_default = 2000; // Receive timeout default time (ms)

        public Form1()
        {
            InitializeComponent();
        }

        private void button1_Click(object sender, EventArgs e)
        {
            String ip = "192.168.0.1";        // IP address
            String port = "23";              // Port number
            int i;

            button1.Enabled = false;         // Disable buttons during communication

            // Connect
            if (OpenInterface(ip, port))
            {
                // Open text file to output test result values
                Assembly myAssembly = Assembly.GetEntryAssembly();
                string path = Path.GetDirectoryName(myAssembly.Location);
                // Output path (where executable file is located)
                StreamWriter fp = new StreamWriter(path + "\\data.csv", false, Encoding.UTF8);

                // Set measurement conditions
                SendMsg(":TRIG:SOUR IMM");     // Select internal triggering
                SendMsg(":INIT:CONT ON");     // Continuous measurement ON

                for (i = 1; i <= 10; i++)
                {
                    SendQueryMsg(":FETCH?"); // Get the latest measurement results
                    fp.Write(MsgBuf + "\r\n"); // Write to file
                }

                // Close the file
                fp.Close();

                // Disconnection
                CloseInterface();
            }
        }
    }
}
```

```
// Enable buttons
button1.Enabled = true;
}
}

// Connect
private Boolean OpenInterface(String ipaddress, String port)
{
    Boolean ret = false;
    IPAddress ip = new IPAddress(0);          // IP address

    try
    {
        if (System.Net.IPAddress.TryParse(ipaddress, out ip))
        {
            LanSocket = new TcpClient();      // Create LAN socket object
            LanSocket.NoDelay = true;        // Disable transmission delay (Nagle algorithm)
            LanSocket.Connect(ip, Convert.ToInt32(port)); // LAN socket open
            ret = true;
        }
    }
    catch (Exception e)
    {
        MessageBox.Show(e.Message);
    }
    return ret;
}

// Disconnection
private Boolean CloseInterface()
{
    Boolean ret = false;

    try
    {
        LanSocket.Close();                  // LAN socket close
        ret = true;
    }
    catch (Exception e)
    {
        MessageBox.Show(e.Message);
    }
    return ret;
}

// Send command
private Boolean SendMsg(String strMsg)
{
    Boolean ret = false;
    Byte[] sendBuffer;

    try
    {
        strMsg += "\r\n";                    // Add terminator "CR+LF"
        sendBuffer = Encoding.Default.GetBytes(strMsg); // Convert to byte type
        LanSocket.GetStream().Write(sendBuffer, 0, sendBuffer.Length);
                                                // Write to send buffer

        ret = true;
    }
}
```

```
    }
    catch (Exception e)
    {
        MessageBox.Show(e.Message);
    }
    return ret;
}

// Receive command response
private Boolean ReceiveMsg(long timeout = Timeout_default)
{
    Boolean ret = false;
    Byte[] rcv = new Byte[1024];
    System.Diagnostics.Stopwatch sw = new System.Diagnostics.Stopwatch();

    try
    {
        MsgBuf = ""; // Clear received data
        sw.Start(); // Start stopwatch for timeout

        // Loop until terminator "LF" is received
        while (true)
        {
            // Received one character at a time
            if (LanSocket.GetStream().DataAvailable) // Read if data is in the receive buffer
            {
                LanSocket.GetStream().Read(rcv, 0, 1); // Read one character from the receive buffer
                if (Convert.ToChar(rcv[0]) == '\n') // Terminate when terminator "LF" is received
                {
                    break;
                }
                else if (Convert.ToChar(rcv[0]) == '\r') // Ignore terminator 'CR'
                {
                    ;
                }
                else
                {
                    MsgBuf += Convert.ToChar(rcv[0]); // Save received data
                }
            }
            // Timeout processing
            if (sw.ElapsedMilliseconds > timeout)
            {
                MsgBuf = "Timeout";
                MessageBox.Show(MsgBuf);
                return ret;
            }
        }
        sw.Stop(); // Stop the stopwatch
        ret = true;
    }
    catch (Exception e)
    {
        MsgBuf = "Error";
        MessageBox.Show(e.Message);
    }
}
```

```
    }
    return ret;
}

// Send and receive commands
private Boolean SendQueryMsg(String strMsg, long timeout = Timeout_default)
{
    Boolean ret = false;

    ret = SendMsg(strMsg);          // Send command
    if (ret)
    {
        ret = ReceiveMsg(timeout); // Receive response after successful transmission
    }
    return ret;
}
}
```

## 8 Device Compliance Statement [GP-IB] RM3545

"Information on compliance to standards" based on the IEEE 488.2 standard

Item	Description
1. IEEE 488.1 interface functions	<a href="#">See:</a> "GP-IB Specifications (Interface Functions) (RM3545-01 only)" (Instrument instruction manual)
2. Operation with a device address other than 0 through 30	A setting outside the 0 to 30 range cannot be made.
3. Timing of changed device address recognition	A change of address is recognized immediately after changing.
4. Device settings at power on	The status information is cleared, and all other items are preserved. However, the header on/off setting, and response message separator and terminator are all initialized.
5. List of message exchange options	<ul style="list-style-type: none"> <li>• Input buffer capacity and operation</li> <li><a href="#">See:</a> "Input Buffer" (p.5)</li> </ul> <p>Queries to which multiple response message units are returned</p> <ul style="list-style-type: none"> <li><a href="#">:FETCh?</a></li> <li><a href="#">:READ?</a></li> <li><a href="#">:CALCulate:LIMit:BEEP?</a></li> <li><a href="#">:CALCulate:STATistics:NUMBer?</a></li> <li><a href="#">:CALCulate:STATistics:MAXimum?</a></li> <li><a href="#">:CALCulate:STATistics:MINimum?</a></li> <li><a href="#">:CALCulate:STATistics:LIMit?</a></li> <li><a href="#">:CALCulate:STATistics:BIN?</a></li> <li><a href="#">:CALCulate:STATistics:DEViation?</a></li> <li><a href="#">:CALCulate:STATistics:CP?</a></li> <li><a href="#">:CALCulate:TCONversion:DELta:PARAmeter?</a></li> <li><a href="#">:CALCulate:TCORrect:PARAmeter?</a></li> <li><a href="#">:MEMory:DATA?</a></li> <li><a href="#">[:SENSe:]SCAN:DATA?</a></li> <li><a href="#">[:SENSe:]TERMinal?</a></li> <li><a href="#">[:SENSe:]TEMPerature:PARAmeter?</a></li> <li><a href="#">:UNIT:IDN?</a></li> <li><a href="#">:SYSTem:DATE?</a></li> <li><a href="#">:SYSTem:TIME?</a></li> </ul> <ul style="list-style-type: none"> <li>• Queries producing responses when syntax checking is performed: All queries produce responses when syntax checking is performed.</li> <li>• Whether any queries produce responses when read: There are no queries which produce response messages when they are read in by the controller.</li> <li>• Whether any commands are coupled: There are no relevant commands.</li> </ul>

Item	Description
6. Summary of functional elements for use when constructing device specific commands, and whether compound commands or program headers can be used	<p>The followings can be used:</p> <ul style="list-style-type: none"> <li>• Program message</li> <li>• Program message terminator</li> <li>• Program message unit</li> <li>• Program message unit separator</li> <li>• Command message unit</li> <li>• Query message unit</li> <li>• Command program header</li> <li>• Query program header</li> <li>• Program data</li> <li>• Character program data</li> <li>• Decimal program data</li> <li>• Character string program data</li> <li>• Compound commands and program headers</li> </ul>
7. Buffer capacity limitations for block data	Block data is not used.
8. Summary of program data elements used in expressions, and deepest nesting level allowable in sub-expressions, including syntax restrictions imposed by the device	Sub-expressions are not used. Character data, decimal data and character string program data are the only program data elements used.
9. Response syntax for queries	<a href="#">See: Message Reference (p.23)</a>
10. Transmission congestion relating to device-to-device messages which do not conform to the general principles for basic response messages	There are no device to device messages.
11. Response capacity for block data	Block data does not appear in responses.
12. Summary of standard commands and queries used	<a href="#">See: Message List (p.13)</a>
13. Device state after a calibration query has been completed without any problem	The “*CAL?” query is not used.
14. Existence/nonexistence of “*DDT” command	The “*DDT” command is not used.
15. Existence/nonexistence of macro command	Macros are not used.
16. For queries related to identification, explanation of the response to the “*IDN?” query	<a href="#">See: Standard Commands (p.24)</a>
17. Capacity of the user data storage area reserved for when the “*PUD” command and the “*PUD?” query are being executed	The “*PUD” command and the “*PUD?” query are not used. Further, there is no user data storage area.
18. Resources when the “*RDT” command and the “*RDT?” query are being used	The “*RDT” command and the “*RDT?” query are not used. Further, there is no user data storage area.
19. Conditions which are influenced when “*RST”, “*LRN?”, “*RCL”, and “*SAV” are used	<p>“*LRN?”, “*RCL”, and “*SAV” are not used. The “*RST” command returns the instrument to its initial state.</p> <p><a href="#">See: Standard Commands (p.24), Initialization Items (p.11)</a></p>
20. Scope of the self-testing executed as a result of the “*TST?” query	<a href="#">See: Standard Commands (p.24)</a>
21. Additional organization of the status data used in a device status report	<a href="#">See: Event Registers (p.8)</a>
22. Whether commands are overlap or sequential type	All the commands are sequential commands.
23. Criterion relating to the functions required at the instant that the termination message is produced, as a response to each command	<p>Termination occurs when the command has been parsed.</p> <p>The :READ? query finishes when the measurement data is received.</p>

**HIOKI**  
**www.hioki.com/**



**All regional  
contact  
information**

**HIOKI E.E. CORPORATION**  
81 Koizumi, Ueda, Nagano 386-1192 Japan

2402 EN

Edited and published by HIOKI E.E. CORPORATION

Printed in Japan

- Contents subject to change without notice.
- This document contains copyrighted content.
- It is prohibited to copy, reproduce, or modify the content of this document without permission.
- Company names, product names, etc. mentioned in this document are trademarks or registered trademarks of their respective companies.

**Europe only**

- EU declaration of conformity can be downloaded from our website.
- Contact in Europe: HIOKI EUROPE GmbH  
Helfmann-Park 2, 65760 Eschborn, Germany hioki@hioki.eu