

Electrical Safety Tester

GPT-9000 Series

USER MANUAL

GW INSTEK PART NO. 82PT-99040EA1



ISO-9001 CERTIFIED MANUFACTURER

GW INSTEK

This manual contains proprietary information, which is protected by copyright. All rights are reserved. No part of this manual may be photocopied, reproduced or translated to another language without prior written consent of Good Will company.

The information in this manual was correct at the time of printing. However, Good Will continues to improve products and reserves the rights to change specification, equipment, and maintenance procedures at any time without notice.

Good Will Instrument Co., Ltd.
No. 7-1, Jhongsing Rd., Tucheng Dist., New Taipei City 236, Taiwan.

Table of Contents

SAFETY INSTRUCTIONS	5
GETTING STARTED	9
GPT-9000 Series Overview	10
Appearance.....	14
Set Up.....	20
OPERATION	27
Menu Tree.....	29
Test Lead Connection.....	33
Manual Testing	35
Common Utility Settings.....	71
Automatic Tests	78
EXTERNAL CONTROL	95
External Control Overview.....	96
REMOTE CONTROL	101
Interface Configuration	102
Command Syntax	106
Command List	109
Error Messages.....	136
FAQ	137
APPENDIX	139
Fuse Replacement.....	139
Error Messages.....	140
GPT-9000 Specifications	142
GPT-9000 Dimensions	146
Declaration of Conformity.....	147

INDEX..... 148

S SAFETY INSTRUCTIONS

This chapter contains important safety instructions that you must follow during operation and storage. Read the following before any operation to ensure your safety and to keep the instrument in the best possible condition.

Safety Symbols

These safety symbols may appear in this manual or on the instrument.



WARNING

Warning: Identifies conditions or practices that could result in injury or loss of life.



CAUTION

Caution: Identifies conditions or practices that could result in damage to the GPT-9000 or to other properties.



DANGER High Voltage



Attention Refer to the Manual



Protective Conductor Terminal



Frame or Chassis Terminal



Earth (ground) Terminal



Do not dispose electronic equipment as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased.

Safety Guidelines

General Guideline



CAUTION

- Do not place any heavy object on the GPT-9000.
- Avoid severe impact or rough handling that leads to damaging the GPT-9000.
- Do not discharge static electricity to the GPT-9000.
- Use only mating connectors, not bare wires, for the terminals.
- Do not block the cooling fan opening.
- Do not disassemble the GPT-9000 unless you are qualified.

(Measurement categories) EN 61010-1:2010 specifies the measurement categories and their requirements as follows. the GPT falls under category I.

- Measurement category IV is for measurement performed at the source of low-voltage installation.
- Measurement category III is for measurement performed in the building installation.
- Measurement category II is for measurement performed on the circuits directly connected to the low voltage installation.
- Measurement category I is for measurements performed on circuits not directly connected to Mains.

Power Supply



WARNING

- AC Input voltage range:
100/120/220/230VAC $\pm 10\%$
 - Frequency: 50Hz/60Hz
 - To avoid electrical shock connect the protective grounding conductor of the AC power cord to an earth ground.
-

**Cleaning the
GPT-9000**

- Disconnect the power cord before cleaning.
 - Use a soft cloth dampened in a solution of mild detergent and water. Do not spray any liquid.
 - Do not use chemicals containing harsh material such as benzene, toluene, xylene, and acetone.
-

**Operation
Environment**

- Location: Indoor, no direct sunlight, dust free, almost non-conductive pollution (Note below)
- Relative Humidity: $\leq 70\%$ (no condensation)
- Altitude: $< 2000\text{m}$
- Temperature: $0^{\circ}\text{C}\sim 40^{\circ}\text{C}$

(Pollution Degree) EN 61010-1:2010 specifies the pollution degrees and their requirements as follows. The GPT-9000 falls under degree 2.

Pollution refers to “addition of foreign matter, solid, liquid, or gaseous (ionized gases), that may produce a reduction of dielectric strength or surface resistivity”.

- Pollution degree 1: No pollution or only dry, non-conductive pollution occurs. The pollution has no influence.
 - Pollution degree 2: Normally only non-conductive pollution occurs. Occasionally, however, a temporary conductivity caused by condensation must be expected.
 - Pollution degree 3: Conductive pollution occurs, or dry, non-conductive pollution occurs which becomes conductive due to condensation which is expected. In such conditions, equipment is normally protected against exposure to direct sunlight, precipitation, and full wind pressure, but neither temperature nor humidity is controlled.
-

**Storage
environment**

- Location: Indoor
 - Temperature: -10°C to 70°C
 - Relative Humidity: $\leq 85\%$ (no condensation)
-

Disposal

Do not dispose this instrument as unsorted municipal waste. Please use a separate collection facility or contact the supplier from which this instrument was purchased. Please make sure discarded electrical waste is properly recycled to reduce environmental impact.

Power cord for the United Kingdom

When using the safety tester in the United Kingdom, make sure the power cord meets the following safety instructions.

NOTE: This lead/appliance must only be wired by competent persons



WARNING: THIS APPLIANCE MUST BE EARTHED

IMPORTANT: The wires in this lead are coloured in accordance with the following code:

Green/ Yellow:	Earth
Blue:	Neutral
Brown:	Live (Phase)



As the colours of the wires in main leads may not correspond with the coloured marking identified in your plug/appliance, proceed as follows:

The wire which is coloured Green & Yellow must be connected to the Earth terminal marked with either the letter E, the earth symbol \oplus or coloured Green/Green & Yellow.

The wire which is coloured Blue must be connected to the terminal which is marked with the letter N or coloured Blue or Black.

The wire which is coloured Brown must be connected to the terminal marked with the letter L or P or coloured Brown or Red.


If in doubt, consult the instructions provided with the equipment or contact the supplier.

This cable/appliance should be protected by a suitably rated and approved HBC mains fuse: refer to the rating information on the equipment and/or user instructions for details. As a guide, a cable of 0.75mm² should be protected by a 3A or 5A fuse. Larger conductors would normally require 13A types, depending on the connection method used.

Any exposed wiring from a cable, plug or connection that is engaged in a live socket is extremely hazardous. If a cable or plug is deemed hazardous, turn off the mains power and remove the cable, any fuses and fuse assemblies. All hazardous wiring must be immediately destroyed and replaced in accordance to the above standard.

G E T T I N G S T A R T E D

This chapter describes the safety tester in a nutshell, including its main features and front / rear panel introduction. After going through the overview, please read the safety considerations in the Set Up chapter.



GPT-9000 Series Overview	10
Series lineup	10
Main Features	11
Accessories	12
Package Contents	13
Appearance.....	14
GPT-9801/9802/9803 Front Panel	14
GPT-9000 Rear Panel.....	18
Set Up	20
Line Voltage Connection and Power Up	20
Installing the Optional GPIB Card	22
Workplace Precautions.....	23
Operating Precautions	24
Basic Safety Checks	26

GPT-9000 Series Overview

Series lineup

The GPT-9000 Series Safety Testers are AC/DC withstanding voltage, insulation resistance and ground bond safety testers. The GPT-9801 is an AC withstanding voltage tester, the GPT-9802 is an AC/DC withstanding voltage tester and the GPT-9803 is an AC/DC withstanding voltage and insulation resistance tester. The GPT-9804 includes all the functions of the other models as well as ground bond testing. All models can operate at up to 5kVAC for AC withstanding voltage testing. The GPT-9802, GPT-9803 and GPT-9804 can also operate at up to 6kVDC for DC withstanding voltage testing.

The GPT-9000 Series can store up to 100 manual tests, as well as run up to 16 manual tests sequentially as an automatic test, allowing the safety testers to accommodate any number of safety standards, including IEC, EN, UL, CSA, GB, JIS and others.

Model name	ACW	DCW	IR	GB
GPT-9801	✓			
GPT-9802	✓	✓		
GPT-9803	✓	✓	✓	
GPT-9804	✓	✓	✓	✓

Main Features

- | | |
|-------------|---|
| Performance | <ul style="list-style-type: none">• ACW: 5kVAC• DCW: 6kVDC• IR: 50V~1000V (50V steps)• GB: 3A~30A |
| Features | <ul style="list-style-type: none">• Ramp up time control• Safety discharge• 100 test conditions (MANU mode)• 100 automatic tests (AUTO mode)• Over temperature, voltage and current protection• Pass, Fail, Test, High Voltage and Ready indicators• PWM output (90% efficiency, increased reliability)• Interlock (configurable). |
| Interface | <ul style="list-style-type: none">• Remote control start/stop interface terminal• RS232/USB interface for programming• Optional GPIB interface for programming• Signal I/O port for pass/fail/test monitoring and start/stop control/interlock |


Accessories

Standard Accessories	Part number	Description
	GHT-114 x1	Test lead
	Region dependent	Power cord
	GTL-115 x1	GB Test leads (GPT-9804)
	N/A	Remote terminal male plug
	N/A	Interlock key
Optional Accessories	Part number	Description
	GHT-205	High Voltage Test Probe
	GHT-113	High Voltage Test Pistol
	GTL-232	RS232C cable
	GTL-248	GPIB cable
	GTL-247	USB cable
	GRA-402	Rack Adapter Panel (19", 4U)
Options	Part number	Description
	Opt.01 GPIB Interface	GPIB module

Package Contents

Check the contents before using the GPT-9000.

Opening the box



Contents (single unit)

- GPT-9000 unit
 - Quick Start guide
 - User manual CD
 - CTC (Calibration Traceable Certificate)
 - Power cord x1 (region dependent)
 - GHT-114 test leads x1
 - GTL-115 test leads x1 (GPT-9804)
 - Remote terminal male plug
 - Interlock key
-




Note


Keep the packaging, including the box, polystyrene foam and plastic envelopes should the need arise to return the unit to GW Instek.

Appearance

GPT-9801/9802/9803 Front Panel





GPT-9804 Front Panel



Display 240 X 64 dot matrix display (LCD)

Function keys The function keys correspond to the soft-keys directly above on the main display.

Pass/Fail indicators  The PASS and FAIL indicators light up upon a PASS or FAIL test result at the end of a manual test or automatic test.

ESC key  The ESC key is used to exit out of a menu or cancel a setting.

PAGE key



The PAGE key is used to view automatic test information and test results.

Directional arrow keys



The directional arrow keys are used to navigate menus and parameter settings.

READY indicator




The READY indicator is lit when the tester is ready to begin testing. The STOP button is used to put the tester into READY status.

TEST indicator




The TEST indicator is lit when a test is on. The START button is used to put the tester into TEST status.

HIGH VOLTAGE indicator



The HIGH VOLTAGE indicator will light up when an output terminal is active. Only after the test has finished or stopped will the indicator turn off.

HIGH VOLTAGE output terminal



The HIGH VOLTAGE terminal output is used for outputting the testing voltage. The terminal is recessed for safety. This terminal is used in conjunction with the RETURN terminal.




WARNING

USE EXTREME CAUTION.

Do not touch the HIGH VOLTAGE terminal during testing.


RETURN terminal
GPT-9801/9802
/9803



The RETURN terminal is the return terminal for all tests.

For GB testing, the RETURN terminal is also the SENSE L terminal.

RETURN/
SENSE L,
SENSE H,
SOURCE L,
SOURCE H
terminal
(GPT-9804)




The RETURN terminal is used for IR, DCW and ACW tests. For GB tests, it is used as the SENSE L terminal.

SENSE H terminal for GB tests. GPT-9804 only.

SOURCE L terminal for GB tests. GPT-9804 only.

SOURCE H terminal for GB test. GPT-9804 only.

Scroll wheel



The scroll wheel is used to edit parameter values.

UTILITY key




Used to enter the MANU Utility or Common Utility menu.

EDIT/SAVE key



Used to start editing MANU/AUTO tests as well as save settings and parameters.

MANU/AUTO
key



The MANU/AUTO key is used to select manual tests (MANU) or automatic tests (AUTO).

REMOTE terminal

REMOTE


The REMOTE terminal is used to connect to a remote controller.



STOP button

STOP


The STOP button is used to stop/cancel tests. The STOP button will also put the safety tester in the READY status to begin testing.



START button

START

The START button is used to start tests.




The START button can be used to start tests when the tester is in the READY status. Pressing the START button will put the tester in the TEST status.


POWER switch

POWER


Turns the power on. The safety tester will always start up with the last test setting from when the instrument was last powered down.



GPT-9000 Rear Panel



SIGNAL I/O port




The SIGNAL I/O port is used to monitor the tester status (PASS, FAIL, TEST) and input (START/STOP signals). It is also used with the Interlock key.

USB A port



Used for remote control.

RS232 interface port




Used for remote control and firmware updates.

Fan


Exhaust fan.

GND




Connect the GND (ground) terminal to the earth ground.

Line voltage input



Line voltage input:
100/120/220/230VAC $\pm 10\%$

Line voltage fuse



Line voltage selector and fuse:


100V/120V

T5A 250V

220V/230V

T2.5A 250V

Optional GPIB
port



Optional GPIB interface for remote control.


Set Up

Line Voltage Connection and Power Up


Background Before powering up the GPT-9000 ensure the correct voltage has been selected on the rear panel. The GPT-9000 supports line voltages of 100V/120V/220V and 230V.

- Steps**
1. Check the line voltage and the fuse Page 139 in the fuse holder.


The desired line voltage should line up with the arrow on the fuse holder.



2. Connect the power cord to the AC voltage input.




3. If the power cord does not have an earth ground, ensure the ground terminal is connected to an earth ground.



 **Warning**

Ensure the power cord is connected to an earth ground. Failure could be harmful to the operator and instrument.


4. Press the Power button.



5. When the unit is powering up, all the LED indicators will light. Check to make sure all 5 LED indicators are working.
6. Check to make sure the System Self Test passes without errors.



After the System Self Test completes, the tester will go into VIEW status and be ready to operate.



See the Appendix on page 140 for details if a self-test error is detected.

Installing the Optional GPIB Card

Background The optional GPIB is a user-installable option. Follow the instructions below to install the GPIB card.




WARNING


Before installing the optional GPIB card ensure the GPT-9000 turned is off and disconnected from power.

Steps

1. Remove the screws from the rear panel cover plate.



2. Insert the GPIB card into the two slots on either side of the opening. Push the card gently until it is fully inserted.



Workplace Precautions

Background The GPT-9000 is a high voltage instrument that outputs dangerous voltages. The following section describes precautions and procedures that must be followed to ensure a safe work environment.



WARNING

The GPT-9000 generates voltages in excess of 5kVAC or 6kVDC. Follow all safety precautions, warnings and directions given in the following section when using the GPT-9000.

1. Only technically qualified personnel should be allowed to operate the safety tester.
2. The operating workplace must be fully isolated, especially when the instrument is in operation. The instrument should be clearly labeled with appropriate warning signage.
3. The operator should not wear any conductive materials, jewelry, badges, or other items, such as wrist watches.
4. The operator should wear insulation gloves for high voltage protection.
5. Ensure the earth ground of the line voltage is properly grounded.
6. Ensure any devices that are adversely affected by magnetic fields are not placed near the tester.

Operating Precautions

Background The GPT-9000 is a high voltage instrument that outputs dangerous voltages. The following section describes precautions and procedures that must be followed to ensure that the tester is operated in a safe manner.



The GPT-9000 generates voltages of up to 5kVAC or 6kVDC. Follow all safety precautions, warnings and directions given in the following section when using the GPT-9000.

1. Never touch the safety tester, lead wires, terminals, probes and other connected equipment when the tester is testing.
2. Do not turn the safety tester on and off quickly or repeatedly. When turning the power off, please allow a few moments before turning the power back on. This will allow the protection circuits to properly initialize.

Do not turn the power off when a test is running, unless in an emergency.

3. Only use those test leads supplied with the instrument. Leads with inappropriate gauges can be dangerous to both the operator and the instrument.
For GB testing, never use the Sense leads on the SOURCE terminals.
4. Do not short the HIGH VOLTAGE terminal with ground. Doing so could charge the chassis to dangerously high voltages.

5. Ensure the earth ground of the line voltage is properly grounded.
6. Only connect the test leads to the HIGH VOLTAGE/SOURCE H/SENSE H terminals before the start of a test. Keep the test leads disconnected at all other times.
7. Always press the STOP button when pausing testing.
8. Do not leave the safety tester unattended. Always turn the power off when leaving the testing area.
9. When remotely controlling the safety tester, ensure adequate safety measures are in place to prevent:
 - Inadvertent output of the test voltage.
 - Accidental contact with the instrument during testing. Ensure that the instrument and DUT are fully isolated when the instrument is remotely controlled.
10. Ensure an adequate discharge time for the DUT.

When DCW or IR tests are performed, the DUT, test leads and probes become highly charged. The GPT-9000 has discharge circuitry to discharge the DUT after each test. The time required for a DUT to discharge is typically 200ms.

Never disconnect the safety tester before a discharge is completed.

Basic Safety Checks

Background The GPT-9000 is a high voltage device and as such, daily safety checks should be made to ensure safe operation.

1. Ensure all test leads are not broken and are free from defects such as cracks or splitting.
 2. Ensure the safety tester is always connected to an earth ground.
 3. Test the safety tester operation with a low voltage/current output:
 Ensure the safety tester generates a FAIL judgment when the HIGH VOLTAGE and RETURN terminals are shorted (using the lowest voltage/current as the testing parameters).
-



Do not use high voltages/currents when the HIGH VOLTAGE and RETURN terminals are shorted. It may result in damage to the instrument.


OPERATION

Menu Tree	29
Menu Tree Overview	30
Test Lead Connection	33
ACW, DCW, IR Connection.....	33
GB Connection.....	34
Manual Testing	35
Choose/Recall a Manual Test Number	36
Edit Manual Test Settings	37
Setting the Test Function.....	38
Setting the Test Voltage or Test Current	38
Setting the Test Frequency	39
Setting the Upper and Lower Limits	40
Setting a Reference Value.....	42
Setting the Test Time (Timer)	43
Setting the Ramp Up Time.....	45
Creating a MANU Test File Name.....	46
Setting the ARC Mode.....	47
Setting PASS HOLD.....	48
Setting FAIL HOLD	50
Setting MAX HOLD	51
Setting the Grounding Mode.....	52
Saving and Exiting EDIT Status	56
Running a MANU Test.....	57
PASS / FAIL MANU Test.....	61
Zeroing of the Test Leads (GB only).....	66
Special MANU Test Mode (000).....	69
Common Utility Settings	71
LCD Settings	71

Buzzer Settings	72
Interface Settings	73
Control Settings	75
Automatic Tests	78
Choose/Recall an Automatic Test	78
Edit Automatic Test Settings	80
Adding a Step to the Automatic Test	81
Creating an AUTO Test File Name	82
Saving and Exiting EDIT Status	83
Automatic Test Page View	84
Running an Automatic Test	87
Automatic Test Results	91

Menu Tree

This section describes the overall structure of the operation statuses and modes for the GPT-9000 safety testers. The testers have two main testing modes (MANU, AUTO) and 5 main operation statuses (VIEW, EDIT, READY, TEST and STOP).




* Press EDIT/SAVE to save settings, or ESC to cancel and return to the previous screen.
 † Press the STOP key twice for a FAIL result.

Menu Tree Overview


VIEW status

VIEW status is used to view the parameters of the selected manual test/automatic test. The VIEW status is also used to put the tester into MANU or AUTO mode.




EDIT status

EDIT status is used to edit the manual test or automatic test parameters. Pressing the EDIT/SAVE key will save any changes. Pressing the ESC key will cancel any changes.



READY status

When the tester is in READY status, it is ready to begin testing. Pressing the START button will begin testing and put the tester into TEST status. Pressing the MANU/AUTO key will return the tester to VIEW status.




TEST status TEST status is active when a MANU test or AUTO test is running. Pressing STOP will cancel the MANU test or the remaining steps in an AUTO test.



STOP status STOP status is shown when a manual test or automatic test did not finish running and has been stopped by the operator. Pressing STOP will return the tester to READY status.




Page View Up to 16 tests can be used to create an automatic test. Page View is used to see which manual tests (steps) an automatic test is composed of. The steps can be re-arranged and deleted in Page View.




AUTO mode

AUTO indicates that the tester is in AUTO mode. AUTO mode is for creating/running a sequence of up to 16 MANU tests.




MANU mode

MANU mode is used to create and/or execute a single test. MANU indicates that the manual test mode is active.




Common Utility Settings

This utility controls the LCD, buzzer, interface and control settings. These settings are system wide.



MANU Utility Settings

The Manu Utility settings are configured for each MANU test separately. The settings include: ARC MODE, PASS HOLD, FAIL HOLD, MAX HOLD and GROUND MODE.




Test Lead Connection

This section describes how to connect the GPT-9000 to a DUT for withstanding, insulation resistance or ground bond testing.


ACW, DCW, IR Connection

Background ACW, DCW and IR tests use the HIGH VOLTAGE terminal and RETURN terminal with the GHT-114 test leads.

ACW, DCW, IR Connection



- Steps**
1. Turn the power off on the safety tester.
 2. Connect the high voltage test lead(red) to the HIGH VOLTAGE terminal and screw firmly into place.
 3. Connect the return test lead(white) into the RETURN terminal and screw the protector bar into place, as shown below.




GB Connection

Background


GB tests use the SENSE H/L and SOURCE H/L terminals with the GTL-115 test leads.

GB Connection



Steps

1. Turn the power off on the safety tester.
2. Connect the Sense H lead to the SENSE H terminal.
3. Connect the Sense L lead to the SENSE L terminal.
4. Connect the Source H lead to the SOURCE H terminal.
5. Connect the Source L lead to the SOURCE L terminal.



Manual Testing


This section describes how to create, edit and run a single ACW, DCW, IR or GB safety test. Each manual test can be stored/recalled to/from one of 100 memory locations. Each stored manual test can be used as a test step when creating an AUTO test (page 78).

- Choose/Recall a Manual Test number → from page 36.
- Edit Manual Test Settings → from page 37.
- Setting the Test Function → from page 38.
- Setting the Test Voltage or Test Current → from page 38.
- Setting the Test Frequency → from page 39.
- Setting the Upper and Lower Limits → from page 40.
- Setting a Reference Value → from page 42.
- Setting the Test Time (Timer) → from page 43.
- Setting the Ramp Up Time → from page 45.
- Creating a MANU Test File Name → from page 46.
- Setting the ARC Mode → from page 47.
- Setting PASS HOLD → from page 49.
- Setting FAIL HOLD → from page 50.
- Setting MAX HOLD → from page 51.
- Setting the Grounding Mode → from page 52.
- Saving and Exiting EDIT Status → from page 56.
- Running a MANU Test → from page 57.
- PASS / FAIL MANU Test → from page 61.
- Zeroing of the Test Leads (GB only) → from page 66
- Special MANU Test Mode (000) → from page 69


Before operating the GPT-9000 please read the safety precautions as outlined in the Set Up chapter on page 20.


Choose/Recall a Manual Test Number

Background ACW, DCW, IR and GB tests can only be created in the MANU (manual) mode. MANU number 001 to 100 can be saved and thus be loaded when editing/creating a MANU test or AUTO test. MANU number 000 is a special mode. See page 66 for details on the special mode.

- Steps**
1. If the tester is in AUTO mode, press and hold the MANU/AUTO key for three seconds to switch to MANU mode. 


The tester can only switch between AUTO and MANU mode when in the VIEW status.



2. Use the scroll wheel to choose the MANU number. 

MANU # 001~100
(MANU# 000 is a special mode)

MANU number





Note

The MANU number can only be chosen in VIEW status. If in the EDIT status, switch to the VIEW status by pressing the EDIT/SAVE or ESC key.

Edit Manual Test Settings

Background


To edit any of the manual test settings, the tester must be in EDIT status.

Any settings or parameters that are edited only apply to the currently selected MANU number.

Steps

1. Press the EDIT/SAVE key when in VIEW status to enter the EDIT status. This will enter the EDIT status for the chosen test number.

EDIT/SAVE



2. The Status changes from VIEW to EDIT.
-



Note

Pressing the EDIT/SAVE key again will save the settings for the current test and return back to VIEW status.

Setting the Test Function


Background After a MANU number has been chosen and the tester is in EDIT status, a test function can be set.

There are four test functions, AC Withstand, DC Withstand, Insulation Resistance and Ground Bond.

Steps 1. To choose the test function, press the ACW, DCW, IR or GB soft-keys.



2. The test function soft-key is highlighted.



↑
test function






The chosen test function only applies to the current test.


Setting the Test Voltage or Test Current

Background The test voltage can be set from 0.100kV to 5kV for ACW, 0.100kV to 6kV for DCW and 0.050 to 1kV for IR (50V steps). For GB tests the test current can be set from 3A to 30A.

Steps

1. Press the UP / DOWN arrow keys to bring the cursor to the voltage setting.  



2. Use the scroll wheel to set the voltage level. 

ACW	0.100kV ~ 5kV
DCW	0.100kV ~ 6kV
IR	0.05kV ~ 1kV (50V steps)
GB	3.00A ~ 30.00A



When setting the voltage, be aware that a maximum of 200VA can be set for ACW and 50W for DCW.



The ground bond voltage (GBV) is calculated as the HI SET limit x Test Current.


Setting the Test Frequency

Background

A test frequency of 60Hz or 50Hz can be set, regardless of the input line voltage. The test frequency setting only applies to ACW and GB tests.


Steps

1. Press the UP / DOWN arrow keys to bring the cursor to the FREQ setting.  



cursor

2. Use the scroll wheel to set the test frequency.



ACW, GB 50Hz, 60Hz



Note

The test frequency can only be set for ACW or GB tests.

Setting the Upper and Lower Limits

Background

There is both a LO and HI judgment setting. When the measured value is below the LO SET setting, the test will be judged as FAIL. When the value exceeds the HI SET setting the test will be judged as FAIL. Any measurement between the LO SET and HI SET setting is judged as PASS. The LO SET limit cannot be made greater than the HI SET limit.

Steps


1. Press the HI/LO soft-key or use the UP / DOWN arrow keys to bring the cursor to the HI SET (ACW/DCW/GB) setting or the LO SET(IR) setting.

HI/LO




OR







2. Use the scroll wheel to set the HI SET/LO SET limit.




ACW (HI) 0.001mA~040.0mA
 DCW (HI) 0.001mA~010.0mA
 IR (LO) 0001MΩ ~ 9500MΩ
 GB (HI) 000.1mΩ ~ 650.0mΩ

3. Press the HI/LO soft-key again or press the DOWN arrow key to switch between HI SET and LO SET.



4. Use the scroll wheel to set the HI SET/LO SET limit.



ACW (LO) 0.000mA~039.9mA
 DCW (LO) 0.000mA~009.9mA
 IR (HI) 0001MΩ~9500MΩ, ∞
 GB (LO) 000.0mΩ ~ 649.9mΩ






Note

The LO SET setting is limited by the HI SET setting. The LO SET limit cannot be greater than the HI SET limit.


Setting a Reference Value

Background The REF# acts as an offset. The REF# value is subtracted from the measured current (ACW, DCW) or measured resistance (IR, GB).

- Steps**
1. Press the UP / DOWN arrow keys  to bring the cursor to the REF# setting. 



2. Use the scroll wheel to set the REF# value.



ACW	0.000mA~HI SET current-0.1mA
DCW	0.000mA~HI SET current-0.1mA
IR	0000MΩ~HI SETΩ-1MΩ
GB	000.0mΩ~HI SETΩ-0.1mΩ




For GB tests, a reference offset can be automatically created using the zeroing function. See page 66 for details.

Setting the Test Time (Timer)

Background


The TIMER setting is used to set the test time for the current test. The test time determines how long the test voltage or current is applied to the DUT. This test time does not include Ramp \nearrow , initial start time or discharge time (note: GB does not have Ramp \nearrow or discharge times). The test time can be set from 0.5 seconds to 999.9 seconds for ACW, DCW and GB and 1.0 second to 999.9 seconds for IR, with a resolution of 0.1 seconds for all modes. The timer can be turned off when in the special MANU test mode when using the ACW or DCW test functions.


Each test has an initial test time of 100ms and a discharge time (except GB) of 200ms.



Steps


1. Press the TIMER soft-key or use the UP/DOWN arrow keys to bring the cursor to the TIMER setting.





cursor

- Use the scroll wheel to set the TIMER value.



ACW	000.5s~999.9s
DCW	000.5s~999.9s
IR	001.0s~999.9s
GB	000.5s~999.9s



Note

With the ACW test function, when the test current is between 30mA and 40mA, the ramp time + test time cannot exceed 240 seconds. At this current level, the tester also needs to pause after a test for a time equal to or greater than the output time. See the specifications on page 142 for details.

Special Manual Mode

When in special MANU test mode (page 66) the Timer can be turned off when using the DCW or ACW test function.

Hold the TIMER soft-key for 3 seconds to turn the timer off.



Note


The timer can only be turned off under special MANU test mode, however there is a limitation: The timer cannot be turned off (limited to 240s) if the test current is between 30mA and 40mA in ACW mode.

The discharge time and initial test time cannot be edited.

Setting the Ramp Up Time



Background

The Ramp Up time is the total time taken for the tester to reach the test voltage level. The Ramp Up time starts after the initial time (100ms) with a start voltage of 50 volts. The Ramp Up time can be set from 000.1 to 999.9 seconds. The Ramp Up time is only applicable for ACW, DCW and IR tests.




Steps

1. Use the UP/DOWN arrow keys to bring the cursor to the RAMP ↗ setting.



cursor

2. Use the scroll wheel to set the RAMP ↗ value.



ACW	000.1s~999.9s
DCW	000.1s~999.9s
IR	000.1s~999.9s



The discharge time and initial test time cannot be edited.

Creating a MANU Test File Name

Background


Each manual test can have a user-defined test file name (default: MANU_NAME) up to 10 characters long. See the character list below for the allowed characters.

Character List


0	1	2	3	4	5	6	7	8	9																
A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R	S	T	U	V	W	X	Y	Z
a	b	c	d	e	f	g	h	i	j	k	l	m	n	o	p	q	r	s	t	u	v	w	x	y	z
+	-	*	/	_	=	:	Ω	?	()	<	>	[]											

Steps

1. Use the UP/DOWN arrow keys to bring the cursor to the MANU test file name at the top of the screen. The test file name is initially set as MANU_NAME.



2. Use the scroll wheel to scroll through the available characters.



3. Press the Left/Right arrow keys to go the next character.



4. The MANU test file name is set when the current test setting is saved or when the cursor is moved to another setting.

Setting the ARC Mode

Background

ARC detection, otherwise known as flashover detection, detects fast voltage or current transients that are not normally detected. Arcing is usually an indicator of poor withstanding insulation, electrode gaps or other insulating problems that cause temporary spikes in current or voltage during ACW and DCW testing.

There are three ARC detection settings: OFF, ON AND CONTINUE, ON AND STOP.

The ON AND CONTINUE setting will detect arcs over the ARC current level and continue the test, the ON AND STOP setting will stop the test when an arc is detected.

ARC mode settings only apply to ACW and DCW tests.

Steps

1. Press the UTILITY key on the front panel when the tester is in EDIT status. The tester will go to the MANU Utility for the current test.

UTILITY




```
MANU=***-002  MANU UTILITY
ARC  MODE:OFF
PASS HOLD:OFF
FAIL HOLD:OFF
MAX  HOLD:OFF
GROUND MODE:ON
```


2. Use the UP/DOWN arrow keys to move to the ARC MODE setting.



3. Use the scroll wheel to set the ARC mode.



ARC MODES: OFF, ON AND CONTINUE,
ON AND STOP



4. Press the EDIT/SAVE key to save and exit the MANU Utility and go back to EDIT status. 




Note

The ESC key can be pressed at any time in the Utility menu to cancel and exit.

5. If the ARC MODE was set to either ON AND CONTINUE, or ON AND STOP, the ARC current level can be edited.

6. Use the UP/DOWN arrow keys to move the cursor to the ARC setting.  

7. Use the scroll wheel to edit the ARC level. 

ACW 0.000mA~080.0mA
DCW 0.000mA~020.0mA



Note

The ARC setting range is directly related to the HI SET current limit.

ACW

HI SET Limit	ARC range
0.001mA~0.999mA	0.000mA~2.000mA
01.00mA~09.99mA	00.00mA~20.00mA
010.0mA~042.0mA	000.0mA~080.0mA

DCW

HI SET Limit	ARC range
0.001mA~0.999mA	0.000mA~2.000mA
01.00mA~09.99mA	00.00mA~20.00mA
010.0mA~011.0mA	000.0mA~020.0mA

Setting PASS HOLD

Background The PASS HOLD settings only apply to the selected test in an AUTO test. When the PASS HOLD setting is set to ON, a PASS judgment is held until the START button is pressed.



Note

The PASS HOLD setting only applies to AUTO tests. This setting is ignored when running MANU tests.

Steps

1. Press the UTILITY key on the front panel when the tester is in EDIT status. The display will go from the normal EDIT status to the MANU Utility menu for the current test.




```
MANU=***-002  MANU UTILITY
ARC  MODE: OFF
PASS HOLD: OFF
FAIL HOLD: OFF
MAX  HOLD: OFF
GROUND MODE: ON
```

2. Use the UP/DOWN arrow keys to move to the PASS HOLD setting.



3. Use the scroll wheel to set PASS HOLD.



PASS HOLD OFF, ON

4. Press the EDIT/SAVE key to save and exit the MANU Utility menu.




Note

The ESC key can be pressed at any time in the MANU Utility menu to cancel and exit.

Setting FAIL HOLD

Background The FAIL HOLD settings only apply to the selected test in AUTO tests. When the FAIL HOLD setting is set to ON, a FAIL judgment is held until the START button is pressed.

 **Note** The FAIL HOLD setting only applies to AUTO tests. This setting is ignored when running MANU tests.

Steps

1. Press the UTILITY key on the front panel when the tester is in EDIT status. The display will go from the normal EDIT status to the MANU Utility menu for the current test.




```
MANU=***-002  MANU UTILITY
ARC  MODE:OFF
PASS HOLD:OFF
FAIL HOLD:OFF
MAX  HOLD:OFF
GROUND MODE:ON
```

2. Use the UP/DOWN arrow keys to move to the FAIL HOLD setting.




3. Use the scroll wheel to set FAIL HOLD.



FAIL HOLD OFF, ON


4. Press the EDIT/SAVE key to save and exit the MANU Utility menu.







 **Note** The ESC key can be pressed at any time in the MANU Utility menu to cancel and exit.

Setting MAX HOLD

Background The MAX HOLD setting will hold the maximum current measured in the ACW and DCW tests or the maximum resistance measured in IR and GB tests.

- Steps**
1. Press the UTILITY key on the front panel when the tester is in EDIT status. The display will go from the normal EDIT status to the MANU Utility menu for the current test. 
- ```

MANU=***-002 MANU UTILITY
ARC MODE:OFF
PASS HOLD:OFF
FAIL HOLD:OFF
MAX HOLD:OFF
GROUND MODE:ON

```
2. Use the UP/DOWN arrow keys to move to the MAX HOLD setting.   

  3. Use the scroll wheel to set MAX HOLD.   
  
MAX HOLD OFF, ON
  4. Press the EDIT/SAVE key to save and exit the MANU Utility menu. 
- 



The ESC key can be pressed at any time in the MANU Utility menu to cancel and exit.

---

## Setting the Grounding Mode


### Background

When GROUND MODE is set to ON, the GPT-9000 grounds the return terminal to the ground. This mode is best for DUTs that are grounded to an earth ground by their chassis, fixtures or operation environment. This mode measures the potential of the HIGH VOLTAGE terminal with respect to earth ground. This means that any stray capacitance/resistance that leaks to earth ground will also be measured. This is the safest testing mode, though potentially not as accurate.


When GROUND MODE is set to OFF, the return terminal is floating with respect to the earth ground. This mode is for DUTs that are floating and not directly connected to an earth ground. This is more accurate than when GROUND MODE is set to ON as any stray capacitance/resistance that leaks to the earth ground from the DUT side of the testing circuit will not be measured. For this reason, this testing mode is able to measure to a higher accuracy and resolution.

The GROUND MODE is always set to OFF for IR and GB tests.


GROUND MODE = ON, DUT grounded




GROUND MODE = ON, DUT floating




GROUND MODE = OFF, DUT floating



GPT-9804 (GB testing)



GROUND MODE = OFF, DUT grounded



Warning

When GROUND MODE is set to OFF, the DUT, fixtures or connected instrumentation cannot be grounded. This will short circuit the internal circuitry during a test.

For ACW and DCW tests, if it is not known whether the DUT test setup is grounded or not, always set GROUND MODE to ON.

Only set GROUND MODE to OFF when the DUT is floating electrically.

Steps

1. Press the UTILITY key on the front panel when the tester is in EDIT status. The display will go from the normal EDIT status to the MANU Utility menu for the current test.




```
MANU=***-002 MANU UTILITY
ARC MODE:OFF
PASS HOLD:OFF
FAIL HOLD:OFF
MAX HOLD:OFF
GROUND MODE: ON
```

2. Use the UP/DOWN arrow keys to move the cursor to the GROUND MODE setting.



3. Use the scroll wheel to set the GROUND MODE.



GROUND MODE OFF, ON

4. Press the EDIT/SAVE key to save and exit the MANU Utility menu.

EDIT/SAVE



5. The GROUND MODE icon on the display changes accordingly.

| NAME         | REF#           |
|--------------|----------------|
| = 01 . 00 mA | ARC =          |
| mA           | <b>ED</b>      |
| /= 000 . 1 S | TIMER          |
| GB           | <b>H I / L</b> |

↑  
GROUND  
MODE = OFF

| NAME         | REF#      |
|--------------|-----------|
| = 01 . 00 mA | ARC =     |
| mA           | <b>ED</b> |
| /= 000 . 1 S | TIMER     |
| GB           | <b>77</b> |

↑  
GROUND  
MODE = ON



The ESC key can be pressed at any time in the MANU Utility menu to cancel and exit.

IR and GB tests can only have GROUND MODE set to OFF.

## Saving and Exiting EDIT Status

**Background** After all test parameters have been set, the test can be saved. After a test is saved it can be used when creating an AUTO test.




**Warning**

The special MANU number, 000, can be saved, however it cannot be used for AUTO tests. See page 66 for details.

**Steps**

1. When in EDIT status, press the EDIT/SAVE key to save the current test. This will enter the VIEW status for the chosen test number.

EDIT/SAVE



2. The Status changes from EDIT to VIEW.



**Note**

Pressing the EDIT/SAVE key again will return the tester back to EDIT status for the current test.



## Running a MANU Test

---

**Background** A test can be run when the tester is in READY status.

---



Note

The tester cannot start to run a test under the following conditions:

- A protection setting has been tripped; when a protection setting has been tripped the corresponding error message is displayed on the screen. See page 141 for a comprehensive list of the all the setting errors.
- The INTERLOCK function is ON and the Interlock key is not inserted in the signal I/O port (page 75).
- The STOP signal has been received remotely.

If Double Action is ON, ensure the START button is pressed immediately after the STOP button (<0.5s).

---




Note



When a test is running the voltage output cannot be changed, unless the test is under the special manual mode. See page 66 for details.

---

- Steps**
1. Ensure the tester is in VIEW status Page 56 for the current test. Save the current test if necessary.




2. Press the STOP button to put the tester into the READY status.




3. The READY indicator will be lit blue when in the READY status.



4. Press the START button when the tester is in the READY status. The manual test starts automatically and the tester goes into the TEST status.



5. The TEST indicator will be lit orange when in the TEST status.




6. The test will start by showing the remaining ramp up time, followed by the remaining test time. The test will continue until the test is finished or the test is stopped.




remaining RAMP time  
 remaining TIMER time


ACW Example




DCW Example



IR Example




GB Example



**Stop the Test**


1. To stop the test at any time when it is running, press the STOP button. The test will stop immediately. When the STOP button is pressed, a judgment is not made on the test.



All panel keys except the STOP button are locked when the tester is in STOP status.




2. To put the tester back into READY status, press the STOP button again.



**Exit TEST Status**

To exit testing, press the MANU/AUTO key when the tester is in the READY status. The tester will revert to the VIEW status for the current test.



**Note**

Do not touch any terminals, test leads or any other connections when the test is on.

## PASS / FAIL MANU Test

**Background**                      If the test is allowed to run to completion (the test is not stopped or a protection setting is not tripped) then the tester will judge the test as either PASS or FAIL.




The test will be judged PASS when:

- The HI SET and LO SET limits have not been tripped during the test time.

The test will be judged FAIL when:


- Either the HI SET or LO SET limit has been tripped during the test time.
- A protection setting has been tripped during the test time. See page 141 for a list of error messages.

**PASS Judgment**    1. When the test is judged as PASS, PASS will be displayed, the buzzer will sound and the PASS indicator will be lit green.




2. The PASS judgment will be held on the display until the STOP or START button is pressed.

Pressing the STOP button will return the tester to the READY status.



Pressing the START button will restart the test.



Note


The buzzer will only sound if the Pass Sound is set to ON. See page 72 for details.

The START button is disabled when the buzzer is beeping.


### PASS Timing Diagrams

The timing diagrams below show the ACW, DCW, IR and GB timing for the START status, TEST status and PASS judgment.


#### ACW PASS Timing




#### DCW PASS Timing



**IR PASS Timing**



**GB PASS Timing**



**FAIL Judgment**

1. When the test is judged as FAIL, FAIL will be displayed, the buzzer will sound and the FAIL indicator will be lit red.

FAIL





As soon as a test is judged FAIL, power is cut from the terminals.




2. The FAIL judgment will be held on the display until the STOP button is pressed. Pressing the STOP button will return the tester to the READY status.

STOP



3. The READY indicator will be lit blue in the READY status. READY 




Note

The buzzer will only sound if Fail Sound is set to ON. See page 72 for details.


**FAIL Timing Diagrams**

The timing diagrams below show the ACW, DCW, IR and GB timing for the START status, TEST status and FAIL judgment.

**ACW FAIL Timing**




**DCW FAIL Timing**






**IR FAIL Timing**



**GB FAIL Timing**



## Zeroing of the Test Leads (GB only)


**Background**                      The Zeroing function is used to determine the resistance of the test leads for GB tests. When a zero check is performed, the reference is automatically set to the measured resistance of the test leads.

This function is only available for GB testing.


- Steps**
1. Ensure the tester is in VIEW status Page 56 for the current GB test. Save the current test if necessary.



2. Short the positive and negative alligator clips as shown below.





3. Press the STOP button to put the tester into the READY status.




- The ZERO function can be activated by pressing the corresponding soft-key in the READY status. The ZERO soft-key will be highlighted.



- Press the START button to perform the zero check. The tester will go into the ZERO status.



- When the zero check has finished, the tester will return back to the VIEW status. The resistance of the test leads will be automatically set as the Reference value.



Remember to replace the test leads to the proper position on the DUT before testing.

**I<SET**

If SOURCE H/L terminals are open or poorly connected, then an I<SET error will appear on the screen. Stop the test and re-check the connection again and try again.

I<SET error message

FAIL status




**R = 0**

Stop the test and perform the zero check again.

R = 0 error message

FAIL status




## Special MANU Test Mode (000)


**Background** When MANU number 000 is selected, the special test mode is activated. Under the special test mode, the voltage can be changed during a test, in real time (ACW, DCW only). The test function can also be changed when in READY or VIEW status, unlike under normal operation.

Separate settings can be saved under the special test mode for each of the testing functions: ACW, DCW, IR and GB. This means a different ACW, DCW, IR and GB test setup can be saved for MANU number 000.

- Steps**
1. Choose MANU number 000 to enter the special test mode. Page 36
  2. Set all the necessary parameters for a test and save. A different test setup can be saved for each test function (ACW, DCW, IR and GB). Pages 37~56




The TIMER settings can be set OFF when in the special test mode for ACW and DCW tests.

3. The settings of a different test function can be loaded by pressing the corresponding soft-key in the VIEW or READY status. 
 Example: ACW

4. Run a manual test for the special test mode (000). The test is started and stopped in the same way as for the normal manual test mode. Page 57

5. Use the scroll wheel to set the voltage level in real-time as the test is running (this does not apply to IR or GB tests).



|     |               |
|-----|---------------|
| ACW | 0.100kV ~ 5kV |
| DCW | 0.100kV ~ 6kV |

## Common Utility Settings

The Common Utility settings are system-wide settings that apply to both MANU tests and AUTO tests.


The Common Utility menu includes the following settings:

- LCD settings → from page 71.
- Buzzer Settings → from page 72.
- Interface Settings → from page 73.
- Control settings → from page 75.

### LCD Settings

**Description**                      The LCD settings include contrast and brightness controls.

- Steps**
1. Ensure the tester is in VIEW status. Page 56  
Save the current test if necessary.





2. Press the UTILITY key.




3. Press the LCD soft-key to bring up the LCD Common Utility menu.




4. Use the UP/DOWN arrow keys to choose a menu item: LCD Contrast, LCD Brightness.
 

  

  
5. Use the scroll wheel to select a parameter for the chosen menu item.
 



LCD Contrast      1(low) ~ 8(high)

LCD Brightness    BRIGHT, DARK
  
6. Press EDIT/SAVE to save the settings and exit to VIEW status.
 






Note

The ESC key can be pressed at any time to cancel and exit back to VIEW status.


## Buzzer Settings

**Description**      The Buzzer settings allow you to set whether the buzzer will sound for PASS/FAIL judgments. The buzzer time can also be set for the PASS/FAIL judgments. The buzzer settings are system-wide.

- Steps**
1. Ensure the tester is in VIEW status. Page 56  
Save the current test if necessary.



2. Press the UTILITY key.
 







3. Press the BUZZ soft-key to bring up the Buzzer Common Utility menu.



4. Use the UP/DOWN arrow keys to choose a menu item: Pass Sound or Fail Sound.



5. Use the scroll wheel to select a parameter for the chosen menu item.



|            |                         |
|------------|-------------------------|
| Pass Sound | ON (000.2s~999.9s), OFF |
| Fail Sound | ON (000.2s~999.9s), OFF |

6. Press EDIT/SAVE to save the settings and exit to the VIEW status.



Note

When in automatic tests, the Pass Sound and Fail Sound settings only apply to the overall PASS/FAIL of the *overall automatic test*, not each test step that make up the automatic tests.



Note

The ESC key can be pressed at any time to cancel and exit back to VIEW status.


## Interface Settings

Description

The interface settings choose the remote interface configuration. USB, RS232 and GPIB (optional) can be selected.

Steps

1. Ensure the tester is in VIEW status. Page 56  
Save the current test if necessary.




2. Press the UTILITY key.




3. Press the INTER soft-key to bring up the Interface Common Utility menu.




4. Use the scroll wheel to select USB, RS232 or GPIB.



5. For RS232 or GPIB, use the UP/DOWN arrow keys to choose Baud or Address.



6. Use the scroll wheel to select the baud rate or GPIB address.



|              |                                      |
|--------------|--------------------------------------|
| Baud         | 9600, 19200, 38400, 57600,<br>115200 |
| GPIB address | 0~30                                 |

7. Press EDIT/SAVE to save the settings and exit to VIEW status.

EDIT/SAVE



Note

Ensure the baud rate settings or GPIB address matches the host machine.



Note

The ESC key can be pressed at any time to cancel and exit back to VIEW status.

## Control Settings

---

### Description

The Control settings are accessed in the COMMON UTILITY menu. The Control settings include: Start Control, Double Action, Key Lock and Interlock.

Start Control is used to determine how a test is started. Tests can be started via the front panel (START/STOP buttons), from a remote controller or via the SIGNAL I/O port.


The Double Action function is a safety feature used to prevent accidentally starting a test. Normally to start a test, the START button is pressed when the tester is in the READY status. To start a test when Double Action is ON, the STOP button must first be pressed, followed by the START button within 500ms.

Key Lock disables the front panel keys from changing the test number, mode or testing parameters. Only the Utility menu and any keys required for testing are not disabled.

The Interlock function is a safety feature. The interlock function prevents a test from running, unless the interlock pins on the signal I/O port connector are shorted. The included interlock key can be used for this purpose. See page 100 for details.

Steps

1. Ensure the tester is in VIEW status. Page 56  
Save the current test if necessary.



2. Press the UTILITY key.




3. Press the CTRL soft-key to bring up the Control Common Utility menu.



4. Use the UP/DOWN arrow keys to choose a menu item: Start Ctrl, Double Action, Key Lock or INTERLOCK.



5. Use the scroll wheel to select setting for the chosen menu item.



|               |                                           |
|---------------|-------------------------------------------|
| Start Ctrl    | FRONT PANEL, REMOTE<br>CONNECT, SIGNAL IO |
| Double Action | ON, OFF                                   |
| Key Lock      | ON, OFF                                   |
| INTERLOCK     | ON, OFF                                   |

6. Press EDIT/SAVE to save the settings.

EDIT/SAVE



Note


The Double Action setting is ignored when the GPT-9000 is being controlled remotely using the USB, RS232 or GPIB interfaces.



Note

If a test is started with INTERLOCK ON, but the interlock signal I/O pins are not shorted (either with the included interlock key or manually), the INTERLOCK OPEN message will be displayed, preventing the test from starting.

Interlock open message



## Automatic Tests

This section describes how to create, edit and run automatic tests. Automatic tests allow you to link together up to 16 different MANU tests and run them sequentially. Each stored MANU test is used as a test step when creating an AUTO test.

- Choose/Recall an Automatic Test → from page 78
- Edit Automatic Test Settings → from page 80
- Adding a Step to the Automatic Test → from page 81
- Creating an AUTO Test File Name → from page 82
- Saving and Exiting EDIT Status → from page 83
- Automatic Test Page View → from page 84
- Running an Automatic Test → from page 87
- Automatic Test Results → from page 91

Before operating the GPT-9000 please read the safety precautions as outlined in the Set Up chapter on page 20.

### Choose/Recall an Automatic Test

---

**Background**                      The tester must first be put into AUTO mode to create or run automatic tests.

---


Up to 100 automatic tests can saved/recalled.

- Steps**
1. If the tester is in MANU mode, press and hold the MANU/AUTO key for three seconds. This will put the tester into Auto mode.

MANU/AUTO




The tester can only switch between AUTO and MANU mode when in the VIEW status.




Note

If the chosen automatic test has not yet been setup, then the screen will be blank except for the status and mode.




2. Use the scroll wheel to choose the AUTO number.



AUTO # 001~100

AUTO number



Note


The AUTO number can only be chosen in VIEW status. If in the EDIT status, switch to the VIEW status by pressing the EDIT/SAVE or ESC key.

## Edit Automatic Test Settings

**Background** To edit an automatic test, the tester must be in EDIT status.

Any settings or parameters that are edited only apply to the currently selected AUTO number.

**Steps**

1. Press the EDIT/SAVE key when in VIEW status to enter the EDIT status. This will enter the EDIT status for the chosen AUTO number. 



2. The Status changes from VIEW to EDIT. The tester is now ready to edit the current AUTO test.


 **Note**


Pressing the EDIT/SAVE key again will save the settings or pressing the ESC will cancel the settings for the current AUTO test and return back to VIEW status.




## Adding a Step to the Automatic Test



**Background** Up to 16 MANU tests (steps) can be added to an automatic (AUTO) test. Each step is added in a sequential order.

- Steps**
1. Press the DOWN arrow keys to bring the cursor to the MANU number. 



2. Use the scroll wheel to choose a MANU number to add to the automatic test. 


MANU number 001~100

3. Press the ADD soft-key to add the selected manual test to the automatic test as another step.   


4. Repeat steps 2 and 3 for any other tests that you wish to add to the automatic test.

 **Note**

After 16 steps have been added to an AUTO test, FULL will be shown on the display when you attempt to add another step to the AUTO test.





Note

The test order can be edited in the Page View menu after the AUTO test is saved. See page 84 for details.

## Creating an AUTO Test File Name

### Background


Each automatic test can have a user-defined test file name (Default: AUTO\_NAME) up to 10 characters long. See the character list below for the allowed characters.

#### Character List


|   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|---|
| 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |   |
| A | B | C | D | E | F | G | H | I | J | K | L | M | N | O | P | Q | R | S | T | U | V | W | X | Y | Z |
| a | b | c | d | e | f | g | h | i | j | k | l | m | n | o | p | q | r | s | t | u | v | w | x | y | z |
| + | - | * | / | _ | = | : | Ω | ? | ( | ) | < | > | [ | ] |   |   |   |   |   |   |   |   |   |   |   |

### Steps

1. Use the UP/DOWN arrow keys to bring the cursor to the AUTO number. A small cursor will also appear under the first character of the AUTO test file name. This is initially set as AAUTO\_NAME



2. Use the scroll wheel to scroll through the available characters.



3. Press the LEFT/RIGHT arrow keys to go to the next character.



- The AUTO test file name is set when the current AUTO test is saved or when the cursor is moved to another setting.



Note

To cancel the name changes, press the ESC key before the cursor is moved to another setting or the name is saved.

## Saving and Exiting EDIT Status


### Background

After all test steps have been added to an automatic test, the automatic test can be saved.

### Steps

- When in EDIT status, press the EDIT/SAVE key to save the automatic test. After the test is saved the tester will revert back to VIEW status.

EDIT/SAVE



- The status changes from EDIT to VIEW.




Note

Pressing the EDIT/SAVE key again will return the tester back to EDIT status for the selected AUTO test.

## Automatic Test Page View


**Background** Pressing the PAGE key will show an overview of the tests for the currently selected automatic test when in the VIEW status. The Page View will show the order of the AUTO test steps as well as the manual file name, function, test voltage and HI/LO SET limits.

- Steps**
1. Ensure the tester has had an automatic test saved and the tester is in AUTO mode/VIEW status. Page 78



2. Press the PAGE key to bring up the Page view of the AUTO test.

All the test steps are shown on the bottom of the screen along with the corresponding MANU numbers. The top of the screen shows the selected MANU test file name and the settings (test function, test voltage, HI/LO SET).



**Editing**

When in the Page View, the automatic test steps can be edited. Steps can be deleted, skipped, moved or swapped.

**Moving a Step**

1. Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the test step you wish to move.



2. Press the MOVE soft-key.



3. Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the destination step.



4. Press the MOVE soft-key again. The manual test will be moved to the destination step. The remaining steps will move up/down to fill the empty step.



```

AUTO=001-010 AUTO_NAME
MANU_NAME ACW=0.100kV HI_SET=01.00mA
← #01:010 ← #02:001 ← #03:003 ← #04:004
#05:007 #06:003 #07:038 #08:005
#09: #10: #11: #12:
#13: #14: #15: #16:
MOVE SWAP SKIP DEL

```

Swapping Two Steps

1. Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the test step you wish to swap.
2. Press the SWAP soft-key.
3. Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the second step.
4. Press the SWAP soft-key again. The tests will be swapped with each other.



```
AUTO=001-010 AUTO_NAME
MANU_NAME ACW=0.100kV HI_SET=01.00mA
#01: 010 *001 #03:003 #04:004
#05:007 #06:003 #07:038 #08:005
#09: #10: #11: #12:
#13: #14: #15: #16:
MOVE SWAP SKIP DEL
```

Skip a Test Step





1. Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the test step you wish to skip.
2. Press the SKIP soft-key.
3. The step will have an asterisk beside the MANU number.



```
AUTO=001-010 AUTO_NAME
MANU_NAME ACW=0.100kV HI_SET=01.00mA
#01: 010 *001 #03:003 #04:004
#05:007 #06:003 #07:038 #08:005
#09: #10: #11: #12:
#13: #14: #15: #16:
MOVE SWAP SKIP DEL
```



The next time the automatic test is run, the steps with asterisks will be skipped.

|                           |                                                                                                                                |                                                                                   |
|---------------------------|--------------------------------------------------------------------------------------------------------------------------------|-----------------------------------------------------------------------------------|
| Delete a Test Step        | <p>1. Use the UP/DOWN and LEFT/RIGHT arrow keys to move the cursor to the test step you wish to delete.</p>                    |  |
|                           | <p>2. Press the DEL soft-key.</p>                                                                                              |  |
|                           | <p>3. The step will be deleted.</p>                                                                                            |                                                                                   |
| Save Changes and Exit     | <p>To save the changes made in Page View, press the EDIT/SAVE key. You will be returned back to AUTO mode/VIEW status.</p>     |  |
| Cancel and Exit Page View | <p>To cancel any changes and to exit the Page View, press the ESC key. You will be returned back to AUTO mode/VIEW status.</p> |  |

## Running an Automatic Test

|            |                                                                 |
|------------|-----------------------------------------------------------------|
| Background | An automatic test can be run when the tester is in VIEW status. |
|------------|-----------------------------------------------------------------|



Note

The tester cannot start to run an AUTO test under the following conditions:

- Any protection modes have been tripped.
- The INTERLOCK function is ON and the Interlock key is not inserted in the signal I/O port (page 100).
- The STOP signal has been received remotely.

If Double Action is ON, ensure the START

button is pressed immediately after the STOP button (<0.5s).




Warning



Do not touch any terminals, test leads or the DUT when a test is running.

Steps

1. Ensure the tester is in VIEW status. Page 78  
Save the automatic test if necessary.




2. Press the STOP button to put the tester into the READY status.




3. The READY indicator will be lit blue when in the READY status.





4. Press the START button when the tester is in the READY status. The AUTO test starts automatically and the display changes to TEST status.








5. The TEST indicator will be lit orange when in the TEST status. 
6. Each test will start by showing the remaining ramp up time, followed by the remaining test time. Each test will be tested in sequence until the last test has finished or the test is stopped.




remaining RAMP time   
 remaining TIMER time 

- PASS/FAIL HOLD 1. If Pass Hold or Fail Hold is set to ON for a manual test, then the tester will “hold” the testing after a Pass/Fail result for that particular test. See page 48, 50 for details.




2. The PASS or FAIL indicator will also be lit. The buzzer will NOT sound.   


3. To continue to the next test after HOLD is displayed on-screen, press the START button.




- To stop the test when HOLD is displayed on-screen, press the STOP button.



When in HOLD status, only the START and STOP buttons can be pressed, all other keys are disabled.

**Stop a Running Test**

- To stop the AUTO test at any time when it is running, press the STOP button. The AUTO test will stop immediately. When the STOP button is pressed, a judgment is not made on the current test and any remaining tests are aborted.




All panel keys except the STOP and START buttons are locked when the tester has been stopped. All the results up until when the AUTO test was stopped are shown on-screen. See page 91 for more details on automatic test results.

```
AUTO=001-*** AUTO_NAME
#01: FAIL #02: PASS #03: STOP #04: ---
#05: --- #06: --- #07: --- #08: ---
#09: #10: #11: #12:
#13: #14: #15: #16:
```

Example of an automatic test that has been stopped. Dashes (-) indicate aborted test steps.


- To put the tester back into READY status, press the STOP button again.



Exit Testing

To exit testing, press the MANU/AUTO key when the tester is in the READY status. The tester will revert to the VIEW status for the current automatic test.

MANU/AUTO




Automatic Test Results

Background

If all the test steps are allowed to run to completion (the AUTO test is not stopped or a protection setting is not tripped) then the tester will judge each step as either PASS or FAIL. This is shown as a table after the automatic test has finished running.

Overview



The PASS/FAIL judgment for an automatic test depends on the results of all the steps (manual tests) that compose the automatic test:

- Each step must be passed for a PASS judgment (excluding skipped tests).
- A FAIL result for a single step will result in FAIL for the whole automatic test.

**PASS Judgment**

When all the tests have been judged as PASS, the PASS indicator will be lit green and the buzzer will sound.

PASS



```
AUTO=001-*** AUTO_NAME
#01: PASS #02: PASS #03: PASS #04: PASS
#05: PASS #06: PASS #07: PASS #08: PASS
#09: #10: #11: #12:
#13: #14: #15: #16:
```



Note

The Pass Sound setting must to set to ON for the buzzer to sound (page 72).

**FAIL Judgment**

When any of the tests have been judged as FAIL, the FAIL indicator will be lit red and the buzzer will sound.

FAIL



```
AUTO=001-*** AUTO_NAME
#01: PASS #02: PASS #03: PASS #04: PASS
#05: PASS #06: FAIL #07: FAIL #08: PASS
#09: #10: #11: #12:
#13: #14: #15: #16:
```




Note

The Fail Sound setting must to set to ON for the buzzer to sound (page 72).

**View Results**

1. When the PASS or FAIL overview table is shown on the screen, turn the scroll wheel right to scroll through each test step.




step number                      MANU number for current step

```
STEP: 02-003 MANU_NAME REF#=00.00mA
FREQ= 60Hz HI SET=01.00mA ARC= OFF
0.100 kV 00.37 mA PASS
RAMP/=000.0S TIME↑003.2S
ACW DCW IR GB 77
```


PASS/FAIL result

2. Turn the scroll wheel left to return back to the overview table.



**Return to Ready Status**


1. The PASS/FAIL results will be held on the screen until the STOP button is pressed.
2. To put the tester back into READY status, press the STOP button (twice for a fail result).



3. The READY indicator will be lit blue in the READY status.




READY status




**Exit Testing**


To exit testing, press the MANU/AUTO key when the tester is in the READY status. The tester will revert to The VIEW status.



**PASS Timing Diagram**



**FAIL Timing Diagram**



# E XTERNAL CONTROL

The External Control chapter covers the  
REMOTE terminal and the SIGNAL I/O port.

---

|                                                |           |
|------------------------------------------------|-----------|
| <b>External Control Overview .....</b>         | <b>96</b> |
| Remote Terminal Overview .....                 | 96        |
| Remote Controller Operation .....              | 96        |
| SIGNAL I/O Overview .....                      | 97        |
| Using the SIGNAL I/O to Start/Stop Tests ..... | 99        |
| Using the Interlock Key .....                  | 100       |

## External Control Overview

The External Control section describes the front panel REMOTE terminal connection and the rear panel SIGNAL I/O port.

### Remote Terminal Overview

---


**Overview** The REMOTE terminal connector is a standard 5-pin DIN terminal suitable for a remote controller.



**WARNING**

Keep any cables that are connected to the REMOTE terminal away from the HIGH VOLTAGE and RETURN terminals.

**Pin Assignment and Connection**



| Pin name  | Pin | Description         |
|-----------|-----|---------------------|
| RMT_STOP  | 1   | Remote Stop signal  |
| RMT_START | 2   | Remote Start signal |
| COM       | 3   | Common line         |
| Not used  | 4   |                     |
| Not used  | 5   |                     |

### Remote Controller Operation

---

**Description** The GPT-9000 accepts external remote controllers with a START and STOP button. To use the REMOTE terminal, the GPT-9000 must first be configured to accept a remote controller.

Operating a remote controller is the same as




---

operating the START and STOP buttons on the front panel.

---

**Steps**

1. Turn off the power.
2. Insert the lead of remote controller into the REMOTE terminal.  

3. Turn on the power to the tester.
4. Configure the Start Ctrl option to REMOTE CONNECT in the Common Utility menu. [Page 75](#)
5. The tester will now only be able to start a test using a remote controller.
6. To return the operation control to the front panel, configure the Start Ctrl option to FRONT PANEL. [Page 75](#)

## SIGNAL I/O Overview

---


**Overview**

The SIGNAL I/O port can be used to remotely start/stop tests and monitor the test status of the instrument. The SIGNAL I/O port is also used for the interlock function (page 75).

The SIGNAL I/O port uses a DB-9 pin female connector.


---

Pin Assignment




| Pin name    | Pin | Description                                    |
|-------------|-----|------------------------------------------------|
| INTERLOCK1  | 1   | When INTERLOCK is ON, a test is only allowed   |
| INTERLOCK2  | 2   | to start when both INTERLOCK pins are shorted. |
| INPUT_COM   | 3   | Common input line                              |
| INPUT_START | 4   | Start signal input                             |
| INPUT_STOP  | 5   | Stop signal input                              |
| OUTPUT_TEST | 6   | Indicates that a test is in progress           |
| OUTPUT_FAIL | 7   | Indicates that a test has failed               |
| OUTPUT_PASS | 8   | Indicates that a test has passed               |
| OUTPUT_COM  | 9   | Common output line                             |


Interlock connection



Input Connection



Output Connection



Signal Properties

| Input Signals            |                 |
|--------------------------|-----------------|
| High level input voltage | 5V ~ 32V        |
| Low level input voltage  | 0V ~ 1V         |
| Low level input current  | Maximum of -5mA |
| Input period             | Minimum of 1ms  |
| Output Signals           |                 |
| Output Type              | Relay form A    |
| Output Rated Voltage     | 30VDC           |
| Maximum output current   | 0.5A            |

## Using the SIGNAL I/O to Start/Stop Tests

---

|            |                                                                                                             |
|------------|-------------------------------------------------------------------------------------------------------------|
| Background | To use the SIGNAL I/O port the Start Ctrl settings have to be set to SIGNAL I/O in the Common Utility menu. |
|------------|-------------------------------------------------------------------------------------------------------------|

---

- |                 |                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                                           |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Panel operation | <ol style="list-style-type: none"><li>1. Set the Start Ctrl option to SIGNAL Page 75 I/O.</li><li>2. Turn off the power.</li><li>3. Connect the Input/Output signals to the SIGNAL I/O port.</li><li>4. Turn the tester back on.</li><li>5. To start the testing, short the INPUT_STOP and INPUT_COM line for a minimum of 1ms to put the tester into READY status.</li><li>6. To start the testing, short the INPUT_START and INPUT_COM lines for a minimum of 1ms.</li><li>7. To stop the testing, temporarily short the INPUT_STOP and INPUT_COM line again.</li></ol> |
|-----------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|


## Using the Interlock Key

---

**Background** When the INTERLOCK function is set to ON, tests are only allowed to start when both Interlock pins on the signal I/O port are shorted. Using the Interlock key will short the INTERLOCK1 and INTERLOCK2 pins on the signal I/O port.

---

**Panel operation** 1. Insert the Interlock key into the SIGNAL I/O port on the rear panel.



2. Set the INTERLOCK option to ON Page 75 in the Common Utility.

---



With INTERLOCK set to ON, the tester can now only start a test when the Interlock key is connected.

Set INTERLOCK to OFF to disable this feature.

---

# RREMOTE CONTROL

This chapter describes basic configuration of IEEE488.2 based remote control. The remote interface supports USB, RS232 and GPIB.

---

|                               |     |
|-------------------------------|-----|
| Interface Configuration ..... | 102 |
| Command Syntax .....          | 106 |
| Command List .....            | 109 |
| Error Messages .....          | 136 |

## Interface Configuration

### USB Remote Interface

|                   |                         |                                   |
|-------------------|-------------------------|-----------------------------------|
| USB Configuration | PC side connector       | Type A, host                      |
|                   | GPT-9000 side connector | Rear panel Type A                 |
|                   | USB Class               | CDC (communications device class) |

- Panel operation
1. Connect the USB cable to the rear panel USB A port.
  2. Set the interface to USB from the Common Utility menu.




Page 73

### RS232 Remote Interface

|                     |              |                                   |
|---------------------|--------------|-----------------------------------|
| RS232 Configuration | Connection   | Null modem cable                  |
|                     | Baud rate    | 9600, 19200, 38400, 57600, 115200 |
|                     | Parity       | None                              |
|                     | Data bits    | 8                                 |
|                     | Stop bit     | 1                                 |
|                     | Flow control | None                              |

Pin Assignment




- 1: No connection
- 2: RxD (Receive Data)
- 3: TxD (Transmit Data)
- 4: No connection
- 5: GND
- 6-9: No connection

| Connection | PC      |        | GPT-9000 |        |
|------------|---------|--------|----------|--------|
|            | DB9 Pin | Signal | Signal   | DB9Pin |
|            | 2       | RxD    | TxD      | 3      |
|            | 3       | TxD    | RxD      | 2      |
|            | 5       | GND    | GND      | 5      |

Panel operation

1. Connect the Null modem cable to the rear panel RS232 port.



2. Set the interface to RS232 from the [Page 73 Common Utility menu](#).

## GPIB Remote Interface

GPIB Configuration      Address      0-30

Panel operation

1. Connect the GPIB cable to the rear panel GPIB port.



2. Set the interface to GPIB and set the GPIB address from the [Page 73 Common Utility menu](#).

## USB/RS232 Remote Control Function Check

---

Functionality  
check

Invoke a terminal application such as Hyper Terminal.

To check the COM port No, see the Device Manager in the PC. For WinXP; Control panel → System → Hardware tab.

---

Run this query command via the terminal after the instrument has been configured for USB or RS232 remote control (page 102, 102).

\*idn?

This should return the Model number, Serial number, and Firmware version in the following format:

GPT-9803, XXXXXXXXXXXXX, V1.00

Model number : GPT-9803


Serial number :12 character serial number

Firmware version : V1.00

- ^j can be used as the terminal character when entering the queries/commands from a terminal application.
-



**Display** When the panel is being remotely controlled via the USB, RS232 or GPIB interfaces, RMT will be displayed on the screen.



## Return to Panel Control


---

**Background** When the instrument is remotely controlled all panel keys except the STOP button are disabled.

---

**Steps**

1. When RMT is on the display, press the STOP button. The panel goes to the READY status.




2. From the READY status the tester can go into one of two states: TEST or VIEW.

- To put the tester into VIEW status, press the MANU/AUTO key.



- To put the tester in TEST status, press the START button. This will start the manual test/automatic test. For more details on running a manual test or automatic test, see pages 57 and 87, respectively.



Note

To put the tester back to RMT, simply issue another remote control command.


---

## Command Syntax

|                     |            |                       |
|---------------------|------------|-----------------------|
| Compatible Standard | IEEE488.2  | Partial compatibility |
|                     | SCPI, 1999 | Partial compatibility |

**Command Structure** SCPI commands follow a tree-like structure, organized into nodes. Each level of the command tree is a node. Each keyword in an SCPI command represents each node in the command tree. Each keyword (node) of an SCPI command is separated by a colon (:).

For example, the diagram below shows an SCPI sub-structure and a command example.



**Command types** There are a number of different instrument commands and queries. A command sends instructions or data to the unit and a query receives data or status information from the unit.

### Command types

**Simple** A single command with/without a parameter

**Example** \*IDN?

**Query**                      A query is a simple or compound command followed by a question mark (?). A parameter (data) is returned.

**Example**                      MANU:ACW:VOLTage?

**Command Forms**            Commands and queries have two different forms, long and short. The command syntax is written with the short form of the command in capitals and the remainder (long form) in lower case.


The commands can be written in capitals or lower-case, just so long as the short or long forms are complete. An incomplete command will not be recognized.

Below are examples of correctly written commands.

**Long form**                      SYSTem:BUZZer:KEYSound  
 SYSTEM:BUZZER:KEYSOUND  
 system:buzzer:keysound

**Short form**                      SYST:BUZZ:KEYS  
 syst:buzz:keys

**Command Format**



**Parameters**

| Type      | Description     | Example        |
|-----------|-----------------|----------------|
| <Boolean> | Boolean logic   | 0, 1           |
| <NR1>     | integers        | 0, 1, 2, 3     |
| <NR2>     | decimal numbers | 0.1, 3.14, 8.5 |

|                       |          |                                  |                 |
|-----------------------|----------|----------------------------------|-----------------|
|                       | <NR3>    | floating point                   | 4.5e-1, 8.25e+1 |
|                       | <NRf>    | any of NR1, 2, 3                 | 1, 1.5, 4.5e-1  |
|                       | <string> | ASCII text<br>string             | TEST_NAME       |
| Message<br>Terminator | CR, LF   | Carriage Return + Line feed code |                 |

---

## Command List

---

|          |                             |     |
|----------|-----------------------------|-----|
| System   | SYSTem:LCD:CONTRast .....   | 111 |
| Commands | SYSTem:LCD:BRIGHtness ..... | 111 |
|          | SYSTem:BUZZer:PSOUND .....  | 112 |
|          | SYSTem:BUZZer:FSOUND .....  | 112 |
|          | SYSTem:BUZZer:PTIME .....   | 112 |
|          | SYSTem:BUZZer:FTIME .....   | 113 |
|          | SYSTem:ERRor .....          | 113 |
| Function | FUNCTion:TEST .....         | 114 |
| Commands | MEASure<x> .....            | 115 |
|          | MAIN:FUNCTion .....         | 115 |
| Manual   | MANU:STEP .....             | 117 |
| Commands | MANU:NAME .....             | 117 |
|          | MANU:RTIME .....            | 117 |
|          | MANU:EDIT:MODE .....        | 118 |
|          | MANU:ACW:VOLTage .....      | 118 |
|          | MANU:ACW:CHISet .....       | 119 |
|          | MANU:ACW:CLOSet .....       | 119 |
|          | MANU:ACW:TTIME .....        | 120 |
|          | MANU:ACW:FREQuency .....    | 121 |
|          | MANU:ACW:REF .....          | 121 |
|          | MANU:ACW:ARCCurrent .....   | 122 |
|          | MANU:DCW:VOLTage .....      | 122 |
|          | MANU:DCW:CHISet .....       | 123 |
|          | MANU:DCW:CLOSet .....       | 123 |
|          | MANU:DCW:TTIME .....        | 124 |
|          | MANU:DCW:REF .....          | 124 |
|          | MANU:DCW:ARCCurrent .....   | 125 |
|          | MANU:IR:VOLTage .....       | 125 |
|          | MANU:IR:RHISet .....        | 126 |
|          | MANU:IR:RLOSet .....        | 126 |
|          | MANU:IR:TTIME .....         | 127 |

|               |                              |     |
|---------------|------------------------------|-----|
|               | MANU:IR:REF .....            | 127 |
|               | MANU:GB:CURRent .....        | 127 |
|               | MANU:GB:RHISet .....         | 128 |
|               | MANU:GB:RLOSet .....         | 128 |
|               | MANU:GB:TTime .....          | 129 |
|               | MANU:GB:FREQuency .....      | 129 |
|               | MANU:GB:REF.....             | 130 |
|               | MANU:GB:ZEROCHECK.....       | 130 |
|               | MANU:UTILity:ARCMODE.....    | 131 |
|               | MANU:UTILity:PASShold.....   | 131 |
|               | MANU:UTILity:FAILhold .....  | 131 |
|               | MANU:UTILity:MAXHold.....    | 132 |
|               | MANU:UTILity:GROUNDMODE..... | 132 |
|               | MANU<x>:EDIT:SHOW .....      | 132 |
| <br>          |                              |     |
| Auto Commands | AUTO:STEP .....              | 133 |
|               | AUTO<x>:PAGE:SHOW .....      | 134 |
|               | AUTO:NAME .....              | 134 |
|               | TESTok:RETurn.....           | 135 |
| <br>          |                              |     |
| Common        | *CLS.....                    | 135 |
| Commands      | *IDN .....                   | 135 |

## System Commands

|                             |     |
|-----------------------------|-----|
| SYSTem:LCD:CONTRast .....   | 111 |
| SYSTem:LCD:BRIGhtness ..... | 111 |
| SYSTem:BUZZer:PSOUND.....   | 112 |
| SYSTem:BUZZer:FSOUND.....   | 112 |
| SYSTem:BUZZer:PTIME.....    | 112 |
| SYSTem:BUZZer:FTIME.....    | 113 |
| SYSTem:ERRor .....          | 113 |

### SYSTem:LCD:CONTRast Set → → Query

|                                |                                                                  |
|--------------------------------|------------------------------------------------------------------|
| Description                    | Sets the contrast of the LCD display from 1 (low) to 8 (bright). |
| Syntax                         | SYSTem:LCD:CONTRast <NR1>                                        |
| Query Syntax                   | SYSTem:LCD:CONTRast?                                             |
| Parameter/<br>Return parameter | <NR1> 1~8                                                        |
| Example                        | SYST:LCD:CONT 5<br>Sets the display contrast to 5.               |

### SYSTem:LCD:BRIGhtness Set → → Query

|                                |                                                                   |
|--------------------------------|-------------------------------------------------------------------|
| Description                    | Sets the brightness of the LCD display from 1(dark) to 2(bright). |
| Syntax                         | SYSTem:LCD:BRIGhtness <NR1>                                       |
| Query Syntax                   | SYSTem:LCD:BRIGhtness?                                            |
| Parameter/<br>Return parameter | <NR1> 1 (dark), 2 (bright)                                        |
| Example                        | SYST:LCD:BRIG 2<br>Sets the display brightness to bright.         |

**SYSTEM:BUZZer:PSOUND** (Set) →  
→ (Query)

|                                |                                                                      |                 |
|--------------------------------|----------------------------------------------------------------------|-----------------|
| Description                    | Turns the buzzer sound on or off for a PASS judgment.                |                 |
| Syntax                         | SYSTEM:BUZZer:PSOUND{ON OFF}                                         |                 |
| Query Syntax                   | SYSTEM:BUZZer:PSOUND ?                                               |                 |
| Parameter/<br>Return parameter | ON                                                                   | PASS Sound on.  |
|                                | OFF                                                                  | PASS Sound off. |
| Example                        | SYST:BUZZ:PSOUND ON<br>Turns the buzzer sound on for PASS judgments. |                 |

**SYSTEM:BUZZer:FSOUND** (Set) →  
→ (Query)

|                                |                                                                      |                 |
|--------------------------------|----------------------------------------------------------------------|-----------------|
| Description                    | Turns the buzzer sound on or off for a FAIL judgment.                |                 |
| Syntax                         | SYSTEM:BUZZer:FSOUND{ON OFF}                                         |                 |
| Query Syntax                   | SYSTEM:BUZZer:FSOUND ?                                               |                 |
| Parameter/<br>Return parameter | ON                                                                   | FAIL Sound on.  |
|                                | OFF                                                                  | FAIL Sound off. |
| Example                        | SYST:BUZZ:FSOUND ON<br>Turns the buzzer sound on for FAIL judgments. |                 |

**SYSTEM:BUZZer:PTIME** (Set) →  
→ (Query)

|                                |                                                                      |           |
|--------------------------------|----------------------------------------------------------------------|-----------|
| Description                    | Sets the PASS sound duration in seconds.                             |           |
| Syntax                         | SYSTEM:BUZZer:PTIME <NR2>                                            |           |
| Query Syntax                   | SYSTEM:BUZZer:PTIME?                                                 |           |
| Parameter/<br>Return parameter | <NR2>                                                                | 0.2~999.9 |
| Example                        | SYST:BUZZ:PTIM 1<br>Sets the buzzer to 1 second for a PASS judgment. |           |



**SYSTem:BUZZer:FTIME** (Set) →  
→ (Query)

|                                |                                                                      |
|--------------------------------|----------------------------------------------------------------------|
| Description                    | Sets the FAIL Sound duration in seconds.                             |
| Syntax                         | SYSTem:BUZZer:FTIME <NR2>                                            |
| Query Syntax                   | SYSTem:BUZZer:FTIME?                                                 |
| Parameter/<br>Return parameter | <NR2> 0.2~999.9                                                      |
| Example                        | SYST:BUZZ:FTIM 1<br>Sets the buzzer to 1 second for a FAIL judgment. |

**SYSTem:ERRor** → (Query)

|                  |                                                                                              |
|------------------|----------------------------------------------------------------------------------------------|
| Description      | Returns any errors in the output buffer. See page 136 for a list of all the possible errors. |
| Query Syntax     | SYSTem:ERRor ?                                                                               |
| Return parameter | <string> Returns an error string.                                                            |
| Example          | SYST:ERR ?<br>>Value Error!<br>Returns "Value Error!" as the error message.                  |


**SYSTem:GPIB:VERSion** → (Query)

|                  |                                                                                                                                                    |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------|
| Description      | Queries the GPIB version.                                                                                                                          |
| Query Syntax     | SYSTem:GPIB:VERSion?                                                                                                                               |
| Return parameter | <string> Returns:<br>The GPIB version as a string<br>"GPIB,V1.00"<br>or<br>"No GPIB connected" if there is not a GPIB device configured/connected. |
| Query Example    | SYST:GPIB:VERS?<br>>GPIB,V1.00<br>Returns the GPIB version.                                                                                        |

## Function Commands

|                    |     |
|--------------------|-----|
| FUNCTION:TEST..... | 114 |
| MEASure<x> .....   | 115 |
| MAIN:FUNCTION..... | 115 |

### FUNCTION:TEST



**Description**            Turns the currently selected test (output) on or off.

When HOLD is displayed on the screen during AUTO tests, use the FUNCTION:TEST command to move on to the next step.

Setting the FUNCTION:TEST command to OFF at the end of a test will also temporarily turn the PASS/FAIL buzzer sound off.

**Syntax**                    FUNCTION:TEST {ON|OFF}

**Query Syntax**            FUNCTION:TEST?

|                  |     |                     |
|------------------|-----|---------------------|
| <b>Parameter</b> | ON  | Turns the test on.  |
|                  | OFF | Turns the test off. |

|                         |          |              |
|-------------------------|----------|--------------|
| <b>Return parameter</b> | TEST ON  | Test is on.  |
|                         | TEST OFF | Test is off. |

**Example**                    FUNC:TEST ON  
                                  Turns the output on.

**MEASure<x>**

→ Query

**Description** Returns the test parameters & results of the GPT-9000 in either MANU or AUTO mode.

MANU mode: Returns the test parameters & results of a MANU test.

AUTO mode: Returns the test parameters & results of the selected step (1-16) of the AUTO test.

Return parameters: function, judgment/status, test voltage, test current/resistance.

**Query Syntax** MEASure<x>?

**Return parameter (MANU mode)** No parameter needed for MANU mode.

**Return parameter (AUTO mode)** <x> <NR1>1~16. Step number.

**Return parameter <string>** Returns the test status of the test.

**Example (in MANU mode)** MEAS?  
>IR, FAIL, 0.046kV, 9999M  
Returns the current manual test result.

**Example (in AUTO mode)** MEAS10?  
>IR, FAIL, 0.046kV, 9999M  
Returns step 10 of the current automatic result.

Set →

**MAIN:FUNction**

→ Query

**Description** Changes the mode between AUTO and MANU.

**Syntax** MAIN:FUNction {MANU|AUTO}

**Query Syntax** MAIN:FUNction ?

**Parameter/** MANU Puts the tester mode to MANU.

**Return parameter** AUTO Puts the tester mode to AUTO.

**Example** MAIN:FUNC MANU  
Sets the tester to MANU mode.

---

## Manual Commands

---

|                              |     |
|------------------------------|-----|
| MANU:STEP.....               | 117 |
| MANU:NAME.....               | 117 |
| MANU:RTIME .....             | 117 |
| MANU:EDIT:MODE.....          | 118 |
| MANU:ACW:VOLTage .....       | 118 |
| MANU:ACW:CHISet.....         | 119 |
| MANU:ACW:CLOSet.....         | 119 |
| MANU:ACW:TTIME .....         | 120 |
| MANU:ACW:FREQuency .....     | 121 |
| MANU:ACW:REF .....           | 121 |
| MANU:ACW:ARCCurrent.....     | 122 |
| MANU:DCW:VOLTage .....       | 122 |
| MANU:DCW:CHISet.....         | 123 |
| MANU:DCW:CLOSet.....         | 123 |
| MANU:DCW:TTIME .....         | 124 |
| MANU:DCW:REF .....           | 124 |
| MANU:DCW:ARCCurrent.....     | 125 |
| MANU:IR:VOLTage .....        | 125 |
| MANU:IR:RHISet.....          | 126 |
| MANU:IR:RLOSet.....          | 126 |
| MANU:IR:TTIME .....          | 127 |
| MANU:IR:REF .....            | 127 |
| MANU:GB:CURRent .....        | 127 |
| MANU:GB:RHISet .....         | 128 |
| MANU:GB:RLOSet .....         | 128 |
| MANU:GB:TTIME.....           | 129 |
| MANU:GB:FREQuency.....       | 129 |
| MANU:GB:REF .....            | 130 |
| MANU:GB:ZEROCHECK.....       | 130 |
| MANU:UTILity:ARCMODE .....   | 131 |
| MANU:UTILity:PASShold.....   | 131 |
| MANU:UTILity:FAILhold .....  | 131 |
| MANU:UTILity:MAXHold.....    | 132 |
| MANU:UTILity:GROUNDMODE..... | 132 |
| MANU<x>:EDIT:SHOW .....      | 132 |

## MANU:STEP Set → ← Query

|                                |                                                      |
|--------------------------------|------------------------------------------------------|
| Description                    | Sets the MANU test number.                           |
| Syntax                         | MANU:STEP <NR1>                                      |
| Query Syntax                   | MANU:STEP?                                           |
| Parameter/<br>Return parameter | <NR1> 0~100.                                         |
| Example                        | MANU:STEP 100<br>Sets the manual test number to 100. |

## MANU:NAME Set → ← Query

|                                |                                                                                                                                                                                                                                                         |
|--------------------------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description                    | Sets or returns the test name for the selected manual test. The test must be in MANU mode before this command can be used.<br>Note only alphanumeric characters (A-Z, a-z, 0-9) and the “_” underscore character can be used to set the MANU test name. |
| Syntax                         | MANU:NAME <string>                                                                                                                                                                                                                                      |
| Query Syntax                   | MANU:NAME?                                                                                                                                                                                                                                              |
| Parameter/<br>Return parameter | <string> 10 character string. (first character must be a letter)                                                                                                                                                                                        |
| Example                        | MANU:NAME test1<br>Sets the manual test name to “test1”.                                                                                                                                                                                                |

## MANU:RTIME Set → ← Query

|             |                                                                                                                                                                                                         |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description | Sets or returns the Ramp Time for the test in seconds.<br><br>Note: A “TIME ERR” will result if the Ramp Time + Test Time is $\geq 240$ seconds when the HI SET limit is over 30mA (ACW function only). |
|-------------|---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|

|                                |                                                       |
|--------------------------------|-------------------------------------------------------|
| Syntax                         | MANU:RTIME <NR2>                                      |
| Query Syntax                   | MANU:RTIME?                                           |
| Parameter/<br>Return parameter | <NR2> 0.1~999.9 seconds                               |
| Example                        | MANU:RTIM 0.5<br>Sets the ramp time to half a second. |

Set →

→ Query

### MANU:EDIT:MODE

|                                |                                                                      |
|--------------------------------|----------------------------------------------------------------------|
| Description                    | Sets or returns the mode (ACW, DCW, IR) of the selected manual test. |
| Syntax                         | MANU:EDIT:MODE {ACW DCW IR GB}                                       |
| Query Syntax                   | MANU:EDIT:MODE?                                                      |
| Parameter/<br>Return parameter | <ACW> AC Withstand mode                                              |
|                                | <DCW> DC Withstand mode                                              |
|                                | <IR> Insulation Resistance mode                                      |
| Example                        | MANU:EDIT:MODE ACW<br>Sets the mode to ACW.                          |

Set →

→ Query

### MANU:ACW:VOLTage

|                                |                                                                                                            |
|--------------------------------|------------------------------------------------------------------------------------------------------------|
| Description                    | Sets or returns the ACW voltage in kV. The test must first be in ACW mode before this command can be used. |
| Syntax                         | MANU:ACW:VOLTage <NR2>                                                                                     |
| Query Syntax                   | MANU:ACW:VOLTage?                                                                                          |
| Parameter/<br>Return parameter | <NR2> 0.100 ~ 5.000 (kV)                                                                                   |
| Example                        | MANU:ACW:VOLT 1<br>Sets the ACW voltage to 1 kV.                                                           |

## MANU:ACW:CHISet

Set →

→ Query

**Description** Sets or returns the ACW HI SET current value in milliamps. The test must first be in ACW mode before this command can be used.

**Syntax** MANU:ACW:CHISet <NR2>

**Query Syntax** MANU:ACW:CHISet?

**Parameter/  
Return parameter** <NR2> 0.001 ~ 042.0

**Example** MANU:ACW:CHIS 10.0

Sets the ACW HI SET current to 10 mA.

Set →

→ Query

## MANU:ACW:CLOSet

**Description** Sets or returns the ACW LO SET current value in milliamps. The LO SET value must be less than the HI SET value. The test must first be in ACW mode before this command can be used.

The LO SET range must use the HI SET range. If all the digits in the LO SET range are outside the HI SET range, an error will be produced. All digits outside the HI SET range are ignored and will not be used.

For example:


HI SET value: 12.34

LO SET value1: 0.005 → error

LO SET value2: 0.053 → no error

In the example above LO SET value1 will produce an error as all digits are outside the range of HI SET. LO SET value2 will not produce an error, but will return 0.05, not 0.053.

|                                |                                                             |               |
|--------------------------------|-------------------------------------------------------------|---------------|
| Syntax                         | MANU:ACW:CLOSet<NR2>                                        |               |
| Query Syntax                   | MANU:ACW:CLOSet?                                            |               |
| Parameter/<br>Return parameter | <NR2>                                                       | 0.000 ~ 041.9 |
| Example                        | MANU:ACW:CLOS 20.0<br>Sets the ACW LO SET current to 20 mA. |               |




**MANU:ACW:TTIME**

|                  |                                                                                                                                                                                                          |                                   |
|------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|
| Description      | Sets or returns the ACW test time in seconds. The test must first be in ACW mode before this command can be used.                                                                                        |                                   |
|                  | <p>Note: A "TIME ERR" will result if the Ramp Time + Test Time is &gt; 240 seconds when the HI SET limit is over 30mA (ACW function only).</p> <p>In special MANU mode, the TIMER can be turned off.</p> |                                   |
| Syntax           | MANU:ACW:TTIME {<NR2> OFF}                                                                                                                                                                               |                                   |
| Query Syntax     | MANU:ACW:TTIME?                                                                                                                                                                                          |                                   |
| Parameter        | <NR2>                                                                                                                                                                                                    | 0.5 ~ 999.9 seconds               |
|                  | OFF                                                                                                                                                                                                      | TIMER OFF (special MANU mode).    |
| Return parameter | <NR2>                                                                                                                                                                                                    | 0.5 ~ 999.9 seconds               |
|                  | TIME OFF                                                                                                                                                                                                 | TIMER is OFF (special MANU mode). |
| Example          | MANU:ACW:TTIM 1<br>Sets the ACW test time to 1 second.                                                                                                                                                   |                                   |



**MANU:ACW:FREQuency**



**Description** Sets or returns the ACW test frequency in Hz. The test must first be in ACW mode before this command can be used.


**Syntax** MANU:ACW:FREQuency {50|60}

**Query Syntax** MANU:ACW:FREQuency?

**Parameter/** <50> 50 Hz

**Return parameter** <60> 60 Hz

**Example** MANU:ACW:FREQ 50  
Sets the ACW test frequency to 50Hz.



**MANU:ACW:REF**

**Description** Sets or returns the ACW reference value in mA. The test must first be in ACW mode before this command can be used.

The ACW reference value must be less than the HI SET value.

The ACW reference value must use the same range as the HI SET value.

**Syntax** MANU:ACW:REF <NR2>

**Query Syntax** MANU:ACW:REF?

**Parameter/** <NR2> 0.000 ~ 041.9

**Return parameter**

**Example** MANU:ACW:REF 0.01  
Sets the ACW reference to 0.01 mA.

**MANU:ACW:ARCCurrent**

Set →

→ Query

**Description** Sets or returns the ACW ARC current value in mA. ARC must be enabled before the ARC current can be set. The test must first be in ACW mode before this command can be used.

ARC current uses the same range as the HI SET value. The ARC current is limited to 2X the HI SET value.

**Syntax** MANU:ACW:ARCCurrent <NR2>

**Query Syntax** MANU:ACW:ARCCurrent?

**Parameter/** <NR2> 0.000 ~ 080.0

**Return parameter**

**Example** MANU:ACW:ARCC 0.04

Sets the ACW ARC value to 0.04 mA.

Set →

→ Query

**MANU:DCW:VOLTage**

**Description** Sets or returns the DCW voltage in kV. The test must first be in DCW mode before this command can be used.

Note: A “DC Over 50W” error will result if the DCW Voltage X HI SET value is > 50 watts.

**Syntax** MANU:DCW:VOLTage <NR2>

**Query Syntax** MANU:DCW:VOLTage?

**Parameter/** <NR2> 0.100 ~ 6.100 (kV)

**Return parameter**

**Example** MANU:DCW:VOLT 6

Sets the DCW voltage to 6 kV.

## MANU:DCW:CHISet

Set →

→ Query

**Description** Sets or returns the DCW HI SET current value in milliamps. The test must first be in DCW mode before this command can be used.

Note: A “DC Over 50W” error will result if the DCW Voltage X HI SET value is > 50 watts.

**Syntax** MANU:DCW:CHISet <NR2>

**Query Syntax** MANU:DCW:CHISet?

**Parameter/  
Return parameter** <NR2> 0.001 ~ 11.00

**Example** MANU:DCW:CHIS 5

Sets the DCW HI SET current to 5mA.

Set →

→ Query

## MANU:DCW:CLOSet

**Description** Sets or returns the DCW LO SET current value in milliamps. The LO SET value must be less than the HI SET value. The test must first be in DCW mode before this command can be used.

The LO SET range must use the HI SET range. If all the digits in the LO SET range are outside the HI SET range, an error will be produced. All digits outside the HI SET range are ignored and will not be used.

For example:

HI SET value: 12.34

LO SET value1: 0.005 → error

LO SET value2: 0.053 → no error

In the example above LO SET value1 will produce an error as all digits are outside the range of HI SET. LO SET value2 will not produce an error, but will return 0.05, not 0.053.

|                                |                                                           |               |
|--------------------------------|-----------------------------------------------------------|---------------|
| Syntax                         | MANU:DCW:CLOSet<NR2>                                      |               |
| Query Syntax                   | MANU:DCW:CLOSet?                                          |               |
| Parameter/<br>Return parameter | <NR2>                                                     | 0.000 ~ 010.9 |
| Example                        | MANU:DCW:CLOS 2.00<br>Sets the DCW LO SET current to 2mA. |               |

Set →

**MANU:DCW:TTIME**

→ Query

|                  |                                                                                                                                                                             |                                   |
|------------------|-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|-----------------------------------|
| Description      | Sets or returns the DCW test time in seconds. The test must first be in DCW mode before this command can be used.<br><br>In special MANU mode, the TIMER can be turned off. |                                   |
| Syntax           | MANU:DCW:TTIME {<NR2> OFF}                                                                                                                                                  |                                   |
| Query Syntax     | MANU:DCW:TTIME?                                                                                                                                                             |                                   |
| Parameter        | <NR2>                                                                                                                                                                       | 0.5 ~ 999.9 seconds               |
|                  | OFF                                                                                                                                                                         | TIMER OFF (special MANU mode).    |
| Return parameter | <NR2>                                                                                                                                                                       | 0.5 ~ 999.9 seconds               |
|                  | TIME OFF                                                                                                                                                                    | TIMER is OFF (special MANU mode). |
| Example          | MANU:DCW:TTIM 1<br>Sets the DCW test time to 1 second.                                                                                                                      |                                   |

Set →

**MANU:DCW:REF**

→ Query

|             |                                                                                                                                                                                                                                                       |  |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|
| Description | Sets or returns the DCW reference value in mA. The test must first be in DCW mode before this command can be used.<br><br>The reference value must be less than the HI SET value.<br><br>The reference value uses the same range as the HI SET value. |  |
|-------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|--|

|                                |                                                         |
|--------------------------------|---------------------------------------------------------|
| Syntax                         | MANU:DCW:REF <NR2>                                      |
| Query Syntax                   | MANU:DCW:REF?                                           |
| Parameter/<br>Return parameter | <NR2> 000.0 ~ 010.9                                     |
| Example                        | MANU:DCW:REF 0.01<br>Sets the DCW reference to 0.01 mA. |

Set →

→ Query

### MANU:DCW:ARCCurrent

|             |                                                                                                                                                                  |
|-------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description | Sets or returns the DCW ARC current value in mA. ARC must be enabled to set the ARC current. The test must first be in DCW mode before this command can be used. |
|-------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|

ARC current uses the same range as the HI SET value. The ARC current is limited to 2X the HI SET value.

|                                |                                                     |
|--------------------------------|-----------------------------------------------------|
| Syntax                         | MANU:DCW:ARCCurrent <NR2>                           |
| Query Syntax                   | MANU:DCW:ARCCurrent?                                |
| Parameter/<br>Return parameter | <NR2> 000.0 ~ 22.00                                 |
| Example                        | MANU:DCW:ARCC 10<br>Sets the DCW ARC value to 10mA. |

Set →

→ Query

### MANU:IR:VOLTage

|             |                                                                                                          |
|-------------|----------------------------------------------------------------------------------------------------------|
| Description | Sets or returns the IR voltage in kV. The test must first be in IR mode before this command can be used. |
|-------------|----------------------------------------------------------------------------------------------------------|

|                                |                                              |
|--------------------------------|----------------------------------------------|
| Syntax                         | MANU:IR:VOLTage <NR2>                        |
| Query Syntax                   | MANU:IR:VOLTage?                             |
| Parameter/<br>Return parameter | <NR2> 0.05 ~ 1 (0.05kV to 1kV: steps of .05) |

Example            MANU:IR:VOLT 1  
                       Sets the IR voltage to 1 kV.

Set →

→ Query

**MANU:IR:RHISet**

Description       Sets or returns the IR HI SET resistance value in MΩ. The test must first be in IR mode before this command can be used.

Syntax            MANU:IR:RHISet <NR1>|NULL

Query Syntax     MANU:IR:RHISet?

Parameter/       <NR1>    2 ~ 9999

Return parameter NULL       Sets the HI SET value to high impedance

Example            MANU:IR:RHIS 10.  
                       Sets the IR HI SET resistance to 10 MΩ.

Set →

→ Query

**MANU:IR:RLOSet**

Description       Sets or returns the IR LO SET resistance value in MΩ. The LO SET value must be less than the HI SET value. The test must first be in IR mode before this command can be used.

Syntax            MANU:IR:RLOSet<NR1>

Query Syntax     MANU:IR:RLOSet?

Parameter/       <NR1>    1 ~ 9999

Return parameter

Example            MANU:IR:RLOS 10  
                       Sets the IR LO SET resistance to 10MΩ.

## MANU:IR:TTIME

Set →

→ Query

**Description** Sets or returns the IR test time in seconds. The test must first be in IR mode before this command can be used.

**Syntax** MANU:IR:TTIME <NR2>

**Query Syntax** MANU:IR:TTIME?

**Parameter/  
Return parameter** <NR2> 1.0 ~ 999.9 seconds

**Example** MANU:IR:TTIM 1  
Sets the IR test time to 1 second.

Set →

→ Query

## MANU:IR:REF

**Description** Sets or returns the IR reference value in MΩ. The test must first be in IR mode before this command can be used.

The reference value must be lower than the HI SET value.

**Syntax** MANU:IR:REF <NR1>

**Query Syntax** MANU:IR:REF?

**Parameter/  
Return parameter** <NR1> 0000 ~ 9999

**Example** MANU:IR:REF 900  
Sets the IR reference to 900 MΩ.

Set →

→ Query

## MANU:GB:CURREnt

**Description** Sets or returns the GB current in A. The test must first be in GB mode before this command can be used.

Syntax MANU:GB:CURRent <NR2>

Query Syntax MANU:GB:CURRent?

Parameter/ Return parameter <NR2> 3.00~32.00

Example MANU:GB:CURR 3.00  
Sets the GB current to 3.00A.

Set →

→ Query

### MANU:GB:RHISet

Description Sets or returns the GB HI SET resistance value in mΩ. The test must first be in GB mode before this command can be used.

Syntax MANU:GB:RHISet <NR2>

Query Syntax MANU:GB:RHISet?

Parameter/ Return parameter <NR2> 000.1 ~ 650.0

Example MANU:GB:RHIS 100.0  
Sets the HI SET value to 100mΩ.



Note

If the (GB current x HI SET resistance) > 5.4V, then an error will be generated (“GBV > 5.4V”).

Set →

→ Query

### MANU:GB:RLOSet

Description Sets or returns the GB LO SET resistance value in mΩ. The LO SET value must be less than the HI SET value. The test must first be in GB mode before this command can be used.

Syntax MANU:GB:RLOSet<NR2>

Query Syntax MANU:IR:RLOSet?

Parameter/ Return parameter <NR2> 0.000 ~ 649.9

Example MANU:GB:RLOS 50  
Sets the GB LO SET resistance to 50mΩ.



## MANU:GB:TTIME

Set →

→ Query

**Description** Sets or returns the GB test time in seconds. The test must first be in GB mode before this command can be used.

**Syntax** MANU:GB:TTIME <NR2>

**Query Syntax** MANU:GB:TTIME?

**Parameter/  
Return parameter** <NR2> 0.5 ~ 999.9 seconds

**Example** MANU:GB:TTIM 1  
Sets the GB test time to 1 second.

Set →

→ Query

## MANU:GB:FREQUENCY

**Description** Sets or returns the GB test frequency in Hz. The test must first be in GB mode before this command can be used.

**Syntax** MANU:GB:FREQUENCY {50|60}

**Query Syntax** MANU:GB:FREQUENCY?

**Parameter/  
Return parameter** <50> 50 Hz  
<60> 60 Hz

**Example** MANU:GB:FREQ 50  
Sets the GB test frequency to 50Hz.

Set →

**MANU:GB:REF**

→ Query

**Description** Sets or returns the GB reference value in mΩ. The test must first be in GB mode before this command can be used.

The GB reference value must be less than the HI SET value.

**Syntax** MANU:GB:REF <NR2>

**Query Syntax** MANU:GB:REF?

**Parameter/Return parameter** <NR2> 0.000 ~ 649.9

**Example** MANU:GB:REF 100  
Sets the GB reference to 100 mΩ.

Set →

**MANU:GB:ZEROCHECK**

→ Query

**Description** Performs the zero check function. The test must first be in GB mode and in the Ready Status before this command can be used.

See page 66 for details on the ZERO function.

**Syntax** MANU:GB:ZEROCHECK {ON|OFF}

**Query Syntax** MANU:GB:ZEROCHECK?

**Parameter/Return parameter** <ON> Zero function is active.  
<OFF> Zero function is not active.

**Example** MANU:GB:ZEROCHECK OFF  
Activates the ZERO function.

**MANU:UTILity:ARCMoDe**

Set →

→ Query

**Description** Sets or returns the ARC mode status for the current test.  
The ARC mode cannot be set for the IR and GB function.

**Syntax** MANU:UTILity:ARCMoDe {OFF|ON\_CONT|ON\_STOP}

**Query Syntax** MANU:UTILity:ARCMoDe?

|                         |         |                                   |
|-------------------------|---------|-----------------------------------|
| <b>Parameter/</b>       | OFF     | Turns ARC mode off.               |
| <b>Return parameter</b> | ON_CONT | Sets ARC mode to ON and CONTINUE. |
|                         | ON_STOP | Sets ARC mode to ON and STOP.     |

**Example** MANU:UTIL:ARCM OFF  
Turns ARC mode OFF.

Set →

→ Query

**MANU:UTILity:PASShold**

**Description** Sets or returns the PASS HOLD setting for the current test.

**Syntax** MANU:UTILity:PASShold {ON|OFF}

**Query Syntax** MANU:UTILity:PASShold?

|                         |     |                      |
|-------------------------|-----|----------------------|
| <b>Parameter/</b>       | OFF | Turns PASS HOLD off. |
| <b>Return parameter</b> | ON  | Turns PASS HOLD on.  |

**Example** MANU:UTIL:PASS OFF  
Turns PASS HOLD OFF.

Set →

→ Query

**MANU:UTILity:FAILhold**

**Description** Sets or returns the FAIL HOLD setting for the current test.

**Syntax** MANU:UTILity:FAILhold {ON|OFF}

**Query Syntax** MANU:UTILity:FAILhold?

|                  |     |                      |
|------------------|-----|----------------------|
| Parameter/       | OFF | Turns FAIL HOLD off. |
| Return parameter | ON  | Turns FAIL HOLD on.  |

Example            MANU:UTIL:FAIL OFF  
                          Turns FAIL HOLD OFF.

Set →

→ Query

### MANU:UTILity:MAXHold

Description       Sets or returns the MAX HOLD setting for the current test.

Syntax             MANU:UTILity:MAXHold {ON|OFF}

Query Syntax      MANU:UTILity:MAXHold?

|                  |     |                     |
|------------------|-----|---------------------|
| Parameter/       | OFF | Turns MAX HOLD off. |
| Return parameter | ON  | Turns MAX HOLD on.  |

Example            MANU:UTIL:MAXH ON  
                          Turns MAX HOLD on.

Set →

→ Query

### MANU:UTILity:GROUNDMODE

Description       Sets or returns the Grounding mode of the current test.

The Ground Mode setting cannot be turned on with the IR and GB function.

Syntax             MANU:UTILity:GROUNDMODE {ON|OFF}

Query Syntax      MANU:UTILity:GROUNDMODE?

|                  |     |                        |
|------------------|-----|------------------------|
| Parameter/       | OFF | Turns ground mode off. |
| Return parameter | ON  | Turns ground mode on.  |

Example            MANU:UTIL:GROUNDMODE ON  
                          Turns GROUND MODE on.

### MANU<x>:EDIT:SHOW

→ Query

Description       Returns the test parameters of a manual test.

Query Syntax      MANU<x>:EDIT:SHOW?


|                                |                 |                                                                                                                                                                  |
|--------------------------------|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Parameter/<br>Return parameter | <x><br><string> | <NR1> 000~100. Manual test number<br>Returns a string in the following format:<br>Test function, test voltage, HI SET value, LO SET value, Ramp time, test time. |
|--------------------------------|-----------------|------------------------------------------------------------------------------------------------------------------------------------------------------------------|

Example            MANU1:EDIT:SHOW ?  
                      > ACW,0.100kV,H=01.00mA,L=00.00mA,R=000.1S,  
                      >T=001.0S.  
                      Returns the test parameters of manual test number 1.

### Auto Commands

|                         |     |
|-------------------------|-----|
| AUTO:STEP .....         | 133 |
| AUTO<x>:PAGE:SHOW ..... | 134 |
| AUTO:NAME .....         | 134 |
| TESTok:RETurn .....     | 135 |

### AUTO:STEP



|                                |                                                          |
|--------------------------------|----------------------------------------------------------|
| Description                    | Sets or queries the AUTO number (automatic test number). |
| Syntax                         | AUTO:STEP <NR1>                                          |
| Query Syntax                   | AUTO:STEP?                                               |
| Parameter/<br>Return parameter | <NR1> 1~100.                                             |



Example            AUTO:STEP 100  
                      Sets the current AUTO number to 100.

**AUTO<x>:PAGE:SHOW** → Query

|              |                                                                                                                                                                                                                         |
|--------------|-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description  | Returns the Page View of the selected automatic test in the following format:<br>step1:MANU number, step2: MANU number, step3....etc.                                                                                   |
| Query Syntax | AUTO<x>:PAGE:SHOW?                                                                                                                                                                                                      |
| Parameter/   | <x>      <NR1> 1~100                                                                                                                                                                                                    |
| Example      | AUTO1:PAGE:SHOW?<br><br>>01:011 ,02:004 ,03:003 ,04:014 ,<br>>05:015 ,06:020* ,07:012 ,08:018 ,<br>>09:    ,10:    ,11:    ,12:    ,<br>>13:    ,14:    ,15:    ,16:    ,<br><br>Shows the Page View for AUTO number 1. |

**AUTO:NAME** Set →  
→ Query

|                                |                                                                                                                                                                                                                                                                |
|--------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Description                    | Sets or returns the AUTO name for the selected automatic test. The test must be in AUTO mode before this command can be used.<br><br>Note only alphanumeric characters (A-Z, a-z, 0-9) and the “_” underscore character can be used to set the AUTO test name. |
| Syntax                         | AUTO:NAME <string>                                                                                                                                                                                                                                             |
| Query Syntax                   | AUTO:NAME?                                                                                                                                                                                                                                                     |
| Parameter/<br>Return parameter | <string> 10 character string. (first character must be a letter)                                                                                                                                                                                               |
| Example                        | AUTO:NAME program1<br><br>Sets the AUTO name to “program1”.                                                                                                                                                                                                    |

TESTok:RETurn 



**Description** Allows “OK” to be displayed on the remote terminal when a test has stopped (PASS/FAIL or STOP). This applies for MANU and AUTO mode.

By default, TESTok:RETurn is set to OFF.

**Syntax** TESTok:RETurn {ON|OFF}

**Query Syntax** TESTok:RETurn?

|                                        |     |                                           |
|----------------------------------------|-----|-------------------------------------------|
| <b>Parameter/<br/>Return parameter</b> | ON  | Enables the “OK” message to be displayed. |
|                                        | OFF | Disables the message                      |

**Example** TEST:RET OFF  
Disables the message.

### Common Commands

|            |     |
|------------|-----|
| *CLS.....  | 135 |
| *IDN ..... | 135 |

\*CLS 

**Description** The \*CLS command clears the internal registers.

**Syntax** \*CLS

\*IDN 

**Description** Queries the model number, serial number, and firmware version of the tester.

**Query Syntax** \*IDN?

Return parameter <string> Returns the instrument identification as a string in the following format:

GPT-9803, XXXXXXXXXXXXX, V1.00

Model number : GPT-9803

Serial number :12 character serial number

Firmware version : V1.00

## Error Messages

Background The possible error messages returned from SYST:ERR? query are listed below.

| Error                | Error Code |
|----------------------|------------|
| Command Error        | 0x14       |
| Value Setting Error  | 0x15       |
| String Setting Error | 0x16       |
| Query Error          | 0x17       |
| MODE Setting Error   | 0x18       |
| Time Error           | 0x19       |
| DC Over 50W          | 0x1A       |
| GBV > 5.4V           | 0x1B       |



# F AQ

---

- The tester will not turn on.
- The panel keys are not working.
- When I press the START button the tester will not start testing?
- The accuracy does not match the specification.

## The tester will not turn on.

---

Ensure the power cord is connected. Ensure the line input is set to the correct line voltage. Check to make sure the fuse is not blown. See page 139.

## The panel keys are not working.

---

Ensure the tester is not in remote mode, page 105.

Ensure the tester is not in SIGNAL I/O or Remote Connect mode, page 75.

## When I press the START button the tester will not start testing?

---

The tester must first be in the READY status before a test can be started. Ensure the tester displays READY before pressing the START button, page 57 (manual test), 87(automatic test).

If “Double Action” is enabled, the START button must be pressed 0.5 seconds after the STOP button is pressed, otherwise the tester will not start testing.

If “Interlock” is enabled, the interlock key must be inserted into the signal I/O port on the rear before a test can be started. See page 100 for details.

The accuracy does not match the specification.

---

Make sure the tester is powered On for at least 30 minutes, within +15°C~+35°C. This is necessary to stabilize the unit to match the specification.

For more information, contact your local dealer or GWInstek at [www.gwinstek.com](http://www.gwinstek.com) / [marketing@goodwill.com.tw](mailto:marketing@goodwill.com.tw).


# APPENDIX

## Fuse Replacement


---

Steps


1. Turn the instrument off.




2. Remove the power cord.




3. Remove the fuse socket using a flat screwdriver.



4. Replace the fuse in the fuse holder.



5. Ensure the correct line voltage is lined up with the arrow on the fuse holder. Insert the fuse socket.



|        |                        |                        |
|--------|------------------------|------------------------|
| Rating | 100V/120V<br>220V/230V | T5A 250V<br>T2.5A 250V |
|--------|------------------------|------------------------|

## Error Messages

### System Self Test

The following error messages or messages may appear on the GPT screen during the Start-Up initialization. If any of these error messages appear on the GPT-9000, please see an authorized GW Instek distributor.

| Error Messages | Description                             |
|----------------|-----------------------------------------|
| 0x11           | EEPROM1 Error                           |
| 0x12           | EEPROM1 Error                           |
| 0x21           | W-V Offset Error (W-V: ACW/DCW voltage) |
| 0x22           | W-I Offset Error (W-I: ACW/DCW current) |
| 0x23           | IR-I Offset Error                       |
| 0x24           | GB-I Offset Error                       |

## MANU Setting Errors

The following error messages or messages may appear on the GPT screen when configuring the MANU test settings.

| Error Messages | Description                                                                                                                                                              |
|----------------|--------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| TIME ERR       | For ACW tests. TIME ERR is displayed when HI SET $\geq 30.00\text{mA} \sim 40.00\text{mA}$ and if the RAMP $\uparrow$ time and the TEST TIME setting is $> 240$ seconds. |
| OVER 50W       | For DCW tests. OVER 50W is displayed if the HI SET setting multiplied by the Voltage setting is greater than 50W.                                                        |
| I ERR          | For ACW, DCW tests. Shown when the current is set too high.                                                                                                              |
| SHORT          | Voltage is too low. Indicates that the DUT could be shorted.                                                                                                             |
| V ERR          | For ACW, DCW tests. Voltage is too high.                                                                                                                                 |
| V = 0          | For GB tests. Voltage is equal to 0. Check to see that the SENSE H is not open.                                                                                          |
| R ERR          | For IR tests. The voltage is too high or resistance $= 0\Omega$ . Check to see whether the DUT or test lead is shorting.                                                 |
|                | For GB tests. The resistance is too high or too low. Check the test lead connections to correct the error.                                                               |
| I < SET        | For GB tests. Current too low. Indicates that the SOURCE L or SOURCE H test lead is open or poorly connected. Test the test lead connection with the DUT to confirm.     |
| I > SET        | For GB tests. Current is too high.                                                                                                                                       |
| R = 0          | For GB tests. Resistance = 0. This error indicates that there is an error with the measured resistance ( $0\Omega$ ). Perform the zeroing function again.                |

## GPT-9000 Specifications

The specifications apply when the GPT-9000 is powered on for at least 30 minutes at 15°C~35°C.

### Specifications

#### Environment

| Range                 | Temperature                             | Humidity               |
|-----------------------|-----------------------------------------|------------------------|
| Warranty              | 15°C ~ 35°C                             | ≤70% (No condensation) |
| Operation             | 0°C ~ 40°C                              | ≤70% (No condensation) |
| Storage               | -10°C ~ 70°C                            | ≤85% (No condensation) |
| Installation Location | Indoors at an amplitude of up to 2000m. |                        |

#### AC Withstanding Voltage

|                              |                                                                                    |
|------------------------------|------------------------------------------------------------------------------------|
| Output Voltage Range         | 0.100kV~ 5.000kV                                                                   |
| Output Voltage Resolution    | 2V                                                                                 |
| Output Voltage Accuracy      | ± (1% of setting +5V) with no load                                                 |
| Maximum Rated Load (Table1)  | 200 VA (5kV/40mA)                                                                  |
| Maximum Rated Current        | 40mA<br>0.001mA ~ 10mA (0.1kV≤V≤0.5kV)<br>0.001mA ~ 40mA (0.5kV<V≤5kV)             |
| Output Voltage Waveform      | Sine wave                                                                          |
| Frequency                    | 50 Hz / 60 Hz                                                                      |
| Voltage Regulation           | ± 1% +5V<br>[Maximum rated load → no load]                                         |
| Voltmeter Accuracy           | ± (1% of reading+ 5V)                                                              |
| Current Measurement Range    | 0.001mA~040.0mA                                                                    |
| Current Best Resolution      | 1uA<br>0.001mA(0.001mA~0.999mA)<br>0.01mA(01.00mA~09.99mA)<br>0.1mA(010.0~040.0mA) |
| Current Measurement Accuracy | ±(1.5% of reading +30uA)                                                           |
| Window Comparator Method     | Yes                                                                                |
| ARC DETECT                   | Yes                                                                                |
| Rise-time Control Function   | Yes                                                                                |
| RAMP (Ramp Time)             | 0.1~999.9S                                                                         |

Continued...

|                   |                   |
|-------------------|-------------------|
| TIMER (Test Time) | OFF*, 0.5S~999.9S |
| GND               | RETURN/GUARD      |

\* The timer can only be turned off under special MANU mode (MANU=\*\*\*-000)

### DC Withstanding Voltage

|                              |                                                                              |
|------------------------------|------------------------------------------------------------------------------|
| Output Voltage Range         | 0.100kV~ 6.000kV                                                             |
| Output Voltage Resolution    | 2V                                                                           |
| Output Voltage Accuracy      | ± (1% of setting +5V) with no load                                           |
| Maximum Rated Load(Table1)   | 50W (5kV/10mA)                                                               |
| Maximum Rated Current        | 10mA<br>0.001mA ~ 2mA (0.1kV≤V≤0.5kV)<br>0.001mA ~ 10mA (0.5kV<V≤6kV)        |
| Voltmeter Accuracy           | ± (1% of reading+ 5V)                                                        |
| Voltage Regulation           | ± 1% +5V<br>[Maximum rated load → no load]                                   |
| Current Measurement Range    | 0.001mA~010.0mA                                                              |
| Current Best Resolution      | 1uA<br>0.001mA(0.001mA~0.999mA)<br>0.01mA(01.00mA~09.99mA)<br>0.1mA(010.0mA) |
| Current Measurement Accuracy | ±(1.5% of reading +30uA)                                                     |
| Window Comparator Method     | Yes                                                                          |
| ARC DETECT                   | Yes                                                                          |
| Rise-time Control Function   | Yes                                                                          |
| RAMP (Ramp Time)             | 0.1~999.9S                                                                   |
| TIMER (Test Time)            | OFF*, 0.5S~999.9S                                                            |
| GND                          | RETURN/GUARD                                                                 |

\* The timer can only be turned off under special MANU mode (MANU=\*\*\*-000)

### Insulation Resistance Test


|                              |                                        |                        |
|------------------------------|----------------------------------------|------------------------|
| Output Voltage               | 50V~1000V                              |                        |
| Output Voltage Resolution    | 50V                                    |                        |
| Resistance Measurement Range | 1MΩ~ 9500MΩ                            |                        |
| Test Voltage                 | Measurement Range Accuracy             |                        |
| 50V≤V<500V                   | 1~50MΩ                                 | ±(5% of reading +1MΩ)  |
|                              | 51~2000MΩ                              | ±(10% of reading +1MΩ) |
| 500V≤V≤1000V                 | 1~500MΩ                                | ±(5% of reading +1MΩ)  |
|                              | 501~9500MΩ                             | ±(10% of reading +1MΩ) |
| Voltage Regulation           | ±1% +5V [Maximum rated load → no load] |                        |
| Window Comparator Method     | Yes                                    |                        |
| Rise-time Control Function   | Yes                                    |                        |
| RAMP (Ramp Time)             | 0.1~999.9S                             |                        |

Continued...

|                   |           |
|-------------------|-----------|
| TIMER (Test Time) | 1S~999.9S |
| GND               | GUARD     |

**Ground Bond Test**

|                               |                                                                                                     |
|-------------------------------|-----------------------------------------------------------------------------------------------------|
| Output Current Range          | 03.00A~30.00A                                                                                       |
| Output Current Accuracy       | ± (1% of reading +0.2A) when $3A \leq I \leq 8A$<br>± (1% of reading +0.05A) when $8A < I \leq 30A$ |
| Output Current Resolution     | 0.01A                                                                                               |
| Frequency                     | 50Hz/60Hz                                                                                           |
| Ohmmeter Measurement Accuracy | ± (1% of reading +2mΩ)                                                                              |
| Ohmmeter Measurement Range    | 10mΩ~650.0mΩ                                                                                        |



|                                 |             |
|---------------------------------|-------------|
| Test Voltage                    | Max. 6V(AC) |
| Ohmmeter Measurement Resolution | 0.1mΩ       |
| Windows Comparator Method       | Yes         |
| TIMER (Test Time)               | 0.5S~999.9S |
| GND                             | GUARD       |

**Interface**

|                          |              |
|--------------------------|--------------|
| REMOTE (Remote terminal) | Yes          |
| SIGNAL IO                | Yes          |
| RS232                    | Yes          |
| USB (Device)             | Yes          |
| GPIB                     | Yes (OPTION) |

**General**

|              |                                         |
|--------------|-----------------------------------------|
| DISPLAY      | 240 x 64 dot matrix LED back light LCD  |
| MEMORY       | AUTO/MANU mode 100 memory blocks total  |
| POWER SOURCE | AC100V/120V/220V/230V ±10%<br>50Hz/60Hz |

Continued...



|                     |                                                                                                                                               |
|---------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| ACCESSORIES         | Power cord x1, Quick Start Guide x1<br>User Manual x1 (CD)<br>GHT-114x1 for GPT-9801, GPT-9802, GPT-9803<br>GHT-114x1, GTL-115x1 for GTP-9804 |
| DIMENSIONS & WEIGHT | Approx. 330(W) x 150(H) x 460(D) mm (Max.),<br>19kg(Max)                                                                                      |


**Table 1: Output Limitation in Withstanding Voltage Testing**

|    | Upper Current                            | Pause                               | Output Time                |
|----|------------------------------------------|-------------------------------------|----------------------------|
| AC | $30\text{mA} \leq I \leq 40\text{mA}$    | At least as long as the output time | Approx. 240 seconds        |
|    | $0.001\text{mA} \leq I < 30\text{mA}$    | Not necessary                       | Continuous output possible |
| DC | $0.001\text{mA} \leq I \leq 10\text{mA}$ | Not necessary                       | Continuous output possible |
| GB | $15\text{A} < I \leq 30\text{A}$         | At least as long as the output time | 999.9                      |
|    | $3\text{A} \leq I \leq 15\text{A}$       | Not necessary                       | 999.9                      |

NOTE: Output Time = Ramp Time + Test Time.

## GPT-9000 Dimensions

---



## Declaration of Conformity

We

**GOOD WILL INSTRUMENT CO., LTD.**

No. 7-1, Jhongsing Rd, Tucheng Dist., New Taipei City 236, Taiwan

**GOOD WILL INSTRUMENT (SUZHOU) CO., LTD.**

No. 69 Lushan Road, Suzhou New District Jiangsu, China.

declare that the below mentioned product

**Type of Product: Electrical Safety Tester**

**Model Number: GPT-9801, GPT-9802, GPT-9803, GPT-9804**

are herewith confirmed to comply with the requirements set out in the Council Directive on the Approximation of the Law of Member States relating to Electromagnetic Compatibility (2004/108/EC) and Low Voltage Directive (2006/95/EC).

For the evaluation regarding the Electromagnetic Compatibility and Low Voltage Directive, the following standards were applied:

| © EMC                                                             |                                                                                             |
|-------------------------------------------------------------------|---------------------------------------------------------------------------------------------|
| EN 61326-1<br>EN 61326-2-1                                        | Electrical equipment for measurement, control and laboratory use -- EMC requirements (2006) |
| Conducted Emission<br>Radiated Emission<br>EN55011: 2009+A1: 2010 | Electrostatic Discharge<br>EN 61000-4-2: 2009                                               |
| Current Harmonics<br>EN 61000-3-2: 2006+A2:2009                   | Radiated Immunity<br>EN 61000-4-3: 2006 +A2:2010                                            |
| Voltage Fluctuations<br>EN 61000-3-3: 2008                        | Electrical Fast Transients<br>EN 61000-4-4: 2004 +A2:2010                                   |
| -----                                                             | Surge Immunity<br>EN 61000-4-5: 2006                                                        |
| -----                                                             | Conducted Susceptibility<br>EN 61000-4-6: 2009                                              |
| -----                                                             | Power Frequency Magnetic Field<br>EN 61000-4-8: 2010                                        |
| -----                                                             | Voltage Dip/ Interruption<br>EN 61000-4-11: 2004                                            |

| Low Voltage Equipment Directive 2006/95/EC |                                          |
|--------------------------------------------|------------------------------------------|
| Safety Requirements                        | EN 61010-1: 2010<br>EN 61010-2-030: 2010 |

# INDEX

|                                 |          |                               |            |
|---------------------------------|----------|-------------------------------|------------|
| Accessories .....               | 12       | overview .....                | 35         |
| Automatic test                  |          | pass hold .....               | 49         |
| add test .....                  | 81       | ramp up time .....            | 45         |
| edit settings .....             | 80       | results .....                 | 61         |
| load .....                      | 78       | running a test .....          | 57         |
| page view .....                 | 84       | saving .....                  | 56         |
| results .....                   | 91       | special mode .....            | 69         |
| running a test .....            | 87       | test filename .....           | 46         |
| saving .....                    | 83       | test frequency .....          | 39         |
| test file name .....            | 82       | test function .....           | 38         |
| Caution symbol .....            | 5        | test limits .....             | 40         |
| Cleaning the instrument .....   | 7        | test reference .....          | 42         |
| Declaration of conformity ..... | 147      | test selection .....          | 33, 34, 36 |
| Dimensions .....                | 146      | test settings .....           | 37         |
| Disposal instructions .....     | 7        | test time .....               | 43         |
| EN61010                         |          | test voltage .....            | 38         |
| measurement category .....      | 6        | timing diagrams .....         | 62         |
| pollution degree .....          | 7        | Marketing                     |            |
| Environment                     |          | contact .....                 | 138        |
| safety instruction .....        | 7        | Menu tree .....               | 29         |
| Error messages .....            | 140, 141 | Operating precautions .....   | 24         |
| External control .....          | 95       | Package contents .....        | 13         |
| Interlock key .....             | 100      | Power on/off                  |            |
| overview .....                  | 96       | safety instruction .....      | 6          |
| remote operation .....          | 96       | Rear panel diagram .....      | 18         |
| remote terminal .....           | 96       | Remote control .....          | 101        |
| signal I/O operation .....      | 99       | Command list .....            | 109        |
| signal I/O overview .....       | 97       | Command syntax .....          | 106        |
| FAQ .....                       | 137      | function check .....          | 104        |
| Front panel diagram .....       | 14       | interface configuration ..... | 102        |
| GPIO installation .....         | 22       | Service operation             |            |
| Ground                          |          | about disassembly .....       | 6          |
| symbol .....                    | 5        | contact .....                 | 138        |
| Interlock key .....             | 100      | Specifications .....          | 142        |
| Line voltage selection .....    | 20       | UK power cord .....           | 8          |
| List of features .....          | 11       | Utility settings              |            |
| Manual tests                    |          | buzzer .....                  | 72         |
| ARC mode .....                  | 47       | Control settings .....        | 75         |
| fail hold .....                 | 50       | double action .....           | 75         |
| ground mode .....               | 52       | GPIO .....                    | 73         |
| max hold .....                  | 51       | interface .....               | 73         |
|                                 |          | key lock .....                | 75         |

|                     |    |                             |    |
|---------------------|----|-----------------------------|----|
| LCD.....            | 71 | Warning symbol.....         | 5  |
| RS232.....          | 73 | Workplace precautions ..... | 23 |
| start control ..... | 75 | Zeroing.....                | 66 |
| USB.....            | 73 |                             |    |