

Unit: mm

Head Specifications (Accessories)

Gage Head Mounting Fixtures

Mounting with a thrust stem

A thrust stem is available as an option for the **LG100**, and **LG200** gage heads. Installing a thrust stem on the stem allows direct mounting, simply by drilling a hole in a section of suitable thickness on the fixture.



For 10 mm LG100/LG200 Components Thrust stem: 02ADB681

Clamp nut: 02ADB682 Wrench: 02ADB683

Note: A mounting section with a thickness of 6 through 10.5 mm is suitable.


With the use of a thrust stem and clamp nut, a gage fixture can be arranged simply by drilling a 9.5 mm dia. hole. A gage can be secured firmly with ease with this arrangement.

IMPORTANT

In attaching a thrust stem, be sure to fix the stem first with a dedicated wrench (**02ADB683**). An excessive force applied between the gage main body and stem may cause damage to the gage.

NOT

Both the dedicated wrench (**02ADB683**) and M9.5×0.5 threaded section are for mounting a thrust stem. Do not use them for any purpose other than mounting a thrust stem.



For 25 mm **LG100** Components Thrust stem: **02ADN371**

Clamp nut: **02ADB692** Wrench: **02ADB693**

Note: A mounting section with a thickness of 10 through 12 mm is suitable.


With the use of a thrust stem and clamp nut, a gage fixture can be arranged simply by drilling an 18 mm dia. hole. A gage can be secured firmly with ease with this arrangement.

IMPORTANT

In attaching a thrust stem, be sure to fix the stem first with a dedicated wrench (02ADB693). An excessive force applied between the gage main body and stem may cause damage to a gage.

NOT

Both the dedicated wrench (**02ADB693**) and M14×0.5 threaded section are for mounting a thrust stem. Do not use them for any purpose other than mounting a thrust stem.



For 50 mm **LG100** Components Thrust stem: **02ADN371**

Clamp nut: 02ADB692 Wrench: 02ADB693

Note: A mounting section with a thickness of 10 through 12 mm is suitable.


With the use of a thrust stem and clamp nut, a gage fixture can be arranged simply by drilling an 18 mm dia. hole. A gage can be secured firmly with ease with this arrangement.

IMPORTAN^{*}

In attaching a thrust stem, be sure to fix the stem first with a dedicated wrench (**02ADB693**). An excessive force applied between the gage main body and stem may cause damage to a gage.

NOTE

Both the dedicated wrench (**02ADB693**) and M14×0.5 threaded section are for mounting a thrust stem. Do not use them for other purpose than mounting a thrust stem.



SPECIFICATIONS

Compatible gage		LG100/LG200 10 mm	LG100 25/50 mm
Order No.	Thrust stem set*	02ADB680	02ADN370
	Thrust stem	(02ADB681)	(02ADN371)
	Clamp Nut	(02ADB682)	(02ADB692)
	Wrench	02ADB683	02ADB693
Gage mounting hole diameter (nominal)		ø9.5 mm	ø18 mm
Recommended plate thickness (mounting section)		6 to 10.5 mm	10 to 12 mm