

# USER'S MANUAL



## AC DIELECTRIC TEST SET BK SERIES

**BK60**

**Version 3.1**

**Phenix Technologies, Inc.**

75 Speicher Drive  
Accident, Maryland 21520

Copyright © Phenix Technologies, Inc.

Rev 5/28/2015 nab

BK60



# TABLE OF CONTENTS


<u>DESCRIPTION</u>	<u>SECTION NUMBER</u>
DANGER / GENERAL SAFETY PRECAUTIONS	
TECHNICAL SPECIFICATIONS	1
UNCRATING PROCEDURE	2
CONTROLS AND INDICATORS	3
ELECTRICAL SET-UP	4
OPERATING INSTRUCTIONS	5
CALIBRATION	6
TROUBLESHOOTING	7
STORAGE OF EQUIPMENT	8
CIRCUIT DIAGRAM SYMBOLS	9
ELECTRICAL DIAGRAMS	10
PARTS LIST	11
PARTS ORDERING INFORMATION	12
RECOMMENDED SPARE PARTS	13
RETURNED MATERIAL	14
CUSTOMER COMMENTS / SUGGESTIONS	15

DANGER

## GENERAL SAFETY PRECAUTIONS



# CAUTION



## HIGH VOLTAGE

**This equipment is capable of providing POTENTIALLY LETHAL VOLTAGES! Improper operation or test practices may result in injury or death to the operator or surrounding personnel.**

**The operation of High Voltage test equipment should only be performed by personnel familiar with HIGH VOLTAGE testing and safety procedures. The operator of this equipment must be aware of all hazards associated with High Voltage testing. The operator is responsible for himself and others in close proximity of the testing area.**

**Some General Safety Practices for working with High Voltage Test Equipment have been listed below for your reference.**

- **Become familiar with your instrument before performing an actual test.**
- **Know your work area, check that all circuits are de-energized and locked out.**
- **Never work alone; always work with another qualified worker.**
- **Mark off entire work area with barriers and warning tape.**
- **Make all personnel aware of your testing activities.**
- **Be aware of dangerous conditions that may arise from energizing a test specimen.**
- **Never modify test equipment, modifications to equipment could introduce an unknown hazard or hinder a designed-in safety feature.**
- **DO NOT operate damaged equipment. Remove power, and do not use the equipment until safe operation can be verified by service-trained personnel.**

Phenix Technologies, Inc. assumes no liability for unsafe or improper use of test equipment.

## SECTION 1: TECHNICAL SPECIFICATIONS

### Input

110 - 120 volts, 50 / 60 Hz, single phase, 10 amperes

OR

208 - 240 volts, 50 / 60Hz, single phase, 5 amperes

### Output Rating

60 kilovolts, 10 mA

### Duty Cycle

5 MINUTES ON / 15 MINUTES OFF at 10 mA

1 HOUR ON/1 HOUR OFF at 7mA

CONTINUOUS at 5mA

### Type of Cooling

ONAN (Oil-Natural / Air-Natural)

### Distortion

Less than 5 percent at full load

### Impedance

Less than 10 percent at rated current

### Operating Ambient Temperature

0-40 degrees Celsius

### Output Termination

Toroid with output lead

### Metering

<b>Output Voltmeter:</b>	Display:	3 ½ digit LCD
	Accuracy:	±(0.8% of Reading +0.2% of Range)
	Ranges:	0 to 60 kV

<b>Output Currentmeter:</b>	Display:	3 ½ digit LCD
	Accuracy:	±(0.8% of Reading +0.2% of Range)
	Ranges:	0 to 200µA / 2mA / 20mA

### Sizes and Weights

Control Section:	16.5" (419 mm) W x 15.25" (388 mm) D x 11.25" (286 mm) H
	Weight: 31 pounds (14.1 kg)


HV Transformer:	14" (356 mm) W x 14" (356 mm) D x 16-7/8" (429 mm) H
	Weight: 66 pounds (29.9 kg)

## SECTION 2: UNCRATING PROCEDURE

1. Exercise care in removing shipping materials so as not to damage unit.
2. Perform visual inspection to determine if unit was damaged during shipment. If there are any signs of physical damage (such as dents, scratches, oil leaks), contact the factory before proceeding.
3. Pull the chassis from the case to check that all printed circuit boards are firmly in position. Visually inspect for any loose wires or components. (If any loose wires or components are found, refer to the appropriate circuit diagram.)

## SECTION 3: CONTROLS AND INDICATORS

FIGURE 3-1



### CONTROL PANEL

The following descriptions are keyed to Figure 3-1.

1. **Main Power Circuit Breaker.** Turns main power of unit on and off and provides input overload protection.
2. **Main Power Lamp.** Illuminates to indicate input power is supplied to unit.
3. **High Voltage On.** Momentary switch activates power to high voltage circuits when pre-required conditions are met. **Ready** lamp (4) must be illuminated before **High Voltage On** switch will operate. See requirements for **Ready** lamp under step 4. **High Voltage On** lamp illuminates to indicate high voltage circuits are energized.

## CONTROLS AND INDICATORS

### CONTROL PANEL (Cont'd)

4. **High Voltage Off/Ready.** Momentary switch turns high voltage off when activated. **Ready** lamp illuminates when all pre-conditions required for high voltage activation are met.

Conditions required for **Ready** lamp illumination are:

- Power applied to unit, **Main Power Breaker** (1) on, **Main Power** lamp illuminated (2).
  - **External Interlock** circuit series loop must not be open (10).
  - **Voltage Control** (5) must be at zero. (Zero Start)
  - Overcurrent circuit must be reset if **Reset** lamp is illuminated (7).
5. **Voltage Control.** Turn clockwise to raise output voltage. High voltage cannot be activated if **Voltage Control** is not started at zero.
  6. **Overcurrent Trip Adjust.** Dial adjusts from 1 to 11 corresponding to 10% to 110% of rated output current (10mA). **Overcurrent Trip/Reset** lamp illuminates and high voltage turns off when output current exceeds setting, causing circuit to trip. Circuit also acts as short circuit and overload protection on high voltage output. To reactivate high voltage, **Voltage Control** (5) must be returned to zero, and **Overcurrent Reset** switch (7) must be pressed to clear overcurrent circuit.
  7. **Overcurrent Reset.** **Reset** lamp illuminates to show that overcurrent circuit has tripped. High voltage circuits are deactivated. Momentary **Reset** switch must be pressed to extinguish **Reset** lamp to allow high voltage to be reapplied after returning **Voltage Control** (5) to zero.
  8. **Currentmeter.** Displays output current of test set, units based on current meter range setting.
  9. **Voltmeter.** Displays output voltage of test set, units in kilovolts.
  10. **Ext. Intlk. – SX1.** Provides for user connection of external interlock or auxiliary safety control device such as emergency off switch, gate switch, foot switch, dead man switch, etc. Included plug has shorting jumper installed to complete circuit. Jumper must be removed and cable connected to user supplied device by user if desired to use this provision. Only non-energized switch or dry relay contact devices may be used. This is a series 120VAC circuit that must remain closed for high voltage to be activated.
  11. **TX2.** Provided interconnect cable is connected here and to the same designation connector on the high voltage unit. This is the metering and return connection. **CAUTION: Do not attempt to operate high voltage unit without this cable connected at both ends.**
  12. **TX1.** Provided power interconnect cable connects here and to the same designation connector on high voltage unit.
  13. **Line Cord.** Supplies input power to unit. (Line Cord supplied)
  14. **CM Range.** Turn to select the desired current measurement range.
  15. **Test Cell Timer** – Press START/RESET to start the timer after test voltage has been reached. Press START/RESET again to reset timer to the original setting. Press HV OFF BYPASS to allow high voltage to remain on after the timer has expired. Test time can be set using the buttons on the face of the timer.



## SECTION 4: ELECTRICAL SET-UP

### WARNING:

**Be sure the Main Power plug of the control unit is unplugged before proceeding.**

1. Locate the desired location for the test set. Prepare the main power input cable for plugging in to the proper facility power (i.e., 120 volts AC or 220 volts AC). Leave plug unconnected at this time.
2. Connect a sufficient ground from the ground stud on the base of the high voltage transformer to a proper facility ground using a low inductance cable rated for 20 amperes or greater, or the supplied 10 AWG GND cable.
3. Connect **TX1** and **TX2** interconnect cables between controls and high voltage transformer.
4. External Interlock

If an external interlock is not to be used, plug the connector as supplied into the socket on the control panel marked **EXT INTLK, SX1**, if not already in place.

If an external interlock is to be used, remove the jumper on the plug of the **EXT INTLK** circuit and connect the external security circuit at these points. (NOTE: The external interlock circuit must consist of a closed loop of dead contacts. When the control power is on, the external circuit will be energized with 120 volts AC.)

### High Voltage Connection

### WARNING:

**Main power circuit breaker on the front panel must be in the OFF position before proceeding. Test specimen must be de-energized and discharged.**

1. Connect the low side (return) of test specimen to the return post with the provided red test lead. See Ground-Guard-Return connection instructions on following pages.
2. Connect the high side of test specimen to the toroid on top of the HV tank. If using the supplied high voltage cable, keep the cable suspended away from all ground or non-related potential points.
3. Check that the control circuit breaker is turned off and connect input main power cable to a suitable grounded receptacle

Brief connection instructions and diagram on following pages.

## ELECTRICAL SET-UP

### CONNECTIONS AND GROUNDING

- Position set in the desired location.
- Ground set by use of ground terminal on base of high voltage transformer.
- Connect **TX1** and **TX2** cables between controls and high voltage transformer.
- Connect **SX1** - external interlock circuit as appropriate.
- Connect return lead, provided, to low potential side of test specimen. See Ground-Guard-Return connection instructions on following pages.
- Connect high potential side of test specimen to high voltage output.
- Connect main power cord to appropriate receptacle.

(Further instructions on test connections may be found in ANSI C37-60.)

## ELECTRICAL SETUP

### GROUND-GUARD-RETURN CONNECTIONS

The base of the High Voltage transformer contains a currentmeter feature useful in measurement of different current sources.

#### 1. **Standard Mode (RTN)**

The standard configuration is set up to measure the current from the high potential side of the unit under test to ground. This configuration **must** be used if it is not possible to isolate the low voltage side of the object under test from ground.

The low potential side of the unit under test is connected directly to ground. The binding post Jumper Clip is installed between the Ground (GND) and the Return (RTN) posts on the base of the HV Transformer.

This measures the output current flowing from the high voltage output through the unit under test to ground and the current meter then senses the return current from ground to the RTN terminal of the high voltage transformer.

#### 2. **Guard Mode**

For test objects that can be fully isolated from ground it may be desirable to use the Guard Mode. In this mode only current passing through the test object will be displayed on the current meter. This will be especially important if very small currents are to be observed.

In this mode the current path does not flow directly to ground from the low potential side of the unit under test, but flows through the currentmeter first and then to ground.

The connection to be made is (1) connect the low potential side of the unit under test directly to the Return post (RTN) and (2) connect the jumper clip between the Guard (GRD) and Ground (GND) posts. (NOTE: Ensure the Ground (GND) post is grounded.)


### **CAUTION**

***If the test specimen is not fully isolated from ground, the current meter will either not work, or not display accurate current readings, and this mode should not be used.***


# ELECTRICAL SETUP

FIGURE 4-1

STANDARD MODE



GUARD MODE



## SECTION 5: OPERATING INSTRUCTIONS

### WARNING:

This unit should only be operated by personnel knowledgeable in High Voltage testing and safety procedures. Improper or careless operation of unit can result in serious injury or death.

1. Ensure proper electrical set-up has been performed. Ensure that the testing set-up is safe for the operator and any other personnel in the area.
2. Check that the **Raise Voltage** dial is set to "0" (zero start position).
3. Set the **Overcurrent Trip** to the desired current level setpoint. Setting of "1" will trip off the unit when drawing 10% of rated output current. Setting of "11" will trip off the unit when drawing 110% of rated output current.

### High Voltage Applied

4. Turn on the front panel circuit breaker. Control Power lamp will illuminate.
5. Ready lamp must be illuminated to proceed further. If not illuminated, check zero start (Step 2 above), check for open external interlock circuit, and make sure overcurrent lamp is off. (Push RESET if overcurrent lamp is on.)
6. Press HV On push-button. High voltage will turn on and high voltage lamp will illuminate.
7. Rotate the Raise Voltage dial and watch the Output Voltage and Output Currentmeter until desired levels are reached.
8. Record data, if desired, and lower the output after testing is completed. Press HV Off button; high voltage will be shut off.

### Overcurrent Failure

9. If an overcurrent situation occurs, the overcurrent lamp will illuminate and high voltage will be shut off. To regain high voltage, the Raise Voltage dial must be returned to zero and the Overcurrent Reset button must be depressed (lamp will extinguish).
10. After all testing is complete, turn off the front panel circuit breaker. Remove the input power cable from the facility power input.

## SECTION 6: CALIBRATION

### CAUTION:


Calibration should only be done by persons familiar with High Voltage testing and safety procedures.

All calibrations have been done at the factory. Periodic calibration of the output voltmeter and output currentmeter should be done annually.

NOTE: Refer to Electrical Diagram Section for schematic pertaining to the model number of your test set.

### Locating the Calibration Adjustments

The calibration points are shown in the following diagram.



#### 1. Output Voltmeter

Voltmeter is peak responding calibrated to  $\text{Peak}/\sqrt{2}$  (RMS value of sine wave).

Connect a precision high voltage voltmeter between the 50kV output (top of tank) to ground. Raise the output to approximately 80% of the rated output voltage. Adjust the reading on the panel meter (M2) by means of potentiometer R2 to a corresponding reading. Check linearity at several points from 20% to 100% of rated tap voltage.

## CALIBRATION

### 2. Output Currentmeter

It is necessary to connect adequately rated High Voltage loads (isolated from ground) to the high voltage unit that will allow each full range current to be drawn at approximately 15% or higher output voltage. This allows sufficient resolution to adjust current levels.

Place Binding Post Configuration in GUARD MODE. (Jumper clip is installed between GRD and GND posts.)

Connect a precision ammeter between the low potential side of the appropriate high voltage load and the RTN post. Select the 200 $\mu$ A currentmeter range. Raise the output to approximately 80% of the range. Adjust the reading on the panel meter (M1) by means of potentiometer R204 to a corresponding reading. Repeat for 200 $\mu$ A, 2mA and 20mA ranges adjusting R203 and R202, respectively. (High Voltage load will need to change when changing range).

An optional method is to use current injection between RTN and GND (Guard Mode). *Do not turn High Voltage On for this method!*

### 3. Overcurrent

This calibration should not need adjustment (factory adjusted). If the overcurrent circuit is out of calibration, perform the following steps.

- a. With unit off, short the output terminal to ground through an appropriate currentmeter. NOTE: A High Voltage Load will give better resolution and make calibration easier.
  - b. Set the Current Trip potentiometer on the front panel to "1" and current range switch to High.
  - c. Turn on HV On and adjust the output current slowly until 10% of rated current (check nameplate) is displayed on the currentmeter.
  - d. Adjust potentiometer R101 until the Reset lamp illuminates and high voltage is shut off.
  - e. Set the Current Trip potentiometer on front panel to "11".
  - f. Turn on HV On and adjust the output current slowly until 110% of rated current is displayed on meter.
  - g. Adjust potentiometer R103 until the Overload lamp illuminates and high voltage is shut off.
  - h. Repeat steps "b" through "g" as necessary until both settings are calibrated.
4. Range Overcurrent. R235 sets an overcurrent for the ranges and should be set to trip at approximately 110% of full range current on medium range setting with current trip potentiometer set at "11".

## SECTION 7: TROUBLESHOOTING

### General

If the controls do not operate properly after having been used according to the instructions, the following hints may help.

- Check main facility input power to the test set.
- Check indicating lamps. (Spare lamps are available through Phenix Technologies.)
- Check operation of the circuit breaker (CB1). Control Power lamp should be on when the circuit breaker is on.
- Check fuses.
- Check all plug connections on the test set, internal and external.

### Specific Problems

#### 1. High voltage cannot be turned on?

- External interlock is open.
- Raise Voltage dial is not in lower limit position.
- Protection circuit (Overcurrent) is not reset.
- Faulty relay contacts.
- Faulty HV On switch.
- Faulty Reset Switch.

#### 2. Voltage control inoperable?

- High voltage is not on (K3 not energized or see number 1 above).
- Faulty variable auto-transformer, T1.
- Faulty high voltage transformer.

#### 3. Overcurrent inoperable?

- Improper sensitivity (adjust Overcurrent Trip, R1, on front panel).
- Defective U101 or SCR101 on PCB 1257.
- Check the unregulated +22 volts DC and the +15 volts DC regulator output at TP5.
- Check signal input voltage to PCB 1257 at Connector 4-4.
- Check overcurrent lamp on the panel and relay K101 on PCB 1257.

#### 4. Currentmeter inoperable?

- Connections between the test set and the test specimen are open
- No output from the  $\pm 15$ VDC power supply on PCB 1257.
- Current meter range switch (SW5) between detents.
- Meter defective.
- No +5VDC power to the meter from PCB 1257.



## TROUBLESHOOTING

### Specific Problems (Cont'd)

#### 5. Voltmeter inoperable?

- High voltage output shorted to ground.
- No output from the  $\pm 15\text{VDC}$  power supply on PCB 1257.
- Meter defective.
- No high voltage present at the test set output.
- No  $+5\text{VDC}$  power to the meter from PCB 1257.

#### 6. No output voltage from high voltage section?

- Defective metering circuit.
- No input to voltage regulator section, possible problems with K3 contacts, variable transformer, or with CB1.
- Shorted high voltage output.
- Defective high voltage output transformer.
- Defective TX1 cable or connector.

## **SECTION 8: STORAGE OF EQUIPMENT**

If the equipment will be stored for a prolonged period, the following precautions are recommended.

1. The equipment should be covered and kept in a warm, dry environment (95% maximum humidity, 5 to 50 degrees C).
2. In no case should the test unit be stored outdoors (unless previously specified in the original purchase agreement).

## SECTION 9: CIRCUIT DIAGRAM SYMBOLS

CIRCUIT DIAGRAM SYMBOLS  
SYMBOLS POUR SCHEMA DE CIRCUIT  
SYMBOLE ZU SCHEMA

REF	SYMBOL	DESCRIPTION	DESCRIPTION	BEMENKUNG
A		Amplifier	Unite d'amplificateur	Verstärker
ARSR		Surge Arrestor	Parafoudre	Ueberspannungsableiter
C		Capacitor	Condensateur	Kondensator
BSHG		Bushing	Traversee	Durchfuehung
C		Electrolytic Capacitor	Condensateur électrol	Eleckrolytik kondensator
F		Fuse	Fusible	Sicherung
CT		Current Transformer	Transformateur de Courant	Stromtransformer
CB		Circuit Breaker	Intérupteur	Unterbrecher
K		Relay, Contactor	Relais, Contacteur	Relais, Schütz
L		Inductor	Self	Drossel, Spule
MOT		Motor	Moteur	Motor
MOV		Movistor	Parafoudre	Movistor
NE		Neon	Parafoudre	Ueberspannungsableiter
LP		Lamp, Indicator	Lampe	Meldeleuchte
R		Resistor	Resistance	Widerstand
R		Variable Resistor	Resistance Variable	Widerstand
T		Transformer	Transformateur	Transformer
TB		Terminal Block	Borne	Lösbare Klemme
X		Connector	Prise de Courant	Steckverbindung
K		Relay Contact Normally Open	Contact Normalement Ouvert	Schlierskontakt
K		Relay Contact Normally Closed	Contact Normalement Fermé	Oeffnungskontakt
K		Changeover Contact	Contact de Changement	Umschaltkontakt
		Shielded Wire	Cable blindé	Abgeschirmetes Kabel
TR		Transistor	Transisteur	Transistor
M		Analog Meter	Insrument Analogue	Analog Meter
D		Diode	Diode	Diode
Z		Zener	Diode Zener	Zener
SCR		Thyristor	Thyristor	Thyristor
SW		Normally Open Maintained Switch	Interrupteur Normalement Maintenu Ouvert	Schrittschalter (Schliesser)
SW		Normally Closed Maintained Switch	Interrupteur Normalement Maintenu Fermé	Schrittschalter (Oeffner)
SW		Normally Closed Momentary Switch	Interrupteur Normalement Fermé Momentanement	Druckschalter (Oeffner)
SW		Normally Open Momentary Switch	Interrupteur Normalement Ouvert Momentanement	Druckschalter (Schliesser)
DP		Current Overload Device	Dispositif De Sûr Intensité	UeberstromschutzEinheit

**SECTION 10: ELECTRICAL DIAGRAMS**

<b><u>Drawing Number</u></b>	<b><u>Description</u></b>
1. 9602100	BK-60 (120V, 60 Hz) ELECTRICAL SCHEMATIC
2. 9602102	BK-60 (220V, 50/60 Hz) ELECTRICAL SCHEMATIC

## SECTION 11: BK-60 PARTS LIST

ITEM	DESCRIPTION	QTY	PART NO.
<b>CONTROLS</b>			
A1	PCB1257 METER/OVERLOAD BD (BK60)	1	31125708
CB1 (220V)	CIRCUIT BREAKER, 5 AMP, 2-POLE	1	1601303
CB1 (120V)	CIRCUIT BREAKER, 10APM, 1-POLE	1	1601310
CB1 (120V)	CKT BRKR HOLE COVER	1	1601395
CORD	INPUT POWER CORD	1	1077140
F1 (220V)	FUSE, 2 AMP	1	1603622
F1 (120V)	FUSE, 1 AMP	1	1603601
F1, F2	FUSE HOLDER	1	1603920
F2	FUSE, 5 AMP	1	1603625
K3	RELAY, 2 POLE	1	1700600
LP1 LENS	CLEAR LENS EAO	1	1422153
LP1 SOCKET	LAMP SOCKET EAO	1	1423300
LMP1, SW1, SW2, SW4	LAMP 60V EAO	4	1420150
M1, M2	METER, DIGITAL, 3 ½ DIGIT	2	1506400
M1, M2	CONNECTOR, 10 CKT, 0.1	2	1152210
M1	METER PROT BOARD (ZENERS ONLY)– PCB1265	1	31126500
M2	METER PROTECTION BOARD – PCB1265	1	31126501
MOV1 (220V)	MOVISTOR, V275LA40A	1	1606110
MOV1 (120V)	MOVISTOR, V130LA10A	1	1606100
P1	POWER INPUT RECEPTACLE	1	1153328
R1	POTENTIOMETER, LINEAR, 10K, 2W	1	1761098
R1 DIAL	BLACK STATOR	1	1355905
R1 DIAL	0-11 NUMBERED DIAL	1	1355910
R1 KNOB	BLACK KNOB	1	1355101
R1 KNOB	KNOB CAP	1	1355102
R2	RESISTOR, 30k, .25W	1	1722570
R3	RESISTOR, 3.0k, .25W	1	1722087
R4	RESISTOR, 300 OHMS, .5W	1	1720600
SW1 LENS	LENS, GREEN EAO	1	1422151
SW1,2,4	SWITCH, PUSHBUTTON, MOMENTARY, 1-POLE	3	1860120
SW2 LENS	LENS, RED EAO	1	1422150
SW3	SWITCH, ROLLER, CAM, ZERO START	1	1866005
SW4 LENS	LENS, BLUE EAO	1	1422148
SW5 KNOB	KNOB, ¼"	2	1355310
SW5	SWITCH, ROTARY, 4-POSITION	1	1863042
SW10	SWITCH LATCHING 2-POLE	1	1860265
SW10	LAMP 60V	1	1420150
SW10,11	LENS CLEAR	2	1422153
SW11	SWITCH LATCHING 1-POLE	1	1860260

## BK 60 PARTS LIST

ITEM	DESCRIPTION	QTY	PART NO.
<b>CONTROLS CONTINUED</b>			
SX1	RECEPTACLE, 4F PINS, SIZE 11	1	1151152
SX1	CONTACT PINS, 24-20AWG, FEMALE	1	1151174
SX1 PLUG	CABLE PLUG, 4M PINS, SIZE 11	1	1151162
SX1 PLUG	CABLE CLAMP, SIZE 11	1	1151186
SX1 PLUG	CONTACT PINS, 24-20AWG, MALE	1	1151176
TMR1	PANEL MOUNT DIGITAL TIMER	1	1480120
T1 (220V)	STACO 1020B VARIABLE TRANSFORMER	1	1890204
T1 (120V)	STACO 1010B VARIABLE TRANSFORMER	1	1890200
T2 (220V ONLY)	TRANSFORMER, 50VA, #MT0050A	1	1896017
TX1	RECEPTACLE, HIGH CURRENT, 3F PINS, SIZE 17	1	1151179
TX1	FEMALE CONTACT PINS, 16-12AWG	2	1151184
TX2	RECEPTACLE, 9M PINS, SIZE 13	1	1151154
TX2	MALE CONTACT PINS, 24-20AWG	7	1151170

ITEM	DESCRIPTION	QTY	PART NO.
<b>HV TRANSFORMER</b>			
BP-GROUND	BINDING POST, GREEN	1	1351103
BP-GUARD	BINDING POST, WHITE	1	1351104
BP-RETURN	BINDING POST, RED	1	1351102
SHORTING BAR	BINDING POST SHORTING BAR	1	1351110
D3001-3004	TRANSORB, 5KP13A	4	1780066
D3005	TRANSORB, 1.5KE18C	1	1780069
MOV3001-3003	MOVISTOR, V275LA40A (220V)	3	1606110
MOV3001-3003	MOVISTOR, V130LA10A (120V)	3	1606100
R3001	RESISTOR, 200 MEG, 10 W, 1%	1	1748415
R3002A,B	RESISTOR, 1.2k OHM, 0.25W	2	1722048
SPG3001-3002	SPARK GAP, CG90L, 90V	2	1605110
T3001	HIGH VOLTAGE TRANSFORMER, GO1-2151	1	38342151
TX1	RECEPTACLE, HIGH CURRENT, 3M PINS, SIZE 17	1	1151178
TX1	MALE CONTACT PINS, 16-12AWG	2	1151182
TX1	SIZE 17 CAP	1	1151196
TX2	RECEPTACLE, 9M PINS, SIZE 13	1	1151154
TX2	MALE CONTACT PINS, 24-20AWG	7	1151170
TX2	SIZE 13 CAP	1	1151195
<b>INTERCONNECT CABLES</b>			
TX1 CABLE	POWER INTERCONNECT CABLE – 10 FT.	1	30110013
TX2 CABLE	SIGNAL INTERCONNECT CABLE- 10 FT	1	30060008
GND CABLE	10 FT. GROUND CABLE ASSY.	1	30080008
HV CABLE	10 FT. HV CABLE ASSY.	1	30080009
RTN CABLE	10 FT. SPECIMEN RETURN CABLE ASSY.	1	30080009

## SECTION 12: PARTS ORDERING INFORMATION

Replacement parts are available from Phenix Technologies, Inc.

Changes to Phenix Technologies' products are sometimes made to accommodate improved components as they become available, and to give you the benefit of the latest technical improvements developed in our Engineering Department. It is, therefore, important when ordering parts to include the serial number of the unit as well as the part number of the replacement part.

When a purchase order is received at our office, a representative of Phenix Technologies will contact you to confirm the current price of the part being ordered. If a part you order has been replaced with a new or improved part, an Applications Engineer will contact you concerning any change in part number.

Send orders for replacement parts to:

Service Department  
Phenix Technologies, Inc.  
75 Speicher Drive  
Accident, Maryland 21520

Ph 1 (301) 746-8118  
Fax: 1 (301) 895-5570  
E-mail: [info@phenixtech.com](mailto:info@phenixtech.com)

## SECTION 13: RECOMMENDED SPARE PARTS

Phenix Technologies recommends that the customer purchase and stock the following parts for normal maintenance of the unit. The recommended quantity should be sufficient to support the unit during normal operation.

If the unit will be operated at an isolated site for an extended period or will be subjected to unusual stresses, a larger quantity of parts should be stocked as spares. In such a case, contact your Phenix Technologies' sales representative for a recommendation.

Current prices may be obtained by contacting the Service Department at Phenix Technologies.

<b><u>Part Name</u></b>	<b><u>Computer Number</u></b>	<b><u>Recommended Quantity</u></b>
Digital Panel Meter, 3 ½ DIGIT LCD	1506400	1
Lamps, 31-963.4 (60 V)	1420150	5
Limit Switch, 2HBA190-1	1866005	1
Relay, 2 Pole	1700600	1
Control Power Fuse, 1A (220V)	1603601	2
Control Power Fuse, 2A (120V)	1603622	2
Variable Transformer Fuse, 5A	1603625	2
Movistor, V275LA40A (220V)	1606110	4
Movistor, V130LA10A (120V)	1606100	4
Panel Switch, 31-121- Momentary, 1 Pole	1860120	1



## SECTION 14: RETURNED MATERIAL

If for any reason it should become necessary to return this equipment to the factory, the Service Department of Phenix Technologies, Inc. must be given the following information:

Name Plate Information

Model Number

Serial Number

Reason for Return

Cause of Defect

If Phenix Technologies, Inc. deems return of the part appropriate; it will then issue an "Authorization for Return." If return is not deemed advisable, other inspection arrangements will be made. **NOTE:** Material received at this plant without the proper authorization shall be held as "Customer's Property" with no service until such time as the proper steps have been taken.

Your cooperation is requested in order to ensure prompt service.

