

# R&S®NGU

## Source Measure Units

### Getting Started



1179247702  
Version 02

**ROHDE & SCHWARZ**  
Make ideas real



This manual describes the following R&S®NGU models with firmware version 1.00 and higher:

- R&S®NGU201 2-QUADRANT SMU (3639.3763.02)
- R&S®NGU401 4-QUADRANT SMU (3639.3763.03)

© 2020 Rohde & Schwarz GmbH & Co. KG

Mühldorfstr. 15, 81671 München, Germany

Phone: +49 89 41 29 - 0

Email: [info@rohde-schwarz.com](mailto:info@rohde-schwarz.com)

Internet: [www.rohde-schwarz.com](http://www.rohde-schwarz.com)

Subject to change – data without tolerance limits is not binding.

R&S® is a registered trademark of Rohde & Schwarz GmbH & Co. KG.

Trade names are trademarks of the owners.

1179.2477.02 | Version 02 | R&S®NGU

Throughout this manual, products from Rohde & Schwarz are indicated without the ® symbol, e.g. R&S®NGU are indicated as R&S NGU.

# Safety Instructions

## Instrucciones de seguridad

### Sicherheitshinweise

### Consignes de sécurité

---

#### **WARNING**

##### **Risk of injury and instrument damage**

The instrument must be used in an appropriate manner to prevent electric shock, fire, personal injury or instrument damage.

- Do not open the instrument casing.
  - Read and observe the "Basic Safety Instructions" delivered as printed brochure with the instrument.
  - Read and observe the safety instructions in the following sections. Note that the data sheet may specify additional operating conditions.
  - Keep the "Basic Safety Instructions" and the product documentation in a safe place and pass them on to the subsequent users.
- 

#### **ADVERTENCIA**

##### **Riesgo de lesiones y daños en el instrumento**

El instrumento se debe usar de manera adecuada para prevenir descargas eléctricas, incendios, lesiones o daños materiales.

- No abrir la carcasa del instrumento.
  - Lea y cumpla las "Instrucciones de seguridad elementales" suministradas con el instrumento como folleto impreso.
  - Lea y cumpla las instrucciones de seguridad incluidas en las siguientes secciones. Se debe tener en cuenta que las especificaciones técnicas pueden contener condiciones adicionales para su uso.
  - Guarde bien las instrucciones de seguridad elementales, así como la documentación del producto, y entréguelas a usuarios posteriores.
-



## **WARNUNG**

### **Gefahr von Verletzungen und Schäden am Gerät**

Betreiben Sie das Gerät immer ordnungsgemäß, um elektrischen Schlag, Brand, Verletzungen von Personen oder Geräteschäden zu verhindern.

- Öffnen Sie das Gerätegehäuse nicht.
  - Lesen und beachten Sie die "Grundlegenden Sicherheitshinweise", die als gedruckte Broschüre dem Gerät beiliegen.
  - Lesen und beachten Sie die Sicherheitshinweise in den folgenden Abschnitten; möglicherweise enthält das Datenblatt weitere Hinweise zu speziellen Betriebsbedingungen.
  - Bewahren Sie die "Grundlegenden Sicherheitshinweise" und die Produktdokumentation gut auf und geben Sie diese an weitere Benutzer des Produkts weiter.
- 



## **AVERTISSEMENT**

### **Risque de blessures et d'endommagement de l'appareil**

L'appareil doit être utilisé conformément aux prescriptions afin d'éviter les électrocutions, incendies, dommages corporels et matériels.

- N'ouvrez pas le boîtier de l'appareil.
  - Lisez et respectez les "consignes de sécurité fondamentales" fournies avec l'appareil sous forme de brochure imprimée.
  - Lisez et respectez les instructions de sécurité dans les sections suivantes. Il ne faut pas oublier que la fiche technique peut indiquer des conditions d'exploitation supplémentaires.
  - Gardez les consignes de sécurité fondamentales et la documentation produit dans un lieu sûr et transmettez ces documents aux autres utilisateurs.
-



이 기기는 업무용(A급) 전자파  
적합기기로서 판매자 또는  
사용자는 이 점을 주의하시기  
바라며, 가정외의 지역에서  
사용하는 것을 목적으로 합니다.

# Contents

<b>1 Documentation Overview.....</b>	<b>5</b>
1.1 Manuals.....	5
1.2 Data Sheet.....	6
1.3 Release Notes, Open Source Acknowledgment.....	6
<b>2 Welcome to R&amp;S NGU.....</b>	<b>7</b>
<b>3 Putting into Operation.....</b>	<b>8</b>
3.1 Safety.....	10
3.2 Intended Operation.....	11
3.3 Unpacking and Checking the Instrument.....	12
3.4 Setting Up the Instrument.....	14
3.4.1 Bench Operation.....	14
3.4.2 Rack Mounting.....	14
<b>4 Instrument Tour.....</b>	<b>15</b>
4.1 Overview of Controls.....	15
4.1.1 Front Panel.....	15
4.1.2 Rear Panel.....	17
4.2 Switching On the Instrument.....	20
<b>5 Trying Out the Instrument.....</b>	<b>22</b>
5.1 Setting the Output Voltage and Current.....	22
5.2 Activating the Channel Output.....	22
<b>6 Maintenance and Support.....</b>	<b>24</b>

**6.1 Maintenance..... 24**

**6.2 Contacting Customer Support.....24**

**Index..... 26**

# 1 Documentation Overview

This section provides an overview of the R&S NGU user documentation.

## 1.1 Manuals

You find the documents on the R&S NGU product page at:

[www.rohde-schwarz.com/manual/ngu](http://www.rohde-schwarz.com/manual/ngu)

### Getting Started

Introduces the R&S NGU source measure units and describes how to set up and start working with the instrument. The printed document is delivered with the instrument.

### User manual

Contains the description of all instrument modes and functions. It also provides an introduction to remote control, a complete description of the remote control commands with programming examples, and information on maintenance and instrument interfaces. Includes the contents of the getting started manual.

The *online version* of the user manual provides the complete contents for immediate display on the internet.

### Basic safety instructions

Contains safety instructions, operating conditions and further important information. The printed document is delivered with the instrument.

### Service manual

Describes the performance test for checking the rated specifications, module replacement and repair, firmware update, troubleshooting and fault elimination, and contains mechanical drawings and spare part lists. The service manual is available for registered users on the global Rohde & Schwarz information system (GLORIS, <https://gloris.rohde-schwarz.com>).



## 1.2 Data Sheet

The datasheet contains the technical specifications of the R&S NGU source measure units. It also lists all options with their order numbers and accessories.

See [www.rohde-schwarz.com/brochure-datasheet/ngu](http://www.rohde-schwarz.com/brochure-datasheet/ngu)

## 1.3 Release Notes, Open Source Acknowledgment

The release notes list new features, improvements and known issues of the current firmware version, and describe the firmware installation. The open source acknowledgment document provides verbatim license texts of the used open source software. It can also be read directly on the instrument.

See [www.rohde-schwarz.com/firmware/ngu](http://www.rohde-schwarz.com/firmware/ngu).

## 2 Welcome to R&S NGU

The single source measure units are based on a classical transformer concept with linear regulators. This concept allows the instrument to achieve highest accuracy and lowest residual ripple.

Multi-purpose protection functions are available which you can set separately, such as overcurrent protection (OCP), overvoltage protection (OVP) and over-power protection (OPP). If such a limit is reached, the affected output is automatically turned off and an indicator icon (Ⓢ, Ⓜ, Ⓟ) blinks on the display.

Additionally, the R&S NGU is protected with overtemperature protection (OTP). This safety feature protects the R&S NGU from overheating. When the temperature in the source measure unit exceeds the OTP limit, the output is automatically cut off.

The Arbitrary function allows a freely definable voltage and current sequences with a timeframe as short as 100  $\mu$ s. It allows varying the voltage or current during a test sequence, for example to simulate different charging conditions of a battery. With "Ramp" function, the R&S NGU provides the operating condition to ramp up the supply voltage within a defined timeframe of 10 ms to 10 s.

All R&S NGU source measure units are equipped with a color TFT display (800 pixels x 480 pixels) and enhanced with touch input capability. The R&S NGU can be remotely controlled via USB, LAN (LXI) interface and optional GPIB option.

The digital I/O interface installed at the rear panel is activated with an option, it allows a single trigger-in signal to control multi trigger-out signals on the source measure unit, providing many possibilities to control outputs and associated devices in the event when a trigger occurs.

The user manual contains description of the functionalities that the instrument provides. The latest version is available for download at the product homepage (<http://www.rohde-schwarz.com/product/ngu>).

## 3 Putting into Operation

This chapter describes how to set up the R&S NGU source measure units for the first time.

---

**⚠ WARNING****Risk of injury due to disregarding safety information**

Observe the information on appropriate operating conditions provided in the data sheet to prevent personal injury or damage to the instrument. Read and observe the basic safety instructions provided with the instrument, in addition to the safety instructions in the following sections. In particular:

- Do not open the instrument casing.
- 

**NOTICE****Risk of instrument damage due to inappropriate operating conditions**

Specific operating conditions are required to ensure accurate measurements and to avoid damage to the instrument. Observe the information on appropriate operating conditions provided in the basic safety instructions and the instrument's data sheet.

---

**NOTICE****Instrument damage caused by electrostatic discharge**

Electrostatic discharge (ESD) can damage the electronic components of the instrument and the device under test (DUT). Electrostatic discharge is most likely to occur when you connect or disconnect a DUT or test fixture to the instrument's test ports. To prevent electrostatic discharge, use a wrist strap and cord and connect yourself to the ground, or use a conductive floor mat and heel strap combination.

---

**NOTICE****Risk of instrument damage during operation**

An unsuitable operating site or test setup can cause damage to the instrument and the connected devices. Ensure the following operating conditions before you switch on the instrument:

- The instrument is dry and shows no sign of condensation
- The instrument is positioned as described in [Chapter 3.4.1, "Bench Operation"](#), on page 14
- The ambient temperature does not exceed the range specified in the data sheet
- Signal levels at the input connectors are all within the specified ranges
- Signal outputs are correctly connected and not overloaded

**EMI impact on measurement results**

Electromagnetic interference (EMI) may affect the measurement results.

To suppress generated electromagnetic interference (EMI):

- Use suitable shielded cables of high quality. For example, use double-shielded RF and LAN cables.
- Always terminate open cable ends.
- Note the EMC classification in the data sheet.

## 3.1 Safety

### NOTICE

#### Recommendations on secure operation

The R&S NGU is designed to operate at local workplaces or in secured networks (LAN). It should not be accessible from the internet, because of a potential security risk, e.g. attackers could misuse or damage your device.

Please always install the latest firmware.

It is highly recommended that you work closely with your IT department or system administrator to ensure compliance with your company policies when connecting devices to your company's network.

This instrument was built in compliance with DIN EN 61010-1, safety regulations for electrical instruments, control units and laboratory equipment.

It has been tested and shipped from the plant in safe condition. It is also in compliance with the regulations of the European standard EN 61010-1 and the international standard IEC 61010-1.

To maintain this condition and ensure safe operation, you must observe all instructions and warnings given in this user manual. Casing, chassis and all measuring ports are connected to a protective earth conductor. The instrument is designed in compliance with the regulations of protection class I.

For safety reasons, the instrument may only be operated with authorized safety sockets. The power cable must be plugged in before signal circuits may be connected.

Never use the product if the power cable is damaged. Check regularly if the power cables are in perfect condition. Choose suitable protective measures and installation types to ensure that the power cable cannot be damaged and that no harm is caused by tripping hazards or from electric shock, for instance.

### DANGER

#### Risk of electric shock

It is prohibited to disconnect the earthed protective connection inside or outside of the instrument!

If it is assumed that a safe operation is no longer possible, the instrument must be shut down and secured against any unintended operation.

Safe operation can no longer be assumed when:

- Instrument shows visible damage
- Instrument includes loose parts
- Instrument no longer functions properly
  - After an extended period of storage under unfavorable conditions (e.g. outdoors or in damp rooms)
  - After rough handling during transport (e.g. packaging that does not meet the minimum requirements by post office, railway or forwarding agency)

---

**⚠ DANGER****Exceeding the low voltage protection**

Use insulated wires and not bare wires for the terminal connection.

It is assumed that only qualified and trained personnel service the source measure units and the connected loads.

---

Before switching on the product, it must be ensured that the nominal voltage setting on the product matches the nominal voltage of the AC supply network.

## 3.2 Intended Operation

The instrument is intended only for use by personnel familiar with the potential risks of measuring electrical quantities.

For safety reasons, the instrument may only be connected to properly installed wall outlets. Separating the ground is prohibited.

The power cable must be inserted before signal circuits may be connected.



Use only the power cable included in the delivery package. See "[Delivery package](#)" on page 13.

Before each measurement, measuring cables must be inspected for damage and replaced if necessary. Damaged or worn components can damage the instrument or cause injury.

## Unpacking and Checking the Instrument

The instrument may be operated only under the operating conditions and in the positions specified by the manufacturer, without the product's ventilation being obstructed. If the manufacturer's specifications are not observed, this can result in electric shock, fire and/or serious personal injury, and in some cases, death.

Applicable local or national safety regulations and rules for the prevention of accidents must be observed in all work performed.

The instrument is designed for use in the following sectors: Industrial, residential, business and commercial areas and small businesses.

The instrument is designed for indoor use only. Before each measurement, you need to verify at a known source if the instrument functions properly.



To disconnect from the mains, unplug the IEC socket on the back panel.

See [Table 3-1](#) for the general data on the instrument specification.

**Table 3-1: General data on instrument specification**

General data		
Mains nominal voltage	AC 100 V / 115 V / 230 V ( $\pm 10\%$ ) 50 Hz to 60 Hz	
Maximum power consumption	400 W	
Mains fuses	2 x IEC T4.0H 250 V	
Operating temperature range	+5 °C to +40 °C	
Storage temperature range	-20 °C to +70 °C	
Humidity noncondensing	5 % to 95 %	
Display	TFT 5" 800 pixels x 480 pixels WVGA Touch	
Rack installation	R&S HZN96 rack adapter 2U (P/N: 3638.7813.02)	
Dimensions (W x H x D)	222 mm x 97 mm x 436 mm (8.74" x 3.82" x 17.17")	
Weight	R&S NGU201	7.1 kg (15.65 lb)
	R&S NGU401	7.1 kg (15.65 lb)

### 3.3 Unpacking and Checking the Instrument

Unpack the R&S NGU source measure unit carefully and check the content of the package.

## Unpacking and Checking the Instrument

- Check the equipment for completeness using the delivery note and package contents list for the various items.
- Check the instrument for any damage and loose parts. If there is any damage, immediately contact the carrier who delivered the instrument.

**Packing material**

Retain the original packing material. If the instrument needs to be transported or shipped later, you can use the material to protect the control elements and connectors.

**NOTICE****Risk of damage during transportation and shipment**

Insufficient protection against mechanical and electrostatic effects during transportation and shipment can damage the instrument.

- Always ensure that sufficient mechanical and electrostatic protections are provided
- When shipping an instrument, the original packaging should be used. If you do not have the original packaging, use sufficient padding to prevent the instrument from moving around inside the box. Pack the instrument in antistatic wrap to protect it from electrostatic charging
- Secure the instrument to prevent any movement and other mechanical effects during transportation

**Delivery package**

The package contents contain the following items:

- R&S NGU source measure unit
- Four power cables
- One printed Getting Started manual
- One document folder containing a printed Basic Safety Instructions guide



## 3.4 Setting Up the Instrument

The R&S NGU is designed for benchtop and rackmount operation.

### 3.4.1 Bench Operation

On a benchtop, the R&S NGU source measure unit can either lie flat or stand on its feet. As shown in [Figure 3-1](#), feet on the bottom can be folded out to set the instrument in an inclined position.



*Figure 3-1: Operating positions*

---

#### **NOTICE**

##### **Positioning of instrument**

The instrument must be positioned in a manner that allows you to disconnect the unit from the mains at any time and without restrictions.

---

### 3.4.2 Rack Mounting

The instrument can be installed in a 19" rack using the rack adapter R&S HZN96 (P/N 3638.7813.02). Proceed according to the installation instructions supplied with the rack adapter.

---

#### **NOTICE**

##### **Ambient temperature**

Place the R&S NGU source measure unit in an area where the ambient temperature is within +5 °C to +40 °C. The R&S NGU source measure unit is fan-cooled and must be installed with sufficient space along the sides to ensure free flow of air.

---

## 4 Instrument Tour


This chapter provides an overview of all the controls available in the R&S NGU models and steps to switch on the instrument for the first time.

- [Overview of Controls](#)..... 15
- [Switching On the Instrument](#)..... 20

### 4.1 Overview of Controls

#### 4.1.1 Front Panel

The front panel of the R&S NGU is shown in [Figure 4-1](#). The function keys and navigation controls are located beside the display. The various connectors are located at the right side of the display.



**Figure 4-1: Front panel of NGU201 model**

- 1 = Display with touch screen
- 2 = Menu control keys
- 3 = Rotary knob and back key
- 4 = Output key
- 5 = Output terminals
- 6 = USB connector
- 7 = Power key

## Display (1)

The display is a color TFT touch screen with measurement settings and functions provided in the channel display area. The status bar which provides at both device and channel level shows the device operating mode and channel settings of the instrument.

For a detailed description on-screen layout, see section "Display Overview" in the User Manual.

## Menu control keys (2)

The menu control keys allow you to access the home window, device/channel menu window and user button key in the instrument.

For a detailed description on menu control keys, see section "Menu Controls" in the User Manual.

## Rotary knob and back key (3)

The rotary knob and back key are used for menu navigation and value adjustment in the instrument.

For a detailed description on rotary knob and back key, see section "Navigation Controls" in the User Manual.

## Output key (4)

The output key allows you to enable or disable the output power.

Refer to datasheet for the channel voltage/current limits in the source and sink mode.

## Output terminals (5)

The R&S NGU is a single channel source measure unit and it comes with the following models:

- NGU201 model is a 2 quadrant source measure unit
- NGU401 model is a 4 quadrant source measure unit

Both models are equipped with "Force (High)", 2 x "Force (Low)", "Sense (High)", "Sense (Low)" and a ground terminal.

With a jumper connecting the ground terminal and the additional "Force (Low)" connector, the R&S NGU provides good ground connection which is essential when measuring very small voltages and currents.

### USB connector (6)


The USB connector is a Type-A connector. You can connect a USB flash drive to this connector to perform a firmware update, store logging data or screen shots.

### Power key (7)

The [Power] key switches the instrument on and off.

## 4.1.2 Rear Panel

Figure 4-2 shows the rear panel of the R&S NGU with its connectors.



**Figure 4-2: Rear panel of NGU201 model**

- 8 = AC inlet with fuse holder and voltage selector
- 9 = Channel 1 rear panel connector. For NGU201, the last two pins are labeled as DVM+ and DVM- as an option. For NGU401, the pins are labeled as MOD+ and MOD-.
- 10 = USB connector (Device)
- 11 = USB connector (Host)
- 12 = Ethernet (LAN) connector
- 13 = Cover for optional IEEE-488 (GPIB) Interface
- 14 = Digital I/O connector

## AC inlet with fuse holder and voltage selector (8)



### Main supply cord

Do not use detachable mains supply cord with inadequate rating.

The power cable must be plugged in before signal circuits can be connected. Do not use the product if the power cable is damaged. See [Chapter 4.2, "Switching On the Instrument"](#), on page 20 for more information.

The built-in voltage selector selects the mains voltage between 100 V, 115 V and 230 V. All voltage settings are using the same fuse rating.

## Channel connectors (9)

---

### NOTICE

#### Output terminals

Either the output terminals at the front panel or those at the back panel can be used. Using both terminals at the same time can cause instrument malfunction.

---



### Digital voltmeter (DVM)

The DVM+ and DVM- pins on the channel connector are available only with NGU201 model equipped with option R&S NGU-K104 (P/N: 3663.0390.02 ).



### Modulating signal (MOD)

The MOD+ and MOD- pins on the channel connector are available only with NGU401 model.

The channel connectors contain both output ("F+", "F-") and sense ("S+", "S-") connections.

## USB connectors (11, 12)

The USB host connector (Type-A) can be used for mass storage devices like the USB connector at the front panel.

The USB device connector is a Type-B connector for remote control operation.

### Ethernet connector (13)

10/100 Ethernet port for remote control operation via the local area network.

For a detailed description on the connection setup, see section "LAN Connection" in the User Manual.

### Option IEEE-488 (GPIB) interface (14)

An IEEE-488 (GPIB) interface can be ordered with option R&S NGU-B105 (P/N: 3661.0763.02). This interface is not user installable.

### Digital I/O connector (15)

The Digital I/O option, R&S NGU-K103 (P/N: 3662.9335.02) must be installed for this function to be available in the instrument.




Figure 4-3: Digital I/O connector (female socket front view)

Table 4-1: Digital I/O pin layout

Pin	Signal	Direction	Pin	Signal	Direction
1	*Inhibit Ch1	IN	9	-	-
2	Ext. Trigger Ch1	IN	10	-	-
3	Digital In1	IN	11	Digital Output Fault	OUT
4	Digital Output Out1	OUT	12	--	-
5 - 8	Gnd	-	13 - 15	Gnd	-

\* The [inhibit signals](#) can be used to turn off the outputs by a digital hardware signal.

Table 4-2: Inhibit signals

Signal name	Pin	Descriptions
Inhibit Ch1	Pin 1 of <a href="#">Digital I/O connector</a>	If the inhibit signal goes active, channel 1 output is turned off. The inhibit signal is low active (inverted logic).

## 4.2 Switching On the Instrument

Before switching on the instrument, check that all the instructions in the “Basic Safety Instruction” brochure and safety measures in previous sections are observed. Also, check if the value on the voltage selector corresponds to the mains voltage (100 V, 115 V or 230 V).



### Fuse rating

The R&S NGU uses the same fuse ratings for all mains voltages.

#### To change power fuse / mains voltage setting:

1. Peel off the yellow label sticker on the AC inlet.
2. Release the latch of the fuse holder which is located at both side of the socket and pull it out.
3. Pull out the removable part of the fuse holder.
4. Turn this removable part until the correct voltage label (100, 115 or 230) is displayed in the window of the holder.
5. Return the fuse holder to its position in the panel.

#### To switch on instrument:

1. Connect the power cable to the AC power connector on the rear panel of the R&S NGU.
2. Connect the power cable to the socket outlet.
3. Press [Power] key on the front panel.  
The instrument performs a system check, boots the operating system, and starts the R&S NGU firmware.

## Switching On the Instrument

By default, all output channels are turned off when the instrument is switched on to prevent connected loads from being damaged unintentionally.

During startup, the R&S NGU is loaded with the last saved instrument settings from internal memory. See "Store and Recall" in the User Manual.

**To switch off instrument:**

1. Press [Power] key.  
All current settings are saved to internal memory and the firmware shuts down.
2. Disconnect the AC power cable from the instrument.



## 5 Trying Out the Instrument

This chapter describes some basic functions that you can perform with the R&S NGU.



### Source and sink current

The NGU201 is a 2 quadrant source measure unit whereas the NGU401 is a 4 quadrant source measure unit. Both models are able to source and sink current. When the voltage across the output terminal exceeds the set voltage, current flows into the instrument.

The default behavior "Auto" can be configured in the output menu to set the output operating mode, see section "Output Mode" in the User Manual.

On the display, sink mode is in operation if negative current is shown for NGU201. However, if both voltage and current are shown as opposite signs (e.g. negative voltage and positive current), it indicates that NGU401 is operated in the sink mode. See also "[CR mode](#)" on page 23.

### 5.1 Setting the Output Voltage and Current

1. Press [Home] key.  
The R&S NGU displays the home window.
2. Select voltage or current parameter in the home window.  
The R&S NGU displays an on-screen keypad to set the value.
3. Enter the required value.
4. Confirm value with the unit key (V/mV or A/mA).  
See "[Source and sink current](#)" on page 22 for more information on the operating modes supported in different models.

### 5.2 Activating the Channel Output

The output voltages can be switched on or off regardless of the instrument's operating mode.

To switch on or off channel output.

- ▶ Press [Output] key on the front panel.  
The R&S NGU outputs the set voltage level on the output terminal.

Depending on the operating mode which the R&S NGU is operated in, the following are observed:






### CR mode

CR mode is available only with NGU201 model.

CR mode is a special case of sink mode in which the instrument behaves like a constant resistor. Only in this mode, the display font color in the home window turns cyan.

In "normal" sink mode, the colors are the same as in source mode: green if the current flowing into the R&S NGU is below the set current and red if the current is limited to the set value. The only visible indication of sink mode is the change of sign of the current readout to "Minus".

Color illuminated on front panel keys and display font color of voltage and current in home window	Operating mode
 Green	Constant voltage mode (CV)
 Red	Constant current mode (CC)
 Cyan	Available only with NGU201 model Constant resistance mode (CR) Note: Instrument is operated in sink mode and "Constant Resistance" is activated.

Also, the operating symbol mode (CV, CC or CR) is displayed at the channel status bar.

## 6 Maintenance and Support

### 6.1 Maintenance

Regular maintenance improves the life span of the instrument, the following chapter provides information on instrument maintenance.

#### Cleaning

Before cleaning the instrument, ensure that it has been switched off and the power cable is disconnected.

Clean the outer case of the instrument at regular intervals, using a soft, lint-free dust cloth.

---

**NOTICE****Instrument damage caused by cleaning agents**

Use a dry, lint-free cloth to clean the product. When cleaning, keep in mind that the casing is not waterproof. Do not use any liquids for cleaning.

Cleaning agents, solvents (thinners, acetone), acids and bases can damage the front panel labeling, plastic parts and display.

---

The display may only be cleaned with an appropriate glass cleaner. Rub the display with a dry, clean and lint-free cloth. Do not allow cleaning fluid to enter the instrument.

### 6.2 Contacting Customer Support

#### Technical support – where and when you need it

For quick, expert help with any Rohde & Schwarz product, contact our customer support center. A team of highly qualified engineers provides support and works with you to find a solution to your query on any aspect of the operation, programming or applications of Rohde & Schwarz products.

**Contact information**

Contact our customer support center at [www.rohde-schwarz.com/support](http://www.rohde-schwarz.com/support), or follow this QR code:



*Figure 6-1: QR code to the Rohde & Schwarz support page*

# Index

## A

Activating the channel output ..... 22

## C

Customer support ..... 24

## D

Delivery package contents ..... 13

Documentation overview ..... 5

## E

Electrostatic discharge ..... 8

ESD ..... 8

## F

Front panel

  Display ..... 16

  Menu control keys ..... 16

  Output keys ..... 16

  Output terminals ..... 16

  Power key ..... 17

  Rotary knob and back keys ..... 16

  USB connector ..... 17

## G

Getting Started ..... 5

## I

Instrument tour ..... 15

  Overview of controls ..... 15

  switching on NGU ..... 20

Intended operation ..... 11

## M

Maintenance

  Cleaning ..... 24

## O

Open source acknowledgment (OSA) ..... 6

Overview of controls

  Front panel ..... 15

  Rear panel ..... 17

## P

Putting into operation ..... 8

  Intended operation ..... 11

  Safety ..... 10

  Unpacking and checking the instrument

    ..... 12

## R

Rear panel

  AC inlet with fuse holder ..... 18

  Channel connectors ..... 18

  Digital I/O connector ..... 19

  Ethernet connector ..... 19

  IEEE-488 (GPIB) interface ..... 19

  USB connectors ..... 18

  Voltage selector ..... 18

Release notes ..... 6

## S

Safety ..... 10

Safety instructions ..... 5

Setting the output voltage and current limit

  ..... 22

Setting up the instrument ..... 14

  Bench operation ..... 14

  Rack mounting ..... 14

## T

Trying out the instrument

  Activating the channels output ..... 22

  Setting the output voltage and current

    limit ..... 22

## U

Unpacking and checking the instrument . 12

User manual ..... 5

## W

Welcome to R&S NGU ..... 7