



# SBS-H2

## Hydrogen Gas Detector Kit

*For battery charging rooms and other areas where hydrogen gas may be present*

### INSTALLATION, OPERATION & MAINTENANCE INSTRUCTIONS



**Protects Life, Property and Profits**



*Electrical Safety – UL 61010-1*

*Compliant with NFPA 70E® and IEEE Recommendations  
Pollution Degree 2*

**1-800-554-2243**

**[www.sbsbattery.com](http://www.sbsbattery.com)**  
**[Test@sbsbattery.com](mailto:Test@sbsbattery.com)**



## Warnings

- This detector is added protection, not a substitute for prudent safety measures, for where hydrogen gas may be present.
- For large or highly-sensitive areas, SBS recommends installing additional sensors for increased coverage area.
- The hydrogen sensor does not provide protection from fires or hydrogen explosions. The relay contacts are intended to be connected to a safety system that would enable audible alarms, system shutdown and ventilation.
- Ensure that installation complies completely with all relevant Local, State, Federal and OSHA safety and health regulations.
- If a sensor enters warning or alarm mode there is a risk of combustion or explosion. To avoid injury, leave the area immediately.
- The sensor is calibrated for operation in air. Tampering with the sensor or operation in environments that are exposed to other types of gases can lead to inaccurate readings, false alarms or permanent damage.
- Please see troubleshooting guide for list of gases and compounds that may damage or alter a sensor's performance.
- Uncured silicone compounds or extended exposure to silicone off gassing can give inaccurate readings or false alarms on a sensor.

# Table of Contents

<b>Description</b>	<b>Page</b>	<b>Section</b>
<i>Overview</i>	5	1.0
<i>Benefits</i>	5	2.0
<i>How It Works</i>	5	3.0
<i>Specifications</i>	6	4.0
<i>Sensor</i>	7	5.0
<i>Main Control</i>	7	6.0
<i>Installation</i>	8 - 11	7.0
<i>Operation</i>	12	8.0
<i>Electrical Testing</i>	13	9.0
<i>Testing the Sensor</i>	13	10.0
<i>Troubleshooting/Maintenance</i>	14 - 15	11.0

## Main Unit and Accessories

<b><u>Part No.</u></b>	<b><u>Description</u></b>
<b>SBS-H2</b>	Hydrogen Gas Detector Includes: one (1) main control, one (1) H2-SENSOR and one (1) 25 ft. cable
<b>H2-JB</b>	Junction Box with Knockouts, 4 11/16" X 4 11/16", Metal
<b>H2-SENSOR</b>	Hydrogen Gas Sensor Only (No Cable)
<b>H2-SENSOR-25FT</b>	Additional/Replacement Hydrogen Gas Sensor with 25 ft. Cable
<b>H2-SENSOR-50FT</b>	Additional/Replacement Hydrogen Gas Sensor with 50 ft. Cable
<b>H2-SENSOR-100FT</b>	Additional/Replacement Hydrogen Gas Sensor with 100 ft. Cable
<b>H2-TESTKIT</b>	Field Test Kit for SBS-H2 Includes: case, regulator, tubing and two (2) cylinders of H <sub>2</sub> gas (1% and 2%)
<b>H2-TESTKIT-INTL</b>	Field Test Kit for SBS-H2 Includes: case, regulator and tubing – does not include H <sub>2</sub> gas cylinders
<b>E190399</b>	110Vac 3 Prong AC Cord, 10 Ft., 18-3 AWG

## 1.0 Overview

Batteries on charge emit hydrogen gas as part of the chemical reaction of recharge.

**Concentrations of 4.1% to 75% H<sub>2</sub> mixed with air can be explosive.** Sparks or hot surfaces can ignite hydrogen gas.

The SBS-H2 hydrogen detector acts as a monitor and provides a visual and audible alarm when hydrogen is detected. The unit also has a 1% concentration relay that can trigger exhaust fan operation and a 2% concentration relay that can trigger a building management/alarm system (via SCADA/Modbus) before the gas reaches the lower explosive limit (LEL) of 4.1%.

## 2.0 Benefits

In addition to protecting employees and property, the detector may also reduce the following costs:

### Energy Efficiencies

Instead of continuously running an exhaust fan to prevent hydrogen gas accumulation, use the detector to activate a fan only if the gas concentration reaches 1%.

### Insurance Savings

Installation of a detector in areas where batteries are charged may result in a premium reduction.

## 3.0 How it Works

Should the concentration of hydrogen gas in the air surrounding the sensor reach 1% by volume, the “**1% Warning**” yellow LED will light up on the main control of the unit. In addition, the 1% internal relay will energize and can be used to activate a remote exhaust fan.

Should the hydrogen gas concentration reach 2% by volume, the “**2% Alarm**” red LED will light up, the strobe will flash and an audible alarm will sound. In addition, the 2% internal relay will energize and can be used to activate a building management/alarm system (via SCADA/Modbus).

The SBS-H2 provides automatic operation, continuous detection, high sensitivity, stability and solid-state reliability. The unit uses 120/240 Vac 50/60 Hz and/or 12 - 48 Vdc operating voltages.

## 4.0 Specifications

### Dimensions

- Main control: 4.7" L x 4.7" W x 1.2" D
- Sensor: 3.1" L x 1.6" W x 0.87" D

### Mounting

- Wall: two 3/16" screws (not included)
- H2-JB Junction box: 4 11/16" x 4 11/16" 2-gang junction box



### Power Requirements/Options

**Warning:** Power requirements for the unit and relays should not exceed min/max specifications

- 120 Vac, 50/60 Hz Nominal (Terminal J8)
  - 93 - 121 Vac
  - 250mA / 10W Max
- 220 Vac, 50/60 Hz Nominal (Terminal J8)
  - 185 - 242 Vac
  - 125mA / 10W Max
- 12-48 Vdc Nominal (Terminal J9)
  - 9 - 58 Vdc
  - 600mA / 6W Max
  - **Note:** An earth ground must be supplied to the GND terminal on the AC terminal block when using only the DC power supply



### Relays

- 1% Warning Relay (Terminal J6)
  - 1 Normally Open and 1 Normally Closed contact
  - Rated for 15 A resistive @ 120 Vac
  - Rated for 10 A resistive @ 277 Vac
  - Rated for 10 A resistive @ 28 Vdc
- 2% Alarm Relay (Terminal J3)
  - 1 Normally Open and 1 Normally Closed contact
  - Rated for 0.5A @ 28 Vdc

### Temperature/Humidity

- Operating Temperature Range: 32°F (0°C) to 122°F (50°C)
- Operating Humidity Range: 20-95% non-condensing
- Storage Humidity Range: 5-95% non-condensing

### Maximum Altitude

- 2000 meters

### Audible Alarm

- 85 dB at 10' @ 1.6 - 3.2 KHz

### Strobe LED

- 146 lumens at 1A @ 3.2-4.2V

## 5.0 Sensor

The H2-SENSOR consists of an electronic sensing element whose electrical conductivity increases when hydrogen is detected at its surface. Conductivity of the sensor is proportional to the gas concentration, which is continuously monitored by the electronic alarm circuits.

The sensor only monitors for hydrogen gas (H<sub>2</sub>) and will not alarm for Hydrogen Sulfide (H<sub>2</sub>S), which has an odor at very low concentrations.




Hydrogen Sensor



Cat5 Cable  
(25 ft. std., 50/100 ft. optional)

## 6.0 Main Control



Main Control

(For troubleshooting, refer to page 14.)

## 7.0 Installation



### WARNING

AC voltage relay terminals (120/240 Vac) are located within this detector, presenting a hazard to service technicians. Only qualified technicians should open the detector case and service the internal circuits. Ensure power is removed from the detector relays prior to servicing the unit. Failure to do so may result in injury or death.

## Mounting and Power Options



### Wall Mountable

Integrated back mounting plate allows user to easily mount directly to any wall using 3/16" screws (not included).

### Wiring

Power and alarm wires can run through the sides of the unit.

Alarm Wiring



Input Power

### H2-JB Junction Box Mountable (optional)

Mounts to a standard, 4 11/16" x 4 11/16" 2-gang junction box



### Hardwire Option

Run AC and/or DC power and alarm wires through back of the unit, into the gang box and out through conduit.



### E190399 AC Line Cord

3-prong grounded AC cord, 18-3 AWG



## Mounting Location

Hydrogen is colorless and odorless; the lightest of all gases, and thus rises. **The sensor should be installed at the highest, draft-free location in the battery room, cabinet or compartment where hydrogen gas would accumulate.**

The detector measures hydrogen gas concentration in the air immediately surrounding the sensor. The area one sensor will monitor depends on the properties of the battery compartment or room. Hydrogen gas may accumulate in several areas of the battery compartment or room and multiple sensors/detectors may be necessary.

The main control can be mounted wherever is convenient for the user, but should be within the cable length range to connect to each sensor.

The sensor should be mounted at the **highest, draft-free location in the battery room, cabinet or compartment**. Each sensor connects with the main control via the cable.

Carefully remove the main control cover by removing the two screws located on the front of the cover. Attach the main control to the wall, ceiling or optional junction box using the mounting holes at the top and bottom of the main control's mounting plate.

After the power and relay wiring is complete, connect each cable from main control to each sensor and refasten the main control cover.

## Power Options

The detector has terminal blocks for connections to a single-phase 120/240 Vac 50/60 Hz power source (**Terminal J8**), and/or a 12-48 Vdc power source (**Terminal J9**). The power supply inputs are redundant, so the unit can use the DC input as a backup source.

## Relays

The detector has two (2) internal alarm relays:

- 1% warning relay (**Terminal J6**) is activated when a sensor detects 1% concentration of hydrogen gas. The 1% relay's dry contacts are rated at 10A/250 Vac, sufficient for most 1/3 HP exhaust fans.
- 2% alarm relay (**Terminal J3**) is activated when a sensor detects 2% concentration of hydrogen gas. The 2% relay's dry contacts are rated for 0.5A/28 Vdc.
- *Note: For higher current requirements, add an external relay.*

## Mounting Options

### Junction Box Mounted

For 120/240 Vac power, use 18-3 gauge stranded wire.

For 9 - 58 Vdc power, use 18-2 conductor insulated wire.

For relay wires, use stranded wire. Maximum wire size for connector terminations is **14 AWG**.


Stranded conductors must be terminated in a manner to prevent shorting from one terminal to another by a loose strand. Tin the wires with solder if required.

### Wall Mounted

For 120 Vac power, an 18-3 gauge insulated line cord is required.

For 9 - 58 Vdc power, use 18-2 conductor insulated cable from the DC supply.

For relay wires, use stranded wire. Maximum wire size for connector terminations is **14 AWG**.



SBS supplies a tie-wrap to secure the AC mains' wiring. The tie wrap can rotate up to 270 degrees to accommodate your installation.


### Disconnection of Supplying Power

When the unit is hard wired, an external 10 Amp (minimum) circuit-breaker or switch should be installed to act as a disconnecting device. The circuit-breaker must open all supply conductors simultaneously, be easily reached by operators and be marked as the disconnecting device for the equipment.

### For Installation of Additional Sensors

A maximum of three (3) sensors may be connected to each main control. Multiple detectors and sensors can be installed to meet the space coverage requirements of your particular installation.

Locate the additional sensors' installation points within cable reach of the main control and mount the sensor. Connect the cables from any additional sensors to the Sensor 2 and Sensor 3 inputs on the main control.




## Alarm System Electronics

Please refer to the illustration below to identify proper power and relay connection points in the detector. It is advisable to use a pair of 14 gauge or smaller stranded wire for the relay contacts to help reduce any interference within the area that may cause false alarms.

Each of the Cat5 sensor input connections has a status indicator LED on the main control, which will illuminate solid green when a sensor is connected and operating normally. A sensor's corresponding LED will flash at the same rate as the strobe LED when detecting 1% or 2% H<sub>2</sub> concentration. The LED for a sensor that is in alarm mode will flash at the same rate as the strobe LED. The alarming sensor and strobe LED will flash at a faster rate than the LED for a sensor that is only in warning mode.

### Terminal Connection Diagram



### Using the Mechanical Relays

1. Remove the front cover of the main control by removing two fix screws and pulling straight off the body. This will reveal the inner electronics of the alarm box.
2. Locate the terminal blocks for the relays and determine which condition you would like the relay to be related to. Use the 1% relay (**Terminal J6**) for the warning condition and the 2% relay (**Terminal J3**) for the alarm condition.
3. Replace the front cover on the alarm box.


## 8.0 Operation

Keep the detector on at all times. The solid green LED for 'POWER' on the main control indicates that the detector is powered on.

**When power is first turned on, a warm up period of 30 seconds will elapse before the unit will function. This delay is to prevent false activation of the internal relays and alarm.**

Should the concentration of hydrogen gas in the air surrounding the sensor reach 1% by volume, the **"1% Warning"** yellow LED will light up on the main control of the unit. In addition, the 1% internal relay will energize and can be used to activate a remote exhaust fan.

Should the hydrogen gas concentration reach 2% by volume, the **"2% Alarm"** red LED will light up, the strobe will flash and an audible alarm will sound. In addition, the 2% internal relay will energize and can be used to activate a building management/alarm system (via SCADA/Modbus).



Condition	Main Control Indicators			Individual Sensor Indicators	Relay Closure	Audible Alarm	Strobe
	Power	Warning	Alarm				
Normal Operation				 (sensor installed)	None	None	None
H <sub>2</sub> Alarm (1% H <sub>2</sub> )				 (blinking green)	Warning Relay Energized	None	None
H <sub>2</sub> Warning (2% H <sub>2</sub> )				 (same flash rate as strobe)	Warning and Alarm Relay Energized	<b>ON</b>	<b>ON</b>
Sensor/Cable Fault					None	None	None
Communication with Sensor Lost				 (plugged in, but not lit)	None	None	None

## 9.0 Electrical Testing

A "TEST" button is located on the front of the main control. Push and hold this button for approximately 10 seconds to test the unit's electronic circuitry.

The warning and alarm LEDs will light up in sequence, the strobe will flash, the relays will activate whatever is connected to them and the internal warning alarm will sound.

**Note:** The "TEST" button does NOT test the sensor(s) itself – only the unit's electronic circuitry.

## 10.0 Testing the Sensor

The sensors and main controls are factory calibrated. It is recommended to test each sensor's functionality every 12-18 months with the H2-TESTKIT.

The H2-TESTKIT is intended for periodic testing of the functionality and proper operation of the system. Once a sensor is installed, calibration or adjustment of the sensor is not possible. Please contact your sales representative if sensor calibration is desired or required.

The H2-TESTKIT includes the following:

- 1% (17 liters) H<sub>2</sub> in air calibrated gas canister
- 2% (17 liters) H<sub>2</sub> in air calibrated gas canister
- Regulator
- Flexible tubing with sensor head adapter



### Testing the 1% Warning and 2% Alarm State

1. Connect the calibration fixture to the 1% H<sub>2</sub> air gas cylinder.
2. Secure the test fixture to the sensor module connected to sensor by pressing the flexible tubing completely over the inlet to the sensor head.
3. Turn on the gas flow by slowly cracking the valve on the cylinder regulator until gas begins to flow. Please wait 30 seconds to ensure the air in the tubing has been purged.
4. Continue gas flow and wait for the yellow LED warning to light up and the 1% relay to energize.
5. Turn off gas and remove from sensor.
6. Repeat Steps 1-5 above using the 2% H<sub>2</sub> air gas cylinder to activate the 2% alarm and relay. The 2% alarm threshold is connected to the red LED, the audible alarm and the strobe light up, which will activate during testing.
7. Repeat steps for every sensor installed.

**Note:** If the unit does not alarm during these tests the sensor may need to be replaced.

### Replacing the Sensor

In a typical operating environment SBS recommends that each sensor be replaced every three years. An abusive operating environment can and will shorten a unit's useful life. In dusty/dirty applications or in situations where a sensor is often subjected to different gases, it is recommended to replace each sensor after one (1) year.

# 11.0 Troubleshooting and Maintenance

## No Power

Verify the AC and/or DC power cables are installed per the connection diagram on page 11.

## Relays

The SBS-H2 system was designed for the relays to operate in a failsafe condition when the power supply is interrupted. If the fan connected to a relay runs as soon as the unit is powered on, the unit has been wired for the use of the Normally Open contact instead of a Normally Closed contact.

## False Alarms

Each sensor has been calibrated for the detection of hydrogen gas, however any combustible gas that comes in contact with a sensor has the potential to activate the warning and/or alarm relays. Contact with any individual or combination of the following gases could trigger false alarms and/or contaminate a sensor.

Gases include but are not limited to:

- |                   |                     |                       |
|-------------------|---------------------|-----------------------|
| - Acetone         | - Ethyl Ether       | - Methyl Ethyl Ketone |
| - Acetylene       | - Ethyl Oxide       | - Nitric Oxide        |
| - Ammonia         | - Gasoline          | - Nitric Dioxide      |
| - Benzene         | - Heptane           | - Propane             |
| - Butane          | - Hexane            | - Propylene Oxide     |
| - n-Butyl Acetate | - Hydrogen          | - Styrene             |
| - Carbon Dioxide  | - Hydrogen Cyanide  | - Sulfur Dioxide      |
| - Carbon Monoxide | - Hydrogen Sulfide  | - Toluene             |
| - Ethane          | - Isopropyl Alcohol | - Turpentine          |
| - Ethanol         | - Methane           | - Vinyl Acetate       |
| - Ethyl Acetate   | - Methanol          | - Xylene              |

If a sensor's warning or alarm condition is reached, **ventilate the area with clean air**. This should reduce the concentration of most gases and the warning or alarm condition should clear.

**Note** - when a warning occurs at 1%, the warning will not clear until concentrations drop below 0.5%. Similarly, when an alarm occurs at 2%, the alarm will not clear until concentrations drop below 1.5%.

Avoid installation in highly corrosive environments where high densities of hydrogen sulfide, sulfur oxide, chlorine, hydrogen chloride, etc. may be present. These gases can cause corrosion of the element and the power leads to the circuit board.

A sensor's output characteristics can be affected if the sensor becomes contaminated or exposed to heavy alkaline metals.

A sensor cannot operate in a zero or low oxygen content atmosphere.

If a sensor collects water condensation, its characteristics may temporarily drift. However, light levels of condensation under normal indoor use should not pose a significant problem with performance.

## Storage

The longer a sensor is stored prior to being energized, the longer the warm up and stabilization period may become. Storage Humidity Range: 5 - 95% non-condensing.

## Maintenance Tips

To maintain the unit, it is recommended to:

1. Test the detector once a month by pressing the 'TEST' button.
2. Vacuum the alarm cover once a month to remove accumulated dust.
3. Never use detergents or solvents to clean the unit or sensor. Chemicals can permanently damage or temporarily contaminate a sensor.
4. Avoid spraying air fresheners, hair spray, paint or other aerosols near a sensor.
5. Never paint the unit or sensor. Paint will seal the vents and interfere with proper sensor operation.



## WARNINGS

**Do not disassemble unit or attempt to repair or modify any component of this instrument. This instrument contains no user serviceable parts, and substitution of components may impair intrinsic safety, which may adversely affect product performance and result in injury**

The SBS-H2 Hydrogen Alarm System is not a standalone safety device and does not provide protection from hydrogen explosions. The relay contacts are intended to be connected to a safety system, enabling audible alarms, system shutdown, ventilation, or other measures to ensure monitoring of hydrogen gas occurs before concentrations reach dangerous levels.

The information in this sheet has been carefully reviewed and is believed to be accurate; however, no responsibility is assumed for inaccuracies. Storage Battery Systems, LLC reserves the right to make changes without further notice to any product, datasheet, technical data bulletin, or website.

Storage Battery Systems, LLC makes no warranty, representation of guarantee regarding the suitability of its product for any particular purpose, nor does Storage Battery Systems, LLC assume any liability arising out of the application or use of any product and specifically disclaims any and all liability, including without limitation consequential or incidental damages. "Typical" parameters can and do vary in different applications. All operating parameters, including "Typical" must be validated for each customer application by customer's technical experts.

Storage Battery Systems, LLC products are not designed, intended, or authorized for use in any application in which the failure of the SBS product could create a situation where personal injury or death may occur.

Should buyer purchase or use SBS products for any such unintended or unauthorized application, Buyer shall indemnify and hold Storage Battery Systems, LLC and its officers, employees, subsidiaries, affiliates, and distributors harmless against all claims, costs, damages, and expenses, and reasonable attorney fees arising out of, directly or indirectly, any claim of personal injury or death associated with such unintended or unauthorized use, even if claim alleges that Storage Battery Systems, LLC was negligent regarding the design or manufacture of the part.

In the case of a defect in the sensor, Storage Battery Systems, LLC shall not be liable for any damages which may result, including, but not limited to, loss of revenue, property, or life. In an event, Storage Battery Systems, LLC shall limit liability to replacement of the defective unit. Storage Battery Systems, LLC does not convey any license under its patent rights nor the rights of others.



Corporate Headquarters: N56 W16665 Ridgewood Dr., Menomonee Falls, WI 53051 • Tel: 262.703.5800 • Fax: 262.703.3073  
Appleton, Wisconsin: N922 Tower View Dr. Unit J, Greenville, WI 54942 • Tel: 920.757.1175 • Fax: 920.757.1180  
Chicago, Illinois: 179 Easy St., Carol Stream, IL 60188 • Tel: 630.221.1700 • Fax: 630.221.1701  
[www.sbsbattery.com](http://www.sbsbattery.com)