



**eco PDU PE Series  
SNMP Settings**

**User Instructions**

## User Information

---

### Online Registration

Be sure to register your product at our online support center:

International	<a href="http://support.aten.com">http://support.aten.com</a>
North America	<a href="http://www.aten-usa.com/product_registration">http://www.aten-usa.com/product_registration</a>

### Telephone Support

For telephone support, call this number:

International	886-2-8692-6959
China	86-10-5255-0110
Japan	81-3-5615-5811
Korea	82-2-467-6789
North America	1-888-999-ATEN ext 4988
United Kingdom	44-8-4481-58923

### User Notice

All information, documentation, and specifications contained in this manual are subject to change without prior notification by the manufacturer. The manufacturer makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties as to merchantability or fitness for any particular purpose. Any of the manufacturer's software described in this manual is sold or licensed *as is*. Should the programs prove defective following their purchase, the buyer (and not the manufacturer, its distributor, or its dealer), assumes the entire cost of all necessary servicing, repair and any incidental or consequential damages resulting from any defect in the software.

The manufacturer of this system is not responsible for any radio and/or TV interference caused by unauthorized modifications to this device. It is the responsibility of the user to correct such interference.

The manufacturer is not responsible for any damage incurred in the operation of this system if the correct operational voltage setting was not selected prior to operation. PLEASE VERIFY THAT THE VOLTAGE SETTING IS CORRECT BEFORE USE.

### PE Device Safety Notice



- ◆ Set the maximum permissible breaker protection in the building circuitry to the current rating specified on the rating plate. Observe all national regulations and safety codes as well as deviations for breakers.
- ◆ Only connect the PE Device to a grounded power outlet or a grounded system!
- ◆ Make sure that the total current input of the connected systems does not exceed the current rating specified on the rating plate of the PE Device.
- ◆ There is a risk of explosion if the battery is replaced with an incorrect type. Dispose of used batteries according to the relevant instructions.

---

# Contents

---

Overview .....	1
Eco PDU .....	1
SNMP Trap Receivers .....	2
Eco Sensors .....	3
SNMP Parameters .....	4
Synchronizing SNMP Parameters .....	4
MIB Browser .....	5
Set SNMP Parameters .....	6
Setting Up Thresholds .....	9
Setting Device/Outlet Status .....	10
Reading Device/Outlet Status .....	11

# Configuring SNMP

## Introduction

---

This guide helps you to set up your PE series eco PDU and NRGence *eco Sensors* software for use with an SNMP manager. With support for SNMP V1, V2C and V3, your PE system can be configured to receive Set/Get commands in order to retrieve status updates and configure some basic settings (such as thresholds), as well as send traps to an SNMP manager.

In order to utilize SNMP functionality in your PE installation, it is important that all the parameters outlined in the following sections are synchronized for all eco PDUs in your installation. See *Synchronizing SNMP Parameters*, page 6, for further details.


There are three ways to utilize SNMP functionality with your NRGence device:

- ♦ with the device's built-in graphical user interface (GUI)
- ♦ with *eco Sensors* power management software
- ♦ with a MIB browser

These are detailed in the following sections.

## Graphical User Interface (GUI)

To configure the SNMP settings on an individual eco PDU via its graphical user interface (GUI), access the unit's *Device Management* page, shown below:



**Note:** Reference your eco PDU User Manual for full details about accessing the unit's Graphical User Interface via a Web browser.

The *Device Management* page allows super administrators, administrators, and users with device management permission to configure and control overall eco PDU operations. To configure the SNMP settings, click on the *Device Configuration* tab, and open the **Event Notification** section.

The Event Notification section is divided into four sections: SMTP Settings; Log Server; SNMP Trap Receivers; and Syslog Server. Scroll down to the **SNMP Trap Receivers** section, as shown below:

---

## SNMP Trap Receivers

### SNMP Trap Receiver

Enable SNMP Trap       SNMP V1    SNMP V2C    SNMP V3

Receiver IP 1:

Service Port 1:

Community:

Username:

Password:

Up to four SNMP management stations can be specified. If you want to use SNMP trap notifications, do the following:

1. Check *Enable SNMP Trap*.
2. Select which version of SNMP you want to use.
3. Key in the IP address(es) and the service port number(s) of the computer(s) to be notified of SNMP trap events. The valid port range is 1–65535. The default port number is 162.

---

**Note:** Make sure that the port number you specify here matches the port number used by the SNMP receiver computer.

---

4. Key in the privacy password(s) that correspond to each of the stations.

---

**Note:** See *Synchronizing SNMP Parameters*, page 6, for further details.

---

# eco Sensors

## Power Management Software

The *eco Sensors* software uses the SNMP protocol to connect to the eco PDU units in your installation.

**Note:** For full details about *eco Sensors* software and how to install it on your system, see the *eco Sensors* User Manual. This can be found on the CD bundled with your PE package or downloaded from the ATEN website.

To configure the SNMP settings using *eco Sensors* software, open the *System Management* page. The page opens with the **SNMP Settings** tab displayed. This section allows you to set up your SNMP and system parameters so that *eco Sensors* can connect to the eco PDUs in your installation:

The screenshot shows the NRGence web interface with the following elements:

- Navigation Bar:** Energy Management, User Management, Device Management, **SNMP Settings** (highlighted), SMTP Settings, Maintenance, Database, Sys Management (highlighted), Log.
- Default SNMP Agent Settings:**
  - Username/community: administrator
  - Port: 161
  - Timeout: 200 (ms)
  - Retry: 2
  - SNMP version: v1
  - Auth protocol: None
  - Auth password: [ ]
  - Privacy protocol: None
  - Privacy password: [ ]
- SNMP Trap Receiver:**
  - Username/community: administrator
  - Port: 162
  - SNMP version: v1/v2c
  - Auth protocol: None
  - Auth password: [ ]
  - Privacy protocol: None
  - Privacy password: [ ]
- System Parameter:**
  - Service delay: 30 (s)
  - Energy Box : 110 (V)
- Buttons:** Save

## **Default SNMP Agent Settings**

This section allows you to set up your default SNMP and system parameters so that *eco Sensors* can connect to the NRGence devices in your installation:

1. Enter a Username/Community, Port ID and Trap Port for the events.
2. Set the timeout and retry values.
3. Select the SNMP version, Privacy, and Authentication protocols from the drop-down menus.
4. Key in the Privacy and Authentication passwords.

---

**Note:** Certain parameters in this section must match those of all the NRGence devices in the installation. See *Synchronizing SNMP Parameters*, page 6.

---

5. Click *Search*. The devices will then be displayed in a list.

## **SNMP Trap Receiver**

To be notified of SNMP trap events, do the following:

1. Enter a Username, Port ID and Trap Port for the events.
2. Set the timeout and retry values.
3. Select the SNMP version, Privacy, and Authentication type from the drop-down menus.
4. Key in the Privacy and Authentication passwords.

---

**Note:** Certain parameters in this section must match those of all the eco PDU devices in the installation. See *Synchronizing SNMP Parameters*, page 6.

---

## **System Parameters**

- ◆ Enter the service delay time in seconds.
- ◆ Enter the Energy Box voltage in V.

---

**Note:** The EC1000 measures current only. Enter a reference voltage value here to calculate power and power dissipation in EC installations.

---



## Synchronizing SNMP Parameters

In order for *eco Sensors* to access the NRGence devices on the installation, it is essential that three of the SNMP parameters are the same. These parameters are *Username*, *Privacy PW*, and *Authen PW*. The default values, which are the same for *eco Sensors* and eco PDU units, are shown in the following table:

Parameter	Default	Web UI
Username	<i>administrator</i>	Administrator Account ID
Privacy PW	<i>privacypwd</i>	SNMP Privacy PW
Authen PW	<i>password</i>	Administrator Account Password

If any of these parameters are modified on the Web GUI of the eco PDU device(s), the same parameters in *eco Sensors* must also be modified.

---

**Note:** *eco Sensors* will only access eco PDUs with the same parameters, so it is essential that these parameters are synchronized for all eco PDUs in your installation. Reference the **Browser Operation** chapter of your eco PDU User Manual for further information.


---

# MIB Browser

## Management Information Base

You can also use a MIB browser to configure the SNMP settings for your PE installation.


First, ensure that a suitable MIB browser is installed on your system. For illustration purposes, the iReasoning MIB Browser is used for the following screenshots:




Next, prepare the PE MIB file. This can be found on the CD bundled with your PE package or downloaded from the ATEN website. Extract the file and save it to a convenient location.

**Note:** As the MIB file may need to be reloaded each time you use the program, we recommend that you save the file in the default MIB file path location.

Then, load the MIB using *File* → *Load MIBs* as below:




Once the MIB file has loaded, its corresponding MIB objects will be added in the appropriate location on the MIB tree hierarchy, as shown below:




Now, proceed to set the SNMP parameters.

## Set SNMP Parameters


1. In the *Address* field, input the DUT IP address.



2. Then click **Advanced** to open the SNMP settings window, as show below:



3. Enter values for the *Port*, *Read Community*, and *Write Community* fields (the example above shows the default settings). Then, select the SNMP version you want to configure from the dropdown menu. For v1 and v2, only the above fields are necessary. Click **OK** to save the settings.
4. If you select version 3 from the dropdown menu, a further SNMPv3 window containing more parameters appears, as shown below:



**Advanced Properties of SNMP Agent**

Address: 127.0.0.1

Port: 161

Read Community: administrator

Write Community: administrator

SNMP Version: 3 (SNMPv3)

USM User: administrator

Security Level: auth, priv

Auth Algorithm: MD5

Auth Password: \*\*\*\*\*

Privacy Algorithm: AES

Privacy Password: \*\*\*\*\*

Context Name:

Engine ID:

Localized Auth Key:

Localized Priv Key:

In the *USM User* field, enter the Default Community username; In the *Auth Password* field, enter the *Default Authentication* password; and in the *Privacy password* field, enter the Default Privacy password.

5. For the *Security Level*, *Auth Algorithm*, and *Privacy Algorithm* fields, make your selections from the options in the dropdown menus.

---

**Note:** SNMPv3 for NRGence PE devices is currently available with the following settings:

*Security Level:* auth, priv

*Auth Algorithm:* MD5


*Privacy Algorithm:* AES

---

## Setting Up Thresholds

To set up maximum and minimum Current and Voltage thresholds for each device and outlet using the MIB browser method, do the following:

1. Under *device* → *outletConfigTable* in the MIB tree, locate the threshold that you want to configure – the example below shows maximum current per outlet.
2. In the Results Table, click on the outlet that you wish to set the threshold for. The *SNMP Set* window appears:



**Note:** Once the MIB object has been selected in the tree, keyboard hotkey [Ctrl + b] will also open the Result Table. Select an item in the Result Table, and [Ctrl + b] will display its specific information.


3. In the *Value* field, enter the threshold setting and click **Save**.
4. Repeat this process for each outlet that you want to configure, and for both Current and Voltage threshold variables.

**Note:** Threshold settings can be entered at the device and/or outlet level, depending on your NRGence model.

## Setting Device/Outlet Status

To power manage a device or an outlet (Power On / Power Off / Reboot) using the MIB browser method, do the following:

1. Under *control* → *device* or *outlet* in the MIB tree, locate the device or outlet that you want to power manage – the example below shows an outlet.
2. In the Results Table, click on the outlet. The *SNMP Set* window appears:



3. In the *Value* field, enter the one of the following values:
  - ♦ 1 – to power off a device/outlet
  - ♦ 2 – to power on a device/outlet
  - ♦ 4 – to reboot a device/outlet

---

**Note:** A value of 3 indicates “pending” and is a view-only value that cannot be entered.

---

4. Click **Save**.
5. Repeat this process for each device/outlet that you want to power manage.

## Reading Device/Outlet Status

To read the status of a device or an outlet using the MIB browser method, do the following:

1. Under *device* → *deviceValueTable*, locate the variable that you want to read – the example below device current.
2. Click on the object in the MIB tree and the values are displayed in the Value column on the Results Page, as shown below:

The screenshot shows the iReasoning MIB Browser interface. The MIB tree on the left is expanded to show the path: iso.org.dod.internet.private.enterprises.aten → control → device → deviceValueTable → deviceValueEntry → deviceCurrent. The Result Table on the right displays the following data:

Name/OID	Value	Type	IP:Port
deviceCurrent.1	0.00	OctetString	10.3.52.65:161

Below the Result Table, a detailed view of the selected object is shown:

Name	deviceCurrent
OID	.1.3.6.1.4.1.21317.1.3.2.2.2.1...
MIB	ATEN-FE-CPG
Syntax	DisplayString
Access	read-only
Status	mandatory
DefVal	

To read status at the outlet level, navigate the MIB tree to that outlet.

Statuses for the following parameters are available:

- ◆ Current
- ◆ Voltage
- ◆ Power
- ◆ Power Dissipation