

IM3523A

Instruction Manual

LCR METER



**Read carefully before use.
Keep for future reference.**



When using the instrument for the first time

- Safety Information ▶ p.4
- Names and Functions of Parts ▶ p.10
- Measurement Preparations ▶ p.21



Troubleshooting

- Maintenance and Service ▶ p.209
- Error Display ▶ p.216

EN

Contents

Introduction.....	1
Verifying Package Contents	2
Options	3
Safety Information	4
■ Safety Symbols	4
■ Symbols for Various Standards	4
■ Notation	5
■ Measurement categories	5
Operating Precautions.....	6
■ Preliminary Checks	6
■ Instrument Installation	6
■ Shipping precautions	7
■ Handling the Instrument	7
■ Handling the LCR Application Disk	7

Chapter 1 Overview 9

1.1 Product Overview and Features	9
1.2 Names and Functions of Parts	10
1.3 Screen Organization and Operation ..	12
1.3.1 Initial Screen	12
1.3.2 Selecting the Measurement Mode ..	13
1.3.3 LCR Mode	14
1.3.4 Continuous Measurement Mode	17
1.3.5 System Settings Screen	18
1.3.6 Comparator/BIN Settings Screen	19
1.3.7 Panel Load screen	19
1.3.8 Compensation Settings Screen	19
1.3.9 Information Screen	20

Chapter 2 Measurement Preparations 21

2.1 Preparation Flowchart	21
2.2 Pre-Operation Inspection	22
2.3 Connecting the Power Cord	23
2.4 Connect measurement cables, optional Hioki probes or test fixture	24
2.5 Turning the Power On and Off	26

Chapter 3 Measurement Example 27

Chapter 4 LCR Function 29

4.1 About LCR function	29
4.2 Setting Basic Settings of Measurement Conditions	31
4.2.1 Setting Display Parameters	31
4.2.2 Setting the Measurement Frequency	33
4.2.3 Setting the Measurement Signal Level	37
4.2.4 Limiting the Voltage or Current Applied to the Sample (Limit Values)	41
4.2.5 Setting the Measurement Range	43
■ Setting AUTO Ranging	44
■ AUTO range limit function	44
■ Setting HOLD Ranging	45
■ JUDGE SYNC setting	48
4.2.6 Measuring at User-specified Timing (Trigger Measurement)	50
4.2.7 Setting Measurement Conditions for Individual Ranges	51
■ List screen layout	51
■ Selecting range settings to change	52
■ Setting the Measurement speed	53
■ Displaying Average Values (Average set) ..	54
■ Setting a delay before measurement data is acquired (trigger delay)	56
■ Applying the signal to the sample during measurement only (Trigger Synchronous Output Function) ...	57
4.3 Setting DC Resistance Measurement ..	61
4.3.1 Setting the Measurement Range	62
■ Setting AUTO Ranging	63
■ AUTO range limit function	63
■ Setting HOLD Ranging	64
■ JUDGE SYNC setting	66
4.3.2 Setting a Delay Time for DC Measurement (DC Delay)	67
4.3.3 Setting a Delay Time for Offset Measurement (Adjustment Delay) ...	69
4.3.4 Setting the Line Frequency	70

- 4.5.7 Detecting OPEN during 2-terminal Measurement (Hi-Z Reject Function) ... 105
- 4.5.8 Turning the LCD Display On and Off 107
- 4.5.9 Setting the Number of Display Digits 108
- 4.5.10 Setting Operation Sounds (Beep Sounds) 110
 - Reporting judgment results with beep operation 110
 - Turning the key tone on and off 111
 - Changing the beep tone and key tone ... 112
- 4.5.11 Adjusting the Screen Contrast 113
- 4.5.12 Disabling Key Operation (Key-lock Function) 114
 - Setting the Passcode of the Key-lock 116
 - Canceling key lock mode 117
- 4.5.13 Initializing (System Reset) 118

5.1	About Continuous Measurement Function 119	
5.1.1	Measurement screen	119
5.1.2	Setting Continuous Measurement ..	120
5.2	Configuring Basic Settings for Continuous Measurement	121
5.3	Performing Continuous Measurement	122
5.4	Configuring Application Settings for Continuous Measurement	123
5.4.1	Setting the Display Timing	123
5.4.2	Setting the LCD to ON/ OFF	124

6.1	Setting Open Circuit Compensation	125
6.1.1	All Compensation	127
6.1.2	Spot Compensation	131
6.2	Short Circuit Compensation	136
6.2.1	All Compensation	138
6.2.2	Spot Compensation	140
6.3	Adjusting Values Based on Reference Values (Load Compensation)	145

6.4	Compensating Measurement Cable Errors(Cable Length Compensation)	157
6.5	Converting Values (Scaling)	158

Chapter 7 Saving and Reading Panel Information 161

7.1	Saving Measurement Conditions (Panel Save Function)	162
7.2	Reading Measurement Conditions (Panel Load Function)	165
7.3	Changing a Panel Name	167
7.4	Deleting a Panel	169

Chapter 8 Setting the SYSTEM 171

8.1	Setting the Interface	171
8.2	Checking the Version of the Instrument	172
8.3	Self Checks (Self Diagnosis)	173

Chapter 9 External Control 177

9.1	External Input/Output Connector and Signals	177
■	Connector Type and Signal pin assignments	178
■	Signal Descriptions	182
9.2	Timing Chart	184
9.2.1	LCR Measurement	184
9.2.2	Continuous Measurement	187
9.3	Internal Circuitry	188
■	Electrical Specifications	189
■	Connection Examples	190
9.4	External I/O Settings	191
■	Setting Delay Time from Output of Comparator and BIN Judgment Results until Output of EOM (LOW)	191
■	Setting Reset of Judgment Results	191
■	Enabling Trigger Input for during Measurement	191
■	Setting Valid Edge of Trigger Input	191
9.5	External Control Q&A	192
9.6	Measurement Using a Computer	193

Chapter 10 Specifications 195

10.1	General Specifications	195
10.2	Measurement Range and Accuracy	200
■	Example calculation	204
10.3	About Measurement Times and Measurement Speed	207

Chapter 11 Maintenance and Service 209

11.1	Inspection, Repair and Cleaning	209
■	Inspection and Repair	209
■	Replaceable Parts and Operating Lifetimes	209
■	Transporting the instrument	210
■	Cleaning	210
■	Disposal	210
11.2	Troubleshooting	211
■	Before returning for repair	211
■	When no apparent cause can be established	214
■	Full Reset Procedure	215
11.3	Error Display	216

Appendix A1

Appendix1	Measurement Parameters and Calculation formula	A 1
Appendix2	Measurement of High Impedance Components	A 3
Appendix3	Measuring In-circuit Elements	A 4
Appendix4	Countermeasures Against Incorporation of External Noise	A 5
Appendix4.1	Countermeasures Against Incorporation of Noise from the Power Line	A 5
Appendix4.2	Countermeasures Against Noise from the measurement Cables	A 6
Appendix5	Supplying DC Bias	A 7
Appendix5.1	How to Supply a DC Bias Voltage	A 7
Appendix5.2	How to Supply a DC Bias Current	A 8
Appendix6	The Residual Charge Protection Function	A 9

Contents

Appendix7 Series Equivalent Circuit Mode and
Parallel Equivalent Circuit Mode
..... A 10

Appendix8 Open Circuit Compensation and
Short Circuit Compensation ... A 11

Appendix9 Rack Mounting A 13

Appendix10 Dimensional Diagram A 15

Appendix11 Initial Settings Table A 16

Introduction

Thank you for choosing the HIOKI Model IM3523A LCR Meter. To ensure your ability to get the most out of this instrument over the long term, please read this manual carefully and keep it available for future reference.

The latest edition of the instruction manual

The contents of this manual are subject to change, for example as a result of product improvements or changes to specifications.

The latest edition can be downloaded from Hioki's website.

<https://www.hioki.com/global/support/download/>



Product registration

Register your product in order to receive important product information.

<https://www.hioki.com/global/support/myhioki/registration/>



Refer to the following instruction manuals in accordance with your application.
Please review the separate "Operating Precautions" before using the instrument.

Name of the instruction manual	Description	Format
Instruction Manual (this manual)	Includes overview of the instrument, operation methods, function descriptions, and specifications.	PDF file (included on CD)
Communication Instruction Manual	Includes information related to controlling the instrument using its communications interface.	PDF file (included on CD)
Startup Guide	Includes information for using the instrument safely, basic operation methods, specifications (selected relevant information).	Hard copy
Operating Precautions	Information for using the instrument safely.	Hard copy

Verifying Package Contents

When you receive the instrument, inspect it carefully to ensure that no damage occurred during shipping. In particular, check the accessories, panel switches, and connectors. If damage is evident, or if it fails to operate according to the specifications, contact your dealer or Hioki representative.

Confirm that these contents are provided.

- | | |
|---|--|
| ☐ IM3523A LCR Meter 1 | ☐ LCR Application Disk 1
(Instruction Manual [PDF format], Communication Instruction Manual [(PDF format], explanation of communications commands, USB driver, sample application)
The latest version can be downloaded from Hioki's website. |
|  | ☐ Startup Guide 1 |
| ☐ Power Cord (2-line + ground) (p. 23) 1 | ☐ Operating Precautions (0990A905) 1 |

NOTE

- Probes, fixture are not supplied with the unit as standard equipment. You should order them separately, according to requirements.
- The instrument ships from the factory configured as described in "Appendix11 Initial Settings Table"(p. A16).

Precautions when transporting the instrument


Use the original packing materials when transporting the instrument, if possible.

See "Transporting the instrument" (p. 210)

Options

The following options are available for the instrument. Contact your authorized Hioki distributor or reseller when ordering. The options are subject to change. Visit our website for updated information.

L2000 4-Terminal Probe



▼ Alligator-clip-type measurement probes. These general-purpose dual-electrode clips fit a wide range of conductor thicknesses.


Measurable range: DC to 8 MHz
Maximum voltage: ± 42 V peak (AC+DC)
Maximum current: ± 1 A peak (AC+DC)
Measurable terminal diameter: 0.3 mm to 5 mm

9140-10 4-Terminal Probe



Measurable range: DC to 200 kHz
Maximum voltage: ± 42 V peak (AC+DC)
Maximum current: ± 1 A peak (AC+DC)
Measurable terminal diameter: 0.3 mm to 5 mm


9500-10 4-Terminal Probe



▼ Rubber-sheathed alligator clip type

Measurable range: DC to 200 kHz
Maximum voltage: ± 40 V DC (42 V peak [Measurement signal + bias voltage])
Maximum current: 1 A peak (Measurement signal + bias current)
Measurable terminal diameter: 0.3 mm to 2 mm


L2001 Pincher Probe



▼ Pincher type


Measurable range: DC to 8 MHz
Maximum applied voltage: ± 42 V peak (AC+DC)
Maximum applied current: ± 1 A peak (AC+DC)
Electrode tip spacing: 0.3 mm to 6 mm

9261-10 Test Fixture



Measurable range: DC to 8 MHz
Maximum applied voltage: ± 40 V DC
Measurable terminal diameter: 0.3 mm to 1.5 mm


9262 Test Fixture



▼ This fixture is for measuring lead components. (residual resistance of 10 m Ω or less after zero adjustment)

Measurable range: 42 Hz to 8 MHz
Maximum applied voltage: ± 40 V DC
Test sample dimensions: Lead diameter of 0.3 mm to 2 mm
Lead pitch of 5 mm or more


9263 SMD Test Fixture



▼ This fixture is for measuring chip components. (residual resistance of 10 m Ω or less after zero adjustment)


Measurable range: DC to 8 MHz
Maximum applied voltage: ± 40 V DC
Test sample dimensions: Test sample width of 1 mm to 10 mm

9677 SMD Test Fixture




Measurable range: DC to 120 MHz
Maximum applied voltage: ± 40 V DC
Test sample width of 3.5 $\pm$ 0.5 mm

9268-10 DC Bias Voltage Unit




Measurable range: 40 Hz to 8 MHz
Maximum applied voltage: ± 40 V DC

9269-10 DC Bias Current Unit



Measurable range: 40 Hz to 2 MHz
Maximum applied current: 2 A DC


9699 SMD Test Fixture



▼ This fixture is for the lower electrode.


Measurable range: DC to 120 MHz
Maximum applied voltage: ± 40 V DC
Test sample dimensions: Test sample width of 1 mm to 4 mm
Test sample height of 1.5 mm or less

IM9100 SMD Test Fixture



Measurable range: DC to 8 MHz
Maximum applied voltage: ± 42 V peak (AC+DC)
Maximum applied current: ± 0.15 A rms (± 0.15 A DC)
Measurement test sample dimensions: 0.4 $\times$ 0.2 mm, 0.6 $\times$ 0.3 mm, 1.0 $\times$ 0.5 mm

IM9110 SMD Test Fixture



Measurable range: DC to 1 MHz
Maximum applied voltage: ± 42 V peak (AC+DC)
Maximum applied current: ± 0.15 A rms (± 0.15 A DC)
Measurement test sample dimensions: 0.25 $\pm$ 20% $\times$ 0.125 $\pm$ 10% $\times$ 0.125 $\pm$ 10% mm

Safety Information



WARNING

This instrument is designed to comply with IEC 61010 Safety Standards, and has been thoroughly tested for safety prior to shipment. However, mishandling during use could result in injury or death, as well as damage to the instrument. Using the instrument in a way not described in this manual may negate the provided safety features.

Be certain that you understand the instructions and precautions in the manual before use. We disclaim any responsibility for accidents or injuries not resulting directly from instrument defects.

This manual contains information and warnings essential for safe operation of the instrument and for maintaining it in safe operating condition. Before using it, be sure to carefully read the following safety precautions.

Safety Symbols



Indicates the presence of a potential hazard. For more information about locations where this symbol appears on instrument components, see the “Operating Precautions” section (p. 6), warning messages listed at the beginning of operating instructions, and the accompanying document entitled “Operating Precautions.”



Indicates AC (Alternating Current).



Indicates the ON side of the power switch.



Indicates the OFF side of the power switch.

The following symbols in this manual indicate the relative importance of cautions and warnings.



Indicates an imminently hazardous situation that, if not avoided, will result in death or serious injury.



Indicates a potentially hazardous situation that, if not avoided, could result in death or serious injury.



Indicates a potentially hazardous situation that could result in minor or moderate injury or potential risks of damage to the supported product (or to other property) if not avoided.



Indicates advisory items related to performance or correct operation of the instrument.



Indicates information or content that is particularly important from the standpoint of operating or maintaining the instrument.

Symbols for Various Standards



Indicates that the product is subject to the Waste Electrical and Electronic Equipment (WEEE) Directive in EU member nations.
Dispose of the product in accordance with local regulations.



This symbol indicates that the product conforms to regulations set out by the EU Directive.

Notation

Symbols in this manual

	Indicates a prohibited action.
(p.)	Indicates the location of reference information.
*	Indicates that descriptive information is provided below.
[]	Menus, Pages, Setting items, dialogs, buttons in a dialog, and other names on the screen and the keys are indicated in brackets.
DIGIT	Indicates that digits may be entered. (p. 35)
10KEY	Indicates that values may be entered using the numeric keypad. (p. 33)
ENTER	Indicates that the same operation can be performed by pressing the ENTER key.
	The cursor key to be used is shown in black, while unused cursor keys are shown in gray. (In the example to the left, the  key is to be used.)

Accuracy labeling

The instrument's accuracy is expressed using a combination of the formats shown below.

- By defining limit values for errors using the same units as measured values.
- By defining limit values for errors as a percentage of the reading and a percentage of the setting.


Reading (display value):	Indicates the value displayed by the instrument. Limit values for reading errors are expressed as a percentage of the reading ("% of reading" or "% rdg").
Setting (set value)	Indicates the set value, such as voltage and current, that the instrument has been configured to output. Limit values for setting errors are expressed as a percentage of the setting ("% of setting").

Measurement categories

To ensure safe operation of measurement instruments, IEC 61010 establishes safety standards for various electrical environments, categorized as CAT II to CAT IV, and called measurement categories.

CAT II	Primary electrical circuits in equipment connected to an AC electrical outlet by a power cord (portable tools, household appliances, etc.) CAT II covers directly measuring electrical outlet receptacles.
CAT III	Primary electrical circuits of heavy equipment (fixed installations) connected directly to the distribution panel, and feeders from the distribution panel to outlets.
CAT IV	The circuit from the service drop to the service entrance, and to the power meter and primary overcurrent protection device (distribution panel).

Using a measurement instrument in an environment designated with a higher-numbered category than that for which the instrument is rated could result in a severe accident, and must be carefully avoided. Using a measurement instrument in an environment designated with a higher numbered category than that for which the instrument is rated could result in a severe accident, and must be carefully avoided.



Operating Precautions

- Follow these precautions to ensure safe operation and to obtain the full benefits of the various functions.
- Use of the instrument should confirm not only to its specifications, but also to the specifications of all accessories, options, and other equipment in use.

Preliminary Checks

Before using the instrument the first time, verify that it operates normally to ensure that the no damage occurred during storage or shipping. If you find any damage, contact your dealer or Hioki representative.



DANGER

Before using the instrument, make sure that the insulation on the voltage cords is undamaged and that no bare conductors are improperly exposed. Using the instrument in such conditions could cause an electric shock, so contact your dealer or Hioki representative for replacements.

Instrument Installation

Avoid the following locations that could cause an accident or damage to the instrument.



Exposed to direct sunlight
Exposed to high temperature



In the presence of corrosive or explosive gases




Exposed to water, oil, other chemicals, or solvents
Exposed to high humidity or condensation



Exposed to strong electromagnetic fields
Near electromagnetic radiators



Exposed to high levels of particulate dust



Near induction heating systems (e.g., high-frequency induction heating systems and IH cooking utensils)





Subject to vibration

- The instrument should be operated only with the bottom side downwards.
- The instrument must not be placed on an unstable table or tilted surface.
- Vents must not be obstructed.

50 mm or more

50 mm or more

10 mm or more



- The instrument can be used with the stand.(p. 11)
It can also be rack-mounted.(p.A13)
- If mounting the instrument in a confined space such as a rack, ensure that the ambient temperature remains within the range specified in the product specifications, for example by using forced-air cooling.

Shipping precautions

Hioki disclaims responsibility for any direct or indirect damages that may occur when this instrument has been combined with other devices by a systems integrator prior to sale, or when it is resold.

Handling the Instrument

DANGER

- To avoid electric shock, do not remove the instrument's case. The internal components of the instrument carry high voltages and may become very hot during operation.
- Do not allow the instrument to get wet, and do not take measurements with wet hands. This may cause an electric shock.

CAUTION

- If the instrument exhibits abnormal operation or display during use, review the information in "Troubleshooting" (p. 211) and "Error Display" (p. 216) before contacting your dealer or Hioki representative.
- Do not connect charged capacitors to measurement terminals or input voltages or currents from an external source. Doing so may damage the instrument.
- This instrument is not designed to be entirely water- or dust-proof. Do not use it in an especially dusty environment, nor where it might be splashed with liquid. This may cause damage.
- To avoid damage to the instrument, protect it from physical shock when transporting and handling. Be especially careful to avoid physical shock from dropping.
- Do not apply heavy downward pressure with the stand extended. The stand could be damaged.
- After use, always turn OFF the power.

NOTE

This instrument complies with EN 61326 Class A. This instrument may cause interference if used in residential areas. Such use must be avoided unless the user takes special measures to reduce electromagnetic emissions to prevent interference to the reception of radio and television broadcasts.

Handling the LCR Application Disk

CAUTION

- Always hold the disc by the edges, so as not to make fingerprints on the disc or scratch the printing.
- Never touch the recorded side of the disc. Do not place the disc directly on anything hard.
- Do not wet the disc with volatile alcohol or water, as there is a possibility of the label printing disappearing.
- To write on the disc label surface, use a spirit-based felt pen. Do not use a ball-point pen or hard-tipped pen, because there is a danger of scratching the surface and corrupting the data. Do not use adhesive labels.
- Do not expose the disc directly to the sun's rays, or keep it in conditions of high temperature or humidity, as there is a danger of warping, with consequent loss of data.
- To remove dirt, dust, or fingerprints from the disc, wipe with a dry cloth, or use a CD cleaner. Always wipe from the inside to the outside, and do not wipe with circular movements. Never use abrasives or solvent cleaners.
- Hioki shall not be held liable for any problems with a computer system that arises from the use of this LCR Application Disk, or for any problem related to the purchase of a Hioki product.

Overview

Chapter 1

1

Chapter 1 Overview

1.1 Product Overview and Features

The HIOKI IM3523A LCR Meter is an impedance measuring instrument that features high-speed, high-precision operation.

With measurement frequencies of 40 Hz to 200 kHz and measurement signal levels of 5 mV to 5 V, the instrument allows you to configure a broad range of measurement conditions. Additionally, the ability to perform tests using different measurement conditions with a single instrument while changing setup profiles easily makes the IM3523A well suited for use on production lines.

Wide range of measurement conditions(p.31)

Capable of measurement under a wide range of measurement conditions: measurement frequencies from 1 mHz to 200 kHz and measurement signal levels from 5 mV to 5 V.

Various interfaces supported

Supports the optimal external I/O (handler interfaces) for production lines: USB and LAN.

Comparator function(p.76)

Capable of making HI/IN/LO pass/fail judgments based on measurement values for two parameters.




Capable of high-speed measurement

High-speed measurement is possible. The IM3523A can perform measurements at speeds of up to 2 ms (typical values).

BIN function(p.83)

Capable of easily ranking up to 10 samples based on measurement values.



Simple production line setup changes

Automatically sets the optimal range according to comparator or BIN judgment standards. Because the IM3523A also lets you set measurement conditions separately for each range, it is possible to automatically set the optimal measurement conditions in response to range changes.

Continuous measurement function(p.119)

Capable of performing continuous measurement using previously stored measurement conditions. This function makes it possible to generate pass/fail judgments using different sets of measurement conditions. (For example, the instrument can perform C-D measurement at 120 Hz followed by Rs measurement at 100 kHz.)

1.2 Names and Functions of Parts

Front

Power Switch(p.26)

- Unlit : power off (when no power supplied)
- Red light : power off (while power is supplied)
- Green light : power on

Display Screen(p.12)

Monochrome graphical LCD
Displays the Measurement screen, Basic Settings screen, and Advanced Settings screen.

COMP/BIN Key(p.75)

**COMP
/ BIN**

When the comparator/BIN function is enabled, displays the Comparator/BIN Settings screen.

Panel Load Key(p.165)

**PANEL
LOAD**

Loads measurement conditions saved with the panel save function.

Entering numerical values(p.12)

0 · · **9**

Enter a numerical value.
(we call these the "tenkeys")

-

Adds a minus sign to the value.

×10³ · · **÷10³**

Switches units.

**BACK
SPACE**

Deletes the value in the selected field.

ENTER

Accepts the value and settings.

ESC

Cancels the measurement condition settings for each range and the comparator/BIN settings, and then returns to the screen that was displayed before you began configuring settings.

ADJ Key(p.125)

ADJ

Lets you configure and use compensation functions and scaling.

INFO Key(p.20)

INFO

Lets you check previously configured measurement conditions.

TRIG Key(p.50)

TRIG

Performs trigger measurement under the conditions for which the external trigger has been configured.

F keys


F1 · · **F4**

Selects the corresponding item on the right side of the display.

Cursor keys

← **↑** **→** **↓**

Selects items on the screen.



Measurement Terminals

Connect measurement cables or a fixture.
(H_{CUR} jack, H_{POT} jack, L_{POT} jack, L_{CUR} jack, GUARD jack)

COMP indicator LEDs

Displays the measurement value judgment results for the main and sub parameters.


Comparator measurement

[See](#) (p.76)

BIN measurement

[See](#) (p.83)

Panel



This instrument can be rack mounted.

[See](#) "Appendix9 Rack Mounting"(p. A13)

Rear

Power inlet

Connect the power cord.
(p.23)

Rear USB connector

Connect a computer to control the instrument using communications commands.

See Communication Instruction Manual (LCR Application Disk)


LAN connector

Lets you control the instrument from a computer via a LAN (socket communications).

See Communication Instruction Manual (LCR Application Disk)

LAN MAC address

See Communication Instruction Manual (LCR Application Disk)




EXT I/O connector

Lets you connect a PLC or I/O board so that you can start measurement and acquire judgment results. (p.177)

Manufacturer's serial number

The serial number consists of nine digits. The first two digits indicate the year of manufacture, while the second two digits indicate the month of manufacture. Do not remove this sticker as the number is important.


Left



Vents

Keep clear of obstructions. (p.6)

Right



Stand

Lets you incline the instrument for easy viewing.

CAUTION

Do not apply heavy downward pressure with the stand extended. The stand could be damaged.

When using the stand

Extend the stand until it clicks into place.
Make sure to extend both legs of the stand.

Collapsing the stand


Fold in the stand until it clicks into place.

1.3 Screen Organization and Operation

The instrument has two general display screen types: Measurement and Settings.
Refer to "11.3 Error Display" (p. 216) for error displays.
The screen examples in this guide appear reversed (black on white) for best visibility. However, the instrument screens can actually be displayed only as white characters on black background.

1.3.1 Initial Screen

The initial screen, which is the first screen displayed when you turn on the instrument, allows you to perform measurement while checking measurement conditions. When the instrument is turned back on, the display will reflect the measurement mode that was in use when the power was turned off.



Key lock screen

The diagram shows a simulated instrument screen in key lock mode. A callout box points to the `[UNLCK]` button, stating: "The Pass Code Entry screen will be displayed. See "Canceling key lock mode" (p. 117)".

The screen displays: `[NORM]` at the top left, `[Z]` and `10.0033kΩ` on the left, `[θ]` and `0.076` on the right, `Vac 987.9mV` and `Iac 98.76mA` in the middle, and a bottom status bar with `1.0000kHz`, `V : 1.000V`, `A: 100kΩ`, `MED`, and `EXT`. A vertical menu on the right shows `UNLCK` and `F1`.


1.3.2 Selecting the Measurement Mode

This section describes how to select the measurement mode.


- 1 Open the Advanced Settings screen.



- 2 Select the [MODE].




- 3 Set the mode.



NOTE After changing the measurement mode, check all settings (including compensation) before performing measurement.

1.3.3 LCR Mode


Screen Organization



Basic Settings Screen

Basic Settings Screen

This screen allows you to configure basic settings for the measurement conditions.




Settings

PARA	Measurement parameter setting (p.31)
FREQ	Measurement frequency setting (p.33)
LEVEL	Measurement signal level setting (p.37)
LIMIT	Voltage and current limit settings (p.41)
RANGE	Measurement range setting (p.43)
JUDGE SYNC	Judgment synchronization setting (p.48)
TRIG	Trigger setting (p.50)
LIST	Setting of measurement conditions for the respective ranges (p.51)

LIST Settings screen

This screen is displayed when you select **[LIST]** on the Basic Settings screen. It allows you to configure measurement conditions for each range.




Settings

SPEED	Measurement speed setting (p.53)
AVG	Average setting (p.54)
DELAY	Trigger delay setting (p.56)
SYNC	Trigger synchronization output setting (p.57)

Rdc (DC resistance measurement) Settings screen

This screen allows you to configure measurement conditions for DC resistance measurement.




Settings

RANGE	Measurement range setting (p.62)
JUDGE SYNC	Judgment synchronization setting (p.66)
DC DELAY	DC delay setting (p.67)
ADJ DELAY	Adjustment delay setting (p.69)
LINE FREQ	Line frequency setting (p.70)
LIST	Setting of measurement conditions for the respective ranges (p.71)

LIST Settings screen

This screen is displayed when you select **[LIST]** on the Rdc Settings screen. It allows you to configure measurement conditions for each range.



Settings


SPEED	Measurement speed setting (p.73)
AVG	Average setting (p.74)

1.3 Screen Organization and Operation

Advanced Settings Screen

Advanced 1 Settings Screen


This screen is used to configure LCR mode application settings.



Settings	
MODE	Measurement mode setting (p.13)
JUDGE	Measurement result judgment setting (p.75)
MEMORY	Save settings of measurement results (p.97)
JUDGE-EOM	JUDGE-EOM delay time setting (p.100)
JUDGE RESET	JUDGE-EOM reset setting (p.100)
TRIG ENABLE	IO trigger setting (p.101)
TRIG EDGE	IO trigger valid edge setting (p.101)
EOM MODE	EOM output method setting (p.102)
EOM-ON-TIME	EOM output time setting (p.102)
CONTACT	Contact check function setting (p.103)
Hi Z	Hi-Z reject function setting (p.105)

Advanced 2 Settings Screen


This screen is used to configure LCR mode application settings.



Settings	
DISP	LCD settings (p.107)
DIGIT	Number of display digits setting (p.108)
BEEP	Beep enable/disable setting (p.110)
BEEP TONE	Beep tone setting (p.112)
CONTRAST	Screen contrast setting (p.113)
KEYLOCK	Key-lock setting (p.114)
PANEL SAVE	Panel save (p.162)
RESET	System reset (p.118)

Panel Save Screen


This screen is used to configure continuous measurement mode application settings.



Settings	
SAVE	Panel save (p.163)
VIEW	Panel information display (p.164)
TYPE	Panel save type setting (p.162)

1.3.4 Continuous Measurement Mode

Screen Organization



Basic Settings Screen

This screen allows you to check continuous measurement settings and saved panel information. (p.121)

CONT >> BASIC		EXEC:2/2		OFF	
No.	EXEC	PANEL NAME	MODE	PARA	
001	ON	NEW_PANEL	ALL	Z- 0	
002	ON	NEW_PANEL	ALL	Z- 0	
004	OFF	NEW_PANEL	ALL	Z- 0	

Settings

OFF	Turns off continuous measurement
ON	Turns on continuous measurement
INFO	Panel information display

Advanced Settings Screen

This screen is used to configure continuous measurement mode application settings. (p.123)


CONT >> ADVANCED		LCR	
MODE	:CONT		
DRAW	:REAL		
DISP	:ON		

Settings

MODE	Measurement mode setting (p.120)
DRAW	Display timing setting (p.123)
DISP	LCD setting (p.124)


1.3.5 System Settings Screen

This screen is used to set the interface type.




Settings	
USB	USB Setting (p.171)
LAN	LAN Setting (p.171)

Check the version of the instrument



Settings	
S/N	Serial No. (p.172)
FPGA	FPGA Version (p.172)
USB	USB ID (Vendor ID, product ID) (p.172)
MAC	MAC address (p.172)
S/W	Software Version (p.172)

Self Check



Settings	
KEY TEST	Performs a key test (p.173)
DISPLAY & LED TEST	Performs a screen display test (p.174)
ROM/RAM TEST	Performs a ROM/RAM test (p.175)
I/O HANDLER TEST	Performs an I/O test (p.176)

1.3.6 Comparator/BIN Settings Screen

Comparator Mode

When the **COMP / BIN** key is pressed during comparator measurement.

COMP	
Z	10.0019kΩ
	0.079 °
Vac 988.7mV Iac 98.85mA	
HI :OFF	HI :OFF
LO :OFF	LO :OFF

Settings

HI	Upper Limit Value Setting (p.76)
LO	Lower Limit Value Setting (p.76)

BIN mode

When the **COMP / BIN** key is pressed during BIN measurement.

BIN MAIN Z:ABS	
No.	HI LO
BIN 1:	OFF OFF
BIN 2:	OFF OFF
BIN 3:	OFF OFF
BIN 4:	OFF OFF

Settings

No.	BIN number (p.83)
HI	Upper Limit Value Setting (p.83)
LO	Lower Limit Value Setting (p.83)

1.3.7 Panel Load screen

When the **PANEL LOAD** key is pressed.

LOAD	
No.	PANEL NAME TYPE INFORMATION
001	NO SAVE
002	NO SAVE
003	NO SAVE
004	NO SAVE

Settings

No.	Panel No. (p.165)
PANEL NAME	Panel name (p.165)
TYPE	Save type (p.165)
INFORMATION	Saved information (p.165)

1.3.8 Compensation Settings Screen

When the **ADJ** key is pressed.

ADJUST	
OPEN	:OFF
SHORT	:OFF
LOAD	:OFF
CABLE	:0m
SCALE	:OFF


Settings

OPEN	Open circuit compensation setting (p.125)
SHORT	Short circuit compensation setting (p.136)
LOAD	Load circuit compensation setting (p.145)
CABLE	Cable length compensation setting (p.157)
SCALE	Scaling setting (p.158)

1.3.9 Information Screen

AC1 Screen


This screen is displayed when the **INFO** key is pressed.



Settings

FREQ	Frequency
V	Signal level
LIMIT	Limit value
RANGE	Measurement range
JSYNC	Judge Synchronous setting
TRIG	Trigger Setting
OPEN	Open Circuit Compensation
SHORT	Short circuit compensation setting
LOAD	Panel load


AC2 Screen



Settings

SPEED	Measurement Speed
AVG	Average setting
DELAY	Trigger delay
SYNC	Trigger Synchronous Output Function
CABLE	Cable length compensation
SCALE	Scaling

DC Screen



Settings

V	Signal level
RANGE	Measurement range
JSYNC	Judgment synchronization setting
dcDLY	DC delay
ajDLY	Adjust delay
SPEED	Measurement Speed
AVG	Average setting
LINE	Line frequency

When **INFO** is pressed

Pressing **INFO** key on the Information screen causes the screen to transition as follows:

AC1 screen→AC2 screen→DC screen→ Back to Measurement screen

Measurement Preparations

Chapter 2

2


Chapter 2 Measurement Preparations

Be sure to read the "Operating Precautions" (p. 6) before installing and connecting this instrument. Refer to "Appendix9 Rack Mounting"(p. A13) for rack mounting.

2.1 Preparation Flowchart

1 Installing the Instrument (p.6)

2 Connecting the Power Cord (p.23)




3 Connect measurement cables, optional Hioki probes or test fixture (p.24)

Connect the external interface (as needed)

NOTE Confirm that the instrument is turned off.

- USB Cable
- LAN Cable
- EXT I/O



4 Turning Power On (p.26)

Make instrument settings (p.31)

Connect to the test sample.
Remove the test sample and turn off the power after use. (p.26)


NOTE When performing DC resistance measurement, be sure to set the line frequency before starting measurement.
See "4.3.4 Setting the Line Frequency" (p. 70)

2.2 Pre-Operation Inspection


Please read the "Operating Precautions" (p. 6) before use.

Before using the instrument for the first time, verify that it operates normally to ensure that no damage occurred during storage or shipping. If you find any damage, contact your dealer or Hioki representative.

1 Peripheral Device Inspection



2 Instrument Inspection



2.3 Connecting the Power Cord




WARNING

Confirm the supply voltage to the instrument matches the supply voltage indicated on the instrument before connecting the power cord to the instrument. Connection to an improper supply voltage may damage the instrument and present an electrical hazard.

Connect the power cord to the power inlet on the instrument, and plug it into an outlet.

Connection Procedure

**1**

Confirm that the power cord matches the line voltage, and plug it into the power inlet on the instrument. (AC100 V to 240 V)

2

Plug the other end of the power cord into an outlet. The POWER button on the instrument's front panel will flash red.

If power is interrupted while the instrument is operating, it will start back up immediately when power is restored. (when the circuit breaker is turned back on, etc.)


2.4 Connect measurement cables, optional Hioki probes or test fixture

DANGER

Before using the instrument, make sure that the insulation on the voltage cords is undamaged and that no bare conductors are improperly exposed. Using the instrument in such conditions could cause an electric shock, so contact your dealer or Hioki representative for replacements.

CAUTION

- For safety reasons, disconnect the power cord when the instrument is not used.
- To avoid damaging the power cord, grasp the plug, not the cord, when unplugging it from the power outlet.
- Do not apply a voltage to the measurement terminals. Doing so may damage the instrument.
- When disconnecting the BNC connector, be sure to release the lock before pulling off the connector. Forcibly pulling the connector without releasing the lock, or pulling on the cable, can damage the connector.
- To avoid breaking the cables or probes, do not bend or pull them.
- Avoid stepping on or pinching cables, which could damage the cable insulation.
- Keep the cables well away from heat sources, as bare conductors could be exposed if the insulation melts.
- Keep in mind that, in some cases, conductors to be measured may be hot.
- To avoid electric shock, do not exceed the lower of the ratings shown on the instrument and connection cords.




NOTE



- Use only the specified connection cables. Using a non-specified cable may result in incorrect measurements due to poor connection or other reasons. Refer to "Options" (p. 3) for details.
- Before using a fixture or the like, read the instruction manual supplied with the product to be used.

2.4 Connect measurement cables, optional Hioki probes or test fixture

Connecting a measurement cable/fixture




(When using the optional 9140-10 or L2001)
Connect the red plugs to the H_{CUR} and H_{POT} jacks, and the black plugs to the L_{CUR} and L_{POT} jacks.



Connect directly to the measurement jacks with the label side up, and affix with the levers on the left and right.

(When using the optional 9500-10)
BNC plug of H_{CUR} , H_{POT} , L_{CUR} and L_{POT} connected properly to the measurement terminals of each of the instruments.




Points to pay attention to when making your own probe

- Use 50 Ω coaxial cable for the measurement cable.
- Ensure that the length of the cable is the same as that set for the instrument. (1m)
- The cable length is defined as the length from the tip of the BNC connector to the tip of the probe electrode.
- Make the portion of the core wire that is exposed as short as possible.
- Connect the H_{CUR} , L_{CUR} , H_{POT} , and L_{POT} shield pairs at the measurement object side.
(Ensure that a shield is not connected to a core wire.)

NOTE

- As a rule, only HIOKI-brand probes, fixtures, and other components (options) should be used. Use of probes that you have built yourself may prevent the instrument from performing in a manner that satisfies its specifications.
See "Options" (p. 3)
- If all four terminals are disconnected, a meaningless number may be displayed on the unit.

Measurement Terminal Configuration



2.5 Turning the Power On and Off

Once you've connected probes and test fixtures, connect the power cord's plug to a power outlet.




WARNING

- Before turning the instrument on, make sure the supply voltage matches that indicated on its power connector. Connection to an improper supply voltage may damage the instrument and present an electrical hazard.
- Be careful to avoid connecting the supply voltage improperly. Doing so may damage the instrument's internal circuitry.
- To avoid electrical accidents and to maintain the safety specifications of this instrument, connect the power cord only to a 3-contact (two-conductor + ground) outlet.
- To avoid shock and short circuits, turn off all power before connecting probes.

Turning main power on

Press the **POWER** button (it lights green).

When the power is turned on, the same setting as when the power was last turned off appears.



To ensure that measurements fulfill the degree of accuracy described in the specifications, allow the instrument to warm up for at least 60 minutes after it is turned on.

Turning main power off

ON the main power in the state, hold down the front **POWER** switch 1 second approximately. (it lights red)(Standby state*).



Disconnect the power cord from the outlet to extinguish the POWER button light. When power is turned on again, operation resumes with the same settings as when last turned off.

*: Standby state

The instrument is in the standby state when measurement has been stopped and the instrument is waiting for POWER button input to be detected. To allow POWER button input to be detected, some internal circuitry is operating with power consumption of approximately 4 W.

NOTE

If a power outage (e.g., breaker trip) occurs when the instrument is on, it will automatically turn on again when power is restored. (without pressing the POWER button)


Measurement Example

Chapter 3

Measuring a Laminated Ceramic Capacitor


Necessary items : 9263 SMD test fixture
Laminated ceramic capacity you want to measure

- 1 Connect the 9263 SMD test fixture to the measurement terminals.




For the connection procedure, refer to the instruction manual supplied with the fixture.

- 2 Open the Basic Settings screen.




F1 ► Displays the Basic Settings screen.

- 3 Set the measurement conditions.



Setting example		
PARA	Display parameters	:MAIN :Cs :SUB :D
FREQ	Measurement frequency	:1.0000 kHz
LEVEL	Measurement signal mode: Open circuit voltage mode (V) Measurement signal level:1.000 V	
LIMIT	Voltage and current limit	:OFF
RANGE	Measurement range	:AUTO
JUDGE SYNC	Judgment synchronization function	:OFF
TRIG	Trigger	:INT
LIST	Displays the LIST Settings screen.	

4 Select **[LIST]** on the Basic Settings screen to open the LIST Settings screen.




5 Set the measurement conditions for the respective ranges.

RANGE	SPEED	AVG	DELAY	SYNC
100mΩ	FAST	OFF	0.0000s	OFF
1Ω	MED	2	0.0010s	0.0010s
10Ω	SLOW	10	0.0100s	0.0100s
100Ω	SLOW2	100	0.1000s	0.1000s

Select


Setting example		
SPEED	Measurement speed	:MED
AVG	Average	:001
DELAY	Trigger Delay	:0s
SYNC	Trigger Synchronous Output	:OFF

6 Connect the test sample to the 9263 SMD test fixture.



For the connection procedure of the test sample, refer to the instruction manual supplied with the fixture.

7 Check the measurement results.



- When you want to judge the measurement results
See "4.4.1 Making Judgments Based on Upper and Lower Limit Values (Comparator Measurement Mode)" (p. 76)
- When you want to save the measurement results
See "4.5.1 Saving Measurement Results (Memory function)" (p. 97)

LCR Function


Chapter 4

4.1 About LCR function

The LCR function allows you to measure the impedance, phase angle, and other items by applying any frequency or level (effective value) signal to the element you want to measure. This function is suitable for evaluating the passive element of a capacitor, coil, or the like.


Measurement screen

The Measurement screen allows you to make measurements while reviewing measurement conditions. When the instrument is turned back on, the display will reflect the measurement mode that was in use when the power was turned off. For more information about the screen layout, see (p.12).




4.1 About LCR function

Keys that can be used on the Measurement screen




When performing comparator measurement.

(Switch between the limit and monitor values with the ◀ ▶ keys.)



When performing BIN measurement.

(Switch between the limit and monitor values with the tenkey (0 to 9 , .) or the ◀ ▶ keys.)



NOTE When the measurement value is outside the guaranteed accuracy range, **REF VAL** will be shown on the error message display. If you encounter this issue, the following factors may be at play. Change the measurement conditions after checking the guaranteed accuracy range as described in "10.2 Measurement Range and Accuracy" (p.200), or use the measurement value as a reference value.

- If the measurement signal level is too low: Increase the measurement signal level.
- If the current measurement range (when using the HOLD setting) is not appropriate: Set the range to the optimal measurement range using AUTO ranging or change the measurement range manually.

4.2 Setting Basic Settings of Measurement Conditions

NOTE Measurement conditions for DC resistance measurement are configured on a different screen.

See "4.3 Setting DC Resistance Measurement" (p.61)


4.2.1 Setting Display Parameters

You can select a main and sub parameter from the 15 measurement parameters to display.

See "Appendix1 Measurement Parameters and Calculation formula"(p. A1)


"Appendix7 Series Equivalent Circuit Mode and Parallel Equivalent Circuit Mode"(p. A10)

- 1 Open the Basic Settings screen.



F1 ► Displays the Basic Settings screen.


- 2 Select [MAIN] under [PARA].



F1 ► Displays the Main Parameter Settings screen. ENTER

1 Select

- 3 Set the main parameter.



F4 ► Accepts the selected parameter and returns to the Basic Settings screen. ENTER

1 Select

4.2 Setting Basic Settings of Measurement Conditions

4 Select [SUB] under [PARA].

NORM

Z 10.0018kΩ

θ 0.076 °

Vac 988.7mV Iac 98.85mA

PARA :MAIN:Z

FREQ :1.0000kHz

LEVEL :V 1.000V

SUB:θ

SEL

F1

EXIT

1

Select

2

Displays the Sub Parameter Settings screen.

ENTER

5 Set the sub parameter.

NORM

Z 10.0018kΩ

θ 0.076 °

Vac 988.7mV Iac 98.85mA

Z Y θ Rs Rp Cs Cp

D G X Ls Lp Q B Rdc OFF

EXIT

F4

Select

Accepts the selected parameter and returns to the Basic Settings screen.

ENTER

List of parameters			
Z	Impedance (Ω)	G	Conductance (S)
Y	Admittance (S)	X	Reactance (Ω)
θ	Impedance phase angle (°)*	Ls	Inductance in series equivalent circuit mode (H)
Rs	Effective resistance in series equivalent circuit mode = ESR (Ω)	Lp	Inductance in parallel equivalent circuit mode (H)
Rp	Effective resistance in parallel equivalent circuit mode (Ω)	Q	Q factor
Cs	Static capacitance in series equivalent circuit mode (F)	B	Susceptance (S)
Cp	Static capacitance in parallel equivalent circuit (F)	Rdc	DC Resistance (Ω)
D	Loss coefficient = tanδ	OFF	Display no measurement parameter in the chosen position.

* The phase angle θ is shown based on the impedance Z.
When performing measurements using admittance Y as the reference, the sign of the impedance Z phase angle q will be reversed.

4.2.2 Setting the Measurement Frequency


Set the frequency of the signal to apply to the test sample.

For some test samples, the value may vary depending on the measurement frequency.


You can enter the frequency using either digit or tenkey input. **10KEY** **DIGIT**

Setting the frequency with tenkey input


- 1 Open the Basic Settings screen.



- 2 Select **[FREQ]**.




- 3 The Tenkey Input screen will be displayed.



4.2 Setting Basic Settings of Measurement Conditions


4

Enter the desired value with the tenkey and accept it with the **ENTER** key. **10KEY**
 Settable range: 40 Hz to 200 kHz



- The $\times 10^3$ $\div 10^3$ keys will be disabled until you enter a value.
 - If you set a frequency of 200 kHz or higher, the frequency will automatically revert to 200 kHz.
 - If a frequency of less than 40 Hz is set, the value will be automatically changed to 40 Hz.
- "Chapter 10 Specifications" (p.195)


5




4.2 Setting Basic Settings of Measurement Conditions

Set each digit (DIGIT)


- 1 Open the Basic Settings screen.




- 2 Select [FREQ].



- 3 Select [DIGIT].



- 4 Enter the desired value. **DIGIT**
Settable range: 40 Hz to 200 kHz




NOTE


The digits in the measurement frequency can also be changed using the ▲ ▼ keys.

4.2 Setting Basic Settings of Measurement Conditions

5 Change the unit and decimal point.



6



4.2.3 Setting the Measurement Signal Level

The value of the test signal level may change according to the sample which is being tested.

This instrument is possible to vary the level of the test signal applied to the object under test over a wide range using the following three methods.

Selecting constant voltage or constant current mode will result in increased measurement times due to use of software feedback control.

Open circuit voltage mode (V)

The value of the open circuit voltage is set.

Constant voltage mode (CV)

The value of the voltage between the terminals of the object under test is set.

Constant current mode (CC)

The value of the current flowing through the object under test is set.



CAUTION Do not switch between V, CV and CC while the test sample is still connected to the measurement terminals. Doing so may damage the test sample.

NOTE

- In constant voltage (CV) mode, the generated voltage is controlled using software feedback so that the set constant voltage value is applied. Since the voltage used for the most recent measurement is output as the generated voltage initial value, a voltage in excess of the set constant voltage value may be applied before feedback control is active if the sample's impedance is higher than that of the last measured sample.
- In constant current (CC) mode, the generated voltage is controlled using software feedback so that the set constant current value is applied. Since the voltage used for the most recent measurement is output as the generated voltage initial value, a current in excess of the set constant current value may be applied before feedback control is active if the sample's impedance is lower than that of the last measured sample.

1


Open the Basic Settings screen.



F1 ► Displays the Basic Settings screen.

2


Select [LEVEL].



Select

3

Select the measurement signal mode.



F1 ► Open circuit voltage mode (V)
F2 ► Constant voltage mode (CV)
F3 ► Constant current mode (CC)

4.2 Setting Basic Settings of Measurement Conditions

4 Select the [LEVEL] voltage or current value and change the value. **DIGIT**
The accuracy of testing varies according to the test signal level.
See "10.2 Measurement Range and Accuracy" (p.200)

2

F 1 ► Increases the value.
F 2 ► Decreases the value.

1 Select

Measurement signal level range

Measurement signal mode	Setting range
V, CV	0.005 V to 5.000 V
CC	0.01 mA to 50.00 mA

5

F 4 ► Returns to the Measurement screen.

NOTE

REF VAL

If the measurement value is outside the accuracy guarantee, **REF VAL** will be displayed at the top of the screen. Check the accuracy guarantee range in "10.2 Measurement Range and Accuracy" (p.200) and either change the measurement conditions or make the measurement value a reference value.

- If the measurement signal level is too low: Increase the measurement signal level.
- If the current measurement range (when using the HOLD setting) is not appropriate: Set the range to the optimal measurement range using AUTO ranging or change the measurement range manually.

About the test signal mode


Relationship between the measurement signal mode of the instrument and the sample is as follows.

Open circuit voltage mode (V)

This voltage value is the value which is applied across the two terminals of the series combination of the object which is being tested and the output impedance. As for the voltage which is applied across the terminals of the object which is being tested (by itself), if required, you should either check the monitor voltage value, or select constant voltage (CV) and set a voltage value across these terminals.

Constant current mode (CC)

You should select this if you wish to set the current passing through the object to be tested to a constant value.



Constant voltage mode (CV)


You should select this if you wish to set the voltage across the terminals of the object to be tested to a constant value.

For setting range and accuracy

Open circuit voltage mode (V) and Constant voltage mode (CV) setting

Open circuit voltage setting range	Open circuit voltage accuracy	Output impedance
0.005 V to 5.000 V	±10% rdg ±10 mV	100 Ω ±10 Ω

NOTE Depending on the sample, you may not be able to perform constant voltage measurement. In this situation, the following mark will be displayed:



Constant voltage measurement will not be performed.

Change the constant voltage level so that it is less than or equal to the displayed Vac monitor values.

Example: Range in which constant voltage operation is supported when measuring a 1 μF C at 10 kHz

The sample impedance Z_m is as follows:

$$Z_m = R_m + jX_m = 0[\Omega] - j15.9[\Omega] \quad X_m = \frac{-1}{(2\pi fC)}$$

The impedance Z_m' observed from the generator is as follows:

$$Z_m' = R_o + Z_m = 100[\Omega] - j15.9[\Omega] \quad R_o: \text{Output resistance (100 } [\Omega])$$

Accordingly, the voltage V_m across both leads of the sample is as follows:

$$V_m = \frac{|Z_m| \times V_o}{|Z_m'|} = \frac{15.9[\Omega] \times V_o}{101.3[\Omega]} \quad V_o: \text{generator output}$$

Because the generator output voltage range is 5 mV to 5 V for 10 kHz, the CV operation range per the above expression is $V_m = 0.8 \text{ mV to } 0.78 \text{ V}$.


4.2 Setting Basic Settings of Measurement Conditions

Constant current mode (CC) setting

However, the constant current operation range differs depending on the test sample to be measured.

Constant current setting range	Constant current accuracy	Output impedance
0.01 mA to 50.00 mA	$\pm 10\%$ rdg $\pm 10 \mu\text{A}$	$100 \Omega \pm 10 \Omega$

NOTE Depending on the sample, you may not be able to perform constant current measurement. In this situation, the following mark will be displayed:



Constant current measurement will not be performed.

Change the constant current level so that it is less than or equal to the displayed Iac monitor value.

Example:

Range in which constant current operation is supported when measuring a 1 mH L at 1 kHz

The sample impedance Z_m is as follows:

$$Z_m = R_m + jX_m = 0[\Omega] - j6.28[\Omega]$$

$$X_m = 2\pi fL$$

The impedance Z_m' observed from the generator is as follows:

$$Z_m' = R_o + Z_m = 100[\Omega] - j6.28[\Omega]$$

R_o : output resistance (100 [Ω])

Accordingly, the current I_m across both leads of the sample is as follows:

$$I_m = \frac{V_o}{|Z_m'|} = \frac{V_o}{100.2[\Omega]}$$

V_o : generator output

Since the generator output voltage range is 5 [mV] to 5 [V] based on the "Open circuit voltage mode (V) and Constant voltage mode (CV) setting" (p. 39) table, constant current operation is supported for I_m values of 49.9 [μA] to 49.9 [mA] as per the above equation.

4.2.4 Limiting the Voltage or Current Applied to the Sample (Limit Values)

Depending on the measurement signal level, in some cases it is possible to damage the sample which is being tested by applying to it a voltage or a current greater than its rated value.

To avoid such damage, you can set a limit value to limit the voltage applied to the sample or the current that flows to the sample.

Enabling the limit function will result in increased measurement times due to use of software feedback control.

When open circuit voltage mode (V) or constant voltage mode (CV) is set

Set the current limit.

When constant current mode(CC) is set


Set the voltage limit.

1 Open the Basic Settings screen.




2 Select [LIMIT].

- When the measurement signal mode is a voltage (V, CV)



- When the measurement signal mode is a current (CC)



- The measurement signal level can be checked using the monitor display.
- The monitor display is different for V, CV, and CC.

NOTE

First set the measurement signal mode, and thereafter set the voltage or current limit. The setting for voltage or current limit changes automatically to current or voltage limit, according to the present measurement signal mode setting.

See "4.2.3 Setting the Measurement Signal Level" (p.37)

4.2 Setting Basic Settings of Measurement Conditions

3 Set the limit function to either [ON] or [OFF].

NORM

2 10.0048kΩ -0.012 °

Vac 1.068 V Iac 106.8mA

FREQ : 1.0000kHz

LEVEL : V 1.000V

LIMIT : ON 050.00mA

EXIT

OFF

ON

F 1

F 2

Disables the limit function.

Enables the limit function.

4 Enter the current limit value or voltage limit value. **DIGIT**

NORM

2 10.0048kΩ -0.012 °

Vac 1.068 V Iac 106.8mA

FREQ : 1.0000kHz

LEVEL : V

LIMIT : ON 050.00mA

▲

▼

F 1

F 2

Increases the value.

Decreases the value.

◀

▶

Select

Selects the digit to change.

Limit range

Measurement signal mode	Set limit	Setting range
V, CV	Current limit	0.01 mA to 50.00 mA
CC	Voltage limit	0.005 V to 5 V

Current limit accuracy

Frequency	Accuracy
40 Hz to 200 kHz	±10 %rdg±10 μA

Voltage limit accuracy

Frequency	Accuracy
40 Hz to 200 kHz	±10% rdg±10 mV

When the limit function is on, the following marks may be displayed.

Example: When constant voltage mode (CV) setting

NORM

2 10.0028kΩ 0.079 °

Vac 1.005 V Iac 100.4mA

LEVEL : CV 1.000V

LIMIT : ON 000.00mA

RANGE : AUTO 100kΩ

EXIT

ERR

If the voltage or current which is applied to the sample under test exceeds the limit value (the current exceeding the limit value flows through the sample even when the open-circuit voltage is set to minimum value.)

Lower the measurement signal level so that the limit value is not exceeded.

NORM

2 10.0058kΩ 0.078 °

Vac 199.1mV Iac 19.90mA

LEVEL : CV 1.000V

LIMIT : ON 000.00mA

RANGE : AUTO 100kΩ

EXIT

LMT

If the test signal level which is being applied to the sample under test exceeds the limit value. Then the test signal level is stopped changing.

At this time, the voltage or current which exceeds the limit value is not being applied to the sample under test. You should change the test signal level so that it does not exceed the limit value.

5

NORM

2 10.0048kΩ -0.012 °

Vac 1.068 V Iac 106.8mA

FREQ : 1.0000kHz

LEVEL : V 1.000V

LIMIT : ON 050.00mA

EXIT

F 4

Returns to the Measurement screen.

4.2.5 Setting the Measurement Range

There are three methods for setting the measurement range: AUTO, HOLD, and JUDGE SYNC.

AUTO	▶	The most suitable test range is set automatically. (Automatically sets the optimal measurement range when measuring samples whose impedance varies greatly with the frequency, or unknown samples.)
HOLD	▶	Fixes the measurement range. The range is set manually. (Fixing the range allows high-speed measurement.)
JUDGE SYNC	▶	Automatically sets the optimal range for the comparator and BIN measurement judgment standards. (Automatically sets the optimal range relative to the comparator and BIN measurement judgment standards when the sample's impedance varies greatly with the frequency.)

NOTE

The ranges are all defined in terms of impedance. Therefore, for a parameter other than impedance, the value is obtained by calculating from the measured values of $|Z|$ and θ .
[See](#) "Appendix1 Measurement Parameters and Calculation formula"(p. A1)

Using the HOLD or AUTO settings when the JUDGE SYNC setting is on causes the JUDGE SYNC setting to be automatically disabled.


4.2 Setting Basic Settings of Measurement Conditions

Setting AUTO Ranging

- 1 Open the Basic Settings screen.



- 2 Select **[RANGE]**.




- 3 Set the measurement range to **[AUTO]**.



- The ranges that can be selected vary with the frequency. (p.46)
- Outside the accuracy guarantee range, AUTO ranging may not function properly, preventing a range from being selected. If this occurs, check the accuracy guarantee range in "10.2 Measurement Range and Accuracy" (p.200) and change the measurement conditions.

- 4



AUTO range limit function


The AUTO range limit function allows you to limit the AUTO ranging range. The AUTO range limit function can be set using communications commands only. It cannot be set from the instrument.

See Communications commands in the included LCR Application Disk documentation (**:RANGE:AUTO:LIMit**)


4.2 Setting Basic Settings of Measurement Conditions

Setting HOLD Ranging


- 1 Open the Basic Settings screen.




- 2 Select [RANGE].



- 3 Set the measurement range to [HOLD].




- 4 To select the measurement range.



4.2 Setting Basic Settings of Measurement Conditions

5 To select the measurement range.



The ranges that can be selected vary with the frequency.

Frequency	Ranges that can be selected	Range Settings screen
DC 40.000 Hz to 10.000 kHz	All range	
10.001 kHz to 100.00 kHz	100 mΩ to 10 MΩ	
100.01 kHz to 200.00 kHz	100 mΩ to 1 MΩ	


Set the test range according to the combined impedance value of the sample to be tested and the test cables.

Range	Accuracy guaranteed range	AUTO Ranging Range
100 MΩ	8 MΩ to 200 MΩ	8 MΩ to
10 MΩ	800 kΩ to 100 MΩ	800 kΩ to 10 MΩ
1 MΩ	80 kΩ to 10 MΩ	80 kΩ to 1 MΩ
100 kΩ	8 kΩ to 1 MΩ	8 kΩ to 100 kΩ
10 kΩ	800 Ω to 100 kΩ	800 Ω to 10 kΩ
1 kΩ	80 Ω to 10 kΩ	80 Ω to 1 kΩ
100 Ω	8 Ω to 100 Ω	8 Ω to 100 Ω
10 Ω	800 mΩ to 10 Ω	800 mΩ to 10 Ω
1 Ω	80 mΩ to 1 Ω	80 mΩ to 1 Ω
100 mΩ	10 mΩ to 100 mΩ	0 Ω to 100 mΩ

4.2 Setting Basic Settings of Measurement Conditions

NOTE

- The guaranteed accuracy range varies depending on the measurement conditions. (p.196)
- Changing the measurement range while the AUTO setting is enabled automatically enables the HOLD setting.
- The measurement range is determined according to the test range setting. If the display for the measured value shows **OVERFLOW** or **UNDERFLOW**, that means that measurement cannot be performed using the currently set test range. Either you should set AUTO ranging so as to select the most suitable test range automatically, or you should set a more suitable test range manually. If a measurement result is outside the display range (p.195), **DISP OUT** is displayed.
- The guaranteed accuracy range is for the measurement values before compensation.
- The AUTO ranging range is the range within which the AUTO range is switched. When the AUTO range limit function is enabled, the range will not be switched outside the defined limit range.
- In the case of a test sample whose impedance changes according to the frequency, when testing is being performed with HOLD set, it may happen, when the frequency is changed over, that measurement cannot be continued to be performed upon the same test range. You should change the test range if this happens.
- The test range setting is made according to the combination of the impedances of the sample being tested and the test cables. Therefore it can happen that testing is not possible, if the test range is held with HOLD only upon the basis of the impedance of the sample under test. If this happens, you should change the test range, making reference to "6.1 Setting Open Circuit Compensation" (p.125) and "6.2 Short Circuit Compensation" (p.136).



If the measurement value is outside the accuracy guarantee, **REF VAL** will be displayed at the top of the screen.

In this case, you should consider the following possible causes, and you should either change the test conditions while checking the accuracy assured ranges "10.2 Measurement Range and Accuracy" (p.200), or you should consider the measured values as values for reference.

- Perhaps the test signal level is too low, increase the test signal level.
- If the current measurement range (during HOLD setting) is not appropriate, set again in the AUTO range, or change the range by manual.


4.2 Setting Basic Settings of Measurement Conditions

JUDGE SYNC setting


When the judgment synchronization setting is enabled and you wish to set an optimal range based on the comparator or BIN measurement judgment standards, it is not necessary to set the range using the HOLD setting. When performing comparator or BIN measurement with a sample whose impedance varies greatly with the frequency, you can fix the measurement range to an optimal value relative to the judgment standard.

NOTE This setting is only available when the judgment standards have been set for comparator and BIN measurement. (p.75)
When judgment standards have been set for comparator and BIN measurement with this setting on, the range will be automatically switched to the optimal range. However, the AUTO range is used when no judgment standards have been set.


1 Open the Basic Settings screen.




2 Select [JUDGE SYNC].



3 Turn the JUDG SYNC setting [OFF] or [ON].



4



NOTE

- The ranges that can be selected vary with the frequency. (p.46)
- When only θ , D, or Q has been set, AUTO functionality is used.
- Because the phase angle cannot be calculated for some combinations of parameters, the range is determined from ideal values. For more information, see the table below.
See "Parameter combination conditions for the JUDGE SYNC setting" (p. 49)

4.2 Setting Basic Settings of Measurement Conditions

Parameter combination conditions for the JUDGE SYNC setting

	Sub parameter															
	AC	OFF	Z	Y	Rs	Rp	X	G	B	Ls	Lp	Cs	Cp	θ	D	Q
Main parameter	OFF	×	●	●	△	△	△	△	△	△	△	△	△	×	×	×
	Z	●	●	●	△	△	△	△	△	△	△	△	△	●	●	●
	Y	●	●	●	△	△	△	△	△	△	△	△	△	●	●	●
	Rs	△	△	△	△	△	△	△	△	△	△	△	△	●	●	●
	Rp	△	△	△	△	△	△	△	△	△	△	△	△	●	●	●
	X	△	△	△	△	△	△	△	△	△	△	△	△	●	●	●
	G	△	△	△	△	△	△	△	△	△	△	△	△	●	●	●
	B	△	△	△	△	△	△	△	△	△	△	△	△	●	●	●
	Ls	△	△	△	△	△	△	△	△	△	△	△	△	●	●	●
	Lp	△	△	△	△	△	△	△	△	△	△	△	△	●	●	●
	Cs	△	△	△	△	△	△	△	△	△	△	△	△	●	●	●
	Cp	△	△	△	△	△	△	△	△	△	△	△	△	●	●	●
	θ	×	●	●	●	●	●	●	●	●	●	●	●	×	×	×
	D	×	●	●	●	●	●	●	●	●	●	●	●	×	×	×
	Q	×	●	●	●	●	●	●	●	●	●	●	●	×	×	×

×	Invalid setting (treated as AUTO range)
△	Invalid setting (treated as AUTO range) Set from ideal value since phase angle cannot be calculated.
●	Valid setting

4.2 Setting Basic Settings of Measurement Conditions

4.2.6 Measuring at User-specified Timing (Trigger Measurement)

Triggering is the process of controlling the start and stop of recording by specific signals or conditions (criteria). When recording is started or stopped by a specific signal, we say the trigger is “applied” or “triggering occurs”.

With this instrument, you can select the following two types of trigger.

Internal Trigger

Automatically generates a trigger signal internally to repeat measurement.


External trigger

Measurements are triggered by an external signal. The trigger is input manually or using external I/O or another interface.

1 Open the Basic Settings screen.



2 Select [TRIG].



3 Set the trigger setting to [INT] or [EXT].




When [EXT] is selected

There are the following three types of input method for a trigger.

- Press **TRIG** key on the screen to manually input a trigger: Measurement is performed once.
- Input via EXT I/O: Measurement is performed once each time a negative logic pulse signal is applied.
See "Connector Type and Signal pin assignments" (p. 178)
- Input from interface: Measurement is performed once when ***TRG** is transmitted.
See Communications commands in the included LCR Application Disk documentation


4



4.2.7 Setting Measurement Conditions for Individual Ranges

The measurement speed, averaging settings, trigger delay, and trigger synchronous output function can be configured for individual ranges. The same settings can also be used for all ranges. (p.60)


List screen layout




4.2 Setting Basic Settings of Measurement Conditions

Selecting range settings to change


1 Open the Basic Settings screen.



2 Select [LIST].



3 Select the range setting you wish to change.



Setting	Description	Window
SPEED	Sets the measurement speed. (p.53)	100kΩ:SPEED FAST MED SLOW SLOW2
AVG	Sets the average. (p.54)	100kΩ:AVG 001
DELAY	Sets the trigger delay. (p.56)	100kΩ:DELAY 0.0000s
SYNC	Sets the trigger synchronous output function. (p.57)	100kΩ:SYNC OFF 0.0010s


Ranges that can be selected:
100 mΩ/1 Ω/10 Ω/100 Ω/1 kΩ/10 kΩ/100 kΩ/1 MΩ/10 MΩ/100 MΩ

4.2 Setting Basic Settings of Measurement Conditions


Setting the Measurement speed

The testing speed can be set. The slower the testing speed is, the more accurate are the results.

- 1 Select the range speed you wish to change on the List screen.
See "Selecting range settings to change" (p. 52)




- 2 Set the SPEED.
The measurement speed varies with the measurement conditions.
See "10.3 About Measurement Times and Measurement Speed" (p.207)



To select the measurement speed.	
FAST	Performs high-speed measurement.
MED	This is the normal measurement speed.
SLOW	Measurement precision improves.
SLOW2	Measurement accuracy is better than SLOW.

3



NOTE

- You can set the measurement speed at a greater level of detail with the waveform averaging function.
 - The speed cannot be set while the waveform averaging function is enabled.
Disable the waveform averaging function before setting the speed.
- See "4.5.2 Setting the Detection Signal Waveform Averaging Count (Waveform Averaging Function)" (p.99)

4

4.2 Setting Basic Settings of Measurement Conditions

Displaying Average Values (Average set)

With the averaging function, the measured values can be averaged. Using this function, it is possible to reduce fluctuations in the measured value display.


With internal trigger

A rolling average of the tested values over the set number of times for averaging is always calculated backwards from the present. When the sample to be tested is changed over, it takes a little time for a certain stabilization time period until the results are reliable.

With external trigger

An average of the test values is calculated over the set number of times for averaging forwards from when the trigger is input.

When the number of averaging times is 4, the number of measurements, measurement output points, and measurement value calculation method during output are as follows.




4.2 Setting Basic Settings of Measurement Conditions

- 1** On the List screen, select the range averaging count you wish to change.
See "Selecting range settings to change" (p. 52)




- 2** Set the averaging count. **(DIGIT)**
Settable range: 1 to 256 times



NOTE You can also change the value with the ▲ ▼ keys.

3



4.2 Setting Basic Settings of Measurement Conditions

Setting a delay before measurement data is acquired (trigger delay)

The delay time period from input of the trigger signal to measurement can be set. With this function it is possible to ensure that testing is started after the connection condition of the object being tested and the test cables has stabilized.

See "Trigger delays and the trigger synchronous output function" (p. 59)

- 1 On the List screen, select the range trigger delay you wish to change.
See "Selecting range settings to change" (p. 52)

BASIC >> LIST ALL RANGE:OFF

RANGE	SPEED	AVG	DELAY	SYNC
10kΩ	MED	OFF	0.0000s	OFF
100kΩ	MED	OFF	0.0000s	OFF
1MΩ	MED	OFF	0.0000s	OFF
10MΩ	MED	OFF	0.0000s	OFF

EDIT

EXIT

F 1

ENTER

Select

Opens the Trigger Delay Setting window.

- 2 Set the delay time. **DIGIT**
Settable range: 0 to 9.9999 s at 0.1 ms resolution

BASIC >> LIST ALL RANGE:OFF

RANGE: 100kΩ:DELAY

10k

100k

1M

10M

0.0000s

1

2

F 1

F 2

F 3

Select

Increases the value.
Decreases the value.
Reverts to the default value.
Selects the digit to change.

NOTE You can also change the value with the **▲ ▼** keys.

- 3
- BASIC >> LIST ALL RANGE:OFF

RANGE: 100kΩ:DELAY

10k

100k

1M

10M

0.0000s

SET

F 4

ENTER

Accepts the setting and returns to the List screen.
- Press the **ESC** key to cancel the configuration process and return to the List screen.

4.2 Setting Basic Settings of Measurement Conditions

Applying the signal to the sample during measurement only (Trigger Synchronous Output Function)


This functionality outputs the measurement signal after trigger input is received so that the signal is only applied to the sample during measurement. You can also set a delay time to ensure that data is acquired after the sample stabilizes.

Thus reducing the generation of heat in the sample and decreasing electrode wear.


See "Trigger delays and the trigger synchronous output function" (p. 59)

- On the List screen, select the range trigger synchronous output function you wish to change.

See "Selecting range settings to change" (p. 52)




- Enable or disable the trigger synchronous output function.



- Select and enter the wait time that will be allowed to elapse before measurement starts.

DIGIT


Settable range: 0.0010 to 9.9999 s



NOTE

You can also change the value with the **▲ ▼** keys.

4



4.2 Setting Basic Settings of Measurement Conditions

NOTE


- When the trigger synchronous output function is set to ON, there is a measurement time delay because the instrument enters a wait time which spans from when the measurement signal is output to when data is acquired.
 - [See](#) "10.3 About Measurement Times and Measurement Speed" (p.207)
 - Changing the settings while the trigger synchronous output function is on may cause the set level to be momentarily output.
 - The measurement signal is output when the trigger signal is input and stops after measurement ends.
 - Setting the contact check timing to [\[BOTH\]](#) or [\[BEFORE\]](#) with the contact check function will automatically turn the trigger synchronous output function on. Set the amount of time to wait before starting measurement.
 - In continuous measurement mode, the measurement signal stops after measurement of the last panel ends.
-

Trigger delays and the trigger synchronous output function


Trigger delays provide functionality for setting a delay from the time that the trigger signal is input until measurement, while the trigger synchronous output function outputs the measurement signal during measurement only and additionally allows you to set a delay before data is acquired.

The measurement process is as follows:

Trigger delay: ON; Trigger synchronous output: OFF



Trigger delay: ON; Trigger synchronous output: ON



NOTE When the range synchronization function has been set, the range settings at which the trigger delay and trigger synchronous output function are enabled vary with the parameter settings.

Effective range settings differ according to the parameter settings for trigger delay and trigger synchronous output functions only.

Parameter	Range setting at which function is enabled
AC measurement only	AC measurement range
AC+DC measurement	AC measurement range
DC measurement only	DC measurement range

4.2 Setting Basic Settings of Measurement Conditions

Applying settings to all ranges

To apply settings to all measurement ranges, configure function settings in their respective setting windows after turning on the ALL RANGE setting.

NOTE To configure settings for individual measurement ranges, turn off the ALL RANGE setting.

Select ALL RANGE and then select [ON] or [OFF].

BASIC >> LIST

ALL RANGE:OFF

RANGE: SPEED

Avg

VELT

TIME

100mΩ: FAST

OFF

0.0000s

OFF

1Ω: MED

2

0.0010s

0.0010s

10Ω: SLOW

10

0.0100s

0.0100s

100Ω: SLOW2

100

0.1000s

0.1000s

EXIT

1

Select

2

OFF

ON

F 1

F 2

Does not apply settings to all ranges.

Applies settings to all ranges.

4.3 Setting DC Resistance Measurement

DC resistance measurement allows you to output a 2.0 V (fixed) DC signal to measure the DC resistance Rdc. The measurement process is as follows:

1. Measure the direct current resistance during 0 V application.
2. Measure the direct current resistance during 0 V application, and set it as the offset value.
3. Using the offset value, reduce measurement error.
4. Output the Rdc measurement value.

NOTE

- It is necessary to set the line frequency for the power source being used by the instrument in order to reject noise. Set the frequency of the commercial power supply you are using before performing measurements. Failure to set the line frequency correctly will result in unstable measurement values.

See "4.3.4 Setting the Line Frequency" (p.70)

- To measure DC resistance, you need to set [Rdc] in the measurement parameters beforehand.

See "4.2.1 Setting Display Parameters" (p.31)

- When [Rdc] and other parameters are set, the DC resistance is measured after those other parameters have been measured with the AC signal. The measurement conditions can be set individually.

- When the sample is a capacitor, it may not be possible to perform DC resistance measurement accurately.


- The time required until the DC signal level stabilizes differs depending on the test sample to be measured. To ensure measurement is performed accurately, observe the measurement waveform in advance and then set the delay time required until the DC signal level stabilizes.

See "4.3.2 Setting a Delay Time for DC Measurement (DC Delay)" (p.67)


"4.3.3 Setting a Delay Time for Offset Measurement (Adjustment Delay)" (p.69)

Adding Rdc to Measurement Parameters


- 1 Open the Basic Settings screen.



- 2 Select the parameter you wish to change.



- 3 Set the parameter to [Rdc].



4.3 Setting DC Resistance Measurement

4

COMP

Z

10.0048kΩ

Rdc

10.0033kΩ

Vac

1.068 V

Iac

106.8mA

SUB

Z

Y

θ

Rs

Rp

Cs

Cp

D

G

X

Ls

Lp

Q

B

Rdc

OFF

EXIT

F 4

►

Accepts the selected parameter and returns to the Basic Settings screen.

ENTER

4.3.1 Setting the Measurement Range

There are three methods for setting the measurement range: AUTO, HOLD, and JUDGE SYNC.

AUTO

►

The most suitable test range is set automatically.

(Automatically sets the optimal measurement range when measuring samples whose impedance varies greatly with the frequency, or unknown samples.)

HOLD

►

Fixes the measurement range. The range is set manually.

(Fixing the range allows high-speed measurement.)

JUDGE SYNC


►

Automatically sets the optimal range for the comparator and BIN measurement judgment standards. (Automatically sets the optimal range relative to the comparator and BIN measurement judgment standards when the sample's impedance varies greatly with the frequency.)


NOTE Using the HOLD or AUTO settings when the JUDGE SYNC setting is on causes the JUDGE SYNC setting to be automatically disabled.

Setting AUTO Ranging

- 1 Open the Rdc Settings screen.



- 2 Select [RANGE].




- 3 Set the measurement range to [AUTO].



Outside the accuracy guarantee range, AUTO ranging may not function properly, preventing a range from being selected. If this occurs, check the accuracy guarantee range in "10.2 Measurement Range and Accuracy" (p.200) and change the measurement conditions.

- 4



AUTO range limit function


The AUTO range limit function allows you to limit the AUTO ranging range. The AUTO range limit function can be set using communications commands only. It cannot be set from the instrument.

See Communications commands in the included LCR Application Disk documentation
(:DCResistance:RANGE:AUTO:LIMIt)


4.3 Setting DC Resistance Measurement

Setting HOLD Ranging


1 Open the Rdc Settings screen.




2 Select [RANGE].



3 Set the measurement range to [HOLD].



4 To select the measurement range.




4.3 Setting DC Resistance Measurement

5

Set the measurement range.

Set the measurement range according to the total impedance of the sample and measurement cable.




Range	Accuracy guaranteed range	AUTO Ranging Range
100 MΩ	8 MΩ to 200 MΩ	8 MΩ to
10 MΩ	800 kΩ to 100 MΩ	800 kΩ to 10 MΩ
1 MΩ	80 kΩ to 10 MΩ	80 kΩ to 1 MΩ
100 kΩ	8 kΩ to 1 MΩ	8 kΩ to 100 kΩ
10 kΩ	800 Ω to 100 kΩ	800 Ω to 10 kΩ
1 kΩ	80 Ω to 10 kΩ	80 Ω to 1 kΩ
100 Ω	8 Ω to 100 Ω	8 Ω to 100 Ω
10 Ω	800 mΩ to 10 Ω	800 mΩ to 10 Ω
1 Ω	80 mΩ to 1 Ω	80 mΩ to 1 Ω
100 mΩ	10 mΩ to 100 mΩ	0 Ω to 100 mΩ

NOTE

- The guaranteed accuracy range varies depending on the measurement conditions. See Check the guaranteed accuracy range as described in "10.2 Measurement Range and Accuracy" (p.200).
- Changing the measurement range while the AUTO setting is enabled automatically enables the HOLD setting.
- The measurement range is determined according to the test range setting. If the display for the measured value shows **OVERFLOW** or **UNDERFLOW**, that means that measurement cannot be performed using the currently set test range. Either you should set AUTO ranging so as to select the most suitable test range automatically, or you should set a more suitable test range manually. If a measurement result is outside the display range (p.195), **DISP OUT** is displayed.
- The accuracy guarantee range is defined in terms of uncorrected measurement values.

6




F 4 ► Changes the selected range and returns to the Basic Settings screen.

ENTER

NOTE

- The test range setting is made according to the combination of the impedances of the sample being tested and the test cables. Therefore it can happen that testing is not possible, if the test range is held with HOLD only upon the basis of the impedance of the sample under test. If this happens, you should change the test range, making reference to "6.1 Setting Open Circuit Compensation" (p.125) and "6.2 Short Circuit Compensation" (p.136).
- If the measurement value is outside the accuracy guarantee, the following comment will be displayed at the top of the screen.



In this case, you should consider the following possible causes, and you should either change the test conditions while checking the accuracy assured ranges "10.2 Measurement Range and Accuracy" (p.200), or you should consider the measured values as values for reference.

- Perhaps the test signal level is too low, increase the test signal level.
- If the current measurement range (during HOLD setting) is not appropriate, set again in the AUTO range, or change the range by manual.

4.3 Setting DC Resistance Measurement

JUDGE SYNC setting


When the judgment synchronization setting is enabled and you wish to set an optimal range based on the comparator or BIN measurement judgment standards, it is not necessary to set the range using the HOLD setting.

NOTE This setting is only available when the judgment standards have been set for comparator and BIN measurement.(p.75)
When judgment standards have been set for comparator and BIN measurement with this setting on, the range will be automatically switched to the optimal range. However, the AUTO range is used when no judgment standards have been set.


1 Open the Rdc Settings screen.




2 Select [JUDGE SYNC].



3 Turn the JUDG SYNC setting [OFF] or [ON].



4



Parameter combination conditions for the JUDGE SYNC setting.


		Sub parameter	
Main parameter		OFF	Rdc
	OFF	x	●
	Rdc	●	●

x	Invalid setting (treated as AUTO range)
●	Valid setting


4.3.2 Setting a Delay Time for DC Measurement (DC Delay)

This section describes how to set a delay before DC resistance measurement is started, for example when switching to DC resistance measurement after measurement using an AC signal. The delay time delays measurement until the DC level stabilizes.

When number of averaging times is 1



When the number of averaging times is 2 or more
(The number of times is 2 in this example)




4.3 Setting DC Resistance Measurement


- 1 Open the Rdc Settings screen.



- 2 Select **[DC DELAY]** and change the value. **[DIGIT]**
Settable range: 0 to 9.9999 s



- 3




NOTE The time required until the DC signal level stabilizes differs depending on the test sample to be measured. To ensure measurement is performed accurately, observe the measurement waveform in advance and then set the delay time required until the DC signal level stabilizes.


4.3.3 Setting a Delay Time for Offset Measurement (Adjustment Delay)

The delay time delays measurement until offset measurement (DC 0V) stabilizes.


When number of averaging times is 1



When the number of averaging times is 2 or more
(The number of times is 2 in this example)




1 Open the Rdc Settings screen.




2 Select [ADJ DELAY] and change the value. **DIGIT**

Settable range: 0.0030 s to 9.9999 s



3




4.3 Setting DC Resistance Measurement


4.3.4 Setting the Line Frequency

When performing DC resistance measurement, be sure to set the line frequency of the power supply being used.


- 1 Open the Rdc Settings screen.



- 2 Select [LINE FREQ] and select the desired line frequency.



- 3




NOTE It is necessary to set the line frequency for the power source being used by the instrument in order to reject noise. Set the frequency of the commercial power supply you are using before performing measurements. Failure to set the line frequency correctly will result in unstable measurement values.

4.3.5 Setting Measurement Conditions for Individual Ranges

The measurement speed and averaging settings can be configured for individual ranges. The same settings can also be applied to all ranges.


List screen layout




4.3 Setting DC Resistance Measurement

Selecting the range setting you wish to change


1 Open the Rdc Settings screen.



2 Select [LIST].



3 Select the range setting you wish to change.




Setting	Description	Window
SPEED	Sets the measurement speed. (p.73)	
AVG	Configures averaging. (p.74)	

Ranges that can be selected:
100 mΩ/1 Ω/10 Ω/100 Ω/1 kΩ/10 kΩ/100 kΩ/1 MΩ/10 MΩ/100 MΩ


Setting the measurement speed

The testing speed can be set. The slower the testing speed is, the more accurate are the results.

- 1 Select the range speed you wish to change on the Rdc screen.
See "Selecting the range setting you wish to change" (p. 72)




- 2 Set the [SPEED].
The measurement speed varies with the measurement conditions.
See "10.3 About Measurement Times and Measurement Speed" (p.207)



To select the measurement speed.

FAST	Performs high-speed measurement.
MED	This is the normal measurement speed.
SLOW	Measurement precision improves.
SLOW2	Measurement accuracy is better than SLOW.

3



NOTE

- You can set the measurement speed at a greater level of detail with the waveform averaging function.
 - The speed cannot be set while the waveform averaging function is enabled.
Disable the waveform averaging function before setting the speed.
- See "4.5.2 Setting the Detection Signal Waveform Averaging Count (Waveform Averaging Function)" (p.99)

4.3 Setting DC Resistance Measurement

Displaying Average Values (Averaging Set)

With the averaging function, the measured values can be averaged. Using this function, it is possible to reduce fluctuations in the measured value display.


After setting the signal level and range, measurement is performed the number of times set with the averaging count, and the measurement value is displayed.

NOTE The averaging process during Rdc measurement performs arithmetic mean processing regardless of the trigger setting. (p.54)

- 1 Select the range averaging count you wish to change on the Rdc screen.
See "Selecting the range setting you wish to change" (p. 72)



- 2 Set the averaging count. **DIGIT**
Settable range: 1 to 256



NOTE You can also change the value with the ▲ ▼ keys.


- 3 Press the **ESC** key to cancel the configuration process and return to the List screen.
Accepts the setting and returns to the List screen. **ENTER**

Applying settings to all ranges

To apply settings to all measurement ranges, configure function settings in their respective setting windows after turning on the ALL RANGE setting.

NOTE To configure settings for individual measurement ranges, turn off the ALL RANGE setting.

Select ALL RANGE and then select ON or OFF.



4.4 Judging Measurement Results

This function, which compares measurement results with a user-specified standard and displays a judgment result, is useful in applications such as quality evaluation. You can select from comparator measurement, in which measurement values are compared to a single judgment standard, and BIN measurement, in which measurement values are compared to multiple reference standards (up to 10).


Setting the judgment mode

- 1 Open the Advanced Settings screen.



F 3 ► Displays the Advanced Settings screen.


- 2 Select **[JUDGE]** and set the judgment mode.



F 1 ► Disables the judgment mode.
F 2 ► Enables comparator measurement.
F 3 ► Enables BIN measurement.

1 Select

3



F 4 ► Returns to the Measurement screen.

4.4.1 Making Judgments Based on Upper and Lower Limit Values (Comparator Measurement Mode)

The comparator measurement allows you to do the following.


- Check judgment results based on the illumination of the judgment results indicator LEDs on the front of the instrument by setting judgment standards (reference values and upper/lower limit values) in advance.
HI (higher than upper limit value), IN (within range defined by upper and lower limit values), LO (less than lower limit value)

See "COMP indicator LEDs" (p. 10)

- Output the judgment results to an external device (via the EXT I/O connector).
- Select different settings and perform judgment for up to two parameters.
- Be notified of judgment results by buzzer.

See "4.5.12 Disabling Key Operation (Key-lock Function)" (p.114)


(Front panel LEDs)



When the comparator measurement results for the main and sub parameters are IN, the IN indicator turns green. When they are HI or LO, the HI or LO indicator turns red.


The comparator decision mode can be set as one of the following:

Absolute value (ABS) setting(p.78)




Set absolute values for the upper limit and lower limit values of the measurement parameters.
The measurement values displayed are the same as those of the measurement parameters.

Percent (%) Setting(p.79)



Enter reference values and then set percentages corresponding to the reference values as the upper limit and lower limit values*¹.
The measurement values displayed are the same as those of the measurement parameters.

Deviation Percent (Δ%) Setting*²(p.81)



Enter reference values and then set percentages corresponding to the reference values as the upper limit and lower limit values*¹.
The measurement values are displayed in deviations (Δ%) from the reference value.

*1: The following equation is used to calculate the comparison upper limit value and comparison lower limit value. (In the case of the comparison lower limit value, if a value that is lower than the reference value is set, the minus (-) sign is required for the percentage setting value.)

$$\text{Upper limit comparison value (Lower limit comparison value)} = \text{reference value} + [\text{reference value}] \times \frac{\text{Percentage set value}}{100}$$

*2: The following equation is used to calculate the Δ% value.

$$\Delta\% = \frac{\text{measurement value} - \text{reference value}}{[\text{reference value}]} \times 100$$

4.4 Judging Measurement Results


NOTE

- The comparator judgment is made in the following order.
 - If the measurement value is "OVER FLOW", **HI** is displayed.
(However, LO is displayed when the parameters are Y, Cs, Cp, G, and B.)
If the measurement value is "UNDER FLOW", **LO** is displayed.
(However, HI is displayed when the parameters are Y, Cs, Cp, G, and B.)
If the measurement value is "SAMPLE ERR" or "CONTACT ERROR," **HI** is displayed.
 - Whether the measurement value is higher than the lower limit value is judged, and **LO** is displayed if the judgment is NG.
 - Whether the measurement value is lower than the upper limit value is judged, and **HI** is displayed if the judgment is NG.
 - If other than 1, 2, or 3, **IN** is displayed.


No test is performed to ensure that the upper limit value is greater than the lower limit value, so no error message will be displayed if you set the upper limit value and lower limit value the wrong way around.

- If the power is turned off while the comparator measurement screen is displayed, the comparator measurement screen will be displayed when the instrument starts the next time you turn the power on.
- Comparator measurement can be performed after setting either the upper or lower limit.

When setting only the upper limit value



When setting only the lower limit value




4.4 Judging Measurement Results

1 Setting the Upper or Lower Limit Value as an Absolute Value (ABS) (Absolute Value mode)


NOTE Set the judgment mode to [COMP].
See "Setting the judgment mode" (p. 75)

1 Press **COMP / BIN** key.


2 Select the parameter you wish to set to absolute value mode.



3 Select the main or sub parameter value you wish to set.




4 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
Settable range: -9.99999 G to 9.99999 G



Unit:
(a/f/p/n/μ/m/none/k/M/G)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.

5



When you want to cancel
the configuration process(p.82):
Press **ESC** to cancel.


If you make a mistake:
Press **BACK SPACE** key and reenter the value.

4.4 Judging Measurement Results

5 Set the main and sub parameter upper and lower limit values.



6 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
Settable range: -9.99999 G to 9.99999 G



Upper limit value

- The upper limit value is set as a percentage of the reference value.
- In terms of the instrument's actual internal operation, the upper limit comparison value is calculated using the following equation and compared with the measurement value to make a judgment.

$$\text{Upper limit comparison value} = \text{reference value} + |\text{reference value}| \times \frac{\text{Percentage set value}}{100}$$

Lower limit value

- The lower limit value is set as a percentage of the reference value.
- In terms of the instrument's actual internal operation, the lower limit comparison value is calculated using the following equation. To set a value that is less than the measurement value, it is necessary to enter a negative percentage.

$$\text{Lower limit comparison value} = \text{reference value} + |\text{reference value}| \times \frac{\text{Percentage set value}}{100}$$

7

3

Setting Upper and Lower Limit Values as ($\Delta\%$) Values Relative to the Offset from the Reference Value (Deviation Percentage Mode)

The upper and lower limit values can be set as a percentage based on the reference value, and the amount of deviation from the reference value can be displayed as the measurement value in the form of a percentage.

NOTE Set the judgment mode to [COMP].

See "Setting the judgment mode" (p. 75)

- In deviation percentage mode, the amount of deviation ($\Delta\%$) from the reference value is displayed as the measurement value.
- The reference value and upper and lower limit values are used in both percentage mode and deviation percentage mode.

See "Setting the Upper or Lower Limit Value as a Percentage (%) Relative to a Reference Value (Percentage mode)" (p.79)

- The $\Delta\%$ value is calculated using the following equation:


$$\Delta\% = \frac{\text{measurement value} - \text{reference value}}{|\text{reference value}|} \times 100$$

1

Press **COMP / BIN** key.


2

Select the parameter you wish to set to deviation percentage mode.




3

Select the main and sub parameter reference values.



4.4 Judging Measurement Results


- 4** Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
 Settable range: -9.99999 G to 9.99999 G




Unit:
 (a/f/p/n/μ/m/none/k/M/G)

If you make a mistake:
 Press **BACK SPACE** key and reenter the value.

- 5** Set the main and sub parameter upper and lower limit values.




- 6** Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
 Settable range: -9.99999 G to 9.99999 G



Unit:
 (a/f/p/n/μ/m/none/k/M/G)

If you make a mistake:
 Press **BACK SPACE** key and reenter the value.


7



When you want to cancel
 the configuration process(p.82):
 Press **ESC** to cancel.


When you want to cancel the comparator measurement setting:

When you want to cancel the comparator measurement setting, you can press **ESC** .



4.4.2 Classifying Measurement Results (BIN Measurement Function)

Up to 10 pairs of upper and lower limit values can be set for the main parameter, and judgment results are displayed based on these values. Only one pair of upper and lower limit values can be set for the sub parameter. Judgment results are output externally.
After selecting the BIN measurement judgment mode, set the judgment conditions. (p.75)



BINS	BIN judgment.
---	- When the main parameter is off. - When BIN judgment has not been selected.
OUT	When the main parameter value did not match any BIN.
SUBNG	When the main parameter value matched a BIN, but the sub parameter value did not.


- Be notified of judgment results by buzzer.
See "4.5.10 Setting Operation Sounds (Beep Sounds)" (p.110)
- Judgment results can be checked using the judgment results indicator LED on the front of the instrument.
See "COMP indicator LEDs" (p. 10)

BINS Results = BIN judgment	OUT	SUBNG Measurement value > upper limit for sub parameter	SUBNG Measurement value < lower limit for sub parameter


4.4 Judging Measurement Results

About BIN function


Perform judgment in the order of BIN1 to BIN10. The BIN number for when a measurement value is first judged to be within the set judgment reference is displayed.



BIN judgment, main measurement value



BIN judgment, sub measurement value




In BIN judgment, a judgment is made based on the main measurement value first, and then the result of a judgment using the sub measurement value is output. In the above example, **OUT** is displayed since main measurement value 1 did not fulfill any of the set judgment standards. Main measurement value 2 was the first to fulfill the standard, and **SUBNG** is displayed since the judgment standard set for BIN5 was fulfilled.

Next, BIN judgment is applied to the sub measurement values. Sub measurement value 2_{SUBNG} did not fulfill the judgment standards, so **BIN5** is displayed. Sub measurement value 2_{IN} fulfilled the judgment standards, so BIN5 is output.

NOTE By setting a series of increasingly lenient judgment standards as shown in the above diagram, you can rank (sort) measurement elements.

The following three judgment methods are available:


Absolute value (ABS) setting(p.86)



Set absolute values for the upper limit and lower limit values of the measurement parameters.

The measurement values displayed are the same as those of the measurement parameters.


Percent (%) Setting(p.88)



Enter reference values and then set percentages corresponding to the reference values as the upper limit and lower limit values^{*1}.

The measurement values displayed are the same as those of the measurement parameters.

Deviation Percent ($\Delta\%$)^{*2} Setting(p.92)



Enter reference values and then set percentages corresponding to the reference values as the upper limit and lower limit values^{*1}.

The measurement values are displayed in deviations ($\Delta\%$) from the reference value.

*1: The following equation is used to calculate the comparison upper limit value and comparison lower limit value.
(In the case of the comparison lower limit value, if a value that is lower than the reference value is set, the minus (-) sign is required for the percentage setting value.)

$$\text{Upper limit comparison value(Lower limit comparison value)} = \text{reference value} + |\text{reference value}| \times \frac{\text{Percentage set value}}{100}$$

*2: The following equation is used to calculate the $\Delta\%$ value.

$$\Delta\% = \frac{\text{measurement value} - \text{reference value}}{|\text{reference value}|} \times 100$$

NOTE

- HI/IN/LO judgment procedure(p.76)
- If the power is turned off in BIN measurement mode, the mode will be BIN measurement mode when the instrument starts the next time you turn the power on.
- For a BIN number that does not require a BIN judgment, set the upper and lower limit values to OFF.
- The measurement conditions that are used when normal measurement is performed are inherited as is for the measurement conditions when BIN is performed.
- BIN measurement can be performed after setting either the upper or lower limit value.

When setting only the upper limit value



When setting only the lower limit value



4.4 Judging Measurement Results

1 Setting the Upper or Lower Limit Value as an Absolute Value (ABS) (Absolute Value mode)

NOTE Set the judgment mode to [BIN].
See "Setting the judgment mode" (p. 75)

Main parameter settings

1 Press **COMP /BIN** key.

2 Select the [MAIN] parameter.

2 **F 1** ▶ Selects the main parameter.

1 Select

3 Select [ABS].

F 1 ▶ Selects absolute value mode.

Select

4 Select the BIN number and select the upper and lower limit values.

F 1 ▶ Does not set an upper or lower limit value.

Select

5 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
Settable range: -9.99999 G to 9.99999 G


Accepts the entered value

Unit:
(a/f/p/n/μ/m/none/k/M/G)


If you make a mistake:
Press **BACK SPACE** key and reenter the value.

Sub parameter settings


1 Select the sub parameter.




2 Select **[ABS]**.



3 Select the sub parameter upper and lower limit values.




4 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
Settable range: -9.99999 G to 9.99999 G



Unit:
(a/f/p/n/μ/m/none/k/M/G)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.

5



When you want to cancel
the configuration process(p.96):
Press **ESC** to cancel.

4.4 Judging Measurement Results

2 Setting the Upper or Lower Limit Value as a Percentage (%) Relative to a Reference Value (Percentage mode)

You can also set upper and lower limit values as a percentage of a reference value.

- NOTE**
- Set the judgment mode to **[BIN]**.
See "Setting the judgment mode" (p. 75)
 - The reference value and upper and lower limit values are used by both percentage mode and deviation percentage mode.

Main parameter settings

1 Press **COMP / BIN** key.

2 Select **[MAIN]**.

The screenshot shows the 'BIN MAIN' menu. At the top, 'Z:ABS' is displayed. Below it, a table lists parameters for BIN 1 through BIN 4, with columns for 'HI' and 'LO'. The 'MAIN' option is highlighted in the top right corner. A blue box highlights the 'MAIN' option, and a blue arrow points from it to the 'F1' key. A blue box also highlights the 'F1' key. A blue arrow points from the 'F1' key to the text 'Selects the main parameter.'

No.	HI	LO
BIN 1:	OFF	OFF
BIN 2:	OFF	OFF
BIN 3:	OFF	OFF
BIN 4:	OFF	OFF

1 Select

3 Select **[%]**.

The screenshot shows the 'BIN MAIN' menu. At the top, 'Z:%' is displayed. Below it, a table lists parameters for BIN 1 through BIN 4, with columns for 'HI' and 'LO'. The '%' option is highlighted in the top right corner. A blue box highlights the '%' option, and a blue arrow points from it to the 'F2' key. A blue box also highlights the 'F2' key. A blue arrow points from the 'F2' key to the text 'Selects percentage mode.'

No.	HI	LO
BIN 1:	OFF	OFF
BIN 2:	OFF	OFF
BIN 3:	OFF	OFF
BIN 4:	OFF	OFF

Select


4 Select the main parameter reference value.

The screenshot shows the 'BIN MAIN' menu. At the top, 'REF: 10.0000k' is displayed. Below it, a table lists parameters for BIN 1 through BIN 4, with columns for 'HI' and 'LO'. The 'NUM' option is highlighted in the top right corner. A blue box highlights the 'REF: 10.0000k' text, and a blue arrow points from it to the 'Select' key. A blue box also highlights the 'Select' key. A blue arrow points from the 'Select' key to the text 'Select'.

No.	HI	LO
BIN 1:	OFF	OFF
BIN 2:	OFF	OFF
BIN 3:	OFF	OFF
BIN 4:	OFF	OFF

Select


- 5 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
Settable range: -9.99999G to 9.99999G




Unit:
(a/f/p/n/ μ /m/none/k/M/G)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.

- 6 Select the BIN number and select the upper and lower limit values.



- 7 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
Settable range: -9.99999 G to 9.99999 G



Unit:
(a/f/p/n/ μ /m/none/k/M/G)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.

4.4 Judging Measurement Results

Sub parameter settings

1 Select the [SUB] parameter.

BIN

SUB

θ:ABS

MOTN

No.

HI

LO

SUB

OFF

OFF

SUB

EXIT

F 2

►

Selects the sub parameter.

1

Select

2 Select [%].

BIN

SUB

θ: %

REF: 10.0000

REF

No.

HI

LO

SUB

OFF

OFF

%

EXIT

F 2

►

Selects percentage mode.

Select

3 Select the sub parameter reference value.

BIN

SUB

θ: %

REF: 10.0000

NUM

No.

HI

LV

SUB

OFF

OFF

EXIT

Select

4 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
Settable range: -9.99999 G to 9.99999 G

COMP
BIN

PANEL
LOAD

ESC

F 1

7

8

9

×

10³

F 2

4

5

6

÷

10³

F 3

1

2

3

ADJ

F 4

0

.

-

INFO

BACK
SPACE

ENTER

TRIG

Increases the unit


Decreases the unit

Accepts the entered value

Unit:
(a/f/p/n/μ/m/none/k/M/G)


If you make a mistake:
Press **BACK SPACE** key and reenter the value.

5 Set the sub parameter upper and lower limit value.



6 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**

Settable range: -9.99999 G to 9.99999 G



Unit:
(a/f/p/n/μ/m/none/k/M/G)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.

Upper limit value

- The upper limit value is set as a percentage of the reference value.
- In terms of the instrument's actual internal operation, the upper limit comparison value is calculated using the following equation and compared with the measurement value to make a judgment.


$$\text{Upper limit comparison value} = \text{reference value} + |\text{reference value}| \times \frac{\text{Percentage set value}}{100}$$

Lower limit value

- The lower limit value is set as a percentage of the reference value.
- In terms of the instrument's actual internal operation, the lower limit comparison value is calculated using the following equation. To set a value that is less than the measurement value, it is necessary to enter a negative percentage.

$$\text{Lower limit comparison value} = \text{reference value} + |\text{reference value}| \times \frac{\text{Percentage set value}}{100}$$

7



When you want to cancel the configuration process(p.96):
Press **ESC** to cancel.

4.4 Judging Measurement Results

3 Setting Upper and Lower Limit Values as(Δ%) Values Relative to the Offset from the Reference Value (Deviation Percentage Mode)

The upper and lower limit values can be set as a percentage based on the reference value, and the amount of deviation from the reference value can be displayed as the measurement value in the form of a percentage.

- NOTE** Set the judgment mode to [BIN].
- See "Setting the judgment mode" (p. 75)
- In deviation percentage mode, the amount of deviation (Δ%) from the reference value is displayed as the measurement value.
 - The method for setting the reference value and the upper and lower limit values is the same as for percentage mode.
- See "Setting the Upper or Lower Limit Value as a Percentage (%) Relative to a Reference Value (Percentage mode)" (p. 79)
- The reference value and upper and lower limit values are used by both percentage mode and deviation percentage mode.

The Δ% value is calculated using the following equation:

$$\Delta\% = \frac{\text{measurement value}-\text{reference value}}{|\text{reference value}|} \times 100$$

Main parameter settings

1 Press **COMP/BIN** key.

2 Select [MAIN].

2

MAIN

F 1

Select the main parameter.

1

Select

3 Select [Δ%].

BIN MAIN

Z:Δ%

REF: 1.00000k


ABS

F 3


Sets the parameter to deviation percentage mode.

Select

4 Select the main parameter reference value.




5 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
Settable range: -9.99999 G to 9.99999 G



Unit:
(a/f/p/n/μ/m/none/k/M/G)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.

6 Select the bin number and select the upper and lower limit values.




Does not set the upper and lower limit values.

4.4 Judging Measurement Results

7

Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
 Settable range: -9.99999 G to 9.99999 G



Unit:
 (a/f/p/n/μ/m/none/k/M/G)

If you make a mistake:
 Press **BACK SPACE** key and reenter the value.

Upper limit value

- The upper limit value is set as a percentage of the reference value.
- In terms of the instrument's actual internal operation, the upper limit comparison value is calculated using the following equation and compared with the measurement value to make a judgment.

$$\text{Upper limit comparison value} = \text{reference value} + |\text{reference value}| \times \frac{\text{Percentage set value}}{100}$$


Lower limit value

- The lower limit value is set as a percentage of the reference value.
- In terms of the instrument's actual internal operation, the lower limit comparison value is calculated using the following equation. To set a value that is less than the measurement value, it is necessary to enter a negative percentage.


$$\text{Lower limit comparison value} = \text{reference value} + |\text{reference value}| \times \frac{\text{Percentage set value}}{100}$$

Sub parameter settings


- 1** Select the **[SUB]** parameter.




- 2** Select **[Δ%]**.



- 3** Select the sub parameter reference value.



- 4** Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
Settable range: -9.9999 G to 9.9999 G




Unit:
(a/f/p/n/μ/m/none/k/M/G)


If you make a mistake:
Press **BACK SPACE** key and reenter the value.

4.4 Judging Measurement Results

- 5** Set the sub parameter upper and lower limit values.



- 6** Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**
- Settable range: -9.99999 G to 9.99999 G




Unit:
(a/f/p/n/μ/m/none/k/M/G)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.

The Δ% value is calculated using the following equation:

$$\Delta\% = \frac{\text{measurement value} - \text{reference value}}{|\text{reference value}|} \times 100$$


7



When you want to cancel the configuration process(p.96):
Press **ESC** to cancel.

When you want to cancel the BIN measurement setting:

When you want to cancel the comparator measurement setting, you can press **ESC** .



4.5 Setting Application Settings

4.5.1 Saving Measurement Results (Memory function)

You can save the measurement results inside the instrument. (Up to 32,000 items) The saved measurement results can be acquired using a communication command.

The items saved to memory are in accordance with the :MEASure:VALid setting.


For details on how to acquire the saved measurement results or set :MEASure:VALid, refer to the Communications commands in the included LCR Application Disk documentation .

- 1 Open the Advanced Settings screen.



F3 ► Displays the Advanced Settings screen.


- 2 Set [MEMORY] to [OFF].
You will not be able to change the number of measurement results if [MEMORY] is not set to [OFF].



F1 ► Sets [MEMORY] to [OFF].

1 Select

- 3 Set the number of measurement results.
Settable range: 1 to 32000




F1 ► Increases the value.

F2 ► Decreases the value.

1 Select

4.5 Setting Application Settings


4 Set [MEMORY] to [ON], [IN], or [OFF].



NOTE

- When comparator and BIN functionality have not been selected, IN operation is the same as ON operation.
- When the memory function is set to IN, measurement values are not saved if even one comparator result is HI or LO, or if the BIN result is OUT or SUBNG.


Clearing all measurement values saved in the instrument's memory



NOTE

Selecting [CLEAR] when no measurement results have been saved will cause the instrument to beep.

5



NOTE

- If the memory function is enabled (ON/IN), the number of memory items currently saved is displayed in the measurement screen.



Indicates that the number of memory items currently saved is 2,929.

- Measurement results saved internally by the instrument can be acquired with the **:MEM-ory?** Command.
See Communications commands in the included LCR Application Disk documentation.
- The internal data is lost when the memory function setting is changed.
- In continuous measurement mode, only measurements for panels for which the memory function is enabled are saved.
- When the instrument memory becomes full, the following message appears on the measurement screen. If this message appears, subsequent measurement results will not be saved. To resume saving, load or clear the measurement results from the instrument memory.



M.FULL

4.5.2 Setting the Detection Signal Waveform Averaging Count (Waveform Averaging Function)

The number of measurement waveforms for each frequency band is set for the measurement speed settings (FAST, MED, SLOW, SLOW2), and this function allows you to set the number of measurement waveforms for each frequency band. Having more waveforms increases the measurement precision, while having fewer waveforms increases the measurement speed.

NOTE

- The waveform averaging count can be set using communications commands only. It cannot be set from the instrument.

- When the waveform averaging function is set, the measurement speed setting is unavailable.

To set a measurement speed, first cancel the waveform averaging function setting.

See Communications commands in the included LCR Application Disk documentation (**:WAVE**)

- The measurement waveform count for each measurement speed can be set with the **:WAVE:RESet** communications command. Additionally, the measurement waveform count can be set to 1 for all frequency bands with **:WAVE:RESet FAST2**.

See Communications commands in the included LCR Application Disk documentation (**:WAVE:RESet**)

- When changing the waveform count for an individual frequency band, do so within the valid setting range outlined in the table below.

No. 2 to 4 provide compatibility with the IM3533 and cannot be used by this instrument.

See Communications commands in the included LCR Application Disk documentation (**:WAVE:NUM**)

No.	Frequency band	Valid setting range
1	DC	1 to 24 ^{*1}
5	40.000 Hz to 99.999 Hz	1 to 40
6	100.00 Hz to 300.00 Hz	1 to 50
7	300.01 Hz to 500.00 Hz	1 to 200
8	500.01 Hz to 1.0000 kHz	1 to 300
9	1.0001 kHz to 2.0000 kHz	1 to 600
10	2.0001 kHz to 3.0000 kHz	1 to 1200
11	3.0001 kHz to 5.0000 kHz	1 to 2000
12	5.0001 kHz to 10.000 kHz	1 to 3000
13	10.001 kHz to 20.000 kHz	1 to 1200 ^{*2}
14	20.001 kHz to 30.000 kHz	1 to 480 ^{*3}
15	30.001 kHz to 50.000 kHz	1 to 800 ^{*3}
16	50.001 kHz to 100.00 kHz	1 to 1200 ^{*3}
17	100.01 kHz to 200.00 kHz	1 to 2400 ^{*3}

*1:The No.1 DC measurement waveform count performs waveform averaging using the set line frequency as one wave.

*2:When using No.13, 5 times the number of waves set with the waveform averaging count are averaged.

*3:Nos.14 to 17 are used, 25 times the number of waves set with the waveform averaging count are averaged.

4.5.3 Setting the Delay Time from the Output of Comparator and BIN Judgment Results until Output of EOM (LOW) and Resetting Judgment Results


You can set the delay time for the period from the output of the comparator and BIN judgment results until the output of EOM (LOW) from the EXT I/O. In addition, you can also select whether to reset the comparator and BIN judgment results when they are EOM (HIGH).

See "9.2 Timing Chart" (p.184)


1 Open the Advanced Settings screen.




2 Set the EOM (low) output delay time based on the comparator and BIN judgment results.
Settable range: 0.0000 s to 0.9999 s



3 Select whether to reset the comparator and BIN judgment results when they are EOM (HIGH).



4



4.5.4 Enabling Trigger Input for during Measurement and Setting the Valid Edge of Trigger Input

You can select whether to enable or disable trigger input from the EXT I/O during measurement (during EOM (HI) output). Erroneous input due to chattering can be prevented by disabling trigger input during measurement. Furthermore, you can also select either the rising edge or falling edge as the valid edge of trigger input from the EXT I/O.


See "9.2 Timing Chart" (p.184)

- 1 Open the Advanced Settings screen.




Displays the Advanced Settings screen.


- 2 Select **[TRIG ENABLE]** and set trigger input from EXT I/O during measurement (while outputting EOM (HI) after the trigger is received) to **[ON]** or **[OFF]**.



- 3 Select **[TRIG EDGE]** and set the rising or falling edge as the trigger input effective edge.




4




4.5.5 Setting the EOM Output Method

The duration of the time period for which INDEX and EOM are high (off) decreases as the measurement frequency increases. If the high (off) time is too short for reasons related to the input circuit architecture when INDEX and EOM are received, it is possible to configure settings so that the low (on) signal state is maintained for the set time after EOM changes to low (on) when measurement completes before reverting the signal to high (off). The output method can be similarly changed for INDEX.
See "Chapter 9 External Control" (p.177)

1 Open the Advanced Settings screen.




2 Select [EOM MODE] and set the output method.



Timing charts when set to hold or pulse:
See "Chapter 9 External Control" (p.177)

3 Select [EOM-ON-TIME] and set the EOM output time to use with pulse EOM mode. **(DIGIT)**
Settable range: 0.0001 s to 0.9999 s



NOTE The output time cannot be set unless the output method is set to pulse.


4

The screenshot shows the ADVANCED 1 screen with the following settings: ADVANCED 1, ADVANCED 2, JUDGE RESET :ON, TRIG ENABLE :ON, TRIG EDGE :DOWN, EOM MODE :PULSE, EOM-ON-TIME :0.0050s. The EXIT button is highlighted with a blue box. To the right of the button is the text "F 4 ▶ Returns to the Measurement screen."


4.5.6 Checking Contact Defects and the Contact State (Contact Check Function)

This functionality allows you to detect contact defects between the terminals (H_{CUR} , H_{POT} , L_{CUR} , and L_{POT}) and the sample during 4-terminal measurement.
[See](#) Contact Check Error display(p.216)


1 Open the Advanced Settings screen.



2 Select [CONTACT].



3 Select the timing at which to perform contact check operation.



Available contact check timing settings	
OFF	Disables the contact check function.
BEFORE	Performs a contact check before measurement.
AFTER	Performs a contact check after measurement.
BOTH	Performs a contact check before and after measurement.

4.5 Setting Application Settings

4 Set the contact check threshold. **DIGIT**
Settable range :1 to 5

threshold	1	2	3	4	5
Permissible contact resistance [Ω]	about 1000	about 500	about 100	about 50	about 10

2

▲

▼

F 1

► Increases the value.

F 2

► Decreases the value.

◀

▲

▼

▶

1

Select

► Selects the digit to change.

5

ADVANCED 1

ADVANCED 2

TRIG ENABLE :ON

TRIG EDGE :DOWN

EOM MODE :HOLD

EOM-ON-TIME :0.0050s

CONTACT :OFF

EXIT

F 4

► Returns to the Measurement screen.

- NOTE**
- Setting the contact check timing to **[BOTH]** or **[BEFORE]** causes the trigger synchronous output function to be automatically turned on.
See "Applying the signal to the sample during measurement only (Trigger Synchronous Output Function)" (p. 57)
 - When setting a contact check threshold, the index time and EOM time will be delayed depending on the timing. (p.208)
 - The allowable contact resistance value may fluctuate depending on the sample being measured.
 - When **[BEFORE]** timing causes a contact check error, the measurement value will not be saved, even if the memory function is enabled.
 - When the sample is a high-capacitance capacitor, the contact check function may not operate under some measurement conditions.
 - The contact check function is designed to check the state of contact, not to generate a pass/fail judgment by accurately measuring the contact resistance. Measured values and threshold values comprise rough guidelines and are subject to an accuracy guaranty.

4.5.7 Detecting OPEN during 2-terminal Measurement (Hi-Z Reject Function)

This function is for outputting a measurement terminal connector error when the measurement result is high relative to the set judgment reference value. The setting value can be set as an absolute value, and the error is output via the measurement screen and the EXT I/O. On the Measurement screen, this error is output as [Hi Z].

See "Chapter 9 External Control" (p.177)

The judgment reference is calculated from the nominal value (range name) of the current measurement range and the judgment reference value as shown below.


Judgment reference = Nominal value of current measurement range × Judgment reference value (%)

Example Current measurement range nominal value :10 kΩ
 Judgment reference value :150%
 Judgment reference = 10 k × 1.50 = 15 k

1 Open the Advanced Settings screen.



2 Set the Hi Z reject function to [OFF] or [ON].



4.5 Setting Application Settings

3 Set the judgment reference value. **DIGIT**
Settable range: 0 to 30000%

A ratio is set using the range name as the reference value.
Example: When the 1 kΩ range is used:A ratio to the value of 1 kΩ is set.

ADVANCED 1 | ADVANCED 2

TRIG EDGE :DOWN

EOM MODE :HOLD

EOM-ON-TIME :0.0050s

CONTACT :OFF

Hi Z :OFF

01000%

EXIT

2

F 1

F 2

F 3

Increases the value.

Decreases the value.

Reverts to the default value.

1

Select

4

ADVANCED 1 | ADVANCED 2

TRIG EDGE :DOWN

EOM MODE :HOLD

EOM-ON-TIME :0.0050s

CONTACT :OFF

Hi Z :OFF

2

02500%

EXIT


F 4

Returns to the Measurement screen.


4.5.8 Turning the LCD Display On and Off

The LCD display can be turned on and off. You can save power by turning the LCD display off, which will cause the display to turn off when there is no key operation for 10 seconds. (This setting is the same as the continuous measurement function's LCD display on/off function.)


- 1 Open the Advanced Settings screen.



- 2 Select the **[ADVANCED2]** tab.



- 3 Select **[DISP]** and set the LCD display to **[OFF]** or **[ON]**.




- 4
-
- Returns to the Measurement screen.


4.5.9 Setting the Number of Display Digits

You can set the number of effective digits of the measurement value for each parameter.


- 1 Open the Advanced Settings screen.




- 2 Select the [ADVANCED2] tab.



- 3 Set the number of display digits for the main parameter. **DIGIT**
Settable range: 3 to 6 digits



- 4 Set the number of digits to display for the sub parameter. **DIGIT**
Settable range: 3 to 6 digits



5

ADVANCED 1 | ADVANCED 2

DISP :ON

DIGIT :MAIN:5 SUB:5

BEEP :JUDGE:NG KEY:ON

BEEP TONE :A

CONTRAST :50

EXIT

F 4 ▶ Returns to the Measurement screen.

List of setting values by parameter

Setting Value	Parameter				
	θ	D	Q	$\Delta\%$	Other
6	3 decimal digits	5 decimal digits	2 decimal digits	3 decimal digits	Full 6 digits
5	2 decimal digits	4 decimal digits	1 decimal digit	2 decimal digits	Full 5 digits
4	1 decimal digit	3 decimal digits	0 decimal digits	1 decimal digit	Full 4 digits
3	0 decimal digits	2 decimal digits	0 decimal digits	0 decimal digits	Full 3 digits

NOTE Minute values may not be displayed using the set number of digits.


4.5 Setting Application Settings

4.5.10 Setting Operation Sounds (Beep Sounds)


You can set the operation sound and each of the beep sounds for judgment results.
You can also select from four beep settings.

1 Reporting judgment results with beep operation


1 Open the Advanced Settings screen.



2 Select the [ADVANCED2] tab.



3 Set beep operation to [OFF], [IN], or [NG].




Comparator judgment beep settings	
OFF	Disables beep operation during comparator judgment.
When making judgments with 1 comparator	
IN	Beeps when the result is IN.
NG	Beeps when the result is LO or HI.
When making judgments with 2 comparators	
IN	Beeps when both results are IN.
NG	Beeps when either of the results is LO or HI.


4

2 Turning the key tone on and off


1 Open the Advanced Settings screen.




2 Select the **[ADVANCED2]** tab.



3 Turn the key tone on or off.



4




NOTE If an invalid key is pressed or an operation causes an error, an error tone will sound regardless of whether the beep tone is turned on or off.


4.5 Setting Application Settings

3 Changing the beep tone and key tone


1 Open the Advanced Settings screen.



2 Select the [ADVANCED2] tab.



3 Select the desired tone. [DIGIT]
You can select from four tones (A to D).



NOTE

No beep will sound if the key tone is set to OFF. To listen to sample beeps while you change the setting, enable key tone.
See "Setting Operation Sounds (Beep Sounds)" (p. 110)

4

A screenshot of the ADVANCED 2 screen. The 'EXIT' button at the bottom right is highlighted with a blue box. To its right, a grey button labeled 'F 4' is shown with an arrow pointing to the text 'Returns to the Measurement screen.'

4.5.11 Adjusting the Screen Contrast


The screen may become difficult to see if the ambient temperature changes. If this occurs, adjust the screen's contrast.

- 1 Open the Advanced Settings screen.




F 3 ► Displays the Advanced Settings screen.

- 2 Select the **ADVANCED2** tab.




- 3 Adjust the screen contrast.
Settable range: 0 to 100% (in 5% increments)



F 1 ► Increases the screen brightness.

F 2 ► Decreases the screen brightness.

- 4




F 4 ► Returns to the Measurement screen.


4.5.12 Disabling Key Operation (Key-lock Function)

There are two types of key-lock mode: full key lock, which disables all setting changes, and set key lock, which enables comparator and BIN measurement settings and the panel load function but disables other setting changes. Use the key lock mode that best suits your application. You can also set a passcode (PIN number).


1 Open the Advanced Settings screen.



2 Select the [ADVANCED2] tab.




3 Select the key lock setting conditions.



Key lock setting conditions	
OFF	Disables the key-lock function.
FULL	Protects settings by disabling all setting changes other than canceling key lock. You can check measurement conditions with the INFO key.
	During comparator measurement, you can only check the limit value with the ◀ ▶ keys. During BIN measurement, you can check limit values with the tenkey (0 to 9 and ◀ ▶) or the ◀ ▶ keys.
SET	• Comparator and BIN measurement settings, accessed with COMP / BIN key. • Panel load function, accessed with PANEL LOAD key. • Canceling key lock Settings are protected by disabling all setting changes other than the above. You can check measurement conditions with the INFO key. During comparator measurement, you can only check the limit value with the ◀ ▶ keys. During BIN measurement, you can check limit values with the tenkey (0 to 9 and ◀ ▶) or the ◀ ▶ keys.

4 Pressing **[EXIT]** enables key lock mode.



F 4 ► Enables key lock mode and returns to the Key Lock screen. (p.12)

NOTE

- In the case of an external trigger, the key lock is not enabled for **TRIG** key.
 - Turning off the power does not cancel the key-lock function.
 - Set and verify the passcode before activating key lock mode.
- See "Setting the Passcode of the Key-lock" (p. 116)


4.5 Setting Application Settings

Setting the Passcode of the Key-lock


1 Open the Advanced Settings screen.



2 Select the [ADVANCED2] tab.




3 Select the key lock passcode.



4 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**

Settable range : 1 to 4 digits
Default password : 3523



If you make a mistake:
Press **BACK SPACE** key and reenter the value.

NOTE When a passcode has been set, that passcode must be entered in order to cancel key lock mode. Take steps to ensure you do not forget the set passcode.


Canceling key lock mode

- 1** Select **[UNLCK]** on the Key Lock screen.




► Select **[UNLCK]** on the Key Lock screen.

- 2** Enter the passcode. **[10KEY]**
If no passcode has been set, select **[UNLCK]** without entering anything.




- The entered passcode will be displayed on the screen with asterisks.
- To erase entered text, press **[BACK SPACE]** key.



► Cancels the unlock operation.


- 3** Select **[UNLCK]**.



► Cancels key lock mode and returns to the Measurement screen.

Pressing **[ENTER]** key also cancels key lock mode and returns to the Measurement screen.

NOTE If you forget the passcode, perform a full reset to revert the instrument to its factory settings. (p.215)



If the above error is displayed, check the following:

Cause: UNLCK was pressed before the passcode was entered.

Solution: Press **[BACK SPACE]** key and enter the passcode.

Cause: The entered passcode is incorrect.

Solution: Press **[BACK SPACE]** key and reenter the passcode.

4.5.13 Initializing (System Reset)


In the event of the instrument malfunctioning, check "Before returning for repair" (p. 211). If you do not know the cause of the problem, perform a system reset.

See "Appendix11 Initial Settings Table"(p. A16)
A system reset can also be performed with the *RST and :RESet communication commands.
See Communications commands in the included LCR Application Disk documentation (*RST), (:PRESet)


1 Open the Advanced Settings screen.




2 Select the [ADVANCED2] tab.



3 Select [RESET].



4 Select [YES] or [NO] for the system reset.



NOTE • If the initialization screen cannot be displayed, perform a full reset. (p.215)
• Please remove the test sample to be measured before performing a system reset.


Continuous Measurement Function Chapter 5

5.1 About Continuous Measurement Function

The continuous measurement function loads measurement conditions saved with the panel save function and performs up to two measurements in succession.

5.1.1 Measurement screen

When the instrument is turned back on, the display reflects the measurement mode in use when it was last turned off. For more information about screen layouts, see (p.17).




- NOTE**
- Setting the measurement conditions so that the measurement frequency or measurement signal level differs for each panel allows you to simply evaluate the characteristics of the test sample.
 - Continuous measurement can also be performed from the EXT I/O. (p.178)
 - If the power is turned off when the Continuous Measurement Screen is displayed, the Continuous Measurement Screen will be displayed when the instrument starts the next time you turn the power on.


5.1 About Continuous Measurement Function

5.1.2 Setting Continuous Measurement


1 Open the Advanced Settings screen.




2 Select [MODE].



3 Set the mode.




4 The measurement mode will be changed to continuous measurement mode.




5.2 Configuring Basic Settings for Continuous Measurement

Before performing continuous measurement, you must specify which panel to target for continuous measurement. First, use the panel save function to save the desired measurement conditions.
[See](#) "7.1 Saving Measurement Conditions (Panel Save Function)" (p. 162)


1 Open the Basic Settings screen.




2 Select a panel.
Panels for which only compensation values (ADJ) have been saved will not be shown.



Measurement condition display (when [INFO] is selected)
[See](#) "1.3.9 Information Screen" (p. 20)



3




NOTE You can select up to two panels. Attempting to select three or more panels will cause the instrument to beep. To change panels, first set the panel you wish to not use to off.

5.3 Performing Continuous Measurement

- 1

Configure continuous measurement settings.
See "5.2 Configuring Basic Settings for Continuous Measurement" (p. 121)
- 2


When you return to the initial screen, the panel numbers you enabled on the Panel Settings screen will be shown.



- 3

Continuous measurement will be performed each time you press **TRIG** key.
- 4

The measurement results will be displayed.



5.4 Configuring Application Settings for Continuous Measurement


5.4.1 Setting the Display Timing

Set the draw timing for during continuous measurement.
If the display timing is set to **[REAL]**, the time for continuous measurement becomes long because the screen is updated every time measurement is performed.
If it is set to **[AFTER]** to give priority to the measurement time, the screen update time becomes short.


1 Open the Advanced Settings screen.



2 Set the display timing.



3




5.4 Configuring Application Settings for Continuous Measurement


5.4.2 Setting the LCD to ON/ OFF

You can turn the display backlight on and off. When the backlight is set to [OFF] it will turn off when no keys are operated for 10 seconds to save power.
(This setting is the same as the LCR function's backlight on/off function.)

1 Open the Advanced Settings screen.




2 Set the backlight to [ON] or [OFF].



When you want to turn the backlight on again:
If you press the key while the backlight is off, the backlight will turn on again. The backlight will turn off again after about 10 seconds if there is no key operation.

3



Error Compensation

Chapter 6

Compensate for errors caused by a fixture or measurement cable.

6.1 Setting Open Circuit Compensation

With open circuit compensation, it is possible to reduce the influence of the floating impedance of the test cables and thereby to enhance the accuracy of measurement.

It is effective for test samples whose impedance is relatively high.

The comparator decision mode can be set as one of the following:



All Compensation	▶	The compensation values are obtained for all test frequencies. (p.127) You can set the range of measurement frequencies to correct. (p.129)
Spot Compensation	▶	The compensation values are obtained at the set measurement frequency only. (p.131)
OFF	▶	Open circuit compensation data becomes invalid. (p.135)

NOTE

- Before open circuit compensation, always set the cable length.
See "6.4 Compensating Measurement Cable Errors(Cable Length Compensation)" (p. 157)
 - The measurement accuracy values defined in the specifications are for when open circuit compensation and short circuit compensation are performed.
 - Be sure to perform compensation again after replacing the measuring cable.
You will be unable to obtain correct values if measurement is performed in the compensation state prior to replacement.
 - For SPOT compensation, the open circuit compensation will be valid only when the measurement frequency agrees with the SPOT compensation frequency.
 - When performing compensation, make sure that there is no noise source nearby. Noise may cause an error when performing compensation.
ex. Servo Motor, switching power source, high-voltage cable and etc.
 - The compensation process should be performed under conditions similar to those in which the sample will be measured.
 - The compensated value is preserved in the memory of the main instrument even when power is turned off.
 - Compensation values cannot be acquired with the continuous measurement mode.
- The **ADJ** key is disabled.

6.1 Setting Open Circuit Compensation


Before performing compensation



- Route the measurement cables as they will be used during actual measurement. Changes in cable layout may prevent accurate compensation.
- Create an open state between the HIGH terminals and LOW terminals of the probes or fixture in accordance with the width of the measurement object. (Connect HCUR and HPOT, and connect LCUR and LPOT.)
- When the open circuit compensation is performed, execute the guarding process.

See "Appendix2 Measurement of High Impedance Components"(p. A3)

(When using the optional 9500-10)



Short the probe's Hcur and Hpot terminals (red) with one metallic wire and its Lcur and Lpot terminals (black) with the other, so that there is no connection between the high and low terminals. Perform open correction.

*1: Leave the high and low terminals as far apart as they will be when connected to the measurement sample.

6.1.1 All Compensation

Simultaneously acquire the open compensation values for all measurement frequencies.

When limiting the frequency range for ALL compensation


See "Compensation range limit function" (p.129)

- 1 Press the **ADJ** key while the Measurement screen is displayed to display the Adjust screen.


NOTE

The **ADJ** key cannot be used on screens other than the Measurement screen.

- 2 Select **[OPEN]** on the Adjust screen.




- 3 Select **[TYPE]** on the open compensation Edit screen.



- 4 Select **[ALL]**.



- 5



6.1 Setting Open Circuit Compensation

6 Select [EXEC].

OPEN ADJUST:ALL

No	FREQ	G	B
01	DC	0.000nS	0.000nS
02	40.000 Hz	0.000nS	0.000nS
03	99.999 Hz	0.000nS	0.000nS
04	100.00 Hz	0.000nS	0.000nS

EXEC
TYPE
EXIT

F 1

▶ Performs open compensation.

F 2

▶ Limits the compensation range. (p.129)

F 4

▶ Cancels acquisition of compensation values and returns to the Adjust screen, leaving the previous compensation values enabled.

NOTE

- The previous compensation values will be displayed on the confirmation screen. (If compensation has never been performed, 0 will be used as the compensation value.)
- Verify that the measurement cables have been left open.

7 Open compensation is performed.
Compensation time: Approx. 45 seconds.

OPEN ADJUST:ALL

No OPEN

Now Adjusting...

51%

CANCL

F 4

▶ Cancels open compensation and closes the window. (The previous open compensation values will be used.)

8 Check the open compensation results.

Compensation no.

Measurement frequency

Compensation results (conductance, susceptance)

OPEN ADJUST:ALL

No	FREQ	G	B
01	DC	0.112nS	0.000nS
02	40.000 Hz	0.077nS	-0.001nS
03	99.999 Hz	-0.110nS	0.001nS
04	100.00 Hz	0.036nS	0.001nS

EXEC
AREA
TYPE
EXIT

When compensation completes normally, the conductance and susceptance will be displayed. Compensation is supported for impedance values of 1 kΩ or greater.

You can check the conductance and susceptance at compensation points with .

- When normal compensation values were not acquired
 - If compensation failed
 - When you want to make open circuit compensation data invalid
- See (p.134)

9

OPEN ADJUST:ALL

No	FREQ	G	B
01	DC	0.112nS	0.000nS
02	40.000 Hz	0.077nS	-0.001nS
03	99.999 Hz	-0.110nS	0.001nS
04	100.00 Hz	0.036nS	0.001nS

EXEC
AREA
TYPE
EXIT

F 4

▶ Returns to the Adjust screen.

Compensation range limit function

In ALL compensation, compensation is performed for all frequency ranges. Using the compensation range limit function, you can set the minimum and maximum compensation frequencies, thereby reducing the time required for the compensation process to complete. The DC on/off setting and the minimum and maximum compensation frequency settings apply to both open and short compensation.

1 Select ALL compensation.
See "All Compensation" (p.127)

2 Select [AREA] on the open compensation Edit screen.

OPEN ADJUST:ALL			
No	FREQ	G	B
01	DC	0.112nS	0.000nS
02	40.000 Hz	0.077nS	-0.001nS
03	99.999 Hz	-0.110nS	0.001nS
04	100.00 Hz	0.036nS	0.001nS

AREA
F2
EXIT

F 2 ▶ Displays the Compensation Range Limit screen.

3 Select DC compensation.

OPEN ADJUST:ALL	
No	ADJUST
01	DC : ON
02	40.000 Hz
03	200.00kHz
04	

OFF
ON
RESET
SET
F1
F2
F3
F4

1 Select

2

- F 1 ▶ Disables DC compensation.
- F 2 ▶ Performs DC compensation.
- F 3 ▶ Reverts to the default setting (on).
- F 4 ▶ Accepts the settings and closes the settings window.

4 Set the minimum compensation frequency.

OPEN ADJUST:ALL	
No	AREA
01	MIN : 40.000 Hz
02	
03	
04	

RESET
SET
F3

Reverts to the default setting. (40.000 Hz)

Select

5 Enter the desired value with the tenkey and accept it with the **ENTER** key. **10KEY**
Settable range: 40.000 Hz to 200.00 kHz

COMP / BIN PANEL LOAD ESC

F1 7 8 9 ×10³
F2 4 5 6 ÷10³
F3 1 2 3 ADJ
F4 0 * - INFO
BACK SPACE ENTER TRIG

Increases the unit

Decreases the unit

Accepts the entered value

Unit : (none/k)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.

6.1 Setting Open Circuit Compensation

6 Set the maximum compensation frequency.

OPEN ADJUST:ALL

No

01

AREA

NUM

02

DC

:

ON

03

MAX

:

200.00kHz

04

RESET

SET

F 3

Reverts to the default setting.
(200.00 kHz)

Select

7 Enter the desired value with the tenkey and accept it with the **ENTER** key. **10KEY**
Settable range: 40.000 Hz to 200.00 kHz

COMP /BIN

PANEL LOAD

ESC

F1

7

8

9

F2

4

5

6

F3

1

2

3

F4

0

.

-

×10³

÷10³

ADJ

INFO

TRIG

Accepts the entered value

Unit : (none/k)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.

8

OPEN ADJUST:ALL

No

01

AREA

NUM

02

DC

:

ON

03

MIN

:

40.000 Hz

04

MAX

:

200.00kHz

RESET

SET

F 4

Returns to the open compensation Edit screen.

NOTE If the maximum compensation frequency is less than the minimum compensation frequency, the minimum and maximum compensation frequencies will be switched automatically.

6.1.2 Spot Compensation


Acquire the compensation values at the set measurement frequencies.
Up to five compensation points can be set for measurement frequencies.

- 1 Press the **ADJ** key while the Measurement screen is displayed to display the Adjust screen.


NOTE

The **ADJ** key cannot be used on screens other than the Measurement screen.


- 2 Select **[OPEN]** on the Adjust screen.




- 3 Select **[TYPE]** on the open compensation Edit screen.




- 4 Select **[SPOT]**.



- 5




- 6 Select the compensation points you wish to set.



6.1 Setting Open Circuit Compensation

7 Enter the frequency to correct.




F 1 ▶ Disables compensation.

F 2 ▶ Sets the compensation frequency to DC.

Until a value is entered, the frequency at which SPOT compensation was previously performed is displayed.

8 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**




Unit : (none/k)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.


- Settable range:DC, 40 Hz to 200 kHz
- If you set a frequency in excess of 200 kHz, the frequency will automatically revert to 200 kHz.
- If a frequency of less than 40 Hz is set, the value will be automatically changed to 40 Hz. However, very small values will cause the DC setting to be used.

9



F 4 ▶ Accepts the frequency to be corrected and returns to the Edit screen.

10 Select **[EXEC]**.



F 1 ▶ Performs open compensation.

F 4 ▶ Cancels acquisition of compensation values and returns to the Adjust screen, leaving the previous compensation values enabled.

NOTE

- The previous compensation values will be displayed on the confirmation screen. (If compensation has never been performed, 0 will be used as the compensation value.)
- Verify that the measurement cables have been left open.

6.1 Setting Open Circuit Compensation

11 Open compensation is performed.
The time required to perform the compensation process varies with the measurement frequency and number of points.

OPEN ADJUST:SPOT

No.	OPEN
01	Now Adjusting...
02	
03	
04	0%

CANCEL

F 4

Cancels open compensation and closes the window.
(The previous open compensation values will be used.)

12 Check the open compensation results.

Compensation no.

Measurement frequency

Compensation results
(conductance, susceptance)

You can check the conductance and susceptance at compensation points with .

OPEN ADJUST:SPOT

No.	FREQ	G	B
01	100.00kHz	6.861nS	18.398nS
02	---	0.000nS	0.000nS
03	---	0.000nS	0.000nS
04	---	0.000nS	0.000nS

EEXEC
EDIT
TYPE
EXIT

When compensation completes normally, the conductance and susceptance will be displayed. Compensation is supported for impedance values of 1 kΩ or greater.

- When normal compensation values were not acquired
 - If compensation failed
 - When you want to make open circuit compensation data invalid
- See (p.134)

13

OPEN ADJUST:SPOT

No.	FREQ	G	B
01	100.00kHz	6.861nS	18.398nS
02	---	0.000nS	0.000nS
03	---	0.000nS	0.000nS
04	---	0.000nS	0.000nS

EEXEC
EDIT
TYPE
EXIT

F 4


Returns to the Adjust screen.

6.1 Setting Open Circuit Compensation

When Normal Compensation Values were Not Acquired

If the following error appears when compensation ends, the acquired compensation values will become valid if you press **EXIT** but those compensation values cannot be guaranteed.

Screen when the instrument was unable to acquire




The open circuit compensation process is quite sensitive to noise - both noise originating externally and induced noise. Therefore, if open circuit compensation has been interrupted with a fault, you should check the following points before starting the compensation process again (p.125):

- Check that the test cables are properly connected.
- Check that nothing is connected to the test cables.
(Open circuit compensation cannot be performed while any test sample is connected to the test cables.)
- Check that the test leads are arranged as closely as possible to their configuration in which measurement will be performed.
- During the compensation process, be sure not to disturb the test cables or to move your hand near them.
- Execute the guarding process.

If open compensation fails

A window such as the following will be displayed if compensation fails.

When an error message appears and compensation has stopped (when **EXIT** is pressed), the instrument conditions revert to those before the compensation was attempted to be performed.




The open circuit compensation process is quite sensitive to noise - both noise originating externally and induced noise. Therefore, if open circuit compensation has been interrupted with a fault, you should check the following points before starting the compensation process again (p.125):

- Check that the test cables are properly connected.
- Check that nothing is connected to the test cables.
(Open circuit compensation cannot be performed while any test sample is connected to the test cables.)
- Check that the test leads are arranged as closely as possible to their configuration in which measurement will be performed.
- During the compensation process, be sure not to disturb the test cables or to move your hand near them.
- Execute the guarding process.

See "Open compensation or short compensation resulted in an error." (p.214)

When You Want to Make Open Circuit Compensation Data Invalid

You can invalidate the acquired compensation data and return to the Measurement screen by pressing **OFF** (**F 1**) and then **EXIT** (**F 4**) in step 4 of the ALL compensation procedure (p.127) or the SPOT compensation procedure (p.131) for open compensation.



NOTE The compensation values that are stored internally are not cleared by the operation described above. When ALL or SPOT is selected, the stored compensation values can be used.

6.2 Short Circuit Compensation

With short circuit compensation, it is possible to reduce the influence of the residual impedance of the test cables and thereby to enhance the accuracy of measurement.

It is effective for test samples whose impedance is relatively low.

The comparator decision mode can be set as one of the following:

All Compensation

Compensation values are obtained for all test frequencies. (p.138)
You can set the range of measurement frequencies to correct. (p.129)

Spot Compensation

Compensation values are obtained at the set measurement frequency only. (p.140)

OFF

Short circuit compensation data becomes invalid. (p.144)


NOTE

- Before short circuit compensation, always set the cable length.
See "6.4 Compensating Measurement Cable Errors(Cable Length Compensation)" (p. 157)
- The measurement accuracy values defined in the specifications are for when open circuit compensation and short circuit compensation are performed.
- Be sure to perform compensation again after replacing the measuring cable.
You will be unable to obtain correct values if measurement is performed in the compensation state prior to replacement.
- For SPOT compensation, the open circuit compensation will be valid only when the measurement frequency agrees with the SPOT compensation frequency.
- When performing compensation, make sure that there is no noise source nearby. Noise may cause an error when performing compensation.
ex. Servo Motor, switching power source, high-voltage cable and etc.
- The compensation process should be performed under conditions similar to those in which the sample will be measured.
- The compensated value is preserved in the memory of the main instrument even when power is turned off.
- Compensation values cannot be acquired with the continuous measurement mode. The **ADJ** key is disabled.

Before Performing Screen Operations

Necessary item: Shorting bar

This shorting bar is for short circuiting together the ends of the test leads. Use an object whose impedance is as low as possible.



If you use a metallic wire or the like as a shorting bar, try to ensure that it is as thick and short as possible.


Usage example:

Arrange the test leads as closely as possible to their configuration in which measurement will be performed, and short circuit together the HIGH and LOW leads.

(When using the optional 9140-10)


If you intend to short circuit between the clamps at the ends of the test leads, clip both clamps onto a short piece of metallic wire as shown.

When using the 9140-10, please pinch the short wire with both clips. A short circuit state can not be created by pinching clip each other.




(When using the optional L2000)

Align the "V" marks on the clips as shown below and short the terminals.




(When using a fixture)

In order to keep external influences as low as possible, be sure to thrust the shorting bar in all the way.



(When using the optional 9500-10)

Pinch the clips onto a short metallic wire in the order of H_{CUR}, H_{POT}, L_{POT}, and L_{CUR} so that all the terminals are shorted, and then perform open correction.




6.2.1 All Compensation

Simultaneously acquire the short compensation values for all measurement frequencies.
When limiting the frequency range for ALL compensation
See "Compensation range limit function" (p.129)


- 1
- Press the **ADJ** key while the Measurement screen is displayed to display the Adjust screen.
- NOTE

The **ADJ** key cannot be used on screens other than the Measurement screen.

- 2
- Select **[SHORT]** on the Adjust screen.



- 3
- Select **[TYPE]** on the short compensation Edit screen.



- 4
- Select **[ALL]**.



- 5
- The screenshot shows the SHORT ADJUST screen with the following layout:

SHORT ADJUST:OFF		OFF	
No	SHORT	ALL	
Select Adjust TYPE.		SPNT	
		EXIT	

Annotations:

 - A blue box highlights the **EXIT** key in the bottom right corner.
 - A blue arrow points from the **EXIT** key to the text "Accepts ALL compensation as the short compensation setting and returns to the Edit screen."
 - A blue box highlights the **F 4** key in the bottom right corner.
 - A blue arrow points from the **F 4** key to the text "Accepts ALL compensation as the short compensation setting and returns to the Edit screen."

6 Select [EXEC].

SHORT ADJUST:ALL

No	FREQ	R	X
01	DC	0.00mΩ	0.00mΩ
02	40.000 Hz	0.00mΩ	0.00mΩ
03	99.999 Hz	0.00mΩ	0.00mΩ
04	100.00 Hz	0.00mΩ	0.00mΩ

EXEC

AREA

EXIT

F 1

F 2

F 4

Performs short compensation.

Limits the compensation range. (p.129)

Cancels acquisition of compensation values and returns to the Adjust screen, leaving the previous compensation values enabled.

NOTE

- The previous compensation values will be displayed on the confirmation screen. (If compensation has never been performed, 0 will be used as the compensation value.)
- Verify that the measurement cables have been shorted.

7 Short compensation is performed.
Compensation time: Approx. 45 seconds.

SHORT ADJUST:ALL

No SHORT

Now Adjusting...

51%

CANCL

F 4

Cancels short compensation and closes the window. (The previous short compensation values will be used.)

8 Check the open compensation results.

Compensation no.

Measurement frequency

Compensation results (effective resistance, reactance)

You can check the effective resistance and reactance at compensation points with .

SHORT ADJUST:ALL

No	FREQ	R	X
01	DC	24.41mΩ	0.00mΩ
02	40.000 Hz	12.77mΩ	-0.07mΩ
03	99.999 Hz	-61.11mΩ	0.08mΩ
04	100.00 Hz	21.39mΩ	-0.03mΩ

EEXEC

AREA

TYPE

EXIT

When compensation completes normally, the effective resistance and reactance will be displayed. Compensation is supported for impedance values of 1 kΩ or greater.

- When normal compensation values were not acquired
 - If compensation failed
 - When you want to make short circuit compensation data invalid
- See (p.143)

9

SHORT ADJUST:ALL

No	FREQ	R	X
01	DC	24.41mΩ	0.00mΩ
02	40.000 Hz	12.77mΩ	-0.07mΩ
03	99.999 Hz	-61.11mΩ	0.08mΩ
04	100.00 Hz	21.39mΩ	-0.03mΩ

EEXEC

AREA

TYPE

EXIT

F 4

Returns to the Adjust screen.

6.2.2 Spot Compensation

In SPOT compensation, compensation values are obtained for the set measurement frequencies. Up to five points can be set for measurement frequencies.

1 Press the **ADJ** key while the Measurement screen is displayed to display the Adjust screen.

NOTE The **ADJ** key cannot be used on screens other than the Measurement screen.

2 Select **[SHORT]** on the Adjust screen.

ADJUST

SHORT :OFF

CABLE :0m

SCALE :OFF

EDIT

EXIT

2

F 1

Displays the Edit screen.

1

Select

3 Select **[TYPE]** on the short compensation Edit screen.

SHORT ADJUST:OFF

No FREQ R H

TYPE

EXIT

F 3

Displays the Short Compensation Setting screen.

4 Select **[SPOT]**.

SHORT ADJUST:OFF

No SHORT

Select Adjust TYPE.

SPOT

EXIT

F 3

Selects SPOT compensation.

5

SHORT ADJUST:OFF

No SHORT

Select Adjust TYPE.

OFF

ALL

SPOT

EXIT

F 4

Accepts SPOT compensation as the short compensation setting and returns to the Edit screen.

6 Select the compensation points you wish to set.

SHORT ADJUST:SPOT

01 --- 0.00mΩ 0.00mΩ

03 --- 0.00mΩ 0.00mΩ

04 --- 0.00mΩ 0.00mΩ

EDIT

EXIT

2

F 2

Displays the Compensation Point Settings screen.


1

Select

F 4

Returns to the Adjust screen.


7 Enter the frequency to correct.



- F 1 ► Disables compensation.
- F 2 ► Sets the compensation frequency to DC.

Until a value is entered, the frequency at which spot compensation was previously performed is displayed.

8 Enter a value with the tenkey and accept it with the **ENTER** key. **10KEY**




Unit : (none/k)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.


- Settable range: DC, 40 Hz to 200 kHz
- If you set a frequency in excess of 200 kHz, the frequency will automatically revert to 200 kHz.
- If a frequency of less than 40 Hz is set, the value will be automatically changed to 40 Hz. However, very small values will cause the DC setting to be used.

9



- F 4 ► Accepts the frequency to be corrected and returns to the Edit screen.

10 Select **[EXEC]**.




- F 1 ► Performs short compensation.
- F 4 ► Cancels acquisition of compensation values and returns to the Adjust screen, leaving the previous compensation values enabled.

NOTE

- The previous compensation values will be displayed on the confirmation screen. (If compensation has never been performed, 0 will be used as the compensation value.)
- Verify that the measurement cables have been shorted.

6.2 Short Circuit Compensation

11 Short compensation is performed.
The time required to perform the compensation process varies with the measurement frequency and number of points.



F 4 ► Cancels short compensation and closes the window.
(The previous short compensation values will be used.)

12 Check the short compensation results.

Compensation no.

Measurement frequency

Compensation results (effective resistance, reactance)

No	FREQ	R	X
01	100.00kHz	28.51mΩ	-0.07mΩ
02	---	0.00mΩ	0.00mΩ
03	---	0.00mΩ	0.00mΩ
04	---	0.00mΩ	0.00mΩ

You can check the effective resistance and reactance at compensation points with .

When compensation completes normally, the effective resistance and reactance will be displayed. Compensation is supported for impedance values of 1 kΩ or greater.

- When normal compensation values were not acquired
 - If compensation failed
 - When you want to make short circuit compensation data invalid
- [See](#) (p.143)

13


No	FREQ	R	X
01	100.00kHz	28.51mΩ	-0.07mΩ
02	---	0.00mΩ	0.00mΩ
03	---	0.00mΩ	0.00mΩ
04	---	0.00mΩ	0.00mΩ

F 4 ► Returns to the Adjust screen.

When Normal Compensation Values were Not Acquired

If the following error is encountered when compensation completes, you can press **EXIT** to enable the acquired compensation values. However, the accuracy of those values is not guaranteed.

Screen when the instrument is unable to acquire normal compensation values



Check the following points before starting the short circuit compensation process again (p.136):


- Check that the test cables are properly connected.
- Check that the test cables are properly shorted together with the shorting bar.
(Short circuit compensation cannot be performed while any test sample is connected to the test cables.)
- Check that the test leads are arranged as closely as possible to their configuration in which measurement will be performed.
- During the compensation process, be sure not to disturb the test cables or to move your hand near them.

When Short Compensation Failed

A window such as the following will be displayed if compensation fails.

When an error message appears and compensation has stopped (when **EXIT** is pressed), the instrument conditions revert to those before the compensation was attempted to be performed.

Screen when compensation fails



Check the following points before starting the short circuit compensation process again (p.136):


- Check that the test cables are properly connected.
- Check that the test cables are properly shorted together with the shorting bar.
(Short circuit compensation cannot be performed while any test sample is connected to the test cables.)
- Check that the test leads are arranged as closely as possible to their configuration in which measurement will be performed.
- During the compensation process, be sure not to disturb the test cables or to move your hand near them.

6.2 Short Circuit Compensation

When You Want to Make Short Circuit Compensation Data Invalid

You can invalidate the acquired compensation data and return to the Measurement screen by pressing **OFF** and then **EXIT** (**F 4**) in step 4 of the ALL compensation procedure (p.138) or the SPOT compensation procedure (p.140) for short compensation.

Short Compensation Settings




NOTE Performing the operation described above will not delete compensation values stored in the instrument's memory. The saved compensation values will be used when ALL or SPOT is selected.

6.3 Adjusting Values Based on Reference Values (Load Compensation)

Compensate measurement values to match the element that will be the reference.
 With load compensation it is possible to calculate the compensation coefficient by measuring a reference sample with known data and perform the compensation for the test data obtained from the target sample. This function provides the compatibility with the test data.
 You can acquire compensation coefficients for up to five sets of compensation conditions. Reference values can be set independently for each set of compensation conditions.

The following six items should be set for one compensation condition.



The compensation coefficient is computed from the reference values of Z and θ obtained from the set values and the actual data acquired from the reference sample at each of the compensation frequencies.

$$\text{Compensation coefficient of Z} = \frac{(\text{Reference value of Z})}{(\text{Actual data of Z})}$$

$$\text{Compensation value of } \theta = (\text{Reference value of } \theta) - (\text{Actual data of } \theta)$$


The measured values of Z and θ are first compensated using the following equations, and then individual parameters from the compensated Z and θ values are employed.

$$Z = (Z \text{ before compensation}) \times (\text{Compensation coefficient of Z})$$


$$\theta = (\theta \text{ before compensation}) + (\text{Compensation value of } \theta)$$

6.3 Adjusting Values Based on Reference Values (Load Compensation)

- NOTE**
- Be sure to set the cable length before performing load compensation.
 - See "6.4 Compensating Measurement Cable Errors(Cable Length Compensation)" (p. 157)
 - Set the compensation condition of the load compensation same as the present measurement condition. If they do not match, load compensations are not performed properly.
 - If the current measurement frequency does not match the compensation frequency, an error such as the following will be displayed on the Info screen.



- If conditions other than the compensation frequency match, compensation will be performed, and an error such as the following will be displayed on the Info screen.




- When the OPEN or SHORT compensation is valid, the load compensation is performed for Z and θ processed by the OPEN or SHORT compensation.
- In acquiring load compensation data (i.e., reference sample measurement), the OPEN/SHORT compensation settings, that were defined before entry into the Load Compensation Screen, are valid.
- If the same compensation frequency is set for multiple compensation points, only the compensation point with the lowest number of the compensation conditions will become effective.


- 1 Press the **ADJ** key while the Measurement screen is displayed to display the Adjust screen.

NOTE The **ADJ** key cannot be used on screens other than the Measurement screen.


- 2 Select **[LOAD]** on the Adjust screen.



- 3 Select **[TYPE]** on the load compensation Edit screen.




- 4 Select **[ON]** for the load compensation setting.



6.3 Adjusting Values Based on Reference Values (Load Compensation)


5



F 4 ▶ Enables load compensation and returns to the Edit screen.

6

Select the load compensation condition number you wish to configure and select **[EDIT]**.




F 2 ▶ Displays the load compensation conditions Edit screen.



7

Set the load compensation conditions.



For more information about how to configure each setting, see the pages listed below.

Compensation condition	Page
FREQ (Compensation frequency)	(p.150)
RANGE (Compensation Range)	(p.151)
LEVEL (compensation level measurement signal mode and value)	(p.152)
MODE (parameter to use as refer- ence value)	(p.153)
REF(Reference value)	(p.154)

NOTE

- Configure settings in the following order: FREQ, RANGE, LEVEL, MODE, REF.
- If the settings have not all been configured, you will not be able to perform compensation.
- If you want to use the current measurement conditions as the load compensation conditions(p.155).

6.3 Adjusting Values Based on Reference Values (Load Compensation)

8 Accept the load compensation conditions.

LOAD No.1

GET

RESET

CANCEL

NUM

FREQ : 1.0000kHz

RANGE : 100kΩ

LEVEL : V 1.000V

MODE : Z -θ

REF : 10.0000kΩ 0.000 *

SET

F 4

Accepts the compensation conditions and returns to the load compensation Edit screen.

Either place a standard sample on the fixture or connect the sample to the measurement cables.

Resetting or canceling the set conditions

Select [RESET] with the ◀ ▶ keys and press F1 key to reset the set conditions. (p.155)
Select [CANCEL] with the ◀ ▶ keys and press F1 key to return to the Edit screen. (p.155)

LOAD No.1

GET

RESET

CANCEL

RESET

F 1

FREQ : 10.000kHz

RANGE : 100kΩ

LEVEL : V 1.000V

MODE : Z -θ

REF : --- ---

SET

9 Select [EXEC] to acquire compensation values.

LOAD

ADJUST:OFF

EXEC

F 1

Acquires compensation values.

No	Freq	Ref1	Ref2
1	1.0000kHz	10.0000kΩ	0.000 *
	Z -θ	10.0000kΩ	0.000 *
2	---	---	---

LOAD

TYPE

EXIT

- Changing any of the compensation conditions after acquiring compensation data will invalidate the compensation data.
- If an error occurs during the acquisition of compensation data, the instrument will beep, and the compensation data will be invalidated. (p.155)
- Changing any of the compensation conditions after acquiring compensation data will invalidate the compensation data.

10 Load compensation will be performed.
The time required to perform the compensation process varies with the measurement frequency.
See "When Load Compensation Failed" (p.155)

LOAD

ADJUST:ON

LOAD

Now Adjusting...

0%

CANCEL

F 4

Cancels the load compensation operation and returns to the Compensation screen. (The previous load compensation values will be used.)

6.3 Adjusting Values Based on Reference Values (Load Compensation)

11 Check the load compensation results.

LOAD	ADJUST:ON			EHEC
No Freq	Ref1	Ref2		EDIT
Z - θ	10.0048k Ω	0.076 °		EXIT

The compensation values will be displayed when the acquisition of compensation values completes.

12

LOAD	ADJUST:ON			EHEC
No Freq	Ref1	Ref2		EDIT
1 1.0000kHz	10.0000k Ω	0.000 °		TYPE
Z - θ	10.0048k Ω	0.076 °		EXIT
2 ---	---	---		

F 4 Returns to the Adjust screen.

Verifying load compensation


NORM				ACT
Z	10.0030k Ω	θ	0.000 °	
Vac 988.7mV Iac 98.79mA				
FREQ	: 1.0000kHz	RANGE	: A 100k Ω	OPEN : OFF
V	: 1.000V	JSYNC	: OFF	
LIMIT	: OFF	TRIG	: EXT	LOAD : ON
				EXIT

- When load compensation is enabled under the set measurement conditions, the LOAD parameter on the **INFO** measurement conditions will turn on.
- If multiple load compensation conditions have been set with the same compensation frequency, the compensation conditions with the lowest compensation condition number will take effect.
- If the current measurement frequency does not match the compensation frequency, load compensation will not be performed.


6.3 Adjusting Values Based on Reference Values (Load Compensation)

Setting the compensation frequency.

1 Select **[FREQ.]**.



2 Enter the frequency to correct. **10KEY**



Unit : (none/k)


If you make a mistake:
Press **BACK SPACE** key and reenter the value.

- Settable range: DC, 40 Hz to 200 kHz
- If you set a frequency in excess of 200 kHz, the frequency will automatically revert to 200 kHz.
- If a frequency of less than 40 Hz is set, the value will be automatically changed to 40 Hz. However, very small values will cause the DC setting to be used.


6.3 Adjusting Values Based on Reference Values (Load Compensation)

Setting the Compensation Range

1 Select [RANGE].



2 Select the compensation range.



The ranges that can be selected vary with the frequency.

Frequency	Settable ranges	Range Setting screen
DC 40.000 Hz to 10.000 kHz	All range	
10.001 kHz to 100.00 kHz	100 mΩ to 10 MΩ	
100.01 kHz to 200.00 kHz	100 mΩ to 1 MΩ	

NOTE If the compensation frequency is not set, the compensation range cannot be set.

6.3 Adjusting Values Based on Reference Values (Load Compensation)

Setting of Compensation signal level measurement signal mode and value

1 Select the measurement signal mode.

LOAD No.1 GET RESET CANCEL

FREQ : 100.00kHz

RANGE : 100Ω

LEVEL : **V**

REF : ---

V

CV

CC

F 1

F 2

F 3

Open voltage (V) mode (p.39)

Constant voltage (CV) mode (p.39)

Constant current (CC) mode (p.39)

1

Select

2 Enter the compensation signal level voltage or current value. **DIGIT**

LOAD No.1 GET RESET CANCEL

FREQ : 100.00kHz

RANGE : 100Ω

LEVEL : V

MODE :

REF :

0.000V

▲

▼

F 1

F 2

Allows you to enter the voltage or current value.

1

Select

◀

▶

▶

Selects the digit to change.

AC Load Compensation	
V, CV	0.005 V to 5.000 V
CC	0.01 mA to 50 mA

DC Load Compensation	
V	2 V (fixed)

- NOTE**
- If the compensation range is not set, you will not be able to set the compensation signal level measurement mode and value.
 - DC load compensation cannot be performed because the open voltage (V) mode is fixed to 2 V.

Setting of Parameter to Use for Reference Value

1

Select [MODE].

LOAD No.1

GET

RESET

CANCEL

EDIT

F1

▶ Displays the Parameter Selection screen.

FREQ : 10.000kHz

RANGE : 100Ω

MODE : Z -θ

5.000V

SET

1

Select

2

Select the parameter mode.

LOAD No.1

GET

RESET

CANCEL

MODE

F4

▶ Accepts the set parameter mode.

FREQ

RANGE

MODE

LE

MO

RE

Z -θ

CS-D

CS-RS

CP-D

CP-RP

LS-Q

LS-RS

LP-Q

LP-RP

RS-X

SET

1

Select


NOTE

- Failure to configure the compensation frequency, compensation range, and compensation signal level settings will prevent you from setting the parameter to use as a reference value.
- When DC is selected for the compensation frequency setting, DC resistance measurement (Rdc) mode will be selected automatically, and you will not be able to set the parameter to use as a reference value.
- Changing the parameter to use as a reference value clears the reference value 1 and reference value 2 settings.


6.3 Adjusting Values Based on Reference Values (Load Compensation)

Setting the Reference Value

1 Select the parameter reference value you wish to set under [REF].



2 Enter the parameter reference values you wish to set and accept it with the **ENTER** key. **10KEY**




- NOTE**
- Failure to configure the compensation frequency, compensation range, and compensation signal level settings will prevent you from setting the parameter to use as a reference value.
 - If you select DC as the compensation frequency setting, you will only be able to set reference value 1.

6.3 Adjusting Values Based on Reference Values (Load Compensation)

When You Want to Use the Current Measurement Conditions as the Load Compensation Conditions


By selecting **[GET]**, you can acquire the current measurement conditions (frequency, range, measurement signal level measurement signal mode and value) as the load compensation conditions.




NOTE In the above example, loading the measurement conditions with GET causes MODE to be initialized to Z-θ.

When You Want to Reset All Settings

By selecting **[RESET]**, you can clear all settings and start again from the compensation frequency setting.




When you want to cancel the settings



When Load Compensation Failed

When compensation fails, a window such as the following will be displayed.

Press **[EXIT]** to close the window and set the compensation condition once again.



6.3 Adjusting Values Based on Reference Values (Load Compensation)

Enabling/disabling load compensation

1 Press the **ADJ** key while the Measurement screen is displayed to display the Adjust screen.

NOTE The **ADJ** key cannot be used on screens other than the Measurement screen.

2 Select **[LOAD]** on the Adjust screen.

ADJUST

OPEN :OFF

LOAD :OFF

SCALE :OFF

EDIT

EXIT

F 1

Displays the Edit screen.

ENTER

1

Select

3 Select **[TYPE]** on the load compensation Edit screen.

LOAD ADJUST:OFF

No Freq Ref1 Ref2

1 1.0000kHz 10.0000kΩ 0.000 *

2 -θ 10.0022kΩ 0.076 *

2 2.0000kHz 10.0000kΩ 0.000 *

2 -θ 10.0025kΩ 0.152 *

EXEC

TYPE

EXIT

F 3

Displays the Load Compensation Setting screen.

1

Select

4 Select **[ON]** or **[OFF]** for the load compensation setting.

LOAD ADJUST:ON

No. 1

LOAD

Select Adjust TYPE.

2

OFF

ON

EXIT

F 1

Disables load compensation.

F 2

Enables load compensation.

LOAD ADJUST:ON

No. 1

LOAD

Select Adjust TYPE.

2

OFF

ON

EXIT

F 4

Enables the load compensation setting and returns to the Edit screen.

6.4 Compensating Measurement Cable Errors(Cable Length Compensation)

During high-frequency measurement, the measurement errors caused by the influence of cables increase in magnitude. You can reduce these errors by configuring the instrument with the length of the cable. Use coaxial cable with an impedance of 50 Ω.

1 Press the **ADJ** key while the Measurement screen is displayed to display the Adjust screen.

NOTE The **ADJ** key cannot be used on screens other than the Measurement screen.

2 Select **[CABLE]** and select the cable length.

ADJUST

OPEN :OFF

SHORT :OFF

CABLE :0m

EXIT

2

F1

F2

1

Changes the cable length.

Select

0 m	Select when using a directly-connected fixture or similar setup.
1 m	Select when using a cable length of 1 m, 2 m, or 4 m.

ADJUST

OPEN :OFF

SHORT :OFF

LOAD :OFF

CABLE :1m

SCALE :OFF

EXIT

F4

Returns to the Measurement screen.

- NOTE**
- If the cable length changes, repeat open, short, and load compensation. The guaranteed accuracy range varies with the cable length.
[See](#) "Cable length coefficient E" (p.202)
 - When manufacturing your own cables, make sure that the cable length matches the length set with the instrument. (p.25)
 - When using the L2000, set cable length compensation to 1 m.

6.5 Converting Values (Scaling)

Scaling applies a compensation function to the measurement value. This function can be used to provide compatibility among measurement devices.

In scaling, the user-specified compensation coefficients a and b are applied to main and sub parameter measurement values using the following formula.

See "Appendix1 Measurement Parameters and Calculation formula"(p. A1)

$Y = a \times X + b$

However, when the parameter corresponding to X is D or Q, its value is calculated based on θ' , whose value is obtained by applying scaling to θ with the following equation:

$\theta' = a \times \theta + b$

- X : the first or third parameter measurement value
- a : integration value of the measured value X
- Y : the last measurement value
- b : the value added to measured value X
- θ' : compensation value of θ

- 1 Press the **ADJ** key while the Measurement screen is displayed to display the Adjust screen.

NOTE

The **ADJ** key cannot be used on screens other than the Measurement screen.

- 2 Select **[SCALE]** on the Adjust screen.

ADJUST

OPEN	:OFF
SHORT	:OFF
LOAD	:OFF
SCALE	:OFF

EDIT F1 ▶ Displays the Edit screen. ENTER

1 Select

- 3 Select **[TYPE]** on the scaling Edit screen.

SCALE ADJUST:OFF

PARAM	A	B
MAIN:	1.000	0.00000
SUB:	1.000	0.00000

TYPE F3 ▶ Displays the Scaling Compensation Setting screen.

- 4 Turn the scaling compensation setting **[ON]** or **[OFF]**.

SCALE ADJUST:OFF

PARAM SCALE


MAI Select Adjust TYPE.

SUE

OFF F1 ▶ Disables scaling compensation.

ON F2 ▶ Enables scaling compensation.


5



F 4 ➤ Enables scaling compensation and returns to the Edit screen.

6

Select the parameter you wish to change (compensation coefficient A).



F 1 ➤ Reverts to the default setting.




7

Enter a value for compensation coefficient A with the tenkey and accept it with the **ENTER** key. **10KEY**

Settable range:-999.999 to 999.999

Pressing ENTER while nothing is displayed will cause the instrument to return to the previous screen without changing the setting.



Unit:
(a/f/p/n/μ/m/none/k/M/G)

If you make a mistake:
Press **BACK SPACE** key and reenter the value.


NOTE

When entering a value for compensation coefficient A, the $\times 10^3$ $\div 10^3$ keys are disabled.

8

Enter a value for compensation coefficient B as you did for compensation coefficient A.


Settable range:-9.99999 G to 9.99999 G



F 1 ➤ Reverts to the default setting.



9



F 4 ➤ Returns to the Adjust screen.

NOTE

If you set the set the same parameter for the main and sub parameters with different compensation coefficients as shown below, scaling will be performed using the main parameter compensation coefficients. (The sub parameter compensation coefficients will be disabled.)

Display Parameter Setting	Compensation Coefficient Setting
MAIN Parameter:Z	a=1.500, b=1.50000
SUB Parameter:Z	a=1.700, b=2.50000

Saving and Reading Panel Information

Chapter 7

This chapter describes how to save to the instrument's internal memory and load data (measurement conditions and compensation values).

Saving Data

- Measurement conditions and compensation values (p.162)

Reading Data

- Measurement conditions and compensation values (p.165)

Editing Saved Data

- Change panel name (p.167)
- Delete panel (p.169)

About the Save Screen

Displays the currently selected save type. Displays the current number of saved panels. (p.165)

SAVE | **SAVE TYPE: ALL** | **LOR:00/60** | **SAVE** (F1) ▶ Displays the measurement conditions. (p.163)

No. | **PANEL NAME** | **TYPE** | **INFORMATION**

001 | ---- NO SAVE ---- | |

002 | ---- NO SAVE ---- | |

003 | ---- NO SAVE ---- | |

004 | ---- NO SAVE ---- | |

TYPE (F3) ▶ Sets the save type. (p.162)

EXIT

Indicates that nothing is saved.

Indicates the panel number. (001 to 128) Indicates the save type.(p.162) (ALL/HARD/ADJ)

No. | **PANEL NAME** | **TYPE** | **INFORMATION**

Indicates the panel name. See "Changing a panel name"(p.167) Indicates basic information on the saved panels.

Displayed parameter	Measurement mode
[MAIN]-[SUB]	[COMP] or [BIN]

7.1 Saving Measurement Conditions (Panel Save Function)

You can save the measurement condition and compensation value. The number of items for which compensation can be performed is as follows:


Measurement Condition ▶ Up to 60 items

Compensation Value ▶ Up to 128 items


However, each of the measurement condition and compensation value is counted as one save data item when saved with **ALL**.

Setting the Type to Save


- 1 Open the Advanced Settings screen.




- 2 Select the **[ADVANCED2]** tab.




- 3 Select **[PANEL SAVE]**.



- 4 Select **[TYPE]**.




- 5 Select the type of data to save.




- 6
-
- Returns to the PANEL SAVE screen.

Saving Measurement Conditions


- 1 Select the panel number to save.
Display range: No.001 to No.128



- 2 Select [SAVE].




- 3 Save the panel.



When [NAME] is selected

Changes the panel's name.


Enter a name for the panel (up to 10 characters).



- If you make a mistake while entering the name:
Delete the previous character with **BACK SPACE** key.
- The name will not be accepted until you press **ENTER** key.

NOTE

If you attempt to save the panel under the same name as a previously saved panel, a window confirming that you wish to overwrite the existing data will be displayed.



7.1 Saving Measurement Conditions (Panel Save Function)

4

SAVE	SAVE TYPE:HARD	LCR:03/60	LEAVE
No.	PANEL NAME	TYPE	INFORMATION
001	HIOKI	HARD	Z- 0
002	NEW_PANEL	ALL	Z-Rdc
003	NEW_PANEL	ADJ	
004	NEW_PANEL	HARD	Cs- 0

VIEW

F 2

EXIT

F 4

► Checks the contents of the panel to be saved.

► Returns to the ADVANCED setting screen.

When [VIEW] is selected

You can check the contents of previously saved panels, delete panels, and change panel names.

AC1 ◀▶ AC2 ◀▶ DC

↑

◀▶

VIEW	No.001 [HIOKI]	AC
PARA :	Z- 0	JUDGE:OFF
FREQ :	1.0000kHz	RANGE:A 100MΩ
V :	1.000V	JSYNC:OFF
LIMIT:OFF	TRIG : INT	

DEL

F 1

NAME

F 2

EXIT

F 4

► Deletes the panel.

► Changes the panel's name.

► Returns to the PANEL SAVE screen.

◀▶

◀▶

► Switches to the Panel Information screen. (p.20)


7.2 Reading Measurement Conditions (Panel Load Function)

You can read saved measurement conditions with the panel load function.


- 1 Press the **PANEL LOAD** key while the Measurement screen is displayed to display the PANEL LOAD screen.

NOTE The **PANEL LOAD** key cannot be used on screens other than the Measurement screen.

- 2 Select the number of the panel to load.
Display range:No.001 to No.128




- 3 Load the measurement conditions for the selected panel number.



When [VIEW] is selected

You can check the contents of previously saved panels, delete panels, and change panel names.



7.2 Reading Measurement Conditions (Panel Load Function)

4 Load the panel.

AC1

AC2

DC

YES

F 1

NO

F 4

Loads the measurement conditions for the selected panel number. After loading the panel, automatically returns to the Measurement screen.

Cancels the load operation and returns to the previous screen.

Switches to the Panel Information screen. (p.20)

5 Verify that the panel was loaded.

No. 001

10.0051kΩ

-0.012

Vac 1.068 V

Iac 106.8mA


1.0000kHz : V : 1.000V : R : 100kΩ : MED : INT :

If the panel has been loaded, the loaded panel number will be displayed on the measurement screen.


7.3 Changing a Panel Name

You can change the name of a panel saved to the instrument.


- 1 Open the Advanced Settings screen.




- 2 Select the **[ADVANCED2]** tab.




- 3 Select **[PANEL SAVE]**.



- 4 Select the panel whose name you wish to change.



- 5 Check the panel's contents and select **[NAME]**.



7.3 Changing a Panel Name

6 Change the panel's name.

Enter a name for the panel (up to 10 characters).

RENAME

Please input PANEL name.

ABCDEF G 789

HIJKLMN 456

OPQRSTU 123

VWXYZ _ 0+-

NEW PANEL

SET

F 1

CANCL

F 4

Changes the panel's name.

Cancels the change operation and returns to the previous screen.

- If you make a mistake while entering the name:
Delete the previous character with **BACK SPACE** key.
 - The name will not be accepted until you press **ENTER** key.
- ◀

▲

▶

▼

Select

► Selects a character.

7 The panel's name will be changed, and the saved contents will be displayed.

VIEW

No.002 [DATA_1]

AC1

DEL

NAME

EXIT


F 4

Returns to the Panel Save screen.


7.4 Deleting a Panel

You can delete a panel saved to the instrument.


- 1 Open the Advanced Settings screen.




- 2 Select the **[ADVANCED2]** tab.




- 3 Select **[PANEL SAVE]**.



- 4 Select the panel you wish to delete.



- 5 Check the panel's contents and select **[DEL]**.



7.4 Deleting a Panel

6 Select **[YES]** on the Delete Confirmation screen.

VIEW

No.002 [NEW_PANEL]

AC

DELETE

⚠ Delete this Panel OK?

YES

NO

F 1

▶ Deletes the panel.

F 4

▶ Returns to the View screen without deleting the panel.

7

SAVE

SAVE TYPE:HARD

LCR:02/60

SAVE

No.	PANEL NAME	TYPE	INFORMATION
001	HIOKI	HARD	Z- 0
002	----- NO SAVE -----		
003	NEW_PANEL	ADJ	
004	NEW_PANEL	HARD	Cs- 0

TYPE

EXIT

F 4

▶ Returns to the Advanced Settings screen.


Setting the SYSTEM

Chapter 8


8.1 Setting the Interface

You can control the instrument from a computer via the USB or LAN interfaces.

1 Open the System screen.



2 Select the [I/F] tab, and then select [KIND].
The available interfaces are displayed. Select an interface to be used by pressing a corresponding F key.




3


I/F INFO TEST
IM3523A LCR METER
S/N : 123456789 S/W : 1.00
FPGA:0x5
USB : 108f 0001
MAC : 00-01-67-03-26-39
EXIT

8.2 Checking the Version of the Instrument

1 Open the System screen.



2 Select [INFO] and check the device information.(p. 18)



3


SCREEN 3: I/F, INFO, TEST. Device info: IM3523A LCR METER, S/N : 123456789, S/W : 1.00, FPGA: 0x5, USB : 108f 0001, MAC : 00-01-67-03-26-39, EXIT (highlighted), F 4. Description: Returns to the Measurement screen.

8.3 Self Checks (Self Diagnosis)


Key Test

The key test allows you to verify whether the instrument's keys are functioning properly.


- 1 Open the System screen.




- 2 Select the **[TEST]** tab.




- 3 Select **[KEY TEST]**.



- 4 Press the rubber keys to perform the key test.
Verify that the key on the screen corresponding to the key you pressed is shown in reverse video.



- 5




8.3 Self Checks (Self Diagnosis)


Screen Display Test

Check the display state of the screen and lighting state of the LEDs.


- 1 Open the System screen.




- 2 Select the **[TEST]** tab.



- 3 Select **[DISPLAY&LED TEST]**.




Each time you press **ENTER**, the screen and the LEDs on the front of the instrument will cycle on and off in the following order:



If the entire screen is not the same color or an LED fails to light up, the instrument needs to be repaired. Contact your dealer or Hioki representative.


- 4




ROM/RAM Test

Check the internal memory (ROM and RAM) of the instrument.


- 1 Open the System screen.



- 2 Select the **[TEST]** tab.




- 3 Select **[ROM/RAM TEST]**.
 - Selecting EXEC will cause the test to start automatically. (Approx. 40 seconds)
 - No operation is possible during the ROM/RAM test.




CAUTION

Never turn off the power during a test.

- 4 Check the ROM/RAM test judgment results.
If any of the judgment results are [NG], the instrument needs to be repaired. Contact your dealer or Hioki representative.



- 5




8.3 Self Checks (Self Diagnosis)


I/O Test

Check whether an output signal is output normally from the EXT I/O, and whether an input signal is read normally.


1 Open the System screen.




2 Select the [TEST] tab.




3 Select [I/O HANDLER TEST].



4 Perform the output signal test and input signal test.



5



External Control Chapter 9


The EXT I/O connector on the back of the instrument can be used to output measurement complete, judgment result, and other signals and to control the instrument by inputting measurement trigger, panel load, and other signals.

All signals are isolated. (The common pin [ISO_COM pin] is used for both input and output.)

Confirm input and output ratings, understand the safety precautions for connecting a control system, and use accordingly.

Connect the instrument's EXT I/O connector to the signal output or input device.

Make instrument settings



Signal input/output

9.1 External Input/Output Connector and Signals

! WARNING

To avoid electric shock or damage to the equipment, always observe the following precautions when connecting to the EXT I/O connector.

- Always turn off the power to the instrument and to any devices to be connected before making connections.
- Be careful to avoid exceeding the ratings of external terminals.(p.189)
- During operation, a wire becoming dislocated and contacting another conductive object can be serious hazard. Make sure that connections are secure and use screws to secure the external connectors.
- Properly insulate any devices and mechanisms to be connected to the EXT I/O connector.
- The ISO_5 V pin of the EXT I/O connector is a 5 V power output. Do not apply external power to this pin.

! CAUTION

To avoid damage to the instrument, observe the following cautions:


- Do not apply voltage or current to the EXT I/O terminals that exceeds their ratings.
- When driving relays, be sure to install diodes to absorb counter-electromotive force.
- Be careful not to short-circuit ISO_5V to ISO_COM.

See "Connector Type and Signal pin assignments" (p.178)

9.1 External Input/Output Connector and Signals


Connector Type and Signal pin assignments

Rear




- Connector: (Instrument Side)**
- 37-pin D-sub female with #4-40 screws
- Mating Connectors:**
- DC-37P-ULR (solder type)
 - DCSP-JB37PR (pressure weld type)
- Japan Aviation Electronics Industry Ltd.

LCR Mode



Continuous Measurement Mode



EXT I/O Connector (Instrument Side)

NOTE The connector shell is conductively connected to the metal instrument chassis and the protective earth pin of the power plug. Be aware that it is not isolated from ground.

9.1 External Input/Output Connector and Signals

LCR Mode

Pin	I/O	Signal name			Function	Logic	
		Common	COMP	BIN			
1	IN	TRIG			External trigger(p.184)	Positive/negative	Edge
2	—	(Unused)			—	—	—
3	—	(Unused)			—	—	—
4	IN	LD1			Select panel number(p.184)	Neg	Level
5	IN	LD3			Select panel number(p.184)	Neg	Level
6	IN	LD5			Select panel number(p.184)	Neg	Level
7	—	(Unused)			—	—	—
8	—	ISO_5V			Isolated 5 V power output	—	—
9	—	ISO_COM			Isolated common signal ground	—	—
10	OUT	ERR			Outputs when a sampling error, contact error, HiZ reject error, constant voltage/constant current error, or voltage/current limit value exceeded error occurs.	Neg	Level
11	OUT		MAIN-HI		HI comparator judgment results for main parameters.	Neg	Level
				BIN1	Generates output when the BIN measurement result is BIN1.		
12	OUT		MAIN-LO		LO comparator judgment results for main parameters.	Neg	Level
				BIN3	Generates output when the BIN measurement result is BIN3.		
13	OUT		SUB-IN		IN comparator judgment results for sub parameters.	Neg	Level
				BIN5	Generates output when the BIN measurement result is BIN5.		
14	OUT		AND		Outputs an AND operation of judgment results of main and sub parameters. Generates output when both judgment results are IN. Additionally, generates output when either of the main or sub parameters is IN and the other is undetermined.	Neg	Level
				BIN7	Generates output when the BIN measurement result is BIN7.		
15	OUT			BIN9	Generates output when the BIN measurement result is BIN9.	Neg	Level
16	—	(Unused)			—	—	—
17	—	(Unused)			—	—	—
18	—	(Unused)			—	—	—
19	OUT			OUT	BIN judgment results OUT	Neg	Level
20	—	(Unused)			—	—	—
21	—	(Unused)			—	—	—
22	IN	LD0			Select panel number (p.184)	Neg	Level
23	IN	LD2			Select panel number (p.184)	Neg	Level
24	IN	LD4			Select panel number (p.184)	Neg	Level
25	IN	LD6			Select panel number (p.184)	Neg	Level
26	IN	LD_VALID			Execute panel load (p.184)	Neg	Level
27	—	ISO_COM			Isolated common signal ground	—	—
28	OUT	EOM			Measurement complete signal: When this signal is output, the comparator judgment results have been finalized.	Neg	Edge
29	OUT	INDEX			Signal indicating that A/D conversion for the measurement circuit has completed: When this signal changes from high (off) to low (on), the sample may be changed.	Neg	Edge

9.1 External Input/Output Connector and Signals

LCR Mode

Pin	I/O	Signal name			Function	Logic	
		Common	COMP	BIN			
30	OUT		MAIN-IN		Outputs BIN judgment results and IN comparator judgment results for main parameters.	Neg	Level
				BIN2	Generates output when the BIN measurement result is BIN2.		
31	OUT		SUB-HI		HI comparator judgment results for sub parameters.	Neg	Level
				BIN4	Generates output when the BIN measurement result is BIN4.		
32	OUT		SUB-LO		LO comparator judgment results for sub parameters.	Neg	Level
				BIN6	Generates output when the BIN measurement result is BIN6.		
33	OUT			BIN8	Generates output when the BIN measurement result is BIN8.	Neg	Level
34	OUT			BIN10	Generates output when the BIN measurement result is BIN10.	Neg	Level
35	–	(Unused)			–	–	–
36	–	(Unused)			–	–	–
37	OUT			SUBNG	Outputs a fail BIN judgment for sub parameters.	Neg	Level

Continuous measurement mode

Pin	I/O	Signal name	Function	Logic	
1	IN	TRIG	External trigger(p.184)	Positive/ negative	Edge
2	—	(Unused)	—	—	—
3	—	(Unused)	—	—	—
4	—	(Unused)	—	—	—
5	—	(Unused)	—	—	—
6	—	(Unused)	—	—	—
7	—	(Unused)	—	—	—
8	—	ISO_5V	Isolated 5 V power output	—	—
9	—	ISO_COM	Isolated common signal ground	—	—
10	OUT	ERR	Outputs when a sampling error, contact error, HiZ reject error, constant voltage/constant current error, or voltage/current limit value exceeded error occurs.	Neg	Level
11	OUT	No.1_MAIN-HI	Outputs HI comparator judgment results for the No. 1 main parameter.	Neg	Level
12	OUT	No.1_MAIN-LO	Outputs LO comparator judgment results for the No. 1 main parameter.	Neg	Level
13	OUT	No.1_SUB-IN	Outputs IN comparator judgment results for the No. 1 sub parameter.	Neg	Level
14	OUT	AND	Outputs when all panel judgments are IN and the instrument is not OUT_OF_BINS.	Neg	Level
15	OUT	No.2_MAIN-IN	Outputs IN comparator judgment results for the No. 2 main parameter.	Neg	Level
16	OUT	No.2_SUB-HI	Outputs HI comparator judgment results for the No. 2 sub parameter.	Neg	Level
17	OUT	No.2_SUB-LO	Outputs LO comparator judgment results for the No. 2 sub parameter.	Neg	Level
18	—	(Unused)	—	—	—
19	—	(Unused)	—	—	—
20	—	(Unused)	—	—	—
21	—	(Unused)	—	—	—
22	—	(Unused)	—	—	—
23	—	(Unused)	—	—	—
24	—	(Unused)	—	—	—
25	—	(Unused)	—	—	—
26	—	(Unused)	—	—	—
27	—	ISO_COM	Isolated common signal ground	—	—
28	OUT	EOM	Measurement complete signal: When this signal is output, the comparator judgment results have been finalized.	Neg	Edge
29	OUT	INDEX	Signal indicating that A/D conversion for the measurement circuit has completed: When this signal changes from high (off) to low (on), the sample may be changed.	Neg	Edge
30	OUT	No.1_MAIN-IN	Outputs IN comparator judgment results for the No. 1 main parameter.	Neg	Level
31	OUT	No.1_SUB-HI	Outputs HI comparator judgment results for the No. 1 sub parameter.	Neg	Level
32	OUT	No.1_SUB-LO	Outputs LO comparator judgment results for the No. 1 sub parameter.	Neg	Level
33	OUT	No.2_MAIN-HI	Outputs HI comparator judgment results for the No. 2 main parameter.	Neg	Level
34	OUT	No.2_MAIN-LO	Outputs LO comparator judgment results for the No. 2 main parameter.	Neg	Level
35	OUT	No.2_SUB-IN	Outputs IN comparator judgment results for the No. 2 sub parameter.	Neg	Level
36	—	(Unused)	—	—	—
37	—	(Unused)	—	—	—

9.1 External Input/Output Connector and Signals

Signal Descriptions

You can select rising or falling for the valid edge of a trigger.

See "4.5.4 Enabling Trigger Input for during Measurement and Setting the Valid Edge of Trigger Input" (p.101)

Input

TRIG	- When the trigger is set to external trigger [EXT], one measurement is performed at the TRIG signal's falling edge (on) or rising edge (off). The edge direction can be set on the Settings screen. (Default value: Falling edge [on]) See "Enabling Trigger Input for during Measurement" (p.191) - When the trigger source is set to the internal trigger [INT], trigger measurement is not performed. - You can set whether to enable or disable TRIG signal input during measurement (while outputting the EOM signal [high]). See "4.5.4 Enabling Trigger Input for during Measurement and Setting the Valid Edge of Trigger Input" (p.101)																																																																																
LD0 to LD6	Selects the number of the panel to load. If a trigger signal is input in external trigger mode, the selected panel is loaded and used for measurement. 0 : (HIGH: 5 V to 24 V), 1 : (LOW: 0 V to 0.9 V) <table><tr><th>PIN No.</th><th>LD6</th><th>LD5</th><th>LD4</th><th>LD3</th><th>LD2</th><th>LD1</th><th>LD0</th></tr><tr><td>Panel 1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td></tr><tr><td>Panel 2</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td></tr><tr><td>Panel 4</td><td>0</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td></tr><tr><td>Panel 8</td><td>0</td><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td></tr><tr><td>Panel 16</td><td>0</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>Panel 32</td><td>0</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>Panel 64</td><td>1</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr><tr><td>Panel 127</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td><td>1</td></tr><tr><td>Panel 128</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td><td>0</td></tr></table>	PIN No.	LD6	LD5	LD4	LD3	LD2	LD1	LD0	Panel 1	0	0	0	0	0	0	1	Panel 2	0	0	0	0	0	1	0	Panel 4	0	0	0	0	1	0	0	Panel 8	0	0	0	1	0	0	0	Panel 16	0	0	1	0	0	0	0	Panel 32	0	1	0	0	0	0	0	Panel 64	1	0	0	0	0	0	0	Panel 127	1	1	1	1	1	1	1	Panel 128	0	0	0	0	0	0	0
PIN No.	LD6	LD5	LD4	LD3	LD2	LD1	LD0																																																																										
Panel 1	0	0	0	0	0	0	1																																																																										
Panel 2	0	0	0	0	0	1	0																																																																										
Panel 4	0	0	0	0	1	0	0																																																																										
Panel 8	0	0	0	1	0	0	0																																																																										
Panel 16	0	0	1	0	0	0	0																																																																										
Panel 32	0	1	0	0	0	0	0																																																																										
Panel 64	1	0	0	0	0	0	0																																																																										
Panel 127	1	1	1	1	1	1	1																																																																										
Panel 128	0	0	0	0	0	0	0																																																																										
LD-VALID	Inputs a negative logic signal from an external device so that the selected panel number is recognized as valid. After TRIG input, maintain a Low level until INDEX is outputted.																																																																																

9.1 External Input/Output Connector and Signals

Error output

Priority Order	Measurement Error	Error Display	ERR No. 10 Pin *4	Comparator Measurement		BIN Measurement	
				Logical Product AND No. 14 Pin	Each Parameter Judgment Result Pin Nos. 11, 12, 13, 30, 31, and 32	BIN1 to BIN10, Pin Nos. 11 to 15 and 30 to 34	OUT_OF_BINS Pin No. 19
High ↑	Sampling error	SAMPLE ERR	LOW	HI	HI	HI	LOW
	H and L side contact errors (after measurement)	NC A HL	LOW	HI	LCR: 11, 31*1	HI	LOW
	L side contact error (after measurement)	NC A L	LOW	HI	LCR: 11, 31*1	HI	LOW
	H side contact error (after measurement)	NC A H	LOW	HI	LCR: 11, 31*1	HI	LOW
	H and L side contact errors (before measurement)	NC B HL	LOW	HI	LCR: 11, 31*1	HI	LOW
	L side contact error (before measurement)	NC B L	LOW	HI	LCR: 11, 31*1	HI	LOW
	H side contact error (before measurement)	NC B H	LOW	HI	LCR: 11, 31*1	HI	LOW
	Underflow	UNDERFLOW	HI	HI	LCR: 12, 32*1, 2	HI	LOW
	Overflow	OVERFLOW	HI	HI	LCR: 11, 31*1, 3	HI	LOW
	Outside of HI Z reject limit range	Hi Z	LOW	Normal judgment	Normal judgment	Normal judgment	Normal judgment
	Outside display range*4	DISP OUT	HI	Normal judgment	Normal judgment	Normal judgment	Normal judgment
	Outside of guaranteed accuracy range	REF VAL	HI	Normal judgment	Normal judgment	Normal judgment	Normal judgment
	Normal	measurement value	HI	Normal judgment	Normal judgment	Normal judgment	Normal judgment
	No measurement after power turned on		HI	HI	HI	HI	HI
Low							

*1 Indicates the pin numbers that will be the LOW level.

*2 LCR 11 and 31 will be LOW when the parameters are Y, Cs, G, and B.

*3 LCR 12 and 32 will be LOW when the parameters are Y, Cs, G, and B.

*4 LOW will be output if even one error occurs.

9.2 Timing Chart


9.2.1 LCR Measurement

If you set the judgment condition for the comparator (the trigger setting is external trigger) and then in that state a trigger signal is input from the EXT I/O or **TRIG** is pressed, the judgment result is output from the signal line for comparator result output of the EXT I/O after measurement ends.

Furthermore, if the panel number is selected with the panel load signal when a trigger signal is input from the EXT I/O, the measurement condition of that panel number is loaded and then measurement is performed.

The following shows examples of the measurement timing.

(In the timing examples, the valid edge of the TRIG signal is set to falling (ON).)



*1 MAIN-HI, MAIN-IN, MAIN-LO, SUB-HI, SUB-IN, SUB-LO, AND BINx, OUT, SUBNG

*2 Reset at EOM (HIGH) : HIGH

Do not reset at EOM (HIGH) : Last judgment result remains

NOTE

Whether the judgment results of comparator measurement are reset at EOM (HIGH) or updated at the point in time when measurement ends can be selected on the instrument or by a communication command.

See "4.5.3 Setting the Delay Time from the Output of Comparator and BIN Judgment Results until Output of EOM (LOW) and Resetting Judgment Results" (p.100) Communications commands in the included LCR Application Disk documentation (:IO:RESult:RESet)

Timing Chart Interval Descriptions

Interval	Description	Time(Approximate)
t1	From Comparator, BIN Judgement Result to EOM (LOW): Setting value for delay time ^{*1}	40 μ s
t2	From EOM width (LOW) to TRIG (LOW): Minimum time from end of measurement to next trigger ^{*2}	400 μ s
t3	From TRIG(LOW) to INDEX (HIGH) : Time from trigger to circuit response ^{*3}	600 μ s
t4	INDEX width (HIGH) : Minimum chuck time, switching chuck with INDEX (LOW) is possible ^{*4}	1 ms
t5	EOM width (HIGH) : Measurement time ^{*4}	2 ms
t6	From TRIG width (LOW) to LD-VALID (HIGH): Time to recognize panel number	t3
t7	Trigger pulse width (LOW time)	100 μ s or more
t8	Trigger OFF (HI time)	100 μ s or more

*1: There is an approximate error of 100 μ s in the delay time entered for Judgement Result $\Leftrightarrow$ EOM for the setting value.

t1 is the reference value for when the setting value is 0.0000 s.

*2: t2 is the reference value for when trigger input for during measurement is disabled.(p.101)

*3: When the panel number is read by the panel load function, the response time is as shown in the table below.

Measurement mode	Load mode	Response time
LCR	LCR+ADJ	10 ms
	HARD	9 ms
	ADJ	4 ms

When the trigger synchronous output function and trigger delay is enabled, wait times are included.

*4: Reference value for Measurement frequency: 1 kHz, Measurement speed: FAST, Measurement range: HOLD.(p.208)

- NOTE** • Since the speed of the rise (LOW $\rightarrow$ HIGH) of the comparator/BIN judgment result differs depending on the configuration of the circuit connected to the EXT I/O, there is the likelihood of an incorrect judgment if the level of the comparator/BIN judgment result acquired immediately after EOM output is used. To prevent this from happening, a delay time (t1) between the comparator/BIN judgment result and the EOM can be set. Furthermore, if the judgment result signal line of the EXT I/O is set to be reset simultaneously with the measurement start signal, and a forced transition to the HIGH level is performed at the same time as TRIG, the transition from LOW to HIGH does not occur when the judgment result is output after measurement ends. As a result, the delay time between the judgment result and the EOM can be set to the minimum level. However, be careful because the judgment result confirmation interval is until the next trigger is accepted.
- During measurement, a trigger input from EXT I/O or communicating by interface may lead to a bigger dispersion of delay time between comparator or BIN judgement result output and EOM. As far as possible, try not to control from external sources when carrying out measurement.

See "4.5.3 Setting the Delay Time from the Output of Comparator and BIN Judgment Results until Output of EOM (LOW) and Resetting Judgment Results" (p.100)

See "4.5.4 Enabling Trigger Input for during Measurement and Setting the Valid Edge of Trigger Input" (p.101)

Communications commands in the included LCR Application Disk documentation
 (:IO:OUTPut:DElay)
 (:IO:RESult:RESet)

9.2 Timing Chart

NOTE The shorter the measurement time, the shorter the time that INDEX and EOM are high (off). When the high (off) time is too short due to characteristics of the input circuit, the instrument can be configured to maintain the low (on) state for a preset time once EOM changes to low (on) before reverting the signal to high (off) after the completion of measurement.

When trigger input is received at EOM:LOW and INDEX:LOW, the signal transitions to high (off) when measurement starts.

Setting the INDEX and EOM output method


See "4.5.5 Setting the EOM Output Method" (p.102)

Communications commands in the included LCR Application Disk documentation(: **IO:EOM:MODE**)

Setting the pulse width for which low (on) EOM is held

See "4.5.5 Setting the EOM Output Method" (p.102)

Communications commands in the included LCR Application Disk documentation(: **IO:EOM:PULSE**)




9.2.2 Continuous Measurement

With continuous measurement, if a trigger signal is input from the EXT I/O or **TRIG** is pressed, after measurement of all of the panel numbers set to be executed on the screen is finished, the main and sub parameter judgment results will be output from the EXT I/O comparator result output signal lines. The following shows examples of the measurement timing.

(In the timing examples, the valid edge of the TRIG signal is set to falling (ON).)

Example: Continuous measurement using panel numbers 1 and 3.

CONT >> BASIC					EXEC:2/2	OFF
No.	EXEC	PANEL NAME	MODE	PARA		ON
001	ON	NEW_PANEL	ALL	Z- 0		INFO
002	OFF	NEW_PANEL	ALL	Z- 0		EXIT
003	ON	NEW_PANEL	ALL	Z- 0		
004	OFF	NEW_PANEL	ALL	Z- 0		



*1 No.x_MAIN-HI, No.x_MAIN-IN, No.x_MAIN-LO, No.x_SUB-HI, No.x_SUB-IN, No.x_SUB-LO, AND

*2 Reset at EOM (HIGH) : HIGH

Do not reset at EOM (HIGH) : Last judgment result remains

Signal line	Description
INDEX, EOM	For both INDEX and EOM, a transition to HIGH is performed when the first panel measurement starts after the trigger signal is input, and a transition to LOW is performed after measurement of the last panel is finished and the judgment result has been output. (The HIGH level is maintained during continuous measurement.)
AND	When the judgment results of all panels are IN, LOW is output.

NOTE

• In the continuous measurement screen, comparator result output signals other than AND and panel load signals (LD-VALID, LD0 to LD6) cannot be used.

See "Chapter 5 Continuous Measurement Function" (p.119)


• Whether the judgment results of comparator measurement are reset at EOM (HIGH) or updated at the point in time when measurement ends can be selected on the instrument or by a communication command.

See "4.5.3 Setting the Delay Time from the Output of Comparator and BIN Judgment Results until Output of EOM (LOW) and Resetting Judgment Results" (p.100)
Communications commands in the included LCR Application Disk documentation
(**:IO:RESult:RESet**)


• For other timing chart times, refer to "9.2.1 LCR Measurement" (p.184).

9.3 Internal Circuitry

Input Circuit



Output Circuit







Electrical Specifications







Connector used	D-sub 37-pin female, #4-40 locking screw	
Input Signals	Isolated non-voltage contact input (current sink output compatible) (active low)	
	Input ON voltage	1 V or less
	Input OFF voltage	Open or 5 V to 24 V
	Input ON current	3 mA/channel
	Maximum applied voltage	30 V
Output Signals	Isolated NPN open-drain output (current sink) (active low)	
	Maximum load voltage	30 V
	Residual voltage	1 V or less (10 mA), 1.5 V or less (50 mA)
	Maximum output current	50 mA/channel
Power output	Output voltage	5.0 V $\pm$ 10%
	Maximum output current	100 mA
	Isolation	Protective ground potential and isolated measurement circuit
	Line-to-ground voltage	50 V DC, 30 V rms AC, 42.4 V peak AC or less

Connection Examples

Input Circuit Connection Examples



Output Circuit Connection Examples



9.4 External I/O Settings

There are the following setting items for the output timing of the judgment result output signal and the logic of the trigger signal.

Setting Delay Time from Output of Comparator and BIN Judgment Results until Output of EOM (LOW)

The delay time for the period from the output of the comparator and BIN judgment results until the output of EOM (LOW) from the EXT I/O can be set on the instrument or by a communication command.

See "4.5.3 Setting the Delay Time from the Output of Comparator and BIN Judgment Results until Output of EOM (LOW) and Resetting Judgment Results" (p.100)

Communications commands in the included LCR Application Disk documentation
(**:IO:OUTPut:DELaY**)

Setting Reset of Judgment Results

Whether to reset the comparator and BIN judgment results simultaneously with the measurement start signal can be selected on the instrument or by a communication command.

See "4.5.3 Setting the Delay Time from the Output of Comparator and BIN Judgment Results until Output of EOM (LOW) and Resetting Judgment Results" (p.100)

Communications commands in the included LCR Application Disk documentation
(**:IO:RESult:RESet**)

Enabling Trigger Input for during Measurement

Whether to enable or disable trigger input from the EXT I/O during measurement (during EOM (HI) output) can be selected on the instrument or by a communication command.

See "4.5.4 Enabling Trigger Input for during Measurement and Setting the Valid Edge of Trigger Input" (p.101)

Communications commands in the included LCR Application Disk documentation
(**:IO:TRIGger:ENABle**)

Setting Valid Edge of Trigger Input

Either the rising edge or falling edge can be selected as the valid edge of trigger input from the EXT I/O.

See "4.5.4 Enabling Trigger Input for during Measurement and Setting the Valid Edge of Trigger Input" (p.101)

Communications commands in the included LCR Application Disk documentation
(**:IO:TRIGger:EDGE**)

9.5 External Control Q&A

Common Questions	Answers
How do I connect external trigger input?	Connect the (active low) TRIG input pin to an ISO_COM pin using a switch or open-collector output.
Which pins are common ground for input and output signals?	The ISO_COM pins.
Are the common (signal ground) pins shared by both inputs and outputs?	Both common ground pins can be shared by inputs and outputs.
How do I confirm output signals?	Confirm voltage waveforms with a recorder or an oscilloscope. To do this, the output pins such as EOM and comparator decision outputs need to be pulled up (through several kΩ).
How do I troubleshoot input (control) signal issues?	For example, if triggering does not operate properly, bypass the PLC and short the TRIG pin directly to an ISO_COM pin. Be careful to avoid power shorts.
Are the comparator decision signals retained during measurement (or can they be off)?	They are initially set to be confirmed at the end of measurement and turned OFF when measurement starts. However, it is possible to change the settings so that the judgment results from last time are also stored during measurement. See "Setting Reset of Judgment Results" (p.191)
When are measurement error signals displayed?	An error is displayed in the following cases. • When sampling error • When constant voltage/constant current error • When voltage/current limit value exceeded error • When contact check error in low Z high accuracy mode • When HIGH-Z reject error
Is a connector or flat cable for connection provided?	A connector and cable are not supplied, so you need to provide them yourself.
Is direct connection to a PLC possible?	Direct connection is supported for relay or open-collector outputs and positive-ground optocoupler inputs. (Before connecting, confirm that voltage and current ratings will not be exceeded.)
Can external I/O be used at the same time as LAN or USB communications?	After setting up communications, it is possible to control measurement with the TRIG signal while acquiring measurement data via a communications interface.
How should external power be connected?	The instrument's external I/O input and output signals all operate from an internal isolated power source, so power must not be supplied from the PLC side.

9.6 Measurement Using a Computer

You can control the instrument with communication commands from a computer via the USB or LAN interfaces.

To enable communication, the communication conditions need to be set on the instrument.

For details on the communication condition settings, refer to "8.1 Setting the Interface" (p.171) .

For the details on the communication control procedure, refer to the supplied Communication Instruction Manual (LCR Application Disk).

CAUTION

- To avoid damage, do not disconnect the communications cable while the instrument is sending or receiving data.
- Use a common ground for both the instrument and the computer. Grounding them to different ground points will result in a potential difference between the instrument's ground and the computer's ground. If the communications cable is connected while such a potential difference exists, it may result in equipment malfunction or failure.
- Before connecting or disconnecting any communications cable, always turn off the instrument and the computer. Failure to do so could result in equipment malfunction or damage.
- After connecting the communications cable, tighten the screws on the connector securely. Failure to secure the connector could result in equipment malfunction or damage.
- When connecting the instrument to your LAN using a LAN cable of more than 30 m or with the cable laid outdoors, take appropriate countermeasures that include installing a surge protector for LANs. Such signal wiring is susceptible to induced lighting, which can cause damage to the instrument.

Specifications Chapter 10

All AC voltage and AC current values are rms values

10.1 General Specifications

1. Basic Specifications

Measurement mode	(1) LCR mode: Measurement with single condition (2) Continuous Measurement Mode: Continuous measurement using saved conditions (up to 2 sets)																						
Measurement items	Z (Impedance), Y (Admittance), θ (Phase angle), Rs (Equivalent series resistance (ESR)), Rp (Equivalent parallel resistance), X (Reactance), G (Conductance), B (Susceptance), Ls (Equivalent series inductance), Lp (Equivalent parallel inductance), Cs (Equivalent series capacitance), Cp (Equivalent parallel capacitance), Q (Q factor), D (Loss coefficient $\tan\delta$), Rdc (DC resistance)																						
Display range	<table border="1"> <thead> <tr> <th>Parameter</th><th>Display range (6 digits)</th></tr> </thead> <tbody> <tr> <td>Z</td><td>0.00 mΩ to 9.99999 GΩ</td></tr> <tr> <td>Y</td><td>0.000 nS to 9.99999 GS</td></tr> <tr> <td>θ</td><td>$\pm(0.000^\circ$ to $999.999^\circ)$</td></tr> <tr> <td>Rs, Rp, X, Rdc</td><td>$\pm(0.00$ mΩ to 9.99999 G$\Omega)$</td></tr> <tr> <td>G, B</td><td>$\pm(0.000$ nS to 9.99999 GS)</td></tr> <tr> <td>Cs, Cp</td><td>$\pm(0.0000$ pF to 9.99999 GF)</td></tr> <tr> <td>Ls, Lp</td><td>$\pm(0.00000$ μH to 9.99999 GH)</td></tr> <tr> <td>D</td><td>$\pm(0.00000$ to $9.99999)$</td></tr> <tr> <td>Q</td><td>$\pm(0.00$ to $99999.9)$</td></tr> <tr> <td>$\Delta\%$</td><td>$\pm(0.000\%$ to $999.999\%)$</td></tr> </tbody> </table> If the upper limit is exceeded, the display will indicate [DISP OUT].	Parameter	Display range (6 digits)	Z	0.00 m Ω to 9.99999 G Ω	Y	0.000 nS to 9.99999 GS	θ	$\pm(0.000^\circ$ to $999.999^\circ)$	Rs, Rp, X, Rdc	$\pm(0.00$ m Ω to 9.99999 G $\Omega)$	G, B	$\pm(0.000$ nS to 9.99999 GS)	Cs, Cp	$\pm(0.0000$ pF to 9.99999 GF)	Ls, Lp	$\pm(0.00000$ μ H to 9.99999 GH)	D	$\pm(0.00000$ to $9.99999)$	Q	$\pm(0.00$ to $99999.9)$	$\Delta\%$	$\pm(0.000\%$ to $999.999\%)$
Parameter	Display range (6 digits)																						
Z	0.00 m Ω to 9.99999 G Ω																						
Y	0.000 nS to 9.99999 GS																						
θ	$\pm(0.000^\circ$ to $999.999^\circ)$																						
Rs, Rp, X, Rdc	$\pm(0.00$ m Ω to 9.99999 G $\Omega)$																						
G, B	$\pm(0.000$ nS to 9.99999 GS)																						
Cs, Cp	$\pm(0.0000$ pF to 9.99999 GF)																						
Ls, Lp	$\pm(0.00000$ μ H to 9.99999 GH)																						
D	$\pm(0.00000$ to $9.99999)$																						
Q	$\pm(0.00$ to $99999.9)$																						
$\Delta\%$	$\pm(0.000\%$ to $999.999\%)$																						
Measurement frequency	(1) Frequency range 40 Hz to 200 kHz (2) Setting resolution 40.000 Hz to 99.999 Hz 1 mHz steps 100.00 Hz to 999.99 Hz 10 mHz steps 1.0000 kHz to 9.9999 kHz 100 mHz steps 10.000 kHz to 99.999 kHz 1 Hz steps 100.00 kHz to 200.00 kHz 10 Hz steps (3) Frequency accuracy $\pm 0.01\%$ of setting or less																						
Output impedance (When the measurement frequency is 1 kHz)	100 $\Omega \pm 10 \Omega$																						

10.1 General Specifications

1. Basic Specifications

Measurement signal level	(1) Open circuit terminal voltage (V) mode and constant voltage (CV) mode • Level range 5 mV to 5 V, maximum 50 mA • Setting resolution 1 mV steps • Setting accuracy $\pm 10\%$ setting ± 10 mV (2) Constant current (CC) mode • Level range 10 μA to 50 mA, maximum 5 V • Setting resolution 10 μA steps • Setting accuracy $\pm 10\%$ setting ± 10 μA
--------------------------	---

Measurement range The measurement range is determined according to impedance Z
 The values of the other measurement items can be calculated
 Ranges: 100 m Ω , 1 Ω , 10 Ω , 100 Ω , 1 k Ω , 10 k Ω , 100 k Ω , 1 M Ω , 10 M Ω , 100 M Ω
 (10 ranges)

No.	Measurement range	Guaranteed Accuracy Range	AUTO Ranging Range
1	100 M Ω	8 M Ω to 200 M Ω	8 M Ω to
2	10 M Ω	800 k Ω to 100 M Ω	800 k Ω to 10 M Ω
3	1 M Ω	80 k Ω to 10 M Ω	80 k Ω to 1 M Ω
4	100 k Ω	8 k Ω to 1 M Ω	8 k Ω to 100 k Ω
5	10 k Ω	800 Ω to 100 k Ω	800 Ω to 10 k Ω
6	1 k Ω	80 Ω to 10 k Ω	80 Ω to 1 k Ω
7	100 Ω	8 Ω to 100 Ω	8 Ω to 100 Ω
8	10 Ω	800 m Ω to 10 Ω	800 m Ω to 10 Ω
9	1 Ω	80 m Ω to 1 Ω	80 m Ω to 1 Ω
10	100 m Ω	10 m Ω to 100 m Ω	0 Ω to 100 m Ω

- The guaranteed accuracy range differs depending on the measurement conditions (p.203)
- REF VAL is displayed when out of the range
OVERFLOW or UNDERFLOW is displayed when out of the A/D converter input range
- HOLD, AUTO, and limit value linking
- Measurement condition range linking function (speed, averaging, trigger delay, trigger synchronization)

Accuracy	Z: $\pm 0.05\%$ rdg, θ : $\pm 0.03^\circ$ (representative value) Accuracy guarantee duration: 1 year Warm-up time: 1 hour Accuracy guarantee temperature and humidity range: 0°C to 40°C (32°F to 104°F), 80% RH or less (non-condensing)
----------	--

Measurement time	Approx. 2.0 ms (1 kHz, FAST, no screen display)
------------------	---

Measurement speed	FAST, MED, SLOW, SLOW2
-------------------	------------------------

Terminal structure	4-terminal pair structure
--------------------	---------------------------

Product warranty period	3 years
-------------------------	---------

2. Function

Monitor functions	(1) Monitor voltage • Monitor range 0.000 V to 5.000 V • Monitor accuracy $\pm 10\%$ rdg ± 10 mV (2) Monitor current • Monitor range 0.000 mA to 50.00 mA • Monitor accuracy $\pm 10\%$ rdg ± 10 μA
-------------------	--

2. Function

Limit function	(1) Current limit (when V or CV) - Limit range 0.01 mA to 50.00 mA - Limit accuracy $\pm 10\%$ rdg $\pm 10 \mu\text{A}$ (2) Voltage limit (when CC set) - Limit range 0.005 V to 5.000 V - Limit accuracy $\pm 10\%$ rdg $\pm 10 \text{ mV}$
DC resistance measurement	Can be measured when the Rdc measurement parameter is set. The following measurement conditions used during DC resistance measurement can be set separately from AC measurement: Measurement range, judgement synchronization setting, DC delay, adjustment delay, line frequency Measurement signal level: 2 V fixed Generation accuracy: $\pm 10\%$ of setting $\pm 20 \text{ mV}$
Average	1 to 256 (1 step)
Trigger function	An internal trigger or external trigger can be set
Trigger delay	0 to 9.9999 s (0.0001 s resolution)
BIN measurement	10 main parameter types, 1 sub parameter type, OUT, SUBNG, absolute value setting, $\Delta\%$ setting, % setting
Comparator	Main parameter: HI/IN/LO Sub parameter: HI/IN/LO Absolute value setting, $\Delta\%$ setting, % setting
Compensation	- Open and short circuit compensation ALL compensation (all ranges, specified ranges) / SPOT compensation (5 frequencies) - Load circuit compensation 5 frequencies - Cable length compensation: 0 m, 1 m Guaranteed accuracy up to 4 m when cable length compensation of 1 m set - Compensation values can be loaded.
Correlation compensation	Enter the compensation coefficients a and b of the following expression $[\text{Measurement value after compensation}] = a \times [\text{measurement value}] + b$
Residual charge protection function (Provides protection against a discharge voltage from a charged capacitor)	$V = \sqrt{\frac{I_0}{C}}$ C: Capacitance [F] of test sample However, $V = \text{maximum } 400 \text{ V}$
Continuous measurement	Perform continuous measurement with saved conditions (up to 2 sets) Up to 2 judgment results can be output simultaneously from EXT I/O.
Display digits setting function	The number of display digits for measurement values can be set to 3, 4, 5, and 6 However, the setting differs depending on the parameter. (The initial value is 6 digits)
Display setting function	The LCD can be set to ON/ OFF Screen contrast adjustment range: 0% to 100%
Key-lock function	Can be enabled and disabled by front panel key operation Can be enabled and disabled by passcode input
Trigger synchronous output function	0 to 9.9999 s (0.0001 s resolution) Outputs a measurement signal during analog measurement only.
Panel save and load function	All measurement conditions : 60 different measurement conditions can be saved Correction values only : 128 different measurement conditions can be saved Any measurement condition can be load by key operation or a control signal via the EXT I/O

10.1 General Specifications

2. Function

Memory function	32,000 measurement result items can be saved to the instrument (Reading via USB or LAN is possible.)												
Contact check	(1) 4-terminal contact check Performs a contact (disconnection) check between H_C and H_P and between L_C and L_P Threshold values can be changed: 1 to 5 (5 high sensitivity, low contact resistance value), Initial setting: 2 (500 Ω) <table><tr><td>Settings</td><td>1</td><td>2</td><td>3</td><td>4</td><td>5</td></tr><tr><td>Contact resistance threshold value (Ω)</td><td>1000</td><td>500</td><td>100</td><td>50</td><td>10</td></tr></table> Contact resistance threshold values are reference values. Check timing can be changed. BEFORE: Performs a contact check before measurement. AFTER: Performs a contact check after measurement. BOTH: Performs a contact check before and after measurement. (2) HIGH-Z reject function (detection of OPEN state during 2-terminal measurement) When the measurement value is higher than the judgment reference, a contact error is output Judgment reference: Can be set from 0% to 30,000% of range full scale (with 1% resolution). Error output: An error is output from the EXT I/O	Settings	1	2	3	4	5	Contact resistance threshold value (Ω)	1000	500	100	50	10
Settings	1	2	3	4	5								
Contact resistance threshold value (Ω)	1000	500	100	50	10								
Buzzer sound	The buzzer for the comparator judgment result (IN or OUT) can be set to ON/ OFF The buzzer sound for key input can be set to ON/ OFF Any of four buzzer tones can be selected												
Waveform averaging function	Function: The number of measurement waveforms can be set for each measurement frequency band. Using more measurement waveforms will result in increased measurement precision, while using fewer measurement waveforms will result in higher measurement speed. Operating mode: OFF/ON Setting range: See p. 99. Initial setting: OFF												

3. Interface

Display	Monochrome LCD
Handler interface	
EXT I/O	See p. 189.
Electrical specifications	
USB	
Electrical specifications	USB 2.0 (Full-speed)
Connector	Series B receptacle
Class	CDC class (USB COM)
Delimiter	Sending: CR+LF Receiving: CR, LF, CR+LF
LAN	
Applicable standards	IEEE 802.3
Transmission method	100BASE-TX
	Full duplex
Protocol	TCP/IP
Connector	RJ-45
Communication description	Configuring settings and acquiring measured values using communications commands
Settings	IP address, subnet mask, default gateway Communications command port number: 1 to 65535
Default setting	IP address: 192.168.000.001 Subnet mask: 255.255.255.000 Default gateway: 0.0.0.0 (None) Communications command port No.: 3500
Delimiter	Sending: CR+LF Receiving: CR, LF, CR+LF

4. Environmental and Safety Specifications

Operating temperature and humidity range	0°C to 40°C (32°F to 104°F), 80% RH or less (non-condensing)
Storage temperature and humidity range	-10°C to 55°C (14°F to 131°F), 80% RH or less (non-condensing)
Operating environment	Indoor use, pollution degree 2, altitude up to 2000 m (6562 ft.)
Rated supply voltage	100 V to 240 V AC
Rated power-supply frequency	50 Hz/60 Hz
Maximum rated power consumption	50 VA
Dimensions	Approx. 260W × 88H × 203D mm (10.24" W × 3.46" H × 7.99" D) (excluding protrusions)
Weight	Approx. 2.1 kg (74.1 oz.)
Standards	Safety EMC
	EN 61010 EN 61326 Class A
Withstand voltage	Between the power wire and ground wire: 1.62 kV AC for 1 minute

5. Included Accessories, Options

Included accessories	See p. 2.
Options	See p. 3.

10.2 Measurement Range and Accuracy

The measurement accuracy is calculated using the following equation:

$$\text{Measurement accuracy} = \text{Basic accuracy} \times C \times D \times E \times F$$

C: Level coefficient, D: Measurement speed coefficient, E: Cable length coefficient,
F: Temperature coefficient

Basic accuracy

Calculated based on coefficients A and B as shown in "Table 1. Basic accuracy table" (p. 201).

Measurement conditions of basic accuracy coefficient table.

- Using the Model 9262 Test Fixture
- Measurement speed: SLOW2
- Cable length: 0 m
- Temperature and humidity: within 23±5°C, 80% RH or less
- Operation 60 minutes after the power is turned on.
- Open circuit compensation and short circuit compensation both being performed.

Basic accuracy formula

Z_x ... Impedance of the test sample

A ... Noted in accuracy table (upper portion: accuracy of Z (% rdg), lower portion: accuracy of θ (°))

B ... Noted in accuracy table (upper portion: accuracy of Z (% rdg), lower portion: accuracy of θ (°))

1 kΩ range or more

$$\text{Basic accuracy} = \pm \left(A + B \times \left| \frac{10 \times Z_x[\Omega]}{\text{Range}[\Omega]} - 1 \right| \right)$$

100 Ω range or less

$$\text{Basic accuracy} = \pm \left(A + B \times \left| \frac{\text{Range}[\Omega]}{Z_x[\Omega]} - 1 \right| \right)$$

See "Example calculation" (p. 204)

10.2 Measurement Range and Accuracy

Table 1. Basic accuracy table

Upper portion: Impedance Z (Unit: %) Lower portion: Phase angle θ (Unit: °)												
Range	DC		40.000 Hz to 99.999 Hz		100.00 Hz to 999.99 Hz		1.0000 kHz to 10.000 kHz		10.001 kHz to 100.00 kHz		100.01 kHz to 200.00 kHz	
100 MΩ	A= 1	B= 1	A= 6 A= 5	B= 5 B= 3	A= 3 A= 2	B= 2 B= 2	A= 3 A= 2	B= 2 B= 2	- -	- -	- -	- -
10 MΩ	A= 0.5	B= 0.3	A= 0.8 A= 0.8	B= 1 B= 0.5	A= 0.5 A= 0.4	B= 0.3 B= 0.2	A= 0.5 A= 0.4	B= 0.3 B= 0.2	A= 3 A= 2	B= 2 B= 2	- -	- -
1 MΩ	A= 0.2	B= 0.1	A= 0.4 A= 0.3	B= 0.08 B= 0.08	A= 0.3 A= 0.2	B= 0.05 B= 0.02	A= 0.3 A= 0.2	B= 0.05 B= 0.02	A= 0.7 A= 1.5	B= 0.08 B= 0.08	A= 1 A= 3	B= 0.5 B= 0.5
100 kΩ	A= 0.1	B= 0.01	A= 0.3 A= 0.3	B= 0.03 B= 0.02	A= 0.2 A= 0.1	B= 0.03 B= 0.02	A= 0.15 A= 0.1	B= 0.02 B= 0.015	A= 0.25 A= 0.4	B= 0.04 B= 0.02	A= 0.4 A= 1.2	B= 0.3 B= 0.3
10 kΩ	A= 0.1	B= 0.01	A= 0.3 A= 0.3	B= 0.025 B= 0.02	A= 0.2 A= 0.1	B= 0.025 B= 0.02	A= 0.05 A= 0.03	B= 0.02 B= 0.02	A= 0.2 A= 0.4	B= 0.025 B= 0.02	A= 0.3 A= 0.6	B= 0.03 B= 0.05
1 kΩ	A= 0.1	B= 0.01	A= 0.3 A= 0.2	B= 0.02 B= 0.02	A= 0.2 A= 0.1	B= 0.02 B= 0.02	A= 0.15 A= 0.08	B= 0.02 B= 0.02	A= 0.2 A= 0.4	B= 0.02 B= 0.02	A= 0.3 A= 0.6	B= 0.02 B= 0.02
100 Ω	A= 0.1	B= 0.02	A= 0.4 A= 0.2	B= 0.02 B= 0.01	A= 0.3 A= 0.15	B= 0.02 B= 0.01	A= 0.15 A= 0.1	B= 0.02 B= 0.01	A= 0.2 A= 0.4	B= 0.02 B= 0.02	A= 0.3 A= 0.6	B= 0.03 B= 0.02
10 Ω	A= 0.2	B= 0.15	A= 0.5 A= 0.3	B= 0.2 B= 0.1	A= 0.4 A= 0.3	B= 0.05 B= 0.03	A= 0.3 A= 0.15	B= 0.05 B= 0.03	A= 0.3 A= 0.75	B= 0.05 B= 0.05	A= 0.4 A= 1.5	B= 0.2 B= 0.1
1 Ω	A= 0.3	B= 0.3	A= 2 A= 1	B= 1 B= 0.6	A= 0.6 A= 0.5	B= 0.3 B= 0.2	A= 0.4 A= 0.25	B= 0.3 B= 0.2	A= 0.4 A= 1	B= 0.3 B= 0.2	A= 1 A= 2	B= 1 B= 0.5
100 mΩ	A= 3	B= 3	A= 10 A= 6	B= 10 B= 6	A= 3 A= 2	B= 3 B= 2	A= 3 A= 2	B= 2 B= 1.5	A= 2 A= 2	B= 2 B= 1.5	A= 4 A= 3	B= 3 B= 4

Level coefficient C

Coefficients for measurement levels are shown in Table 2.

Table 2. Level coefficient table

	2 V		
Level coefficient C (DC resistance measurement)	1		
	0.005 V to 0.999 V	1 V	1.001 V to 5 V
Level coefficient C (AC measurement)	$1 + \frac{0.2}{V}$	1	$1 + \frac{2}{V}$

V: Measurement value(equivalent to when V mode) [V]

Measurement speed coefficient D

Coefficients for measurement speeds are shown in Table 3.

Table 3. Measurement speed coefficient table

		FAST	MED	SLOW	SLOW2
Speed coefficient D	DC resistance measurement	4	3	2	1
	AC measurement	8	4	2	1
Coefficients when using the waveform averaging function	See Table 4.				

10.2 Measurement Range and Accuracy

Coefficients for waveform counts when using the waveform averaging function are shown in Table 4.

Table 4. Measurement speed coefficient table when using the waveform averaging function

No	Frequency band	Settable range	Measurement speed coefficient			
			4	3	2	1
1	DC (Line frequency 50 Hz)	1 to 24	1 to 2	3 to 4	5 to 19	20 to 24
	DC (Line frequency 60 Hz)	1 to 24	1 to 2	3 to 5	6 to 23	24

No	Frequency band	Settable range	Out of guaranteed accuracy	Measurement speed coefficient			
				8	4	2	1
5	40.000 Hz to 99.999 Hz	1 to 40	-	1	2 to 4	5 to 39	40
6	100.00 Hz to 300.00 Hz	1 to 50	-	1	2 to 4	5 to 49	50
7	300.01 Hz to 500.00 Hz	1 to 200	-	1	2 to 9	10 to 199	200
8	500.01 Hz to 1.0000 kHz	1 to 300	-	1 to 4	5 to 19	20 to 299	300
9	1.0001 kHz to 2.0000 kHz	1 to 600	1	2 to 7	8 to 39	40 to 599	600
10	2.0001 kHz to 3.0000 kHz	1 to 1200	1 to 3	4 to 11	12 to 59	60 to 1199	1200
11	3.0001 kHz to 5.0000 kHz	1 to 2000	1 to 5	6 to 19	20 to 99	100 to 1999	2000
12	5.0001 kHz to 10.000 kHz	1 to 3000	1 to 9	10 to 39	40 to 199	200 to 2999	3000
13	10.001 kHz to 20.000 kHz	1 to 1200	1 to 3	4 to 15	16 to 79	80 to 1199	1200
14	20.001 kHz to 30.000 kHz	1 to 480	1	2 to 5	6 to 23	24 to 479	480
15	30.001 kHz to 50.000 kHz	1 to 800	1	2 to 9	10 to 39	40 to 799	800
16	50.001 kHz to 100.00 kHz	1 to 1200	1 to 3	4 to 15	16 to 79	80 to 1199	1200
17	100.01 kHz to 200.00 kHz	1 to 2400	1 to 7	8 to 31	32 to 159	160 to 2399	2400

NOTE

When the measurement frequency falls outside the guaranteed accuracy, instrument operation is considered to be outside the guaranteed accuracy.

Cable length coefficient E

Coefficients for cable length are shown in Table 5.

Table 5. Cable length coefficient table

		0 m	1 m	2 m	4 m
Cable length coefficient E	10 k Ω range or less	1	1.2	$1.5 + \frac{fm}{100}$	$2 + \frac{fm}{50}$
	100 k Ω range and over	1	1.2	$1.5 + \frac{fm}{20}$	$2 + \frac{fm}{10}$

fm: Measurement frequency [kHz]

Guaranteed Accuracy Range (frequency)

	Cable length	10 k Ω range or less	100 k Ω range and over
Guaranteed Accuracy Range (frequency)	0 m	Up to 200 kHz	
	1 m	Up to 200 kHz	
	2 m	Up to 200 kHz	Up to 100 kHz
	4 m	Up to 200 kHz	Up to 10 kHz

Temperature coefficient F

Coefficients for operating temperature are shown in Table 6.

Table 6. Temperature coefficient table

	$0^{\circ}\text{C} \leq t < 18^{\circ}\text{C}, 28^{\circ}\text{C} < t \leq 40^{\circ}\text{C}$	$18^{\circ}\text{C} \leq t \leq 28^{\circ}\text{C}$
Temperature coefficient F	$1 + 0.1 \times t - 23 $	1

Guaranteed Accuracy Range

range	Sample impedance	40.000 Hz to 99.999 Hz	100.00 Hz to 999.99 Hz	1.0000 kHz to 10.000 kHz	10.001 kHz to 100.00 kHz	100.01 kHz to 200.00 kHz
100 MΩ	8 MΩ to 200 MΩ	0.101 V to 5 V				
10 MΩ	800 kΩ to 10 MΩ				0.501 V to 5 V	
1 MΩ	80 kΩ to 1 MΩ	0.05 V to 5 V	0.101 V to 5 V			
100 kΩ	8 kΩ to 100 kΩ	0.005 V to 5V			0.05 V to 5 V	0.101 V to 5 V
10 kΩ	800 Ω to 10 kΩ					
1 kΩ	80 Ω to 1 kΩ					
100 Ω	8 Ω to 100 Ω					
10 Ω	800 mΩ to 10 Ω	0.05 V to 5 V				
1 Ω	80 mΩ to 1 Ω	0.101 V to 5 V				
100 mΩ	10 mΩ to 100 mΩ	0.501 V to 5 V				

The voltage values in the above table refer to the voltage setting for V mode.

If the measured value (impedance value) exceeds the range while using the 10 M Ω to 1 k Ω range, the accuracy guarantee range conditions will be as shown in the following table.

range	Sample impedance	40.000 Hz to 99.999 Hz	100.00 Hz to 999.99 Hz	1.0000 kHz to 10.000 kHz	10.001 kHz to 100.00 kHz	100.01 kHz to 200.00 kHz	
10 MΩ	10 MΩ to 100 MΩ	0.101 V to 5 V					
1 MΩ	1 MΩ to 10 MΩ						
100 kΩ	100 kΩ to 1 MΩ	0.05 V to 5 V		0.101 V to 5 V	0.501 V to 5 V		
10 kΩ	10 kΩ to 100 kΩ	0.005 V to 5V					
1 kΩ	1 kΩ to 10 kΩ						

NOTE

The above measurement specification was determined using a 1.5D-2V coaxial cable with an established cable length for the instrument.

Using a cable other than a 1.5D-2V, or a cable that not an established length for the instrument in question increases the chance of measurement inaccuracy. A large capacitance between the H terminal and grounding capacitance (GND) or the L terminal and GND may result in measurement inaccuracy. Please set the GND to 10 pF or less.

10.2 Measurement Range and Accuracy

Example calculation

- Impedance ($Z=50\ \Omega$) basic accuracy
(For example) Measurement conditions: measurement frequency=10 kHz, measurement speed=SLOW2

Accuracy table (p.201)

range				1.0000 kHz to 10.000 kHz		
1 k Ω						
100 Ω				A= 0.15 B= 0.02		Z
				A= 0.1 B= 0.01		θ
10 Ω						

- Because Z is 50 Ω , the 100 Ω measurement range will be used.
- Obtain the Z coefficients A and B from the accuracy table (p.201) and then calculate the basic accuracy of Z .
In the 10 kHz/100 Ω range, the accuracy table (p.201) yields the values $A = 0.15$ and $B = 0.02$.

Using the basic accuracy formula (p.200) for 100 Ω or less ranges,

$$Z \text{ accuracy} = \pm \left(0.15 + 0.02 \times \left| \frac{100}{50} - 1 \right| \right) = \pm 0.17\%$$

- Similarly, calculate the basic accuracy of θ .
The accuracy table (p.201) yields the values $A = 0.1$ and $B = 0.01$

Using the basic accuracy formula (p.200) for 100 Ω and lower ranges,

$$\theta \text{ accuracy} = \pm \left(0.1 + 0.01 \times \left| \frac{100}{50} - 1 \right| \right) = \pm 0.11^\circ$$

10.2 Measurement Range and Accuracy

- Capacitance (Cs=160 nF) basic accuracy
(For example) Measurement conditions: measurement frequency=1 kHz, measurement speed=SLOW2

Accuracy table(p.201)

range				1.0000 kHz to 10.000 kHz		
100 kΩ						
10 kΩ				A= 0.05 B= 0.02	Z	
				A= 0.03 B= 0.02	θ	
1 kΩ						

- Measure the sample's Z and θ values using auto-ranging.
- Assume that the measured Z and θ values are as follows:

$$Z = 1.0144 \text{ k}\Omega, \theta = -78.69^\circ$$

Because Z is 1.0144 kΩ, the 10 kΩ measurement range will be used.

- Obtain the Z coefficients A and B from the accuracy table (p.201) and then calculate the basic accuracy of Z. In the 1 kHz/10 kΩ range, the accuracy table (p.201) yields the values A = 0.05 and B = 0.02.

Using the basic accuracy formula (p.200) for 1 kΩ or more ranges,

$$Z \text{ accuracy} = \pm \left(0.05 + 0.02 \times \left| \frac{10 \times 1.0144 \times 10^3}{10 \times 10^3} - 1 \right| \right) \rightleftharpoons \pm 0.05\%$$

- Similarly, calculate the basic accuracy of θ.
The accuracy table (p.201) yields the values A = 0.03 and B = 0.02.
Using the basic accuracy formula (p.200) for 1 kΩ or more ranges,

$$\theta \text{ accuracy} = \pm \left(0.03 + 0.02 \times \left| \frac{10 \times 1.0144 \times 10^3}{10 \times 10^3} - 1 \right| \right) \rightleftharpoons \pm 0.03^\circ$$

- Calculate the range within which Z and θ values can be acquired from the basic accuracy.

$$Z_{\min} = 1.0144 \text{ k}\Omega \times \left(1 - \frac{0.05}{100} \right) \rightleftharpoons 1.0139 \text{ k}\Omega$$

$$Z_{\max} = 1.0144 \text{ k}\Omega \times \left(1 + \frac{0.05}{100} \right) \rightleftharpoons 1.0149 \text{ k}\Omega$$

$$\theta_{\min} = -78.69 - 0.03 = -78.72^\circ$$

$$\theta_{\max} = -78.69 + 0.03 = -78.66^\circ$$

- Calculate the range within which Z and θ values can be acquired from the basic accuracy.
(For more information about the Cs calculation formula, see "Appendix1 Measurement Parameters and Calculation formula" (p. A1).)


$$C_{s\min} = - \frac{1}{\omega \times Z_{\max} \times \sin \theta_{\min}} \rightleftharpoons 159.90 \text{ nF} \quad \dots -0.0625\%$$

$$C_{s\max} = - \frac{1}{\omega \times Z_{\min} \times \sin \theta_{\max}} \rightleftharpoons 160.10 \text{ nF} \quad \dots 0.0625\%$$

$$\omega = 2 \times \pi \times f \quad f = \text{frequency [Hz]}$$

- Consequently, the Cs basic accuracy is ±0.0625%.

Conversion table from C and L to |Z|



10.3 About Measurement Times and Measurement Speed

Measurement times differ depending on the measurement conditions. Refer to the following values.

NOTE

All of the values are reference values. Note that they may differ depending on the conditions of use.

Measurement time: approx. 2.0 ms (1 kHz, FAST, no screen display)

Measurement speed: FAST, MED, SLOW, SLOW2

Analog measurement times (INDEX)

	FAST	MED	SLOW	SLOW2
DC (Line frequency 50 Hz)	43 ms	123 ms	203 ms	803 ms
DC (Line frequency 60 Hz)	37 ms	103 ms	203 ms	803 ms
40.000 Hz to 99.999 Hz	Tf	2×Tf	5×Tf	40×Tf
100.00 Hz to 300.00 Hz	Tf	2×Tf	5×Tf	50×Tf
300.01 Hz to 500.00 Hz	Tf	2×Tf	10×Tf	200×Tf
500.01 Hz to 1.0000 kHz	Tf	5×Tf	20×Tf	300×Tf
1.0001 kHz to 2.0000 kHz	2×Tf	8×Tf	40×Tf	600×Tf
2.0001 kHz to 3.0000 kHz	4×Tf	12×Tf	60×Tf	1200×Tf
3.0001 kHz to 5.0000 kHz	6×Tf	20×Tf	100×Tf	2000×Tf
5.0001 kHz to 10.000 kHz	10×Tf	40×Tf	200×Tf	3000×Tf
10.001 kHz to 20.000 kHz	20×Tf	80×Tf	400×Tf	6000×Tf
20.001 kHz to 30.000 kHz	50×Tf	150×Tf	600×Tf	12000×Tf
30.001 kHz to 50.000 kHz	50×Tf	250×Tf	1000×Tf	20000×Tf
50.001 kHz to 100.00 kHz	100×Tf	400×Tf	2000×Tf	30000×Tf
100.01 kHz to 200.00 kHz	200×Tf	800×Tf	4000×Tf	60000×Tf

$T_f [s] = 1 \div \text{Measurement frequency [Hz]}$

Tolerance: $\pm 5\%$ ± 0.2 ms

Measurement times (EOM)

Measurement times = INDEX + A + B + C + D + E

A. Calculation time

(no OPEN /SHORT/ LOAD compensation, HOLD range, no screen display, normal measurement)

	FAST	MED	SLOW	SLOW2
All frequencies	1.0 ms			

Tolerance: $\pm 10\%$ ± 0.1 ms

B. OPEN/ SHORT/ LOAD compensation

OPEN/ SHORT/ LOAD compensation	
No	0.0 ms
Yes	MAX 0.4 ms

C. Measurement mode

Measurement mode	
Normal measurement	0.0 ms
Comparator measurement	MAX 0.4 ms
BIN measurement	MAX 0.8 ms

D. Screen Display

Screen Display	
OFF	0.0 ms
ON	MAX 0.3 ms

E. Saving to memory

Saving to memory	
Memory function ON/IN	MAX 0.4 ms
Memory function OFF	0.0 ms

Wait time

- When the frequency is changed:
When the frequency is changed, the wait time is 1 ms.
- When switching levels
When the AC signal level is changed, the wait time is 1 ms.
- When switching ranges
When the range is changed, the wait time is 1 ms.
- When DC resistance measurement
When switching from AC measurement to DC resistance measurement, the wait time is 3 ms.
- When panel load
After all changes have been made, there is a wait for the maximum value of the corresponding wait time above.

Maintenance and Service

Chapter 11

11.1 Inspection, Repair and Cleaning

Before requesting instrument repair or inspection, please read "Before returning for repair" (p.211) and section "Error Display" (p.216).

Inspection and Repair

⚠ WARNING Do not attempt to modify, disassemble or repair the instrument; as fire, electric shock and injury could result.

NOTE

- Regular calibration is required in order to maintain and check the instrument's accuracy.
- The fuse is housed in the power unit of the instrument. If the power does not turn on, the fuse may be blown. If this occurs, a replacement or repair cannot be performed by customers. Please contact your dealer or Hioki representative.
- If damage is suspected, check the "Troubleshooting" section before contacting your dealer or Hioki representative.
If damage is suspected, check the "Before returning for repair" (p.211) section before contacting your dealer or Hioki representative.
However, in the following cases, immediately stop using the instrument, unplug the power cord and contact your dealer or Hioki representative.
 - When the nature of the damage is clearly evident
 - When measurement is impossible
 - After long-term storage in adverse conditions such as high temperature or humidity
 - After being subject to severe shock during transport
 - After severe exposure to water, oil, or dust (internal insulation can be degraded by oil or water, causing increase hazard of electric shock or fire)

Replaceable Parts and Operating Lifetimes

Useful life depends on the operating environment and frequency of use. Operation cannot be guaranteed beyond the following periods.

For replacement parts, contact your dealer or Hioki representative.

Part	RemarksLife	Remarks
Electrolytic Capacitors	Approx. 10 years	The useful life of electrolytic capacitors depends on the operating environment. Periodic replacement is necessary.
LCD backlight (to half brightness)	Approx. 50,000 hours	Periodic replacement is necessary.

Transporting the instrument

- Pack the instrument so that it will not sustain damage during shipping, and include a description of existing damage. We do not take any responsibility for damage incurred during shipping.
- Use the original packing materials when transporting the instrument, if possible.

Cleaning

Wipe the LCD gently with a soft, dry cloth.

If the instrument becomes dirty, wipe the instrument clean with a soft cloth slightly moistened with water or a neutral detergent.

NOTE Clean the vents periodically to avoid blockage.

IMPORTANT

Never use solvents such as benzene, alcohol, acetone, ether, ketones, thinners or gasoline. Doing so could deform and discolor the instrument.

Disposal

Dispose of the instrument in accordance with local regulations.

11.2 Troubleshooting

Before returning for repair

In the event of the instrument malfunctioning, check the following items.

Symptom	Check Item, or Cause	Remedy and Reference
The instrument cannot be turned on.	Is the power cord unplugged? Is it properly connected?	Confirm that the power cord is properly connected. See (p.23)
Keys do not work.	Are the keys locked?	Disable the key lock. See (p.114)
	Is the instrument being remotely operated from an external device using communication cable?	Switch to the local state. See Communication Instruction Manual (LCR Application Disk)
The instrument doesn't work.	Are you using the instrument as part of an automated system?	Consult the administrator or manager of the instrument or the automated system containing the instrument.
Nothing is displayed on the screen.	The LCD may be set to automatically turn off after a set time. Is the instrument in the standby state?	Press a key to cancel the standby state. See (p.26), (p.107)
Key response and screen drawing are slow.	Is the measurement value automatic output function enabled?	When the measurement value automatic output function is enabled, key response and screen drawing may become slow in order to give priority to measurement and measurement value output. See Communication Instruction Manual (LCR Application Disk)

Symptom	Check Item, or Cause	Remedy and Reference
The measurement values are exhibiting excessive variation.	Is the signal level setting too low?	Change the signal level setting. See (p.37)
	Is an error from "11.3 Error Display" (p. 216) being displayed?	Check the item indicated by the error display, address the cause, and then perform measurement. See (p.216)
		If REF VAL is being displayed, check measurement conditions such as the frequency and signal level and select conditions for which REF VAL will not be displayed. See (p.37)
	Are you using the instrument in a high-noise environment?	If you are using the instrument in a high-noise environment, consider taking the following measures: • Use guarding. • Separate the sample, measurement cables, and instrument from the source of the noise (motor, inverter, electromagnetic switch, power line, equipment generating sparks, etc.) or perform the measurement in a separate room. • Plug the instrument into a grounded outlet. • Use a separate power supply from the device that is generating the noise.
	Are you using a cable that you made yourself?	Use a designated cable.
	Is the connection cable length sufficient?	Use a cable of the length set by the cable length compensation. See (p.157)
	Are you using a 2-terminal connection to perform measurement?	Two-terminal connections are susceptible to the influence of contact resistance. Perform measurement using the four-terminal connection for the electrodes of the test sample.
		Add a wait time to allow contact to stabilize before measurement.
	Did you perform open and short compensation?	Perform open and short compensation properly. See (p.125), (p.136)

Symptom	Check Item, or Cause	Remedy and Reference
You are unable to perform measurement properly.	Is an error from "11.3 Error Display" (p. 216) being displayed?	Check the item indicated by the error display, address the cause, and then perform measurement. See (p.216)
	Is OVERFLOW or UNDERFLOW being displayed? See "11.3 Error Display" (p. 216)	If the range is not appropriate: Change to an appropriate range or perform measurement using auto ranging.
		If there is a break or short in the wiring: Check the wiring and perform measurement with the correct wiring connections.
	Is an error such as NC A or NC B being displayed (contact error)? See "11.3 Error Display" (p. 216)	Proper contact is not being made with the sample. Check the points of contact with the sample. Check the wiring for a break or defective contact. See (p.103) If you are using the instrument in a high-noise environment, consider taking the following measures: • Use guarding. • Separate the sample, measurement cables, and instrument from the source of the noise (motor, inverter, electromagnetic switch, power line, equipment generating sparks, etc.) or perform the measurement in a separate room. • Plug the instrument into a grounded outlet. • Use a separate power supply from the device that is generating the noise.
	Are you measuring an element that generates voltage on its own, for example a battery?	If there is a high DC voltage, you may damage the instrument. Avoid measuring the sample.
	Are you measuring an element on a printed circuit board?	• You can measure an element on a printed circuit board if the target element is isolated from external connections. However, if the target element is connected to other components or external circuitry, you will not be able to obtain a proper measurement. • You may be unable to measure components in circuits that are generating a voltage or to which a voltage is being applied, for example because they are energized.
The measurement values differ when a standard resistor, standard capacitor, or other known test sample is measured.	Is a high-impedance element which is influenced by noise being measured?	Use guarding. See (p.A3)
	Do the measurement conditions of the known test sample and measurement conditions of the instrument match?	Make sure the measurement conditions match.
	Did you perform open and short compensation properly?	Perform open and short compensation again. See (p.125), (p.136)
	Is load compensation set?	Turn load compensation off. See (p.145)
AUTO ranging is unable to determine a range.	Is the wait time for from connecting the test sample until performing measurement insufficient?	Ensure there is an appropriate trigger delay and trigger synchronization output wait time. See (p.56)
	Is a high-impedance element which is influenced by noise being measured?	Use guarding. See (p.A3)

Symptom	Check Item, or Cause	Remedy and Reference
Open compensation or short compensation resulted in an error.	Is the open or short compensation wiring correct?	Perform open compensation or short compensation with the proper wiring.
	Are you using the instrument in a high-noise environment?	If you are using the instrument in a high-noise environment, consider taking the following measures: • Use guarding. • Implement anti-noise measures. • Separate the sample, measurement cables, and instrument from the source of the noise (motor, inverter, electromagnetic switch, power line, equipment generating sparks, etc.) or perform the measurement in a separate room. • Plug the instrument into a grounded outlet. • Use a separate power supply from the device that is generating the noise.
An error beep sound is emitted continuously.	Is the measurement value automatic output function enabled?	When the measurement value automatic output function is enabled, a send error occurs on the measuring instrument side if the receive operation is not performed on the PC side, and a send error sound is emitted continuously when, for example, there is an internal trigger. Perform the receive operation on the PC side and then perform measurement on the measuring instrument side, or disable the measurement value automatic output function. See Communication Instruction Manual (LCR Application Disk)
No EXT I/O output signal can be obtained.	Do you know what type of output circuit is being used?	The instrument's EXT I/O functionality generates open collector output. Connect the wiring properly to the open collector. See (p.177)

When no apparent cause can be established

Perform a system reset.

See (p.118)

Full Reset Procedure

Performing a full reset will restore all of the settings to the factory default settings.
Only perform a full reset in the following cases.

- When the normal reset screen cannot be displayed because of a problem with the instrument.
(After the full reset, perform a self check to confirm that there are no problems. (p.173))
- When you have forgotten the passcode for the key lock.



- 1 Connect the power cable.
- 2 Press the POWER button.
- 3 Press and hold the $\times 10^3$ and $\div 10^3$ keys simultaneously while the opening screen is displayed.
- 4 The full reset is complete when a beeping sound is emitted.

If the instrument still does not operate normally after the full reset, it needs to be repaired.
Contact your authorized Hioki distributor or reseller.

NOTE Before performing a full reset, please remove the connection of the test sample to be measured first.

11.3 Error Display

When any of the following indications appear on the screen, check the corresponding reference page.


Error display	Description	Remedy and Reference
REF VAL	This is displayed when a measurement value is outside of the guaranteed accuracy range.	Increase the measurement signal level or change the measurement range to one that matches the impedance of the element to be measured. See (p.37), (p.43)
!	This is displayed when load compensation is enabled and the load compensation frequency does not match the current measurement frequency.	When load compensation: Match the current measurement frequency to the compensation frequency. See (p.145)
ERR	This is displayed when constant voltage measurement and constant current measurement cannot be performed.	When constant voltage measurement or constant current measurement: Reduce the constant voltage level or constant current level. See (p.39)
LMT	This is displayed when a signal level that is lower than the set value is applied to the test sample as a result of the voltage/current limit value setting.	Set the limit value again or change the measurement signal level so that the limit value is not exceeded. See (p.41)
?	This is displayed when load compensation is enabled and a load compensation condition other than the frequency does not match the current measurement condition.	Match the current measurement condition to the load compensation condition. See (p.145)
M. FULL	This is displayed when the set number of measurement results have been stored in the instrument's memory.	Load measurement values stored in the instrument's memory with the memory function or clear the memory. See (p.97)
DISP OUT	This is displayed when a measurement value is outside of the screen display range.	Change the measurement range to one that matches the impedance of the element to be measured. See (p.43)
SAMPLE ERR	This is displayed when measurement does not end because of an internal circuit error.	The instrument needs to be repaired. Contact your dealer or Hioki representative.
OVERFLOW	This is displayed when a measurement value is at or above the upper limit value of the auto ranging range.	Change the measurement range to a high-impedance range. See (p.43)
UNDERFLOW	This is displayed when a measurement value is at or below the lower limit value of the auto ranging range.	Change the measurement range to a low-impedance range. See (p.43)
NC A HL	This is displayed when the H_{POT} , H_{CUR} , L_{POT} , or L_{CUR} terminal is not connected after measurement, for example due to a break in wiring.	Check the connection of each terminal. See (p.24)
NC A L	This is displayed when the L_{POT} or L_{CUR} terminal is not connected after L measurement, for example due to a break in wiring.	Check the connection of each terminal. See (p.24)
NC A H	This is displayed when the H_{POT} or H_{CUR} terminal is not connected after H measurement, for example due to a break in wiring.	Check the connection of each terminal. See (p.24)

Error display	Description	Remedy and Reference
NC B HL	This is displayed when the H_{POT} , H_{CUR} , L_{POT} , or L_{CUR} terminal is not connected prior to measurement, for example due to a break in wiring.	Check the connection of each terminal. See (p.24)
NC B L	This is displayed when the L_{POT} or L_{CUR} terminal is not connected prior to L measurement, for example due to a break in wiring.	Check the connection of each terminal. See (p.24)
NC B H	This is displayed when the H_{POT} or H_{CUR} terminal is not connected prior to H measurement, for example due to a break in wiring.	Check the connection of each terminal. See (p.24)
Hi Z	This is displayed when a measurement result is high in relation to the judgment reference set for the HIGH-Z reject function.	Check the connection of each terminal. See (p.105)

Appendix

Appendix1 Measurement Parameters and Calculation formula

In general, impedance Z is used to evaluate the characteristics of, for example, circuit components. The IM3523A measures voltage and current vectors for circuit components relative to an AC signal at the set measurement frequency and uses those values to calculate the impedance Z and phase difference θ . The impedance Z can be expanded on a complex plane to calculate the following values:




$$Z = R + jX$$

$$\theta = \tan^{-1} \frac{X}{R}$$

$$|Z| = \sqrt{R^2 + X^2}$$

Z : Impedance(Ω)
 θ : Phase angle ($^\circ$)
 R : Resistance(Ω)
 X : Reactance(Ω)
 $|Z|$: Absolute value of impedance(Ω)

Furthermore, admittance Y that is the reciprocal of impedance Z can also be used depending on the characteristics of circuit components. As in the case of impedance Z , the following values can also be obtained from admittance Y by rotating the admittance Y around the complex plane.



$$Y = G + jB$$

$$\phi = \tan^{-1} \frac{B}{G}$$

$$|Y| = \sqrt{G^2 + B^2}$$

Y : Admittance (S)
 ϕ : Phase angle ($^\circ$) = $-\theta$
 G : Conductance (S)
 B : Susceptance (S)
 $|Y|$: Absolute value of admittance (S)

Appendix1 Measurement Parameters and Calculation formula

The instrument uses the following equations to calculate the components listed below from the voltage V flowing across the measurement sample's terminals, the resulting current I that passes through the sample, the phase difference θ relative to the voltage V and current I , and the measurement frequency's angular velocity ω .

NOTE

The phase angle θ is displayed using the impedance Z as the reference. When performing measurements using admittance Y as the reference, the sign of the impedance Z phase angle θ will be reversed.

Item	Series equivalent circuit mode	Parallel equivalent circuit mode
Z	$ Z = \frac{V}{I} \left(= \sqrt{R^2 + X^2} \right)$	
Y	$ Y = \frac{I}{ Z } \left(= \sqrt{G^2 + B^2} \right)$	
R	$R_S = ESR = Z \cos \theta$	$R_P = \frac{I}{ Y \cos \phi} \left(= \frac{I}{G} \right)^{*1}$
X	$X = Z \sin \theta$	_____
G	_____	$G = Y \cos \phi \quad ^{*1}$
B	_____	$B = Y \sin \phi \quad ^{*1}$
L	$L_S = \frac{X}{\omega}$	$L_P = -\frac{I}{\omega B} \quad ^{*2}$
C	$C_S = -\frac{I}{\omega X}$	$C_P = \frac{B}{\omega} \quad ^{*2}$
D	$D = \frac{\cos \theta}{ \sin \theta }$	
Q	$Q = \frac{ \sin \theta }{\cos \theta} \left(= \frac{I}{D} \right)$	

*1: ϕ is a symbol for the phase angle of admittance Y ($\phi = -\theta$).


*2: $\omega = 2\pi f$, $\pi \approx 3.14$, f is a symbol for the measurement frequency.

L_S , C_S , R_S : The measured values of L , C , and R in series equivalent circuit mode.

L_P , C_P , R_P : The measured values of L , C , and R in parallel equivalent circuit mode.

Appendix2 Measurement of High Impedance Components

The measured value obtained when testing a high impedance element (such as, for example, a resistor with resistance 100 k Ω or higher) is sometimes unreliable, because such an element is vulnerable to the effects of external interference and the like. In this case, reliable testing can be performed by the use of guarding, that is, connecting a metallic plate to the GUARD terminal and carrying out the measurement on the metallic plate.




When measuring components on a metal plate, use, for example, resin film as insulation to ensure terminals and the like are not short-circuited.

NOTE Open circuit compensation is high impedance measurement, so be sure to use the shielding process. If it is not used, the compensation values may become unstable and affect the measurement values.


Appendix3 Measuring In-circuit Elements

Measure an in-circuit component after providing guarding.

$$R = R_2 \cdot \frac{R_3 + R_4}{R_2 + R_3 + R_4}$$




Referring to the following figure, when measuring a resistance value for the resistor R_2 , even if the tips of the two probes are contacted against the ends of the resistor R_2 , considering the sum of the current flowing through the resistor R_2 and the current flowing through the resistors R_3 and R_4 , what is obtained is the resistance value for the parallel combination:




If as shown in the next figure a guard terminal is used, the current flowing through the resistors R_3 (not flowing through R_4) is absorbed by this guard terminal, so that the resistance value for the resistor R_2 is accurately measured.

NOTE

- The accuracy of measurement will not be improved in cases where for example $R_2 \gg R_3$ and R_3 is close to zero.
- As shown in the figure below, it is not possible to use this type of separation process for testing of the impedance values of two resistors or other elements of identical types which are connected in parallel, or for testing of the impedance values of a coil and a capacitor which are connected in parallel.



Two resistors in parallel



Coil and capacitor in parallel

Appendix4 Countermeasures Against Incorporation of External Noise

This instrument is designed to be resistant to errors caused by interference from the test cables or the power supply line. However, if the level of the interference is particularly large, this can cause measurement errors or faulty operation.

Refer to the examples given below for examples of countermeasures which can be taken against interference which has caused faulty operation etc.

Appendix4.1 Countermeasures Against Incorporation of Noise from the Power Line


You can use the following countermeasures to reduce the effect of noise being incorporated from the power line.

Grounding Using a Protective Ground Wire

This instrument is structured so that the ground wire of the power cable can be used as protective grounding for the instrument. Protective grounding plays an important role in not only the prevention of electrical accidents but also the use of an internal filter to eliminate the incorporation of noise from the power line. Use the supplied power cord.

Attaching a Noise Filter to the Power Line

Connect a commercial plug-in noise filter to the power outlet and then connect the instrument to the output of the noise filter in order to suppress the incorporation of noise from the power line. Plug-in noise filters are commercially available from various specialist manufacturers.




Attaching an EMI Suppression Ferrite Core to the Power Cord

Pass the power cord through a commercially available EMI suppression ferrite core and secure the core as close as possible to the AC power inlet of the instrument in order to suppress the incorporation of noise from the power line.

Suppression is even more effective if you also attach an EMI suppression ferrite core close to the power plug.

If a toroidal ferrite core or split ferrite core with a large enough internal diameter is used, the amount of noise suppression can be increased by passing the power cord through the core several times.

EMI ferrite cores and ferrite beads are commercially available from various specialist manufacturers.


**Appendix4.2 Countermeasures Against Noise from the measurement Cables**

If interference is producing noise in the measurement cables, its influence can be moderated by the following countermeasure.

Fitting an anti-interference ferrite core on the measurement cables

Pass the test cables through a commercially available anti-interference ferrite core, and fix it close to the measurement terminals, so as to suppress noise from the measurement cables.

Moreover, if the internal diameter of the ferrite core allows, winding the measurement cables several times around the ferrite core (as with the power cord as described above) may further reduce the amount of noise.



Appendix5 Supplying DC Bias

Supplying DC bias means that a DC voltage is supplied as a bias to a sample for test whose characteristics are voltage dependent, such as an electrolytic capacitor or a ceramic capacitor.

Further, a DC current can be supplied as a bias to a sample for test whose characteristics are current dependent, such as a choke coil.

This instrument does not provide a DC bias input terminal. DC bias should be applied using the method described below.



CAUTION A voltage must not be applied to the measurement terminals of the instrument from an external source.


If a voltage is applied from an external source, the instrument may be damaged.

Appendix5.1 How to Supply a DC Bias Voltage

When you want to apply a DC voltage bias, refer to the following explanation.

Apply a DC voltage bias to a capacitor or other test sample as shown below.

DC Bias Voltage Circuit



- Use a resistance (R) or inductance (L) which has a large enough impedance with reference to the sample under test (Z).
- A H_{CUR} side capacitor must have a small enough impedance (i.e. a large enough capacitance) relative to the output resistance ($100\ \Omega$) while a H_{POT} capacitor must have a small enough impedance to the R_{HP} .
- Be careful about the polarity when connecting together the probes, the sample to be tested, and the DC voltage source.
- It takes a little time for the DC voltage which is being supplied to the sample under test to reach the set voltage, so you should wait for a certain stabilization time period (which depends upon the sample) before performing.
- After testing is completed, drop the voltage of the DC voltage source to zero, and remove the sample under test from the probes after having discharged any electric charge which may have built up.
- If you have removed the sample under test from the probes without first having discharged the accumulated electric charge, you should be careful to do so immediately.



CAUTION • In order to avoid electric shock accident, be absolutely sure not to touch the test terminals while the DC bias voltage is being supplied to them.

• If you disconnect the sample under test from the test terminals with the DC bias voltage still being supplied, then the test sample is left charged, which is very dangerous. In order to avoid electric shock.

• Do not short circuit between the clips of the test probes with the DC bias voltage still being supplied. Doing so may damage the probes or cause a short circuit accident.


• When measuring the element whose DC resistance is not high enough, DC current will flow to the main instrument and the measurement will not be performed properly.

Appendix5.2 How to Supply a DC Bias Current

When you want to apply a DC current bias, refer to the following explanation.

With regards to a DC current bias for a transformer, choke coil, or other test sample, configure the external bias circuit as shown below.

DC Bias Current Circuit



- Connect the sample to the measuring probe and then gradually raise the voltage of the DC source to the specified DC bias level. To disconnect the sample, gradually reduce the voltage of the DC source until the DC bias supplied to the sample is decreased to zero. You may disconnect the sample after this is achieved.
- Use a choke coil (CH) which has a large enough impedance with reference to the sample under test (Z).
- A H_{CUR} side capacitor must have a small enough impedance (i.e. a large enough capacitance) relative to the output resistance (100 Ω) while a H_{POT} capacitor must have a small enough impedance to the R_{HP} .
- Be careful about the polarity when connecting together the probes, the sample to be tested, and the DC current source.
- Be careful not to magnetically saturate the choke coil (CH) with the DC bias current.
- It takes a little time for the DC current which is being supplied to the sample under test to reach the set value, so you should wait for a certain stabilization time period (which depends upon the sample) before performing testing. Be careful, because if you perform testing before this stabilization time period has elapsed, the results will not be reliable.

CAUTION

- In order to avoid electric shock accident, be absolutely sure not to touch the test terminals while the DC bias is being supplied to them.
- Due to the inductance of the coil and the sample, counter electromotive force is generated when the sample is removed or inserted with the DC bias supplied. This may result in damage to the instrument or to the DC source.
- When measuring the element whose DC resistance is high (incl. open state), a high voltage occurred on the H side may cause damage on the main instrument.

Appendix6 The Residual Charge Protection Function

The instrument has been enhanced by the incorporation of a residual charge protection function. If by mistake a charged capacitor is connected to the measurement terminals, this function protects the internal circuitry of the instrument from discharge of such residual charge.

The maximum voltage from which the instrument can be protected by this function is determined from the capacitance value of the sample under test by the following equation:

$$V = \sqrt{\frac{10}{C}}$$


V : voltage [V] (maximum 400 VDC)

C : capacitance [F]

CAUTION

- The quoted maximum voltage from which the instrument can be protected by this function is for reference purposes only, and is not a guaranteed value. There may be danger of damage to the instrument, depending upon the operational circumstances and upon how often such charged capacitors are connected. In general, you should not rely upon this protection function; be sure to discharge charged capacitors properly before connecting them to the test terminals.
- The residual charge protection function is for protection of the instrument against the discharge of voltage present in charged capacitors, and is not capable of protecting the instrument against DC voltage which is constantly applied such as a superimposed DC voltage. If this is done, there is a danger of damage to the instrument.
[See Appendix5 Supplying DC Bias \(p.A7\)](#)


Relationship of capacitance and residual voltage from which the LCR meter can be protected.




Appendix7 Series Equivalent Circuit Mode and Parallel Equivalent Circuit Mode

The instrument measures the current flowing to the test sample and the voltage at both ends of the test sample, and determines Z and θ . Other measurement items such as L , C , and R are calculated from Z and θ . At this time, the mode for calculation becomes series equivalent circuit mode if the resistance components for C (or L) are assumed to be in series, and the mode becomes parallel equivalent circuit mode if the resistance components for C (or L) are assumed to be in parallel. It is, therefore, necessary to select the correct equivalent circuit mode to reduce errors because the calculation expression differs for series equivalent circuit mode and parallel equivalent circuit mode.

Generally, for measurement of a low impedance device (approx. less than $100\ \Omega$) like a large capacitance capacitor or a low inductance, a series equivalent circuit mode will be selected. While, for a high impedance device (approx. more than $10\ \text{k}\Omega$) like a small capacitance capacitor or a high inductance, a parallel equivalent circuit mode will be selected. When you are not sure about selection of circuit mode, please ask the parts maker. (ex. a impedance approx. between $100\ \Omega$ and $10\ \text{k}\Omega$)



Series equivalent circuit




Parallel equivalent circuit

NOTE

Because measurement value in each equivalent circuit mode is obtained through calculation, measurement values of both modes can be displayed. However, please note that the appropriate equivalent circuit depends on the test sample.

Appendix8 Open Circuit Compensation and Short Circuit Compensation

The residual impedance component of the test fixture can be considered in terms of an equivalent circuit as shown in the figure. Further, because the measured value Z_m for impedance includes this residual component, therefore, in order to obtain the genuine impedance value, it is necessary to compensate the measured value in terms of the open circuit impedance residual component and the short circuit residual component, which accordingly must be obtained.



Z_x : true value	R_s : residual resistance
L_s : residual inductance	G_o : residual conductance
C_o : floating capacitance value	Z_s : short circuit residual component
Y_o : open circuit residual component	Z_m : measured value

In this case, for the measured value Z_m :

$$Z_m = Z_s + \frac{1}{Y_o + \frac{1}{Z_x}}$$

The residual components can be determined in the following manner:

- Open circuit compensation
The terminals of the test fixture are left separated (open circuited). Because the short circuit residual component Z_s is now zero, therefore the open circuit residual component Y_o can be determined.
- Short circuit compensation
The terminals of the test fixture are connected together (short circuited). Because the open circuit residual component Y_o is now zero, therefore the short circuit residual component Z_s can be determined.

These residual components thus obtained are recorded as compensation values, and the compensation process may then be performed by substituting them into the above equation.

NOTE The determination of test range is performed according to the measured value Z_m for impedance. Therefore it may happen that testing cannot be performed, when HOLD is on, if the test range is determined merely according to the value of impedance of the sample under test. In this case, you should set the test range in consideration both of the impedance of the test sample and also of the residual impedance components of the test fixture.

Deviations in the measured values can become comparatively large in the following cases:

- If only short circuit compensation has been performed.

With short circuit compensation only having been performed, since no compensation can be performed in terms of the open circuit residual component Y_o (which is not available), thereby deviation in the resultant values will become large if the value of that open circuit residual component Y_o is relatively large.

- If only open circuit compensation has been performed.

With open circuit compensation only having been performed, since no compensation can be performed in terms of the short circuit residual component Z_s (which is not available), thereby deviation in the resultant values will become large if the value of that short circuit residual component Z_s is relatively large.

In order to avoid this sort of thing, be sure always to perform both short circuit compensation and also open circuit compensation.

Appendix9 Rack Mounting

Rack mounting brackets can be attached to the instrument.

Parts removed from this instrument should be stored in a safe place to enable future reuse.



WARNING


Observe the following precautions regarding the mounting screws to avoid instrument damage and electric shock accidents.

- When installing the Rack Mounting Plate, the screws must not intrude more than 3.5 mm into either side of the instrument.
- When removing the Rack Mounting Plate to return the instrument to stand-alone use, replace the same screws that were installed originally.
(Feet: M3 × 6 mm, Sides: M4 × 6 mm)


Rack Mounting Plate Template Diagram and Installation Procedure

Unit: mm


Rack Mounting Plate (EIA)



Spacer (Two Required)




Rack Mounting Plate (JIS)




A14

Appendix9 Rack Mounting




- 1 Remove the feed from the bottom of the instrument, and the screws from the sides (four near the front).




- 2 Installing the spacers on both sides of the instrument, affix the Rack Mounting Plate with the M4 x 10 mm screws.

When installing into the rack, reinforce the installation with a commercially available support stand.



Appendix10 Dimensional Diagram

Unit: mm



Appendix11 Initial Settings Table

The following table shows the initial settings of the instrument.

Setting Items			Initial setting	System reset or Full reset	*RST	:PRE-Set	Return to initial settings when power is turned on	Panel Save/load *1
Measurement parameter			Z/θ	←	←	←	x	●
LCR mode basic settings	Measurement frequency		1 kHz	←	←	←	x	●
	Measurement signal level	Mode	V	←	←	←	x	●
		V	1.000 V	←	←	←	x	●
		CV	1.000 V	←	←	←	x	●
		CC	10.00 mA	←	←	←	x	●
	Limit	ON/OFF	OFF	←	←	←	x	●
		Current limit value	50.00 mA	←	←	←	x	●
		Voltage limit value	5.00 V	←	←	←	x	●
	Measurement range	Mode	AUTO	←	←	←	x	●
		AUTO range limit function (communications setting only)	100 mΩ/ 100 MΩ	←	←	←	x	●
		Range	100 Ω	←	←	←	x	●
		Judgment synchronization setting	OFF	←	←	←	x	●
	Trigger mode		INT (Internal Trigger)	←	←	←	x	●
AC range LIST settings *2	Measurement speed		MED	←	←	←	x	●
	Number of times for average		1	←	←	←	x	●
	Trigger delay		0.0000 s	←	←	←	x	●
	Trigger synchronous output	ON/OFF	OFF	←	←	←	x	●
		Trigger time	0.0010 s	←	←	←	x	●
DC resistance measurement	Measurement range	Mode	AUTO	←	←	←	x	●
		AUTO range limit function (communications setting only)	100 mΩ/ 100 MΩ	←	←	←	x	●
		Range	100 Ω	←	←	←	x	●
		Judgment synchronization setting	OFF	←	←	←	x	●
	DC delay		0.0000 s	←	←	←	x	●
	ADJ delay		0.0030 s	←	←	←	x	●
	Line frequency		60 Hz	←	←	←	x	●
DC range LIST settings *2	Measurement speed		MED	←	←	←	x	●
	Number of times for average		1	←	←	←	x	●

● : Available, x:Unavailable, ←:Same as initial settings

*1: ● (ADJ) also saved when TYPE is set to ALL.

*2: All 10 ranges are initialized as shown to the right.

*3: Setting returns to initial setting (0) when a full reset is performed.

Setting Items			Initial setting	System reset or Full reset	*RST	:PRE-Set	Return to initial settings when power is turned on	Panel Save/load *1
Application settings	Measurement mode		LCR	←	←	←	×	●
	Judgment mode		OFF	←	←	←	×	●
	Memory	OFF/IN/ON	OFF	←	←	←	×	●
		Number of memory items	1000	←	←	←	×	●
	Waveform averaging function (communication setting only)	ON/OFF	OFF	←	←	←	×	●
		Waveform averaging count for each frequency band	Averaging count for MED	←	←	←	×	●
	Judgment result	Delay between judgment results and EOM	0.0000 s	←	←	←	×	×
		Reset	ON	←	←	←	×	×
	IO trigger	ENABLE	ON	←	←	←	×	×
		Edge	DOWN	←	←	←	×	×
	IO EOM	Mode	HOLD	←	←	←	×	×
		EOM output time	0.0050 s	←	←	←	×	×
	Contact check	Timing	OFF	←	←	←	×	●
		Threshold	2	←	←	←	×	●
	HIGH-Z Reject	ON/OFF	OFF	←	←	←	×	●
		Judgment standard	1000%	←	←	←	×	●
	Backlight	ON/OFF	ON	←	←	←	×	×
	Display digits		6/6	←	←	←	×	●
	Beep sound	Judgment result Key	NG	←	←	←	×	●
		Beep tone	A	←	←	←	×	×
	Contrast		50	←	←	←	×	×
	Key-lock	OFF/FULL/SET	OFF	←	←	←	×	×
		Passcode	3523	←	←	←	×	×
Comparator	Mode		ABS/ABS	←	←	←	×	●
	Absolute value mode	Upper limit value	OFF/OFF	←	←	←	×	●
		Lower limit value	OFF/OFF	←	←	←	×	●
	Percent mode Deviation percentage mode	Reference value	1.00000 k/10.0000	←	←	←	×	●
		Upper limit value	OFF/OFF	←	←	←	×	●
		Lower limit value	OFF/OFF	←	←	←	×	●
BIN	Mode		ABS/ABS	←	←	←	×	●
	Absolute value mode	Upper limit value	OFF/OFF	←	←	←	×	●
		Lower limit value	OFF/OFF	←	←	←	×	●
	Percent mode Deviation percentage mode	Reference value	1.00000 k/10.0000	←	←	←	×	●
		Upper limit value	OFF/OFF	←	←	←	×	●
		Lower limit value	OFF/OFF	←	←	←	×	●
Continuous measurement	Display timing		REAL	←	←	←	×	×
Open circuit compensation	Compensation mode		OFF	←	←	No Change	×	● (ADJ)
	Correction value	G Correction	0.000 ns	←	←	No Change	×	● (ADJ)
		B Correction	0.000 ns	←	←	No Change	×	● (ADJ)
	Correction range limit function	DC	ON	←	←	No Change	×	● (ADJ)
		MIN	40.000 Hz	←	←	No Change	×	● (ADJ)
		MAX	200.00 kHz	←	←	No Change	×	● (ADJ)

● : Available, ×:Unavailable, ←:Same as initial settings

*1: ● (ADJ) also saved when TYPE is set to ALL.

*2: All 10 ranges are initialized as shown to the right.

*3: Setting returns to initial setting (0) when a full reset is performed.

A18

Appendix11 Initial Settings Table

Setting Items			Initial setting	System reset or Full reset	*RST	:PRE-Set	Return to initial settings when power is turned on	Panel Save/load *1
Short circuit compensation	Compensation mode		OFF	←	←	No Change	×	● (ADJ)
	Correction value	R Correction value	0.00 mΩ	←	←	No Change	×	● (ADJ)
		X Correction value	0.00 mΩ	←	←	No Change	×	● (ADJ)
	Correction range limit function	DC	ON	←	←	No Change	×	● (ADJ)
		MIN	40.000 Hz	←	←	No Change	×	● (ADJ)
		MAX	200.00 kHz	←	←	No Change	×	● (ADJ)
Load correction value	ON/OFF		OFF	←	←	No Change	×	● (ADJ)
	Compensation mode		Z-θ	←	←	No Change	×	● (ADJ)
	Reference value	Z reference value	OFF	←	←	No Change	×	● (ADJ)
		θ reference value	OFF	←	←	No Change	×	● (ADJ)
	Compensation frequency		OFF	←	←	No Change	×	● (ADJ)
	Compensation signal level	Mode	V	←	←	No Change	×	● (ADJ)
		V	OFF	←	←	No Change	×	● (ADJ)
		CV	OFF	←	←	No Change	×	● (ADJ)
		CC	OFF	←	←	No Change	×	● (ADJ)
	Compensation range	Range	OFF	←	←	No Change	×	● (ADJ)
	Compensation value	Z coefficient	OFF	←	←	No Change	×	● (ADJ)
		θ coefficient	OFF	←	←	No Change	×	● (ADJ)
Cable length compensation			0 m	←	←	No Change	×	● (ADJ)
Scaling compensation	ON/OFF		OFF	←	←	No Change	×	● (ADJ)
	Compensation value	A	1.000	←	←	No Change	×	● (ADJ)
		B	0.00000	←	←	No Change	×	● (ADJ)
Panel	Save type		ALL	←	←	No Change	×	×
	Panel		No registration	Clear all data	Clear all data	No Change	×	×

● : Available, ×:Unavailable, ←:Same as initial settings

*1: ● (ADJ) also saved when TYPE is set to ALL.

*2: All 10 ranges are initialized as shown to the right.

*3: Setting returns to initial setting (0) when a full reset is performed.

Setting Items			Initial setting	System reset or Full reset	*RST	:PRE-Set	Return to initial settings when power is turned on	Panel Save/load *1
Interface	USB	Terminator	CR+LF	←	No Change	No Change	×	×
	LAN	IP address	192.168.000.001	←	No Change	No Change	×	×
		Subnet mask	255.255.255.000	←	No Change	No Change	×	×
		Gateway	OFF	←	No Change	No Change	×	×
		Port	3500	←	No Change	No Change	×	×
		Terminator	CR+LF	←	No Change	No Change	×	×
	Header		OFF	←	←	No Change	●	×
	Status Byte register		0	No Change *3	No Change	No Change	●	×
	Event register		0	No Change *3	No Change	No Change	●	×
	Enable register		0	No Change *3	No Change	No Change	●	×
	:MEASure:ITEM		0,0	←	←	←	×	●
	:MEASure:VALid		10	←	←	←	×	●
	Automatic output of measurement values		OFF	←	←	←	×	×
	Transfer format		ASCII	←	←	←	×	×
	Long format		OFF	←	←	←	×	×

● : Available, ×:Unavailable, ←:Same as initial settings

*1: ● (ADJ) also saved when TYPE is set to ALL.

*2: All 10 ranges are initialized as shown to the right.

*3: Setting returns to initial setting (0) when a full reset is performed.

Index

Absolute Value mode	78, 86
Accuracy	200
Adjustment Delay	69
All Compensation	127, 138
AUTO	43, 62
AUTO range limit function	44, 63
Average	54

B

Beep Sound	110
BIN	83

C

Cable Length Compensation	157
Calculation formula	A1
CC	37
Changing a Panel Name	167
Cleaning	209
Comparator	76
Configuring Settings for Continuous Measurement	
121	
Connection Examples	190
Constant current	37
Constant voltage	37
Contact Check Function	103
Continuous Measurement Function	119
Countermeasures Against Incorporation of External	
Noise	A5
current limit	41
CV	37

D

DC Bias	A7
DC Bias Current	A8
DC Bias Voltage	A7
DC delay	67, 69
Deleting a Panel	169
Deviation Percentage Mode	81
Dimensional Diagram	A15
Display	107

E

EMI Suppression	A6
-----------------------	----

Error display	216
EXT I/O Connector (Instrument Side)	178
External Control	177
Q&A	192
External trigger	50

F

FAST	53, 73
frequency	33
Full Reset	215

G

guarding	A4
----------------	----

H

High Impedance Components	A3
HIGH-Z Reject	105
HOLD	43, 62

I

I/O Test	176
In-circuit	A4
Initial Screen	12
Initial Settings Table	A16
Initializing	118, A16
Inspection, Repair	209
Instrument Installation	6
Interface	171
Internal Circuitry	188
Internal Trigger	50

J

JUDGE SYNC setting	48
--------------------------	----

L

LCD	124
LCD Display	107
LCR Application Disk	2
LCR Function	29
Limit Value	41
Line Frequency	70
Load Compensation	145

M

Measurement accuracy	200
measurement cables	24
Measurement categories	5
Measurement frequency	33
Measurement Mode	13
Measurement Range	43, 62, 200
Measurement signal level	37
Measurement speed	53
Measurement Times	207
MED	53, 73
Memory function	97

N

Noise	A5
Number of Display Digits	108

O

Open Circuit Compensation	125, A11
Opening screen	22
opening screen	215
Options	3
output signal	176

P

Panel Load	165
Panel Save	162
Parallel Equivalent Circuit	A10
Parameter	31
Passcode	116
Percentage mode	79, 88
POWER button	26
power inlet	23
Power Line	A5
Pre-Operation Inspection	22

R

Rack Mounting	A13
Range	43, 62
Replaceable Parts and Operating Lifetimes	209
Residual Charge Protection	A9
ROM/RAM Test	175

S

Saving Measurement Results	97
Scaling	158
Screen Contrast	113
Self Diagnosis	173
Series Equivalent Circuit Mode	A10
Setting the SYSTEM	171

Short Circuit Compensation	136, A11
signal level	37
Signal pin assignments	178
SLOW	53, 73
SLOW2	53, 73
Specifications	195
Spot Compensation	131
Standby	26
System Reset	118

T

Timing Chart	184
EXT I/O	184
Trigger	50
trigger delay	56
Trigger Synchronous Output Function	57

V

V	37
Version	172
voltage limit	41

W

Waveform Averaging	99
--------------------------	----

HIOKI

www.hioki.com/



**All regional
contact
information**

HEADQUARTERS

81 Koizumi
Ueda, Nagano 386-1192 Japan

HIOKI EUROPE GmbH

Helfmann-Park 2
65760 Eschborn, Germany
hioki@hioki.eu

2111 EN

Edited and published by HIOKI E.E. CORPORATION

Printed in Japan

- CE declarations of conformity can be downloaded from our website.
- Contents subject to change without notice.
- This document contains copyrighted content.
- It is prohibited to copy, reproduce, or modify the content of this document without permission.
- Company names, product names, etc. mentioned in this document are trademarks or registered trademarks of their respective companies.