

FANUC Robot SR-3iA, SR-6iA

MECHANICAL UNIT OPERATOR'S MANUAL

RESHAPE YOUR WORLD
RESTRESH YOUR WORLD

B-84024EN/08

© FANUC CORPORATION, 2018

• Original Instructions

Thank you very much for purchasing FANUC Robot.

Before using the Robot, be sure to read the "FANUC Robot series SAFETY HANDBOOK (B-80687EN)" and understand the content.

- No part of this manual may be reproduced in any form.
- All specifications and designs are subject to change without notice.

The products in this manual are controlled based on Japan's "Foreign Exchange and Foreign Trade Law". The export from Japan may be subject to an export license by the government of Japan.

Further, re-export to another country may be subject to the license of the government of the country from where the product is re-exported. Furthermore, the product may also be controlled by re-export regulations of the United States government.

Should you wish to export or re-export these products, please contact FANUC for advice.

In this manual, we endeavor to include all pertinent matters. There are, however, a very large number of operations that must not or cannot be performed, and if the manual contained them all, it would be enormous in volume. It is, therefore, requested to assume that any operations that are not explicitly described as being possible are "not possible".

SAFETY PRECAUTIONS

This chapter describes the precautions which must be followed to enable the safe use of the robot. Before using the robot, be sure to read this chapter thoroughly.

For detailed functions of the robot operation, read the relevant operator's manual to understand fully its specification.

For the safety of the operator and the system, follow all safety precautions when operating a robot and its peripheral equipment installed in a work cell.

For safe use of FANUC robots, you must read and follow the instructions in "FANUC Robot series SAFETY HANDBOOK (B-80687EN)".

1 PERSONNEL

Personnel can be classified as follows.

Operator:

- Turns the robot controller power ON/OFF
- Starts the robot program from operator panel

Programmer or Teaching operator:

- Operates the robot
- Teaches the robot inside the safeguarded space

Maintenance technician:

- Operates the robot
- Teaches the robot inside the safeguarded space
- Performs maintenance (repair, adjustment, replacement)
- The operator is not allowed to work in the safeguarded space.
- The programmer or teaching operator and maintenance technician are allowed to work in the safeguarded space. Works carried out in the safeguarded space include transportation, installation, teaching, adjustment, and maintenance.
- To work inside the safeguarded space, the person must be trained on proper robot operation.

Table 1 (a) lists the work outside the safeguarded space. In this table, the symbol "○" means the work allowed to be carried out by the specified personnel.

Table 1 (a) List of work outside the Safeguarded Space

| | Operator | Programmer or Teaching operator | Maintenance technician |
|---|----------|------------------------------------|---------------------------|
| Turn power ON/OFF to Robot controller | ○ | ○ | ○ |
| Select operating mode (AUTO/T1/T2) | | ○ | ○ |
| Select remote/local mode | | ○ | ○ |
| Select robot program with teach pendant | | ○ | ○ |
| Select robot program with external device | | ○ | ○ |
| Start robot program with operator's panel | ○ | ○ | ○ |
| Start robot program with teach pendant | | ○ | ○ |
| Reset alarm with operator's panel | | ○ | ○ |
| Reset alarm with teach pendant | | ○ | ○ |
| Set data on teach pendant | | ○ | ○ |

| | Operator | Programmer or Teaching operator | Maintenance technician |
|--------------------------------------|-----------------------|------------------------------------|---------------------------|
| Teaching with teach pendant | | <input type="radio"/> | <input type="radio"/> |
| Emergency stop with operator's panel | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Emergency stop with teach pendant | <input type="radio"/> | <input type="radio"/> | <input type="radio"/> |
| Operator's panel maintenance | | | <input type="radio"/> |
| Teach pendant maintenance | | | <input type="radio"/> |

During robot operation, programming and maintenance, the operator, programmer, teaching operator and maintenance technician take care of their safety using at least the following safety protectors.

- Use clothes, uniform, overall adequate for the work
- Safety shoes
- Helmet

2 DEFINITION OF SAFETY NOTATIONS

To ensure the safety of users and prevent damage to the machine, this manual indicates each precaution on safety with "**Warning**" or "**Caution**" according to its severity. Read the contents of each "**Warning**", "**Caution**" before attempting to use the robot.

| Symbol | Definitions |
|--|---|
|  WARNING | Used if hazard resulting in the death or serious injury of the user will be expected to occur if he or she fails to follow the approved procedure. |
|  CAUTION | Used if a hazard resulting in the minor or moderate injury of the user, or equipment damage may be expected to occur if he or she fails to follow the approved procedure. |
| NOTE | Used if a supplementary explanation not related to any of WARNING and CAUTION is to be indicated. |

3 PROCEDURE TO MOVE ARM WITHOUT DRIVE POWER IN EMERGENCY OR ABNORMAL SITUATIONS

For emergency or abnormal situations (e.g. persons trapped in or pinched by the robot), turn off the robot controller immediately, change robot posture by directly pressing robot arm and release the worker.

You cannot move the J3-axis posture because the brake operate for prevent of falling. To move the J3-axis, release the brake by pressing the J3-axis brake release button as shown in Figure during turning on the controller power. If J3-axis brake cannot be released even if turning on controller power, open the cover, loosen the J3 unit mounting bolts, and release engagement between the belt and the pulley.

⚠ WARNING

If the belt was released from pulley, J3-axis will fall and may cause injury of the personnel. Therefore, it is strongly recommended to take adequate measures such as supporting the J3-axis by a block etc. before releasing a brake.




Fig. 3 (a) J3-axis brake release button

NOTE

Contact your local FANUC representative for method of adjusting belt tension when restoring.




Fig. 3 (b) Bolt position to be loosened (SR-3iA, SR-3iA/H, SR-3iA/C)




Fig. 3 (c) Bolt position to be loosened (SR-6iA, SR-6iA/H, SR-6iA/C)

4 PRECAUTIONS FOR MECHANISMS

NOTE

- 1 Never move J1 or J2 by applying pressure to the ball-screw spline.
- 2 Please do not wipe out the grease on the ball screw spline.

5

WARNING & CAUTION LABEL

(1) Transportation label




Fig. 5 (a) Transportation label

Description

When transporting the robot, observe the instructions indicated on this label.

- 1) Use a crane having a load capacity of 100 kg or greater.
- 2) Use at least three slings each having a load capacity of 100 kg or greater.
- 3) Use at least three eyebolts each having an allowable load of 490 N (50 kgf) or greater.

(2) Operating space and payload label




Fig. 5 (b) Operating space and payload label (Example of SR-3iA)

(3) Grease caution label**Fig. 5 (c) Caution label****Description**


Do not wipe out the grease applied to the ball screw spline.

PREFACE

This manual explains operation procedures for the following mechanical units:

| Model name | Mechanical unit specification No. | Maximum load |
|----------------------|-----------------------------------|--------------|
| FANUC Robot SR-3iA | A05B-1116-B201 | 3kg |
| FANUC Robot SR-3iA/H | A05B-1116-B202 | 3kg |
| FANUC Robot SR-3iA/C | A05B-1116-B203 | 3kg |
| FANUC Robot SR-6iA | A05B-1117-B201 | 6kg |
| FANUC Robot SR-6iA/H | A05B-1117-B202 | 6kg |
| FANUC Robot SR-6iA/C | A05B-1117-B203 | 6kg |

The label stating the mechanical unit specification number is affixed in the position shown below. Before reading this manual, verify the specification number of the mechanical unit.



Position of label indicating mechanical unit specification number

TABLE 1)

| CONTENTS | (1) Model name | (2) TYPE | (3) No. | (4) DATE | (5) WEIGHT kg (Without controller) |
|----------|----------------------|----------------|--------------------------|--|--|
| LETTERS | FANUC Robot SR-3iA | A05B-1116-B201 | SERIAL NO. IS PRINTED | PRODUCTION YEAR AND MONTH ARE PRINTED | 19 |
| | FANUC Robot SR-3iA/H | A05B-1116-B202 | | | 17 |
| | FANUC Robot SR-3iA/C | A05B-1116-B203 | | | 21 |
| | FANUC Robot SR-6iA | A05B-1117-B201 | | | 30 |
| | FANUC Robot SR-6iA/H | A05B-1117-B202 | | | 28 |
| | FANUC Robot SR-6iA/C | A05B-1117-B203 | | | 32 |

RELATED MANUALS

For the FANUC Robot series, the following manuals are available:

| | | |
|---|---|---|
| SAFETY HANDBOOK B-80687EN All persons who use the FANUC Robot and system designer must read and understand thoroughly this handbook | | Intended readers : Operator, system designer Topics : Safety items for robot system design, operation, maintenance |
| R-30iB Compact Plus controller | OPERATOR'S MANUAL Basic Operation B-83284EN Alarm Code List B-83284EN-1 Optional Function B-83284EN-2 | Intended readers : Operator, programmer, maintenance technician, system designer Topics : Robot functions, operations, programming, setup, interfaces, alarms Use : Robot operation, teaching, system design |
| | MAINTENANCE MANUAL B-84035EN | Intended readers : Maintenance technician, system designer Topics : Installation, start-up, connection, maintenance Use : Installation, start-up, connection, maintenance |

This manual uses following terms.

| Name | Terms in this manual |
|---|------------------------|
| Connection cable between robot and controller | Robot connection cable |
| Robot mechanical unit | Mechanical unit |

TABLE OF CONTENTS

| | |
|-------------------------|-----|
| SAFETY PRECAUTIONS..... | s-1 |
|-------------------------|-----|

| | |
|--------------|-----|
| PREFACE..... | p-1 |
|--------------|-----|

| | |
|---|-----------|
| 1 TRANSPORTATION AND INSTALLATION | 1 |
| 1.1 TRANSPORTATION..... | 1 |
| 1.2 INSTALLATION | 4 |
| 1.2.1 Installation Example..... | 10 |
| 1.2.2 Angle of Mounting Surface Setting..... | 13 |
| 1.3 MAINTENANCE AREA..... | 15 |
| 1.4 INSTALLATION CONDITIONS..... | 16 |
| 2 CONNECTION WITH THE CONTROLLER | 17 |
| 3 BASIC SPECIFICATIONS | 20 |
| 3.1 ROBOT CONFIGURATION | 20 |
| 3.1.1 Tool flange option | 25 |
| 3.2 MECHANICAL UNIT OPERATING SPACE AND INTERFERENCE AREA. | 26 |
| 3.3 ZERO POINT POSITION AND MOTION LIMIT | 30 |
| 3.4 WRIST LOAD CONDITIONS | 37 |
| 4 EQUIPMENT INSTALLATION TO THE ROBOT | 42 |
| 4.1 END EFFECTOR INSTALLATION TO WRIST | 42 |
| 4.2 EQUIPMENT MOUNTING FACE | 46 |
| 4.3 PAYLOAD SETTING | 50 |
| 5 PIPING AND WIRING TO THE END EFFECTOR | 54 |
| 5.1 AIR SUPPLY | 55 |
| 5.2 AIR SUPPLY AND EE (RI/RO) INETRFACE..... | 56 |
| 6 AXIS LIMIT SETUP | 64 |
| 6.1 CHANGE AXIS LIMIT BY DCS (OPTION)..... | 64 |
| 6.2 J4-AXIS MOTION RANGE EXTENSION BY CONTINUOUS ROTATION FUNCTION | 67 |
| 7 CHECKS AND MAINTENANCE | 69 |
| 7.1 CHECKS AND MAINTENANCE | 69 |
| 7.1.1 Daily Checks | 69 |
| 7.1.2 Periodic Check and Maintenance | 70 |
| 7.2 CHECK POINTS..... | 72 |
| 7.2.1 Confirmation of Oil Seepage..... | 72 |
| 7.2.2 Confirmation of the Air Control Set and Air Purge kit (option) | 73 |
| 7.2.3 Check the Connectors..... | 73 |
| 7.2.4 Check of Mechanical Stopper | 74 |
| 7.3 MAINTENANCE..... | 75 |

| | | |
|-----------------|---|------------|
| 7.3.1 | Replacing the Batteries (1-Year Periodic Inspection If Built-in Batteries Are Specified) (1.5-Year Periodic Inspection If External Batteries Are Specified) | 75 |
| 7.3.2 | Replenish the Grease of the Reducer (1.5 years (5760 hours) or 1 years (3840 hours) checks) | 78 |
| 7.3.3 | Replenish the Grease of the Ball Screw Spline (6 months (1920 hours) checks) | 79 |
| 7.4 | STORAGE | 83 |
| 8 | MASTERING | 84 |
| 8.1 | OVERVIEW | 84 |
| 8.2 | RESETTING ALARMS AND PREPARING FOR MASTERING | 85 |
| 8.3 | ZERO POSITION MASTERING | 86 |
| 8.3.1 | Fixture for bellows of SR-3iA/C, SR-6iA/C | 89 |
| 8.4 | QUICK MASTERING | 91 |
| 8.5 | QUICK MASTERING FOR SINGLE AXIS | 93 |
| 8.6 | SINGLE AXIS MASTERING | 95 |
| 8.7 | MASTERING DATA ENTRY | 97 |
| 8.8 | VERIFYING MASTERING | 99 |
| 8.9 | MASTERING BACKUP AND RESTORATION WHEN CONTINUOUS ROTATION ENABLED | 99 |
| 9 | TROUBLESHOOTING | 100 |
| 9.1 | TROUBLESHOOTING | 100 |
| APPENDIX | | |
| A | PERIODIC MAINTENANCE TABLE | 109 |
| B | STRENGTH OF BOLT AND BOLT TORQUE LIST..... | 114 |

1**TRANSPORTATION AND INSTALLATION****1.1 TRANSPORTATION**

Use a crane to transport the robot. When transporting the robot, be sure to change the posture of the robot to that shown below and lift by using the eyebolts and the transport equipment at their points.

Transportation using a crane (Fig. 1.1 (a) to (d))

Fasten the M8 eyebolts of special transport equipment and lift the robot by the three slings.

NOTE

- 1 When lifting the robot, be careful not to damage motors, connectors, or cables of the robot by slings.
- 2 When hoisting or lowering the robot with a crane, move it slowly with great care. When placing the robot on the floor, exercise care to prevent the installation surface of the robot from striking the floor strongly.
- 3 Be sure to remove end effector before transporting robot.

**WARNING**

Use the transport equipment only to transport the robot. Do not use the transport equipment to secure the robot.




Fig. 1.1 (a) Transportation using a crane (SR-3iA, SR-3iA/H)

NOTE

There is no J4-axis for SR-3iA/H.

1. TRANSPORTATION AND INSTALLATION

B-84024EN/08




Fig. 1.1 (b) Transportation using a crane (SR-3iA/C)




Fig. 1.1 (c) Transportation using a crane (SR-6iA, SR-6iA/H)

NOTE

There is no J4-axis for SR-6iA/H.




Fig. 1.1 (d) Transportation using a crane (SR-6iA/C)

1.2 INSTALLATION

Fig. 1.2 (a) to (d) show the robot base dimensions.

! CAUTION

Flatness of robot installation surface must be less than or equal to 0.5mm.

Inclination of robot installation surface must be less than or equal to 0.5°.

If robot base is placed on uneven ground, it may result in the base breakage or low performance of the robot.




Fig. 1.2 (a) Dimensions of the robot base (back side connector plate) (SR-3iA, SR-3iA/H, SR-3iA/C)




Fig. 1.2 (b) Dimensions of the robot base (back side connector plate) (SR-6iA, SR-6iA/H, SR-6iA/C)




Fig. 1.2 (c) Dimensions of the robot base (bottom side connector plate) (SR-3iA, SR-3iA/H)




Fig. 1.2 (d) Dimensions of the robot base (bottom side connector plate) (SR-6iA, SR-6iA/H)




Fig. 1.2 (e) Dimensions of the robot base (wall mount) (SR-3iA, SR-3iA/H)




Fig. 1.2 (f) Dimensions of the robot base (wall mount) (SR-6iA, SR-6iA/H)

1.2.1 Installation Example

Fig. 1.2.1 (a) to (d) show examples of the robot installation. In case of SR-3iA, SR-3iA/H/C, fasten the robot base with four M8 x30 (Tensile strength 1200N/mm² or more) and appended washers with regulated torque 28Nm. In case of SR-6iA, SR-6iA/H/C, fasten the robot base with four M10 x30 (Tensile strength 1200N/mm² or more) and appended washers with regulated torque 56Nm. If compatibility must be maintained in teaching the robot after the robot mechanical unit is replaced, use the locating surface.




Fig. 1.2.1 (a) Installation Example (SR-3iA, SR-3iA/H/C)




Fig. 1.2.1 (b) Installation Example (SR-6iA, SR-6iA/H/C)




Fig. 1.2.1 (c) Installation Example (wall mount) (SR-3iA, SR-3iA/H/C)




Fig. 1.2.1 (d) Installation Example (wall mount) (SR-6iA, SR-6iA/H/C)

Fig. 1.2.1 (e) and Table 1.2.1 (a) to (d) indicate the force and moment applied to the base plate at the time of Power-off stop of the robot. Table 1.2.1 (e) and (f) indicate the stopping distance and time of the J1 to J3 axis until the robot stopping by Power-Off stop and by Smooth stop after input of the stop signal. Refer to the data when considering the strength of the installation face.

NOTE

Stopping times and distances in Table 1.2.1 (e) and (f) are reference values measured in accordance with ISO 10218-1. Please measure and check the actual values, since it varies depending on robot individual, load condition and operation program. Stopping times and distances in Table 1.2 (e) are affected by the robot's operating status and the number of servo-off stops. Please measure and check the actual values periodically.

Table 1.2 (a) Force and moment that acts on robot base (SR-3iA, SR-3iA/H)

| | Vertical moment M_v (Nm) | Force in Vertical direction F_v (N) | Horizontal moment M_H (Nm) | Force in Horizontal direction F_H (N) |
|--|-------------------------------|---|------------------------------------|---|
| During stillness | 28.5 | 187.1 | 0 | 0 |
| During acceleration or deceleration | 77.8 | 218.3 | 75.2 | 321.4 |
| During Power-Off stop | 201.5 | 289.2 | 354.9 | 1007.6 |

Table 1.2 (b) Force and moment that acts on robot base (SR-3iA/C)

| | Vertical moment M_v (Nm) | Force in Vertical direction F_v (N) | Horizontal moment M_H (Nm) | Force in Horizontal direction F_H (N) |
|--|-------------------------------|---|------------------------------------|---|
| During stillness | 30.9 | 205.8 | 0 | 0 |
| During acceleration or deceleration | 121.8 | 251.8 | 117.6 | 433.0 |
| During Power-Off stop | 201.5 | 308.8 | 354.9 | 1007.6 |

Table 1.2 (c) Force and moment that acts on robot base (SR-6iA, SR-6iA/H)

| | Vertical moment M _V (Nm) | Force in Vertical direction F _V (N) | Horizontal moment M _H (Nm) | Force in Horizontal direction F _H (N) |
|--|--|--|---|--|
| During stillness | 66.3 | 292.1 | 0 | 0 |
| During acceleration or deceleration | 270.3 | 328.9 | 414.6 | 752.1 |
| During Power-Off stop | 279.7 | 580.0 | 572.4 | 1155.8 |

Table 1.2 (d) Force and moment that acts on robot base (SR-6iA/C)

| | Vertical moment M _V (Nm) | Force in Vertical direction F _V (N) | Horizontal moment M _H (Nm) | Force in Horizontal direction F _H (N) |
|--|--|--|---|--|
| During stillness | 68.8 | 313.6 | 0 | 0 |
| During acceleration or deceleration | 163.3 | 383.4 | 216.8 | 553.3 |
| During Power-Off stop | 279.7 | 599.6 | 572.4 | 1155.8 |

Table 1.2 (e) Stopping time and distance until the robot stopping by Power-Off stop after input of stop signal

| | | J1 | J2 | J3 |
|----------|---|-------------|-------------|------|
| SR-3iA | Stopping time [ms] | 240 | 196 | 188 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 57.8 (1.01) | 39.8 (0.70) | 41.8 |
| | Stopping distance [mm] (J3-axis) | | | |
| SR-3iA/H | Stopping time [ms] | 216 | 225 | 268 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 57.2 (1.00) | 39.5 (0.69) | 69.3 |
| | Stopping distance [mm] (J3-axis) | | | |
| SR-3iA/C | Stopping time [ms] | 240 | 196 | 188 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 68.7 (1.20) | 41.1 (0.72) | 60.3 |
| | Stopping distance [mm] (J3-axis) | | | |
| SR-6iA | Stopping time [ms] | 252 | 292 | 144 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 53.1 (0.93) | 56.0 (0.98) | 55.8 |
| | Stopping distance [mm] (J3-axis) | | | |
| SR-6iA/H | Stopping time [ms] | 273 | 304 | 156 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 48.6 (0.85) | 54.7 (0.96) | 91.0 |
| | Stopping distance [mm] (J3-axis) | | | |
| SR-6iA/C | Stopping time [ms] | 252 | 292 | 144 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 53.2 (0.93) | 62.8 (1.10) | 55.8 |
| | Stopping distance [mm] (J3-axis) | | | |

Table 1.2 (f) Stopping time and distance until the robot stopping by Smooth stop after input of stop signal

| | | J1 | J2 | J3 |
|----------|---|-------------|-------------|-------|
| SR-3iA | Stopping time [ms] | 272 | 292 | 248 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 57.3 (1.00) | 62.2 (1.09) | 73.7 |
| | Stopping distance [mm] (J3-axis) | | | |
| SR-3iA/H | Stopping time [ms] | 272 | 271 | 272 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 56.7 (0.99) | 56.2 (0.99) | 90.4 |
| | Stopping distance [mm] (J3-axis) | | | |
| SR-3iA/C | Stopping time [ms] | 272 | 292 | 248 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 60.7 (1.06) | 64.9 (1.13) | 88.4 |
| | Stopping distance [mm] (J3-axis) | | | |
| SR-6iA | Stopping time [ms] | 292 | 256 | 300 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 61.4 (1.08) | 87.4 (1.53) | 95.4 |
| | Stopping distance [mm] (J3-axis) | | | |
| SR-6iA/H | Stopping time [ms] | 368 | 385 | 292 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 57.0 (1.00) | 87.4 (1.53) | 121.4 |
| | Stopping distance [mm] (J3-axis) | | | |
| SR-6iA/C | Stopping time [ms] | 292 | 256 | 300 |
| | Stopping distance [deg] (rad) (J1, J2-axis) | 61.4 (1.07) | 87.4 (1.53) | 95.4 |





Fig. 1.2.1 (e) Force and moment that acts on robot base

1.2.2 Angle of Mounting Surface Setting

If the robot are installed as wall mount, be sure to set the mounting angle referring to the procedure below. Refer to specifications in Section 3.1 for installation type.

- 1 Turn on the controller with the [PREV] and the [NEXT] key pressed.
- 2 Then select [3 Controlled start].
- 3 Press the [MENU] key and select “9 MAINTENANCE”.
- 4 Select the robot for which you want to set the mount angle and press the [ENTER] key.




- 5 Press the [F4] key.
- 6 Press the [ENTER] key until screen below is displayed.

*****Group 1 Initialization*****
*****R-2000iB/220U*****

--- Mount Type Setting---

1: Floor Mount
2: Wall Mount
Select mount type ?
Default value = 1

- 7 To change to the wall mount, input “2”.
- 8 Press the [ENTER] key. Then the following screen will be displayed.



- 9 Press the [FCTN] key and select "1 START (COLD)".

1.3 MAINTENANCE AREA

Fig.1.3 (a), (b) show the maintenance area of the mechanical unit. Be sure to leave enough room for the robot to be mastered. See Chapter 8 for mastering.




Fig. 1.3 (a) Maintenance area (SR-3iA, SR-3iA/H, SR-3iA/C)




Fig. 1.3 (b) Maintenance area (SR-6iA, SR-6iA/H, SR-6iA/C)

1.4 INSTALLATION CONDITIONS

Refer to the caution below concerning installation conditions.
Refer to also to the specifications found in Section 3.1.

2 CONNECTION WITH THE CONTROLLER

The robot is connected with the controller via the power cable and signal cable. Connect these cables to the connectors on the back of the robot base. Please be sure to connect the earth cable. For details on air and option cables, see Chapter 5.

⚠️ WARNING

Before turning on controller power, be sure to connect the robot and controller with the earth line (ground). Otherwise, there is the risk of electrical shock.

⚠️ CAUTION

- 1 Before connecting the cables, be sure to turn off the controller power.
- 2 Don't use 10m or longer coiled cable without first untying it. The long coiled cable will heat up and become damaged.




Fig. 2 (a) Cable connection (back side connector panel)

2. CONNECTION WITH THE CONTROLLER

B-84024EN/08




Fig. 2 (b) Cable connection (bottom side connector panel)




Fig. 2 (c) Cable connection (wall mount)

3 BASIC SPECIFICATIONS

3.1 ROBOT CONFIGURATION




Fig. 3.1 (a) Mechanical unit configuration

NOTE

There is no J4-axis for SR-3iA/H and SR-6iA/H.




Fig. 3.1 (b) Each axis coordinates and mechanical interface coordinates

NOTE

The end effector mounting face center is 0, 0, 0 of the mechanical interface coordinates.

Specifications (NOTE 1) (1/3)

| | | SR-3iA | SR-6iA |
|---|------------|--|---|
| Type | | Scara type | |
| Controlled axis | | 4-axis (J1, J2, J3, J4) | |
| Motion range (Maximum speed) (NOTE 3) | J1 | ±142° (720°/s) ±2.48 rad (12.57rad/s) | ±148° (440°/s) ±2.58 rad (7.68rad/s) |
| | J2 | ±145° (780°/s) ±2.53 rad (13.61rad/s) | ±150° (700°/s) ±2.62 rad (12.22rad/s) |
| | J3 | 200mm (1800mm/s) | 210mm (2000mm/s) |
| | J4 | ±720° (3000°/s) ±12.57 rad (52.36rad/s) Continuous rotation is available. (NOTE 4) | ±720° (2500°/s) ±12.57 rad (43.63rad/s) Continuous rotation is available. (NOTE 4) |
| Max. load capacity at wrist | | 3kg | 6kg |
| Allowable inertia At wrist | J4-axis | 0.06 kg m ² | 0.12 kg m ² |
| Repeatability | J1+J2-axis | ±0.01mm | |
| | J3-axis | ±0.01mm | |
| | J4-axis | ±0.004deg | |
| Cables and air for user | Standard | RI x 4/RO x 4, φ 6mm x 1,φ 4mm x 2 | |
| | Option | RI x 4, φ 6mm x 1, Solenoid valve x 2 | |
| Drive method | | Electric servo drive by AC servo motor | |
| Mass | | 19kg | 30kg |
| Dust proof and drip proof mechanism | | Conform to IP20 | |
| Acoustic noise level | | 70dB or less (NOTE 5) | |
| Installation environment (NOTE 7) | | Ambient temperature: 0 to 45°C (NOTE 6) Ambient humidity: Normally 75%RH or less. (No condensation allowed.) Short time (within one month) Max 95%RH (No condensation allowed.) Vibration acceleration : 4.9m/s ² (0.5G) or less Free of corrosive gases Free of heavy dust, metal dust No splash of water, water vapor, cutting oil and cleaning fluid | |

NOTE

- Even if the robot is used according to the defined specifications, motion programs might shorten reducer life or cause the robot to overheat. Use ROBOGUIDE for further evaluation before running production.
- Software setting is required to change the installation. Refer to Subsection 1.2.1.
- During short distance motions, the axis speed may not reach the maximum value stated.
- This is an option. Refer to Section 6.2.
- This value is equivalent continuous A-weighted sound pressure level that applied with ISO11201 (EN31201). This value is measured with the following conditions.
 - Maximum load and speed
 - Operating mode is AUTO
- When robot is used in low temperature environment that is near to 0°C, or robot is not operated for a long time in the environment that is less than 0°C in a holiday or the night, because viscous resistance of the drive train is so big that may cause occurrence of collision detect alarm (SRVO-050) etc. In this case, we recommend performing the warm up operation for several minutes.
- Contact the service representative when using in a place that does not meet the conditions.

Specifications (Note 1) (2/3)

| | | SR-3iA/H | SR-6iA/H |
|---|----------|--|--|
| Type | | Scara type | |
| Controlled axis | | 3-axis (J1, J2, J3) | |
| Installation (NOTE 2) | | Floor, Wall | |
| Motion range (Maximum speed) (NOTE 3) | J1 | ±142° (720°/s) ±2.48 rad (12.57rad/s) | ±148° (440°/s) ±2.58 rad (7.68rad/s) |
| | J2 | ±145° (780°/s) ±2.53 rad (13.61rad/s) | ±150° (700°/s) ±2.62 rad (12.22rad/s) |
| | J3 | 200mm (1800mm/s) | 210mm (2000mm/s) |
| Max. load capacity at wrist | | 3kg | 6kg |
| Repeatability | J1+J2 | ±0.01mm | |
| | J3 | ±0.01mm | |
| Cables and air for user | Standard | RI x 4/RO x 4, φ 6mm x 1, φ 4mm x 2 | |
| | Option | RI x 4, φ 6mm x 1, Solenoid valve x 2 | |
| Drive method | | Electric servo drive by AC servo motor | |
| Mass | | 17kg | 28kg |
| Dust proof and drip proof mechanism | | Conform to IP20 | |
| Acoustic noise level | | 70dB or less (NOTE 4) | |
| Installation environment (NOTE 6) | | Ambient temperature: 0 to 45°C (NOTE 5) Ambient humidity: Normally 75%RH or less. (No condensation allowed.) Short time (within one month) Max 95%RH (No condensation allowed.) Vibration acceleration : 4.9m/s ² (0.5G) or less Free of corrosive gases Free of heavy dust, metal dust No splash of water, water vapor, cutting oil and cleaning fluid | |

NOTE

- Even if the robot is used according to the defined specifications, motion programs might shorten reducer life or cause the robot to overheat. Use ROBOGUIDE for further evaluation before running production.
- Software setting is required to change the installation. Refer to Subsection 1.2.1.
- During short distance motions, the axis speed may not reach the maximum value stated.
- This value is equivalent continuous A-weighted sound pressure level that applied with ISO11201 (EN31201). This value is measured with the following conditions.
 - Maximum load and speed
 - Operating mode is AUTO
- When robot is used in low temperature environment that is near to 0°C, or robot is not operated for a long time in the environment that is less than 0°C in a holiday or the night, because viscous resistance of the drive train is so big that may cause occurrence of collision detect alarm (SRVO-050) etc. In this case, we recommend performing the warm up operation for several minutes.
- Contact the service representative when using in a place that does not meet the conditions.

3. BASIC SPECIFICATIONS

B-84024EN/08

Specifications (NOTE 1) (3/3)

| | | SR-3iA/C | SR-6iA/C |
|---|------------|--|---|
| Type | | Scara type | |
| Controlled axis | | 4-axis (J1, J2, J3, J4) | |
| Installation (NOTE 2) | | Floor, Wall | |
| Motion range (Maximum speed) (NOTE 3) | J1 | ±142° (720°/s) ±2.48 rad (12.57rad/s) | ±148° (440°/s) ±2.58 rad (7.68rad/s) |
| | J2 | ±145° (780°/s) ±2.53 rad (13.61rad/s) | ±150° (700°/s) ±2.62 rad (12.22rad/s) |
| | J3 | 200mm (1800mm/s) | 210mm (2000mm/s) |
| | J4 | ±720° (3000°/s) ±12.57 rad (52.36rad/s) Continuous rotation is available. (NOTE 4) | ±720° (2500°/s) ±12.57 rad (43.63rad/s) Continuous rotation is available. (NOTE 4) |
| Max. load capacity at wrist | | 3kg | 6kg |
| Allowable inertia At wrist | J4-axis | 0.06 kg m ² | 0.12 kg m ² |
| Repeatability | J1+J2-axis | ±0.01mm | |
| | J3-axis | ±0.01mm | |
| | J4-axis | ±0.004deg | |
| Cables and air for user | Standard | RI x 4/RO x 4, φ 6mm x 1,φ 4mm x 2 | |
| | Option | RI x 4, φ 6mm x 1, Solenoid valve x 2 | |
| Drive method | | Electric servo drive by AC servo motor | |
| Mass | | 21kg | 32kg |
| Dust proof and drip proof mechanism | | Conform to IP54 | |
| Clean class | | ISO class 2 to 5 | |
| Acoustic noise level | | 70dB or less (NOTE 5) | |
| Installation environment (NOTE 7) | | Ambient temperature: 0 to 45°C (NOTE 6) Ambient humidity: Normally 75%RH or less. (No condensation allowed.) Short time (within one month) Max 95%RH (No condensation allowed.) Vibration acceleration : 4.9m/s ² (0.5G) or less Free of corrosive gases Free of heavy dust, metal dust No splash of water, water vapor, cutting oil and cleaning fluid | |

NOTE

- Even if the robot is used according to the defined specifications, motion programs might shorten reducer life or cause the robot to overheat. Use ROBOGUIDE for further evaluation before running production.
- Software setting is required to change the installation. Refer to Subsection 1.2.1.
- During short distance motions, the axis speed may not reach the maximum value stated.
- This is an option. Refer to Section 6.2.
- This value is equivalent continuous A-weighted sound pressure level that applied with ISO11201 (EN31201). This value is measured with the following conditions.
 - Maximum load and speed
 - Operating mode is AUTO
- When robot is used in low temperature environment that is near to 0°C, or robot is not operated for a long time in the environment that is less than 0°C in a holiday or the night, because viscous resistance of the drive train is so big that may cause occurrence of collision detect alarm (SRVO-050) etc. In this case, we recommend performing the warm up operation for several minutes.
- Contact the service representative when using in a place that does not meet the conditions.

The following table lists the IEC60529-based Severe dust/liquid protection characteristics.

| | SR-3iA, SR-3iA/H SR-6iA, SR-6iA/H | SR-3iA/C, SR-6iA/C |
|------------|--|---------------------------|
| Main body | IP20 | IP54 |
| Controller | IP20 | IP20 |

NOTE

Definition of IP code (Protection structure rating)

Definition of IP 20

2→Materials which diameter is larger than 12mm does not intrude internal.

0→No protection against water

Definition of IP 54

5→Dust-tight: Ingress of dust is not entirely prevented, but it must not enter in sufficient quantity to interfere with the satisfactory of the equipment.

4→Protection from water immersion: Water splashing against the enclosure from any direction shall have no harmful effect.

Performance of resistant chemicals and resistant solvents

- (1) The robot cannot be used with the following liquids. Potentially these liquids will cause irreversible damage to the rubber parts (such as: gaskets, oil seals, O-rings etc.). (As exception to this only liquids tested and approved by FANUC can be used with the robot.)
 - (a) Organic solvents
 - (b) Cutting fluid or detergent including chlorine / gasoline
 - (c) Amine type cutting fluid or detergent
 - (d) Acid, alkali and liquid causing rust
 - (e) Other liquids or solutions, that will harm NBR or CR rubber
- (2) Do not use unconfirmed liquid.
- (3) Do not use the robot immersed in water, neither temporary nor permanent. Robot must not be wet permanently.

3.1.1 Tool flange option

A tool flange (A05B-1116-K113) is prepared as an option for installation to the wrist.

- Mass of the tool flange is 0.16kg.
- Refer to Section 3.2 and 4.2 for the operating space and the equipment mounting surface when installing the tool flange.
- Refer to Section 4.3 for load information of the tool flange.
- The wrist load condition (Section 3.4) is same without the flange.

3.2 MECHANICAL UNIT OPERATING SPACE AND INTERFERENCE AREA

Fig. 3.2 (a) to (d) show the robot operating space. When installing peripheral equipment, be careful not to interfere with the robot and its operating space.




Fig. 3.2 (a) Operating space (SR-3iA, SR-3iA/H)

NOTE

Please read J4-axis as J3-axis throughout this figure in case of SR-3iA/H.




Fig. 3.2 (b) Operating space (SR-3iA/C)




Fig. 3.2 (c) Operating space (SR-6iA, SR-6iA/H)

NOTE

Please read J4-axis as J3-axis throughout this figure in case of SR-6iA/H.




Fig. 3.2 (d) Operating space (SR-6iA/C)

3.3 ZERO POINT POSITION AND MOTION LIMIT

A zero point and motion range are provided for each controlled axis. Exceeding the software motion limit of a controlled axis is called overtravel (OT). Overtravel is detected at both ends of the motion limit for each axis. The robot cannot exceed the motion range unless there is a loss of the zero point position due to abnormalities in servo system or a system error. In addition, a mechanical stopper is also used to limit maximum motion and to improve safety.

Fig. 3.3 (a) to (d) show the position of the mechanical stopper. Don't reconstruct the mechanical stopper. If you do, there is a possibility that the robot will not stop normally.




Fig. 3.3 (a) Position of mechanical stopper (SR-3iA, SR-3iA/H)




Fig. 3.3 (b) Position of mechanical stopper (SR-3iA/C)




Fig. 3.3 (c) Position of mechanical stopper (SR-6iA, SR-6iA/H)




Fig. 3.3 (d) Position of mechanical stopper (SR-6iA/C)

Fig. 3.3 (e) to (m) show the zero point, motion limit and maximum stopping distance (stopping distance in condition of max speed and max load) of each axis.

Only in case of the J1-axis, when the robot comes in contact with the mechanical stopper, it may deform. When the mechanical stopper is deformed, replacement is needed. Contact FANUC about replacing J1-axis mechanical stopper.

- * The motion range can be changed. For information on how to change the motion range, see Chapter 6, "AXIS LIMIT SETUP".




Fig. 3.3 (e) J1-axis motion limit (SR-3iA, SR-3iA/H, SR-3iA/C)




Fig. 3.3 (f) J1-axis motion limit (SR-6iA, SR-6iA/H, SR-6iA/C)




Fig. 3.3 (g) J2-axis motion limit (SR-3iA, SR-3iA/H, SR-3iA/C)




Fig. 3.3 (h) J2-axis motion limit (SR-6iA, SR-6iA/H, SR-6iA/C)




Fig. 3.3 (i) J3-axis motion limit (SR-3iA, SR-3iA/H)




Fig. 3.3 (j) J3-axis motion limit (SR-3iA/C)




Fig. 3.3 (k) J3-axis motion limit (SR-6iA, SR-6iA/H)




Fig. 3.3 (l) J3-axis motion limit (SR-6iA/C)




Fig. 3.3 (m) J4-axis motion limit (SR-3iA, SR-3iA/C, SR-6iA, SR-6iA/C)

3.4 WRIST LOAD CONDITIONS

Fig. 3.4 (a) and (e) show diagram to limit loads applied to the wrist. Offset value of the Z direction is when $-100\text{mm} < J3 < 0\text{mm}$. If $J3 < -100\text{mm}$, allowable offset value of the Z direction becomes $(100\text{mm} + J3)$ smaller when J1, J2-axis move. In addition, in case of $J3 < -100\text{mm}$, the allowable offset value of the Z direction is as Fig. 3.4 (a) and (e) when J1, J2-axis do not move.

- Apply a load within the region indicated in the graph.
- For the zero point and the motion range of the J3-axis, refer to Fig. 3.3 (i) and (l) in Section 3.3.
- See Section 4.1 about the mounting of an end effector.




Fig. 3.4 (a) Wrist load diagram (SR-3iA, SR-3iA/H, SR-3iA/C)

NOTE

- The diagram changes depending on the conditions. See Fig. 3.4 (b) and (c).
- The robot might vibrate even if wrist load in diagram. At this time, reduce the acceleration.

Condition 1: For J3 joint position ≥ -100 mm

Condition 2: For J3 joint position < -100 mm (When J1 and J2 are not moving)




Fig. 3.4 (b) Wrist load diagram (SR-3iA, SR-3iA/H, SR-3iA/C) (condition 1&2)

NOTE

- Condition 1: For J3 joint position ≥ -100 mm
All areas of the diagram are applicable.
- Condition 2: For J3 joint position < -100 mm (When J1 and J2 are not moving)
All areas of the diagram are applicable.

Condition 3: For J3 joint position < -100 mm (When J1 and J2 are moving)




Fig. 3.4 (c) Wrist load diagram (SR-3iA, SR-3iA/H, SR-3iA/C) (condition 3)

NOTE

Condition 3: For J3 joint position < -100 mm (When J1 and J2 are moving)
Correction is required for the diagram. See the example below for details.

Example of the condition 3

When J3 joint position is -130 mm (When J1 and J2 are moving), the offset value of the Z direction will be 3 cm (-130 + 100 = -30 mm) smaller. The correction process is as follows.




Fig. 3.4 (d) Wrist load diagram (SR-3iA, SR-3iA/H, SR-3iA/C) (example of condition 3)




Fig. 3.4 (e) Wrist load diagram (SR-6iA, SR-6iA/H, SR-6iA/C)

NOTE

- The diagram changes depending on the conditions. See Fig. 3.4 (f) and (g).
- The robot might vibrate even if wrist load in diagram. At this time, reduce the acceleration.

Condition 1: For J3 joint position ≥ -100 mm

Condition 2: For J3 joint position < -100 mm (When J1 and J2 are not moving)




Fig. 3.4 (f) Wrist load diagram (SR-6iA, SR-6iA/H, SR-6iA/C) (condition 1&2)

NOTE

- Condition 1: For J3 joint position ≥ -100 mm
All areas of the diagram are applicable.
- Condition 2: For J3 joint position < -100 mm (When J1 and J2 are not moving)
All areas of the diagram are applicable.

Condition 3: For J3 joint position < -100 mm (When J1 and J2 are moving)




Fig. 3.4 (g) Wrist load diagram (SR-6iA, SR-6iA/H, SR-6iA/C) (condition 3)

NOTE

Condition 3: For J3 joint position < -100 mm (When J1 and J2 are moving)
Correction is required for the diagram. See the example below for details.

Example of the condition 3

When J3 joint position is -130 mm (When J1 and J2 are moving), the offset value of the Z direction will be 3 cm (-130 + 100 = -30 mm) smaller. The correction process is as follows.




Fig. 3.4 (h) Wrist load diagram (SR-6iA, SR-6iA/H, SR-6iA/C) (example of condition 3)

4 EQUIPMENT INSTALLATION TO THE ROBOT

4.1 END EFFECTOR INSTALLATION TO WRIST

Fig. 4.1 (a), (b) are the diagrams for installing end effectors on the wrist. Select screws and positioning pins of a length that matches the depth of the tapped and pin holes. Fasten the bolt for attaching the end effector referring to Appendix B for the tightening torque.

⚠ CAUTION

Observe the following when installing the device because end effector mounting face may damaged.

- 1 When attaching a flange, fix it with a friction fastener and do not fix it only with a set screw.
- 2 When using a set screw, adhere the screw tip to the width across flats.
- 3 The tooling coupling depth to wrist flange should be shorter than the flange coupling length.

When installing the equipment using the friction type fastening fixture to SR-3iA, SR-3iA/H, SR-6iA, SR-6iA/H, make the surface pressure on the friction surface less than 70N/mm^2 .
(reference)

Allowable maximum thrust force at the end effector tip

: 150N (SR-3iA, SR-3iA/H), 200N (SR-6iA, SR-6iA/H)

Allowable maximum torque at the end effector tip

: 16Nm (SR-3iA, SR-3iA/H), 35Nm (SR-6iA, SR-6iA/H)




Fig. 4.1 (a) Surface for installing the end effector (SR-3iA, SR-3iA/H, SR-6iA, SR-6iA/H)



CAUTION

Observe the following when installing the device because end effector mounting face may damaged.

1. When attaching a flange, fix it with a friction fastener and do not fix it only with a set screw.
2. When using a set screw, adhere the screw tip to the width across flats.
3. The tooling coupling depth to wrist flange should be shorter than the flange coupling length.

When installing the equipment using the friction type fastening fixture to SR-3iA/C, SR-6iA/C, make the surface pressure on the friction surface less than 110N/mm².

(reference)

Allowable maximum thrust force at the end effector tip

: 150N (SR-3iA/C), 200N (SR-6iA/C)

Allowable maximum torque at the end effector tip

: 16Nm (SR-3iA/C), 35Nm (SR-6iA/C)




Fig. 4.1 (b) Surface for installing the end effector (SR-3iA/C, SR-6iA/C)

When tool flange option are specified

Fig. 4.1 (c) shows end effector mounting face when the tool flange option is specified.

Apply grease (*) to the tool flange fixing bolt(M4 x 20) to secure the axial tension, and tighten it at 4.5Nm.
(* Do not use grease containing molybdenum disulfide.)

The end effector locates it using a fitting, the pin hole of [B] of a [A] part or the [D] part and fixes it using a tap of [C]. Choose the length of the bolts to be used so that engagement length is 6mm to 8mm.

- Tighten the fixing bolts with the following torque.
- Set the load parameter of the end effector including the tool flange. (Refer to Section 4.3)

Hexagon socket head bolt (Tensile strength 1200N/mm² or more)

| Nominal diameter | Tightening torque N·m (kgf·cm) | |
|------------------|--------------------------------|-------------|
| | Upper limit | Lower limit |
| M5 | 7.9 (81) | 5.6 (57) |




Fig. 4.1 (c) End effector mounting face (tool flange option)

4.2 EQUIPMENT MOUNTING FACE

As shown in Fig. 4.2 (a) to (d), tapped holes are provided to install equipment to the robot.

⚠ CAUTION

- 1 Never perform additional machining operations such as drilling or tapping on the robot body. This can seriously affect the safety and functions of the robot.
- 2 Note that the use of a tapped hole not shown in the following figure is not assured. Please do not tighten both with the tightening bolts used for mechanical unit.
- 3 Equipment should be installed so that mechanical unit cable is not pinched or damaged. If equipment installation restricts or damages the mechanical unit cable, it might become disconnected, and unexpected conditions might occur.




Fig. 4.2 (a) Equipment mounting faces (SR-3iA, SR-3iA/H)

4. EQUIPMENT INSTALLATION TO THE ROBOT

B-84024EN/08




Fig. 4.2 (b) Equipment mounting faces (SR-3iA/C)

4. EQUIPMENT INSTALLATION TO THE ROBOT

B-84024EN/08




Fig. 4.2 (c) Equipment mounting faces (SR-6iA, SR-6iA/H)

4. EQUIPMENT INSTALLATION TO THE ROBOT

B-84024EN/08




Fig. 4.2 (d) Equipment mounting faces (SR-6iA/C)

4.3 PAYLOAD SETTING

⚠ CAUTION

Set the correct load condition parameter before the robot runs. Do not operate the robot in over when its payload is exceeded or incorrect. Do not exceed the allowable payload including connection cables and its swing. Operation in with the robot over payload may result in troubles such as reducer life reduction.

NOTE

Explanation in this chapter is for when teach pendant (option) is selected.

Overview

Payload setting is a setting of the payload which is mounted on the robot. It consists of payload data such as weight, center of gravity, etc. Setting appropriate payload data can bring the following effects:

- Improvement in motion performance (such as reduction of vibration and cycle time)
- More effective performance of functions related to dynamics (such as collision detection and gravity compensation).

Wrong payload data can cause vibration, mis-detection of collision, and so on. For effective use of the robot, set appropriate data of the load such as a hand, a workpiece, and an armload (equipment mounted on the robot arm, not on the face plate).

You can set the payload data using "Motion Performance screens". In these screens, you can set up 10 schedules of payload setting. If you set up two or more payload schedules in advance, you can achieve appropriate payload setting only by switching the schedule number according to changing of actual payload. You can also change the schedule number using program instruction which you can place anywhere in TP program. (Refer to the Subsection 4.10 PAYLOAD INSTRUCTION of the CONTROLLER OPERATOR'S MANUAL (B-83284EN).)

As an option function, "Payload Identification" is available. This function enables the robot to calculate load information automatically.

Motion Performance Screens (Payload setting screen)

You can set the payload data using "Motion Performance screens". Motion Performance screens consist of list screen, payload setting screen and armload setting screen.

Table 4.3 (a) Motion Performance screen

| Screen name | Description |
|-------------------------------------|---|
| MOTION PERFORMANCE (List screen) | A screen to display the list of payload schedules (No. 1 ~ No. 10). You can also check or switch the active schedule number in this screen. |
| MOTION / PAYLOAD SET | A screen for detailed payload data for each schedule. You can display or modify the values of payload weight, gravity center position and inertia in this screen. This screen is provided for each individual payload setting number. |
| MOTION / ARMLOAD SET | A screen for armload (equipments mounted on the robot arm, not on the face plate). You can set the weight of equipments mounted on such as J2 base and J3 arm. |

The following description is a procedure to show Motion Performance screen, to input payload data and to activate the payload schedule. You can also modify the setting values later.

NOTE

Depending on the combination of robot model and option, the payload data may be set in advance.

Step

- 1 Press the [MENU] key to display the screen menu.
- 2 Press "0 NEXT", then select "6 SYSTEM".
- 3 Press F1 [TYPE] to display the screen switch menu.
- 4 Select "Motion". The list screen ("MOTION PERFORMANCE" screen) appears. (If a screen other than the list screen appears, press the [PREV] key several times until the list screen appears.) For a multi-group system, if you want to go to the list screen of the other group, press F2, "GROUP" then enter the group number you like.

| MOTION PERFORMANCE | | JOINT 10% |
|--------------------|-------------|-----------|
| No. | PAYLOAD[kg] | Comment |
| 1 | 6.00 | [] |
| 2 | 0.00 | [] |
| 3 | 0.00 | [] |
| 4 | 0.00 | [] |
| 5 | 0.00 | [] |
| 6 | 0.00 | [] |
| 7 | 0.00 | [] |
| 8 | 0.00 | [] |
| 9 | 0.00 | [] |
| 10 | 0.00 | [] |

Active PAYLOAD number =0
 [TYPE] GROUP DETAIL ARMLOAD SETIND >

NOTE

Up to 10 of payload data can be set as standard. The number of payload data can be increased up to 256 by the following way. (up to 32 in R-30iB and R-30iB Mate)

- a. Turn on the controller with [PREV] and [NEXT] key pressed.
- b. Select "3 Controlled start".
- c. Press the [MENU] key.
- d. Select "4 Variables"
- e. Set the number of payload data to the system variable \$PLST_SCHNUM.
- f. Restart (power off/on) the controller and "Control start" again.
- g. Press the [FCTN] key.
- h. Select "1 START (COLD)".

- 5 Move the cursor to the schedule number you want to set up, and press F3, "DETAIL" to display PAYLOAD SET screen of the selected schedule number.

| MOTION PAYLOAD SET | | JOINT 10% |
|--|-------------|-----------|
| Group 1 | | |
| 1 Schedule No[| 1]:[Comment |] |
| 2 PAYLOAD | [kg] | 6.00 |
| 3 PAYLOAD CENTER X [cm] | | 0.00 |
| 4 PAYLOAD CENTER Y [cm] | | 0.00 |
| 5 PAYLOAD CENTER Z [cm] | | 0.49 |
| 6 PAYLOAD INERTIA X [kgfcms ²] | | 0.50 |
| 7 PAYLOAD INERTIA Y [kgfcms ²] | | 0.50 |
| 8 PAYLOAD INERTIA Z [kgfcms ²] | | 1.00 |

[TYPE] GROUP NUMBER DEFAULT HELP

4. EQUIPMENT INSTALLATION TO THE ROBOT

B-84024EN/08

6 Enter the weight, gravity center position of the load, and inertia about its gravity center. If required, you can enter the comment. The entered comment is displayed in list screen.

The X, Y, and Z directions displayed in the PAYLOAD SET screen correspond to those in the default tool coordinate system (“default” means no Tool frame is set).




Fig. 4.3 (a) Standard tool coordinate

m : Mass (kg)

xg : Center of gravity x direction (m)

yg : Center of gravity y direction (m)

zg : Center of gravity z direction (m)


Ix : Inertia at the center of the gravity (around the axis in the x direction through the center of gravity) (kgm²)

Iy : Inertia at the center of the gravity (around the axis in the y direction through the center of gravity) (kgm²)


Iz : Inertia at the center of the gravity (around the axis in the z direction through the center of gravity) (kgm²)

W : Mass (kg)
J : Inertia (kgm²)
a, b, l, r : Length (m)


Expressions for calculating inertia around the center of gravity (geometric inertia)




$$J_i = W \frac{a^2 + b^2}{12}$$



$$J_i = W \frac{l^2}{12}$$



$$J_i = W \frac{r^2}{2}$$



$$J_i = W \frac{2r^2}{5}$$

Fig. 4.3 (b) Calculating center of the gravity inertia

NOTE

- 1 If a hand or workpiece has a complicated shape, divide it into simple shapes as shown above. Calculate the geometric inertia and offset inertia of each shape, then obtain their sum.
- 2 Confirm the input units in the payload setting screen. If necessary convert values using the equation below.
 $1\text{kgfcm}^2 = 0.098\text{kgm}^2 (=980\text{kgcm}^2)$

When you change the value, a confirmation message "Path and Cycle time will change. Set it?" appears. Press F4, "YES" or F5, "NO".

Then, you may see a message "Load is OVER spec! Accept?". This message indicates the load exceeds the capacity of the robot. Reconfigure your system so that the load does not exceed the capacity.

In another case, you may see a message "Load is close to capacity! Accept?". This message indicates the load is close to capacity although it does not exceed the capacity.

⚠ CAUTION

Don't install a load which exceeds the capacity of the robot because overload can cause a life loss of the reducer.

- 7 If you want to go to the screen of the other schedule number, press F3, "NUMBER" then enter the schedule number you like. For a multi-group system, if you want to go to the screen of the other group, press F2, "GROUP" then enter the group number you like.
- 8 Activate payload schedule you are going to use. Press the [PREV] key to go back to the list screen, press F5, "SETIND", and enter the index number of payload schedule you are going to use.

NOTE

The initial schedule number is 0. In order to activate the payload setting you entered, you need to set the schedule number to 1-10. If the schedule number is 0, the system uses the default payload value which is shown in the screen before you change the value.

When the tool flange (option) is specified, consider the following load information.




Fig.4.3 (b) Load information of the tool flange (option)

5 PIPING AND WIRING TO THE END EFFECTOR

WARNING

- Only use appropriately-specified mechanical unit cables.
- Do not add user cables or hoses inside of the mechanical unit.
- Please do not obstruct the movement of the mechanical unit cable when cables are added to the outside of the mechanical unit.
- Please do not perform remodeling (adding a protective cover, or secure an additional outside cable) that obstructs the behavior of the cable.
- When external equipment is installed on the robot, make sure that it does not interfere with other parts of the robot.
- Cut and discard any unnecessary length of wire strand of the end effector (hand) cable. Insulate the cable with seal tape. (See Fig. 5 (a))
- If you have end effector wiring and a process that develops static electricity, keep the end effector wiring as far away from the process as possible. If the end effector and process must remain close, be sure to insulate the cable.
- Be sure to seal the connectors of the user cable and terminal parts of all cables to prevent water from entering the mechanical unit. Also, attach the cover to the unused connector.
- Especially in case of SR-3iA/C, SR-6iA/C, attach the optional cap (A05B-1139-K051) to the EE interface to ensure the dustproof and waterproof performance.
- Frequently check that connectors are tight and cable jackets are not damaged.
- When precautions are not followed, damage to cables might occur. Cable failure may result in incorrect function of the end effector, robot faults, or damage to robot electrical hardware. In addition, electric shock could occur when touching the power cables.




Fig. 5 (a) Treatment method of end effector (hand) cable

5.1 AIR SUPPLY

Air supply holes ($\phi 4$ and $\phi 6$) exists on the J1-axis connector panel for end effector as shown in Section 5.2. There is a mechanical unit cable which includes solenoid valve as shown in Table 5.1 (a).

When the solenoid valve is replaced, the entire manifold should be replaced.

Table 5.1 (a) Optional solenoid valves

| Mechanical unit cable spec. | Model | Description | Solenoid (Manifold) spec. | Remarks | RO |
|--|----------|---|---|----------------|----------|
| A05B-1116-H201 A05B-1116-H301 A05B-1116-H311 | SR-3iA | Path 3 air piping, RO connector output (without solenoid valve) | — | — | — |
| A05B-1116-H203 A05B-1116-H303 A05B-1116-H313 | SR-3iA/H | Path 3 air piping, RO connector output (without solenoid valve) | — | — | — |
| A05B-1116-H207 | SR-3iA/C | Path 3 air piping, RO connector output (without solenoid valve) | — | — | — |
| A05B-1117-H201 A05B-1117-H301 A05B-1117-H311 | SR-6iA | Path 3 air piping, RO connector output (without solenoid valve) | — | — | — |
| A05B-1117-H203 A05B-1117-H303 A05B-1117-H313 | SR-6iA/H | Path 3 air piping, RO connector output (without solenoid valve) | — | — | — |
| A05B-1117-H207 | SR-6iA/C | Path 3 air piping, RO connector output (without solenoid valve) | — | — | — |
| A05B-1116-H202 A05B-1116-H302 A05B-1116-H312 | SR-3iA | Double solenoids x 2 | A97L-0218-0147#D2 (manufactured by SMC) | 2 position x 2 | RO1 to 4 |
| A05B-1116-H204 A05B-1116-H304 A05B-1116-H314 | SR-3iA/H | Double solenoids x 2 | A97L-0218-0147#D2 (manufactured by SMC) | 2 position x 2 | RO1 to 4 |
| A05B-1116-H205 A05B-1116-H305 A05B-1116-H315 | SR-3iA | Double solenoids x 2 | A97L-0218-0153#D2 (manufactured by SMC) | 2 position x 2 | RO1 to 4 |
| A05B-1116-H206 A05B-1116-H306 A05B-1116-H316 | SR-3iA/H | Double solenoids x 2 | A97L-0218-0153#D2 (manufactured by SMC) | 2 position x 2 | RO1 to 4 |
| A05B-1116-H208 | SR-3iA/C | Double solenoids x 2 | A97L-0218-0153#D2 (manufactured by SMC) | 2 position x 2 | RO1 to 4 |
| A05B-1117-H202 A05B-1117-H302 A05B-1117-H312 | SR-6iA | Double solenoids x 2 | A97L-0218-0147#D2 (manufactured by SMC) | 2 position x 2 | RO1 to 4 |
| A05B-1117-H204 A05B-1117-H304 A05B-1117-H314 | SR-6iA/H | Double solenoids x 2 | A97L-0218-0147#D2 (manufactured by SMC) | 2 position x 2 | RO1 to 4 |
| A05B-1117-H205 A05B-1117-H305 A05B-1117-H315 | SR-6iA | Double solenoids x 2 | A97L-0218-0153#D2 (manufactured by SMC) | 2 position x 2 | RO1 to 4 |
| A05B-1117-H206 A05B-1117-H306 A05B-1117-H316 | SR-6iA/H | Double solenoids x 2 | A97L-0218-0153#D2 (manufactured by SMC) | 2 position x 2 | RO1 to 4 |
| A05B-1117-H208 | SR-6iA/C | Double solenoids x 2 | A97L-0218-0153#D2 (manufactured by SMC) | 2 position x 2 | RO1 to 4 |

Available section area of the solenoid valve : 1.95mm^2 (CV value : 0.11)

NOTE

Attach an air filter with a mesh size of $5\mu\text{m}$ or better on the upstream side near the robot. Compressed air including much drainage causes valve malfunctions. Take action to prevent the entry of drainage, and also drain the air filter periodically.

| | | |
|--------------|-----------------------|--|
| Air pressure | Supply air pressure | 0.49 to 0.69MPa (5 to 7kgf/cm ²), Setting: 0.49MPa (5kgf/cm ²) |
| | Amount of consumption | Maximum instantaneous amount 120Nl/min (0.12Nm ³ /min) |

* The air should be dry. Do not use oiled compressed air.

5.2 AIR SUPPLY AND EE (RI/RO) INTERFACE

Fig. 5.2 (a) to (g) show air supply and EE (RI/RO) interface position.





Fig. 5.2 (a) Air supply and EE (RI/RO) interface position

5. PIPING AND WIRING TO THE END EFFECTOR


B-84024EN/08



**Fig. 5.2 (b) Air supply and EE (RI/RO) interface
(SR-3iA, SR-3iA/H)(1/2)**

5. PIPING AND WIRING TO THE END EFFECTOR


B-84024EN/08



**Fig. 5.2 (c) Air supply and EE (RI/RO) interface
(SR-3iA, SR-3iA/H)(2/2)**

5. PIPING AND WIRING TO THE END EFFECTOR


B-84024EN/08



**Fig. 5.2 (d) Air supply and EE (RI/RO) interface
(SR-3iA/C)**

5. PIPING AND WIRING TO THE END EFFECTOR


B-84024EN/08



**Fig. 5.2 (e) Air supply and EE (RI/RO) interface
(SR-6iA, SR-6iA/H)(1/2)**

5. PIPING AND WIRING TO THE END EFFECTOR

B-84024EN/08



**Fig. 5.2 (f) Air supply and EE (RI/RO) interface
(SR-6iA, SR-6iA/H) (2/2)**

5. PIPING AND WIRING TO THE END EFFECTOR

B-84024EN/08




Fig. 5.2 (g) Air supply and EE (RI/RO) interface (SR-6iA/C)

Fig. 5.2 (h), (i) show pin layout for EE interface (RI/RO).




Fig. 5.2 (h) EE (RI/RO) interface (When A05B-1116-H201,H203,H207, H301,H303,H311,H313, A05B-1117-H201,H203,H207,H301,H303,H311,H313 are specified)

5. PIPING AND WIRING TO THE END EFFECTOR

B-84024EN/08




Fig. 5.2 (i) EE (RI/RO) interface
(When A05B-1116-H202, H204, H205, H206, H208, H302, H304, H305, H306, H312, H314, H315, H316
A05B-1117-H202, H204, H205, H206, H208, H302, H304, H305, H306, H312, H314, H315, H316 are specified)

NOTE

For wiring of the peripheral device to the EE interface, refer to "CONNECTIONS WITH EQUIPMENT" of manuals below, too.
MAINTENANCE MANUAL (B-84035EN)

Connector specifications

Table 5.2 (a) show the connector parts supported by the EE interface. Some of these parts are available as an option from FANUC. (Table 5.2 (b))

Table 5.2 (a) Supported connector (user side)

| Maker | Manufacturer specification | Remarks |
|--------------------------|--|---|
| Hirose Electric Co. Ltd. | Plug: RM15WTPZ-12P(76) Clamp: JR13WCC-*(72) | Straight type connector (12 pins) *indicates an applicable cable diameter selected from the following: * : ϕ 5, 6, 7, 8, 9, 10mm |
| | Plug: RM15WTLP-12P(33) Clamp: JR13WCC-*(72) | Elbow type connector (12 pins) *indicates an applicable cable diameter selected from the following: * : ϕ 5, 6, 7, 8, 9, 10mm |

Table 5.2 (b) Supported option

| Option specification | Remarks |
|----------------------|--|
| A05B-1137-J057 | Straight type connector (12-pins) Applicable cable diameter : 8mm |
| A05B-1137-J058 | Elbow type connector (12-pins) Applicable cable diameter : 9mm |
| A05B-1116-K421 | Cable with straight type connector (12-pins) 2200mm |

Table 5.2 (c) Specification of J2 connector panel caps

| Part name | Specification |
|---------------|-------------------|
| Cap (EE) (*1) | A97L-0118-0757#21 |
| Cap (EE) (*2) | A05B-1139-K051 |

The interface is covered by simple plastic cap (*1) at ex-factory. If water-proof is needed, please order caps (*2). These caps are attachments at ex-factory.

NOTE

For details, such as the dimensions, refer to the related catalogs offered by the respective manufacturers, or contact your local FANUC representative.

6 AXIS LIMIT SETUP

When axis limits are defined, the motion range of the robot can be changed from the standard value. The motion range of the robot axes can be restricted because of:

- Used motion range limitations
- Tools and peripheral equipment interfere each other in some areas.
- Length of the cable or hose attached to the application is limited.
- The software method used to prevent the robot from going beyond the necessary motion range.
- Axis limit by DCS (All axes)

⚠ WARNING

Changing the motion range of any axis affects the operation range of the robot. To avoid trouble, carefully consider a possible effect of the change to the movable range of each axis in advance. Otherwise, it is likely that an unexpected condition occurs; for example, an alarm may occur in a previous taught position.

NOTE

Explanation in this chapter is for when teach pendant (option) is selected.

6.1 CHANGE AXIS LIMIT BY DCS (OPTION)


The robot motion can be restricted with DCS (Dual check safety) function. For J2/J3-axis, the same effect as an adjustable mechanical stopper can be obtained.

The robot motion can be restricted at any angle and position if it is in robot motion area. DCS functions are certified to meet the requirements of International Standard ISO13849-1 and IEC61508 approved by certificate authority. If only the operating space is set using Joint Position Check, the robot stops after it goes beyond the workspace. When the motor power is shut down, the robot's momentum causes it to move some distance before it completely stops. The actual "Robot Stop Position" will be beyond the workspace. To stop the robot within the robot workspace, use the DCS Stop Position Prediction function. The stop position prediction is disabled by default.


As an example, we show the procedure to set $\pm 90^\circ$ for J2-axis in here. Refer to Dual check safety function Operator's Manual (B-83184EN) for details of other setting, function and DCS stop position prediction.

Setting procedure


- 1 Press the [MENU] key to display the screen menu.
- 2 Press [0 NEXT] and press [6 SYSTEM].
- 3 Press the F1 ([TYPE]).
- 4 Select [DCS]. The following screen will be displayed.



5 Move the cursor to [1 Joint position check], then press the [DETAIL].



6 Move the cursor to [1], then press the [DETAIL].




7 Move the cursor to [DISABLE], then press [CHOICE], set the status to [ENABLE].
 8 Move the cursor to [Group], then input the robot group number, then press the [ENTER] key.
 9 Move the cursor to [Axis], then input “2”, then press the [ENTER] key.
 10 Move the cursor to [Upper limit] right side, then input “90”, then press the [ENTER] key.
 11 Move the cursor to [Lower limit] right side, then input “-90”, then press the [ENTER] key.




WARNING


If only the operating space is set using Joint Position Check, the robot stops after it goes beyond the workspace. When the motor power is shut down, the robot's momentum causes it to move some distance before it completely stops. The actual "Robot Stop Position" will be beyond the workspace. To stop the robot within the robot workspace, use the DCS Stop Position Prediction function. The stop position prediction is disabled by default.




12 Press the [PREV] key two times, back to the first screen.



13 Press the [APPLY].
14 Input 4-digit password, then press the [ENTER] key. (Password default setting is “1111”.)
15 The following screen will be displayed, then press the [OK].



[CHGD] on the right side of [1 Joint position check] will change to [PEND].



16 Cycle the power of the controller in the cold start mode so the new settings are enabled.

⚠ WARNING

You must cycle the power of the controller to enable the new setting. If you fail to do so, the robot does not work normally and it may injure personnel or damage the equipment.

6.2 J4-AXIS MOTION RANGE EXTENSION BY CONTINUOUS ROTATION FUNCTION

The continuous rotation function allows continuous and limitless rotation about the final axis or an additional rotation axis of the robot in one direction.

For SR-3iA, SR-3iA/C, SR-6iA, SR-6iA/C, the final axis J4-axis can be the target of this function.

For the general setup and details of continuous rotation function, refer to “Optional Function OPERATOR’S MANUAL” (B-83284EN-2).

For the robot, this function is available on the system software 7DF1/17 (V9.10P/17) or later.

When you set up J4-axis axis of the robot as a continuous rotation axis, keep in mind the following limitation.

- 1 Joint Position Check of Dual Check Safety function is not available for J3 and J4-axes.
- 2 When you load a previous backup (all backup, etc.) including the mastering data, do it with the following procedure. During the procedure (1) to (3), do not change the position of the robot axes.
 - (1) Write down the current Mastering Data (\$DMR_GRP[group].\$MASTER_COUN[axis]) or save a Mastering data file (SYSMAST.SV). This file is also included in all backup.
 - (2) Restore the previous backup.
 - (3) Restore the mastering data you made in step (1). You can restore it either by directly entering the mastering data to system variable or loading SYSMAST.SV.




Fig. 6.2 (a) Restoration of a previous all backup after continuous rotation.

NOTE

When the continuous rotation is enabled with SR-3iA, SR-3iA/C, SR-6iA, SR-6iA/C, you cannot load a previous mastering data even if you have not done a remastering since then. (see Fig. 6.2 (b))

If you load the data, the J3-axis position will become incorrect.

In such a case, remaster J3-axis.




Fig. 6.2 (b) Example of wrong procedure of loading a previous mastering data

When setting the J4-axis of the robot as a continuous rotation axis, the following pop-up window is displayed.




Fig. 6.2 (c) Pop-up window of caution

7**CHECKS AND MAINTENANCE**

Optimum performance of the robot can be maintained by performing the checks and maintenance procedures presented in this chapter. (See APPENDIX A PERIODIC MAINTENANCE TABLE.)

NOTE

The periodic maintenance procedures described in this chapter assume that the FANUC robot is used for up to 3840 hours a year. In cases where robot use exceeds 3840 hours/year, adjust the given maintenance frequencies accordingly. The ratio of actual operating time/year vs. the 3840 hours/year should be used to calculate the new (higher) frequencies. For example, when using the robot 7680 hours a year, the maintenance frequency should be doubled – i.e. the time interval should be divided by 2.

7.1 CHECKS AND MAINTENANCE**7.1.1 Daily Checks**

Clean each part, and visually check component parts for damage before daily system operation. Check the following items when necessary.

| Check items | Check points and management |
|--|---|
| Oil seepage | Check to see if there is oil on the sealed part of each joint. If there is an oil seepage, clean it. ⇒“7.2.1 Confirmation of Oil Seepage” |
| Air control set Air purge kit | (When air control set or air purge kit is used) ⇒“7.2.2 Confirmation of the Air Control Set and Air Purge kit” |
| Vibration, abnormal noises | Check whether vibration or abnormal noises occur. When vibration or abnormal noises occur, perform measures referring to the following section: ⇒“9.1 TROUBLESHOOTING” (symptom : Vibration, Noise) |
| Positioning accuracy | Check that the taught positions of the robot have not deviated from the previously taught positions. If displacement occurs, perform the measures as described in the following section: ⇒“9.1 TROUBLESHOOTING” (Symptom : Displacement) |
| Peripheral equipment for proper operation | Check whether the peripheral equipment operates properly according to commands from the robot and the peripheral equipment. |
| Brakes for each axis | Check that the end effector drops 2 mm or less when servo power is turned off. If the end effector (hand) drops, perform the measures as described in the following section: ⇒“9.1 TROUBLESHOOTING” (symptom : Dropping axis) |
| Warnings | Check whether unexpected warnings occur in the alarm screen on the teach pendant. If unexpected warnings occur, perform the measures as described in the following manual: ⇒“OPERATOR’S MANUAL (Alarm Code List) (B-83284EN-1)” |

7.1.2 Periodic Check and Maintenance

Check the following items at the intervals recommended below based on the period or the accumulated operating time, whichever comes first. (○ : Item needs to be performed.)

| Check and maintenance intervals (Period, Accumulated operating time) | | | | | | | | Check and maintenance item | Check points, management and maintenance method | Periodic maintenance No. |
|---|---------------------------|----------------------|--------------------|-----------------------|---------------------|----------------------|--|---|--|--------------------------------|
| 1 month 320h | 3 months 960h | 6 months 1920h | 1 year 3840h | 1.5 years 5760h | 2 years 7680h | 4 years 15360h | | | | |
| ○ Only 1st check | ○ | | | | | | Cleaning the controller ventilation system | Confirm that the controller ventilation system is not dusty. If dust has accumulated, remove it. | 16 | |
| | ○ | | | | | | Check for external damage or peeling paint | Check whether the robot has external damage or peeling paint due to contact with the peripheral devices. If unintended contact has occurred, eliminate the cause. Also, if the external damage is serious, and causes a problem in which the robot will not operate, replace the damaged parts. | 1 | |
| | ○ | | | | | | Check for water | Check whether the robot is subjected to water or cutting oils. If water is found, remove the cause and wipe off the liquid. | 2 | |
| | ○ Only 1st check | | ○ | | | | Check for damages to the teach pendant cable, the operation box connection cable or the robot connection cable | Check whether the cable connected to the teach pendant, operation box and robot are unevenly twisted or damaged. If damage is found, replace the damaged cables. | 15 | |
| | ○ Only 1st Check | | ○ | | | | Check for damage to the end effector (hand) cable and external batteries cable | Check whether the end effector cables and external batteries cable are unevenly twisted or damaged. If damage is found, replace the damaged cables. | 8 | |
| | ○ Only 1st check | | ○ | | | | Check the exposed connectors | Check the exposed connectors. ⇒“7.2.3 Check the Connectors” | 3 | |
| | ○ Only 1st check | | ○ | | | | Retightening the end effector mounting bolts | Retighten the end effector mounting bolts. Refer to the following section for tightening torque information: ⇒“4.1 END EFFECTOR INSTALLATION TO WRIST” | 4 | |
| | ○ Only 1st check | | ○ | | | | Retightening the external main bolts | Retighten the robot installation bolts, bolts that have been removed for inspection, and bolts exposed to the outside. Refer to the recommended bolt tightening torque guidelines at the end of the manual. An adhesive to prevent bolts from loosening is applied to some bolts. If the bolts are tightened with greater than the recommended torque, the adhesive might be removed. Therefore, follow the recommended bolt tightening torque guidelines when retightening the bolts. | 5 | |

| Check and maintenance intervals (Period, Accumulated operating time) | | | | | | | | Check and maintenance item | Check points, management and maintenance method | Periodic maintenance No. |
|---|---------------------|---------------------------|---------------------------|-----------------------|-----------------------|----------------------|--|--|--|--------------------------------|
| 1 month 320h | 3 months 960h | 6 months 1920h | 1 year 3840h | 1.5 years 5760h | 2 years 7680h | 4 years 15360h | | | | |
| <input type="radio"/> Only 1st check | | <input type="radio"/> | | | | | Check the fixed mechanical stopper (except SR-3iA/C, SR-6iA/C) | Check that there is no evidence of a collision on the fixed mechanical stopper, and check that the stopper mounting bolts are not loose. ⇒“7.2.4 Check of Fixed Mechanical Stopper” | 6 | |
| <input type="radio"/> Only 1st check | | <input type="radio"/> | | | | | Clean spatters, sawdust and dust | Check that spatters, sawdust, or dust does not exist on the robot main body. If dust has accumulated, remove it. Especially, clean the robot movable parts well (each joint). | 7 | |
| | | <input type="radio"/> (*) | <input type="radio"/> (*) | | | | Replacing the mechanical unit batteries | Replace the mechanical unit batteries. Regardless of operating time, replace batteries at these intervals. ⇒“7.3.1 Replacing the Batteries” | 9 | |
| | | <input type="radio"/> (*) | <input type="radio"/> (*) | | | | Replenish grease to each axis reducer | Grease reducers. (*) Periodic interval differs according to the model. SR-3iA/C, SR-6iA/C : 1 year (3840 hours) Except SR-3iA/C, SR-6iA7C : 1.5 year (5760 hours) ⇒“7.3.2 Replenish the Grease of the Reducer” | 10 | |
| | | <input type="radio"/> | | | | | Replenish grease to ball screw spline | Grease ball screw spline ⇒“7.3.3 Replenish the Grease of the Ball Screw Spline” | 11 | |
| | | <input type="radio"/> | | | | | Confirm belt tension | Confirm the belt tension. Contact your local FANUC representative for information regarding adjusting the belt tension. | 12 | |
| | | | | <input type="radio"/> | | | Replacing the mechanical unit cable | Replace the mechanical unit cable. Contact your local FANUC representative for information regarding replacing the cable. | 13 | |
| | | | <input type="radio"/> | | | | Check the bellows (SR-3iA/C, SR-6iA/C) | Check the damage of the bellows. Check the tightness of bolts. Check the rattling. | 14 | |
| | | | | | <input type="radio"/> | | Replacing the controller batteries | Replace the controller batteries. Regardless of operating time, replace batteries at 4 years. ⇒“Chapter 7 Replacing batteries of MAINTENANCE MANUAL (B-84035EN)” | 17 | |

7.2 CHECK POINTS

7.2.1 Confirmation of Oil Seepage

Check items

Check to see whether there is an oil seepage on the rotating parts of each joint axis.




Fig. 7.2.1 (a) Check points of oil seepage

Management

- Oil might accumulate on the outside of the seal lip depending on the movement condition or environment of the axis. If the oil changes to a state of liquid, the oil might fall depending on the axis movement. To prevent oil spots, be sure to wipe away any accumulated oil under the axis components before you operate the robot.
- Also, motors might become hot and the internal pressure of the grease bath might rise by frequent repetitive movement and use in high temperature environments. In these cases, normal internal can be restored by venting the grease inlet. (When opening the grease inlet, refer to Subsection 7.3.2 and ensure that grease is not expelled onto the machine or tooling.)
- If you must wipe oil frequently, and opening the grease outlet does not stop the seepage, perform the measures below.

⇒”9.1 TROUBLESHOOTING” (symptom : Grease leakage)

7.2.2 Confirmation of the Air Control Set and Air Purge kit (option)

When an air control set or an purge kit is used, check the items below.

| Item | Check items | Check points |
|------|-------------------|--|
| 1 | Air pressure | Check air pressure using the pressure gauge on the air control set as shown in Fig.7.2.2 (a). If it does not meet the specified pressure of 0.49MPa (5 kgf/cm ²), adjust it using the regulator pressure setting handle. |
| 2 | Leakage from hose | Check the joints, tubes, etc. for leaks. Repair leaks, or replace parts, as required. |
| 3 | Drain | Check drain and release it. If the quantity of the drained liquid is significant, examine the setting of the air dryer on the air supply side. |




Fig. 7.2.2 (a) Air control set (option)

7.2.3 Check the Connectors

Inspection points of the connectors

- Robot connection cables, earth terminal and user cables

Check items

- Circular connector : Check the connector for tightness by turning it manually.
- Cable clamp : Check the clamp for tightness by turning it manually.
- Earth/Ground terminal : Check the terminal for tightness.




Fig. 7.2.3 (a) Cable clamp and connector Inspection points

7.2.4 Check of Mechanical Stopper

- Check that there is no evidence of a collision on the fixed mechanical stopper and the adjustable mechanical stopper. If there is evidence of a collision on the stopper, replace the parts. When installing the J3-axis mechanical stopper, refer to Fig. 7.2.4 (a) to (d).
- Check the tightness of the stopper mounting bolts. If they are loose, retighten them.
- In case of SR-3iA/C, SR-6iA, check the stoppers is not necessary.




Fig. 7.2.4 (a) Position of mechanical stopper (SR-3iA, SR-3iA/H)




Fig. 7.2.4 (b) Position of mechanical stopper (SR-6iA, SR-6iA/H)

7.3 MAINTENANCE

7.3.1 Replacing the Batteries

**(1-Year Periodic Inspection If Built-in Batteries Are Specified)
(1.5-Year Periodic Inspection If External Batteries Are Specified)**

The position data of each axis is preserved by the backup batteries. If built-in batteries are in use, replace them every year. If external batteries are in use, replace them every year and a half. Also use the following procedure to replace them when the backup battery voltage drop alarm occurs.

Procedure of replacing the battery (if built-in batteries are specified) (SR-3iA, SR-3iA/H, SR-6iA, SR-6iA/H)

- 1 Press the EMERGENCY STOP button to prohibit the robot motion.

CAUTION

Be sure to keep the power supply turned on. Replacing the batteries with the power supply turned off causes all current position data to be lost. If this occurs, mastering will be required again.

- 2 Remove the battery case cap. (Fig. 7.3.1 (a)) If it cannot be removed, tap it on the side with a plastic hammer.
- 3 Loosen the plate screw and take off the lid of the battery box and replace the battery. The battery can be taken out by pulling the stick which is in the center of the battery box.
- 4 Assemble them by reversing the sequence. Pay attention to the direction of batteries.




Fig. 7.3.1 (a) Replacing the battery (if built-in batteries are specified)

Procedure of replacing the battery (SR-3iA/C, SR-6iA/C)

- 1 Press the EMERGENCY STOP button to prohibit the robot motion.

⚠ CAUTION

Be sure to keep the power supply turned on. Replacing the batteries with the power supply turned off causes all current position data to be lost. If this occurs, mastering will be required again.

- 2 Remove the battery box cover. (Fig. 7.3.1 (b)) If it cannot be removed, tap it on the side with a plastic hammer.
- 3 Loosen the plate screw and take off the lid of the battery box and replace the battery. The battery can be taken out by pulling the stick which is in the center of the battery box.
- 4 Assemble them by reversing the sequence. Pay attention to the direction of batteries. It is necessary to replace the gasket (A290-7142-X249) and stainless sealant coated bolts (A97L-0218-0760-041608S).




Fig. 7.3.1 (b) Replacing the battery (SR-3iA/C, SR-6iA/C)

Procedure for replacing the battery (if external batteries are specified) (SR-3iA, SR-3iA/H, SR-6iA, SR-6iA/H)

- 1 Press the EMERGENCY STOP button to prohibit the robot motion.

⚠ CAUTION

Be sure to keep the power supply turned on. Replacing the batteries with the power supply turned off causes all current position data to be lost. If this occurs, mastering will be required again.

- 2 Uncap the battery case (Fig. 7.3.1 (c)).
- 3 Take out the old batteries from the battery case.
- 4 Insert new batteries into the battery case while observing their correct orientation.
- 5 Cap the battery case.




Fig. 7.3.1 (c) Replacing the battery (if external batteries are specified)

Fig. 7.3.1 (d) shows the external size of external battery box.

When the battery box needs to be built into the controller or other internal units, refer to the external dimensions shown in Fig. 7.3.1 (d).

The battery box can be fixed by using M4 flat-head screws. (The bolts do not come with the system.) A maximum of six terminals can be attached to the backplane of the battery box.




Fig. 7.3.1 (d) External dimensions of the battery box

7.3.2 Replenish the Grease of the Reducer (1.5 years (5760 hours) or 1 years (3840 hours) checks)

In case of SR-3iA, SR-3iA/H, SR-6iA, SR-6iA/H, supply J1, J2-axis reducer grease at the intervals based on every 1.5 years or 5760 hours, whichever comes first by using the following procedures. In case of SR-3iA/C, SR-6iA/C, supply J1, J2-axis reducer grease at the intervals based on every 1 year or 3840 hours, whichever comes first by using the following procedures For the grease name and quantity, see the Table 7.3.2 (a), (b).

**Table 7.3.2 (a) Grease for 1.5 years (5760 hours) periodical greasing
(SR-3iA, SR-3iA/H, SR-6iA, SR-6iA/H)**

| Greasing points | Greasing amount | Specified grease |
|-----------------|-----------------|------------------------|
| J1-axis reducer | 4g (5 ml) | Spec. : A98L-0040-0230 |
| J2-axis reducer | 4g (5 ml) | |

**Table 7.3.2 (b) Grease for 1 year (3840 hours) periodical greasing
(SR-3iA/C, SR-6iA/C)**

| Greasing points | Greasing amount | Specified grease |
|-----------------|-----------------|------------------------|
| J1-axis reducer | 2g (2 ml) | Spec. : A98L-0040-0320 |
| J2-axis reducer | 2g (2 ml) | |

NOTE

The following maintenance kits are prepared for the greasing.

- Grease in tube: A05B-1139-K022 (grease in tube (80g))
(SR-3iA, SR-3iA/H, SR-6iA, SR-6iA/H)
- Grease in tube: A05B-1142-K027 (grease in tube (80g))
(SR-3iA/C, SR-6iA/C)



CAUTION

Failure to follow proper lubrication procedures may cause the suddenly increase of the grease bath internal pressure and the damage to the seal, which could lead to grease leakage and abnormal operation. When greasing, observe the following cautions.

- 1 Use specified grease. Use of non-approved grease may damage the reducer or lead to other problems.
- 2 To prevent slipping accidents and catching fire, completely remove any excess grease from the floor or robot.
- 3 Please fill a necessary amount to the injection syringe after softening grease in the tube massaging it by the hand when you use the grease greasing kit. Please install the nozzle in the point of the injection syringe. Please remove the nozzle and do the cap when you do not use the injection syringe.

For grease replacement or replenishment, use the arbitrary posture.

- 1 Turn off controller power.
- 2 Remove the seal bolts from the grease inlet.
- 3 Supply a regulated amount of grease by using the injection syringe. Please note that grease might come out immediately after the grease has been supplied, or during the greasing. Even in this case, please do not supply grease beyond the regulated amount specified.
- 4 Replace the seal bolts with new ones. When reusing a seal bolt, be sure to seal it with seal tape.




Fig. 7.3.2 (a) Applying grease of the J1, J2-axis reducer

Table 7.3.2 (c) Spec. of seal bolts

| Parts name | Specifications | Remarks |
|------------|-----------------------|--|
| Seal bolt | A97L-0218-0417#040606 | J1, J2-axis grease inlet 2 pcs/ per 1 robot |

7.3.3 Replenish the Grease of the Ball Screw Spline (6 months (1920 hours) checks)

Supply grease to ball screw spline at the intervals recommended below based on every 6 months or 1920 hours, whichever comes first. See table 7.3.3 (a) for the grease name and the quantity.

Table 7.3.3 (a) Grease for 6-months (1920 hours) periodical replacement

| Supply position | Quantity | Grease name |
|-------------------|-----------------|--|
| Ball screw spline | Proper quantity | SR-3iA, SR-3iA/H, SR-6iA, SR-6iA/H Spec. : A98L-0040-0329 SR-3iA/C, SR-6iA/C Spec. : A98L-0040-0187 |

NOTE

The following maintenance kits are prepared for the greasing.

- Grease in tube: A05B-1116-K001 (grease in tube (70g))
(SR-3iA, SR-3iA/H, SR-6iA, SR-6iA/H)
- Grease in tube: A05B-1116-K031 (grease in tube (70g))
(SR-3iA/C, SR-6iA/C)

7. CHECKS AND MAINTENANCE

B-84024EN/08

For grease replacement or replenishment, use the arbitrary posture.

- 1 Turn off controller power.
- 2 Loosen bolts (1). Remove bolts (2). Then remove the cover. In case of SR-3iA/C, SR-6iA/C, remove the seal washers (4).
- 3 Remove the cover (3).




Fig. 7.3.3 (a) Removing the cover

SR-3iA, SR-3iA/H

| | Parts name | Specifications | Q'ty | LOCTITE | Torque (N·m) |
|---|--------------|---------------------|------|---------|--------------|
| 1 | COVER BOLT | A290-7116-X409 | 4 | | 2.0 |
| 2 | BOLT | A97L-0218-0504#M4X8 | 4 | | 0.8 |
| 3 | J2 ARM COVER | A290-7116-X402 | 1 | | |

SR-3iA/C

| | Parts name | Specifications | Q'ty | LOCTITE | Torque (N·m) |
|---|--------------|----------------------|------|---------|--------------|
| 1 | COVER BOLT | A290-7116-X459 | 4 | | 2.0 |
| 2 | BOLT | A97L-0218-0591#M4X10 | 4 | | 0.8 |
| 3 | J2 ARM COVER | A290-7116-X439 | 1 | | |
| 4 | SEAL WASHER | A97L-0218-0427#0410 | 4 | | |

SR-6iA, SR-6iA/H

| | Parts name | Specifications | Q'ty | LOCTITE | Torque (N·m) |
|---|--------------|---------------------|------|---------|--------------|
| 1 | COVER BOLT | A290-7117-X409 | 4 | | 2.0 |
| 2 | BOLT | A97L-0218-0504#M4X8 | 4 | | 0.8 |
| 3 | J2 ARM COVER | A290-7117-X439 | 1 | | |

SR-6iA/C

| | Parts name | Specifications | Q'ty | LOCTITE | Torque (N·m) |
|---|--------------|----------------------|------|---------|--------------|
| 1 | COVER BOLT | A290-7117-X438 | 4 | | 2.0 |
| 2 | BOLT | A97L-0218-0591#M4X10 | 4 | | 0.8 |
| 3 | J2 ARM COVER | A290-7117-X430 | 1 | | |
| 4 | SEAL WASHER | A97L-0218-0427#0410 | 4 | | |

- 4 Supply new grease to the ball screw spline grooved with a thin brush or toothbrush referring to Fig. 7.3.3 (d), (e).
- 5 Attach the cover.



Fig. 7.3.3 (b) Metal with brush



Fig. 7.3.3 (c) Toothbrush




Fig. 7.3.3 (d) Applying grease of ball screw spline (SR-3iA, SR-3iA/H, SR-6iA, SR-6iA/H)




Fig. 7.3.3 (e) Applying grease of ball screw spline (SR-3iA/C, SR-6iA/C)

- 4 Attach the cover.

WARNING

Operate the robot without the cover is very dangerous. The power transmission part inside the robot is exposed, and there is a risk of serious injury due to being caught or pinched. Be sure to fix the cover with bolts after greasing. If noise occurs, cover might not be fixed. Confirm the bolts are not loose.

Fig.7.3.3 (f) shows states of unfixed cover.




Fig. 7.3.3 (f) States of unfixed cover

7.4 STORAGE

When storing the robot, place it on a level surface with the same posture that was used for transportation. (See Section 1.1.)

8 MASTERING

Mastering associates the angle of each robot axis with the pulse count value supplied from the absolute Pulsecoder connected to the corresponding axis motor. To be specific, mastering is an operation for obtaining the pulse count value; corresponding to the zero position.

NOTE

Explanation in this chapter is for when teach pendant (option) is selected.

8.1 OVERVIEW

The current position of the robot is determined according to the pulse count value supplied from the Pulsecoder on each axis.

Mastering is factory-performed. It is unnecessary to perform mastering in daily operations. However, mastering becomes necessary after:

- Motor replacement.
- Pulsecoder replacement
- Reducer replacement
- Cable replacement
- Batteries for pulse count backup in the mechanical unit have gone dead



CAUTION

Robot data (including mastering data) and Pulsecoder data are backed up by their respective backup batteries. Data will be lost if the batteries die. Replace the batteries in the controller and mechanical units periodically. An alarm will alert you when battery voltage is low.

Types of Mastering

Table 8.1 (a) describes the following mastering methods.

Table 8.1 (a) Type of mastering

| | |
|--|---|
| Fixture position mastering | This is performed using a mastering fixture before the machine is shipped from the factory. |
| Zero-position mastering (witness mark mastering) | This is performed with all axes set at the 0-degree position. A zero-position mark (witness mark) is attached to each robot axis. This mastering is performed with all axes aligned to their respective witness marks. |
| Quick mastering | This is performed at a user-specified position. The corresponding count value is obtained from the rotation count of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost. (All axes at the same time) |
| Quick mastering for single axis | This is performed at a user-specified position for one axis. The corresponding count value is obtained from the rotation count of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost. |
| Single-axis mastering | This is performed for one axis at a time. The mastering position for each axis can be specified by the user. This is useful in performing mastering on a specific axis. |
| Mastering data entry | Mastering data is entered directly. |

Once mastering is performed, you must carry out positioning (calibration). Positioning is an operation in which the controller reads the pulse count value to sense the current position of the robot.

This section describes zero-position mastering, quick mastering, quick mastering for single axis, single-axis mastering, and mastering data entry. For more detailed mastering (fixture position mastering), contact your local FANUC representative.

! CAUTION

- 1 If mastering is performed incorrectly, the robot may behave unexpectedly. This is very dangerous. For this reason, the Master/Cal screen is designed to appear only when the \$MASTER_ENB system variable is 1 or 2. After performing positioning, press F5, ([DONE]) on the Master/Cal screen. The \$MASTER_ENB system variable is then reset to 0 automatically, and the Master/Cal screen will disappear.
- 2 Before performing mastering, it is recommended that you back up the current mastering data.

8.2 RESETTING ALARMS AND PREPARING FOR MASTERING

Before performing mastering because a motor has been replaced, it is necessary to release the relevant alarm and display the positioning menu.

Alarm displayed

“SRVO-062 BZAL” or “SRVO-075 Pulse not established”

Procedure

- 1 Display the positioning menu by following the steps 1 to 6.
 - 1 Press the [MENU] key.
 - 2 Press [0 NEXT] and select [6 SYSTEM].
 - 3 Press F1 ([TYPE]), and select [Variable] from the menu.
 - 4 Place the cursor on \$MASTER_ENB, then key in “1” and press the [ENTER] key.
 - 5 Press F1 ([TYPE]), and select [Master/Cal] from the menu.
 - 6 Select the desired mastering type from the [Master/Cal] menu.
- 2 To reset the “SRVO-062 BZAL” alarm, follow steps 1 to 5.
 - 1 Press the [MENU] key.
 - 2 Press [0 NEXT] and select [6 SYSTEM].
 - 3 Press F1 ([TYPE]), and select [Master/Cal] from the menu.
 - 4 Press F3 ([RES_PCA]), then press F4 ([YES]).
 - 5 Cycle power of the controller.
- 3 To reset the “SRVO-075 Pulse not established” alarm, follow the steps 1 to 2.
 - 1 After cycling controller power, the message “SRVO-075 Pulse not established” appears again.
 - 2 Move the axis for which the message mentioned above has appeared in either direction till the alarm disappears when you press the [RESET] key.

If “SRVO-062 BZAL” alarm or “SRVO-068 DTERR” alarm occurred, and you cannot release the alarm, Please check there is no faulty wiring or disconnected part.


8.3 ZERO POSITION MASTERING

Zero-position mastering (witness mark mastering) is performed with all axes set at the 0-degree position. A zero-position mark (witness mark) is attached to each robot axis. (Fig.8.3 (a)) This mastering is performed with all axes set at the 0-degree position using their respective witness marks.

Zero-position mastering involves a visual check, and might not be highly accurate. It should be used only as a quick-fix method.

Zero-position Mastering Procedure

- 1 Press the [MENU] key to display the screen menu.
- 2 Select [0 NEXT] and press [6 SYSTEM].
- 3 Press F1 [TYPE], display the screen change menu.
- 4 Select [Master/Cal]. The positioning screen will be displayed.



- 5 Release brake control, and jog the robot into a posture for mastering.

NOTE


Brake control can be released by setting the system variables as follows:

`$PARAM_GROUP.SV_OFF_ALL` : FALSE


`$PARAM_GROUP.SV_OFF_ENB[*]` : FALSE (for all axes)

After changing the system variables, turn off the controller power and on again.

- 6 Select [2 ZERO POSITION MASTER]. Press F4 [YES].



7 Select [7 CALIBRATE] and press F4 [YES]. Mastering will be performed automatically. Alternatively, turn off the controller power and on again. Turning on the power always causes positioning to be performed.



8 After positioning is completed, press F5 [DONE].



9 Return brake control to original setting, and turn off the controller power and on again.

Table 8.3 (a) Posture with position marks aligned

| Axis | Position |
|---------|----------|
| J1-axis | 0 deg |
| J2-axis | 0 deg |
| J3-axis | 0 mm |
| J4-axis | 0 deg |

NOTE

There is no J4-axis for SR-3iA/H and SR-6iA/H.




Fig. 8.3 (a) Marking position (SR-3iA, SR-3iA/H, SR-3iA/C)




Fig. 8.3 (b) Marking position (SR-6iA, SR-6iA/H, SR-6iA/C)

8.3.1 Fixture for bellows of SR-3iA/C, SR-6iA/C

In case of SR-3iA/C, SR-6iA/C, install the following fixture. (order spec. : A05B-1116-K107). The following shows the procedure.




Fig. 8.3.1 (a) Fixture installation

Tighten 2 bolts during performing 1 and 2 of the Fig. 8.3.1 (b).




Fig. 8.3.1 (b) Fixture installation

Seen from the front, the metal plate upper side matches the circle mark center at the J3-axis zero degree position.




Fig. 8.3.1 (c) J3-axis zero degree position

Seen from slightly above the front of the plate, circle mark of the shaft matches the center position of the plate clearance at the J4-axis zero degree position.




Fig. 8.3.1 (d) J4-axis zero degree position

8.4 QUICK MASTERING

Quick mastering is performed at a user-specified position for each axis. The pulse count value is obtained from the rotation times of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost.

Quick mastering is factory-performed at the position indicated in Table 8.3 (a). If possible, do not change the setting.


If it is impossible to set the robot at the position mentioned above, it is necessary to re-set the quick mastering reference position using the following method. (It would be convenient to set up a marker that can work in place of the witness mark.)

⚠ CAUTION


- 1 Quick mastering can be used, if the pulse count value is lost, for example, because a low voltage has been detected on the backup battery for the pulse counter.
- 2 Quick mastering cannot be used, after the motor is replaced or after the mastering data is lost from the robot controller.

Procedure for Recording the Quick Mastering Reference Position

- 1 Select [6 SYSTEM].
- 2 Select [Master/Cal]. The positioning screen will be displayed.



- 3 Release brake control, and jog the robot to the quick mastering reference position.
- 4 Select [6 SET QUICK MASTER REF] and press F4 [YES]. Quick mastering reference position is saved.




⚠ CAUTION


If the robot has lost mastering data due to mechanical disassembly or repair, you cannot perform this procedure. In this case, perform Fixture position mastering or Zero position mastering to restore mastering data.

Procedure of Quick Mastering


- 1 Display the Master/Cal screen.



- 2 Release brake control, and jog the robot to the quick mastering reference position.
- 3 Move the cursor to [3 QUICK MASTER] and press the [ENTER] key. Press F4 [YES]. Quick mastering data is memorized.



- 4 Move the cursor to [7 CALIBRATE] and press the [ENTER] key. Calibration is executed. Calibration can also be executed by cycling power.
- 5 After completing the calibration, press F5 [DONE].



- 6 Return brake control to original setting, and turn off the controller power and on again.

8.5 QUICK MASTERING FOR SINGLE AXIS

Quick mastering for a single axis is performed at a user-specified position for one axis. The pulse count value is obtained from the rotation times of the Pulsecoder connected to the relevant motor and the rotation angle within one rotation. Quick mastering uses the fact that the absolute value of a rotation angle within one rotation will not be lost.

Quick mastering is factory-performed at the position indicated in Table 8.3 (a). If possible, do not change the setting.


If setting the robot at the position mentioned above is impossible, you must re-set the quick mastering reference position using the following method. (It would be convenient to set up a marker that can work in place of the witness mark.)

⚠ CAUTION


- 1 Quick mastering can be used, if the pulse count value is lost, for example, because a low voltage has been detected on the backup battery for the pulse counter.
- 2 Quick mastering cannot be used, after the motor is replaced or after the mastering data is lost from the robot controller.

Procedure for Recording the Quick Mastering Reference Position

- 1 Select [6 SYSTEM].
- 2 Select [Master/Cal]. The positioning screen will be displayed.



- 3 Release brake control, and jog the robot to the quick mastering reference position.
- 4 Select [6 SET QUICK MASTER REF] and press F4 [YES]. Quick mastering reference position is saved.




⚠ CAUTION

If the robot has lost mastering data due to mechanical disassembly or repair, you cannot perform this procedure. In this case, perform Fixture position mastering or zero -position mastering to restore mastering data.

Procedure of Quick Mastering for single axis

- Display the Master/Cal screen.




- Select [4 QUICK MASTER FOR SINGLE AXIS]. You will see the quick master for single axis screen.

| SINGLE AXIS MASTER | | AUTO | JOINT 10% |
|--------------------|-------|------------|------------|
| 1/9 | | | |
| ACTUAL | POS | (MSTR POS) | (SEL) [ST] |
| J1 | 0.000 | (0.000) | (0) [2] |
| J2 | 0.000 | (0.000) | (0) [2] |
| J3 | 0.000 | (0.000) | (0) [2] |
| J4 | 0.000 | (0.000) | (0) [2] |
| J5 | 0.000 | (0.000) | (0) [2] |
| J6 | 0.000 | (0.000) | (0) [0] |
| E1 | 0.000 | (0.000) | (0) [0] |
| E2 | 0.000 | (0.000) | (0) [0] |
| E3 | 0.000 | (0.000) | (0) [0] |
| EXEC | | | |

- Move the cursor to the (SEL) column for the unmastered axis and press the numeric key [1]. Setting of (SEL) is available for one or more axes.

| SINGLE AXIS MASTER | | AUTO | JOINT 10% |
|--------------------|-------|------------|------------|
| 1/9 | | | |
| ACTUAL | POS | (MSTR POS) | (SEL) [ST] |
| J5 | 0.000 | (0.000) | (0) [2] |
| J6 | 0.000 | (0.000) | (0) [0] |
| EXEC | | | |

- Turn off brake control, then jog the robot to the quick mastering reference position.
- Press F5 [EXEC]. Mastering is performed. So, (SEL) is reset to 0, and [ST] is re-set to 2.
- Move the cursor to [7 CALIBRATE] and press the [ENTER] key. Calibration is executed. Calibration can also be executed by cycling power.
- After completing the calibration, press F5 [DONE].



- Return brake control to original setting, and turn off the controller power and on again.

8.6 SINGLE AXIS MASTERING

Single axis mastering is performed for one axis at a time. The mastering position for each axis can be specified by the user.

Single axis mastering can be used, if mastering data for a specific axis is lost, for example, because a low voltage has been detected on the pulse counter backup battery or because the Pulsecoder has been replaced.

| SINGLE AXIS MASTER | | AUTO | JOINT 10% | |
|--------------------|-------|------------|-----------|------|
| | | | | 1/9 |
| ACTUAL | POS | (MSTR POS) | (SEL) | [ST] |
| J1 | 0.000 | (0.000) | (0) | [2] |
| J2 | 0.000 | (0.000) | (0) | [2] |
| J3 | 0.000 | (0.000) | (0) | [2] |
| J4 | 0.000 | (0.000) | (0) | [2] |
| J5 | 0.000 | (0.000) | (0) | [2] |
| J6 | 0.000 | (0.000) | (0) | [0] |
| E1 | 0.000 | (0.000) | (0) | [0] |
| E2 | 0.000 | (0.000) | (0) | [0] |
| E3 | 0.000 | (0.000) | (0) | [0] |
| | | | | EXEC |

Table 8.6 (a) Items set in single axis mastering

| Item | Description |
|-----------------------------------|--|
| Current position (ACTUAL AXIS) | The current position of the robot is displayed for each axis in degree or mm units. |
| Mastering position (MSTR POS) | A mastering position is specified for an axis to be subjected to single axis mastering. It would be convenient to set to it to the 0 position. |
| SEL | This item is set to 1 for an axis to be subjected to single axis mastering. Usually, it is 0. |
| ST | This item indicates whether single axis mastering has been completed for the corresponding axis. It cannot be changed directly by the user. The value of the item is reflected in \$EACHMST_DON (1 to 9). 0 : Mastering data has been lost. Single axis mastering is necessary. 1 : Mastering data has been lost. (Mastering has been performed only for the other interactive axes.) Single axis mastering is necessary. 2 : Mastering has been completed. |

Procedure of Single axis mastering

- 1 Select [6 SYSTEM].
- 2 Select [Master/Cal]. The positioning screen will be displayed.

| SYSTEM Master/Cal | | AUTO | JOINT 10 % | |
|--|--|------|----------------|------|
| | | | TORQUE = [ON] | |
| 1 FIXTURE POSITION MASTER | | | | |
| 2 ZERO POSITION MASTER | | | | |
| 3 QUICK MASTER | | | | |
| 4 QUICK MASTER FOR SINGLE AXIS | | | | |
| 5 SINGLE AXIS MASTER | | | | |
| 6 SET QUICK MASTER REF | | | | |
| 7 CALIBRATE | | | | |
| Press 'ENTER' or number key to select. | | | | |
| [TYPE] | | LOAD | RES_PCA | DONE |

3 Select [5 SINGLE AXIS MASTER]. The following screen will be displayed.

| SINGLE AXIS MASTER | | AUTO | JOINT 10% | |
|--------------------|-------|------------|-----------|------|
| | | | 1/9 | |
| ACTUAL | POS | (MSTR POS) | (SEL) | [ST] |
| J1 | 0.000 | (0.000) | (0) | [2] |
| J2 | 0.000 | (0.000) | (0) | [2] |
| J3 | 0.000 | (0.000) | (0) | [2] |
| J4 | 0.000 | (0.000) | (0) | [2] |
| J5 | 0.000 | (0.000) | (0) | [2] |
| J6 | 0.000 | (0.000) | (0) | [0] |
| E1 | 0.000 | (0.000) | (0) | [0] |
| E2 | 0.000 | (0.000) | (0) | [0] |
| E3 | 0.000 | (0.000) | (0) | [0] |
| EXEC | | | | |


4 Move the cursor to the [SEL] column for the unmastered axis and press the numeric key [1]. Setting of [SEL] is available for one or more axes.
 5 Turn off brake control, then jog the robot to the mastering position.
 6 Enter axis data for the mastering position.
 7 Press F5 [EXEC]. Mastering is performed. So, [SEL] is reset to 0, and [ST] is re-set to 2 or 1.

| SINGLE AXIS MASTER | | AUTO | JOINT 10% | |
|--------------------|--------|------------|-----------|------|
| | | | 6/9 | |
| ACTUAL | POS | (MSTR POS) | (SEL) | [ST] |
| J1 | 0.000 | (0.000) | (0) | [2] |
| J2 | 0.000 | (0.000) | (0) | [2] |
| J3 | 0.000 | (0.000) | (0) | [2] |
| J4 | 0.000 | (0.000) | (0) | [2] |
| J5 | 0.000 | (0.000) | (0) | [2] |
| J6 | 90.000 | (0.000) | (1) | [0] |
| E1 | 0.000 | (0.000) | (0) | [0] |
| E2 | 0.000 | (0.000) | (0) | [0] |
| E3 | 0.000 | (0.000) | (0) | [0] |
| EXEC | | | | |

8 When single axis mastering is completed, press the [PREV] key to resume the previous screen.

| SYSTEM Master/Cal | | AUTO | JOINT 10 % | |
|--|--|------|------------|------|
| TORQUE = [ON] | | | | |
| 1 FIXTURE POSITION MASTER | | | | |
| 2 ZERO POSITION MASTER | | | | |
| 3 QUICK MASTER | | | | |
| 4 QUICK MASTER FOR SINGLE AXIS | | | | |
| 5 SINGLE AXIS MASTER | | | | |
| 6 SET QUICK MASTER REF | | | | |
| 7 CALIBRATE | | | | |
| Press 'ENTER' or number key to select. | | | | |
| [TYPE] | | LOAD | RES_PCA | DONE |

9 Select [7 CALIBRATE], then press F4 [YES]. Positioning is performed. Alternatively, turn off the controller power and on again. Positioning is performed.
 10 After positioning is completed, press F5 [DONE].



11 Return brake control to original setting, and turn off the controller power and on again.

8.7 MASTERING DATA ENTRY

This function enables mastering data values to be assigned directly to a system variable. It can be used if mastering data has been lost but the pulse count is preserved.

Mastering data entry method

- 1 Press the [MENU] key, then press [0 NEXT] and select [6 SYSTEM].
- 2 Press F1 [TYPE]. Select [Variables]. The system variable screen will be displayed.

| SYSTEM Variables | | AUTO | JOINT 10% |
|------------------|---------------|--------------|-----------|
| | | 1/669 | |
| 1 | \$AAVM_GRP | AAVM_GRP_T | |
| 2 | \$AAVM_WRK | AAVM_WRK_T | |
| 3 | \$ABSPOS_GRP | ABSPOS_GRP_T | |
| 4 | \$ACC_MAXLMT | 0 | |
| 5 | \$ACC_MINLMT | 0 | |
| 6 | \$ACC_PRE_EXE | 0 | |
| [TYPE] | | DETAIL | |

- 3 Change the mastering data.

The mastering data is saved to the \$DMR_GRP.\$MASTER_COUN system variable.

| SYSTEM Variables | | AUTO | JOINT 10% |
|------------------|------------|------------|-----------|
| | | 1/669 | |
| 135 | \$DMR_GRP | DMR_GRP_T | |
| 136 | \$DMSW_CFG | DMSW_CFG_T | |
| [TYPE] | | | |

- 4 Select \$DMR_GRP.

| SYSTEM Variables | | AUTO | JOINT 10% |
|------------------|-----|-----------|-----------|
| | | 1/1 | |
| 1 | [1] | DMR_GRP_T | |
| [TYPE] | | DETAIL | |

| SYSTEM Variables | | AUTO | JOINT 10% |
|------------------|---------------|----------------|-----------|
| | | 1/29 | |
| 1 | \$MASTER_DONE | FALSE | |
| 2 | \$OT_MINUS | [9] of BOOLEAN | |
| 3 | \$OT_PLUS | [9] of BOOLEAN | |
| 4 | \$MASTER_COUN | [9] of INTEGER | |
| 5 | \$REF_DONE | FALSE | |
| 6 | \$REF_POS | [9] of REAL | |
| [TYPE] | | TRUE | FALSE |

5 Select \$MASTER_COUN, and enter the mastering data you have recorded.

| SYSTEM Variables | | AUTO | JOINT 10% |
|----------------------------|-----|----------|-----------|
| \$DMR_GRP[1].\$MASTER_COUN | | 1/9 | |
| 1 | [1] | 95678329 | |
| 2 | [2] | 10223045 | |
| 3 | [3] | 3020442 | |
| 4 | [4] | 30405503 | |
| 5 | [5] | 0 | |
| 6 | [6] | 0 | |
| 7 | [7] | 0 | |
| 8 | [8] | 0 | |
| 9 | [9] | 0 | |
| [TYPE] | | | |

6 Press the [PREV] key.
7 Set \$MASTER_DONE to TRUE.

| SYSTEM Variables | | AUTO | JOINT 10% |
|------------------|---------------|----------------|-----------|
| \$DMR_GRP | | 1/29 | |
| 1 | \$MASTER_DONE | TRUE | |
| 2 | \$OT_MINUS | [9] of BOOLEAN | |
| [TYPE] | | TRUE | FALSE |

8 Display the positioning screen, and select [7 CALIBRATE], then press F4 [YES].
9 After completing positioning, press F5 [DONE].



8.8 VERIFYING MASTERING

1 How to verify that the robot is mastered properly:

Usually, positioning is performed automatically when the power is turned on. To check whether mastering has been performed correctly, examine if the current displayed position matches the actual robot position by using one or more of the procedures described below:

- (1) Reproduce a particular point in a program. Check whether the point agrees with the specified position.
- (2) Set all axes of the robot to their 0-degree (0 rad) positions. Check that the zero-degree position marks indicated in Section 8.3 are aligned. There is no need to use a visual aid.

If the displayed and actual positions do not match, the counter value for a Pulsecoder may have been invalidated as a result of an alarm described in 2. Alternatively, the mastering data in system variable \$DMR_GRP.\$MASTER_COUN may have been overwritten as a result of an operation error or some other reason.

Compare the data with the values indicated on the supplied data sheet. This system variable is overwritten whenever mastering is performed. Whenever mastering is performed, record the value of the system variable on the data sheet.

2 Alarm types displayed during mastering and their solution method:

(1) BZAL alarm

This alarm is displayed if the Pulsecoder's backup battery voltage decreases to 0 V while the power to the controller is disconnected. Furthermore, if the Pulsecoder connector is removed for cable replacement, etc. this alarm is displayed as the voltage decreases to 0. Check to see if the alarm will disappear by performing a pulse reset (See Section 8.2.). Then, cycle controller power and check if the alarm disappears or not.

The battery may be drained if the alarm is still displayed. Perform a pulse reset, and turn off and on the controller power after replacing the battery. Note that, if this alarm is displayed, all the original data held by the Pulsecoder will be lost. Mastering is required.

(2) BLAL alarm

This alarm is displayed if the voltage of the Pulsecoder's backup battery has fallen to a level where backup is no longer possible. If this alarm is displayed, replace the battery with a new one immediately while keeping the power turned on. Check whether the current position data is valid, using the procedure described in 1.

(3) Alarm notification like CKAL, RCAL, PHAL, CSAL, DTERR, CRCERR, STBERR, and SPHAL may have trouble with Pulsecoder, contact your local FANUC representative.

8.9 MASTERING BACKUP AND RESTORATION WHEN CONTINUOUS ROTATION ENABLED

Refer to Section 6.2 for backup and restoration of mastering data when the continuous rotation is enabled.

9 TROUBLESHOOTING

The source of mechanical unit problems may be difficult to locate because of overlapping causes. Problems may become further complicated, if they are not corrected properly. Therefore, you must keep an accurate record of problems and take proper corrective actions.

9.1 TROUBLESHOOTING

Table 9.1 (a) shows the problems that may occur in the mechanical unit and their probable causes. If you cannot pinpoint the cause of a failure or which measures to take, contact your local FANUC representative. For troubleshooting except the mechanical unit, refer to “CONTROLLER MAINTENANCE MANUAL (B-84035EN)” and Alarm Code List (B-83284EN-1).

Table 9.1 (a) Troubleshooting

| Symptom | Description | Cause | Measure |
|--------------------|---|---|--|
| Vibration Noise | <ul style="list-style-type: none"> - The J1 base lifts off the floor plate as the robot operates. - There is a gap between the J1 base and floor plate. - A J1 base retaining bolt is loose. | <p>[J1 base fastening]</p> <ul style="list-style-type: none"> - It is likely that the robot J1 base is not securely fastened to the floor plate. - Probable causes are a loose bolt, an insufficient degree of surface flatness, or contamination caught between the robot and floor plate. - If the robot is not securely fastened to the floor plate, the J1 base lifts the floor plate as the robot operates, allowing the base and floor plates to strike each other. That, in turn, leads to vibration. | <ul style="list-style-type: none"> - If a bolt is loose, apply LOCTITE and tighten it to the appropriate torque. - Adjust the floor plate surface flatness to within the specified tolerance. - If there is any contamination between the J1 base and floor plate, remove it. |
| | <ul style="list-style-type: none"> - The rack or floor plate vibrates during operation of the robot. | <p>[Rack or floor]</p> <ul style="list-style-type: none"> - It is likely that the rack or floor is not rigid enough. - If they are not rigid enough, counterforce deforms the rack or floor, and is responsible for the vibration. | <ul style="list-style-type: none"> - Reinforce the rack or floor to make it more rigid. - If reinforcing the rack or floor is impossible, modify the robot control program; doing so might reduce the vibration. |

| Symptom | Description | Cause | Measure |
|-----------------------------------|---|---|---|
| Vibration Noise (Continued) | <ul style="list-style-type: none"> - Vibration becomes more serious when the robot adopts a specific posture. - If the operating speed of the robot is reduced, vibration stops. - Vibration is most noticeable when the robot is accelerating. - Vibration occurs when two or more axes operate at the same time. - Vibration was first noticed after the robot collided with an object or the robot was overloaded for a long period. - The grease of the vibrating axis has not been replenished for a long period. - Cyclical vibration and noise occur. | <p>[Overload]</p> <ul style="list-style-type: none"> - It is likely that the load on the robot is greater than the maximum rating. - It is likely that the robot control program is too demanding for the robot hardware. <p>[Bearing, ball screw spline or reducer]</p> <ul style="list-style-type: none"> - It is likely that the collision or overload applied an excessive force to the drive mechanism, thus damaging the rolling surface of a bearing, ball screw spline or reducer. - It is likely that prolonged use of the robot while overloaded caused fretting of rolling surface of a bearing, ball screw spline or reducer due to resulting metal fatigue. - It is likely that contamination which was caught in a bearing, ball screw spline or within a reducer caused damage on the rolling surface of the bearing, or reducer. - It is likely that contamination which was caught in a bearing, ball screw spline or within a reducer cause vibration. - It is likely that, because the grease has not been replenished for a long period, peeling occurred on the bearing, the ball screw spline, or the gear tooth surface or rolling surface of a bearing, or reducer due to metal fatigue. | <ul style="list-style-type: none"> - Check the maximum load that the robot can handle once more. If the robot is found to be overloaded, reduce the load, or modify the robot control program. - Vibration in a specific portion can be reduced by modifying the robot control program while slowing the robot and reducing its acceleration (to minimize the influence on the entire cycle time). <ul style="list-style-type: none"> - Operate one axis at a time to determine which axis is vibrating. - Remove the motor, and replace the gear, the bearing, the ball screw spline and the reducer. For the spec. of parts and the method of replacement, contact your local FANUC representative. - Using the robot within its maximum rating prevents problems with the drive mechanism. - Using the specified grease at the recommended interval will prevent problems. |

| Symptom | Description | Cause | Measure |
|-----------------------------------|--|--|--|
| Vibration Noise (Continued) | <ul style="list-style-type: none"> - The cause of problem cannot be identified from examination of the floor, rack, or mechanical unit. | <p>[Controller, cable, and motor]</p> <ul style="list-style-type: none"> - If a failure occurs in a controller circuit, preventing control commands from being supplied to the motor normally, or preventing motor information from being sent to the controller normally, vibration might occur. - A Pulsecoder defect may be the cause of the vibration as the motor cannot propagate the accurate position. - If the motor becomes defective, vibration might occur because the motor cannot deliver its rated performance. - If a power line in a movable cable of the mechanical unit has an intermittent break, vibration might occur because the motor cannot accurately respond to commands. - If a Pulsecoder wire in a movable part of the mechanical unit has an intermittent break, vibration might occur because commands cannot be sent to the motor accurately. - If a robot connection cable has an intermittent break, vibration might occur. - If the power cable between them has an intermittent break, vibration might occur. - If the power source voltage drops below the rating, vibration might occur. - The robot may vibrate when the invalid value parameter was set. | <ul style="list-style-type: none"> - Refer to the Controller Maintenance Manual for troubleshooting related to the controller and amplifier. - Replace the motor of the axis that is vibrating, and check whether vibration still occurs. For the method of replacement, contact your local FANUC representative. - If vibration occurs only when the robot assumes a specific posture, it is likely that there is a mechanical problem. - Check whether the cable jacket of the robot connection cable is damaged. If so, replace the connection cable, and check whether vibration still occurs. - Check whether the power cable jacket is damaged. If so, replace the power cable, and check whether vibration still occurs. - Check that the robot is supplied with the rated voltage. - Check that the robot control parameter is set to a valid value. If it is set to an invalid value, correct them. Contact your local FANUC representative for further information if necessary. - Contact your local FANUC representative if performing the belt check. |

| Symptom | Description | Cause | Measure |
|-----------------------------|--|--|--|
| Vibration Noise (Continued) | <ul style="list-style-type: none"> - There is some relationship between the vibration of the robot and the operation of a machine near the robot. | <p>[Noise from a nearby machine]</p> <ul style="list-style-type: none"> - If the robot is not grounded properly, electrical noise may be induced on the grounding wire, preventing commands from being transferred accurately, thus leading to vibration. - If the robot is grounded at an unsuitable point, its grounding potential becomes unstable, and noise is likely to be induced on the grounding line, thus leading to vibration. | <ul style="list-style-type: none"> - Connect the grounding wire firmly to ensure a reliable ground potential and prevent extraneous electrical noise. |
| Rattling | <ul style="list-style-type: none"> - While the robot is not supplied with power, pushing it with the hand causes part of the mechanical unit to wobble. - There is a gap on the mounting face of the mechanical unit. | <p>[Mechanical unit coupling bolt]</p> <ul style="list-style-type: none"> - It is likely that overloading or a collision has loosened a mounting bolt in the robot mechanical unit. | <ul style="list-style-type: none"> - Check that the following bolts for each axis are tight. If any of these bolts is loose, apply LOCTITE and tighten it to the appropriate torque. <ul style="list-style-type: none"> - Motor retaining bolt - Reducer retaining bolt - Base retaining bolt - Arm retaining bolt - Casting retaining bolt - End effector retaining bolt |
| Motor overheating | <ul style="list-style-type: none"> - The motor overheated due to a rise in temperature in the installation area. - After changing the Robot control program or the load, the motor overheated. - After a control parameter (load setting etc.) was changed, the motor overheated. | <p>[Ambient temperature]</p> <ul style="list-style-type: none"> - It is likely that the motor overheated when the ambient temperature rose, and could not dissipate the heat. <p>[Operating condition]</p> <ul style="list-style-type: none"> - It is likely that the overcurrent is above the specified permissive average current. <p>[Parameter]</p> <ul style="list-style-type: none"> - If data input for a workpiece is invalid, the robot cannot be accelerate or decelerate normally, so the average current increases, leading to the motor overheating. | <ul style="list-style-type: none"> - Reducing the ambient temperature is the most effective means of preventing overheating. - If there is a source of heat near the motor, it is advisable to install shielding to protect the motor from heat radiation. - Relaxing the robot control program and load condition is an effective way to reduce the average current. Thus, prevent overheating. - The teach pendant can be used to monitor the average current. Check the average current when the robot control program is running. - As for load setting, Input an appropriate parameter referring to Section 4.3. |

| Symptom | Description | Cause | Measure |
|-------------------|---|---|---|
| Motor overheating | <ul style="list-style-type: none"> - Symptom other than stated above | <p>[Mechanical unit problems]</p> <ul style="list-style-type: none"> - It is likely that problems occurred in the mechanical unit drive mechanism, thus placing an excessive load on the motor. <p>[Motor problems]</p> <ul style="list-style-type: none"> - It is likely that a failure of the motor brake resulted in the motor running with the brake applied, thus placing an excessive load on the motor. - It is likely that a failure of the motor prevented it from delivering its rated performance, thus causing an excessive current to flow through the motor. | <ul style="list-style-type: none"> - Repair the mechanical unit while referring to the above descriptions of vibration, noise, and rattling. - Check that, when the servo system is energized, the brake is released. If the brake remains applied to the motor all the time, replace the motor. - If the average current falls after the motor is replaced, it indicates that the first motor was faulty. |
| Grease leakage | <ul style="list-style-type: none"> - Grease is leaking from the mechanical unit. | <p>[Poor sealing]</p> <ul style="list-style-type: none"> - Probable causes are a crack in the casting, a damaged oil seal, or a loose seal bolt. - A crack in a casting can occur due to excessive force that might be caused in a collision. - An oil seal might be damaged if extraneous dust scratches the lip of the oil seal. - A loose seal bolt might allow grease to leak along the threads. - There is a possibility that too much grease is applied to the ball screw spline. | <ul style="list-style-type: none"> - If a crack develops in the casting, sealant can be used as a quick-fix to prevent further grease leakage. However, the component should be replaced as soon as possible, because the crack might extend. - Oil seals are used in the locations stated below. <ul style="list-style-type: none"> - Inside the reducer - Inside the wrist - Seal bolts are used in the locations stated below. <ul style="list-style-type: none"> - Grease inlet - Wipe off grease on the ball screw spline adequately. |
| Dropping axis | <ul style="list-style-type: none"> - An axis drops because the brake failed. - An axis drops gradually when it should be at rest. | <p>[Brake drive relay and motor]</p> <ul style="list-style-type: none"> - It is likely that the brake drive relay contacts are stuck to each other keeping the brake current flowing, thus preventing the brake from operating when the motor is de-energized. - It is likely that the brake shoe has worn out or the brake main body is damaged, preventing the brake from operating efficiently. - It is likely that oil or grease has entered the motor, causing the brake to slip. | <ul style="list-style-type: none"> - Check whether the brake drive relay contacts are stuck to each other or not. If they are stuck, replace the relay. - Replace the motor after confirming the following symptoms. <ul style="list-style-type: none"> - Brake shoe is worn out - Brake main body is damaged - Oil soaked through the motor |

| Symptom | Description | Cause | Measure |
|--------------|--|--|--|
| Displacement | <ul style="list-style-type: none"> The robot moves to a point other than the taught position. The repeatability is not within the tolerance. | <p>[Mechanical unit problems]</p> <ul style="list-style-type: none"> If the repeatability is unstable, probable causes are a failure in the drive mechanism or a loose bolt. If the repeatability becomes stable it is likely that a collision imposed an excessive load, leading to slipping on the base surface or the mating surface of an arm or reducer. It is likely that the Pulsecoder is faulty. | <ul style="list-style-type: none"> If the repeatability is unstable, repair the mechanical unit by referring to the above descriptions of vibration, noise, and rattling. If the repeatability is stable, correct the taught program. The problem will not reoccur unless another collision occurs. If the Pulsecoder is faulty, replace the motor. |
| | <ul style="list-style-type: none"> Displacement occurs only in a specific peripheral unit. | <p>[Peripheral unit displacement]</p> <ul style="list-style-type: none"> It is likely that an external force was applied to the peripheral unit, thus shifting its position relative to the robot. | <ul style="list-style-type: none"> Correct the setting of the peripheral unit position. Correct the taught program. |
| | <ul style="list-style-type: none"> Displacement occurred after a parameter was changed. | <p>[Parameter]</p> <ul style="list-style-type: none"> It is likely that the mastering data was rewritten in such a way that the robot origin was shifted. | <ul style="list-style-type: none"> Re-enter the previous mastering data, which is known to be correct. If correct mastering data is unavailable, perform mastering again. |

| Symptom | Description | Cause | Measure |
|--|--|--|--|
| CLALM alarm occurred. Move error excess alarm occurred. | <ul style="list-style-type: none"> - Ambient temperature of the robot installation location is low, CLALM alarm is displayed on the teach pendant screen. - Ambient temperature of the robot installation position is low, "Move error excess" alarm is displayed on the teach pendant screen. | <p>[Peripheral temperature]</p> <ul style="list-style-type: none"> - When the robot is used in a low temperature environment that is near to 0°C, or the robot is not operated for a long time in an environment that is less than 0°C, there will be a large viscous resistance of the drive train immediately after starting which will cause the alarm. | <ul style="list-style-type: none"> - Perform a warm up operation or a low speed operation for several minutes. |
| | <ul style="list-style-type: none"> - After changing the motion program or the load condition, the CLALM alarm is displayed. - After changing the motion program or the load condition, the "Move error excess" alarm is displayed. | <ul style="list-style-type: none"> - It is likely that a robot collision occurred. | <ul style="list-style-type: none"> - If a robot collision has occurred, press the [RESET] key while pressing the [SHIFT] key. Then, jog the robot in the opposite direction while pressing the [SHIFT] key. - Check the motion program. |
| | <ul style="list-style-type: none"> - None of the symptoms stated above are the problem. | <p>[Overload]</p> <ul style="list-style-type: none"> - It is likely that load exceeded the permissible value. - It is likely that the motion program is too severe for the robot. <ul style="list-style-type: none"> • Tight motion such as reverse motion using "CNT". • Linear motion occurs near singularity point where axes revolve in high speed. | <ul style="list-style-type: none"> - Check the permissible value of the robot payload. If the load exceeds the permissible value, reduce the load or change the motion program. - Consider minimizing the influence on cycle time by reducing the speed or acceleration, and changing the motion program. - Check that the load setting is performed correctly. |
| BZAL alarm displayed | <ul style="list-style-type: none"> - BZAL is displayed on the teach pendant screen. | <ul style="list-style-type: none"> - The voltage of the memory backup battery may be low. - The Pulsecoder cable may be broken. | <ul style="list-style-type: none"> - Replace the battery. - Replace the cable. |

APPENDIX

RESHAPE AUTOMATION INC
RESTREPOL

RESHAPE AUTOMATION INC
RESTREPOL

A PERIODIC MAINTENANCE TABLE

RESHAPE AUTOMATION INC
RESTREPOL

FANUC Robot SR-3iA, SR-3iA/H, SR-6iA, SR-6iA/H

Periodic Maintenance Table

| Items | | Accumulated operating time (H) | Check time | Grease amount | First check 320 | 3 months 960 | 6 months 1920 | 9 months 2880 | 1 years 3840 | 4800 | 5760 | 6720 | 7680 | 2 years 7680 | 8640 | 9600 | 10560 |
|-----------------|----|---|------------|-----------------|-----------------|--------------|---------------|---------------|--------------|------|------|------|------|--------------|------|------|-------|
| Mechanical unit | 1 | Check for external damage or peeling paint | 0.1H | — | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 2 | Check for water | 0.1H | — | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 3 | Check the exposed connector. (loosening) | 0.2H | — | | ○ | | | ○ | | | | ○ | | | | |
| | 4 | Tighten the end effector bolt. | 0.2H | — | | ○ | | | ○ | | | | ○ | | | | |
| | 5 | Tighten the cover and main bolt. | 1.0H | — | | ○ | | | ○ | | | | ○ | | | | |
| | 6 | Check the fixed mechanical stopper. | 0.1H | — | | ○ | | | ○ | | | | ○ | | | | |
| | 7 | Clean spatters, sawdust and Dust | 1.0H | — | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 8 | Check the end effector (hand) cable | 0.1H | — | | ○ | | | ○ | | | | ○ | | | | |
| | 9 | Replacing batteries (if built-in batteries are specified) *3 | 0.1H | — | | | | | | ● | | | | ● | | | |
| | 9 | Replacing batteries (if external batteries are specified) *3 | 0.1H | — | | | | | | | | ● | | | | | |
| | 10 | Greasing the J1, J2-axis reducers. | 0.1H | each 5ml | | | | | | | | ● | | | | | |
| | 11 | Greasing the ball screw spline | 0.1H | Proper quantity | | | ● | | ● | | ● | | ● | | ● | | |
| | 12 | Confirm the belt tension | 0.1H | | | | | | ○ | | | | ○ | | | | |
| Controller | 13 | Replacing cable of mechanical unit | 1.0H | — | | | | | | | | | ● | | | | |
| | 15 | Check the robot cable, teach pendant cable and robot connecting cable | 0.2H | — | | ○ | | | ○ | | | | ○ | | | | |
| | 16 | Cleaning the controller ventilation system | 0.2H | — | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 17 | Replacing batteries *1 *3 | 0.1H | — | | | | | | | | | | | | | |

*1 Refer to the "REPLACING UNITS Chapter of "MAINTENANCE" in the following manuals.
CONTROLLER MAINTENANCE MANUAL (B-84035EN)

*2 ●: requires order of parts

○: does not require order of parts

*3 Regardless of the operating time, replace the mechanical unit batteries at 1 year or 1.5 year, replace controller batteries at 4 years.

| 3 years 11520 | 12480 | 13440 | 14400 | 4 years 15360 | 16320 | 17280 | 18240 | 5 years 19200 | 20160 | 21120 | 22080 | 6 years 23040 | Item |
|------------------|-------|-------|-------|------------------|-------|-------|-------|------------------|-------|-------|-------|------------------|------|
| O | O | O | O | O | O | O | O | O | O | O | O | O | 1 |
| O | O | O | O | O | O | O | O | O | O | O | O | O | 2 |
| O | | | O | | | | O | | | | | | 3 |
| O | | | O | | | | O | | | | | | 4 |
| O | | | O | | | | O | | | | | | 5 |
| O | | | O | | | | O | | | | | | 6 |
| O | O | O | O | O | O | O | O | O | O | O | O | O | 7 |
| O | | | O | | | | O | | | | | | 8 |
| ● | | | ● | | | | ● | | | | | | 9 |
| ● | | | | | | ● | | | | | | | 10 |
| ● | | | | | | ● | | | | | | | 11 |
| ● | ● | ● | ● | ● | ● | ● | ● | ● | | | | | 12 |
| O | | | O | | | | O | | | | | | 13 |
| | | | ● | | | | | | | | | | 15 |
| O | | | O | | | | O | | | | | | 16 |
| O | O | O | O | O | O | O | O | O | O | O | O | O | 17 |
| | | | ● | | | | | | | | | | |

FANUC Robot SR-3iA/C, SR-6iA/C

Periodic Maintenance Table

| Items | | Accumulated operating time (H) | Check time | Grease amount | First check 320 | 3 months 960 | 6 months 1920 | 9 months 2880 | 1 years 3840 | 4800 | 5760 | 6720 | 7680 | 2 years 7680 | 8640 | 9600 | 10560 |
|-----------------|----|---|------------|-----------------|-----------------|--------------|---------------|---------------|--------------|------|------|------|------|--------------|------|------|-------|
| Mechanical unit | 1 | Check for external damage or peeling paint | 0.1H | — | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 2 | Check for water | 0.1H | — | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 3 | Check the exposed connector. (loosening) | 0.2H | — | | ○ | | | ○ | | | | ○ | | | | |
| | 4 | Tighten the end effector bolt. | 0.2H | — | | ○ | | | ○ | | | | ○ | | | | |
| | 5 | Tighten the cover and main bolt. | 1.0H | — | | ○ | | | ○ | | | | ○ | | | | |
| | 7 | Clean spatters, sawdust and Dust | 1.0H | — | | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 8 | Check the end effector (hand) cable | 0.1H | — | | ○ | | | ○ | | | | ○ | | | | |
| | 9 | Replacing batteries *3 | 0.1H | — | | | | | ● | | | | ● | | | | |
| | 10 | Greasing the J1, J2-axis reducers. | 0.1H | each 2ml | | | | | ● | | | | ● | | | | |
| | 11 | Greasing the ball screw spline | 0.1H | Proper quantity | | | ● | | ● | | ● | | ● | | ● | | |
| | 12 | Confirm the belt tension | 0.1H | — | | | | | ○ | | | | ○ | | | | |
| | 13 | Replacing cable of mechanical unit | 1.0H | — | | | | | | | | | ● | | | | |
| | 14 | Check the bellows | 0.1H | — | | | | | ○ | | | | ○ | | | | |
| Controller | 15 | Check the robot cable, teach pendant cable and robot connecting cable | 0.2H | — | | ○ | | | ○ | | | | ○ | | | | |
| | 16 | Cleaning the controller ventilation system | 0.2H | — | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | ○ | |
| | 17 | Replacing batteries *1 *3 | 0.1H | — | | | | | | | | | | | | | |

*1 Refer to the "REPLACING UNITS Chapter of "MAINTENANCE" in the following manuals.
CONTROLLER MAINTENANCE MANUAL (B-84035EN)

*2 ●: requires order of parts

○: does not require order of parts

*3 Regardless of the operating time, replace the mechanical unit batteries at 1 year, replace controller batteries at 4 years.

| 3 years 11520 | 12480 | 13440 | 14400 | 4 years 15360 | 16320 | 17280 | 18240 | 5 years 19200 | 20160 | 21120 | 22080 | 6 years 23040 | Item |
|------------------|-------|-------|-------|------------------|-------|-------|-------|------------------|-------|-------|-------|------------------|----------|
| O | O | O | O | O | O | O | O | O | O | O | O | O | Overhaul |
| O | O | O | O | O | O | O | O | O | O | O | O | O | |
| O | | | | O | | | | O | | | | | |
| O | | | | O | | | | O | | | | | |
| O | | | | O | | | | O | | | | | |
| O | O | O | O | O | O | O | O | O | O | O | O | O | |
| O | | | | O | | | | O | | | | | |
| ● | | | | ● | | | | ● | | | | | |
| ● | | | | ● | | | | ● | | | | | |
| ● | ● | ● | ● | ● | | ● | | ● | | ● | | | |
| O | | | O | | | | | O | | | | | |
| | | | ● | | | | | | | | | | |
| O | | | O | | | | | O | | | | | |
| O | | | O | | | | | O | | | | | |
| O | O | O | O | O | O | O | O | O | O | O | O | O | |
| | | | ● | | | | | | | | | | |

B STRENGTH OF BOLT AND BOLT TORQUE LIST

NOTE

When applying LOCTITE to a part, spread the LOCTITE on the entire length of the engaging part of the female thread. If applied to the male threads, poor adhesion can occur, potentially loosening the bolt. Clean the bolts and the threaded holes and wipe off any oil on the engaging section. Make sure that there is no solvent left in the threaded holes. When finished, remove all the excess LOCTITE when you are finished screwing the bolts into the threaded holes.

Use the following strength bolts. Comply with any bolt specification instructions.

Hexagon socket head bolt made of steel:

Size M20 or less: Tensile strength 1200N/mm² or more



Size M22 or more: Tensile strength 1000N/mm² or more

All size plating bolt: Tensile strength 1000N/mm² or more

Hexagon bolt, stainless bolt, special shape bolt (button bolt, low-head bolt, flush bolt .etc.)

Tensile strength 400N/mm² or more

Refer to the following tables if the bolts tightening torque is not specified.

| Nominal diameter | Recommended bolt tightening torques | | | | | | | | Unit: Nm |
|------------------|---|-------------|--|-------------|--|--|----------------------|---|----------|
| | Hexagon socket head bolt (steel) | | Hexagon socket head bolt (stainless steel) | | Hexagon socket head button bolt Hexagon socket head flush bolt Low-head bolt (steel) | | Hexagon bolt (steel) | | |
| | Tightening torque | | Tightening torque | | Tightening torque | | Tightening torque | | |
| | Upper limit | Lower limit | Upper limit | Lower limit | Upper limit | Lower limit | Upper limit | Lower limit | |
| M3 | 1.8 | 1.3 | 0.76 | 0.53 | — | — | — | — | |
| M4 | 4.0 | 2.8 | 1.8 | 1.3 | 1.8 | 1.3 | 1.7 | 1.2 | |
| M5 | 7.9 | 5.6 | 3.4 | 2.5 | 4.0 | 2.8 | 3.2 | 2.3 | |
| M6 | 14 | 9.6 | 5.8 | 4.1 | 7.9 | 5.6 | 5.5 | 3.8 | |
| M8 | 32 | 23 | 14 | 9.8 | 14 | 9.6 | 13 | 9.3 | |
| M10 | 66 | 46 | 27 | 19 | 32 | 23 | 26 | 19 | |
| M12 | 110 | 78 | 48 | 33 | — | — | 45 | 31 | |
| (M14) | 180 | 130 | 76 | 53 | — | — | 73 | 51 | |
| M16 | 270 | 190 | 120 | 82 | — | — | 98 | 69 | |
| (M18) | 380 | 260 | 160 | 110 | — | — | 140 | 96 | |
| M20 | 530 | 370 | 230 | 160 | — | — | 190 | 130 | |
| (M22) | 730 | 510 | — | — | — | — | — | — | |
| M24 | 930 | 650 | — | — | — | — | — | — | |
| (M27) | 1400 | 960 | — | — | — | — | — | — | |
| M30 | 1800 | 1300 | — | — | — | — | — | — | |
| M36 | 3200 | 2300 | — | — | — | — | — | — | |
| |  | | | | |  | |  | |

INDEX

<A>

| | |
|--|----|
| AIR SUPPLY | 55 |
| AIR SUPPLY AND EE (RI/RO) INETRFACE..... | 56 |
| Angle of Mounting Surface Setting..... | 13 |
| AXIS LIMIT SETUP | 64 |

| | |
|----------------------------|----|
| BASIC SPECIFICATIONS | 20 |
|----------------------------|----|

<C>

| | |
|--|----|
| CHANGE AXIS LIMIT BY DCS (OPTION)..... | 64 |
| Check of Mechanical Stopper | 74 |
| CHECK POINTS | 72 |
| Check the Connectors..... | 73 |
| CHECKS AND MAINTENANCE | 69 |
| Confirmation of Oil Seepage..... | 72 |
| Confirmation of the Air Control Set and Air Purge kit (option)..... | 73 |
| CONNECTION WITH THE CONTROLLER..... | 17 |

<D>

| | |
|--------------------|----|
| Daily Checks | 69 |
|--------------------|----|

<E>

| | |
|---|----|
| END EFFECTOR INSTALLATION TO WRIST | 42 |
| EQUIPMENT INSTALLATION TO THE ROBOT | 42 |
| EQUIPMENT MOUNTING FACE | 46 |

<F>

| | |
|---|----|
| Fixture for bellows of SR-3iA/C, SR-6iA/C | 89 |
|---|----|

<I>

| | |
|-------------------------------|----|
| INSTALLATION | 4 |
| INSTALLATION CONDITIONS | 16 |
| Installation Example..... | 10 |

<J>

| | |
|---|----|
| J4-AXIS MOTION RANGE EXTENSION BY CONTINUOUS ROTATION FUNCTION | 67 |
|---|----|

<M>

| | |
|--|----|
| MAINTENANCE | 75 |
| MAINTENANCE AREA..... | 15 |
| MASTERING | 84 |
| MASTERING BACKUP AND RESTORATION WHEN CONTINUOUS ROTATION ENABLED | 99 |
| MASTERING DATA ENTRY | 97 |
| MECHANICAL UNIT OPERATING SPACE AND INTERFERENCE AREA..... | 26 |

<O>

| | |
|----------------|----|
| OVERVIEW | 84 |
|----------------|----|

<P>

| | |
|-----------------------|----|
| PAYLOAD SETTING | 50 |
|-----------------------|----|

| | |
|---|-----|
| Periodic Check and Maintenance | 70 |
| PERIODIC MAINTENANCE TABLE | 109 |
| PIPING AND WIRING TO THE END EFFECTOR | 54 |
| PREFACE | p-1 |

<Q>

| | |
|---------------------------------------|----|
| QUICK MASTERING | 91 |
| QUICK MASTERING FOR SINGLE AXIS | 93 |

<R>

| | |
|--|----|
| Replacing the Batteries (1-Year Periodic Inspection If Built-in Batteries Are Specified) (1.5-Year Periodic Inspection If External Batteries Are Specified) | 75 |
| Replenish the Grease of the Ball Screw Spline (6 months (1920 hours) checks) | 79 |
| Replenish the Grease of the Reducer (1.5 years (5760 hours) or 1 years (3840 hours) checks) | 78 |
| RESETTING ALARMS AND PREPARING FOR MASTERING | 85 |
| ROBOT CONFIGURATION | 20 |

<S>

| | |
|--|-----|
| SAFETY PRECAUTIONS | s-1 |
| SINGLE AXIS MASTERING | 95 |
| STORAGE | 83 |
| STRENGTH OF BOLT AND BOLT TORQUE LIST | 114 |

<T>

| | |
|---------------------------------------|-----|
| Tool flange option | 25 |
| TRANSPORTATION | 1 |
| TRANSPORTATION AND INSTALLATION | 1 |
| TROUBLESHOOTING | 100 |

<V>

| | |
|---------------------------|----|
| VERIFYING MASTERING | 99 |
|---------------------------|----|

<W>

| | |
|-----------------------------|----|
| WRIST LOAD CONDITIONS | 37 |
|-----------------------------|----|

<Z>

| | |
|--|----|
| ZERO POINT POSITION AND MOTION LIMIT | 30 |
| ZERO POSITION MASTERING | 86 |

RESHAPE AUTOMATION INC
RESTREPOL

REVISION RECORD

| Edition | Date | Contents |
|---------|------------|--|
| 08 | Jul., 2023 | <ul style="list-style-type: none">• Addition of wall mount• Correction wrist load diagram• Correction of errors |
| 07 | Jul., 2022 | <ul style="list-style-type: none">• Addition of SR-3iA/C, SR-6iA/C• Correction of errors |
| 06 | Jan., 2022 | <ul style="list-style-type: none">• Addition information of the tool flange option• Addition of mechanical unit cables• Correction of errors |
| 05 | Feb., 2021 | <ul style="list-style-type: none">• Addition of the tool flange option• Addition of NOTE• Correction of errors |
| 04 | Jun., 2020 | <ul style="list-style-type: none">• Addition of SR-3iA/H, SR-6iA/H• Correction of errors |
| 03 | Jan., 2020 | <ul style="list-style-type: none">• Addition of continuous rotation function• Correction of errors |
| 02 | Aug., 2018 | <ul style="list-style-type: none">• Addition of SR-6iA• Correction of errors |
| 01 | Feb., 2018 | |

RESHAPE AUTOMATION INC
RESTREPOL

B-84024EN/08



* B - 8 4 0 2 4 E N / 0 8 *