


# Schneider Electric Mitsubishi FX Protocol XBT N/R/RT

33004004

06/2008

33004004.01





---

# Table of Contents




---

|                   |  |           |
|-------------------|--|-----------|
|                   | <b>Safety Information</b> .....                              | <b>5</b>  |
|                   | <b>About the Book</b> .....                                  | <b>7</b>  |
| <b>Chapter 1</b>  | <b>Compatibility</b> .....                                   | <b>9</b>  |
| <b>Chapter 2</b>  | <b>Operating Principle</b> .....                             | <b>11</b> |
|                   | General Information on Bus Communications. ....              | 12        |
|                   | Master / Slave Communication Principle. ....                 | 13        |
|                   | Communication of XBT Terminals with Mitsubishi FX PLCs. .... | 14        |
| <b>Chapter 3</b>  | <b>Software Configuration</b> .....                          | <b>15</b> |
|                   | Vijeo-Designer Lite .....                                    | 15        |
| <b>Chapter 4</b>  | <b>Variable Types Supported</b> .....                        | <b>17</b> |
| <b>Chapter 5</b>  | <b>Cables and Connectors</b> .....                           | <b>19</b> |
| <b>Chapter 6</b>  | <b>Diagnostics</b> .....                                     | <b>21</b> |
|                   | Detected Error Indication. ....                              | 21        |
| <b>Appendices</b> | .....  | <b>25</b> |
| <b>Appendix A</b> | <b>RS232 Recommendations</b> .....                           | <b>27</b> |
| <b>Glossary</b>   | .....  | <b>29</b> |
| <b>Index</b>      | .....  | <b>31</b> |

---

---

## Safety Information



---

### Important Information

#### NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a Danger or Warning safety label indicates that an electrical hazard exists, which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

### DANGER

DANGER indicates an imminently hazardous situation, which, if not avoided, **will result** in death or serious injury.

### WARNING

WARNING indicates a potentially hazardous situation, which, if not avoided, **can result** in death, serious injury, or equipment damage.

### CAUTION

CAUTION indicates a potentially hazardous situation, which, if not avoided, **can result** in injury or equipment damage.

**PLEASE NOTE**


Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

© 2008 Schneider Electric. All Rights Reserved.

---

---

## About the Book



---

### At a Glance

**Document Scope** This document describes communication between automation systems and the XBT N/R/RT product range using the Mitsubishi FX protocol.

**Validity Note** The data and illustrations found in this document are not binding. We reserve the right to modify our products in line with our policy of continuous product development. The information in this document is subject to change without notice and should not be construed as a commitment by Schneider Electric.

---

### Related Documents

| Title of Documentation       | Reference Number  |
|------------------------------|-------------------|
| XBT N/R/RT Instruction sheet | W916810140111 A08 |
| XBT N/R/RT User Manual       | 33003962          |
| Vijeo-Designer Lite          | Online help       |

---

**Product Related Warnings** Schneider Electric assumes no responsibility for any errors that may appear in this document. If you have any suggestions for improvement or amendments or have found errors in this publication, please notify us.

No part of this document may be reproduced in any form or by means, electronic or mechanical, including photocopying, without express written permission of Schneider Electric.

All pertinent state, regional and local safety regulations must be observed when installing and using this product. For reasons of safety and to ensure compliance with documented system data, only the manufacturer should perform repairs to components.

Since the XBT N/R/RT terminals are not designed to pilot safety critical processes, no specific instructions apply in this content.

---

**User Comments**

We welcome your comments about this document. You can reach us by e-mail at [techpub@schneider-electric.com](mailto:techpub@schneider-electric.com)

---



---

# Compatibility



---

## Compatibility

### Overview

The Mitsubishi CPU-direct protocol available for XBT terminals can be used to communicate with the following Mitsubishi FX process controllers:

- FX0N, FX0S
  - FX1N, FX1S
  - FX2N, FX2NC, FX2C
-



---

# Operating Principle

# 2

---

## At a Glance

### Overview

This chapter describes the operating principle of XBT terminals in applications using the Mitsubishi CPU-direct protocol.

### WARNING

#### LOSS OF CONTROL

- The designer of any control scheme must consider the potential failure modes of control paths and, for certain critical functions, provide a means to achieve a safe state during and after a path failure. Examples of critical control functions are emergency stop and overtravel stop.
- Separate or redundant control paths must be provided for critical control functions.
- System control paths may include communication links. Consideration must be given to the implications of unanticipated transmission delays or failures of the link.\*
- Each implementation of a Magelis XBT N/R/RT must be individually and thoroughly tested for proper operation before being placed into service.

\*For additional information, refer to NEMA ICS 1.1 (latest edition), *Safety Guidelines for the Application, Installation, and Maintenance of Solid State Control*

**Failure to follow these instructions can result in death, serious injury, or equipment damage.**

### What's in this Chapter?

This chapter contains the following topics:

| Topic  | Page |
|--|------|
| General Information on Bus Communications              | 12   |
| Master / Slave Communication Principle                 | 13   |
| Communication of XBT Terminals with Mitsubishi FX PLCs | 14   |

## General Information on Bus Communications

---

### Overview

The XBT terminals can be connected to PLCs using different protocols. This document describes the communication using the Mitsubishi CPU-direct protocol with the XBT terminal acting as master.

---

### Roles of XBT Terminals

The terminals are usually connected to a communication equipment (PLC or other) via a field bus. The XBT and the PLCs work autonomously of each other.

XBT terminals perform the following functions:

- monitoring function: XBT terminals visualize the processes that are active in the PLCs and indicate alarm states
  - command function: XBT terminals send information to the PLC upon user request
- 

### Roles of Buses

A bus system provides the possibility to connect different devices via a unique cabling.

---

### Roles of Protocols

The protocol defines the language that is spoken by all the equipment connected to the bus.

---

## Master / Slave Communication Principle

### Overview

Mitsubishi FX communications are performed according to the master / slave principle that is described in the following.

### Characteristics of the Master / Slave Principle


The master / slave principle is characterized as follows:

- Only one master is connected to the bus at a time.
- One or several slaves can be connected to the same serial bus.
- Only the master is allowed to initiate communication, i.e. to send requests to the slaves.
- In Mitsubishi FX communications, the master can only initiate one Mitsubishi FX transaction at the same time.
- The slaves can only answer requests they received from the master.
- The slaves are not allowed to initiate communication, neither to the master nor to any other slaves.
- In Mitsubishi FX communications, the slaves generate an error message and send it as response to the master if an error occurred in receipt of the message or if the slave is unable to perform the requested action.

### Terminals acting as Master in Mitsubishi FX Applications

In Mitsubishi FX applications, the XBT terminal acts as master device, i.e. it provides the client role, whereas the slave devices act as servers.

Application example of XBT R411



- 1 XBT N200 (master)
- 2 Mitsubishi FX PLC

## Communication of XBT Terminals with Mitsubishi FX PLCs

---

### Overview

In communications with Mitsubishi FX PLCs the XBT terminal has the status of master.

The Mitsubishi CPU-direct protocol is the communication protocol for Mitsubishi FX PLCs.

The XBT can be connected in point-to-point mode to Mitsubishi FX PLCs.

|   |
|---|
|  <b>WARNING</b>      |
| <b>UNINTENDED EQUIPMENT OPERATION</b>   |
| The protocol should only be used by authorized and properly trained personnel.                        |
| <b>Failure to follow these instructions can result in death, serious injury, or equipment damage.</b> |

---

## Software Configuration



# 3

---

### Vijeo-Designer Lite

#### Overview

Vijeo-Designer Lite does not provide dialog boxes for Mitsubishi CPU direct protocol applications because no configuration settings are required.

---





---

# Variable Types Supported

# 4

---

## Variable Types Supported

### Table of Variable Types Supported by the XBT

The following table lists all Mitsubishi FX variables XBT terminals can access.

| Variable Type Supported | Mitsubishi FX Syntax |
|-------------------------|----------------------|
| Output Bits             | %Yi                  |
| Input Bits              | %Xi                  |
| Bits of Word            | %Di;j                |
| Word                    | %Di                  |
| Double Word             | = word               |
| Floating                | = word               |
| String                  | = word               |

#### Identifiers

- i : 0...65535
- j : 0...15

Depending on the Mitsubishi FX PLC type connected, the width of the memory is different:

| Variable Type | Type of Variable | Symbol | Limits        |               |               |               |               |
|---------------|------------------|--------|---------------|---------------|---------------|---------------|---------------|
|               |                  |        | FX0N          | FX1S          | FX2C          | FX1N          | FX2N, FX2NC   |
| Bit           | Inputs           | X      | X0000 - X0127 | X0000 - X0015 | X0000 - X0223 | X0000 - X0127 | X0000 - X0183 |
|               | Outputs          | Y      | Y0000 - Y0127 | Y0000 - Y0013 | Y0000 - Y0223 | Y0000 - Y0127 | Y0000 - Y0183 |

| Variable Type | Type of Variable       | Symbol | Limits         |      |               |                |             |
|---------------|------------------------|--------|----------------|------|---------------|----------------|-------------|
|               |                        |        | FX0N           | FX1S | FX2C          | FX1N           | FX2N, FX2NC |
| Word          | Data Registers         | D      | D0000 -- D0255 |      | D0000 - D0999 | D0000 -- D7999 |             |
|               | File Registers         |        | D1000 - D2499  | N/A  | D1000 - D2999 | N/A            |             |
|               | RAM File Registers     |        | N/A            |      | D6000 - D7999 | N/A            |             |
|               | Special Data Registers |        | D8000 - D8255  |      |               |                |             |

The HMI application designer must use only those variables that are supported by the equipment he connects the XBT terminal to. Vijeo-Designer Lite cannot verify whether the configured variables are correct because the software does not know which equipment the terminal will finally be connected to.

---

## Cables and Connectors

# 5

---

### Cables

#### Technical Data


The following table lists the cables required to connect XBT terminals to the different Mitsubishi FX PLCs.

| PLC Type   | Terminal Type | Cable References   | Length          |
|--|---------------|--|-----------------|
| <ul style="list-style-type: none"><li>● FX0N</li><li>● FX1N</li><li>● FX1S</li><li>● FX2N</li><li>● FX2NC</li><li>● FX2C</li></ul> | XBT N401/410  | XBT Z980   | 2.5 m (8.2 ft.) |
|  | XBT R410/411  | mini-Din <--> SUB-D25                                      |                 |
|  | XBT RT        | XBT Z980<br>+ XBT ZG939<br>(+ XBT ZRTPW for<br>XBT RT 500) |                 |

---

**XBT Z980 Wiring Diagram**

The XBT Z980 cable used to connect XBT terminals to Mitsubishi FX PLCs includes an RS422-RS232 converter.



---

# Diagnostics



# 6

---

## Detected Error Indication

### Overview

XBT terminals indicate detected errors in different ways

- by displaying question marks ?????? in alphanumerical fields
- by displaying crosses for graphic objects
- by displaying hash characters in alphanumerical fields
- by blinking alphanumerical fields
- by issuing system error messages

The following paragraphs list these detected errors and their possible reasons.

### Question Marks and Crosses

When question marks ?????? and crosses XXXXXX are displayed on the display of your XBT terminal, a transmission error has occurred. To correct this, check the following:

| If...                        | Then ...   |
|------------------------------|--|
| question marks are displayed | verify that all cables are correctly connected.                        |
| question marks are displayed | the XBT terminal may have received no response from the PLC.           |
| question marks are displayed | the XBT terminal may have received an exception response from the PLC. |

### Hash Characters

Hash characters displayed in alphanumerical fields on your XBT terminal indicate that the value to be displayed is too long for this alphanumerical field and cannot completely be displayed. The value 100 can, for example, not be displayed in a 2-digit alphanumerical field. To correct this, enter a shorter value or adapt the size of the alphanumerical field so that it can display any of the possible values of the PLC variable.

## Blinking Alphanumerical Fields

Blinking alphanumerical fields on your XBT terminal indicate that the value of this field has exceeded or fallen below a user-defined threshold.

## System Error Messages

A variety of system error messages is by default configured for the terminals. All these standard system messages are assigned a panel number 200+x. A distinction is made between detected error messages indicating communication interruptions and status messages provoked by inputs at the terminal.

These 2 message types differ by the numbers they are assigned and by the way they are displayed at the terminal as shown in the list below:

| Error Message Caused by:    | Error Message Numbers | Display Mode   |
|-----------------------------|-----------------------|--|
| Communication Interruptions | 201– 204              | To indicate that a communication interruption has occurred, the message is displayed in a popup dialog box every 10 seconds. |
| Input at Terminal           | 241 – 258             | The status message is displayed as a response to user input at the terminal.   |

## Messages Caused by Communication Interruptions

Messages 201 to 204 are issued by the terminal to indicate that a communication interruption has occurred. They are displayed in a popup dialog every 10 seconds.

| If...  | Then ...   |
|--|--|
| message 201: DIALOG TABLE AUTHORIZATION INCORRECT is displayed | the authorization word in the dialog table does not have the expected value. (Refer to the Vijeo-Designer Lite online help for information on how this word is working.) To correct this verify that: <ul style="list-style-type: none"> <li>● you are connected to the right PLC</li> <li>● the memory of your PLC is not corrupted</li> <li>● the correct value is saved on the PLC</li> </ul> |
| message 202: DIALOG TABLE WRITING IMPOSSIBLE is displayed      | the write cycle to the dialog table of the PLC could not be ended. This condition may have the following causes: <ul style="list-style-type: none"> <li>● too much load on the communication bus</li> <li>● EMC disturbances on the communication bus</li> </ul>   |
| message 203: DIALOG TABLE READING IMPOSSIBLE is displayed      | the read cycle from the dialog table of the PLC could not be ended. This condition may have the following causes: <ul style="list-style-type: none"> <li>● too much load on the communication bus</li> <li>● EMC disturbances on the communication bus</li> </ul>  |

## Messages Caused by Input at the Terminal

Messages 242 to 254 are issued by the XBT as a response to user input at the terminal. These messages are displayed directly after the operator has sent an incorrect command to the terminal and will persist until the user has corrected the entered command or value. Messages 255 to 258 are status messages displayed after the user has initiated an operation at the terminal to indicate that it has (or has not) been accepted and is in progress.

| If...  | Then ...  |
|--|---|
| message 241: IMPOSSIBLE TO READ VARIABLE is displayed  | the terminal has attempted to read a variable but could not retrieve its value. This condition may have the following causes: <ul style="list-style-type: none"> <li>● too much load on the communication bus</li> <li>● EMC disturbances on the communication bus</li> </ul>   |
| message 242: IMPOSSIBLE TO WRITE VARIABLE is displayed | the terminal has attempted to write in a memory area of the equipment and has received a negative acknowledgement or no acknowledgement at all. This condition may have the following causes: <ul style="list-style-type: none"> <li>● too much load on the communication bus</li> <li>● EMC disturbances on the communication bus</li> </ul> |
| messages 243 to 249 are displayed                      | correct the value or command you have entered as indicated by the message.  |
| message 250: LANGUAGE IMPOSED BY PLC is displayed      | the PLC forces the terminal to use a language. This language cannot be changed by the operator. For more information see the Vijeo-Designer Lite online help, functions of the dialog table.  |
| messages 251 or 252 are displayed                      | correct the value or command you have entered as indicated by the message.  |
| message 253: PASSWORD IMPOSED BY PLC is displayed      | you cannot change the password at the terminal because it is forced by the PLC. For more information see the Vijeo-Designer Lite online help, functions of the dialog table.  |
| message 254: PROTECTED ACCESS PAGE is displayed        | you are trying to access a page that is password protected but you do not have the required authorization level.  |
| messages 255 to 258 are displayed                      | the commands you entered at the terminal are executed or not executed, as indicated in these status messages.   |

**Diagnosis  
Counters**

3 diagnosis counters can be displayed on the protocol's system page (line parameters):

| <b>Counter</b> | <b>Meaning</b>                                     |
|----------------|--|
| 1              | number of responses received without any FCS error |
| 2              | number of responses received with any FCS error    |
| 3              | number of requests that have not been answered     |

**Note:** The counters no. 4...8 are not used and remain at 0.

---



---

# Appendices



---

## At a Glance

### Overview

This chapter contains some RS232 recommendations.

### What's in this Appendix?


The appendix contains the following chapters:

| Chapter | Chapter Name          | Page |
|---------|-----------------------|------|
| A       | RS232 Recommendations | 27   |



---

## RS232 Recommendations




---

### RS232 Recommendations

#### Diagrams for RS232C Link

RS232C link




- Maximum length for the link is 15 m (49.2 ft.).
- Wiring = 3 shielded wires with a minimum cross-section of 0.6 mm<sup>2</sup> (AWG22)

**Note:** The maximum length including the RS232 link is 15 m (49.21 ft.), provided that the equipment connected to the XBT terminal is not subject to more stringent restrictions (refer to connected devices instruction sheet) and for XBT RT500 provided that the length of the cable is below 10 m (32.8 ft.) (because power is also supplied by this cable).



---

# Glossary



---

## A

**AWG** American wire gauge (wire diameter)

---

## F

**FCS** frame check sequence

---

## M

**Magelis** Generic commercial name of the range of Schneider HMI terminals.

---

## P

**PLC** programmable logic controller

---

**R**

- RS232**                      recommended standard for connecting serial devices = EIA/TIA 232
- RS422**                      recommended standard for connecting serial devices = EIA/TIA 422
- 

**V**


- Vijeo-Designer  
Lite**                      Configuration software for the low end Magelis range. It replaces the XBT-L1000 software.
- 

**X**

- XBT**                      Any HMI terminal (when it is not necessary to make a distinction).
-

---

# Index



---

## C

- cables
  - Mitsubishi FX, 19
- communication principle
  - master / slave, 13
- communications
  - Mitsubishi FX PLCs, 14
- compatibility
  - Mitsubishi FX protocol, 9

## D

- data types
  - Mitsubishi FX, 17
- diagnostics
  - Mitsubishi FX, 21

## M

- master / slave communication principle, 13
- Mitsubishi FX
  - cables, 19
  - data types, 17
  - diagnostics, 21
- Mitsubishi FX PLCs
  - communications, 14
- Mitsubishi FX protocol
  - compatibility, 9
  - operating principles, 12

## O

- objects
  - Mitsubishi FX, 17
- operating principles
  - Mitsubishi FX protocol, 12

## R

- RS232
  - recommendations, 27

## V

- variable types
  - Mitsubishi FX, 17
  - Vijeo-Designer Lite, 15

