

PacDrive Logic Motion Controller


LMC Pro/Pro2 Hardware Guide

(Original Document)

04/2018

EIO0000001503.04

www.schneider-electric.com

Schneider
 **Electric**

The information provided in this documentation contains general descriptions and/or technical characteristics of the performance of the products contained herein. This documentation is not intended as a substitute for and is not to be used for determining suitability or reliability of these products for specific user applications. It is the duty of any such user or integrator to perform the appropriate and complete risk analysis, evaluation and testing of the products with respect to the relevant specific application or use thereof. Neither Schneider Electric nor any of its affiliates or subsidiaries shall be responsible or liable for misuse of the information contained herein. If you have any suggestions for improvements or amendments or have found errors in this publication, please notify us.

You agree not to reproduce, other than for your own personal, noncommercial use, all or part of this document on any medium whatsoever without permission of Schneider Electric, given in writing. You also agree not to establish any hypertext links to this document or its content. Schneider Electric does not grant any right or license for the personal and noncommercial use of the document or its content, except for a non-exclusive license to consult it on an "as is" basis, at your own risk. All other rights are reserved.

All pertinent state, regional, and local safety regulations must be observed when installing and using this product. For reasons of safety and to help ensure compliance with documented system data, only the manufacturer should perform repairs to components.

When devices are used for applications with technical safety requirements, the relevant instructions must be followed.

Failure to use Schneider Electric software or approved software with our hardware products may result in injury, harm, or improper operating results.

Failure to observe this information can result in injury or equipment damage.

© 2018 Schneider Electric. All Rights Reserved.

Table of Contents



	Safety Information	7
	About the Book	11
Chapter 1	Specific Safety Information	15
	Product Related Information	16
	Proper Use	20
Chapter 2	System Overview	23
	System Overview	24
	Logic Motion Controller	25
	Lexium 62 Drive System	26
	Lexium 52	30
	Lexium 62	31
	Lexium SH3 Servo Motor	32
	Type Code	33
	Nameplate Descriptions	34
Chapter 3	Planning	35
3.1	Electromagnetic Compatibility, EMC	36
	Electromagnetic Compatibility, EMC	36
3.2	Control Cabinet Planning	40
	Degree of Protection (IP)	41
	Mechanical and Climatic Environmental Conditions in the Control Cabinet	42
	Using Cooling Units	43
3.3	Information about Wiring	45
	General Information about Wiring	46
	Cable Characteristics	47
	Configuring and Coding the Cables	48
	ESD Protection Measures	49
Chapter 4	Installation and Maintenance	51
4.1	Commissioning	52
	Prerequisites for Commissioning	53
	Preparing Commissioning	54
	Preparing the Control Cabinet	56
	Mechanical Mounting	59
	Wiring	60
	Completion of Commissioning	63

4.2	Maintenance, Repair, Cleaning, Replacement Equipment Inventory	64
	Prerequisites for Maintenance, Repair, and Cleaning	65
	Battery Compartment	67
	Maintenance - Uninterruptible Power Supply	69
	Machine Repair	69
	Cleaning	70
	Replacement Equipment Inventory	70
4.3	Replacing Components and Cables	71
	Prerequisites for Replacing Components and Cables	72
	Device Replacement	74
	Fast Device Replacement (FDR) - Introduction	76
	Fast Device Replacement - Usage	77
	Fast Device Replacement - Controller Display	79
	Fast Device Replacement - Application	82
	Cable Replacement	87
Chapter 5	Indicators and Control Elements	89
	Indicators of the Controller	90
	Menu Navigation	97
	CompactFlash Card Slot	101
	Buttons	102
Chapter 6	Integrated Communication Ports	103
	Electrical Connections Overview	104
	Connection Details Controller	106
Chapter 7	Technical Data	121
	Ambient Conditions	122
	Standards and Regulations	125
	Mechanical and Electrical Data	126
	Dimensions	131
Chapter 8	Uninterruptible Power Supply UPS	133
	Retrofitting Installation of UPS	133
Chapter 9	Optional Modules	137
9.1	Communication Module OM-NE	138
	Overview	139
	Initial Installation of the Optional Module	140
	Removal of the Optional Module (No Replacement)	142
	Replacement of the Optional Module	143
	Electrical Connections	144

9.2	Communication Module OM-P	147
	Overview	148
	Initial Installation of the Optional Module	149
	Removal of the Optional Module (No Replacement)	151
	Replacement of the Optional Module	152
	Electrical Connections	153
9.3	Communication Module OM-C	154
	Overview	155
	Initial Installation of the Optional Module	156
	Removal of the Optional Module (No Replacement)	158
	Replacement of the Optional Module	159
	Electrical Connections	160
Appendices	161
Appendix A	Further Information on the Manufacturer	163
	Contact Addresses	164
	Product Training Courses	164
Appendix B	Disposal	165
	Disposal	165
Appendix C	Units and Conversion Tables	167
	Units and Conversion Tables	167
Index	171

Safety Information



Important Information

NOTICE

Read these instructions carefully, and look at the equipment to become familiar with the device before trying to install, operate, service, or maintain it. The following special messages may appear throughout this documentation or on the equipment to warn of potential hazards or to call attention to information that clarifies or simplifies a procedure.



The addition of this symbol to a “Danger” or “Warning” safety label indicates that an electrical hazard exists which will result in personal injury if the instructions are not followed.



This is the safety alert symbol. It is used to alert you to potential personal injury hazards. Obey all safety messages that follow this symbol to avoid possible injury or death.

DANGER

DANGER indicates a hazardous situation which, if not avoided, **will result in death** or serious injury.

WARNING

WARNING indicates a hazardous situation which, if not avoided, **could result in death** or serious injury.

CAUTION

CAUTION indicates a hazardous situation which, if not avoided, **could result** in minor or moderate injury.

NOTICE

NOTICE is used to address practices not related to physical injury.

PLEASE NOTE

Electrical equipment should be installed, operated, serviced, and maintained only by qualified personnel. No responsibility is assumed by Schneider Electric for any consequences arising out of the use of this material.

A qualified person is one who has skills and knowledge related to the construction and operation of electrical equipment and its installation, and has received safety training to recognize and avoid the hazards involved.

QUALIFICATION OF PERSONNEL

Only appropriately trained persons who are familiar with and understand the contents of this manual and all other pertinent product documentation are authorized to work on and with this product.

The qualified person must be able to detect possible hazards that may arise from parameterization, modifying parameter values and generally from mechanical, electrical, or electronic equipment. The qualified person must be familiar with the standards, provisions, and regulations for the prevention of industrial accidents, which they must observe when designing and implementing the system.

INTENDED USE

The products described or affected by this document, together with software, accessories, and options, are programmable logic controllers (referred to herein as “logic controllers”), intended for industrial use according to the instructions, directions, examples, and safety information contained in the present document and other supporting documentation.

The product may only be used in compliance with all applicable safety regulations and directives, the specified requirements, and the technical data.

Prior to using the product, you must perform a risk assessment in view of the planned application. Based on the results, the appropriate safety-related measures must be implemented.

Since the product is used as a component in an overall machine or process, you must ensure the safety of persons by means of the design of this overall system.

Operate the product only with the specified cables and accessories. Use only genuine accessories and spare parts.

Any use other than the use explicitly permitted is prohibited and can result in unanticipated hazards.

BEFORE YOU BEGIN

Do not use this product on machinery lacking effective point-of-operation guarding. Lack of effective point-of-operation guarding on a machine can result in serious injury to the operator of that machine.

WARNING

UNGUARDED EQUIPMENT

- Do not use this software and related automation equipment on equipment which does not have point-of-operation protection.
- Do not reach into machinery during operation.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

This automation equipment and related software is used to control a variety of industrial processes. The type or model of automation equipment suitable for each application will vary depending on factors such as the control function required, degree of protection required, production methods, unusual conditions, government regulations, etc. In some applications, more than one processor may be required, as when backup redundancy is needed.

Only you, the user, machine builder or system integrator can be aware of all the conditions and factors present during setup, operation, and maintenance of the machine and, therefore, can determine the automation equipment and the related safeties and interlocks which can be properly used. When selecting automation and control equipment and related software for a particular application, you should refer to the applicable local and national standards and regulations. The National Safety Council's Accident Prevention Manual (nationally recognized in the United States of America) also provides much useful information.

In some applications, such as packaging machinery, additional operator protection such as point-of-operation guarding must be provided. This is necessary if the operator's hands and other parts of the body are free to enter the pinch points or other hazardous areas and serious injury can occur. Software products alone cannot protect an operator from injury. For this reason the software cannot be substituted for or take the place of point-of-operation protection.

Ensure that appropriate safeties and mechanical/electrical interlocks related to point-of-operation protection have been installed and are operational before placing the equipment into service. All interlocks and safeties related to point-of-operation protection must be coordinated with the related automation equipment and software programming.

NOTE: Coordination of safeties and mechanical/electrical interlocks for point-of-operation protection is outside the scope of the Function Block Library, System User Guide, or other implementation referenced in this documentation.

START-UP AND TEST

Before using electrical control and automation equipment for regular operation after installation, the system should be given a start-up test by qualified personnel to verify correct operation of the equipment. It is important that arrangements for such a check be made and that enough time is allowed to perform complete and satisfactory testing.

WARNING

EQUIPMENT OPERATION HAZARD

- Verify that all installation and set up procedures have been completed.
- Before operational tests are performed, remove all blocks or other temporary holding means used for shipment from all component devices.
- Remove tools, meters, and debris from equipment.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Follow all start-up tests recommended in the equipment documentation. Store all equipment documentation for future references.

Software testing must be done in both simulated and real environments.

Verify that the completed system is free from all short circuits and temporary grounds that are not installed according to local regulations (according to the National Electrical Code in the U.S.A, for instance). If high-potential voltage testing is necessary, follow recommendations in equipment documentation to prevent accidental equipment damage.

Before energizing equipment:

- Remove tools, meters, and debris from equipment.
- Close the equipment enclosure door.
- Remove all temporary grounds from incoming power lines.
- Perform all start-up tests recommended by the manufacturer.

OPERATION AND ADJUSTMENTS

The following precautions are from the NEMA Standards Publication ICS 7.1-1995 (English version prevails):

- Regardless of the care exercised in the design and manufacture of equipment or in the selection and ratings of components, there are hazards that can be encountered if such equipment is improperly operated.
- It is sometimes possible to misadjust the equipment and thus produce unsatisfactory or unsafe operation. Always use the manufacturer's instructions as a guide for functional adjustments. Personnel who have access to these adjustments should be familiar with the equipment manufacturer's instructions and the machinery used with the electrical equipment.
- Only those operational adjustments actually required by the operator should be accessible to the operator. Access to other controls should be restricted to prevent unauthorized changes in operating characteristics.

About the Book



At a Glance

Document Scope

Read and understand the material contained in this manual before you work on the controller for the first time. Take particular note of the chapter Specific Safety Information (*see page 15*). Only those persons who meet the criteria described in Qualification of Personnel (*see page 8*) are allowed to work with the controller.

A copy of this manual must be available for personnel who work with the controller.

This manual is to help you use the capabilities of the controller safely and properly.

Follow the instructions within this manual to help:

- Reduce risks
- Reduce repair costs and downtime of the controller
- Increase the service life of the controller
- Increase reliability of the controller

Validity Note

This document has been updated for the release of SoMachine Motion V4.4 SP1.

The technical characteristics of the devices described in the present document also appear online. To access the information online:

Step	Action
1	Go to the Schneider Electric home page www.schneider-electric.com .
2	In the Search box type the reference of a product or the name of a product range. <ul style="list-style-type: none">● Do not include blank spaces in the reference or product range.● To get information on grouping similar modules, use asterisks (*).
3	If you entered a reference, go to the Product Datasheets search results and click on the reference that interests you. If you entered the name of a product range, go to the Product Ranges search results and click on the product range that interests you.
4	If more than one reference appears in the Products search results, click on the reference that interests you.
5	Depending on the size of your screen, you may need to scroll down to see the data sheet.
6	To save or print a data sheet as a .pdf file, click Download XXX product datasheet .

The characteristics that are presented in the present document should be the same as those characteristics that appear online. In line with our policy of constant improvement, we may revise content over time to improve clarity and accuracy. If you see a difference between the document and online information, use the online information as your reference.

For product compliance and environmental information (RoHS, REACH, PEP, EOLI, etc.), go to www.schneider-electric.com/green-premium.

Related Documents

Document title	Reference
Lexium 62 Hardware Guide	EIO0000001349 (ENG) ; EIO0000001350 (GER) ;
Lexium 52 Hardware Guide	EIO0000001347 (ENG) ; EIO0000001348 (GER) ;
Lexium 62 ILM Hardware Guide	EIO0000001351 (ENG) ; EIO0000001352 (GER) ;
SH3 Servo motor, Motor manual	0198441113987 (ENG) 0198441113988 (FRE) 0198441113986 (GER) 0198441113990 (SPA) 0198441113989 (ITA) 0198441113991 (CHS)

You can download these technical publications and other technical information from our website at www.schneider-electric.com/en/download.

Terminology Derived from Standards

The technical terms, terminology, symbols and the corresponding descriptions in this manual, or that appear in or on the products themselves, are generally derived from the terms or definitions of international standards.

In the area of functional safety systems, drives and general automation, this may include, but is not limited to, terms such as *safety*, *safety function*, *safe state*, *fault*, *fault reset*, *malfunction*, *failure*, *error*, *error message*, *dangerous*, etc.

Among others, these standards include:

Standard	Description
EN 61131-2:2007	Programmable controllers, part 2: Equipment requirements and tests.
ISO 13849-1:2008	Safety of machinery: Safety related parts of control systems. General principles for design.
EN 61496-1:2013	Safety of machinery: Electro-sensitive protective equipment. Part 1: General requirements and tests.

Standard	Description
ISO 12100:2010	Safety of machinery - General principles for design - Risk assessment and risk reduction
EN 60204-1:2006	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
EN 1088:2008 ISO 14119:2013	Safety of machinery - Interlocking devices associated with guards - Principles for design and selection
ISO 13850:2006	Safety of machinery - Emergency stop - Principles for design
EN/IEC 62061:2005	Safety of machinery - Functional safety of safety-related electrical, electronic, and electronic programmable control systems
IEC 61508-1:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems: General requirements.
IEC 61508-2:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems: Requirements for electrical/electronic/programmable electronic safety-related systems.
IEC 61508-3:2010	Functional safety of electrical/electronic/programmable electronic safety-related systems: Software requirements.
IEC 61784-3:2008	Digital data communication for measurement and control: Functional safety field buses.
2006/42/EC	Machinery Directive
2014/30/EU	Electromagnetic Compatibility Directive
2014/35/EU	Low Voltage Directive

In addition, terms used in the present document may tangentially be used as they are derived from other standards such as:

Standard	Description
IEC 60034 series	Rotating electrical machines
IEC 61800 series	Adjustable speed electrical power drive systems
IEC 61158 series	Digital data communications for measurement and control – Fieldbus for use in industrial control systems

Finally, the term *zone of operation* may be used in conjunction with the description of specific hazards, and is defined as it is for a *hazard zone* or *danger zone* in the *Machinery Directive (2006/42/EC)* and *ISO 12100:2010*.

NOTE: The aforementioned standards may or may not apply to the specific products cited in the present documentation. For more information concerning the individual standards applicable to the products described herein, see the characteristics tables for those product references.

Chapter 1

Specific Safety Information

Overview

This chapter contains important safety information regarding working with the controller. The controller conforms to recognized technical safety regulations.

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Product Related Information	16
Proper Use	20

Product Related Information

Overview

Health and safety risks arising from the controller have been reduced. However a residual risk remains, since the controller works with electrical voltage and electrical currents.

If activities involve residual risks, a safety message is made at the appropriate points. This includes potential hazard(s) that may arise, their possible consequences, and describes preventive measures to avoid the hazard(s).

Electrical Parts

DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables, or wires except under the specific conditions specified in the appropriate hardware guide for this equipment.
- Always use a properly rated voltage sensing device to confirm the power is off where and when indicated.
- Replace and secure all covers, accessories, hardware, cables, and wires and confirm that a proper ground connection exists before applying power to the unit.
- Use only the specified voltage when operating this equipment and any associated products.

Failure to follow these instructions will result in death or serious injury.

DANGER

ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Operate electrical components only with a connected protective ground (earth) cable.
- After the installation, verify the secure connection of the protective ground (earth) cable to all electrical devices to ensure that connection complies with the connection diagram.
- Before enabling the device, safely cover the live components to prevent contact.
- Do not touch the electrical connection points of the components when the module is energized.
- Provide protection against indirect contact (EN 50178).
- Connect and disconnect cables and terminals only after you have verified that the power has been removed from the system.

Failure to follow these instructions will result in death or serious injury.

Assembly and Handling

This product has a leakage (touch) current greater than 3.5 mA. If the protective ground connection is interrupted, a hazardous leakage (touch) current may flow if the housing is touched.

DANGER

INSUFFICIENT GROUNDING

- Use a protective ground conductor with at least 10 mm² (AWG 6) or two protective ground conductors with the same or larger cross section of the conductors supplying the power terminals.
- Verify compliance with all local and national electrical code requirements as well as all other applicable regulations with respect to grounding of all equipment.

Failure to follow these instructions will result in death or serious injury.

WARNING

CRUSHING, SHEARING, CUTTING AND HITTING DURING HANDLING

- Observe the general construction and safety regulations for handling and assembly.
- Use appropriate mounting and transport equipment and use appropriate tools.
- Prevent clamping and crushing by taking appropriate precautions.
- Cover edges and angles to protect against cutting damage.
- Wear appropriate protective clothing (for example, protective goggles, protective boots, protective gloves).

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Hazardous Movements

There can be different sources of hazardous movements:

- No, or incorrect, homing of the drive
- Wiring or cabling errors
- Errors in the application program
- Component errors
- Error in the measured value and signal transmitter

NOTE: Provide for personal safety by primary equipment monitoring or measures. Do not rely only on the internal monitoring of the drive components. Adapt the monitoring or other arrangements and measures to the specific conditions of the installation in accordance with a risk and error analysis.

DANGER

UNAVAILABLE OR INADEQUATE PROTECTION DEVICE(S)

- Prevent entry to a zone of operation with, for example, protective fencing, mesh guards, protective coverings, or light barriers.
- Dimension the protective devices properly and do not remove them.
- Do not make any modifications that can degrade, incapacitate, or in any way invalidate protection devices.
- Before accessing the drives or entering the zone of operation, bring the drives and the motors they control to a stop.
- Protect existing workstations and operating terminals against unauthorized operation.
- Position EMERGENCY STOP switches so that they are easily accessible and can be reached quickly.
- Validate the functionality of EMERGENCY STOP equipment before start-up and during maintenance periods.
- Prevent unintentional start-up by disconnecting the power connection of the drive using the EMERGENCY STOP circuit or using an appropriate lock-out tag-out sequence.
- Validate the system and installation before the initial start-up.
- Avoid operating high-frequency, remote control, and radio devices close to the system electronics and their feed lines, and perform, if necessary, an EMC validation of the system.

Failure to follow these instructions will result in death or serious injury.

Drive systems may perform unanticipated movements because of incorrect wiring, incorrect settings, incorrect data or other errors.

WARNING

UNINTENDED MOVEMENT OR MACHINE OPERATION

- Carefully install the wiring in accordance with the EMC requirements.
- Do not operate the product with undetermined settings and data.
- Perform comprehensive commissioning tests that include verification of configuration settings and data that determine position and movement.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

PELV Circuits

The signal voltage and the control voltage of the devices are less than 30 Vdc and have to be designed as PELV (Protective Extra Low Voltage) circuits. In this range, the specification as PELV system, according to IEC 61800-5-1 requires a protective measure against direct and indirect contact with hazardous voltage through an implemented separation in the system/machine of the primary and the secondary side. Separate high and low voltage wiring and respect the standard IEC 61800-5-1, Adjustable speed electrical power drive systems - safety requirements.

⚠ DANGER**ELECTRIC SHOCK BY INADEQUATE PROTECTIVE SEPARATION**

Only connect devices, electrical components, or lines to the signal voltage connectors of these products that feature a sufficient, protective separation from the connected circuits in accordance with the standards (IEC 61800-5-1: Adjustable speed electrical power drive systems - safety requirements).

Failure to follow these instructions will result in death or serious injury.

Cyber Security**⚠ WARNING****UNAUTHENTICATED ACCESS AND SUBSEQUENT UNAUTHORIZED MACHINE OPERATION**

- Evaluate whether your environment or your machines are connected to your critical infrastructure and, if so, take appropriate steps in terms of prevention, based on Defense-in-Depth, before connecting the automation system to any network.
- Limit the number of devices connected to a network to the minimum necessary.
- Isolate your industrial network from other networks inside your company.
- Protect any network against unintended access by using firewalls, VPN, or other, proven security measures.
- Monitor activities within your systems.
- Prevent subject devices from direct access or direct link by unauthorized parties or unauthenticated actions.
- Prepare a recovery plan including backup of your system and process information.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Proper Use

Installation

Install and operate this equipment in an enclosure appropriately rated for its intended environment and secured by a keyed or tooled locking mechanism..

Provide for Protective Measures

Before installing the device, provide for appropriate protective devices in compliance with local and national standards. Do not commission components without appropriate protective devices. After installation, commissioning, or repair, test the protective devices used.

Perform a risk evaluation concerning the specific use before operating the product and take appropriate security measures.

 WARNING
UNINTENDED EQUIPMENT OPERATION
Ensure that a risk assessment is conducted and respected according to EN/ISO 12100 during the design of your machine.
Failure to follow these instructions can result in death, serious injury, or equipment damage.

If circumstances occur that affect the safety or cause changes to the operating behavior of the controllers, then immediately shut down the controllers and contact your Schneider Electric representative.

Use Original Equipment Only

Use only the accessories and mounting parts specified in the documentation and no third-party devices or components that have not been expressly approved by Schneider Electric.

There are no user-serviceable parts within the PacDrive LMC Pro/Pro2 components besides the battery (*see page 67*) and the uninterruptible power supply battery pack (*see page 133*). Either replace the component or contact the Schneider Electric Customer Service (for contact addresses, refer to the Appendix (*see page 164*)).

 **WARNING****UNINTENDED EQUIPMENT OPERATION**

- Only use software and hardware components approved by Schneider Electric for use with this equipment.
- Do not attempt to service this equipment outside of authorized Schneider Electric service centers.
- Update your application program every time you change the physical hardware configuration.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Environment Restrictions

The components must not be used in the following environments:

- In hazardous (explosive) atmospheres
- In mobile, movable, or floating systems
- In life support systems
- In domestic appliances
- Underground

This equipment has been designed to operate outside of any hazardous location. Only install this equipment in zones known to be free of a hazardous atmosphere.

 **DANGER****POTENTIAL FOR EXPLOSION**

Install and use this equipment in non-hazardous locations only.

Failure to follow these instructions will result in death or serious injury.

Chapter 2

System Overview

What Is in This Chapter?

This chapter contains the following topics:


Topic	Page
System Overview	24
Logic Motion Controller	25
Lexium 62 Drive System	26
Lexium 52	30
Lexium 62	31
Lexium SH3 Servo Motor	32
Type Code	33
Nameplate Descriptions	34

System Overview

System Overview

The control system consists of several components, depending on its application.


PacDrive 3 system overview



* Safety Logic Controller according to IEC 61508:2010 and EN ISO 13849:2008

Logic Motion Controller

Overview

Product	Description
	<p>The PacDrive LMC (Logic Motion Controller), with a VxWorks real-time operating system, centrally implements the Logic Controller and motion functions. A PacDrive LMC synchronizes, coordinates, and creates the motion functions of a machine for a maximum of:</p> <ul style="list-style-type: none">● 0 Sercos servo drives for the controller PacDrive LMC100● 4 Sercos servo drives for the controller PacDrive LMC101● 6 Sercos servo drives for the controller PacDrive LMC106● 8 Sercos servo drives for the controller PacDrive LMC201● 12 Sercos servo drives for the controller PacDrive LMC212● 16 Sercos servo drives for the controller PacDrive LMC216● 8 Sercos servo drives for the controller PacDrive LMC300● 16 Sercos servo drives for the controller PacDrive LMC400● 16 Sercos servo drives for the controller PacDrive LMC402● 99 Sercos servo drives for the controller PacDrive LMC600● 130 Sercos servo drives for the controller PacDrive LMC802

Lexium 62 Drive System

Overview

The modular servo drive system Lexium 62 Drive System is designed for the operation of servo drives in a multi-axes system.

The power electronic components of the Lexium 62 Drive System are fitted inside the control cabinet.

Lexium 62 Power Supply



Using a common DC bus, the central power supply unit Lexium 62 Power Supply supplies the connected servo converters with the power required. The central Lexium 62 Power Supply, using a common DC bus, supplies the connected Lexium 62 Cabinet Drives with the power required.

Lexium 62 Connection Module



The Lexium 62 Connection Module supplies the Lexium 62 ILMs with DC voltage from the DC bus via a hybrid cable or via a power cable (daisy chain wiring). Additionally, the Lexium 62 Connection Module provides the Inverter Enable and Sercos interface.

The Lexium 62 Drive System helps simplify the wiring of the devices in relation to the initial start-up and in service cases. This also applies to the cable connection of the enclosed devices to the field. All the connectors that can be connected from the outside (power input, DC bus, 24 Vdc supply, Sercos, Ready, and Inverter Enable) are designed such, that a fast and simple configuration without tools can be realized on the device.

Lexium 62 Distribution Box



The Lexium 62 Distribution Box is the link between Lexium 62 Connection Module and Lexium 62 ILM. Depending on the number of drives, 1 to 4 Lexium 62 ILMs or daisy chain lines can be connected. When operating more than four drives, simply expand the system using one or more Lexium 62 Distribution Box.

The highlights:

- 1...4 connections for Lexium 62 ILMs or daisy chain lines or further Lexium 62 Distribution Box
- Easy wiring using pre-assembled hybrid cables or power cables (daisy chain wiring)
- Easy to expand

Lexium 62 ILM



The innovative Lexium 62 ILM combines motor, power stage, and digital servo controller for an axis in a space-saving housing. Due to its compact construction with the integrated controller, it is perfectly suitable for peripheral setup. It is available with individual or multi-turn encoders and configures itself with the aid of the electronic nameplate in the Lexium 62 ILM.

The Lexium 62 ILMs are available in three different flange sizes:

- ILM070
- ILM100
- ILM140

The highlights:

- Compact type of construction
- 3.5 times peak torque
- Integrated Sercos interface
- High-resolution single or multi-turn encoder
- Degree of protection IP65
- Simple wiring

ILM62DC•000 Daisy Chain Connector Box



ILM62DCA000



ILM62DCB000



ILM62DCC000

The ILM62DC•000 Daisy Chain Connector Box is mounted on a standard Lexium 62 ILM in order to enable a daisy chain wiring. The Lexium 62 ILMs can be either directly connected to the Lexium 62 Distribution Box or via a Lexium 62 Connection Module. When connecting via a Lexium 62 Distribution Box, a larger number of drives can be connected. At this first Lexium 62 Distribution Box another Lexium 62 Distribution Box can be connected.

Power (DC bus voltage/24V/Inverter Enable signals) and Sercos signals are distributed via separate cables. Each Lexium 62 ILM must be extended by a Daisy Chain Connector Box. If only one Lexium 62 Distribution Box is used, then up to four daisy chain lines can be connected to it. If several Lexium 62 Distribution Box are used, then on the first, up to the second to last Lexium 62 Distribution Box respectively up to three daisy chain lines can be connected and on the last Lexium 62 Distribution Box up to four daisy chain lines. A daisy chain line can consist of up to 9 Lexium 62 ILMs.

The connection between the Lexium 62 ILMs is established as follows:

- Power cable for power distribution (DC bus voltage/24 V/Inverter Enable signals) with an M23 connector
- Sercos cable for distribution of the Sercos signals via M12 connector

The following Lexium 62 ILMs can be equipped with the Daisy Chain Connector Box in order to implement a daisy chain wiring:


- ILM070**
- ILM100**
- ILM140**

The Daisy Chain Connector Box is available in the following variants:

- ILM62DCA000 (suitable for ILM070**, ILM100** and ILM140**)
- ILM62DCB000 (suitable for ILM070** only)
- ILM62DCC000 (suitable for ILM100** only)

Lexium 52

Overview



Product	Description
	<p>The stand-alone Lexium 52 Sercos servo amplifier is designed for servo drive solutions with independent single axes, or other applications involving asynchronous motors.</p> <p>The power electronic components of the Lexium 52 are fitted inside the control cabinet.</p> <p>The drive provides the phase currents required for the position control of the connected motors. According to the different requirements in relation to the individual servo axes of the application, the Lexium 52 is available in different current classes.</p> <p>The Lexium 52 helps simplify the wiring in relation to the initial start-up and service cases. This also applies to the cable connection of the enclosed devices to the field. All the connectors that can be connected from the outside (power input, DC bus, 24 Vdc supply, Sercos, motor, encoder, I/Os, I/O supply, Ready and Inverter Enable (STO)) are designed so that a fast, simple configuration on the device can be realized.</p>

Lexium 62

Overview


The modular servo drive system Lexium 62 is designed for the operation of servo drives in a multi-axis group.

The power electronic components of the Lexium 62 are fitted inside the control cabinet.

Product	Description
	<p>The central Lexium 62 Power Supply, using a common DC bus, supplies the connected Lexium 62 Cabinet Drives with the power required.</p>
	<p>The servo converters, Lexium 62 Cabinet Drives, provide the necessary phase currents for the position control of the connected servo motors. In addition, Lexium 62 Cabinet Drives are suitable for applications involving asynchronous motors.</p> <p>According to the different requirements in relation to the individual servo axes of the application, the Lexium 62 Cabinet Drives are available in different current classes.</p> <p>The Lexium 62 helps simplify the wiring of the devices. This also applies to the cable connection of the enclosed devices to the field. All the connectors that can be connected from the outside (power input, DC bus, 24 Vdc supply, Sercos, motor, encoder, I/Os, I/O supply, Ready and Inverter Enable) are designed so that a fast, simple configuration on the device can be realized.</p>

Lexium SH3 Servo Motor

Overview

Product	Description
	The servo motors meet rigorous requirements of dynamics and precision. Five flange sizes with different torque outputs offer the correct drive solution for your application.

High Dynamic AC Servo Motors

Because of the low inertia and a high overload capability, the motor Lexium SH3 fulfills the requirements concerning the accuracy, dynamics, and efficiency.

The Lexium SH3 motors are available in five different flange sizes:

- SH3-055
- SH3-070
- SH3-100
- SH3-140
- SH3-205


The highlights:

- Developed for high dynamics and precision
- Single tooth winding
- Compact size
- High-power density
- Low internal moment of inertia
- High overload capability
- Low detent torque

Type Code

Overview

The graphic shows the type code PacDrive LMC Pro/Pro2:



Family	Size			Type	Modules		HW	Internal	Internal	Internal
1	2	3	4	5	6	7	8	9	10	11
L	M	C	C	A	A	1	0	0	0	0

Family
LMC = Lexium Controller

Size
300 = max. 8 servo axes
400 = max. 16 servo axes
402 = max. 16 servo axes
600 = max. 99 servo axes
802 = max. 130 servo axes

Type
C = Controller based

Modules (not for LMC 101/201)

AA = None	CA = USV (Accu)
BB = CAN OM-C	CB = USV (Accu) + CAN OM-C
BC = Profibus DP OM-P	CC = USV (Accu) + Profibus DP OM-P
BD = RT-Ethernet OM-NE	CD = USV (Accu) + RT-Ethernet OM-NE
BG = 2x OM-NE	CG = USV (Accu) + 2xOM-NE
BI = 1x OM-C + 1x OM-NE	CI = USV (Accu) + 1x OM-C + 1x OM-NE
BL = 1x OM-P + 1x OM-NE	CL = USV (Accu) + 1x OM-C + 1x OM-NE

Hardware - Release

Nameplate Descriptions

Overview

The Logic Motion Controller (LMC) nameplate is located on the side of the housing:



Explanation of the technical nameplate entries:

Label	Description
LMC400Cxxxxx	Device type and Unicode
Input d.c	Digital inputs / input voltage and input current (per input)
Output d.c.	Digital outputs / output voltage and rated current (per input)
IP20	Degree of protection
CE (symbol)	CE mark

The logistical nameplate of the LMC is located on top of the housing.

Label	Description
LMC400CCABA00	Device type and Unicode
907156.0010	Serial number
RS:02	Hardware revision ⁽¹⁾
DOM	Date of manufacture
<p>(1) When replacing the controller (<i>see page 74</i>), the hardware revision for the previous and the new device should be identical to help avoid potential compatibility issues with the equipment. The hardware revision can also be read from the hardware code in the device (<i>see page 99</i>). For more information on the compatibility of different hardware revisions, contact your local Schneider Electric representative.</p>	

Chapter 3

Planning

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
3.1	Electromagnetic Compatibility, EMC	36
3.2	Control Cabinet Planning	40
3.3	Information about Wiring	45


Section 3.1

Electromagnetic Compatibility, EMC

Electromagnetic Compatibility, EMC

Electromagnetic Disturbances of Signals and Devices

This product meets the EMC requirements in accordance with the standard IEC 61131-2, provided that the EMC measures described in this manual are complied with during installation.


 **WARNING**

ELECTROMAGNETIC DISTURBANCES OF SIGNALS AND DEVICES

Use proper EMC shielding techniques to help prevent unintended device operation in accordance with the standard IEC 61131-2.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

These types of devices are not intended to be used on a low-voltage public network which supplies domestic premises. Radio frequency interference is expected if used in such a network.

 **WARNING**

RADIO INTERFERENCE

Do not use these products in domestic electrical networks.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Enclosure Layout

The prerequisite for compliance with the specified limit values is an EMC compatible layout. Depending on the application, the following measures can improve the EMC-dependent values:

EMC measures	Objective
Use galvanized or chromium-plated sub plates, bond metallic parts across large surface areas, remove paint layer from contact surfaces.	Good conductivity by surface area contact.
Ground enclosure, door, and sub plates by using grounding strips or grounding cables with a cross-section of 10 mm ² (AWG 6).	Reduce emission.

EMC measures	Objective
Supplement switch devices such as contactors, relays, or magnetic valves with interference suppression combinations or spark suppressor elements (for example, diodes, varistors, RC elements).	Reduces mutual interference.
Fit power and control components separately.	Reduces mutual interference.

Shielded Cables

EMC measures	Objective
Place cable shields on the surface, use cable clamps and grounding strips.	Reduce emission.
Ground shields of digital signal cables on both sides across large surface areas or through conducting connector housings.	Reduce interference action on signal cables, reduce emissions.
Ground shield of analog signal cables directly on the device (signal input), insulate the shield at the other cable end or ground the same through a capacitor, such as 10 nF.	Reduce grounding loops by low frequency interferences.

Cable Routing

EMC measures	Objective
Do not route fieldbus cables and signal cables together with cabling for direct and alternating voltages above 60 V in the same cable duct (fieldbus cables can be routed together with signal cables and analog cables in the same duct). Electromagnetic immunity will improve by routing cables in separated cable ducts with a distance of at least 20 cm (7.84 in).	Reduces mutual interference.
Keep the cables as short as possible. Do not install any unnecessary cable loops, short cable routing from a central grounding point in the control cabinet to the external grounding connection.	Reduce capacitive and inductive interference couplings.
Insert a potential equalization for: <ul style="list-style-type: none"> ● Large surface installation ● Different voltage infeeds ● Networking across buildings 	Reduce current on cable shield, reduce emissions.
Use fine wire potential equalization conductor.	Discharging of high frequency interference currents.

EMC measures	Objective
If motor and machine are not connected in a conducting fashion, for example, due to an insulated flange or a connection not across a full surface, the motor must be grounded via a grounding cable with a minimum 10 mm ² (AWG 6) cross-section or a grounding strip with a length as short as possible.	Reduce emissions, increase interference resistance.
Use twisted pair for 24 Vdc signals.	Reduce interference action on signal cables, reduce emissions.

Voltage Supply

EMC measures	Objective
Operate product on mains with a grounded neutral.	Enable the effect of the integrated mains filter.
Protection circuit if there is a risk of overvoltage.	Reduce risk of damage due to overvoltages.

Motor and Encoder Cables

From an EMC perspective, motor supply cables and encoder cables are particularly important. Only use pre-configured cables, or cables with the prescribed properties, and comply with the following EMC measures.

EMC measures	Objective
Do not install switching elements in motor cables or encoder cables.	Reduces interference.
Route motor cable with a distance of at least 20 cm (7.84 in) to the signal cables or insert shield plates between the motor supply cable and the signal cable.	Reduces mutual interference.
For cabling that approaches the maximum cable distance specification (75 m/ 246.06 ft.), use potential equalization cables.	Reduce current on cable shield.
Route motor supply cables and encoder cables without any separation point ⁽¹⁾ .	Reduces emission.
(1) If a cable must be cut through for installation purposes, the cables must be connected at the point of separation by using screen connections and metal housing.	

Additional Measures for Improving the EMC

Depending on the respective application, the following measures may lead to an EMC compatible layout:

EMC measures	Objective
Upstream connection of mains line reactor (choke)	Reduction of the harmonic network oscillations, extension of the service life of the product.
Upstream connection of external mains filters	Improvement of the EMC limit values.
Special EMC-appropriate layout, for example, within an enclosed control cabinet complete with 15 dB attenuation of the interferences emitted	Improvement of the EMC limit values.

Section 3.2

Control Cabinet Planning

What Is in This Section?

This section contains the following topics:

Topic	Page
Degree of Protection (IP)	41
Mechanical and Climatic Environmental Conditions in the Control Cabinet	42
Using Cooling Units	43

Degree of Protection (IP)

Overview

Install components such that a degree of protection corresponding to the actual operational environment is set up.

For more information on the degree of protection of the component, refer to Ambient Conditions (*see page 122*).

The following ambient conditions may damage the components:

- Oil
- Moisture
- Electromagnetic interference
- Ambient temperature
- Metal dust deposits

WARNING

UNINTENDED EQUIPMENT OPERATION

- Observe and conform to ambient temperatures, storage temperatures and transport temperatures of the individual components as specified in the operating manuals of the components.
- Prevent the formation of moisture during the operation, storage and transport of individual components.
- Conform to the vibration and shock requirements specified in the operating manuals for the components when operating, storing and transporting system components.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Mechanical and Climatic Environmental Conditions in the Control Cabinet

Overview

Step	Action
1	Observe the climatic and mechanical ambient conditions. For more information on the general climatic and mechanical environmental conditions according to IEC/EN 60721, refer to Ambient Conditions (<i>see page 122</i>).
2	Verify the technical data of the device whether the permitted deviations (for example, higher shock load or higher temperature) are specified.

Using Cooling Units

Installing a Cooling Unit

How to proceed when installing a cooling unit:

Step	Action
1	Position the cooling units so that no condensate drips out of the cooling unit onto electronic components or is sprayed by the cooling air flow.
2	Provide specially designed control cabinets for cooling units on the top of the control cabinet.
3	Design the control cabinet so that the cooling unit fan cannot spray any accumulated condensate onto the electronic components when it restarts after a pause.
4	When using cooling units, use only well-sealed control cabinets so that warm, humid outside air, which causes condensation, does not enter the cabinet.
5	When operating control cabinets with open doors during commissioning or maintenance, ensure that the electronic components are at no time cooler than the air in the control cabinet after the doors are shut, in order to avoid any condensation.
6	Continue to operate the cooling unit even when the system is switched off, so that the temperature of the air in the control cabinet and the air in the electronic components remains the same.
7	Set cooling unit to a fixed temperature of 40 °C (104 °F).
8	For cooling units with temperature monitoring, set the temperature limit to 40 °C (104 °F) so that the internal temperature of the control cabinet does not fall below the external air temperature.



WARNING

UNINTENDED EQUIPMENT OPERATION

Follow the installation instructions such that the condensation from the cooling unit can not enter electronic components.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Installing a cooling unit



Section 3.3

Information about Wiring

What Is in This Section?

This section contains the following topics:

Topic	Page
General Information about Wiring	46
Cable Characteristics	47
Configuring and Coding the Cables	48
ESD Protection Measures	49

General Information about Wiring

Overview

Use only Schneider Electric approved devices in your application, and especially Schneider Electric pre-fabricated cables wherever and whenever possible.

Use an appropriate torque indication or screwdriver for tightening connections.

For information on the tightening torques and cable cross-sections, refer to Integrated Communication Ports (*see page 103*).

Observe the following points when wiring:

1. Observe the minimum cross-sections of the cables necessary for the load carrying capacity of the equipment being connected.
2. Verify the integrity of cable shields to ensure continuity to ground.
3. Ensure that there is a proper connection to ground for all interconnected equipment.
4. Eliminate any ground loops.
5. Do not disconnect cable connections terminals when under power.
6. Ensure that all ground connections have sufficient surface area continuity.
7. Do not interchange encoder connections.
8. Do not interchange the EMERGENCY STOP circuits.

Example

If, for example, two parallel conductors are shown as coming from one point, you may not run just one conductor and then branch it off at a later point. If it is wired this way, induction loops (interference emitters and antennas) as well as interfering potential shifts may occur.

DANGER

INCORRECT OR UNAVAILABLE GROUNDING

Remove paint across a large surface at the installation points before installing the devices (bare metal connection).

Failure to follow these instructions will result in death or serious injury.

Cable Characteristics

Characteristics

Cable characteristics of the Sercos cable (see the Schneider Electric catalog for the various cables available):

Property	Value
Voltage isolation (jacket)	300 Vdc
Temperature range	-20... +60 °C / -4...+140 °F
Cable diameter	5.8 ± 0.2 mm (0.23 ± 0.008 in.)
Bending radius	8 x diameter (fixed routing)
Sheath	PVC, flame-retardant
Cable type and shielding	CAT6 with S/FTP (Sercos III)

Configuring and Coding the Cables

Overview

For configuring and coding the cables, use the appropriate connector kit supplied with the device.

Accessory part	Number	Connection designation
Connector control voltage / watchdog	2	CN1
Connector digital outputs	2	CN2
Connector digital inputs	2	CN3
Connector TP / fast digital inputs	2	CN4
Connector analog inputs / outputs	2	CN5
Sercos cable 130 mm (5.11 in)	1	CN12, CN13
PacNet terminating plug	1	CN9

ESD Protection Measures

General

Observe the following instructions to help avoid damages due to electrostatic discharge:

NOTICE

ELECTROSTATIC DISCHARGE

- Do not touch any of the electrical connections or components.
- Prevent electrostatic charges, for example, by wearing appropriate clothing.
- If you must touch circuit boards, do so only on the edges.
- Move the circuit boards as little as possible.
- Remove existing static charge by touching a grounded, metallic surface.

Failure to follow these instructions can result in equipment damage.

Chapter 4

Installation and Maintenance

General Information

Proceed with care during the following steps in order to help to avoid the following points:

- Injuries and material damage
- Incorrect installation and programming of components
- incorrect operation of components
- use of non-authorized cables or modified components

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
4.1	Commissioning	52
4.2	Maintenance, Repair, Cleaning, Replacement Equipment Inventory	64
4.3	Replacing Components and Cables	71

Section 4.1

Commissioning

What Is in This Section?

This section contains the following topics:

Topic	Page
Prerequisites for Commissioning	53
Preparing Commissioning	54
Preparing the Control Cabinet	56
Mechanical Mounting	59
Wiring	60
Completion of Commissioning	63

Prerequisites for Commissioning

Prerequisites

DANGER

HAZARD OF ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables, or wires except under the specific conditions specified in the appropriate hardware guide for this equipment.
- Always use a properly rated voltage sensing device to confirm the power is off where and when indicated.
- Replace and secure all covers, accessories, hardware, cables, and wires and confirm that a proper ground connection exists before applying power to the unit.
- Use only the specified voltage when operating this equipment and any associated products.

Failure to follow these instructions will result in death or serious injury.

DANGER

ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Operate electrical components only with a connected protective ground (earth) cable.
- After the installation, verify the secure connection of the protective ground (earth) cable to all electrical devices to ensure that connection complies with the connection diagram.
- Before enabling the device, safely cover the live components to prevent contact.
- Do not touch the electrical connection points of the components when the module is energized.
- Provide protection against indirect contact (EN 50178).
- Connect and disconnect cables and terminals only after you have verified that the power has been removed from the system.

Failure to follow these instructions will result in death or serious injury.

Preparing Commissioning

Prerequisite

Verify safety-related circuits for proper function, if applicable.

ESD Protection

Observe the following instructions to help avoid damages due to electrostatic discharge:

<i>NOTICE</i>	
ELECTROSTATIC DISCHARGE	
<ul style="list-style-type: none"> ● Do not touch any of the electrical connections or components. ● Prevent electrostatic charges, for example, by wearing appropriate clothing. ● If you must touch circuit boards, do so only on the edges. ● Move the circuit boards as little as possible. ● Remove existing static charge by touching a grounded, metallic surface. 	
Failure to follow these instructions can result in equipment damage.	

Unpacking

How to unpack the device:

Step	Action
1	Remove packaging
2	Dispose of the packaging material in accordance with the relevant local regulations.

Verifying

How to verify the device:

Step	Action
1	Verify that the delivery is complete on the basis of the delivery slip.
2	Closely inspect the device for any signs of damage.
3	Verify the data with the help of the nameplates.
4	Observe requirements for the installation location.
5	In addition to the following instructions, also note the information in the chapter Planning (<i>see page 35</i>).
6	If you intend to install optional modules, refer also to the information in the chapter Optional Modules (<i>see page 137</i>).
7	If you intend to install the UPS battery pack, refer also to the information in the chapter Uninterruptible Power Supply UPS (<i>see page 133</i>).

 **WARNING**

UNINTENDED EQUIPMENT OPERATION

- Do not mount or commission damaged drive systems.
- Do not modify the drive systems.
- Send back inoperative devices.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Preparing the Control Cabinet

Overview

DANGER

INCORRECT OR UNAVAILABLE GROUNDING


Remove paint across a large surface at the installation points before installing the devices (bare metal connection).

Failure to follow these instructions will result in death or serious injury.

Step	Action
1	If necessary to maintain and respect the maximum ambient operating temperature, install additional fan in the control cabinet.
2	Do not block the fan air inlet of the product.
3	Drill mounting holes in the control cabinet according to the mounting-grid pattern.
4	Keep a distance of at least 100 mm (3.94 in) above and below the products.

Assembly Distances, Ventilation


Assembly distances and air circulation:



Distance	Air circulation
$a \geq 100 \text{ mm (3.94 in)}$	Clearance above the device.
$b \geq 100 \text{ mm (3.94 in)}$	Clearance below the device.
$c \geq 60 \text{ mm (2.36 in)}$	Clearance in front of the device.
$d \geq 0 \text{ mm (0 in)}$	Clearance between the devices for ambient temperature during operation: +5...+55 °C (41...131 °F) without UPS +5...+40 °C (41...104 °F) with UPS

Required Distances

Required distances in the control cabinet for the PacDrive LMC Pro/Pro2, Lexium 62 Power Supply, Lexium 62 Cabinet Drive:



-	mm	in	Thread
(1)	100 (± 0.2)	3.94 (± 0.01)	M6
(2)	296 (+ 0.5 / -0)	11.65 (± 0.02 / -0)	M6
(3)	35 (± 0.2)	1.38 (± 0.01)	M6
(4)	90 (± 0.2)	3.54 (± 0.01)	M6
(5)	45 (± 0.2)	1.77 (± 0.01)	M6

NOTE: For the shield plates (external shield connections), additional holes are required.

Mechanical Mounting

Procedure


Step	Action
1	Screw the pan-head screws M6 (socket head cap screws) into the prepared mounting holes.
2	Keep a distance of 10 mm (0.39 in) between the screw head and the mounting plate.
3	Hook in device and verify the vertical mounting arrangement.
4	Tighten the mounting screws (torque: 4.6 Nm (41 lbf in)).

Wiring

How to Assemble the Modules

To assemble the modules, proceed as follows:

Step	Action
1	Connect the protective conductor with the ring cable lug and the M5 screw to the shield connection of the controller (tightening torque: 1 Nm (8.85 lbf in))
2	Follow the assembly based on the shield connection: <ul style="list-style-type: none"> ● lock washer ● ring cable lug ● lock washer ● washer ● screw
3	Connect the plug-in connector CN1 "24 V supply" to the controller. For important safety information, follow the instructions in the second safety message after this table.
4	Connect the Sercos cable CN12 (CN13) to the power supply

Step	Action
5	<p>Insert the other end of the Sercos cable to CN2 (CN3) into the Lexium 62 Power Supply or Lexium 62 Cabinet Drive.</p> <p>NOTE: Depending on the device combination choose the appropriate Sercos cable length.</p> <p>NOTE: If possible, establish a Sercos connection via the ring topology (2).</p> <p>NOTE: If Sercos devices are assigned via the topological addresses (IdentificationMode = TopologyAddress) to the PacDrive LMC Pro/Pro2, then consider the following:</p> <ul style="list-style-type: none"> ● Connect your Sercos device to the PacDrive LMC Pro/Pro2 either completely via Sercos port 1 (CN12) in line topology or in ring topology using Sercos port 1 and 2 (CN12/CN13). ● Do not connect the Sercos devices to the PacDrive LMC Pro/Pro2 via double line topology (CN12/CN13). ● Do not connect the Sercos devices to the PacDrive LMC Pro/Pro2 only via Sercos port 2 (CN13). <p>Line topology and ring topology</p>  <p>1 Line topology 2 Ring topology</p>
6	Optionally, connect the plug-in connector CN2 / CN3 "Digital I/Os" to the controller.
7	Optionally, connect the plug-in connector CN4 "TP / fast digital inputs" to the controller
8	Optionally, connect the plug-in connector CN5 "Analog I/Os" to the controller.
9	Optionally, connect a Ethernet cable to CN8 "Ethernet connection" of the controller.
10	Optionally, connect a PacNet cable to CN9 "PacNet" of the PacDrive LMC Pro/Pro2. Provide an unused connection CN9 with a PacNet terminating plug.
11	Optionally, connect a RT-Ethernet cable to CN10 (CN11) "RT Ethernet port1 (port2)" of the controller.
12	Optionally, connect serial interface cable to CN15 "COM1 (RS-232)" of the controller.

Step	Action
13	Optionally, connect serial interface cable to CN16 "COM2 (RS-485)" of the controller.
14	Optionally, connect CAN bus cable to CN17 "CAN" of the controller.
15	Optionally, connect PROFIBUS DP bus cable to CN18 "PROFIBUS" of the controller.
16	Optionally, if optional modules are available then insert the respective cables with the corresponding connections of the optional modules.

⚠ DANGER

ELECTRIC SHOCK CAUSED BY HIGH LEAKAGE (TOUCH) VOLTAGE

- Attach the shock protector covers on the extremities of the Bus Bar Module combination (*see page 59*).
- Apply power to the device only if the shock protector covers have been attached to the extremities of the Bus Bar Module combination.

Failure to follow these instructions will result in death or serious injury.

⚠ DANGER

INSUFFICIENT GROUNDING

- Use a protective ground conductor with at least 10 mm² (AWG 6) or two protective ground conductors with the same or larger cross section of the conductors supplying the power terminals.
- Verify compliance with all local and national electrical code requirements as well as all other applicable regulations with respect to grounding of all equipment.

Failure to follow these instructions will result in death or serious injury.

Completion of Commissioning

Transferring the Configuration and the Program

For information on how to transfer the project to the PacDrive controller, refer to the *SoMachine Motion Online Help*.

Adjust Real-Time Clock

The real-time clock is not adjusted at the time of delivery of the device. Summer and winter time is not considered by the device. If the real-time clock is not adjusted, the time and date specifications in the message logger will not be correct. Make certain that the real-time clock is adjusted correctly.

Minimal Boot of the Controller

NOTE: If a serious boot error occurs as a result of an application error, the user can perform a minimal boot. During the minimal boot, the application is not loaded.

Performing a minimal boot of the controller manually:

Step	Action	Result
1	Restart the controller by pressing the reset button or on- / off- button.	The controller starts and the Error indicator lights up.
2	Press the reset button again while the preset IP address is displayed.	After the boot, the controller will flash quickly (10 Hz), signaling a minimal boot.

Conditions triggering an automatic minimal boot

The controller automatically performs a minimal boot if the following conditions apply:

- A voltage interruption of the control voltage occurs when starting the controller while the **Error** indicator is illuminated.
- A reset of the controller is triggered.
- A serious error is detected (memory recall cannot be performed).

Section 4.2

Maintenance, Repair, Cleaning, Replacement Equipment Inventory

What Is in This Section?

This section contains the following topics:

Topic	Page
Prerequisites for Maintenance, Repair, and Cleaning	65
Battery Compartment	67
Maintenance - Uninterruptible Power Supply	69
Machine Repair	69
Cleaning	70
Replacement Equipment Inventory	70

Prerequisites for Maintenance, Repair, and Cleaning

Introduction

Observe the following instructions before carrying out maintenance on the controller.

De-Energize the System

DANGER

ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables, or wires.
- Place a "Do Not Turn On" or equivalent hazard label on all power switches and lock them in the non-energized position.
- Wait 15 minutes to allow the residual energy of the DC bus capacitors to discharge.
- Measure the voltage on the DC bus with a properly rated voltage sensing device and verify that the voltage is less than 42.4 Vdc.
- Do not assume that the DC bus is voltage-free when the DC bus LED is off.
- Block the motor shaft to prevent rotation prior to performing any type of work on the drive system.
- Do not create a short-circuit across the DC bus terminals or the DC bus capacitors.
- Replace and secure all covers, accessories, hardware, cables, and wires and confirm that a proper ground connection exists before applying power to the unit.
- Use only the specified voltage when operating this equipment and any associated products.

Failure to follow these instructions will result in death or serious injury.

How to de-energize the system:

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	In the case of any drives, servos or other equipment with high capacity capacitors, wait at least 15 minutes after removing power (switching off) to allow the DC bus capacitors to discharge.
4	Verify whether the DC-BUS LED indicator has turned off on all components located in the axis group.
5	Verify with an appropriate measuring instrument that the voltages between DC+ to PE (Protective Earth/ground), DC- to PE and DC+ to DC- are all less than 42.4 Vdc.

 **DANGER**

ELECTRIC SHOCK, EXPLOSION OR ARC FLASH


Verify with a correctly calibrated measuring instrument that the DC bus is de-energized (less than 42.4 Vdc) before replacing, maintaining or cleaning machine components.

Failure to follow these instructions will result in death or serious injury.

For more information on the DC Bus LED indicator, refer to *Bus Bar Module LED Indicators on the Lexium 62 Power Supply and Lexium 62 Cabinet Drive (see Lexium 62, Hardware Guide)*.

Battery Compartment

Overview



- 1 CompactFlash card slot
- 2 Battery compartment

The battery compartment is located under the operating cover of the controller. The controller battery buffers controller data (BIOS cmos, NVRAM, RTC).

Maintenance Interval

The maintenance interval for replacing the battery is 5 years. After this period of time, the battery must be replaced. If the device (with battery installed) is not used for an extended period of time, you should verify/replace the battery.

Measuring the Battery

To measure the battery, proceed as follows:

Step	Action
1	Remove battery and then make the manual measurement.
2	Or observe the diagnostic message 037 Battery low in the IEC program and display it on an HMI (panel), if necessary.
3	Replace battery three days after the first diagnostic message at the latest.

Replacing the Battery

While lithium batteries are preferred due to their slow discharge and long life, they can present hazards to personnel, equipment and the environment and must be handled properly.

⚠ DANGER

EXPLOSION, FIRE, OR CHEMICAL BURNS

- Replace with identical battery type.
- Follow all the instructions of the battery manufacturer.
- Remove all replaceable batteries before discarding unit.
- Recycle or properly dispose of used batteries.
- Protect battery from any potential short-circuit.
- Do not recharge, disassemble, heat above 100 °C (212 °F), or incinerate.
- Use your hands or insulated tools to remove or replace the battery.
- Maintain proper polarity when inserting and connecting a new battery.

Failure to follow these instructions will result in death or serious injury.

Step	Action
1	You can change the battery while the controller is on or off. There is no loss of data when it is performed with the controller on. When the controller is switched off, the time period of the data buffering without a battery is approximately 30 seconds.
2	Use pliers with insulated tips to lightly pull the battery out of its slot.
3	Carefully place the battery on the guide and lightly push it into the device.

NOTE: Replacement of the battery in the controllers other than with the type specified in this documentation may present a risk of fire or explosion.

⚠ WARNING

IMPROPER BATTERY CAN PROVOKE FIRE OR EXPLOSION

Replace battery only with identical type: 3 V Lithium Renata Type CR2450N.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Maintenance - Uninterruptible Power Supply

Overview

The maintenance interval for replacing the battery pack is 3 years. For more information, refer to Uninterruptible Power Supply - UPS (*see page 133*).

Machine Repair

Presentation

When replacing controllers, be sure to observe the important safety information in the sections of the present document concerning mounting and dismantling components.

With exception of batteries, there are no other user-serviceable parts within the controllers. Either replace the controller or contact Schneider Electric (*see page 164*).

WARNING

UNINTENDED EQUIPMENT OPERATION

- Only use software and hardware components approved by Schneider Electric for use with this equipment.
- Do not attempt to service this equipment outside of authorized Schneider Electric service centers.
- Update your application program every time you change the physical hardware configuration.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Use only the accessories and mounting parts specified in the documentation and no third-party devices or components that have not been expressly approved by Schneider Electric. Do not modify the equipment.

In case machine repair includes the replacement of the drive components, observe the following instructions for ESD protection in order to avoid any damage due to electrostatic discharge:

NOTICE

ELECTROSTATIC DISCHARGE

- Do not touch any of the electrical connections or components.
- Prevent electrostatic charges, for example, by wearing appropriate clothing.
- If you must touch circuit boards, do so only on the edges.
- Move the circuit boards as little as possible.
- Remove existing static charge by touching a grounded, metallic surface.

Failure to follow these instructions can result in equipment damage.

Cleaning

To Clean the Controller

Care must be taken with cleaning products as some active agents may have deleterious effects on plastics and stainless steel welds.

NOTICE

CORROSION CAUSED BY CLEANING AGENTS

- Before using a cleaning agent, carry out a compatibility test in relation to the cleaning agent and the component affected.
- Do not use alkaline detergent.
- Do not use any chlorid-containing cleaning agents.

Failure to follow these instructions can result in equipment damage.

For more information on the material properties of your component, refer to Mechanical and Electrical Data (*see page 126*).

Replacement Equipment Inventory

Presentation

Keep a stock of the most important components to make certain your machine is functioning and ready for operation.

Replace devices with the same hardware configuration to help ensure compatibility.

Indicate the following information on the replacement equipment order:

- Unicode: for example, **LMC400CAABA00**
- Hardware revision: for example, **RS:02**

This information can be found on the logistic nameplate (*see page 34*).

For more information concerning the replacement of components, refer to Replacing Components and Cables (*see page 71*).

Section 4.3

Replacing Components and Cables


What Is in This Section?

This section contains the following topics:

Topic	Page
Prerequisites for Replacing Components and Cables	72
Device Replacement	74
Fast Device Replacement (FDR) - Introduction	76
Fast Device Replacement - Usage	77
Fast Device Replacement - Controller Display	79
Fast Device Replacement - Application	82
Cable Replacement	87

Prerequisites for Replacing Components and Cables

De-Energize the System

 **DANGER**

ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables, or wires.
- Place a "Do Not Turn On" or equivalent hazard label on all power switches and lock them in the non-energized position.
- Wait 15 minutes to allow the residual energy of the DC bus capacitors to discharge.
- Measure the voltage on the DC bus with a properly rated voltage sensing device and verify that the voltage is less than 42.4 Vdc.
- Do not assume that the DC bus is voltage-free when the DC bus LED is off.
- Block the motor shaft to prevent rotation prior to performing any type of work on the drive system.
- Do not create a short-circuit across the DC bus terminals or the DC bus capacitors.
- Replace and secure all covers, accessories, hardware, cables, and wires and confirm that a proper ground connection exists before applying power to the unit.
- Use only the specified voltage when operating this equipment and any associated products.

Failure to follow these instructions will result in death or serious injury.

How to de-energize the system:

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	In the case of any drives, servos or other equipment with high capacity capacitors, wait at least 15 minutes after removing power (switching off) to allow the DC bus capacitors to discharge.
4	Verify whether the DC-BUS LED indicator has turned off on all components located in the axis group.
5	Verify with an appropriate measuring instrument that the voltages between DC+ to PE (Protective Earth/ground), DC- to PE and DC+ to DC- are all less than 42.4 Vdc.

⚠ DANGER**ELECTRIC SHOCK, EXPLOSION OR ARC FLASH**

Verify with a correctly calibrated measuring instrument that the DC bus is de-energized (less than 42.4 Vdc) before replacing, maintaining or cleaning machine components.

Failure to follow these instructions will result in death or serious injury.

For more information on the DC Bus LED indicator, refer to *Bus Bar Module LED Indicators on the Lexium 62 Power Supply and Lexium 62 Cabinet Drive (see Lexium 62, Hardware Guide)*.

Other Prerequisites**⚠ DANGER****ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH**

- Operate electrical components only with a connected protective ground (earth) cable.
- After the installation, verify the secure connection of the protective ground (earth) cable to all electrical devices to ensure that connection complies with the connection diagram.
- Before enabling the device, safely cover the live components to prevent contact.
- Do not touch the electrical connection points of the components when the module is energized.
- Provide protection against indirect contact (EN 50178).
- Connect and disconnect cables and terminals only after you have verified that the power has been removed from the system.

Failure to follow these instructions will result in death or serious injury.

With exception of batteries, there are no other user-serviceable parts within the controllers. Either replace the component or contact Schneider Electric (*see page 164*).

⚠ WARNING**UNINTENDED EQUIPMENT OPERATION**

- Only use software and hardware components approved by Schneider Electric for use with this equipment.
- Do not attempt to service this equipment outside of authorized Schneider Electric service centers.
- Update your application program every time you change the physical hardware configuration.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Device Replacement

How to Replace the Controller

Before beginning the replacement of specific components, read thoroughly the Prerequisites for Replacing Components and Cables (*see page 72*).

DANGER

INOPERABLE SAFETY FUNCTION

Test the proper functioning of the safety functions after every device replacement and every change of the wiring.

Failure to follow these instructions will result in death or serious injury.

Observe the following instructions to replace the controller.

Step	Action
1	In order to maintain compatibility with your application and machine, replace the existing controller with that of the same hardware revision (for example, RS:02 on the logistical nameplate (<i>see page 34</i>) or 02 in the hardware code (<i>see page 91</i>).
2	Contact your Schneider Electric representative if the replacement controller is of a different hardware revision.
3	When replacing the controller, in addition to the following instructions, the specifications of the original machine manufacturer must also be observed.
4	Disconnect cables from the controller.
5	Loosen the mounting screws from the top and bottom of the housing brackets.
6	Remove the controller and replace the complete unit.
7	Install the new controller and tighten the mounting screws.
8	Connect the controller according to the circuit diagram of the machine.
9	Following replacement of the controller, proceed as for the initial start-up.

NOTICE

IMPROPER REPLACEMENT / COMMISSIONING

Do not open the controller for commissioning or replacement.

Failure to follow these instructions can result in equipment damage.

⚠ DANGER**INCORRECT ASSIGNMENT OF CABLES**

Verify that the assignment of the cables conforms to their previous connector assignments.

Failure to follow these instructions will result in death or serious injury.

⚠ CAUTION**FALLING HEAVY OBJECT**

Do not fully remove the screw connections of the device mounting suspension and prevent the device from falling out and down.

Failure to follow these instructions can result in injury or equipment damage.

How to Start-Up

Proceed as follows to start up:

Step	Action
1	Import the user project again using a PC on which the automation toolkit SoMachine Motion Logic Builder is installed. Or Retrieve the CompactFlash card from the controller to be replaced and insert it into the new controller.
2	Ensure that the CompactFlash card is functional.
3	Store the PacDrive controller in a suitable transport packaging.
4	Put the system back in operation.

Fast Device Replacement (FDR) - Introduction

Introduction

With the help of the fast device replacement, the Lexium 62, Lexium 52 and ILM devices that are in the configuration of a SoMachine Motion project on the controller can be replaced.

There are certain parameters that have to be set in SoMachine Motion first. Information on this can be found in the online help of SoMachine Motion.

Subsequently, certain settings on the display of the controller have to be made which are described in the following.

The controller interface for FDR gives the possibility to manually access the assignment between logical devices in the controller configuration (SoMachine Motion Logic Builder) and the physical connected devices.

Fast Device Replacement - Usage

Error Detected During the Manual Device Assignment

If two or more devices of the same type (or a double drive) are replaced, it is possible that an incorrect manual assignment of the logical devices to the physical connected devices is made.

⚠ WARNING

UNINTENDED OPERATING STATE OF THE DEVICE

- Make sure that the assignment of the logical devices to the physical connected devices is exactly the same as the device assignment before the device replacement.
- Before putting the machine back into service, you have to verify that the application is addressing the physical drives correctly.

Failure to follow these instructions can result in death, serious injury, or equipment damage.

Different Device Types


The controller interface for FDR does not consider the device type of physical devices.

NOTE: If the logical device type is not the same as the assigned physical device type, then a device assignment with the controller interface for FDR is possible. However, it leads to an error being detected during the Sercos phase start-up (8501 Sercos slave not found). If `FDRStartMode` is set to the value `Phase start-up/2`, then the controller interface for FDR is restarted.

Further information on the parameters can be found under *Fast Device Replacement* in the online help of SoMachine Motion.

Device Replacement

If the requirements are fulfilled (see chapter *Fast Device Replacement* in the SoMachine Motion online help) and you are replacing a device, then the controller display automatically shows the start picture of the controller interface for FDR.



Confirmation or Cancel

Action	Result
You can exit the controller interface for FDR with the Enter key (if the arrow pointing right is on No).	The controller interface for FDR is ended.
You can also switch to Yes with the arrow pointing down key (arrow pointing right on Yes), and then confirm the Yes with Enter .	Now you can navigate through the menu like described in the chapter Controller Display (<i>see page 79</i>). For more information, refer to the chapter Application (<i>see page 82</i>).

Timeout (5 Minutes)

If no button is pressed at the display for 5 minutes, the controller interface for FDR is terminated (timeout = 5 minutes). The system then behaves as if you have terminated the FDR mechanism as described above. If you press a display button within the 5 minutes, the time for the timeout is reset.

Behavior After Repeated Download

If after the controller interface for FDR a download of a project is made, then the saved changes of the parameter `ConfiguredSerialNumber` are reset and set to the values that are saved in the project that was downloaded.

For devices that are identified via **Identification mode → Device number** (`SerialNumberController / 0`) and were allocated via FDR, the system acts as if the controller interface for FDR had not been performed.

Further information on the parameters can be found under *Fast Device Replacement* in the online help of SoMachine Motion.







Fast Device Replacement - Controller Display

Overview


When the controller interface for FDR is active, the controller display shows the corresponding menu.

The following describes the menu in general. For more information, refer to the section Application (*see page 82*).

General Menu Description

Arrow / Key		Description
		If up/down arrows are displayed at the right menu edge, you can scroll up and down using these arrow keys. Scrolling starts only after the right arrow is displayed at the lower or upper menu edge. If the right arrow is displayed in a line in between, you can move it using the up/down arrow keys
		
	-	The command that is in the line that is marked with the arrow pointing right can be confirmed/executed with the Enter key.
	-	

In the following example, FDR SNRC stands for addressing a device via the device serial number. Instead of FDR SNRC, the FDR ATYP (for application type) or FDR SADR (for Sercos address) can also be used.



Placeholders	Description
[x/y]	<p>Number of the logic device (x) which currently has to be processed and the total number of the assigned devices (y). If, for example, 20 devices cannot be assigned by default addressing and you have already assigned 11 devices via the controller interface for FDR, then 12/20 is displayed.</p> <p>If this line (for example, FDR SNRC[x/y] [TA]) contains more than 18 characters, then the first 16 characters are displayed, followed by . . .</p> <p>Via the menu item Details, you can switch to a display mode that displays the complete line (see below).</p>
[TA]	<p>Topological address of the physical device that is currently displayed.</p>
[log.device]	<p>Name of the logical device in the controller configuration (SoMachine Motion Logic Builder) that shall be assigned to the physical device at the topological address [TA].</p> <p>If the device name consists of more than 18 characters, the first 16 characters of the device name are displayed, followed by . . .</p> <p>Via the menu item Details, you can switch to a display mode that displays the complete logical device name (see below).</p>
[SNRC]	<p>Serial number of the currently displayed physical device on the topological address [TA]</p> <p>If the serial number has more than 18 characters, then the first 16 characters of the serial number are displayed, followed by . . .</p> <p>Via the menu item Details, you can switch to a display mode that displays the complete serial number (see below).</p>

NOTE: Devices that were assigned via the menu item/command **Assign device** (see below) cannot be removed again via a menu item/command.

Menu item/Command	Description
Assign device	<p>With this command, you confirm the assignment between the logical device [log.device] and the physical device at the topological address [TA].</p> <ul style="list-style-type: none"> ● In the case of Identification mode → Device serial number, the serial number of the physical device is copied to the parameter <code>ConfiguredSerialNumber</code> of the logical device. ● In the case of Identification mode → Application type, the application type is written to the respective device via the Sercos bus ● By Identification mode → sercos address, the Sercos address is written to the respective device via the Sercos bus. <p>After assigning a device, the x (see placeholder [x/y]) is increased. If no other devices without an assignment are existent, then the mechanism is completed and the Sercos phase start-up continues.</p>
next phys.	<p>With this command, the next physical device to the logical device (x) that currently has to be processed is displayed.</p>

Menu item/Command	Description
Details	With this command, it is possible to switch to a display mode that displays the complete lines (multi-line). This is helpful if in the standard view lines cannot be displayed completely (see above). For a logical device, a maximum of 40 characters can be displayed
back	With this command, it is possible to switch back to the standard view (maximum 16 characters followed by . . . are displayed).
Exit FDR	With this command, the controller interface for FDR is canceled. The cancelation has to be confirmed once again (Really exit? → Exit FDR).

Further information on the parameters can be found under *Fast Device Replacement* in the online help of SoMachine Motion.


Fast Device Replacement - Application

Starting Conditions

The following example shows a typical application for the controller interface for FDR. For the displayed example, the following applies:

- All the devices are operational.
- The Sercos bus is started up.
- For all the devices, the **Device addressing** via the **Identification mode** → **Device serial number** was made (parameter `SerialNumberController / 0`).
- The parameter `FDRConfirmationMode` of the controller was set to the value by `Display / 0`.

Further information on the parameters can be found under *Fast Device Replacement* in the online help of SoMachine Motion.




Device Replacement

The following devices have to be replaced because of maintenance:

- The device at the topology address 2 (TA: 2) with the logical device name DEV_02 and the serial number SNRC phy: xxx-02 has to be replaced by the new device that has the serial number SNRC phy: xxx-15.
- The device at the topology address 5 (TA: 5) with the logical device name DEV_05 and the serial number SNRC phy xxx-05 has to be replaced by the new device that has the serial number SNRC phy xxx-16.

After the Device Replacement



After the physical replacement of the devices the machine has to be restarted again. In order for the controller interface for FDR to be started, the parameter `FDRStartMode` has to be set to `Start/1` or `Phase start-up/2` and the parameter `FDRConfirmationMode` to `by display / 0`.


Now the controller interface for FDR has to find the correct assignment of the two logical devices DEV_02 and DEV_05 to the new physically connected devices at topology address 2 and 5.


Further information on the parameters can be found under *Fast Device Replacement* in the online help of SoMachine Motion.

Process

The controller interface for FDR verifies all the logical devices one after another which would trigger the diagnostic message `8501 Sercos slave not found` during the Sercos phase start-up. Afterwards, to the respective logical device all the physical devices are checked until one device is acknowledged.

Due to space constraints, the sequence for device 1 and device 2 is displayed one beneath the other.





Cable Replacement

Introduction

NOTE: In addition to the following instructions, you must observe the specifications of the machine manufacturer when replacing the cables.

De-Energize the System

⚠ DANGER

ELECTRIC SHOCK, EXPLOSION, OR ARC FLASH

- Disconnect all power from all equipment including connected devices prior to removing any covers or doors, or installing or removing any accessories, hardware, cables, or wires.
- Place a "Do Not Turn On" or equivalent hazard label on all power switches and lock them in the non-energized position.
- Wait 15 minutes to allow the residual energy of the DC bus capacitors to discharge.
- Measure the voltage on the DC bus with a properly rated voltage sensing device and verify that the voltage is less than 42.4 Vdc.
- Do not assume that the DC bus is voltage-free when the DC bus LED is off.
- Block the motor shaft to prevent rotation prior to performing any type of work on the drive system.
- Do not create a short-circuit across the DC bus terminals or the DC bus capacitors.
- Replace and secure all covers, accessories, hardware, cables, and wires and confirm that a proper ground connection exists before applying power to the unit.
- Use only the specified voltage when operating this equipment and any associated products.

Failure to follow these instructions will result in death or serious injury.

How to de-energize the system:

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	In the case of any drives, servos or other equipment with high capacity capacitors, wait at least 15 minutes after removing power (switching off) to allow the DC bus capacitors to discharge.
4	Verify whether the DC-BUS LED indicator has turned off on all components located in the axis group.
5	Verify with an appropriate measuring instrument that the voltages between DC+ to PE (Protective Earth/ground), DC- to PE and DC+ to DC- are all less than 42.4 Vdc.

⚠ DANGER

ELECTRIC SHOCK, EXPLOSION OR ARC FLASH

Verify with a correctly calibrated measuring instrument that the DC bus is de-energized (less than 42.4 Vdc) before replacing, maintaining or cleaning machine components.

Failure to follow these instructions will result in death or serious injury.

For more information on the DC Bus LED indicator, refer to *Bus Bar Module LED Indicators on the Lexium 62 Power Supply and Lexium 62 Cabinet Drive (see Lexium 62, Hardware Guide)*.

Procedure

Proceed as follows for cable replacement:

- Be sure that the cables clearly indicate their connections before disconnecting.
- Replace cables with an identical type and length.
- Refer to any documentation from the original machine manufacturer before replacing cables.
- Disconnect/Attach the cable from the equipment components involved.

⚠ DANGER

INCORRECT ASSIGNMENT OF CABLES

Verify that the assignment of the cables conforms to their previous connector assignments.

Failure to follow these instructions will result in death or serious injury.

Chapter 5

Indicators and Control Elements


What Is in This Chapter?

This chapter contains the following topics:


Topic	Page
Indicators of the Controller	90
Menu Navigation	97
CompactFlash Card Slot	101
Buttons	102

Indicators of the Controller

Overview



1	4-line Liquid Crystal Display (LCD) <i>(see page 91)</i>
2	Power LED indicator <i>(see page 91)</i>
3	WD LED indicator <i>(see page 92)</i>
4	Error LED indicator <i>(see page 92)</i>
5	S3 (Sercos III) LED indicator <i>(see page 93)</i>
6	Ethernet status LED indicators <i>(see page 93)</i>
7	Sercos status LED indicators <i>(see page 94)</i>
8	Protocol-specific status LED indicators <i>(see page 94)</i>
9	PacNet LED indicators (not used)



If the cover of the controller is closed, you see 3 vertically arranged LED indicators, which signify various operating states or detected errors:

- **Power**
- **WD** (watchdog indicator)
- **Error** (error display)

Liquid Crystal Display (LCD)



In addition to the LED indicators, further information about the operating status of the controller is given on the 4-line Liquid Crystal Display (LCD).

Line 1	Controller type and firmware version
Line 2	Current IP address of the controller
Line 3	–
Line 4	PFPGA version/PIC version

Power LED Indicator

The **Power** LED indicator indicates the state of the control voltage in the UPS status.

LED indicator status	Meaning
Off	The control voltage (24 Vdc) is absent or under-voltage.
On	Normal operation; control voltage in the normal range.
Flashes	UPS active.

Watchdog LED Indicator

The **WD** (watchdog) LED indicator of the watchdog hardware module is used to monitor the controller.

LED indicator status	Meaning
Off	Normal operation.
On	An unrecoverable error was detected or the controller is in initialization phase. Press the reset button to reset and reboot the controller.

An unrecoverable error is a serious hardware or software issue that requires intervention.

When this error is detected, the following actions are performed:

- The controller is stopped.
- The optional modules are reset.
- The digital and analog outputs are reset.
- The wd (watchdog) relay output is opened.

Error LED Indicator

The **Error** LED indicator indicates detected errors. The table lists the possible display conditions and their accompanying error descriptions.

LED indicator status	Meaning
Off	Normal operation.
Flashes slowly (1.7 Hz)	Error of class 3 and 4 active. Refer to the <i>SoMachine Motion Online Help\SoMachine Motion Diagnostics\System Diagnostic\Diagnostic Classes</i> .
Flashes quickly (10 Hz)	Controller boot completed, last boot was not successful. See diagnostic message 209 last boot failed . Controller performed a minimal boot.
Flashes fast and slowly alternately	Firmware download via Sercos is active or controller is in initialization phase
On	An error was detected during the boot.

The **Error** LED indicator is flashing on after BIOS is started. Once the operating system, user configuration, user parameters, and the IEC program have been loaded and the IEC program has been started successfully, the **Error** LED indicator is switched off again. The boot procedure is now complete.

S3 (Sercos III) LED Indicator

The **S3** LED indicator indicates the state and the phases of the Sercos communication.

LED indicator color / status	Meaning	Instructions/information for the user	Notes
Off	No Sercos communication	–	–
Orange	The device is in a communication phase CP0 up to and including CP3.	–	SERC3.State = 0..3
Green	Sercos communication in communication phase CP4 without error detected.	–	SERC3.State = 4
Red	Detected communication error.	Reset condition: <code>DiagQuit</code>	SERC3.State = 11

Ethernet Status LED Indicators

The Ethernet connector of PacDrive LMC Pro has two LED indicators. One LED indicator is green, the other is yellow.

LED indicator	State	Meaning
Green	On	Connection established
Green	Flashing	Data traffic
Green	Off	No connection, for example, no cable connected, or connected device has no power
Yellow	On	100 MBit/s connection
Yellow	Off	10 MBit/s connection

The Ethernet connector of PacDrive LMC Pro2 has two LED indicators. One LED indicator is green (above), the other is yellow/green (below).

LED indicator	State	Meaning
Green (above)	On	Connection established
Green (above)	Off	No connection, for example, no cable connected, or connected device has no power
Green (below)	Flashing	1000 MBit/s (1 GBit/s) connection with data traffic
Yellow (below)	Flashing	10/100 MBit/s connection with data traffic
Yellow/Green (below)	Off	No data traffic

Sercos Status LED indicators

Each Sercos connector has two LED indicators. One LED indicator is green, the other is yellow.

LED indicator	State	Meaning
Yellow	On	Connection established
	Off	No cable connected or connected device has no power.
Green	On	Active network traffic
	Off	No active network traffic

Protocol-specific Status LED Indicators

LED indicators EtherCAT master

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Off	Off	The device has no connection to Ethernet.
RJ45 Ch0 & Ch1	yellow LED indicator		
	Yellow	Flashing cyclic with 2.5 Hz	The device sends/receives Ethernet frames.

LED indicators EtherCAT slave

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Green	Flashing cyclic with 2.5 Hz	The device sends/receives Ethernet frames.
	Off	Off	The device has no connection to Ethernet.
RJ45 Ch0 & Ch1	yellow LED indicator		
	–	–	The LED indicator is not being used.

LED indicators EtherNet/IP scanner (master)

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Off	Off	The device has no connection to Ethernet.
ACT/RJ45 Ch0 & Ch1	yellow LED indicator		
	Yellow	Flashes	The device sends/receives Ethernet frames.

LED indicators EtherNet/IP adapter (slave)

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Off	Off	The device has no connection to Ethernet.
ACT/RJ45 Ch0 & Ch1	yellow LED indicator		
	Yellow	Flashes	The device sends/receives Ethernet frames.

LED indicators PROFINET controller

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Off	Off	The device has no connection to Ethernet.
RX/TX/RJ45 Ch0 & Ch1	yellow LED indicator		
	Yellow	Flashes	The device sends/receives Ethernet frames.


LED indicators PROFINET device

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Off	Off	The device has no connection to Ethernet.
RX/TX/RJ45 Ch0 & Ch1	yellow LED indicator		
	Yellow	Flashes	The device sends/receives Ethernet frames.

Menu Navigation

Menu Buttons








Three menu buttons are located on the front side of the controller. With these menu buttons, the user can open and navigate through the menu.





- 1 Up arrow button
- 2 **Enter** button
- 3 Down arrow button


Functions of the Menu Buttons

Under the Liquid Crystal Display (LCD), three menu buttons are located through which the user can open and navigate in the menu. The menu buttons feature the following functions:

Buttons	Function
First  and then simultaneously 	Access of the menu
	Cursor up
	Cursor down
	Open menu item
First  and then simultaneously 	One level up in the menu

If an up or down arrow is displayed on the right display edge, this indicates that the current menu has more lines than can be shown on the display. In this case, you can use the arrow buttons  and  to scroll up or down.

Menu Navigation



Description of the Menu Navigation

The submenu **Versions** provides an overview of all the software and hardware versions installed on the controller.

Item	Description
FW	Currently used firmware version.
PFFGA	Version of the PacDrive FPGA software
PIC	Version of PIC firmware
BIOS	BIOS version

In the submenu **HCode/SerialNo.** a serial number and the hardware code are displayed. The serial number is a unique number which is used to identify the controller. The hardware code indicates the hardware revision.

Item	Description
Serial number	Controller serial number
Hardware code	Hardware code of the controller ⁽¹⁾
<p>(1) The first two digits of the hardware code indicate the hardware revision (for example, 02). The hardware revision is also indicated on the logistical nameplate (<i>see page 34</i>) (for example, RS:02). In order to maintain compatibility with your application and machine, replace the existing controller with that of the same hardware code.</p>	

In the submenu **IP address**, the IP address, the subnet mask, and the gateway are displayed.

Item	Description
IP	IP address of the controller
MASK	Subnet mask
GW	Gateway

The MAC address is specified in the submenu **MAC address**. The MAC address is a clear address of the device to identify the device in the network.

Item	Description
MAC address	MAC address

In the submenu **Inputs**, the user can prompt the logic state of each input. The digital inputs correspond to the standard IEC61131-2 type 1. Touchprobes and fast inputs have a resolution of 10 μ s. Fast inputs can be used to trigger an interrupt.

Item	Description
DI	Digital input
FI	Fast input
TP	Touchprobe

In the submenu **Outputs**, the user can prompt the logic state of each output.

Item	Description
DQ	Outputs

In the submenu **DiagMessage**, the diagnostic class, the diagnostic code, and the diagnostic text are displayed. The system assigns each diagnostic message a specific diagnostic class when enabled. The diagnostic code is a code that encrypts a certain diagnostic. In the diagnostic text, a diagnostic is described in detail.

Item	Description
A:	A: Diagnostic class
BBB:	BBB: Diagnostic code
C...C	C...C: Diagnostic text

In the submenu **Select language**, the user can choose the display language.

Item	Description
Select language:	
German	Display language is German.
English	Display language is English.




Display during the boot with empty battery pack (UPS).

Press the right button below the display to continue the boot and to start charging the battery pack.

For more information, refer to the chapter Device Replacement ([see page 74](#)).

CompactFlash Card Slot

Overview



- 1 CompactFlash card slot
- 2 Battery compartment

The CompactFlash card slot is located on the operating cover of the controller.

The CompactFlash card slot is the receptacle for the permanent data storage (**CF card**) of the controller.

How to Replace the CompactFlash Card in Case of Servicing

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Hold the CompactFlash card with your thumb and forefinger and pull it out of the slot.
4	To insert, carefully place the CompactFlash card on the guide rail and push it into the device.
5	Push lightly until the CompactFlash card clicks in.

Buttons

on / off Button



The **on / off** buttons are located under the operating cover of the controller.

Precondition: Place the system in a secure position before switching it off.

Step	Action
1	Press this button to energize the controller when the controller is completely wired and connected to the power supply system.
2	Press this button to de-energize the controller when the system is running.

reset Button



The **reset** button is located under the operating cover of the controller.

Precondition: Place the system in a secure position before resetting.

Step	Action
1	Press the button to reset and reboot the controller.

Chapter 6

Integrated Communication Ports

What Is in This Chapter?

This chapter contains the following topics:


Topic	Page
Electrical Connections Overview	104
Connection Details Controller	106

Electrical Connections Overview


Front Panel

Connection overview of the PacDrive LMC Pro/Pro2:

Front view of the PacDrive LMC Pro/Pro2:



Bottom view of the PacDrive LMC Pro/Pro2:



Connection	Meaning	Connection cross-section [mm ²] / [AWG]		Tightening torque [Nm] / [lbf in]
CN1	Control voltage / watchdog	1...1.5	17...16	–
CN2	Digital outputs	1...1.5	17...16	–
CN3	Digital inputs	0.5...1.5	20...16	–
CN4	TP / fast digital inputs	0.5...1.5	20...16	–
CN5	Analog inputs / outputs	0.5...1.5	20...16	–
CN7	USB host (USB-A)	–	–	–
CN8	Ethernet connection	–	–	–
CN9	PacNet	–	–	–
CN10	RT Ethernet, port 1	–	–	–
CN11	RT Ethernet, port 2	–	–	–
CN12	Sercos, port 1	–	–	–

Connection	Meaning	Connection cross-section [mm ²] / [AWG]		Tightening torque [Nm] / [lbf in]
CN13	Sercos, port 2	–	–	–
CN14	Master encoder (Hiperface)	–	–	0.4 / 3.54
CN14	Master encoder (incremental)	–	–	0.4 / 3.54
CN15	COM 1 (RS-232)	–	–	0.4 / 3.54
CN16	COM 2 (RS-485)	–	–	0.4 / 3.54
CN17	CAN	–	–	0.4 / 3.54
CN18	PROFIBUS DP	–	–	0.4 / 3.54
CN20	Option slot 1	–	–	0.5 / 4.42
CN21	Option slot 2	–	–	0.5 / 4.42
<i>rh</i>	Shield connection	4	11	1 / 8.85

Connection Details Controller


CN1 - Control Voltage And Watchdog



Connection CN1


Pin	Designation	Meaning	Range
1	DC +24 V	Supply voltage	-15 % / +25 %
2	DC 0 V	Supply voltage	–
3	+UL	For digital outputs	DC +24 V -15 % / +25 %
4	L0	For digital inputs / outputs	–
5	DC +24 V	Supply voltage (bridged with pin 1, maximum ampacity 4 A)	–
6	DC 0 V	Supply voltage (bridged with pin 2, maximum ampacity 4 A)	–
7	WD	Watchdog relay	–
8	WD	Watchdog relay	–

Input connection



- 1 Internal wiring diagram - input connection of power supply (simplified)
- 2 Internal supply voltage
- 3 Supply voltage for digital outputs/inputs

CN2 - Digital Outputs



Connection CN2

Pin	Designation	Meaning
1	O.00	Digital output 0
2	O.01	Digital output 1
3	O.02	Digital output 2
4	O.03	Digital output 3
5	O.04	Digital output 4
6	O.05	Digital output 5
7	O.06	Digital output 6
8	O.07	Digital output 7
9	O.08	Digital output 8
10	O.09	Digital output 9
11	O.10	Digital output 10
12	O.11	Digital output 11
13	O.12	Digital output 12
14	O.13	Digital output 13
15	O.14	Digital output 14
16	O.15	Digital output 15

CN3 - Digital Inputs



Connection CN3

Pin	Designation	Meaning
1	I.00	Digital input 0
2	I.01	Digital input 1
3	I.02	Digital input 2
4	I.03	Digital input 3
5	I.04	Digital input 4
6	I.05	Digital input 5
7	I.06	Digital input 6
8	I.07	Digital input 7
9	I.08	Digital input 8
10	I.09	Digital input 9
11	I.10	Digital input 10
12	I.11	Digital input 11
13	I.12	Digital input 12
14	I.13	Digital input 13
15	I.14	Digital input 14
16	I.15	Digital input 15
17	I.16	Digital input 16
18	I.17	Digital input 17
19	I.18	Digital input 18
20	I.19	Digital input 19


CN4 - Touchprobe And Fast Digital Inputs



Connection **CN4**

Pin	Designation	Meaning
1	T.00	Touchprobe input 0
2	T.01	Touchprobe input 1
3	T.02	Touchprobe input 2
4	T.03	Touchprobe input 3
5	T.04	Touchprobe input 4
6	T.05	Touchprobe input 5
7	T.06	Touchprobe input 6
8	T.07	Touchprobe input 7
9	T.08	Touchprobe input 8
10	T.09	Touchprobe input 9
11	T.10	Touchprobe input 10
12	T.11	Touchprobe input 11
13	T.12	Touchprobe input 12
14	T.13	Touchprobe input 13
15	T.14	Touchprobe input 14
16	T.15	Touchprobe input 15
17	F.00	Fast input 1
18	F.01	Fast input 2
19	F.02	Fast input 3
20	F.03	Fast input 4

CN5 - Analog Inputs / Outputs




Connection CN5

Pin	Designation	Meaning	Range
1	AI.0 +	Analog input 0+	-10...+10 V (*) 0...20 mA (**)
2	J.0 +	Br. current input 0 +	–
3	AI.0 -	Analog input 0-	–
4	A.GND 0	Analog ground 0	–
5	12 V Out 0	Output voltage 0	12 V
6	FE (functional earth)	Shield	–
7	AO.0	Analog output 0	-10...+10 V
8	A.GND AO.0	Analog ground 0	–
9	FE (functional earth)	Shield	–
10	AI.1 +	Analog input 1+	-10...+10 V (*) 0...20 mA (**)
11	J.1 +	Br. current input 1 +	–
12	AI.1 -	Analog input 1-	–
13	A.GND 1	Analog ground	–
14	12 V Out 1	Output voltage 1	12 V
15	FE (functional earth)	Shield	–
16	AO.1	Analog output 1	-10...+10 V
17	A.GND AO.1	Analog ground	–
18	FE (functional earth)	Shield	–


(*) Voltage measurement and (**) current measurement on AI.0+ / AI.0- (pin 1 / pin 3) and AI.1+ / AI.1- (pin 10 / pin 12)
 (**) Current measurement via bridging to J.0+ (pin 2) or J.1+ (pin 11).

Input connection



- 1 Internal wiring diagram - input connections for analog inputs (simplified)
- 2 Analog input 1
- 3 Analog input 2

CN7 - USB Host



Connection CN7

Pin	Designation	Meaning	Range
1	VBUS / +5V	-	-
2	D- / Data-	-	-
3	D+ / Data+	-	-
4	GND / Ground	-	-

CN8 - EthernetConnection **CN8** of PacDrive LMC Pro


Pin	Designation	Meaning	Function
1	Tx+	Output transmit data +	–
2	Tx-	Output transmit data -	–
3	Rx+	Input receive data +	–
4	–	Reserved	–
5	–	Reserved	–
6	Rx-	Input receive data -	–
7	–	Reserved	–
8	–	Reserved	–

Connection **CN8** of PacDrive LMC Pro2

Pin	Designation	Meaning	Function
1	MDI 0+	Transmit line 0	–
2	MDI 0-	Transmit line 0	–
3	MDI 1+	Transmit line 1	–
4	MDI 2+	Transmit line 2	–
5	MDI 2-	Transmit line 2	–
6	MDI 1-	Transmit line 1	–
7	MDI 3+	Transmit line 3	–
8	MDI 3-	Transmit line 3	–

There are two LED indicators affixed to the Ethernet connection.


For further information on the functions of the LED indicators, refer to the description of the Ethernet status LED indicator .

CN9 - PacNet

Connection CN9

Pin	Designation	Meaning	Function
1	TxD+	Output transmit data +	–
2	TxD-	Output transmit data -	–
3	RxD+	Input receive data +	–
4	TxC-	Output transmit clock -	–
5	TxC+	Output transmit clock +	–
6	RxD-	Input receive data -	–
7	RxC+	Input receive clock +	–
8	RxC-	Input receive clock -	–

CN10/CN11 - RT Ethernet




Connection CN10/11

Pin	Designation	Meaning	Function
1	Tx+	Output transmit data +	–
2	Tx-	Output transmit data -	–
3	Rx+	Input receive data +	–
4	–	Reserved	–
5	–	Reserved	–
6	Rx-	Input receive data -	–
7	–	Reserved	–
8	–	Reserved	–

NOTE: When using the PacDrive LMC Pro/Pro2 as EtherCAT slave, the connection **CN10** represents the input port and the connection **CN11** the output port. The input port and output port are predetermined by the firmware and cannot be configured.

For further information on the functions of the LED indicators, refer to the description of the Indicators and Control elements ([see page 89](#)).

CN12/CN13 - Sercos



Connection CN12/CN13

Pin	Designation	Meaning	Range
1	Tx+	Output transmit data +	–
2	Tx-	Output transmit data -	–
3	Rx+	Input receive data +	–
4	–	Reserved	–
5	–	Reserved	–
6	Rx-	Input receive data -	–
7	–	Reserved	–
8	–	Reserved	–


NOTE:

If Sercos devices are assigned via the topological addresses (**IdentificationMode = TopologyAddress**) to the PacDrive LMC Pro/Pro2, then consider the following:

- Connect your Sercos device to the PacDrive LMC Pro/Pro2 either completely via Sercos port 1 (CN12) in line topology or in ring topology using Sercos port 1 and 2 (CN12/CN13).
- Do not connect the Sercos devices to the PacDrive LMC Pro/Pro2 via double line topology (CN12/CN13).
- Do not connect the Sercos devices to the PacDrive LMC Pro/Pro2 only via Sercos port 2 (CN13).

CN14 - Master Encoder (Hiperface)


The Hiperface connection consists of a standard, differential, digital connection (RS-485 = 2 wires), a differential, analog connection (sine- and cosine signal = 4 wires), and a mains connection to supply the encoder (+9 V, GND = 2 wires).



Connection **CN14** - Master encoder (Hiperface)


Pin	Designation	Meaning	Range
1	REFSIN	Reference signal sine	–
2	SIN	Sinusoidal trace	–
3	REFCOS	Reference signal cosinus	–
4	COS	Cosinus trace	–
5	+9 V	Supply voltage	–
6	RS485-	Parameter channel -	–
7	RS485+	Parameter channel +	–
8	SC_SEL	Master encoder plugged in (bridge to GND)	–
9	GND	Supply voltage	–

CN14 - Master Encoder (Incremental)




Connection **CN14** - Master encoder (incremental)

Pin	Designation	Meaning	Range
1	_UA	Track A	–
2	UA	Track A	–
3	_UB	Track B	–
4	UB	Track B	–
5	+5 V	Supply voltage	–
6	_UO	Track O	–
7	UO	Track O	–
8	–	Reserved	–
9	GND	Ground	–

CN15 - COM 1 (RS-232)Connection **CN15**


Pin	Designation	Meaning	Range
1	DCD	Data carrier detect	–
2	RxD	Receive data	–
3	TxD	Transmit data	–
4	DTR	Data terminal ready	–
5	GND	Signal ground	–
6	DSR	Data set ready clear to send	–
7	RTS	Request to send	–
8	CTS	Clear to send	–
9	RI	Ring indicator	–

CN16 - COM 2 (RS-485)Connection **CN16**

Pin	Designation	Meaning	Range
1	+5 VM	Supply voltage	–
2	TxD-	RS-485 transmit-	–
3	TxD+	RS-485 transmit+	–

Pin	Designation	Meaning	Range
4	RxD+	RS-485 receive+	–
5	RxD-	RS-485 receive-	–
6	GNDR	GND via resistor (100 Ohm)	–
7	–	Reserved	–
8	GNDM	Supply voltage	–
9	GNDR	GND via resistor (100 Ohm)	–

CN17 - CAN




Connection CN17

Pin	Designation	Meaning	Range
1	–	Reserved	–
2	CAN_L	Bus line (low)	–
3	GND	Ground	–
4	–	Reserved	–
5	–	Reserved	–
6	–	Reserved	–
7	CAN_H	Bus line (high)	–
8	–	Reserved	–
9	–	Reserved	–

NOTE: The connection of the TM5 System to the PacDrive controller can only occur via a Sercos bus interface TM5NS31. A connection of TM5 System via CAN bus and a CANopen interface module is not supported.

CN18 - PROFIBUS



Connection **CN18**

Pin	Designation	Meaning	Range
1	FE (functional earth)	Shield	–
2	–	Reserved	–
3	RxD / TxD -P	Data -P	–
4	CNTR-P	Control signal P	–
5	DGND	Signal ground	–
6	VP	Supply voltage	–
7	–	Reserved	–
8	RxD / TxD -N	Data -N	–
9	–	Reserved	–

Connectors

NOTE: For the connection plugs, use a PROFIBUS connector to connect to the 9 pole PROFIBUS outlet because the bus terminal resistors are in this connector.

Note for the bus terminal resistors:

Step	Action
1	Verify for the first and last bus nodes if the terminal resistors are switched on. Otherwise data transmission will not function properly.
2	Verify if the shielding is applied extensively and on both sides.

Chapter 7

Technical Data

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Ambient Conditions	122
Standards and Regulations	125
Mechanical and Electrical Data	126
Dimensions	131

Ambient Conditions

Ambient Conditions for Control Cabinet Devices (Without UPS)

Procedure	Parameter	Value	Basis
Operation	Class 3K3		IEC/EN 60721-3-3
	Degree of protection	IP 20	
	Pollution degree	2	
	Ambient temperature	+5...+55 °C (+41...+131 °F)	
	Relative humidity	5...95%	
	● Condensation	No	
	● Formation of ice	No	
	Class 3M4		
	Shock	147 m/s ² (15 g _n) for a duration of 6 ms	
	Vibration	3.5 mm (0.138 in.) fixed amplitude from 5...8.4 Hz	
9.8 m/s ² (1 g _n) fixed acceleration from 8.4...150 Hz			
Transport	Class 2K3		IEC/EN 60721-3-2
	Ambient temperature	-40...+70 °C (-40...+158 °F)	
	Relative humidity	5...95%	
	● Condensation	No	
	● Formation of ice	No	
	Class 2M2		
	Shock	147 m/s ² (15 g _n) for a duration of 6 ms	
	Vibration	3.5 mm (0.138 in.) fixed amplitude from 5...8.4 Hz	
		9.8 m/s ² (1 g _n) fixed acceleration from 8.4...150 Hz	

Procedure	Parameter	Value	Basis
Long-term storage in transport packaging	Class 1K4		IEC/EN 60721-3-1
	Ambient temperature	-25...+55 °C (-13...+131 °F)	
	Relative humidity	5...95%	
	● Condensation	No	
	● Formation of ice	No	

Ambient Conditions for Control Cabinet Devices (With UPS)

Procedure	Parameter	Value	Basis	
Operation	Class 3K3		IEC/EN 60721-3-3	
	Degree of protection housing	IP 20		
	Pollution degree	2		
	Ambient temperature	+5...+40°C (+41...+104 °F)		
	Relative humidity	5...95%		
	● Condensation	No		
	● Formation of ice	No		
	Class 3M4			
	Shock	147 m/s ² (15 g _n) for a duration of 6 ms		
	Vibration			3.5 mm (0.138 in.) fixed amplitude from 5...8.4 Hz 9.8 m/s ² (1 g _n) fixed acceleration from 8.4...150 Hz
				9.8 m/s ² (1 g _n) fixed acceleration from 8.4...150 Hz

Procedure	Parameter	Value	Basis
Transport	Class 2K3		IEC/EN 60721-3-2
	Ambient temperature	-25...+50 °C (-13...+122 °F)	
	Relative humidity	5...95%	
	● Condensation	No	
	● Formation of ice	No	
	Class 2M2		
	Shock	147 m/s ² (15 g _n) for a duration of 6 ms	
Vibration	3.5 mm (0.138 in.) fixed amplitude from 5...8.4 Hz		
	9.8 m/s ² (1 g _n) fixed acceleration from 8.4...150 Hz		
Long-term storage in transport packaging	Class 1K3		IEC/EN 60721-3-1
	Ambient temperature	-5...+45 °C (-23...+113 °F)	
	Relative humidity	5...95%	
	● Condensation	No	
	● Formation of ice	No	

Standards and Regulations

Overview

Standards and regulations

CE	EMC Directive 2014/30/EU <ul style="list-style-type: none">● EN 61131-2:2007
cULus	UL 508C Power Conversion Equipment
	Adjustable Speed Drives <ul style="list-style-type: none">● CSA-C22.2 No. 274
CSA	Industrial Control Equipment <ul style="list-style-type: none">● CSA-C22.2 No. 14
China RoHS	Marking for the Restricted Use of Hazardous Substances in Electronic and Electrical Products <ul style="list-style-type: none">● SJ/T 11364

Mechanical and Electrical Data

Technical Data PacDrive LMC Pro/Pro2

Category	Parameter	Value			
Product configuration	Type code	PacDrive LMC300	PacDrive LMC400	PacDrive LMC600	PacDrive LMC402 PacDrive LMC802
Configuration	Processor	up to Rev. 01: CPU Intel Celeron M 600 MHz 512 KB L2 cache	CPU Intel Celeron M 1.5 GHz 1 MB L2 cache	CPU Intel Pentium M 2.0 GHz 2 MB L2 cache	CPU Intel Celeron 2000E 2.2 GHz 2 MB Smart Cache
		as of Rev. 02: CPU Intel Celeron M 1.5 GHz 1 MB L2 cache			
	Memory	512 MB DDR2			1 GB DDR3L
	NV RAM	128 KB	128 KB	256 KB	
	Battery on the front for BIOS cmos, NVRAM and RTC	Yes (battery maintenance interval: typically 5 years)			
	CompactFlash card	At least 128 MB (accessible from the outside)			
	On/Off button	Yes			
	Reset button	Yes			
	Cooling	Fan (temperature-controlled)			
Real Time Clock (RTC)	Yes				
Diagnostics	Watchdog	Yes (maximum 2 A, maximum 60 Vdc)			
	Alphanumeric diagnostic display	4 x 20 letters			
	Status LED indicators	3			
	Integrated data logger for diagnostic messages	Yes			
	Integrated trace recorder (software oscilloscope)	Yes			
	Remote maintenance	Yes			

Category	Parameter	Value			
		PacDrive LMC300	PacDrive LMC400	PacDrive LMC600	PacDrive LMC402 PacDrive LMC802
Bus connections	Integrated motion and field buses	Sercos			
	Integrated additional fieldbus connection (configuration 1)	PROFIBUS DP (master/slave) and			
		CAN (2.0B)			
	Integrated additional fieldbus connection (configuration 2)	RT-Ethernet (2 ports) and			
PROFIBUS DP (master/slave) or 1 x CAN (2.0B)					
	PacNet interface	1			
Communication / interfaces	Serial interfaces	COM1: RS-232			
		COM2: RS-422 / RS-485			
	Network connection	1 x Ethernet 10/100 Base-T (auto negotiation, auto-MDI)		1 x Ethernet 10/100/1000 Base-T (auto negotiation, auto-MDI)	
	USB connection	1 x USB-2.0 (host for storage medium)			
	Master encoder interface	1 Hiperface master encoder or			
		1 Incremental master encoder			
	Programming interface	Ethernet			
	Additional encoder input via PacNet interface with added BT-4/ENC module	Hiperface master encoder or			
		Incremental master encoders			
	Master encoder output via PacNet interface	Incremental			
	Integrated OPC interface	Yes			
	Diagnostic interface for remote maintenance	Ethernet or modem			
	Communication protocols	Http			
Ftp					
ICMP (Ping)					
Optional slots for OM-C/OM-P/OM-NE	2				

Category	Parameter	Value			
Product configuration	Type code	PacDrive LMC300	PacDrive LMC400	PacDrive LMC600	PacDrive LMC402 PacDrive LMC802
Programming-languages IEC 61131-3	–	Continuous function chart (CFC)			
		Function block diagram (FBD)			
		Instruction list (IL)			
		Structured text (ST)			
		Ladder diagram (LD)			
		Sequential function chart (SFC)			
Touchprobe inputs	Number	16 (IEC 61131-2)			
	Range U_{IN} 0 voltage	0...6 Vdc			
	Range U_{IN} 1 voltage	20...33 Vdc			
	Input current	$I_{IN} = 5 \text{ mA}$ at $U_{IN} = 24 \text{ V}$			
	Polarized	Yes			
	Input filter TP0...TP15	100 μs resolution			
	TP0 to TP15	10 μs at a Sercos cycle time of 1, 2, 4 ms			
Additional inputs or Touchprobe inputs via PacNet	Number	maximum 64			
Fast PacNet inputs	Number	64			
Digital inputs	Number	20 (IEC 61131-2)			
	Range U_{IN} 0 voltage	0...6 Vdc			
	Range U_{IN} 1 voltage	20...33 Vdc			
	Input current	$I_{IN} = 5 \text{ mA}$ at $U_{IN} = 24 \text{ V}$			
	Polarized	Yes			
	Input filter	1 ms or 5 ms can be parameterized			
Fast inputs (interrupt)	Number	4 (IEC 61131-2)			
	Range U_{IN} 0 voltage	0...6 Vdc			
	Range U_{IN} 1 voltage	20...33 Vdc			
	Input current	$I_{IN} = 5 \text{ mA}$ at $U_{IN} = 24 \text{ V}$			
	Polarized	Yes			
	Input filter	0.1 ms or 1 ms can be parameterized			

Category	Parameter	Value			
Product configuration	Type code	PacDrive LMC300	PacDrive LMC400	PacDrive LMC600	PacDrive LMC402 PacDrive LMC802
Analog inputs	Number	2			
	Range U_{IN}	-10...10 V			
		Resolution 12 bit (5 mV)			
		Resistor 100 kOhm			
	Range I_{IN}	-20...20 mA			
		Resolution 12 bit (5 μ A)			
Resistor 500 Ohm					
Fast PacNet outputs	Number	64			
Digital outputs	Number	16 (IEC 61131-2)			
	Output voltage	$(+UL-3 V) < U_{OUT} < +UL$			
	Rated current	$I_e = 250$ mA per output			
	Inrush current	$I_{emax} < 2$ A for 1 s			
	Leakage current with 0 signal	< 0.4 mA			
	Transmission time	100 μ s			
	Short circuit protection	Yes			
Analog outputs	Number	2			
	Range U_{OUT}	-10...10 V			
	Resolution	12 bit (5 mV)			
	Load	> 5 kOhm (maximum offset $< +/- 75$ mV)			
Power	Maximum number of drives	8 servo axes	16 servo axes	99 servo axes	16 servo axes (PacDrive LMC402) 130 servo axes (PacDrive LMC802)

Category	Parameter	Value			
Product configuration	Type code	PacDrive LMC300	PacDrive LMC400	PacDrive LMC600	PacDrive LMC402 PacDrive LMC802
Power supply	Power supply unit	without UPS (with UPS)			
		<ul style="list-style-type: none"> up to Rev. 01: 1.5 A (2.5 A) as of Rev. 02: 2.0 A (3 A) 	2.0 A (3 A)	2.0 A (3 A)	2.0 A (3 A)
	Supply voltage	DC +24 V -15 %/+25 %			
	Inrush current	maximum 20 A / 1 ms			
	Voltage drop immunity	Up to 25 ms.			
	UPS	Yes (optional)			
	Power consumption of power supply	<ul style="list-style-type: none"> up to Rev. 01: 24 W (66 W) as of Rev. 02: 48 W (72 W) 	48 W (72 W)	48 W (72 W)	48 W (72 W)
Dimensions	Dimensions of housing	DxWxH: 243 x 100 x 310 mm / 9.57 x 3.94 x 12.20 in			
Weight	Weight (with packaging)	3.5 kg (4.1 kg) / 7.71 lb (9.03 lb)			
Pollution degree	2 (according to CN 60664-1)				

Chapter 8

Uninterruptible Power Supply UPS

Retrofitting Installation of UPS


Overview

The controllers PacDrive LMC Pro and PacDrive LMC Pro2 can be equipped with an internal battery pack for an uninterruptible power supply. The internal battery pack is continually being charged via the power supply of the controller while in operation.

The function of the battery pack is to maintain the power supply to the controller in the event of a power outage long enough to shut down the controller properly without losing any data. The preset time of shutdown can be up to 5 minutes.

If necessary, the battery pack can also be installed or replaced afterwards, as described below.

How to Open the Controller

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent the main switch from being switched back on.
3	Open the operating cover of the PacDrive controller.
4	Loosen the two fastening screws on the front of the controller (1). 
5	Remove the electronic module from the housing.

NOTICE

ELECTROSTATIC DISCHARGE

- Do not touch any of the electrical connections or components.
- Prevent electrostatic charges, for example, by wearing appropriate clothing.
- If you must touch circuit boards, do so only on the edges.
- Move the circuit boards as little as possible.
- Remove existing static charge by touching a grounded, metallic surface.

Failure to follow these instructions can result in equipment damage.

How to Connect the Battery Pack

Step	Action
1	Adjust the battery pack and attach with two cable ties (1).
2	Connect the battery cable (2).

Improperly secured equipment and accessories can cause mechanical damage of PacDrive controller.

CAUTION

BATTERY PACK NOT PROPERLY SECURED

- Use only the supplied cable ties to secure the battery pack (item number VW3E6006).
- Verify that the battery pack is properly secured.

Failure to follow these instructions can result in injury or equipment damage.

The maintenance interval for replacing the battery pack is 3 years. Once this period has expired, you must replace the battery pack.

CAUTION

POSSIBLE DATA LOSS BY POWER OUTAGE

Replace the battery pack at regular maintenance intervals not to exceed 3 years.


Failure to follow these instructions can result in injury or equipment damage.

CAUTION

DAMAGE TO DISPLAY SUPPLY CABLE POSSIBLE

- Do not force the electronic module into the housing.
- Ensure that during installation of the electronic module the display supply cable does not get caught or torn.

Failure to follow these instructions can result in injury or equipment damage.



- 1 Cable ties
- 2 Battery cable
- 3 Display supply cable

How to Connect the Controller

Step	Action
1	Carefully push the electronic module of the controller back into the housing.
2	Tighten the two fastening screws on the front of the controller.
3	Close the operating cover.

Chapter 9

Optional Modules

What Is in This Chapter?

This chapter contains the following sections:

Section	Topic	Page
9.1	Communication Module OM-NE	138
9.2	Communication Module OM-P	147
9.3	Communication Module OM-C	154

Section 9.1

Communication Module OM-NE

What Is in This Section?

This section contains the following topics:

Topic	Page
Overview	139
Initial Installation of the Optional Module	140
Removal of the Optional Module (No Replacement)	142
Replacement of the Optional Module	143
Electrical Connections	144

Overview


Initial Installation

Initial installation of the optional module should only be done by Schneider Electric personnel.

General Information

The OM-NE module is a general communication module which features two Ethernet connectors to realize Ethernet based field bus protocols.

OM-NE module with slot assignment



- 1 Ethernet connection **CN30 (RT Eth P1)**
- 2 Ethernet connection **CN31 (RT Eth P2)**

After installing the optional module, the controller will automatically detect the module. Then configure it by using the controller configuration in SoMachine Motion Logic Builder.

NOTE: Only use OM-NE modules from hardware code 0008 for PacDrive LMC Pro/Pro2 controllers.

Initial Installation of the Optional Module

Required Tools for Initial Installation of the Optional Module

Module part	Tool
Controller front side	Cross slot maximum PH2 alternative PH1; slot maximum 1.2 x 7.0
Backplane and blanking plates on the module sockets	Cross slot maximum PH1

How to Open the Controller

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Open the operating cover of the PacDrive controller upwards.
4	Undo the two fastening screws on the front of the controller.
5	Then remove the electronic module from housing.

NOTICE

INCORRECT INSERTION OF OPTIONAL MODULE

Do not insert the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

How to Install the Backplane

The backplane connects the optional module to the controller.

How to install the backplane:

Step	Action
1	Insert the backplane on the rear of the module shaft into the controller circuit board.
2	Screw the backplane to the three holes provided.

How to Install the Optional Module

The module is ready-to-use when delivered.

You can insert the module into module slot 1 or module slot 2.

How to install the optional module:

Step	Action
1	Select one of the two module slots on the controller.
2	Remove module slot blanking plate.
3	Insert module into open slot.
4	Screw module to module shaft with two M3x6 screws (tightening torque: 0.5 Nm (4.42 lbf in)). Result: The module is now installed.

How to Close the Controller

Step	Action
1	Carefully push the electronic module of the controller back into the housing.
2	Tighten the two fastening screws on the front of the controller.
3	Close operating cover.

Removal of the Optional Module (No Replacement)

Required Tool for Removal of the Optional Module (no Replacement)

Module part	Tool
Module shaft	Cross slot maximum PH1

How to Disassemble the Optional Module

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Undo the two M3x6 screws on the module shaft.
4	Withdraw the module from the cartridge. Result: The module is deinstalled now and the module shaft is empty.
5	Screw the blanking plate onto the empty module shaft. Result: The empty module shaft is closed by the blanking plate.

NOTICE

INOPERABLE EQUIPMENT

Do not remove the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

Replacement of the Optional Module

Required Tool for Replacing the Optional Module

Module part	Tool
Module shaft	Cross slot maximum PH1

How to Disassemble the Optional Module

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Undo the two M3x6 screws on the module shaft.
4	Withdraw the module from the cartridge. Result: The module is deinstalled now and the module shaft is empty.

NOTICE

INOPERABLE EQUIPMENT

Do not remove the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

How to Install the Optional Module

The module is ready-to-use when delivered.

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Insert module into open slot.
4	Screw module to module shaft with two M3x6 screws (tightening torque: 0.5 Nm (4.42 lbf in)). Result: The module is now installed.

NOTICE

INCORRECT INSERTION OF OPTIONAL MODULE

Do not insert the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

Electrical Connections

Connection Details Optional Module OM-NE



CN30/31 - Ethernet outlet

Pin	Designation	Meaning
1	Tx+	Transmit data +
2	Tx-	Transmit data -
3	Rx+	Receive data +
4	-	Reserved
5	-	
6	Rx-	Receive data -
7	-	Reserved
8	-	

NOTE: Operate the EtherNet/IP scanner only by using the connection **CN30 (RT Eth P1)**. The connection **CN31 (RT Eth P2)** is reserved.

NOTE: When using them as EtherCAT slave, the connection **CN30 (RT Eth P1)** represents the input port and the connection **CN31 (RT Eth P2)** the output port. The input port and output port are predetermined by the firmware and cannot be configured.

LED Indicator Description EtherCAT

LEDs EtherCAT master

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Off	Off	The device has no connection to Ethernet.
RJ45 Ch0 & Ch1	yellow LED indicator		
	Yellow	Flashing cyclic with 2.5 Hz	The device sends/receives Ethernet frames.

LEDs EtherCAT slave

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Green	Flashing cyclic with 2.5 Hz	The device sends/receives Ethernet frames.
	Off	Off	The device has no connection to Ethernet.
RJ45 Ch0 & Ch1	yellow LED indicator		
	–	–	The LED indicator is not being used.

LED Indicator Description EtherNet/IP

LEDs EtherNet/IP scanner (master)

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Off	Off	The device has no connection to Ethernet.
ACT/RJ45 Ch0 & Ch1	yellow LED indicator		
	Yellow	Flashes	The device sends/receives Ethernet frames.

LEDs EtherNet/IP adapter (slave)

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Off	Off	The device has no connection to Ethernet.
ACT/RJ45 Ch0 & Ch1	yellow LED indicator		
	Yellow	Flashes	The device sends/receives Ethernet frames.

LED Indicator Description PROFINET

LEDs PROFINET controller

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Off	Off	The device has no connection to Ethernet.
RX/TX/RJ45 Ch0 & Ch1	yellow LED indicator		
	Yellow	Flashes	The device sends/receives Ethernet frames.

LEDs PROFINET device

LED indicator	Color	State	Meaning
LINK/RJ45 Ch0 & Ch1	green LED indicator		
	Green	On	A connection to Ethernet exists.
	Off	Off	The device has no connection to Ethernet.
RX/TX/RJ45 Ch0 & Ch1	yellow LED indicator		
	Yellow	Flashes	The device sends/receives Ethernet frames.

Section 9.2

Communication Module OM-P

What Is in This Section?

This section contains the following topics:

Topic	Page
Overview	148
Initial Installation of the Optional Module	149
Removal of the Optional Module (No Replacement)	151
Replacement of the Optional Module	152
Electrical Connections	153


Overview

Initial Installation

Initial installation of the optional module should only be done by Schneider Electric personnel.

General Information

Another PROFIBUS interface is made available via the OM-P module.



After installing the optional module, the controller will automatically detect the module. Then configure it by using the controller configuration in SoMachine Motion Logic Builder.

Initial Installation of the Optional Module

Required Tools for Initial Installation of the Optional Module

Module part	Tool
Controller front side	Cross slot maximum PH2 alternative PH1; slot maximum 1.2 x 7.0
Backplane and blanking plates on the module sockets	Cross slot maximum PH1

How to Open the Controller

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Open the operating cover of the PacDrive controller upwards.
4	Undo the two fastening screws on the front of the controller.
5	Then remove the electronic module from housing.

NOTICE

INCORRECT INSERTION OF OPTIONAL MODULE

Do not insert the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

How to Install the Backplane

The backplane connects the optional module to the controller.

How to install the backplane:

Step	Action
1	Insert the backplane on the rear of the module shaft into the controller circuit board.
2	Screw the backplane to the three holes provided.

How to Install the Optional Module

The module is ready-to-use when delivered.

You can insert the module into module slot 1 or module slot 2.

How to install the optional module:

Step	Action
1	Select one of the two module slots on the controller.
2	Remove module slot blanking plate.
3	Insert module into open slot.
4	Screw module to module shaft with two M3x6 screws (tightening torque: 0.5 Nm (4.42 lbf in)). Result: The module is now installed.

How to Close the Controller

Step	Action
1	Carefully push the electronic module of the controller back into the housing.
2	Tighten the two fastening screws on the front of the controller.
3	Close operating cover.

Removal of the Optional Module (No Replacement)

Required Tool for Removal of the Optional Module

Module part	Tool
Module shaft	Cross slot maximum PH1

How to Disassemble the Optional Module

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Undo the two M3x6 screws on the module shaft.
4	Withdraw the module from the cartridge. Result: The module is deinstalled now and the module shaft is empty.
5	Screw the blanking plate onto the empty module shaft. Result: The empty module shaft is closed by the blanking plate.

NOTICE

INOPERABLE EQUIPMENT

Do not remove the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

Replacement of the Optional Module

Required Tool for Replacing the Optional Module

Module part	Tool
Module shaft	Cross slot maximum PH1

How to Disassemble the Optional Module

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Undo the two M3x6 screws on the module shaft.
4	Withdraw the module from the cartridge. Result: The module is deinstalled now and the module shaft is empty.

NOTICE

INOPERABLE EQUIPMENT

Do not remove the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

How to Install the Optional Module

The module is ready-to-use when delivered.

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Insert module into open slot.
4	Screw module to module shaft with two M3x6 screws (tightening torque: 0.5 Nm (4.42 lbf in)). Result: The module is now installed.

NOTICE

INCORRECT INSERTION OF OPTIONAL MODULE


Do not insert the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

Electrical Connections

Connection Details Optional Module OM-P

CN33 - PROFIBUS interface



Pin	Designation	Meaning	Range	Maximum cross section
1	PE	Shield	–	0.25 mm ²
2	–	Reserved	–	
3	RxD / TxD -P	Data -P	–	
4	CNTR-P	Control signal P	–	
5	DGND	Signal ground	–	
6	VP	Supply voltage	–	
7	–	Reserved	–	
8	RxD / TxD -N	Data N	–	
9	–	Reserved	–	

Section 9.3

Communication Module OM-C

What Is in This Section?

This section contains the following topics:

Topic	Page
Overview	155
Initial Installation of the Optional Module	156
Removal of the Optional Module (No Replacement)	158
Replacement of the Optional Module	159
Electrical Connections	160


Overview

Initial Installation

Initial installation of the optional module should only be done by Schneider Electric personnel.

General Information

Another CANBUS interface is made available via the OM-C module.



After installing the optional module, the controller will automatically detect the module. Then configure it by using the controller configuration in SoMachine Motion Logic Builder.

Initial Installation of the Optional Module

Required Tool for Initial Installation of the Optional Module

Module part	Tool
Controller front side	Cross slot maximum PH2 alternative PH1; slot maximum 1.2 x 7.0
Backplane and blanking plates on the module sockets	Cross slot maximum PH1

How to Open the Controller

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Open the operating cover of the PacDrive controller upwards.
4	Undo the two fastening screws on the front of the controller.
5	Then remove the electronic module from housing.

NOTICE

INCORRECT INSERTION OF OPTIONAL MODULE

Do not insert the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

How to Install the Backplane

The backplane connects the optional module to the controller.

How to install the backplane:

Step	Action
1	Insert the backplane on the rear of the module shaft into the controller circuit board.
2	Screw the backplane to the three holes provided.

How to Install the Optional Module

The module is ready-to-use when delivered.

You can insert the module into module slot 1 or module slot 2.

How to install the optional module:

Step	Action
1	Select one of the two module slots on the controller.
2	Remove module slot blanking plate.
3	Insert module into open slot.
4	Screw module to module shaft with two M3x6 screws (tightening torque: 0.5 Nm (4.42 lbf in)). Result: The module is now installed.

How to Close the Controller

Step	Action
1	Carefully push the electronic module of the controller back into the housing.
2	Tighten the two fastening screws on the front of the controller.
3	Close operating cover.

Removal of the Optional Module (No Replacement)

Required Tool for Removal of the Optional Module (No Replacement)

Module part	Tool
Module shaft	Cross slot maximum PH1

How to Disassemble the Optional Module

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Undo the two M3x6 screws on the module shaft.
4	Withdraw the module from the cartridge. Result: The module is deinstalled now and the module shaft is empty.
5	Screw the blanking plate onto the empty module shaft. Result: The empty module shaft is closed by the blanking plate.

NOTICE

INOPERABLE EQUIPMENT

Do not remove the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

Replacement of the Optional Module

Required Tool for Replacing the Optional Module

Module part	Tool
Module shaft	Cross slot maximum PH1

How to Disassemble the Optional Module

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Undo the two M3x6 screws on the module shaft.
4	Withdraw the module from the cartridge. Result: The module is deinstalled now and the module shaft is empty.

NOTICE

INOPERABLE EQUIPMENT

Do not remove the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

How to Install the Optional Module

The module is ready-to-use when delivered.

Step	Action
1	Set main switch to OFF position, or otherwise disconnect all power to the system.
2	Prevent main switch from being switched back on.
3	Insert module into open slot.
4	Screw module to module shaft with two M3x6 screws (tightening torque: 0.5 Nm (4.42 lbf in)). Result: The module is now installed.

NOTICE

INCORRECT INSERTION OF OPTIONAL MODULE


Do not insert the optional module when the controller is under power.

Failure to follow these instructions can result in equipment damage.

Electrical Connections

Connection Details Optional Module OM-C

CN34 - CANBUS interface



Pin	Designation	Meaning	Range	Maximum cross section
1	–	Reserved	–	0.25 mm ²
2	CAN_L	Bus line (low)	–	
3	GND	Ground	–	
4	–	Reserved	–	
5	–	Reserved	–	
6	–	Reserved	–	
7	CAN_H	Bus line (high)	–	
8	–	Reserved	–	
9	EXVCC	Ext. supply trans.	–	

NOTE: The connection of the TM5 System to the PacDrive controller can only occur via a Sercos bus interface TM5NS31. A connection of TM5 System via CAN bus and a CANopen interface module is not supported.

Appendices



What Is in This Appendix?

The appendix contains the following chapters:

Chapter	Chapter Name	Page
A	Further Information on the Manufacturer	163
B	Disposal	165
C	Units and Conversion Tables	167

Appendix A

Further Information on the Manufacturer

What Is in This Chapter?

This chapter contains the following topics:

Topic	Page
Contact Addresses	164
Product Training Courses	164

Contact Addresses

Schneider Electric Automation GmbH

Schneiderplatz 1
97828 Marktheidenfeld, Germany
Phone: +49 (0) 9391 / 606 - 0
Fax: +49 (0) 9391 / 606 - 4000
Email: info-marktheidenfeld@schneider-electric.com
Internet: www.schneider-electric.com

Machine Solution Service

Schneiderplatz 1
97828 Marktheidenfeld, Germany
Phone: +49 (0) 9391 / 606 - 3265
Fax: +49 (0) 9391 / 606 - 3340
Email: automation.support.de@schneider-electric.com
Internet: www.schneider-electric.com

Additional Contact Addresses

See the homepage for additional contact addresses:
www.schneider-electric.com

Product Training Courses

Product Training Courses

Schneider Electric offers a number of product training courses.
The Schneider Electric training instructors will help you take advantage of the extensive possibilities offered by the system.
See the website (www.schneider-electric.com) for further information and the seminar schedule.

Appendix B

Disposal

Disposal

Information on the Disposal of Schneider Electric Products

NOTE: The components consist of different materials which can be recycled and must be disposed of separately.

Step	Action
1	Dispose of the packaging in accordance with the relevant national regulations.
2	Dispose of the packaging at the disposal sites provided for this purpose.
3	Dispose of controller in accordance with the applicable national regulations.

Appendix C

Units and Conversion Tables

Units and Conversion Tables

Length

–	in	ft	yd	m	cm	mm
in	–	/ 12	/ 36	* 0.0254	* 2.54	* 25.4
ft	* 12	–	/ 3	* 0.30479	* 30.479	* 304.79
yd	* 36	* 3	–	* 0.9144	* 91.44	* 914.4
m	/ 0.0254	/ 0.30479	/ 0.9144	–	*100	*1000
cm	/ 2.54	/ 30.479	/ 91.44	/ 100	–	* 10
mm	/ 25.4	/ 304.79	/ 914.4	/ 1000	/ 10	–

Mass

–	lb	oz	slug	0.22 kg	g
lb	–	* 16	* 0.03108095	* 0.4535924	* 453.5924
oz	/ 16	–	* 1.942559*10 ⁻³	* 0.02834952	* 28.34952
slug	/ 0.03108095	/ 1.942559*10 ⁻³	–	* 14.5939	* 14593.9
0.22 kg	/ 0.45359237	/ 0.02834952	/ 14.5939	–	*1000
g	/ 453.59237	/ 28.34952	/ 14593.9	/ 1000	–

Force

–	lb	oz	p	dyne	N
lb	–	* 16	* 453.55358	* 444822.2	* 4.448222
oz	/ 16	–	* 28.349524	* 27801	* 0.27801
p	/ 453.55358	/ 28.349524	–	* 980.7	* 9.807*10 ⁻³
dyne	/ 444822.2	/ 27801	/ 980.7	–	/ 100*10 ³
N	/ 4.448222	/ 0.27801	/ 9.807*10 ⁻³	* 100*10 ³	–

Power

–	HP	W
HP	–	* 746
W	/ 746	–

Rotation

–	min ⁻¹ (rpm)	rad/s	deg./s
min ⁻¹ (rpm)	–	* $\pi / 30$	* 6
rad/s	* $30 / \pi$	–	* 57.295
deg./s	/ 6	/ 57.295	–

Torque

–	lb•in	lb•ft	oz•in	Nm	kp•m	kp•cm	dyne•cm
lb•in	–	/ 12	* 16	* 0.112985	* 0.011521	* 1.1521	* $1.129 \cdot 10^6$
lb•ft	* 12	–	* 192	* 1.355822	* 0.138255	* 13.8255	* $13.558 \cdot 10^6$
oz•in	/ 16	/ 192	–	* $7.0616 \cdot 10^{-3}$	* $720.07 \cdot 10^{-6}$	* $72.007 \cdot 10^{-3}$	* 70615.5
Nm	/ 0.112985	/ 1.355822	/ $7.0616 \cdot 10^{-3}$	–	* 0.101972	* 10.1972	* $10 \cdot 10^6$
kp•m	/ 0.011521	/ 0.138255	/ $720.07 \cdot 10^{-6}$	/ 0.101972	–	* 100	* $98.066 \cdot 10^6$
kp•cm	/ 1.1521	/ 13.8255	/ $72.007 \cdot 10^{-3}$	/ 10.1972	/ 100	–	* $0.9806 \cdot 10^6$
dyne•cm	/ $1.129 \cdot 10^6$	/ $13.558 \cdot 10^6$	/ 70615.5	/ $10 \cdot 10^6$	/ $98.066 \cdot 10^6$	/ $0.9806 \cdot 10^6$	–

Moment of Inertia

–	lb•in ²	lb•ft ²	kg•m ²	kg•cm ²	kg•cm ² •s ²	oz•in ²
lb•in ²	–	/ 144	/ 3417.16	/ 0.341716	/ 335.109	* 16
lb•ft ²	* 144	–	/ 3	* 0.30479	* 30.479	* 304.79
kg•m ²	* 3417.16	/ 0.04214	–	* 0.9144	* 91.44	* 914.4
kg•cm ²	* 0.341716	/ 421.4	/ 0.9144	–	* 100	* 1000
kg•cm ² •s ²	* 335.109	/ 0.429711	/ 91.44	/ 100	–	* 10
oz•in ²	/ 16	/ 2304	/ 54674	/ 5.46	/ 5361.74	–

Temperature

–	°F	max	K
°F	–	$(°F - 32) * 5/9$	$(°F - 32) * 5/9 + 273.15$
max	$°C * 9/5 + 32$	–	$°C + 273.15$
K	$(K - 273.15) * 9/5 + 32$	$K - 273.15$	–

Conductor Cross-section

AWG	1	2	3	4	5	6	7	8	9	10	11	12	13
mm ²	42.4	33.6	26.7	21.2	16.8	13.3	10.5	8.4	6.6	5.3	4.2	3.3	2.6

AWG	14	15	16	17	18	19	20	21	22	23	24	25	26
mm ²	2.1	1.7	1.3	1.0	0.82	0.65	0.52	0.41	0.33	0.26	0.20	0.16	0.13



B

bending cycles, *47*

C

certifications, *125*
climatic, *42*
condensate, *43*
contact addresses, *164*
cooling units, *43*

D

daisy chain connector box, *28*
daisy chain wiring, *28*
degree of protection, *41*
domestic appliances, *20*

F

floating systems, *20*

H

hazardous, explosive atmospheres, *20*
homepage, *164*

I

intended use, *8*
IP, *41*

L

life support system, *20*

M

machine grounding, *46*
mechanical, *42*

minimum bending radius, *47*
minimum cross sections, *46*
mobile systems, *21*

P

portable systems, *21*
product related information, *16*

Q

qualification of personnel, *8*

S

seminars, *164*
service addresses, *164*

T

temperature limit, *43*
training courses, *164*

U

underground, *20*

W

wiring, *46*