

Vigilohm System


XM300C

XML308 / XL308

XML316 / XL316

Permanent insulation monitoring

User's manual



Content

introduction..... page 3

**description
of your device..... page 3**

**discover
your device..... page 4**

- protect the quality of your device
- identify your device
- check the content of the parcel

**install
your device..... page 5**

- systems to be monitored
- interfaces to use
- dimensions
- cutouts
- precautions
- securing
- use the specific accessories for mounting in Prisma P cabinet
- connect your XM300C
- connect your XML308 or XML316
- connect your XL308 or XL316
- identify your feeders
- wiring rules
- installing a device on an already operational network
- toroid wiring
- wiring circuit
- breaker position contacts
- wiring precaution
- electrical data
- auxiliaries

address your device page 12

- communication
- addressing your device
- determining the address
- precaution

commissioning page 13

- take care
- presentation of the front panel
- switching on
- self-test

**determine your operating
thresholds page 15**

- definitions (Tp,Td, Iomax, Risol,...)
- thresholds settings
- setting coherence

monitor your network page 16

- introduction
- operation
- safety operation
- operating example

**operate
your XM or XML..... page 20**

- operating page 20
- menu block diagram page 20
- screen block diagram page 21
- initial status screen page 22
- screen description..... page 24

- description of main menu
- description of local CPI parameters menu
- description of internal XL screens
- description of visu alarm screens
- description of the system state screens
- communication page 26**
- communicate in english
- test the state of your device

- local CPI Visualization..... page 28
- local CPI alarm threshold description
- local CPI prevent threshold description
- local CPI intermittent faults visualization and reset

- network capacitance visualization
- internal localizer visualization ... page 32
- internal localizer alarms visualization
- internal localizer intermittent faults visualization and reset
- internal localizer threshold visualization
- internal localizer R and C visualization
**- localizer piloted by the PI
visualization page 36**

- intermittent faults and alarms visualization
**- failure and device status
visualization..... page 37**
- failure messages visualization
- system status visualization

**set the parameters of
your XM or XML..... page 39**

- modification page 40
- description of the CPI parameters modification menu screens
- fault threshold modification
- self-setting
- date/hour modification
- address and transmission rate of the interface JBUS
- voltage frequency modification
- password modification
- internal XL parameters modification

operate your XL..... page 47

- use of the XL keyboard
- display state
- visualization
- modification
- signalling
- clearing intermittent faults

**problems
during the self test page 50**

- follow this procedure
- identification of error messages

any problems? page 52


- seek out the cause

introduction


This manual regroups the information on the three types of devices forming the **Vigilohm System** series.

description of your device


type: **XM300C**
function: communicating **CPI**
principle: ensures overall insulation monitoring by continually measuring the insulation resistance value and the earth coupling capacitance of the network.
Enables interchange with devices of the **Vigilohm system** series. (XM, XML, XL).



type: **XML308 / 316**
function: communicating **CPI**
principle: + 8 / 16 channel **localizer**
ensures overall insulation monitoring by continually measuring the insulation resistance value and earth coupling capacitance of the network.
Enables interchange with devices of the **Vigilohm system** series (XM, XML, XL).
The localizer part continually measures the insulation resistance value and earth coupling capacitance of each monitored feeder.




type: **XL308 / 316**
function: 8 / 16 channel **localizer**
principle: associated with a CPI (XM300C or XML), ensures local insulation monitoring by continually measuring the insulation resistance value and earth coupling capacitance of each monitored feeder.




discover your device

protect the qualities of your device prior to installation



identify your device



- ① commercial reference
(see table below)
- ② commercial name
- ③ manufacturing code
- ④ auxiliary supply


example:

- ① commercial reference: **50541**
(see opposite table)
- ② commercial name: **XM300C**
- ③ manufacturing code: n/a
- ④ auxiliary supply: **220 V/240 V AC**


auxiliary supply	ref. XM300C	ref. XML316	ref. XML308	ref. XL308	ref. XL316
AC 50 / 60 Hz					
115 V / 127 V AC	50540	50490	50322	50606	50615
220 V / 240 V AC	50541	50491	50323	50607	50616
380 V / 415 V AC	50542	50492	50324	50608	50617

check the content of the parcel


1- pull-out drawer containing a simplified keyboard / screen operating manual










2- user's manual



3- device address and feeder locating table



4- connectors

	 output relays 9 points	 auxiliary supply 3 points	 earth faston terminal	 system 2 points	 BUS 4 points	 toroids 16 points	 circuit-breaker contact 3 points
XM300C	1	1	1	1	1	0	1
XML308	1	1	1	1	1	1	1
XML316	1	1	1	1	1	2	1
XL308	1	1	1	0	1	1	0
XL316	1	1	1	0	1	2	0

install your device


systems to be monitoring

- alternating or mixed system with ungrounded neutral or grounded by impedance of the ZX type.
phase to phase voltage:
available neutral < 760V*~
unavailable neutral < 440V*~
frequency 45 - 1000 Hz


- ungrounded DC or rectified system.
phase to phase voltage < 500V ~

* for higher voltage, use an additional plate PHT 1000 (consult our catalogue).




U < 760V ~



U < 440V ~



U < 500V ~



Interfaces to use


		type of system to be monitored (device number)		
		1 XL or 1 XM	XM or XML ≤ 4 and XL ≤ 8	
			with coupling	without coupling
communication function	link to printer	XLI300 + supervisor	XLI300 + supervisor	XTU300 + supervisor
	JBUS link	XLI300	XLI300 ¹	XTU300 ²
		nothing	XAS ³	XTU300

- XPI300: printer interface
- XLI300: supervisor interface.
- XTU300: supervisor interface (busbar coupling).
- XAS: Bus supply box (if no XLI 300, XPI 300, XTU 300).


interface references

aux. supply	ref. XPI 300	ref. XLI 300	ref. XTU 300	ref. XAS
115-127 V	50525	50515	50545	50520
220-240 V	50526	50516	50546	50521
380-415 V	50527	50517	50547	50522
500-525 V	50528	50518	50548	50523

1 without coupling




2 with coupling



3 without coupling

- no communication with outside without interface









install your device

XM 300C




XML 308 / 316

XL 308 / 316

dimensions



cutouts





precautions


■ respect the distances between devices

■ mount the devices horizontally



note: to ensure a good legibility of display, it is best to place the device at least 1 m 70 from the ground.



securing



dismantling



install your device

use the specific accessories for mounting in Prisma P cabinet

XM 300C





plate
reference:
07642

front cover
reference:
07972

securing accessories: 2 supports + 4 crosspieces
reference: **07619**

■ for further information, consult the Prisma P design block catalogue.
ref: **01302**



① - DIN rail for mounting Multi 9 type box.

■ **front cover configuration:**

- 1 XM300C + 3 XD301 or
- 1 XM300C + 2 XD312 or
- 1 XM300C + 1 XD301 and 1 XD312

XML 308 / 316 - XL 308 / 316





plate
reference:
07643

front cover
reference:
07973

shutter

securing accessories: 2 supports + 4 crosspieces
reference: **07619**

■ for further information, consult the Prisma P design block catalogue.
ref: **01302**




■ **front cover configuration:**

- 1 XML 308 / 116 or XM300C + 2 interfaces (XTU300, XLI300, XPI300, XAS type)
- 1 XML 308 / 316 or XM300C + 1 XL308 or XL316


install your device

connect your XM300C



terminal n°	function
4-5-6	prevention setting relay
7-8-9	1 st fault setting relay
10-11-12	2 nd failsafe fault setting relay. The relay is de-energized if a fault occurs, in the case of accidental loss of auxiliary supply voltage or should the device breakdown.
1-2	auxiliary supply
13	device frame grounded
14	system / neutral or phase
15-16-17-18	Bus communication output
19-20-21	circuit-breaker position contact inputs
	code wheel / addressing

connect your XML308 or XML316




terminal n°	function
4-5-6	prevention setting relay
7-8-9	1 st fault setting relay
10-11-12	2 nd failsafe fault setting relay. The relay is de-energized if a fault occurs, in the case of accidental loss of auxiliary supply voltage or should the device breakdown.
1-2	auxiliary supply
13	device frame grounded
14	system / neutral or phase
15-16-17-18	Bus communication output
19-20-21	circuit-breaker position contact inputs
	code wheel / addressing

A- toroid wiring for 8 channel devices (XML308, XL308).

B- toroid wiring for 16 channel devices (XML316, XL316).

connect your XL308 or XL316



terminal n°	function
7-8-9	1 st fault setting relay
10-11-12	2 nd failsafe fault setting relay. The relay is de-energized if a fault occurs, in the case of accidental loss of auxiliary supply voltage or should the device breakdown.
1-2	auxiliary supply
13	device frame grounded
15-16-17-18	Bus communication output
	code wheel / addressing
A- toroid wiring for 8 channel devices (XML308, XL308).	
B- toroid wiring for 16 channel devices (XML316, XL316).	

install your device


Identify your feeders

■ A self-adhesive label, provided with your operating manual enables you to identify your feeders.


Schneider Electric Vigilohm System		adresse / 31 address
tor 1: escalator 1	tor 9:	
tor 2: electric oven 1	tor 10:	
tor 3: electric oven 2	tor 11:	
tor 4: electric oven 3	tor 12:	
tor 5: air conditioning 1	tor 13:	
tor 6: desk 1 st step	tor 14:	
tor 7: escalator 2	tor 15:	
tor 8: escalator 3	tor 16:	

wiring rules


■ communication bus: we recommend precaution you make a loop



■ precaution




connect the shield to a device frame at one end only. (preferably with the interface, in this case XAS).



■ maxi. wiring length:



the limit length to be respected is the maximum length of the loop.




■ Capacity between ligne must be less than 100 nF.

■ Total resistor must be less than 12 Ω.

diagram 1: 4 cable wiring



connection detail




- 1- shield
- 2- 0.35 mm² wire welded at shield
- 3- thermoretractable sleeve

installing a new device on an operational system

■ Without XTU300, the system automatically takes into account the presence of a new device.


■ You can add a device in a system with XTU 300, if the device has been taken into account in XTU programming.



install your device

toroid transformer

XML308 / 316 - XL308 / 316



- cable to be used
2 conductors shielded cable
L max: 100 m

L (m)	ref.
20	50137
100	50136

nota: do not use the shielding.

toroids to be used

compatible toroids (if you are already equipped with).

■ A toroids range

dia. type	mm	ref.
TA30	30	50437
PA50	50	50438
IA80	80	50439
MA120	120	50440
SA200	200	50441
GA300	300	50442

■ OA opening toroids range

dia. type	mm	ref.
POA	46	50485
GOA	100	50486

■ XS toroids range

dia. type	mm	ref.
XS30	30	50420
XS50	50	50421
XS80	80	50422
SX120	120	50423
SX200	200	50424

■ N toroids range

dia. type	mm	ref.
TN30	30	50105
PN50	50	50106
IN80	80	50107
MN120	120	50108
SN200	200	50109

circuit-breaker position contacts

XM300C - XML308 / 316


wiring

- 1st case:
only 1 CPI: no position contact required (these inputs only function when there is a XAS, XLI300, XPI300 or XTU300 interface).


cable to use:
section: $\geq 0.75 \text{ mm}^2$ and $\leq 1.5 \text{ mm}^2$
Lmax = 300 m
simple twisted cable

note: for operating mode by changing circuit - breaker position, see interface manual (XLI300, XTU300).

- 2nd case:
you have 1 XTU300 or 1 XCU10




- 3rd case:
you have 1 XLI300 or 1 XPI300 or 1 XAS




Maxi time between closing switch I1 and switch I2: 200 ms

XM300C - XML308 / 316 - XL308 / 316



wiring precautions



distance to respect



cable cross section to be used



- do not secure the stands on the device.

install your device

electrical data

breaking capacity of output contacts

CA 380v cos. $\varphi = 0.7$	3 A
CA 220v cos. $\varphi = 0.7$	5 A
CC 220v L/R = 0	0.45 A
CC 120v L/R = 0	0.65 A
CC 48v L/R = 0	2.5 A
CC 24v L/R = 0	10 A

auxiliary supply

auxiliary supply operating range	0.85 - 1.1 U_n
frequency	45 - 65 Hz
rush current on switch-on	1.5 A
maxi. own consumption	40 VA

connection to system

measuring voltage (2.5 Hz)	5 V Eff
measuring current	5 mA
50 Hz impedance	20 k Ω
DC resistance	20 k Ω

auxiliary contacts of circuit breaker

contact voltage	24 V
maxi current	10 mA
maxi loop resistance	50 Ω

standards (UTE C63-080)

- protection index IP 30
- protection index front panel: IP40
- operating temp. -5 C° to +50 C°
- vibration withstand IEC 68 - 2 - 6
 - amplitude: 0.075 mm or 2 g
 - frequency: 10 to 65 Hz
 - 5 sweepings per axis
- climatic conditions: (tropicalization type T2)
 - damp heat: 55 C°, 95 % relative humidity, 6 cycles (according to standard IEC 68-2-30)
 - salt spray: 5 % Na Cl, 48 hours, 3 months storage (according to standard IEC 68-2-11)

auxiliaries

Cardew C

■ principle:

Connected to the secondary of the HV/LV transformer on an ungrounded or impedance-grounded neutral system, it protects LV installations against overvoltage hazards. It clips weak overvoltages and drains off to the ground the high energy resulting from internal breakdown of the transformer or from atmospheric phenomena. It can withstand the transformer short-circuit current.

■ standard:

N.F.C. 63-150
N.F. C 15-100
Compulsory in France and in certain countries.

■ connection:

By cable or busbar, the cross section of which is calculated according to the power P of the transformer (IEC and UTE standard).

■ reference

base	50169
cardew C 250 V	50170
cardew C 440 V	50171
cardew C 660 V	50172
cardew C 1000 V	50173

Cardew C base




plate ZX

■ principle:

limitation impedance. Creates an impedance-grounded neutral.

- impedance: 1 500 Ω to 50 Hz
100 000 Ω to 2.5 Hz

■ reference: 50159

plate ZX 1 kg




plate PHT1000

■ principle:

With the plate PHT 1000, you can use your CPI on networks:

- accessible neutral 760 V < U between phases < 1700 V
- unaccessible neutral 440 V < U between phases < 1000 V
- direct current network 500 V DC < U < 1200 V DC

■ reference: 50248

■ connection:





plate PHT1000



address your device


communication

Communication is ensured by means of a BUS. All exchanges transit via the BUS and enable the devices to intercommunicate.

note: The device protocol is of the "random access" type and all the devices in the system must be addressed

addressing your device


The code wheel found on the rear panel of each device is used to address the devices.



determining the address

	device addressing			
	XM300C	XML308 / 316		XM300C
		CPI	localizer	
<p>fixe →</p>	1	1	2	3
	1 to 4	1 to 4	takes the value of the CPI see example	1 to 8

example:
The second figure in the address of the XML localizer part is implicitly fixed at the value chosen for the CPI part.



precaution




Two CPI (XM300C and XML) or two localizers cannot have the same address.

note: this type of anomaly is not detected and results in malfunctioning.


example	XM300C	XML308	XL308	XL308
address				

commissioning

take care

XM300C - XML308 / 316	XL308 / 316
<p>When conducting the dielectric test (of the assembly in which your device is mounted), terminals 1, 2 and 14 must absolutely be disconnected. After the dielectric test, reconnect terminals 1, 2 and 14, then switch on.</p>	<p>When conducting the dielectric test (of the assembly in which your device is mounted), terminals 1 and 2 must absolutely be disconnected. After the dielectric test, reconnect terminals 1 and 2, then switch on.</p>
<p>before switching on, ensure:</p> <div style="display: flex; align-items: center;"> <div style="flex: 1;"> <p>1 - the voltage coherence of your device.</p>  </div> <div style="flex: 1; margin-left: 20px;"> <p>2 - that all the devices are correctly addressed.</p> <p>3 - that the wiring of both the communication BUS and the toroids is correct.</p> </div> </div>	

presentation of the front panel




1. self-diagnostic red indicator light. Reports CPI internal failures.
2. orange indicator light. Reports presence of intermittent faults.
3. "correct insulation" green indicator light.
4. luminous scale. Reports an insulation drop. The number of indicator lights on is proportional to the insulation drop.
5. "insulation fault" red indicator light.
6. pull-out drawer containing an operating manual.
7. interchange keys
8. sealable cap (locking of settings)
9. screen displaying operating measurements and parameters.

I: zone displaying the various screens to be visualized or modified.

II: interchange zone, giving the function of each key.

10. Orange indicator light. Reports presence of intermittent faults.
11. visualization of the insulation state of each feeder:
 - green light "correct insulation"
 - orange light not used
 - red light "insulation fault"
12. Indicator lights locating the faulty feeder.



1. self-diagnostic red indicator light. Reports XL internal failures.
2. orange indicator light. Reports presence of intermittent faults.
3. visualization of the insulation state of the feeders:
 - green indicator light "correct insulation".
 - orange indicator light "insulation drop".
 - red indicator light "insulation fault".
4. pull-out drawer containing an operating manual.
5. sealable cap (locking of settings)
6. interchange keys
7. lights indicating the measurements displayed:
 - Ω \emptyset - Ω \neq μF
 - ○ ○ ○ ○ → display of capacity value in μF
 - ○ ○ ○ ○ → display of intermittent faults in $k\Omega$
 - ○ ○ ○ ○ → display of fault settings in $k\Omega$
 - ○ ○ ○ ○ → not used
 - ○ ○ ○ ○ → display of insulation resistance of feeder in $k\Omega$
8. Measurement display screen
9. Indicator lights locating the faulty feeder.

switching on

Whatever the order in which the devices are switched on, they all carry out their self-test and communicate with the others to inform them of their presence on the system.

System consideration time:

- switching on of all the devices at the same time: **1 mn 06 s**

- addition of a localizer to a system already switched on: **1 mn 06 s**

- addition of a toroid on a localizer:

Briefly switch off the auxiliary supply of the device in question and wait for the end of the autotest.

self-test

This self-test enables the internal electronics of your device to be tested.


The self-test is carried out for each device:

- each time the device is switched on (without relay)

- every 6 hours (without relay)

- on the operator's request (with or without relay).

note: the values displayed on the screens shown in this manual are purely fictitious and act as a guide only.



If you have a problem during the autotest, follow the instructions on pages 52 and 53.

determine your operating thresholds

definitions

Tp: "prevention" insulation threshold beneath which an alarm is tripped to warn the maintenance department. Tp is determined according to the lowest insulation level authorized before intervention. Bear in mind that insulation reduction depends on:

- the quality of the insulating materials and the design of the installation, switchgear and receivers.
- the age of the network.
- the severity of the network environment (dust, humidity, overvoltage...)

Td: "fault" insulation threshold . Td is determined by the maintenance department (in agreement with the monitoring organization). When overshoot, it trips a general alarm (Maintenance Department + Operator) without causing operation to shut down. The maintenance department must then take immediate action to locate and clear the fault (if a second fault were to occur between the general alarm and clearance of the first fault, the installation would be automatically switched off and the service continuity objective wouldn't be achieved).

Io max: maximum earth leakage current tolerable in the installation (resistive current + capacitive current).

Risol: insulation resistance measured by the CPI.

Intermittent fault: faults disappearing before clearing (by "reset" button) are known as intermittent faults. Intermittent faults are stored and can be consulted. An orange indicator light on the front face indicates that a intermittent fault is stored.

pilot CPI: the CPI pilots localizers when it injects on the installation part where they are located (XL).

threshold settings

Each CPI has a fault threshold and a prevention threshold. All the localizer feeders (XL or XML) only have a fault Threshold .

- presetting **Tp** in the plant

Td = 30 kΩ

Tp setting tip

Tp = 0.8 x Risol
Tp > 1.1 Sd

- presetting **Td** in the plant

Td = 02 kΩ

Td setting tip

The optimal setting value is 1 kΩ because this value is compatible with the XD detection function.

- CPI threshold setting range (XM and XML)

- Td setting range for XL

- read range for the insulation resistance measured by the device:

CPI (XM XML): from 0.1 kΩ to 999 kΩ

XL: from 0.1 kΩ to 300 kΩ

Td: from 0.2 kΩ to 99.9 kΩ

Tp: from 1 kΩ to 300 kΩ


Td: from 0.2 kΩ to 99.9 kΩ

setting coherence

- We recommend you set all the fault thresholds to the same value, except if there are other specifications.

- Use the self-setting function to set at the same time all the fault and prevention thresholds to the same value (see page 41).


special cases 1st case



The fault threshold on a XL feeder is lower than the fault Threshold of the continuous insulation monitor:

- **consequence:**
If the fault lies between the two fault thresholds, only the CPI reports the fault.

2nd case



The fault threshold on a XL feeder is greater than the fault threshold of the continuous insulation monitor.

- **consequence:**
If the fault lies between the two fault thresholds, the CPI does not report the fault.

monitor your network

introduction

The Vigilohm System devices (XM300C - XML 308/316 - XL308/316) enable you to measure permanently the insulation resistance and the earth coupling capacitance of your network.

Why measuring the resistance between your network and earth?


When your network insulation is degrading, it is your network insulation resistance which is growing down, that's why it important to measure it permanently.

Why measuring the earth coupling capacitance?

If your network earth coupling capacitance is too high, it could be an important risk factor for your network.


Example:

A total capacitance of $50 \mu\text{F}$ equals to a capacitive impedance of 65Ω (at 50 Hz).
In case of insulation fault, this capacitance enables differential current circulation which can damage your network.



Limit your network capacitance impedance

On high capacitive feeder, segment your fault search.



configuration 1

configuration 2


If your total capacitance is higher than $15 \mu\text{f}$, use the 2nd configuration.

(A too important differential current ($> 3 \text{ A}$) may degrade localizer performances).


monitor your network

operation

■ The CPI injects permanently a 2.5 Hz voltage and measures the insulation resistance of the network. The localizer (XL part of XML or XL) is in continuous communication with the CPI and measures the insulation resistance of each feeder.



■ When the communication BUS connection is cut or when the CPI is faulty and thus stops communicating with the localizer (XL part of XML or XL), the latter changes over to **safety operation**. So as to avoid breakdown risks, we recommend you use loop wiring.



response time: time required between two measurements:

■ CPI

XM300C:	10 seconds
XML:	15 seconds

■ XL localizer:

$$TR = (10 \text{ sec.}) \times N^*$$

so the maximum time is:

XL308: 10 sec. x 8 = 1 mn. 20 sec.
XL316: 10 sec. x 16 = 3 mn. 7 sec.

* N is the number of toroid connected

■ XML localizer:

$$TR = (15 \text{ sec.}) \times N^*$$

so the maximum time is:

XML308: 15 sec. x 8 = 2 mn.
XML316: 15 sec. x 16 = 4 mn.

* n is the number of toroid connected

safety operation

The localizer is in this status for 2 raisons:

- the CPI is faulty: in this case, the CPI has to be repaired
- the communication bus is cut: check out the wiring


XM300C - XML308 / 316

consequence on the display

■ visualization of localizer fault setting of your XML.

the final screen becomes:


Threshold detector mode
Th = 02 kΩ
quit quit



The value of Td is automatically set at 2 kΩ.

■ visualization of R and C and modification of the fault setting of your internal localizer are not possible. The localizer part of your XML operates like a XD301 or XD312. It detects the current injected by the CPI and signals if the feeder is on fault. The final screen becomes:


DETECTOR MODE
quit quit



XL308 / 316


consequence on the display

■ when a localizer is in the detector mode all the fault settings are set to 2 kΩ, the screen becomes:



In this case, the localizer operates like a XD301/XD312 and compares the value of the current with a given setting (2 kΩ).

■ in the insulation visualization mode, the screen becomes:




Note: this operation mode is not the normal one and needs a checking of the system (see page 52).


operating examples

example 1: prevention threshold overshooting followed by alarm threshold overshooting


legend:  led lit up



screen visualization / status of XM 300 or XML 308 / 316 indicators and relays status





status of XL indicators and relays




monitor your network


operating examples

example 2: intermittent fault appearance and disappearing


legend:  led lit up
 led flashing



screen visualization / XM 300 or XML 308 / 316 indicators and relays status



XL indicators and relays status




operate your XM or XML


operating

The communication with your device is executed with unidirectional scroll menus. The key \wedge enables you to obtain the different possible options. The key ok enables you to valid your move in the menu block diagram. When no key is pressed, your device present you an initial status screen (see description page 22).

password
self setting
date / hour
interface
f(Hz) ,w Un(v)
language




menu block diagram



operate your XM or XML

screen block diagram



operate your XM or XML


initial status screen

Without using keyboard, the device informs you of its status. The next screens are possible:

- display of the system insulation resistance value
- display of fault presence on the system
- display of prevent alarm on the system
- display of fault presence on the system without CPI detection
- display of temporary exclusion of the system.

display of the system insulation resistance value



This configuration is normal there is no insulation fault on the network.




display of insulation fault on the network

This screen signals that a fault has appeared on the network. The insulation resistance value is:

$$R_{isol} < T_d$$



give the value of the adjusted settings.





de-energizes T_p , T_d and failsafe relays.


display of prevent threshold overshooting

This screen signals that the insulation resistance value R_{isol} is between the 2 threshold values T_d and T_p .

$$T_d < R_{isol} < T_p$$



give the value of the adjusted settings.




de-energizes the prevention relay.

operate your XM or XML


initial status screen

fault reported on a feeder although the CPI does not detect any fault



display of tempory exclusion

This screen signals that your device is excluded. Another CPI injects on the network. You can have access to the menu.




operate your XM or XML

To improve understanding of the operation of your device, do not forget to refer to the menu block diagram on page 20, when faced with **writing on black background**.


description

main menu description

Using the main menu you can visualize the information relating to the CPI and the other system products (XL, XML).



main menu screens



description of local CPI parameters menu screens

parameter to be validated	screen visualized	comments
local CPI parameters menu > fault threshold	fault th. kΩ aa/mm/jj hh H mn ok quit	display of fault setting value (see p 28).
> prevent threshold	prevention th. kΩ aa/mm/jj hh H mn ok quit	display of the prevention threshold value (see p 29).
> capacitance	line capacitance in μF ok quit	display of the network capacitance (see p 31).
> intermit. fault	1 kΩ : mn 2 kΩ : mn 3 kΩ : mn ok hour	display of the last three intermittent faults. If XTU 300, XLI 300 or XPI 300 exists, the date and hour of faults are displayed (see p 30).
> date / hour	date hour aa/mm/jj hh H mn aa/mm/jj hh H mn ok quit	display of date and hour. See page 42 to enter date and hour.
> input / relay	input relay I1=01 I2=0/1 RP=0/1 RD=0/1 RS=0/1 ok quit	display of relay position and circuit-breaker position output status (prevention, fault, failsafe).

operate your XM or XML

description of internal XL screens

parameter to be validated	screen visualized	comments
XL internal parameters menu > R (kΩ) , C (μF)	measures toroid: ... R = kΩ C = μF tor. quit	visualization of resistance and capacitance of each feeder. See page 35
> threshold	threshold toroid: ... Td = kΩ tor. quit	Visualization of fault threshold for each feeder (see page 34).
> alarms	fault toroid: ... R = kΩ aa/mm/jj hh H mn tor. quit	Visualization of fault resistance for each feeder (see page 32).
> intermit. fault	intermit. toroid: ... R = kΩ aa/mm/jj hh H mn tor. reset	Visualization of intermittent faults on all feeders (see page 33).

description of alarm visu screens

parameter to be validated	screen visualized	comments
main menu > alarms visu	alarm XL ... T ... R = kΩ aa/mm/jj hh H mn ok quit	visualization of fault resistance (fault / device and toroid), see page 36 ex: XL31 TO1. If XTU 300, XLI 300 or XPI 300 exist, the date and hour are displayed.
	intermittent XL ... T ... R = kΩ aa/mm/jj hh H mn ok reset	visualization of intermittent faults (fault / device and toroid). If XTU 300, XLI 300 or XPI 300 exists, date and hour of occurrence of the intermittent faults are displayed.

description of the system state screens

parameter to be validated	screen visualized	comments
main menu > system status	system modif X... (PI - LI - TU) inhibited ok quit	visualization of the inhibited interface (see page 38). ex: if there are 2 interfaces on the same system, the system automatically inhibits one interface (order of priority: XTU 300, XLI 300).
	system modif X... (M-ML-L-PI-LI-TU-XCU10) has disappeared ok quit	visualization of the products which, during operation, no longer reply. ex.: supply loss, Bus cut off, device failure.
	system modif XL... TOROID has disappeared ok quit	visualization of the toroids which no longer reply, plus the device on which it occurred ex: XL32 TOROID 02.

operate your XM or XML


COMMUNICATION

communicate in English with your XM300C ou XML308/ 316

The device you have just installed is programmed in French. You can easily program it in English using the modification screen.

1

MAIN SCREEN




HAVE ACCESS TO THE MAIN MENU

1X

2

MAIN MENU




HAVE ACCESS TO THE MODIFICATION MENU

1X

3

CPI PARAMETERS MODIFICATION MENU




SELECT "langue"

7X

4

CPI PARAMETERS MODIFICATION MENU




VALIDATE YOUR CHOICE

1X

5

LANGUAGE MENU




SELECT "Anglais" AND VALIDATE

1X

6

CPI PARAMETERS MODIFICATION MENU




QUIT

1X

**COMMUNICATE
IN ENGLISH
WITH YOUR
XM300C OR
XML308/316**

COMMUNICATION

test the state of order of your device



VISUALIZATION

local CPI visualization

local CPI fault threshold visualization Td

1

MAIN SCREEN

insulation
R = 040 kΩ
test menu

HAVE ACCESS TO THE MAIN MENU

1X

2

MAIN MENU

quit
> XM visu
alarms visu
ok ^ mod

VALIDATE "XM visu" AND
VALIDATE YOUR CHOICE

1X

3

LOCAL CPI PARAMETERS MENU

quit
> capacitance
fault th.
ok ^

SELECT "fault th."

1X

4

LOCAL CPI PARAMETERS MENU

capacitance
> fault th.
prevent th.
ok ^

VALIDATE YOUR CHOICE

1X

5

VISUALIZATION OF THE FAULT THRESHOLD

fault th.
>2 kΩ < mA
aa/mm/jj/ hhHmm
ok quit

VISUALISE
If U and F have been entered, the value of the maxi leakage current flowing in the fault in absence of unbalanced capacity, is displayed. If XTU 300, XPI 300 or XLI 300 exists, date and hour of threshold modification are displayed.

6

VISUALIZATION OF THE FAULT THRESHOLD

fault th.
2 kΩ < mA
aa/mm/jj/ hhHmm
ok quit

date/hour
quit
> capacitance
ok ^

QUIT

1X 2X

**LOCAL CPI
FAULT
THRESHOLD
VISUALIZATION
Td**

VISUALIZATION

local CPI visualization

local CPI prevention threshold visualization

1

MAIN SCREEN

insulation
R = 040 kΩ
test menu

HAVE ACCESS TO THE MAIN MENU

2

MAIN MENU

quit
> XM visu
alarms visu
ok ^ mod

SELECT "XM visu" AND VALIDATE

3

LOCAL CPI PARAMETERS MENU

quit
> capacitance
fault th.
ok ^

SELECT "prevent th."

4

LOCAL CPI PARAMETERS MENU

fault th.
> prevent th.
intermit. fault
ok ^

VALIDATE YOUR CHOICE

5

PREVENT THRESHOLD MENU

fault th.
> 30 kΩ
aa/mm/jj hh:mm
ok ^

VISUALISE
If XTU300, XPI300 or XLI300 exists, date and hour of threshold modification are displayed.

6

PREVENT THRESHOLD MENU

prevent th.
30 kΩ
aa/mm/jj hh:mm
ok ^

date/hour
quit
> capacitance
ok ^




QUIT

**LOCAL CPI
PREVENT
THRESHOLD
VISUALIZATION**
Tp

VISUALIZATION

local CPI visualization


local CPI intermittent faults visualization and reset



VISUALIZATION

local CPI visualization

network capacitance visualization




VISUALIZATION

Internal localizer visualization

internal localizer alarms visualization

1

MAIN SCREEN




insulation
R = 040 kΩ
test menu

HAVE ACCESS TO THE MAIN MENU

1X

2

MAIN MENU




quit
> XM visu
alarms visu

SELECT "internal XL"

2X

3

MAIN MENU




alarms visu
> internal XL
system status

VALIDATE YOUR CHOICE

1X

4

INTERNAL XL PARAMETERS MENU




quit
> alarms
intermit. fault

SELECT "alarms"
AND VALIDATE YOUR CHOICE

1X

5

INTERNAL XL ALARMS VISUALIZATION




fault tor.: 01
R = 01.0 kΩ
tor. quit

VISUALISE

1X — visualise the other fault

6

INTERNAL XL ALARMS VISUALIZATION



fault tor.: 01
R = 01.0 kΩ
tor. quit

QUIT


3X

**INTERNAL
LOCALIZER
ALARMS
VISUALIZATION**

VISUALIZATION


internal localizer visualization

internal localizer intermittent faults visualization



INTERNAL LOCALIZER INTERMITTENT FAULTS VISUALIZATION

internal localizer



Reset of the internal localizer intermittent faults is performed in the "alarms visu" menu of the CPI main menu.

VISUALIZATION

Internal localizer visualization

internal localizer threshold visualization

1

MAIN SCREEN

insulation
R = 040 kΩ
test menu

HAVE ACCESS TO THE MAIN MENU

2

MAIN MENU

quit
> XM visu
alarms visu
ok ^ mod

SELECT "internal XL"

3

MAIN MENU

alarms visu
> internal XL
system status
ok ^ mod

VALIDATE YOUR CHOICE

4

INTERNAL XL PARAMETERS MENU

quit
> alarm
intermit. fault
ok ^ mod

SELECT "threshold"

5

INTERNAL XL PARAMETERS MENU

R(kΩ) C(μF)
> threshold
quit
ok ^ mod

VALIDATE YOUR CHOICE

6

INTERNAL XL THRESHOLD VISUALIZATION

th. tor.: 01
th = 02.0 kΩ
tor. quit

next threshold

th. tor.: 01
th = 02.0 kΩ
tor. quit

3X QUIT

INTERNAL LOCALIZER THRESHOLD VISUALIZATION


operate your XM or XML

VISUALIZATION

Internal localizer visualization

internal localizer R and C visualization


1 **MAIN SCREEN**



HAVE ACCESS TO THE MAIN MENU

1X


2 **MAIN MENU**



SELECT "internal XL"

1X


3 **MAIN MENU**



VALIDATE YOUR CHOICE

1X


4 **INTERNAL XL PARAMETERS MENU**



SELECT "R(Ω) C(μ f)"


2X

5 **INTERNAL LOCALIZER R and C VISUALIZATION**



VALIDATE YOUR CHOICE

6 **INTERNAL LOCALIZER R and C VISUALIZATION**



visualise the other value

2X

VISUALISE: If display marked:
 .. $k\Omega$
 .. μF

The CPI is fault. The fault is not located on the channel selected.
quit

INTERNAL LOCALIZER R and C VISUALIZATION

VISUALIZATION

Localizer piloted by the CPI visualization

localizer piloted by the CPI intermittent fault and alarms visualization

Reset of intermittent faults of localizers is performed in this menu

1

MAIN SCREEN

HAVE ACCESS TO THE MAIN MENU

1X

2

MAIN MENU

SELECT "alarms visu"

1X

3

MAIN MENU

VALIDATE YOUR CHOICE

1X

4

ALARMS VISUALIZATION

VISUALISE THE ALARMS

Visualise the next screen. When all the fault have been visualised, you visualise the intermittent fault.

When all the intermitten fault have been visualised, the press on ok provoke the return to previous menu.

Reset the intermittent displayed fault and display the next fault. When all the fault shave been visualised, the press on ok provoke the return to previous menu.

QUIT

**LOCALIZER
PILOTED BY
THE CPI
INTERMITTENT
FAULTS AND
ALARMS
VISUALIZATION**


VISUALIZATION

Error messages and system state visualization

Error messages visualization

All these messages result from tests carried out on the operation of your device together with tests carried out on the system part of your installation (see page 50).



- The blocking messages interrupt the operation of your device and require immediate intervention. These messages are not stored.
- The no blocking messages are stored and do not interrupt operation of your device. They can be visualized in "FAILURES VISU".



VISUALIZATION

system state visualization

Visualization of messages concerning system configuration modifications.
These messages are stored in "system state".



set the parameters of your XM or XML

To improve understanding of the operation of your device, do not forget to refer to the menu block diagram on page 20, when faced with **writing on black background**.

modification of CPI parameters

Only parameters relating to the CPI and the internal XL can be modified.

main screen

main screen

if you have a password, it must be entered when modifying.

CPI parameters modification menu

unidirectional scroll menu
use the central key "A" to position the parameter to be visualized opposite the validation line ">" then validate the information using the "OK" key.

description of the CPI parameters modification menu screens

parameter to be validate	screen visualize	comments
CPI parameters modification menu		
> fault th.	<pre> fault th. kΩ mA aa/mm/jj hh H mn ok annul ^ </pre>	when it leaves the plant, the fault threshold is preset at 2 kΩ. Setting range: 0.2 kΩ < Td < 99.9 kΩ
> prevent thres.	<pre> prevent th. kΩ mA aa/mm/jj hh H mn ok annul ^ </pre>	when it leaves the plant, the prevention setting is preset at 30 kΩ. Setting range: 1 kΩ < Tp < 300 kΩ
> self-setting	<pre> Td =kΩ Tp = 0.8 * R self setting ? quit quit yes </pre>	<div style="border: 1px solid black; padding: 2px;"> all devices XM, XML, XL self-setting ? quit quit yes </div> enables remote setting of all the Td of the system devices at the same value in one single operation together with Tp on all CPI.
> date / hour	<pre> date hour aa/mm/jj hh H mn aa/mm/jj hh H mn ok annul ^ </pre>	If XTU 300, XLI 300 or XPI 300 exists this menu enables to enter date and hour.
> interface	<pre> serial link addr bauds xx yyyy ok annul ^ </pre>	enables addressing of your interface "01" to "FE", and choice of the transmission rate of the JBUS link.
> f (Hz), Un (v)	<pre> frequency 50 Hz Un network.....V ok annul ^ </pre>	When entering the system voltage and frequency value, the fault current value is displayed in mA on the "fault threshold" screen. frequency setting range: 50 Hz, 60 Hz, DC. voltage setting range: from 0 to 999 V.
> password	<pre> enter the password 0000 ok annul ^ </pre>	when leaving the factory, the password is set at "0000". If this password is modified, the new password must be entered before changing parameters.
> language choice	<pre> French English ok ^ </pre>	language modification screen, see page 26.


set the parameters of your XM or XML

MODIFICATION

CPI fault threshold modification

1

MODIFICATION MENU




quit
> fault th.
prevent th.
ok ^ quit

SELECT AND VALIDATE
"fault threshold"

1X

2

MODIFICATION MENU




fault th.
> 0.2 kΩ < mA
aa/mm/jj hh H mn
ok annul ^

VISUALISE THE THRESHOLD

1X

3

MODIFICATION MENU




0002
ok annul ^

MODIFY OR VALIDATE THE 1st DIGIT

validate the digit — increase the digit value

4

MODIFICATION MENU




0002
ok annul ^

MODIFY OR VALIDATE THE 2nd DIGIT

validate the digit — increase the digit value

5

MODIFICATION MENU




0002
ok annul ^

MODIFY OR VALIDATE THE 3rd DIGIT

validate the digit — increase the digit value


6

MODIFICATION MENU



0003
ok annul ^

validate the digit — increase the digit value



ENTER
"OK"


MODIFY OR VALIDATE THE 3rd DIGIT
AND RETURN TO PREVIOUS MENU

**FAULT
THRESHOLD
MODIFICATION**

set the parameters of your XM or XML

SELF SETTING

fault threshold modification



This function is available on devices XM or XML. It enables remote setting of all fault thresholds to the same value on the other system devices (XL, XM, XML) from the pilot CPI.

It enables automatic calculation of prevention threshold ($T_p = 0,8 \times \text{Risol}$) of all CPI (Risol is the insulation resistance measurement of the CPI on which self-setting is performed).

The fault threshold send to all devices (CPI and localizers) is the fault threshold of the CPI on which self setting is performed.

nota: Self-setting can not be performed on a CPI which is in exclusion mode.

1

MODIFICATION MENU

```

quit
> fault th.
prevent th.
ok ^ quit
    
```

SELECT "self setting"

2X

2

MODIFICATION MENU

```

prevent th.
> self-setting
date / hour
ok ^ quit
    
```

VALIDATE YOUR CHOICE

1X

3

MENU MODIFICATION

```

Td=2kΩ
Tp=0.8*R
self setting?
quit quit yes
    
```

VALIDATE THE SELF SETTING VALUE OR QUIT

display of the existing fault threshold value. If it is not the required value "QUIT" and modify the fault threshold.

5


MENU MODIFICATION

```

all devices
XM, XML, XL
self setting?
quit quit yes
    
```

VALIDATE THE SELF-SETTING OF ALL DEVICES OR QUIT

quit validate



SELF-SETTING

set the parameters of your XM or XML

MODIFICATION

Date / hour modification

If you have a XLI 300, XTU 300, or XPI 300 interface in your system, you can then enter the date and hour in order to date events.

1 **MODIFICATION MENU**
quit
> fault th.
prevent th.
ok ^ quit
3X
SELECT "date / hour"

2 **MODIFICATION MENU**
self setting
> date/hour
interface
ok ^ quit
1X
VALIDATE YOUR CHOICE

3 **MODIFICATION MENU**
date hour
aa/mm/jj hh H mn
91/01/01 00 H 00
ok annul ^
VISUALISE THE PREVIOUS PARAMETERS

4 **DATE MODIFICATION DETAIL**
aa / mm / jj aa / mm / jj aa / mm / jj
02 / 01 / 01 92 / 01 / 01 93 / 01 / 01
ok annul ^ ok annul ^ ok annul ^
validate the 1st digit modify the 2nd digit MODIFY THE DATE

5 **HOUR MODIFICATION DETAIL**
hh / H / mn hh / H / mn hh / H / mn
00 / H / 00 00 / H / 00 02 / H / 00
ok annul ^ ok annul ^ ok annul ^
validate the 1st digit modify the 2nd digit 2X MODIFY HOUR

6 **MODIFICATION MENU**
hh / H / mn
02 / H / 1
ok annul ^
ENTER "OK"
VALIDATE YOUR MODIFICATIONS AND RETURN TO PREVIOUS MENU

**DATE / HOUR
MODIFICATION**

set the parameters of your XM or XML

MODIFICATION

Interfaces (JBUS) address and transmission rate modification

If you have an XLI 300, XTU 300, or XPI 300 in your system, you must enter:

- for XLI 300, XTU 300, XCU10: address and rate
- for XPI 300: address only

The values set by default are: address = 01 rate = 9600 bauds

1

MODIFICATION MENU

SELECT "interface"

4X

2

MODIFICATION MENU

VALIDATE YOUR CHOICE

1X

3

MODIFICATION MENU

MODIFY OR VALIDATE THE RATE
The disponibles transmission rate are: 300, 1200, 2400, 4800, 9600, 19200 bauds

validate the rate ——— increase the rate

4

MODIFICATION MENU

validate the rate ——— increase the rate

MODIFY OR VALIDATE THE RATE AND RETURN TO PREVIOUS MENU

ADDRESS AND TRANSMISSION RATE MODIFICATION

set the parameters of your XM or XML

MODIFICATION

voltage and frequency of the monitored network entering

This is optional and means that you can obtain on the fault threshold screen, the maximum value of the current flowing in the fault in absence of unbalanced capacity.

1 **MODIFICATION MENU**
quit > fault th. prevent th. ok ^ quit
SELECT "f (Hz) , Un (V)"
5X

2 **MODIFICATION MENU**
interface > f(Hz), Un(V) langue ok ^ quit
VALIDATE YOUR CHOICE
1X

3 **MODIFICATION MENU**
frequency 50 Hz Un network...V ok annul ^
MODIFY THE FREQUENCY
1X

4 **MODIFICATION MENU**
frequency 60 Hz Un network...V ok annul ^
VALIDATE YOUR MODIFICATION
1X

5 **MODIFICATION MENU**
frequency 50 Hz Un network 000 V ok annul ^
MODIFY THE VOLTAGE VALUE
(see fault threshold modification)
validate the digit ————— increase the digit value

6 **MODIFICATION MENU**
2203 ok annul ^
ENTER "OK"
VALIDATE YOUR MODIFICATION AND RETURN TO PREVIOUS MENU

**VOLTAGE AND
FREQUENCY
ENTERING**

set the parameters of your XM or XML

MODIFICATION

password modification

PASSWORD MODIFICATION

1 **MODIFICATION MENU**
quit
> fault th.
prevent th.
ok ^ quit
6X
SELECT "password"

2 **MODIFICATION MENU**
f (Hz), Un (V)
> password
langue
ok ^ quit
1X
VALIDATE YOUR CHOICE

3 **MODIFICATION MENU**
0000
ok annul ^
validate the digit — increase the digit
MODIFY OR VALIDATE THE 1st DIGIT

4 **MODIFICATION MENU**
1000
ok annul ^
validate the digit — increase the digit
MODIFY OR VALIDATE THE 2nd DIGIT

5 **MODIFICATION MENU**
1300
ok annul ^
validate the digit — increase the digit
MODIFY OR VALIDATE THE 3rd DIGIT

6 **MODIFICATION MENU**
13203
ok annul ^
validate the digit — increase the digit
ENTER "OK"
MODIFY OR VALIDATE THE 3th DIGIT AND RETURN TO PREVIOUS MENU

set the parameters of your XM or XML

INTERNAL XL PARAMETERS MODIFICATION

On an internal localizer you can only modify the fault threshold.

1 **MAIN MENU**
insulation R = 040 kΩ
test menu
1X
HAVE ACCESS TO THE MAIN MENU

2 **MODIFICATION MENU**
alarm
> internal XL
system status
ok ^ mod
1X
quit
> alarm
intermit. fault
ok ^ mod
1X
SELECT MODIFICATION MODE

3 **MODIFICATION MENU**
enter password
0000
ok ^ quit
nota: This screen only appears if you have already entered a password
ENTER YOUR PASSWORD

4 **MODIFICATION MENU**
fault tor.: 01
Td = 02 kΩ
tor. quit Td
select the toroid
nota: If you wish to adjust all the feeders to the same setting value, press TOR. until toroid XX appears, then adjust the setting value as shown below.
SELECT THE FEEDER


5 **MODIFICATION MENU**
fault tor.: 04
Td = 02 kΩ
tor. quit Td
1X
HAVE ACCESS TO THE THRESHOLD VALUE MODIFICATION

6 **MODIFICATION MENU**
02.3
ok annul ^
validate the digit
increase the digit
ENTER "OK"
MODIFY OR VALIDATE THE 3rd DIGIT AND RETURN TO PREVIOUS MENU


INTERNAL XL PARAMETERS MODIFICATION

operate your XL

legend:



use of the XL keyboard



fault threshold adjustment detail

The setting is modified by variable "steps". You MUST keep the "+" or "-" key pressed down.

The values slowly scroll down at the beginning, speeding up until the key is released.

display state

Without using the keyboard, your device informs you by messages of the problem detected.



message		1.5 ⚡ red	test	tor test led voie		■■■■ test	■■
meaning	the display is off. On all feeders Ri > Td.	value of the insulation resistance detected in fault.	the pilot CPI does not reply or incorrect self-test. The device continues to work.	localizer toroid link disconnected or short-circuited.	address of another XL with a faulty feeder.	important problem during the autotest. the device loops in self-test.	measurement impossible. the CPI is a fault. the fault is not on the channel selected.

visualization


you can use the keyboard to visualize the parameters for your device.

- Ω : insulation resistance
- Td: fault threshold
- $\frac{\Omega}{\mu F}$: intermittent fault
- μF : insulation capacity


example: visualization of the fault setting for feeder 3.



press twice



press twice




- the led corresponding to feeder 3 flashes.
- display of Td in kΩ

the device returns to the normal mode if no key is pressed for 2 mn.


modification

you can use the keyboard to modify the fault threshold for each feeder.


example: modification of the fault setting of feeder 3 to 4 kΩ.




press twice



press twice



- the led corresponding to feeder 3 flashes.



keep the key pressed down. The value increases gradually then quicker and quicker. When you approach the required value, release the key and advance by successive "steps".


Once the value has been set, the led flashes for 6 secondes. You can then set all the feeders at this same value by pressing simultaneously on

the plus key and the key symbol. The toroid leds flash in turn and each feeder is automatically set at the same value until both keys are released.

signalling


example 1: alarm fault feeder 2

for a fault alarm, the fault value is automatically displayed.




- reset de-energizes the fault and failsafe relays.

example 2: intermittent fault feeder 4



press 3 times




display of the intermittent fault.

- both leds flash.
- the display shows 1 kΩ.

Reset of the intermittent faults (see next page).


legend:



signalling


example 3: alarm fault feeder 2 and intermittent fault feeder 4.

for a fault alarm, the fault value is automatically displayed.




■ reset de-energizes the fault and failsafe relays.

look for intermittent fault.



selection of intermittent fault function



display of the intermittent fault.


■ both leds flash.
■ the display shows 1 kΩ.

Reset of the intermittent faults, see opposite.

clearing intermittents faults


intermittent faults are reset feeder by feeder.

example: intermittent faults on feeders 2 and 4.




press 3 times

selection of intermittent fault function




press once


selection of feeder 2



reset of the intermittent fault




the device displays 999 and moves to the following feeder (if the following feeder is not used, the device automatically moves to the one after).




press once

selection of feeder 4



reset of the intermittent fault




■ all the intermittent faults are cleared.

■ the led goes out.

reminder: the device returns to the starting mode if the keys are not pressed for 2 mn.

problems during the autotest



problems during the autotest

identification of error messages

XM300C - XML308 - XML316

messages		interpretation and action	visualization	signalling	
not blocking	blocking				
input i1 = I2 = 1 inconsistent XM is inhibited		incorrect wiring circuit-breaker position contact	"failures visu"	red led	
XML... tore... has disappeared		toroid short-circuited or disconnected	"failures visu"	red led	
memory problem check parameters		check the operating parameters Tp, Td	"failures visu"	red led	
	address XM/XML > 14 (18) correct	correct the address ACQ startup the autotest again		red led + failsafe relay	
	measurement error	contact Schneider Electric		red led + failsafe relay	
memory error		RAM problem contact Schneider Electric	"failures visu"	red led	
	no measurement possible	contact Schneider Electric		red led + failsafe relay	

XL308 - XL316

visualization	interpretation	signalling	
	the device continually loops on the autotest	red led + failsafe relay	
	autotest problem. the device continues to operate or safe operate mod, check the bus wiring	red led + failsafe relay	
	toroid short-circuited or disconnected, check the connection between toroid and relays	red led + failsafe relay	

any problems?

seek out the cause

■ XM- XML

□ XL

symptoms		probable causes	solutions
The device displays nothing when switched on.	■	The device is not supplied.	Check the auxiliary supply is present.
	□	The auxiliary supply does not comply.	Check the value of the auxiliary voltage. $0.85 U_n < U < 1.1 U_n$.
The device continuously displays 999 K Ω when switched on	■	Incorret connection of the injection circuit, insulation of your system exceeds 999 k Ω .	Check that the fast-on terminal 13 is connected to the ground and terminal 14 to the neutral or a phase (unavailable neutral).
You deliberately create an insulation fault. The device still shows the same insulation value.	■	The XM or XML injection circuit is cut off.	Check connection on terminals 13 and 14
		Incorrect grounding connections.	Check interconnection of all grounds.
		The resistance value used to simulate the fault is greater than the value of the fault setting.	Take a value of $R < T_d$ or change T_d .
		The fault was not made to occur between phase and ground.	Start again ensuring you are between phase and ground.
The monitoring device on the failsafe output (3) is continuously activated (alarm or indicator light)	■	Removal or drop of auxiliary supply.	Check the auxiliary supply is greater than $0.85 U_n$.
	□	Incorrect failsafe relay output wiring.	Check that outputs wired are: 11 and 10 or 11 and 12.
The monitoring device on the output (3) is not activated when the auxiliary supply is removed.	■	The alarm or indicator light is not supplied.	Start resupplying the failsafe device.
	□	Incorrect failsafe relay output wiring.	Check that outputs wired are: 11 and 10 or 11 and 12.
The monitoring device on the output (1) "prevent alarm" is continuously activated.	■	Incorrect "prev" relay output wiring.	Check that outputs used are: 5 and 6, or 5 and 4.
The monitoring device on the output (3) "prevent alarm" is not activated when $R_{isol} < T_p$	■	The "prevent alarm" device is not supplied.	Start resupplying prevention.
The monitoring device on the output (2) "fault alarm" is continuously activated.	■	Incorrect "fault" relay output wiring.	Check that outputs used are: 8 and 9, or 8 and 7.
	□	The response time is not over.	Wait for the end of the response time.
The monitoring device on the output (2) "fault alarm" is not activated when $R_{isol} < T_d$.	■	incorrect "fault relay" output wiring.	Check that outputs used are: 8 and 9, or 8 and 7.
	□	The fault device is not supplied.	Check supply of the "fault" device.
The corresponding indicator lights do not come on for anomalies and faults.	■	Faulty indicator lights.	Start up the autotest again and check that all the indicator lights come on briefly.
	□		

Schneider Electric Industries SAS

35, rue Joseph Monier
CS 30323
F- 92506 Rueil Malmaison Cedex
RCS Nanterre 954 503 439
Capital social 896 313 776

www.schneider-electric.com

As standards, specifications and designs change from time to time, please ask for confirmation of the information given in this publication.



This document has been printed on ecological paper

Produced: System France
Published by: Schneider Electric
Printing: