4L60E-PRO

Reprogramming Kit™

Fits 1996-2018 except 2005 Corvette

Does Not Fit 1993-1995 or Hybrid

Kit Includes Optional Internal Upgrades. Unit Removal Recommended.



If the trans is on the bench, follow instructions for the Pump Ring Kit & Clutch Spring Kit Supplied.

Corrects/Reduces/Prevents

3-4 Clutch and 2nd Band Burn-up--Bang, Bump or Slide Bump 1-2, 2-3 Shift Reduces code P1870, converter slip/shudder.

Optional Gear Command 1996-2008

Holds Manual 1st--2nd--3rd to any RPM--Backshifts to gear you select.

Step 1

Identify the Type Accum housing you are using (2nd or 3rd Type), then *choose* new spacer that matches your housing and install it with new small orange spring. Install new seal on new 1-2 piston furnished. Lubricate the seal & install piston with 3 tab side up, followed by large & medium orange springs as shown.



New Medium Orange

New Large Orange

New 1-2 Piston
& seal.

New Small Orange

New Long Spacer .430"

Double stepped


spring pocket.

3rd Type

1-2 Accum Housing

Pin .236

Don't Use




One Single spring pocket.

2nd Type
1-2 Accum Housing


Check AFL bore for wear first!

If your valve body is worn out, get TransGo # 4L60E-AFL-OS. Requires # 4L60E-AFL-TK



Step 1. Remove and discard the converter Reg valve, spring and isolator valve. Save the end plug and clip. **Note:** If the original outer Valve is in a bushing or it measures larger than .441" VB has been modified Skip Steps 1, 2 & 3 and reassemble as found.

Step 2. Insert **ISO-CONV Valve** into bore. Using hex bolt as a handle, push valve in and out at least 20 times with slight side pressure. The valve must fall in and out of bore. Clean the bore. Remove the bolt.



New ISO-CONV valve replaces all of the earlier factory type Isolator and Converter valves.

BLUE

Hex bolt

Reuse

Recessed End

Spacer

Step 3.

For Normal Use:

Install BLUE spring & ISO-CONV Valve,


Models with Cylinder Deactivation:

Install Spacer (Recessed end outward), & ISO-CONV Valve. *Do not use Blue Spring!*

If Cylinder deactivation has been eliminated with a aftermarket tune Install New blue spring & ISO-CONV valve discarding new spacer.

Always Reuse original End Plug and Clip.

Step 4. Remove 3-2 Downshift Valve assembly to access & discard **original** divider **plug.** Save the roll pin for reuse.




2008-09 Avalanche 6.0L

2005-09 Trailblazer, Envoy Denali 5.3L

2007-10 Silverado, Sierra, Suburban,


Yukon, Tahoe, 1500 5.3L


2007-08 Silverado, Sierra, Suburban, Yukon, Tahoe, 1500 6.0L




Step 5. Using longer threaded bolt, position new divider plug into the bore wiggle to get it started straight & making sure it installs deep enough for original roll pin to insert thru the hole in the new plug. Remove threaded bolt and reassemble 3-2 downshift with **New White Spring.**

Note: High mileage pump with excessive wear at the inboard area of the PR valve bore leads to unstable pressure and broken pump rotor. TransGo oversized valve part # 4L60E-PR-OS can be used to salvage those worn out pumps. *Requires # 4L60-PR-TK*









New Yellow & Red Step 2. 4th Accumulator Discard original Spring. Install original guide Pin into Case first. Install original piston as shown followed by Yellow & Red Springs regardless of how it came apart.

t. Install original piston as shown followed by Red Springs regardless of how it came apart. Step 3. Case- One check ball here.


WARNING: Wrong Bolts locks Gear Train.



Step 1. Disassemble Servo as shown discard the original 2nd piston & housing Install the New supplied 2nd Piston & Housing using the new Rings & Seals provided.



Step 3. Band Adjust: Install 2nd Piston and housing into the trans. Install 2 GOLD shims against housing. Install 4th Piston and cover without Blue O-ring. Install wire retainer. Check band by wiggling it front to rear 1/8" or more. (See below) Final Check—You must be able to turn driveshaft both ways by hand in Neutral. If too tight remove one shim, and test again. Then remove and install cover with BLUE O-ring.



Check Band Clearance:

Through the opening in Case, with a Screwdriver make sure the Band wiggles on drum front to rear.