## **4L6-CCV Non L/up Conversion Valve**

For Use With NON-L/UP Converters Only!

Fits 1993 & Up 4L60E Transmissions.

Computer must have aftermarket re-flash for Non Lock-up use. (Re-flash removes computer request for Lock-up "ON".) Also OK with Transgo 4L60E-3 or 46Mod used with 4L60E-HD2



## Step 1


With a small flat punch and hammer, remove orifice capsule by hitting high spot on capsule shown at arrow location. This will expand the capsule and allow you to remove it with needle nose pliers.

Do not use O-Ring on end of input shaft!

New valve system corrects converter flow to the primary pump area so the converter will stay full under high load and RPM. This New valve system does not require any pump machining, cross drilling or any modification to the pump or support. It does not require a solenoid but you can reinstall it if you wish. Always install a cooler for best results.

Not Recommended for working trucks, vans, suburbans, or towing. A non-lock-up converter increases transmission temperature which can lead to overheating in these vehicles.






Apr 09 2008

Page 1

**1** Remove and discard the converter reg valve, spring and isolator valve. Save the end plug and clip.

**4L6-CCV** Valve body section. Complete Steps 1 & 2.



New ISO-CONV valve replaces all .442 diameter Iso-Conv valves. \*\*

New ISO-CONV Valve Plain Spacer

.442

Reuse

amm

2. Install Plain Spacer spring & ISO-CONV Valve.

\*\* Check your valve's diameter! Our valve does not fit oversize valve bores! Your original valve MUST be approx .442 in diameter! Call us if your valve diameter is larger.

