

MyVALLOX CONTROL

Manual



Contents

1. Introduction	5
1.1. Safety	5
1.1.1. Installation	5
1.2. Guarantee	5
1.3. Intended use	6
1.4. Disposal of the ventilation unit	6
1.5. Safety signs used in the instructions	7
1.6. Compatibility of the MyVallox Control panel	7
1.7. System description	8
1.8. Ventilation unit control options	10
1.8.1. Connecting the ventilation unit to the cloud service.....	10
1.9. MyVallox Control panel buttons	11
1.10. Unit software	13
2. Installation of the MyVallox Control panel	15
3. MyVallox Control setup	18
3.1. Start guided setup	18
3.2. Language	18
3.3. Time and date	19
3.4. Air flow unit (CFi)	19
3.5. Ventilation mode settings (CFi)	20
3.5.1. Maximum air flow (CFi)	20
3.5.2. At Home mode settings (CFi).....	21
3.5.3. Calibration (CFi).....	21
3.5.4. Away mode settings (CFi).....	22
3.5.5. Boost mode settings (CFi)	23
3.5.6. Custom mode settings (CFi).....	24
3.6. Ventilation mode settings (MV)	25
3.6.1. At Home mode settings (MV)	25
3.6.2. Away mode settings (MV).....	25
3.6.3. Boost mode settings (MV)	26

3.6.4. Custom mode settings (MV)	27
3.7. Completion of setup or configuration of additional settings	28
3.7.1. Configuration of Modbus settings.....	28
3.7.2. Configuration of relay settings	29
3.7.3. Configuration of input settings.....	31
3.7.3.1. Analog input settings	31
3.7.3.2. Digital input settings	32
3.7.4. Determination of access rights.....	34
3.7.5. Control settings.....	34
4. Using MyVallox Control.....	39
4.1. Starting the unit.....	39
4.2. Ventilation modes.....	39
4.2.1. Symbols related to ventilation modes.....	40
4.2.2. Changing the ventilation mode	41
4.2.3. Browsing the ventilation mode information	42
4.2.3.1. Browsing the At Home mode information	42
4.2.3.2. Browsing the Away mode information	43
4.2.3.3. Browsing the Boost mode information	45
4.2.3.4. Browsing the Custom mode information	47
4.2.3.5. Browsing the Automatic mode information	49
4.2.4. Changing the ventilation mode settings.....	50
4.2.4.1. Change the At Home mode settings	51
4.2.4.2. Change the Away mode settings.....	53
4.2.4.3. Change the Boost mode settings	55
4.2.4.4. Change the Custom mode settings.....	59
4.3. Temperatures and sensors.....	61
4.3.1. Browsing of temperature information.....	61
4.3.2. Browsing of temperature statistics	63
4.3.3. Browsing of humidity and carbon dioxide levels measured by the sensors.....	65
4.3.4. Browsing of relative humidity and carbon dioxide statistics.....	67
4.3.5. Monitoring the fan performance (CFi)	69
4.4. Settings.....	70
4.4.1. Filter settings	70
4.4.1.1. Setting the reminder interval for filter replacement	71
4.4.1.2. Setting the filter reminder	73
4.4.1.3. Setting the automatic filter reset interval	73

4.4.1.4. Setting the filter replacement date	74
4.4.1.5. Filter maintenance reminder	76
4.4.2. Display settings	76
4.4.2.1. Setting a sleep time	76
4.4.2.2. Adjusting the display brightness	77
4.4.2.3. Screen lock	78
4.4.2.4. Setting a screen lock code	78
4.4.3. Selecting the user interface language	79
4.4.4. Setting the time and date	80
4.4.4.1. Setting the time	80
4.4.4.2. Setting the 24-hour or 12-hour clock.....	80
4.4.4.3. Automatic daylight saving time	82
4.4.4.4. Setting the date.....	83
4.5. Week clock	84
4.5.1. Setting and editing a weekly program	84
4.5.2. Turning on the week clock	86
4.5.3. Turning off the week clock	87
4.5.4. Resetting the week clock	88
4.5.5. Example of setting a weekly program.....	89
4.6. Timed function.....	90
4.6.1. Enabling/disabling the timed function.....	90
4.6.2. Setting the timed function's start and end date	91
4.6.3. Selecting a timed ventilation mode	92
4.7. Expert settings	92
4.7.1. Basic fan settings (CFi).....	93
4.7.2. Adjusting the supply and extract air flow (MV).....	94
4.7.3. I/O and bus settings	95
4.7.3.1. Control panel address.....	95
4.7.3.2. Modbus settings	97
4.7.3.3. Relay settings	100
4.7.3.4. Duct radiator control	102
4.7.3.5. Input settings.....	106
4.7.3.6. Programmable input.....	110
4.7.3.7. External sensor settings	111
4.7.4. Access rights	112
4.7.4.1. Access code.....	112
4.7.4.2. Access level.....	113

4.7.5. Defrost settings	114
4.7.5.1. Defrosting method.....	114
4.7.5.2. Supply air temperature during defrosting.....	115
4.7.5.3. Defrost sensitivity (CFi).....	116
4.7.5.4. Adjusting the defrost humidity level (MV)	117
4.7.5.5. Outdoor air temperature (MV).....	118
4.7.6. Settings management.....	120
4.7.7. Control settings.....	120
4.7.7.1. Setting the supply air temperature control method	121
4.7.7.2. Humidity control (Automatic / Manual)	123
4.7.7.3. Setting the humidity limit	125
4.7.7.4. Setting the carbon dioxide limit.....	126
4.7.7.5. Activating the constant air flow limiter (CFi).....	128
4.7.8. Bypass settings of the HR cell.....	129
4.7.9. Heating settings	131
4.8. Service menu.....	133
4.8.1. Unit information.....	133
4.8.2. Error log	135
4.8.3. Fan test	137
4.8.4. Heater test.....	138
4.8.5. HR cell bypass test.....	139
4.8.6. HR cell defrost.....	141
4.9. Turning the unit off	142
5. Updating the unit software (MyVallox Control).....	144
6. User level diagrams.....	146

1. INTRODUCTION

1.1. Safety

Safe and appropriate handling requires knowledge of the basic safety regulations, and of the intended use of the ventilation system. Read this manual before operating the ventilation unit. Retain the manual for later reference. If you lose the manual, it can be downloaded from our website.

These instructions contain all the information needed for the safe operation of the unit. All persons who install, operate, and maintain the ventilation unit must follow the provided instructions. Furthermore, all local accident prevention regulations must be observed.

Installation

Installation and setup should be carried out only by qualified experts. Electrical installations and connections must be carried out only by an electrician and in compliance with local regulations

NOTE: For further information, go to <https://www.vallox.com>

1.1.1. Installation

WARNING:

Installation and setup should only be carried out by a qualified specialist. Electrical installations and connections must only be carried out by an electrician and in compliance with local regulations.

1.2. Guarantee

The guarantee and liability exclude damage resulting from:

- Inappropriate use of the ventilation unit or the control panel
- Incorrect or inappropriate installation, setup, or use
- Failure to follow instructions regarding transport, installation, operation, or maintenance
- Structural or electronic modifications or changes made to the software

1.3. Intended use

All Vallox ventilation units have been designed to provide appropriate and continuous ventilation so as to present no threat to health and to maintain structures in good condition.

⚠ WARNING:

Ensure that the fireplace air intake is sufficient. Operating certain kitchen range hood, central vacuum cleaner and ventilation unit functions can create underpressure in the indoor air. Combustion gases can then be released from the fireplace into the indoor air.

The following can create underpressure indoors:

- Kitchen range hood or central vacuum cleaner are in operation while there is a fire burning in the fireplace
- The supply air fan is stopped during the defrosting function of the ventilation unit
- The boosted defrosting function of the ventilation unit is being used

Underpressure can prevent fireplace air intake, and combustion gases can then be released into the indoor air.

! IMPORTANT: In order to ensure that the indoor air presents no harm to health and remains optimal also for the structures of the building, ventilation must be kept on without disruptions. It is recommended that ventilation be left turned on during long holidays also. This keeps the indoor air fresh and prevents humidity from condensing in the ventilation ducts and structures. It also reduces the risk of moisture damage.


! IMPORTANT:

Prolonged overpressure can result in damage to the structures of the building.






1.4. Disposal of the ventilation unit

Do not dispose of electronic devices with household waste. Follow local laws and regulations on safe and ecological disposal of the product.

See the MyVallox ventilation unit recycling instructions at: https://res.cloudinary.com/vallox/image/upload/v1704800151/FileStock/ValidManuals/Recycling_Instructions_Vallox_Ventilation_units.pdf.




1.5. Safety signs used in the instructions

 DANGER:	Indicates a hazard that will result in death or serious injury if not avoided.
 WARNING:	Indicates a hazard that can result in death or serious injury if not avoided.
 CAUTION:	Indicates a hazard that can result in minor or moderate injury if not avoided.
 IMPORTANT:	Indicates a hazard that can result in damage to property or loss of data if not avoided.
 NOTE:	Indicates essential information about the product.
TIP:	Provides additional information about the use of the product and its benefits.


1.6. Compatibility of the MyVallox Control panel

The control panel is compatible with all MyVallox ventilation units.

1.7. System description



- 1 Internet
- 2 WLAN
- 3 Router
- 4 WLAN/LAN
- 5 Additional switch
- 6 Sensors



- 1 Internet
- 2 WLAN
- 3 Router

- 4 WLAN/LAN
- 5 Additional switch
- 6 Sensors

1.8. Ventilation unit control options

The Vallox ventilation unit can be controlled by the following means:

- Through the MyVallox control panel installed to the building
- Through the MyVallox Home LAN connection and the MyVallox Home/Cloud user interface
- Through the MyVallox Cloud service and the MyVallox Home/Cloud user interface
- Through a remote monitoring or building automation system that uses voltage signals or Modbus messages.

The ventilation unit's integrated humidity and carbon dioxide sensors control ventilation automatically, as necessary. Ventilation can also be adjusted automatically by using an optional carbon dioxide, humidity, or VOC (air quality) sensor. When these sensors are used, ventilation remains optimal even when the apartment is unoccupied. The standard equipment and available optional accessories vary from country to country.

The ventilation unit's integrated humidity and carbon dioxide sensors adjust ventilation automatically according to the need. In addition, ventilation can be automated by using optional carbon dioxide, humidity or air quality (VOC) sensors.

TIP:

The MyVallox control panel automatically switches to the sleep mode when the pre-set has elapsed. To reactivate the MyVallox control panel, press any button.

1.8.1. Connecting the ventilation unit to the cloud service

You can connect the ventilation unit to the MyVallox Cloud service. In the cloud service, you can control ventilation remotely with a smartphone or tablet, for example. The unit software is updated automatically through the cloud service. To connect to the cloud service, the ventilation unit must be connected to the internet through LAN and registered for the cloud service. By registering the unit, you create a MyVallox Cloud account for yourself. Read more about the service at <https://cloud.vallox.com>.

To register a Vallox ventilation unit with the MyVallox Cloud service:

1. Connect one end of the network cable to the grey connector of the Vallox ventilation unit and the other end to the router.

2. Open the computer's network settings by selecting **Start** → **My Computer** → **Network**. You can see a computer icon with the text Vallox and a series of numbers. Open the MyVallox Home user interface by double clicking on the icon. The MyVallox Home user interface opens.

OR

Select on the MyVallox control panel **Service menu** → **Diagnostics display** → **IP address**. Type in the IP address and press Enter. The MyVallox Home user interface opens.

3. Select Special functions.
4. The MyVallox Cloud area will open and you can see whether you are signed in to the cloud service.
5. Select **Connect**.
6. The registration page of the MyVallox Cloud cloud service opens, **Ventilation unit ID** i.e. the unique identification number of the unit will be automatically generated into the field.
7. Enter the following information in the form:
 - **Ventilation unit name** - Enter the ventilation unit name of your choice in this field.
 - **Language** - Select the desired language from the menu.
 - **Country** - Select the desired country from the menu.
 - **Choose username** - Enter the username of your choice in this field.
 - **Email** - Enter the email address of your choice in this field.
 - **Password** - Enter the password of your choice in this field.
 - **Retype your password** - Retype your password in this field.
8. Select the **I want to receive notifications related to my ventilation unit** box if you wish to receive email notifications related to your ventilation unit.
9. Read the terms and conditions of use of the service and select **I have read and accepted the terms and conditions of use of the MyVallox Cloud cloud service**. The use of the service requires that the user has accepted the terms and conditions.
10. Select **Create MyVallox Cloud account**. The ventilation unit generates a unique identification code and sends it to the service. The service will remember the unit the next time you sign into the cloud service.
11. A confirmation message will be sent to your email address. Click on the link in the message to confirm your email address and to sign in to the cloud service for the first time.
12. Once you have signed in, the MyVallox Cloud service will open and the main page of the MyVallox Cloud account will be displayed in your browser.

1.9. MyVallox Control panel buttons








The MyVallox Control panel contains the buttons described in the following table.

! NOTE:

Press the buttons below the display to activate the buttons in the graphic user interface. The control panel is not a touch screen.

Table 1. MyVallox Control panel buttons

Button	Description
	The Change mode button allows you to change the operating mode of the ventilation unit.
	The At Home information button displays the At Home mode information.
	The Away information button displays the Away mode information.
	The Boost information button displays the Boost mode information.
	The Custom information button displays the Custom mode information.
	The Automatic information button displays the Automatic mode information.
	The Info button displays information about temperatures and optional sensors.
	The Settings button opens the settings menu.
	The Back button takes you backwards in the menu.
	The Left arrow button takes you leftwards in the menu.
	The Right arrow button takes you rightwards in the menu.
	The OK button accepts the selected option.
	The Cancel button cancels the selected option.
	The Select button selects the desired option.
	The Edit button allows you to edit settings.

Button	Description
	The Plus button allows you to: <ul style="list-style-type: none"> • Increase the value of the selected setting • Move to the next menu item • Move from a one-day view to a week view in the temperature, relative humidity or carbon dioxide content graphs.
	The Minus button allows you to: <ul style="list-style-type: none"> • Decrease the value of the selected setting • Return to the previous menu item • Move from a week view to a one-day view in the temperature, relative humidity or carbon dioxide content graphs.
	The Up arrow button takes you upwards in the menu.
	The Down arrow button takes you downwards in the menu.
	The Statistics button opens the temperature, relative humidity or carbon dioxide content graph (one-day/week).
	These icons indicate the setting hierarchy..
	This icon indicates that this function cannot be used at your access level

1.10. Unit software

We recommend that the latest software version be always used. Check and download the latest version at <https://cloud.vallox.com> either before or immediately after setup.

The current software version of the ventilation unit is shown on the control panel display when the unit is connected to the mains or factory settings are restored. Alternatively, the current software version can be checked from the Unit information display of the Service menu.


Updating the unit software:

1. Unplug the ventilation unit from the mains or turn off the fuse.
2. Connect the computer to the control panel of the ventilation unit using a USB MicroB connector.
3. Start the ventilation unit. A USB sign will appear on the display of the control panel and the control panel of the ventilation unit cannot be used when it is connected to the computer.
4. Transfer the update file you have downloaded onto the ventilation unit. Copy the update file HSWUPD.BIN (Please note! Do not alter the file name!) you have downloaded at the root of the control panel (the control panel will be displayed on your computer as a mass memory or a removable disk drive). When the file has uploaded onto the control panel,



remove the USB cable. Next, the control panel will take a while to load the update. The control panel will now start to load the update file onto the motherboard. This can take several hours. The control panel will remain turned on, but it is recommended that the control panel be not used during that time. When the update is ready, the unit will restart automatically.

2. INSTALLATION OF THE MYVALLOX CONTROL PANEL


1. Screw the back of the control panel to a wall according to image 1A or to an outlet box according to image 1B.




2. Connect the wires to the control panel and the ventilation unit's external connection box according to images 2 and 3.




3. Push in the panel's front cover. You can hear a click when the cover is locked in place.



4. Plug in the ventilation unit. If the wires are connected correctly, both the unit and the control panel are turned on.



If you must remove the control panel's front cover, unplug the unit first. Remove the front cover by turning the pawls at the bottom of the panel 90° with a screwdriver and pull out the front cover bottom first.



3. MYVALLOX CONTROL SETUP

Use one of the following to set up the ventilation unit

- MyVallox Control panel
- MyVallox Touch panel
- MyVallox Home user interface.

! IMPORTANT:

The basic fan settings must be set according to the ventilation plan. Do not change these settings.

This section describes the setup of the Vallox ventilation unit on the MyVallox Control panel step by step.

TIP:

If you make a mistake when configuring the settings during guided setup and move to the next phase, finish the guided setup and then change the incorrect setting.

! IMPORTANT:

We recommend you always use the latest software version. Check and download the latest version at <https://cloud.vallox.com> either before or immediately after setup. See section *Updating the unit software*.

3.1. Start guided setup

1. Turn on the Vallox ventilation unit.
2. When you turn on the unit for the first time, the control panel displays a language menu.


3.2. Language

Select the desired language.




3.3. Time and date

1. Set the time and select the 24-hour or 12-hour clock.



2. Use the arrow button to switch to/from daylight saving time and set the date.




3. Proceed with the setup by selecting OK: ✓

3.4. Air flow unit (CFi)

The air flow unit options are:

- l/s
- m³/h

1. Set the air flow unit.





2. Proceed with the setup by selecting OK: ✓


3.5. Ventilation mode settings (CFi)

3.5.1. Maximum air flow (CFi)


You can measure the ventilation unit's maximum air flow in the duct system in use. The test takes

no longer than one minute and it is not mandatory. To skip the test, select **Cancel**: . If the test is skipped, the default maximum air flow value is used.


1. Select **OK**:  and start the maximum air flow test.



2. Open the valves. To carry out the maximum air flow test, all the valves/terminal devices must be fully open.



3. The maximum air flow has been determined.




If the maximum air flow is low, the supply or extract air flow may be blocked. In that case, check the ventilation unit and ducts for obstructions.

3.5.2. At Home mode settings (CFi)

To set the **At Home** mode settings:

1. Set the supply and extract air flows for the **At Home** mode and adjust the valves according to the ventilation plan.



NOTE:

By default, the fan speed in the **At Home** mode is the higher percentage of the basic ventilation air flow values set earlier. We recommend this basic ventilation output be set for the **At Home** mode. You can adjust the output if necessary.

2. You can adjust the supply air temperature setting and disable the humidity and carbon dioxide control.




3. Proceed with the setup by selecting **OK**: ✓


3.5.3. Calibration (CFi)

During calibration, the unit's actual operating range is determined in relation to the ducts in use. This test is mandatory. The test takes no longer than one minute.

1. The calibration screen opens after the **At Home** mode settings have been configured.



2. After calibration, the unit's actual maximum air flow is shown in relation to the ducts in use.




If the unit indicates that the **Away** or **At Home** modes cannot be activated, go back and adjust the air flows for the **At Home** mode.

3.5.4. Away mode settings (CFi)


The air flows in the **Away** mode are automatically 30% lower than the air flows in the **At Home** mode, but they can be adjusted. Other **Away** mode settings are configured identically to the settings of the **At Home** mode.

To set the **Away** mode settings:

1. Set the supply and extract air flows for the Away mode and adjust the valves according to the ventilation plan.



- You can adjust the supply air temperature setting and disable the humidity and carbon dioxide control.




3.5.5. Boost mode settings (CFi)


The air flows in the **Boost** mode are automatically 30% higher than the air flows in the **At Home** mode, but they can be adjusted. Other **Boost** mode settings are configured identically to the settings of the **At Home** mode. A timer can also be set for the **Boost** mode.

To set the **Boost** mode settings:

- Set the supply and extract air flows for the **Boost** mode and adjust the valves according to the ventilation plan.




- You can adjust the supply air temperature setting and disable the humidity and carbon dioxide control.



- Set a timer for the **Boost** mode (optional).

When the timer goes off, the ventilation unit switches back to the previous mode.




3.5.6. Custom mode settings (CFi)

The **Custom** mode is used in special circumstances, for example, to compensate for temporary negative pressure caused by a fireplace or cooker hood. In such situations, the difference between the supply and extract air flows should not exceed 30%.


You can set a timer and adjust the air flows and supply air temperature in the **Custom** mode.

To set the **Custom** mode settings:


1. Set the supply and extract air flows for the **Custom** mode and adjust the valves according to the ventilation plan.



2. You can adjust the supply air temperature setting and disable the humidity and carbon dioxide control.



3. Set a timer for the **Custom** mode (optional).




3.6. Ventilation mode settings (MV)


3.6.1. At Home mode settings (MV)

First, configure the basic fan settings to set the **At Home** mode's fan speeds.

1. Adjust the valves and set the supply and extract air fans such control percentages that enable the **At Home** mode's air flows.



2. You can adjust the fan speed and supply air temperature of the **At Home** mode and disable the humidity and carbon dioxide control.



3. Proceed with the setup by selecting **OK**: ✓


3.6.2. Away mode settings (MV)

The air flows in the **Away** mode are automatically 30% lower than the air flows in the **At Home**


mode, but they can be adjusted. Other **Away** mode settings are configured identically to the settings of the **Away** mode.

You can also adjust the fan speed and supply air temperature of the **Away** mode and disable the humidity and carbon dioxide control.

1. Set the **Away** mode's fan speed and supply air temperature.



2. Set the carbon dioxide and humidity settings for the **Away** mode.




3. Proceed with the setup by selecting **OK**: ✓


3.6.3. Boost mode settings (MV)

Set the **Boost** mode's fan speed, supply air temperature and carbon dioxide and humidity control settings. The fan speed in the **Boost** mode is automatically 30% higher than the fan speed in the **At Home** mode. You can adjust the fan speed and supply air temperature of the **Boost** mode and disable the humidity and carbon dioxide control. A timer can also be set for the **Boost** mode.

1. Set the **Boost** mode's fan speed and supply air temperature.




2. Configure the carbon dioxide and humidity settings.



3. Set a timer for the **Boost** mode (optional).

When the timer goes off, the ventilation unit switches back to the previous mode.




4. Proceed with the setup by selecting **OK**: ✓


3.6.4. Custom mode settings (MV)

The **Custom** mode is used in special circumstances, for example, to compensate for temporary negative pressure caused by a fireplace or cooker hood. A timer can also be set for the **Custom** mode. In such situations, the difference between the supply and extract air flows should not exceed 30%.

1. Set a timer for the **Custom** mode (optional).



2. Set the **Custom** mode's fan speeds and supply air temperature.



3. Proceed with the setup by selecting **OK**: ✓


3.7. Completion of setup or configuration of additional settings

You can either complete the setup or proceed to configure additional settings.

The available additional settings are:

- **Modbus settings**
- **Relay settings**
- **Input settings**
- **Access rights**
- **Control settings**


Complete the setup or proceed to configure additional settings.




3.7.1. Configuration of Modbus settings

Configuring the Modbus settings is necessary if an external Modbus (e.g. building automation) is used to control the ventilation unit.

1. Open **Modbus settings**.



2. Configure the Modbus settings.




3. Proceed with the setup by selecting **OK**: ✓


3.7.2. Configuration of relay settings

The relay is used to control devices connected to the duct radiator, such as the pump or solenoid valve. Please note that the relay's voltage is only 24 V, so a contactor, for example, must be used to control the 230 VAC feed.

1. Open **Relay settings**.




2. Select a relay setting.



- Select **Maintenance reminder** to notify e.g. the cooker hood or building automation system of the need for filter replacement.
- Select **Error message** to notify e.g. the cooker hood or building automation system of ventilation unit errors.
- Select **Error message and maintenance reminder** to notify e.g. the cooker hood or building automation system of ventilation unit errors and the need for filter replacement.
- Select **Emergency stop** to notify e.g. the cooker hood or building automation system when the emergency stop is activated.
- Select **Position of the bypass damper** to notify the building automation system of the position of the ventilation unit's bypass damper. The position options are heat recovery or bypass mode.
- Select **Duct radiator control** to control the ventilation unit's external liquid radiator, e.g. an MLV radiator, with the unit. This setting is selected in special situations, when a duct radiator has been installed in the ventilation duct system.
- Select **Air heating** to control e.g. a liquid heating radiator in the supply air duct with the ventilation unit.
- Select **On/off status** to notify e.g. the building automation system when the ventilation unit has been turned off or the fans have stopped. The On/off status setting can also be used to control external gate valves.
- Select **None** when the relay function is not in use.

3. Configure the relay setting.




4. Proceed with the setup by selecting **OK**: ✓

3.7.3. Configuration of input settings

The following inputs can be configured:

- Analog input
- Digital input 1
- Digital input 2

1. Open **Input settings**.




2. Proceed to configure the settings.


3.7.3.1. Analog input settings

Analog inputs are used when the ventilation unit is controlled with voltage signals. When voltage signals are used, the ventilation mode is changed according to an external voltage from the cooker hood, external controller or building automation system. The analog input is connected to the AN/I and GND terminals in the ventilation unit's connection box.

1. Open **Analog input settings**.




2. Configure the analog input settings.




3.7.3.2. Digital input settings

Digital inputs are used when the ventilation unit is controlled with external contact data. The digital inputs are connected to the D/I 1 and +24 V or D/I 2 and +24 V terminals of the ventilation unit's connection box. Please note that the programmable input can be connected to either digital input but they always have identical settings.

1. Open **Digital input settings**.



2. Configure the digital input settings.



Digital input settings:

- **Custom mode off / on** — Used to compensate for negative pressure caused by e.g. a fireplace, cooker hood or central vacuum system.
- **At Home / Away** — Switches the ventilation unit to the **At Home** or **Away** mode according to external contact data from e.g. a switch.
- **Emergency stop / Normal** — Switches off the ventilation unit based on an external emergency stop message from e.g. an automation substation system or switch. Do not select the emergency stop function if the digital input is not connected to a voltage of 24 V.
- **Boost off / on** — Switches the ventilation unit to the **Boost** mode according to external contact data from e.g. a cooker hood or switch.
- **Normal operation / Heat recovery cell bypass** — Forces the heat recovery cell bypass to activate. Please note that the bypass is only activated if the outdoor temperature is above 5°C.
- **Week clock off / on** — Switches the week clock control on or off according to external contact data from e.g. a switch.
- **Programmable input off / on**


3.7.4. Determination of access rights

There are three access right tiers:

- **Extensive** — The user can change all the settings of the ventilation unit.
- **Normal** — The user can view the ventilation unit information and make limited changes to the settings.
- **Limited** — The user can change the ventilation mode and view the ventilation unit details.

For more information about access rights, see *Access level diagrams*.

1. Open **Access rights**.



2. Use the arrow buttons to select the access level.



NOTE: To confirm the access level restrictions, enter the access code.

The access level has now been set.

3. You can also set an access code. The default access code is 0000, and the access code prompt is disabled.

3.7.5. Control settings


The unit's control method can be selected in the control settings.

The control settings are:



- Temperature selection
- Humidity control
- Humidity limit
- CO2 limit
- Constant air flow limiter (CFi)

For more information, see *Control settings*.

1. Open **Control settings**.



2. Configure the Control settings.



Temperature selection (Supply air / Extract air / Cooling)

The supply air temperature control method defines how the ventilation unit controls the temperature of inflowing air. The control method determines how the unit reacts to changes in indoor and outdoor air temperature. The temperature setting (+5...+25°C, recommendation: +18°C) is set in the ventilation mode (**At Home**, **Away**, **Boost**, **Custom**) settings.

-
- **Supply air** (factory setting) — The supply air temperature is maintained at the set target value (+5...+25°C). The unit uses automatic heat recovery and, if necessary, post-heating to maintain the target temperature.
 - **Extract air** — The supply air temperature is adjusted automatically according to the temperature of air extracted from indoors. The unit reacts to changes in indoor air temperature and maintains balanced indoor air conditions. If the apartment is warm, the supply air is cooled down automatically and vice versa.
 - **Cooling** — This control method is based on the extract air temperature. In addition, ventilation is boosted when necessary to keep the supply air temperature close to the target temperature, especially in warm weather. This control method is ideal for situations, in which the indoor temperature rises easily.

Humidity control (Automatic / Manual)


The humidity control method determines how the ventilation unit reacts to the humidity level of indoor air. The unit's integrated humidity sensor is located in the extract air chamber. The unit can also be connected to an external humidity sensor (optional) installed in the apartment.

The humidity control boosts the fan speed to the speed set for the Boost mode. If the Boost mode is activated, the speed can be increased to the maximum fan speed. In any case, the humidity control does not reduce the fan speed below the level set for the active ventilation mode (e.g. At Home, Away). The humidity control can be disabled from the ventilation mode settings.

! NOTE: The humidity control does not increase the humidity level in the apartment but removes excess humidity more efficiently.

Adjustment options:

- **Automatic** (factory setting) — The automatic mode is suitable for regular household ventilation. The ventilation unit determines the normal humidity level automatically and updates it seasonally. The ventilation unit strives to restore the normal humidity level after a shower or cooking, for example. When the unit is started up for the first time, it takes approximately 3–10 hours for the unit to determine the humidity level. During this time, the humidity level cannot be adjusted and the screen says **Calibrating**. When automatic adjustment is enabled, the humidity limit is not set separately.



- **Manual** — The manual mode is ideal for spaces, in which the humidity level of indoor air stays constant around the year, for example in indoor pool facilities. The humidity level is set between 1 and 99%RH, and the ventilation unit strives to maintain this level. When manual adjustment is used, the humidity limit must be set separately (see Setting the humidity limit).

Humidity limit

- When the humidity control is set to **Automatic**, the unit determines the base level automatically. This mode is ideal for regular household ventilation, and the user does not have to set the humidity level separately. If the screen says **Calibrating**, the unit is in the middle of determining the normal humidity level.
- When the humidity control is set to **Manual**, the user must set the humidity limit between 1 and 99%RH. Usually, the suitable humidity level for a normal living environment is around 40–60%RH. A higher humidity limit (e.g. over 70%RH) is suitable for spaces with a naturally high humidity level, such as indoor pool facilities or humid work environments.

CO2 limit

The ventilation unit adjusts the fan speed automatically according to the carbon dioxide content of indoor air. The carbon dioxide level can be set between 500 and 2000 ppm, and the factory setting is 800 ppm. This level is suitable for regular household use and ensures a good indoor air quality.

You can set the level higher if, for example, there is a large number of people in the apartment simultaneously and ventilation seems to activate too easily. A lower carbon dioxide level improves the indoor air quality further, as the system reacts quickly to minor increases in carbon dioxide content and activates the ventilation.

The ventilation unit is equipped with a carbon dioxide sensor, which is located in the unit's extract air chamber. A separate carbon dioxide sensor (optional) can also be installed in the apartment. The carbon dioxide control boosts the fan speed to the speed set for the Boost mode. If the Boost mode is activated, the speed can be increased to the maximum fan speed. In any case, the carbon dioxide control does not reduce the fan speed below

the level set for the active ventilation mode (e.g. At Home, Away).

Constant airflow limit (CFi)

By default, the constant air flow limiter is deactivated. When the function is activated, it monitors the ventilation unit's operation automatically, and the unit runs as usual with the constant air flow function enabled. If ventilation performance becomes weaker due to, for example, a blocked filter, the constant air flow limiter stops the fan speed from spiking to avoid excessive noise. The limiter icon indicates when the function is active.

When the air flow returns to normal (e.g. after the blocked filter has been cleaned), the constant air flow limiter is deactivated automatically and the unit continues to adjust the constant air flow normally. The function remains in stand-by mode. The function is used in locations, where the filters are replaced centrally, for example, in apartment blocks.

4. USING MYVALLOX CONTROL

4.1. Starting the unit

If you are starting the ventilation unit for the first time or after a maintenance procedure, first connect it to the mains. This will start the unit.

If the ventilation unit was turned off from the control panel (see *Turning the unit off*), you can start it by pressing any control panel button.

4.2. Ventilation modes





The Vallox ventilation unit has five ventilation modes:


- **At Home** — Use this mode when the apartment is occupied. The Vallox ventilation unit has been set up according to the ventilation plan. The **At Home** mode changes the indoor air at the recommended rate approximately once in two hours.
- **Away** — Use this mode when the apartment is vacant for a longer period of time, e.g. during a trip or longer absence. By default, the **Away** mode's ventilation speed is 30% lower than the speed of the **At Home** mode.
- **Boost** — Use this mode to enhance ventilation when there is a large number of people in the apartment or for other reasons. By default, the **Boost** mode's ventilation speed is 30% higher than the speed of the **At Home** mode.
- **Custom** — Use this mode e.g. when lighting a fire in a fireplace. The mode is primarily used to create a momentary overpressure in the apartment.

! IMPORTANT: Prolonged overpressure can damage the building structures.

- **Automatic** — Use this mode, if the ventilation unit should maintain optimal ventilation automatically.

Table 2. Ventilation mode icons

Icon	Ventilation mode	Icon	Ventilation mode
	At Home mode		Boost mode
	Away mode		Custom mode


Icon	Ventilation mode	Icon	Ventilation mode
	Automatic mode		

TIP:
Using the **At Home**, **Away** and **Boost** modes according to need saves energy.

! IMPORTANT: If the **Custom** mode is used to create a momentary overpressure (as a fireplace switch, for example), the timer function may only be turned off if the external fireplace switch has a timer.



4.2.1. Symbols related to ventilation modes







The image below is an example of a ventilation mode screen:



The following symbols are used on the ventilation mode screens:


Table 3. Symbols for ventilation modes

Symbol	Description
	The mode in use is either At Home , Away or Boost . The week clock is turned off.
	The mode in use is either At Home , Away or Boost . The week clock is on.

Symbol	Description
	The Custom mode is used. The week clock might be turned on.
	The mode in use is either At Home , Away or Boost . The programmable input has been activated.
	The constant air flow limiter is activated and it prevents the fan speed from increasing excessively.
	The fan symbols indicate the currently used mode. <ul style="list-style-type: none"> • Fan and one shaded bar — The Away mode is in use. • Fan and two shaded bars — The At Home mode is in use. • Fan and three shaded bars — The Boost mode is in use.
	The droplet symbols indicate the relative humidity of air. <ul style="list-style-type: none"> • Droplet and one shaded bar — A humidity sensor has been installed and the relative humidity of air is normal. • Droplet and two shaded bars — The relative humidity of air is slightly higher than normal. If automatic adjustment is enabled, the fan speed increases. • Droplet and three shaded bars — The relative humidity of air is significantly higher than normal. If automatic adjustment is enabled, the fan speed increases.
	The CO ₂ symbols indicate the carbon dioxide or VOC content of air. <ul style="list-style-type: none"> • CO₂ and one shaded bar — A carbon dioxide or VOC sensor has been installed and the level is normal. • CO₂ and two shaded bars — The carbon dioxide or VOC level is slightly higher than normal. If automatic adjustment is enabled, the fan speed increases. • CO₂ and three shaded bars — The carbon dioxide or VOC level is significantly higher than normal. If automatic adjustment is enabled, the fan speed increases.

4.2.2. Changing the ventilation mode

1. Tap on the **Change mode** button  until the icon of the desired ventilation mode appears on the display.



2. Wait until the main view of the selected ventilation mode opens.


The ventilation mode has now been changed.

4.2.3. Browsing the ventilation mode information

The next sections describe how to browse the basic information of different ventilation modes. See also *Changing the ventilation mode settings*.


4.2.3.1. Browsing the At Home mode information

To browse the basic information of the **At Home** mode:

1. Press the **Change mode** button  until the icon of the **At Home** mode appears on the display:



2. Please wait until the main view of the **At Home** mode opens:



The main view shows a summary of the mode information.


3. Select **At Home information**: 
4. The first mode information screen opens:

Figure 1. At Home information CFi/MV

At home info		1/2
Supply air	(18 °C) 21 °C	
Extract	50 l/s	
Supply	(47l/s) 50 l/s	
Heat recovery		

At home info		1/2
Supply air	-13 °C	
Outdoor air	-13 °C	
Fan speed	50 %	
Heat recovery		

This screen shows the following information:

- **Supply air** — Indicates the temperature of the air blown into the building and its set value (in brackets), if the supply air is warmer than the set value.
 - **Extract (CFi)**— Indicates the current extract air flow (l/s or m³/h). The extract air flow setting is determined automatically based on the supply air flow, and the user cannot adjust it.
 - **Supply (CFi)** — Indicates the current supply air flow (l/s or m³/h). If the ventilation unit is automatically boosting the air flow in response to an increased humidity or carbon dioxide level or a need for cooling, the actual air flow can be higher than the set value. The set value is shown in brackets.
 - **Outdoor air (MV)** — Indicates the outdoor temperature.
 - **Fan speed (MV)** — Indicates the fan speed. If the automatic fan speed boost is active, the set value is shown in brackets, followed by the real fan speed.
 - **Cell status** — The ventilation unit has the following HR cell modes:
 - **Heat recovery** —The HR cell heats the air flowing in from outdoors with extract air.
 - **Cold recovery** — The HR cell cools the air flowing in from outdoors with extract air when the temperature of the air that is extracted from the apartment is two degrees lower than the outdoor temperature.
 - **Bypass** — The inflowing air bypasses the HR cell.
 - **HR cell defrost in progress** — The HR cell is being defrosted.
5. Select **Right arrow**. The second mode information screen opens:


At home info	2/2
Humidity	23 %
Carbon dioxide	446 ppm
Replace filters	19.03.2025
Time in operation	0 d 0 y

This screen shows the following information:

- **Humidity** —Indicates the highest relative humidity value measured by the sensors.
- **Carbon dioxide** — Indicates the highest carbon dioxide value measured by the sensors.
- **Replace filters** — Indicates the next recommended filter replacement date.
- **Time in operation** — Indicates for how long the unit has been running.


4.2.3.2. Browsing the Away mode information

To browse the basic information of the **Away** mode:


1. Press the **Change mode** button  until the icon of the **Away** mode appears on the display:



2. Please wait until the main view of the **Away** mode opens:



The main view shows a summary of the mode information.

3. Select **Away information**: 

The first mode information screen opens:

Figure 2. Away mode information CFi/MV

Away info		1/2	Away info		1/2
Supply air	(18 °C)	21 °C	Supply air		-13 °C
Extract		32 l/s	Outdoor air		-13 °C
Supply	(50l/s)	32 l/s	Fan speed		30 %
Heat recovery			Heat recovery		

This screen shows the following information:

- **Supply air** — Indicates the temperature of the air blown into the building and its set value (in brackets), if the supply air is warmer than the set value.
- **Extract** (CFi) — Indicates the current extract air flow (l/s or m³/h). The extract air flow setting is determined automatically based on the supply air flow, and the user cannot adjust it.
- **Supply** (CFi) — Indicates the current supply air flow (l/s or m³/h). If the ventilation unit is automatically boosting the air flow in response to an increased humidity or carbon dioxide level or a need for cooling, the actual air flow can be higher than

the set value. The set value is shown in brackets.

- Outdoor air (MV) — Indicates the outdoor temperature.
- Fan speed (MV) — Indicates the fan speed. If the automatic fan speed boost is active, the set value is shown in brackets, followed by the real fan speed.
- Cell status — The ventilation unit has the following HR cell modes:
 - Heat recovery — The HR cell heats the air flowing in from outdoors with extract air.
 - Cold recovery — The HR cell cools the air flowing in from outdoors with extract air when the temperature of the air that is extracted from the apartment is two degrees lower than the outdoor temperature.
 - Bypass — The inflowing air bypasses the HR cell.
 - HR cell defrost in progress — The HR cell is being defrosted.

4. Select Right arrow. The second mode information screen opens:


Away info	2/2
Humidity	23 %
Carbon dioxide	449 ppm
Replace filters	19.03.2025
Time in operation	0 d 0 y

This screen shows the following information:

- Humidity — Indicates the highest relative humidity value measured by the sensors.
- Carbon dioxide — Indicates the highest carbon dioxide value measured by the sensors.
- Replace filters — Indicates the next recommended filter replacement date.
- Time in operation — Indicates for how long the unit has been running.


4.2.3.3. Browsing the Boost mode information

To browse the basic information of the Boost mode:

1. Press the Change mode button  until the icon of the Boost mode appears on the display:



2. Please wait until the main view of the **Boost** mode opens:




The main view shows a summary of the mode information.

3. Select **Boost information**:



The first mode information screen opens:

Figure 3. Boost mode information CFi/MV




This screen shows the following information:

- **Supply air** — Indicates the temperature of the air blown into the building and its set value (in brackets), if the supply air is warmer than the set value.
- **Extract** (CFi) — Indicates the current extract air flow (l/s or m³/h). The extract air flow setting is determined automatically based on the supply air flow, and the user cannot adjust it.
- **Supply** (CFi) — Indicates the current supply air flow (l/s or m³/h). If the ventilation unit is automatically boosting the air flow in response to an increased humidity or carbon dioxide level or a need for cooling, the actual air flow can be higher than the set value. The set value is shown in brackets.
- **Outdoor air** (MV) — Indicates the outdoor temperature.
- **Fan speed** (MV) — Indicates the fan speed. If the automatic fan speed boost is active, the set value is shown in brackets, followed by the real fan speed.
- **Cell status** — The ventilation unit has the following HR cell modes:

- **Heat recovery** — The HR cell heats the air flowing in from outdoors with extract air.
 - **Cold recovery** — The HR cell cools the air flowing in from outdoors with extract air when the temperature of the air that is extracted from the apartment is two degrees lower than the outdoor temperature.
 - **Bypass** — The inflowing air bypasses the HR cell.
 - **HR cell defrost in progress** — The HR cell is being defrosted.
4. Select **Right arrow**. The second mode information screen opens:

Boost info	2/3
Humidity	23 %
Carbon dioxide	453 ppm
Replace filters	19.03.2025
Time in operation	0 d 0 y



This screen shows the following information:


- **Humidity** — Indicates the highest relative humidity value measured by the sensors.
 - **Carbon dioxide** — Indicates the highest carbon dioxide value measured by the sensors.
 - **Replace filters** — Indicates the next recommended filter replacement date.
 - **Time in operation** — Indicates for how long the unit has been running.
5. Select **Right arrow**. The third mode information screen opens.

This screen shows the following information:

- **Duration** — Indicates the duration of the Boost mode, when the **Boost** mode is activated. The duration is given in hours and minutes.
- **Remaining** — Indicates how much time is remaining in the Boost mode.


4.2.3.4. Browsing the Custom mode information

To browse the basic information of the **Custom** mode:


1. Press the **Change mode** button  until the icon of the **Custom** mode appears on the display:



2. Please wait until the main view of the **Custom** mode opens:



The main view shows a summary of the mode information.

3. Select **Custom information**: 

The first mode information screen opens:

Figure 4. Custom mode information CFi/MV

Custom mode info	1/2	Custom mode info	1/2
Duration	15 min	Duration	15 min
Remaining	15 min	Remaining	14 min
Supply airflow	50 l/s	Supply fan	50 %
Extract airflow	50 l/s	Extract fan	50 %

This screen shows the following information:

- **Duration** — Indicates the duration of the Custom mode, when the **Custom** mode is activated. The duration is given in hours and minutes.
- **Remaining** — Indicates how much time is remaining in the Custom mode.
- **Supply air flow** (CFi) — Indicates the current supply air flow (l/s or m³/h).
- **Extract air flow** (CFi) — Indicates the current extract air flow (l/s or m³/h).
- **Supply air fan speed** (MV) — Indicates the speed of the supply air fan as a percentage of the maximum speed.
- **Extract air fan speed** (MV) — Indicates the speed of the extract air fan as a percentage of the maximum speed.

NOTE: Unlike in other ventilation modes, the automatic boost functions (humidity, carbon dioxide and cooling) or freeze protection are not available in the **Custom** mode. The **Custom** mode should only be used temporarily to balance ventilation when a fireplace or cooker hood is used, for example.

4. Select **Right arrow**. The second mode information screen opens.

This screen shows the following information:

- **Supply air** — Indicates the temperature of the air blown into the building and its set value (in brackets), if the supply air is warmer than the set value.
- **Outdoor air** — Indicates the outdoor temperature.


4.2.3.5. Browsing the Automatic mode information

Automatic mode adjusts ventilation based on the information from humidity and carbon dioxide sensors. Humidity and carbon dioxide controls are always in operation, and the fan speed is adjusted automatically as needed.

In the Automatic mode, the default speed is the Away mode's fan speed and the temperature is the At Home mode's temperature setting. Temperature and fan speed settings cannot be adjusted separately in the Automatic mode.


The automatic mode is designed for continuous use and for maintaining good indoor air quality without separate adjustments.

To browse the basic information of the **Automatic** mode:


1. Press the **Change mode** button  until the icon of the **Automatic** mode appears on the display:



2. Please wait until the main view of the **Automatic** mode opens:



The main view shows a summary of the mode information.

3. Select **Automatic information**: 

The first mode information screen opens.

This screen shows the following information:

- **Supply air** — Indicates the temperature of the air blown into the building and its set value (in brackets), if the supply air is warmer than the set value.
 - **Extract (CFi)**— Indicates the current extract air flow (l/s or m³/h). The extract air flow setting is determined automatically based on the supply air flow, and the user cannot adjust it.
 - **Supply (CFi)** — Indicates the current supply air flow (l/s or m³/h). If the ventilation unit is automatically boosting the air flow in response to an increased humidity or carbon dioxide level or a need for cooling, the actual air flow can be higher than the set value. The set value is shown in brackets.
 - **Outdoor air (MV)** — Indicates the outdoor temperature.
 - **Fan speed (MV)** — Indicates the fan speed. If the automatic fan speed boost is active, the set value is shown in brackets, followed by the real fan speed.
 - **Cell status** — The ventilation unit has the following HR cell modes:
 - **Heat recovery** —The HR cell heats the air flowing in from outdoors with extract air.
 - **Cold recovery** — The HR cell cools the air flowing in from outdoors with extract air when the temperature of the air that is extracted from the apartment is two degrees lower than the outdoor temperature.
 - **Bypass** — The inflowing air bypasses the HR cell.
 - **HR cell defrost in progress** — The HR cell is being defrosted.
4. Select **Right arrow**. The second mode information screen opens.

This screen shows the following information:


- **Humidity** —Indicates the highest relative humidity value measured by the sensors.
- **Carbon dioxide** — Indicates the highest carbon dioxide value measured by the sensors.
- **Replace filters** — Indicates the next recommended filter replacement date.
- **Time in operation** — Indicates for how long the unit has been running.

4.2.4. Changing the ventilation mode settings

The next sections describe how to change the ventilation settings of different ventilation modes.


4.2.4.1. Change the **At Home** mode settings


To change the **At Home** mode settings:

1. Press the **Change mode** button  until the icon of the **At Home** mode appears on the display:




2. Please wait until the main view of the **At Home** mode opens:




3. Select **At Home information**: 

4. Select **Edit**. 

CFi: The air flow control screen opens:



MV: The fan speed control screen opens:




5. **CFi:** Use the **Plus** and **Minus** buttons to set the target supply air flow level. The extract air flow level is adjusted automatically according to the supply air flow, and the user does not have to adjust it separately.

MV: Use the **Plus** and **Minus** buttons to set the fan speed as a percentage of the maximum output for this ventilation mode.

6. Select **Right arrow**.

The temperature control screen opens:




7. Use the **Plus** and **Minus** buttons to set the target supply air temperature for this ventilation mode.

You can set the temperature between +5°C and +25°C. The recommended temperature is +18°C or 2–3°C below room temperature.


8. Select **Right arrow**.

The screen for automatic fan speed control based on relative humidity opens:



9. Use the arrow buttons to enable or disable automatic fan speed adjustment based on relative humidity.
10. Select **Right arrow**.

The screen for automatic fan speed control based on carbon dioxide content opens:




11. Use the arrow buttons to enable or disable automatic fan speed adjustment based on carbon dioxide content.
12. Select **OK**.

The **At Home** mode settings have now been set.


4.2.4.2. Change the **Away** mode settings


To change the **Away** mode settings:

1. Press the **Change mode** button  until the icon of the **Away** mode appears on the display:



2. Please wait until the main view of the **Away** mode opens:




3. Select **Away information**: 


-
4. Select **Edit**.



CFi: The air flow control screen opens:



CFi: The fan speed control screen opens:




5. **CFi:** Use the **Plus** and **Minus** buttons to set the target supply air flow level. The extract air flow level is adjusted automatically according to the supply air flow, and the user does not have to adjust it separately.

MV: Use the **Plus** and **Minus** buttons to set the fan speed as a percentage of the maximum output for this ventilation mode.


6. Select **Right arrow**.

The temperature control screen opens:




7. Use the **Plus** and **Minus** buttons to set the target supply air temperature for this ventilation mode.
The temperature range is +5°C – +25°C.
8. Select **Right arrow**.

The screen for automatic fan speed control based on relative humidity opens:



9. Use the arrow buttons to enable or disable automatic fan speed adjustment based on relative humidity.
10. Select **Right arrow**.

The screen for automatic fan speed control based on carbon dioxide content opens:




11. Use the arrow buttons to enable or disable automatic fan speed adjustment based on carbon dioxide content.
12. Select **OK**. ✓

The **Away** mode settings have now been set.


4.2.4.3. Change the **Boost** mode settings


To change the **Boost** mode settings:

1. Press the **Change mode** button  until the icon of the **Boost** mode appears on the display:




2. Please wait until the main view of the **Boost** mode opens:



3. Select **Boost information**: 


4. Select **Edit**. 

The setup screen for the mode timer function opens:




5. Use the arrow buttons to turn the timer function on or off. The options are:
 - **On** — When the timer function is on, the selected ventilation mode is active for the period indicated by the timer.
 - **Off** — When the timer function is off, the selected ventilation mode is active until you change the mode (or the week clock changes the mode).
6. Select **Right arrow**.

The screen for setting the timer duration for the mode opens:




7. Use the **Plus** and **Minus** buttons to set the timer in hours and minutes for the mode. This value indicates the duration of boosted ventilation when the **Boost** mode is activated.
8. Select **Right arrow**.

CFi: The air flow control screen opens:




MV: The fan speed control screen opens:



9. **CFi:** Use the **Plus** and **Minus** buttons to set the target supply air flow level. The extract air flow level is adjusted automatically according to the supply air flow, and the user does not have to adjust it separately.


MV: Use the **Plus** and **Minus** buttons to set the fan speed as a percentage of the maximum output for this ventilation mode.

10. Select **Right arrow**. The temperature control screen opens:




11. Use the **Plus** and **Minus** buttons to set the target supply air temperature for this ventilation mode.
The temperature range is +5°C – +25°C.
12. Select **Right arrow**.

The screen for automatic fan speed control based on relative humidity opens:



13. Use the arrow buttons to enable or disable automatic fan speed adjustment based on relative humidity.
14. Select **Right arrow**.

The screen for automatic fan speed control based on carbon dioxide content opens:




15. Use the arrow buttons to enable or disable automatic fan speed adjustment based on carbon dioxide content.
16. Select **OK**. ✓

The **Boost** mode settings have now been set.


4.2.4.4. Change the **Custom** mode settings

To change the **Custom** mode settings:


1. Press the **Change mode** button  until the icon of the **Custom** mode appears on the display:



2. Please wait until the main view of the **Custom** mode opens:




The main view shows a summary of the mode information.

3. Select **Custom information**: 

4. Select **Edit**. 

The setup screen for the mode timer function opens:




5. Use the arrow buttons to turn the timer function on or off. The options are:
 - **On** — When the timer function is on, the selected ventilation mode is active for the period indicated by the timer.
 - **Off** — When the timer function is off, the selected ventilation mode is active until you change the mode (or the week clock changes the mode).

6. Select **Right arrow**.

The screen for setting the Custom mode duration opens.

7. Use the **Plus** and **Minus** buttons to set the **Custom** mode duration in minutes. This value indicates the duration of the **Custom** mode, when the **Custom** mode is activated. The recommended duration is 15–30 min.
8. Select **Right arrow**.

CFi: The supply air flow control screen opens:



MV: The screen for setting the supply air fan power for the mode opens:




9. **CFi:** Use the **Plus** and **Minus** buttons to set the supply air output.

MV: Use the **Plus** and **Minus** buttons to set the supply air fan output as a percentage of the maximum output for the Custom mode.

TIP: If you want to create temporary high pressure in the Custom mode, for example when a fireplace is lit or the cooker hood is used, increase the supply air output. Reducing the extract air output is not recommended.

10. Select **Right arrow**.

CFi: The extract air flow control screen opens:




MV: The screen for setting the extract air fan power for the mode opens.

11. **CFi:** Use the **Plus** and **Minus** buttons to set the extract air output.

MV: Use the **Plus** and **Minus** buttons to set the extract air fan output as a percentage of the maximum output for the Custom mode.

12. Use the **Plus** and **Minus** buttons to adjust the temperature of supply air. The temperature range is +5°C – +25°C.

The recommended temperature is +18°C, or a couple degrees cooler than the room temperature.



13. Select **OK**. ✓


The **Custom** mode settings have now been set.


4.3. Temperatures and sensors

This section describes how to browse temperature and sensor information on the MyVallox Control panel.

4.3.1. Browsing of temperature information

To browse temperature and sensor information:

1. Select **Settings**. 
2. Select **Temperatures and sensors** with the arrow buttons:




3. Select **OK**. 

TIP:

You can also access the temperature and sensor information by selecting the information button on the mode screen:



A summary of the temperatures and sensors appears:





This screen shows the following information:

- **Extract air** — Indicates the temperature of air flowing into the unit and extracted from the apartment.
- **Outdoor air** — Indicates the temperature of air flowing into the unit from outside.
- **Supply air** — Indicates the temperature of air flowing into the apartment from the unit.
- **Exhaust air** — Indicates the temperature of air flowing out of the unit.
- **External sensor** — The temperature of the external sensor is shown in the temperature and sensor view when the method of use is configured for the sensor in the expert settings.

4.3.2. Browsing of temperature statistics

To browse the temperature statistics:

1. Select **Settings**. 
2. Select **Temperatures and sensors** with the arrow buttons:




3. Select **OK**. 

TIP:

You can also access the temperature and sensor information by selecting the information button on the mode screen:




A summary of the temperatures appears:



4. Select **Statistics**. 


A graph describing the indoor air temperature in the past 24 hours appears:



NOTE:
The daily statistics are reset after a power cut.


- Select **Right arrow**.

A graph describing the outdoor air temperature in the past 24 hours appears:




- Select **Right arrow**.

A graph describing the supply air temperature in the past 24 hours appears:



- Select **Right arrow**.

A graph describing the exhaust air temperature in the past 24 hours appears:




- Exit the menu by selecting **Back**:

4.3.3. Browsing of humidity and carbon dioxide levels measured by the sensors

You can browse the humidity and carbon dioxide levels measured by individual sensors:

- Select **Settings**.
- Select **Temperatures and sensors** with the arrow buttons:




- Select **OK**.

TIP:

You can also access the temperature and sensor information by selecting the information button on the mode screen:




A summary of the temperatures and sensors appears.



4. Select **Right arrow**.


A screen showing the highest relative humidity level measured by the humidity sensors opens.




5. Select **Right arrow**.

A screen showing the highest relative humidity level measured by the humidity sensors opens again.

6. Select **Right arrow**.
7. If a carbon dioxide sensor (optional) has been installed, a screen showing the highest carbon dioxide level measured by the carbon dioxide sensors (ppm = parts per million) opens.




8. Select **Right arrow**.
9. A screen showing the highest carbon dioxide level measured by the carbon dioxide sensors opens again.


10. Exit the menu by selecting **Back**: 

4.3.4. Browsing of relative humidity and carbon dioxide statistics

The ventilation unit's integrated humidity and carbon dioxide sensors control ventilation automatically, as necessary. Ventilation can also be adjusted automatically by using an optional carbon dioxide, humidity, or VOC (air quality) sensor.

To browse relative humidity and carbon dioxide statistics:

1. Select **Settings**. 
2. Select **Temperatures and sensors** with the arrow buttons:




3. Select **OK**. 

TIP:

You can also access the temperature and sensor information by selecting the information button on the mode screen:




A summary of the temperatures and sensors appears:



4. Select **Right arrow**.

A screen showing the relative humidity level measured by humidity sensors 1–3 opens.




NOTE:

The daily statistics are reset after a power cut.

5. Select **Statistics**: 

A graph opens depicting the trend of relative humidity in the last 24 hours measured by the sensor that measured the highest value:





6. Select **Right arrow**.


A screen showing the relative humidity level measured by humidity sensors 4–6 opens. You can view the statistics like with sensors 1–3.



7. When you are ready, return to the sensor group menu by selecting **Back**: 
8. Select **Right arrow**.

A screen showing the carbon dioxide level measured by carbon dioxide sensors 1–3 opens.



9. Select **Statistics**: 
10. A graph opens depicting the trend of carbon dioxide in the last 24 hours measured by the sensor that measured the highest value:



11. Select **Right arrow**.
A screen showing the carbon dioxide level measured by carbon dioxide sensors 4–6 opens. You can view the statistics like with sensors 1–3.
12. When you are ready, return to the sensor group menu by selecting **Back**: 
13. Exit the menu by selecting **Back**: 

4.3.5. Monitoring the fan performance (CFi)


Monitoring the fan performance helps you detect when the fans are forced to increase revolutions because a filter has become blocked or there are other factors obstructing the air flow.

To view the fan performance:


1. Select **Settings**. 



2. Select the **Temperatures and sensors** menu or the info button in the main view:



3. The current status of the supply air fan and extract air fan is displayed.



The fan status is depicted as follows:

- **Good** - The fan is working normally.
- **Moderate** – The fan is under a load that is slightly higher than normal. Check for any obstructions, such as dirty filters, a blocked outdoor air grille or ice.
- **Critical** – The fan is under a high load and requires immediate action. Check for any obstructions and clean or repair the system as soon as possible.

4. Exit the menu by selecting **Back**:



4.4. Settings

This section describes how to set and change the settings of the MyVallox Control panel and the Vallox ventilation unit.


4.4.1. Filter settings

To browse the filter settings:

1. Select **Settings**.



2. Select **Filters**:



3. Select **OK**. ✓

4. A summary view of filter replacement appears:

Filters	
Reminder	On
Replaced	30.12.2028
Next reminder	27.08.2029
Reminder interval	8 months
Automatic reset interval	14 d


This screen shows the following information:

- **Reminder** — Indicates whether the reminder is enabled or disabled or in special mode.
- **Replaced** — The day on which the filters were last replaced.
- **Next reminder** — The day on which the system will remind about the next filter replacement.
- **Reminder interval** — The reminder interval for filter replacement in months.
- **Automatic reset interval** — The number of days the filter reminder is active. After this, the filter reminder is acknowledged automatically.

4.4.1.1. Setting the reminder interval for filter replacement

1. Select **Settings**. ☰

2. Select **Filters**:



3. Select **OK**. ✓


A summary view of filter replacement appears:

Filters	
Reminder	On
Replaced	30.12.2028
Next reminder	27.08.2029
Reminder interval	8 months
Automatic reset interval	14 d

4. Select **Down arrow**.

5. Select **Edit**. ✎

The **Reminder interval** screen opens:





6. Set the reminder interval in months in the **Reminder interval** field with the **Arrow** buttons. You can set the reminder interval between 1–12 months. The factory setting is 6 months.



7. Select **OK**. ✓

The reminder interval for filter replacement has now been set.

4.4.1.2. Setting the filter reminder


1. Select **Settings**. 
2. Select **Filters**:



3. Select **OK**. 
4. Select **Down arrow**.
5. Select **Edit**. 

Select the filter reminder mode:

- **On** - The filter reminder is enabled and acknowledged manually.
- **Off** - The filter reminder is disabled.
- **Special mode** - The filter reminder is enabled and acknowledged manually or automatically within the time set in the Automatic reset interval field.




6. Select **OK**. 

4.4.1.3. Setting the automatic filter reset interval


! NOTE: You can set the automatic filter reset interval if the reminder is a Special mode reminder.

1. Select **Settings**. 

2. Select **Filters**:



3. Select **OK**.
4. Select **Down arrow**.
5. Select **Edit**.
6. Select **Right arrow** **Automatic reset interval**.
7. Set the automatic acknowledgement interval in days. You can set the reminder interval between 1–60 days. The factory setting is 14 days.




8. Select **OK**.

4.4.1.4. Setting the filter replacement date

For more information about replacing the filters, see the maintenance instructions of the Vallox ventilation unit (see *Maintenance*).

1. Select **Settings**.


2. Select **Filters**:




3. Select **OK**. ✓

A summary view of filter replacement appears:

Filters	
Reminder	On
Replaced	30.12.2028
Next reminder	27.08.2029
Reminder interval	8 months
Automatic reset interval	14 d

4. Select **Edit**. 
5. Select **Filters replaced today**.
6. Select **OK** to update the filters as replaced today.



The filter replacement day has now been set.

! NOTE:

The unit sets an automatic maintenance reminder to remind you to replace the filters according to the maintenance interval set. See *Setting the reminder interval for filter replacement* and *Filter maintenance reminder*.

4.4.1.5. Filter maintenance reminder

The maintenance reminder appears in a pop-up window to remind the user to replace the filter.

Acknowledge the message by selecting **OK**.

Select **Back** to postpone the reminder by a week.


4.4.2. Display settings

The next sections describe the display settings.

4.4.2.1. Setting a sleep time


The MyVallox Control panel automatically switches to the sleep mode when the pre-set sleep time has elapsed.


1. Select **Settings**. 
2. Select **Display settings** with the arrow buttons:



3. Select **OK**. 

The **Display settings** 1/2 screen opens.



4. Use the **Plus** and **Minus** buttons to set the **Sleep time** in minutes.
5. Select **OK**. 


The **Sleep time** has now been set.


TIP:

The MyVallox Control panel automatically switches to the sleep mode when the pre-set **Sleep time** has elapsed. To reactivate the MyVallox Control panel, press any button.

4.4.2.2. Adjusting the display brightness

1. Select **Settings**. 
2. Select **Display settings** with the arrow buttons:





3. Select **OK**. 

The **Display settings** screen opens.

4. Select **Right arrow**.

The **Display settings 2/2** screen opens.




5. Use the **Plus** and **Minus** buttons to adjust the display brightness.
6. Select **OK**. 


The display brightness has now been adjusted.

4.4.2.3. Screen lock

1. Select **Settings**. 
2. Select **Display settings**:




3. You can enable or disable the screen lock. By default, the screen lock is disabled.




4.4.2.4. Setting a screen lock code


1. Select **Settings**. 
2. Select **Display settings**:




- The default lock code is 1001. To change the code, select **Modify**.



4.4.3. Selecting the user interface language

- Select **Settings**. 
- Select **Language** with the arrow buttons



- Select **OK**. 
- Use the arrow buttons to select a language:



- Select **OK**. 

The language has now been selected.


4.4.4. Setting the time and date

NOTE:


The time is not affected by a power cut of a few hours.

4.4.4.1. Setting the time

1. Select **Settings**.
2. Select **Time and date** with the arrow buttons.



3. Select **OK**.
4. The **Time and date** settings open.




5. Use the **Plus** and **Minus** buttons to set the hours.
6. Select **Right arrow**.
7. Use the **Plus** and **Minus** buttons to set the minutes.
8. Select **OK**.


The time has now been set.


4.4.4.2. Setting the 24-hour or 12-hour clock

The 24-hour clock is used by default. To use the 12-hour clock:


1. Select **Settings**. 
2. Select **Time and date** with the arrow buttons.




3. Select **OK**. 
- The **Time and date** settings open.



4. Select **Right arrow**.



5. The Select **Down arrow**, **24 h** setting is changed to **Off**.
6. Select **OK**. 

The 12-hour clock has now been selected.


TIP:

To switch back to the 24-hour clock, follow the steps above but select **On** at step 6.

4.4.4.3. Automatic daylight saving time


By default, automatic daylight saving time is turned on. To use the manual daylight saving time setting:

1. Select **Settings**.
2. Select **Time and date** with the arrow buttons.




3. Select **OK**.

The **Time and date** settings open.



4. Select **Right arrow**.




5. Use the **Up arrow** and **Down arrow** buttons to enable or disable automatic daylight saving time.


6. Select **OK**.


Daylight saving time has now been set.

4.4.4.4. Setting the date


1. Select **Settings**. 
2. Select **Time and date** with the arrow buttons.




3. Select **OK**. 
- The **Time and date** settings open.



4. Select **Right arrow**.



5. Use the **Plus** and **Minus** buttons to set the day.
6. Select **Right arrow**.
7. Use the **Plus** and **Minus** buttons to set the month.
8. Select **Right arrow**.
9. Use the **Plus** and **Minus** buttons to set the year.
10. Select **OK**. 

The date has now been set.

4.5. Week clock

Use the week clock to set the ventilation unit a weekly ventilation programme. You can select one of the following modes for every hour of the week:

- At Home — At Home mode on.
- Away — Away mode on.
- Boost — Boost mode on.
- Custom — Custom mode on.
- Standby mode — Standby mode on.
- Blank — Previous mode on.


NOTE:

If you change the mode manually when the week clock is used, the selected mode will be active until the next period programmed in the week clock.

If ventilation is controlled by the humidity, carbon dioxide or VOC sensors, the sensors adjust the fan speed regardless of the manually selected mode or week clock settings.

TIP:

To enable or disabled the week clock, press **OK** in the **Week clock** view for a few seconds:




4.5.1. Setting and editing a weekly program

To set a new weekly program or edit an existing weekly program:


1. Select **Settings**. 

2. Select **Week clock on**/**Week clock off** with the arrow buttons.




3. Select **OK**. ✓



The week clock's calendar view opens:






4. Select **Edit the week clock**:



5. Select **OK**. ✓
6. Select **Right arrow** to set the date.
7. Select **Down arrow** to set the time.
8. Use the **Select** button to select the ventilation mode to be activated at a certain hour. Use the **Select** button to browse the mode icons. The icons are:

-  — **At Home** mode
-  — **Away** mode

-  — Boost mode.
-  — Custom mode.
-  — Standby mode


9. Follow the steps above to set other ventilation modes for the week clock. See also *Example of setting a weekly program*.
10. When you are done selecting the ventilation modes, select **Settings**.
11. Select **OK** to save the changes. Select **Cancel** to cancel the changes. Select **Back** to make more changes to the week clock.

The week clock is now in use and follows the weekly program.

4.5.2. Turning on the week clock


To turn on the week clock:

1. Select **Settings**. 
2. Select **Week clock off** with the arrow buttons:




3. Select **OK**. 

The week clock's calendar view opens:



4. Select **Settings**. 


Week clock menu opens:



5. Select **Start week clock** with the arrow buttons.

6. Select **Select**: 

The confirmation screen opens:




The week clock is now in use and follows the weekly program.

4.5.3. Turning off the week clock

To turn off the week clock:

1. Select **Settings**. 

2. Select **Week clock on** with the arrow buttons:



3. Select **OK**. ✓
4. Select **Stop week clock** with the arrow buttons.
5. Select **OK**. ✓

The confirmation screen opens:




The week clock is now disabled. If you have set a weekly program, it is not deleted.

4.5.4. Resetting the week clock

To reset a weekly program you have set:

1. Select **Settings**. ☰
2. Select **Week clock on** / **Week clock off** with the arrow buttons.



3. Select **Remove all settings** with the arrow buttons.

The unit asks you to confirm the task.

4. Select **OK**. ✓

The confirmation screen opens.


The week clock has now been reset.

4.5.5. Example of setting a weekly program

In this example, the following weekly program has been set:

- Mon–Fri 08–16, you are away from home.
- Mon–Fri 17–07, you are home.
- Sat 08–17, you are home.
- Sat 18–20, you are home and need a ventilation boost e.g. for cooking.
- Sat 21–Mon 08, you are home.

In the images below, the week clock has been set according to the example:



Set the week clock:

1. Open the week clock (see. *Setting and editing a weekly program*)
2. Select Monday, and make the following settings:
 - 08:00: select the **Away** mode.
 - 17:00: select the **At Home** mode.
3. Then make the corresponding settings for the other weekdays.
4. Then select Saturday, and make the following settings:
 - 18:00: select the **Boost** mode.

- 21:00: select the **At Home** mode.

5. Make sure the week clock is turned on. If not, see *Turning on the week clock*.

The weekly program has now been set.

NOTE:

Do not set a ventilation mode separately for every hour. Only include the hours during which you want the ventilation mode to change.

4.6. Timed function

This section describes the timed function and its settings on the MyVallox Control panel.

4.6.1. Enabling/disabling the timed function

The timed function allows you to adjust ventilation for a specific period of time, for example, for the duration of a holiday. You can select a ventilation mode and set a start and end date for this mode.


If the timed function is enabled and you switch the ventilation unit to another mode manually, the unit returns to the timed mode at the next midnight. When the pre-set period ends, the unit switches automatically back to the **At Home** mode.

NOTE: When the timed function activates, the weekly program is disabled. If the weekly program was active before the activation of the timer function, it reactivates automatically after the pre-set period.

1. Select **Settings**.
2. Select **Timed function**:




3. Enable or disable the **Timed function**:




4.6.2. Setting the timed function's start and end date


1. Select **Settings**.
2. Select **Timed function**:



3. Set the timed function's start date:



4. Set the timed function's end date:




4.6.3. Selecting a timed ventilation mode

The timed function allows you to adjust ventilation in advance for a specific period of time, for example, for the duration of a holiday or another absence. You can pre-set any of the following ventilation modes:


- **Away** – The ventilation unit operates at a lower intensity to save energy during your absence.
- **At Home** – The ventilation unit operates at a normal intensity like in normal use.
- **Standby mode**: The ventilation unit is stopped (not recommended for constant use).

! IMPORTANT: Stopping the ventilation can deteriorate the indoor air quality, increase the accumulation of moisture in the building structures and potentially lead to mildew or ice. If you want to reduce ventilation, it is better to use the **Away** mode. In this mode, the ventilation unit operates at a lower intensity but does not stop completely.

1. Select **Settings**. 
2. Select **Timed function**:



3. Select a ventilation mode:



4.7. Expert settings

This section describes how to set and change the expert settings of the MyVallox Control panel and the Vallox ventilation unit.


4.7.1. Basic fan settings (CFi)

The basic air flow setting values can be adjusted on this configuration page. The operation of these values is based on the same principle as the air flow adjustment that is carried out during setup.


- The set value for Away mode air flows cannot be higher than the At Home or Boost mode air flows.
- The set value for At Home mode air flows cannot be lower than the Away mode air flows or higher than the Boost mode air flows.
- The set value for Boost mode air flows cannot be lower than the At Home or Away mode air flows.

This configuration page is designed for fine tuning these values. If the ventilation unit air flows need to be measured again, it is recommended to restart the setup process.

1. Select **Settings**.
2. Select **Expert settings** with the arrow buttons.



3. Select **OK**.
4. Select **Basic fan settings**.
5. Set the supply and extract air flows.



6. Select **OK**.

4.7.2. Adjusting the supply and extract air flow (MV)

TIP:

You can browse the **Basic fan settings** settings with the **Right arrow** button.

! IMPORTANT:

Adjust the air flows according to the ventilation plan. First, set the valves to the correct adjustment positions. Next, set the fans as close to the optimal value as possible by consulting the fan diagram. You can use the gauge fittings connected to the unit or delivered with the unit when adjusting the total air flow of the system. Then, measure and adjust the air flows from the valves. Try to adjust the air flows without choking them with the valves. This makes the solution as quiet and energy-efficient as possible.


If the output ratio between the air flows is very high at first, the ventilation unit may have to carry out extra defrosting cycles in sub-zero temperatures, thus making adjustment of the air flows more complicated.

! IMPORTANT:

If the ventilation unit has been set up before adjusting the air flows, we recommend you measure the air flows through the air volume adjustment menu (see **Start commissioning** under Settings management). This optimises the unit settings for air volume adjustment.

! NOTE:


If the outdoor air is very cold (aluminium unit: below -10°C; plastic unit: under -3°C), the ventilation unit may have to defrost the HR cell. In that case, the air flows cannot be adjusted and the control panel displays the **Defrosting** icon.




When you want to adjust the supply and extract air flows:


1. Select **Basic fan settings**.

- Use the **Plus** and **Minus** buttons to set the supply air fan ratio as a percentage of the maximum output ratio. The fan speed (**rpm**) will change accordingly.



- Measure and adjust the supply air flows from the valves.
- Select **Right arrow**.
- Use the **Plus** and **Minus** buttons to set the extract air fan ratio as a percentage of the maximum output ratio. The fan speed (**rpm**) will change accordingly.



- Measure and adjust the extract air flows from the valves.
- Select **OK**. 
- Supply and extract air flow settings are now complete.
- Record the set percentages in the measurement log.

4.7.3. I/O and bus settings

The next sections describe the configuration of I/O and bus settings.

4.7.3.1. Control panel address


If two control panels have been connected to the ventilation unit, the panel addresses must be different. In other words, each control panel must have a unique address. If only one control panel is used, its address can be any number between 10 and 19.

! IMPORTANT:


If your system uses multiple control panels, connect them one at a time.


To set a control panel address:


-
1. Select **Settings**. 
 2. Select **Expert settings** with the arrow buttons.



3. Select **OK**. 
4. Select **I/O and bus settings** with the arrow buttons.




5. Select **OK**. 
6. Select **Control panel address**



7. Select **OK**. 

- The **Control panel address** screen opens.



- Use the **Plus** and **Minus** buttons to set the control panel address. You can set the address between 10 and 19.
- Select **OK**. ✓

The control panel address has now been set.

4.7.3.2. **Modbus settings**


If the ventilation unit is connected to e.g. a building automation system via Modbus, configure the Modbus settings. The Modbus settings are:

- Ventilation unit's Modbus address
- Modbus baud rate
- Modbus parity
- Modbus stop bit.


The configuration of all Modbus settings is described below in the above-mentioned order. You can also refer to these instructions when configuring individual settings, such as the Modbus address.

To configure the Modbus settings:


- Select **Settings**. ☰
- Select **Expert settings** with the arrow buttons.




-
3. Select **OK**. ✓
 4. Select **I/O and bus settings** with the arrow buttons.



5. Select **Modbus settings** with the arrow buttons:




6. Select **OK**. ✓
- The **Modbus** 1/4 screen opens.




7. Use the **Plus** and **Minus** buttons to set the ventilation unit's Modbus address. You can set the address between 1 and 247.
8. Select **Right arrow**.

The **Modbus** 2/4 screen opens.




9. Use the **Plus** and **Minus** buttons to set the Modbus **Baud rate**. The options are 9600, 19200, 38400, 57600 and 115200.
10. Select **Right arrow**.
11. The **Modbus 3/4** screen opens.



12. Use the **Up arrow** and **Down arrow** buttons to set the Modbus **Parity**. The options are:
 - **no** — No parity
 - **even** — Even parity
 - **odd** — Odd parity.
13. Select **Right arrow**.

The **Modbus 4/4** screen opens.



14. Use the **Plus** and **Minus** buttons to set the Modbus **Stop bit**. The options are 1 or 2.
15. Select **OK**. ✓

The Modbus settings have now been set.

4.7.3.3. Relay settings


In the **Relay settings** menu, you can choose the operating mode of the ventilation unit's 24 V relay. Only one operating mode can be selected at a time.

NOTE:


The information is also accessible through the Modbus.


To set the operating mode of the ventilation unit's relay:


1. Select **Settings**. 
2. Select **Expert settings** with the arrow buttons.



3. Select **OK**. 
4. Select **I/O and bus settings** with the arrow buttons.




5. Select **OK**. 
6. Select **Relay settings** with the arrow buttons.



7. Select **OK**. ✓

The **Relay settings** screen opens.





8. Use the arrow buttons to select the operating mode of the 24 V relay. The options are described in the table below:

Table 4. Relay functions

Function	Ends closed	Ends open
Maintenance reminder — When the unit's maintenance reminder is activated, the relay changes its mode. This change of mode can be read by the building automation system, for example.	Normal operation	Maintenance reminder
Error message — If there is an error in the ventilation unit, the relay changes its mode. This change of mode can be read by the building automation system, for example. The error is also recorded in the error log.	Normal operation	Error situation
Error message and maintenance reminder — If the unit's maintenance reminder is activated or if there is an error in the ventilation unit or the unit has been turned off, the relay changes its mode. This change of mode can be read by the building automation system, for example. The maintenance reminder notifies the user of the need for maintenance every four months (factory setting). For more information, see <i>Maintenance</i> .	Normal operation	Maintenance reminder/error
Emergency stop — If the unit's emergency stop is activated, the relay changes its mode. The emergency stop is usually activated by an external signal received through the digital input. The emergency stop information can be sent to the building automation system, for example.	Normal operation	Emergency stop
Position of the bypass damper — The relay indicates the bypass damper position. This change of mode can be read by the building automation system, for example.	Heat recovery	Cell bypass
Duct radiator control — This setting is used in special situations, in which a duct radiator has been installed in the ventilation duct. The relay can be used to control devices connected to the duct radiator, such as the pump, solenoid valve etc. For more information, see <i>Duct radiator control</i> .	On	Off

Function	Ends closed	Ends open
<p>NOTE: The relay's voltage is only 24 V, so the information cannot be directly used to control the 230 VAC feed and e.g. a contactor is needed in between.</p>		
None — The relay function is not in use.	Normal operation	Normal operation
Air heating — This setting is used in the warm-air heater. Use the relay to control the liquid radiator actuator of the warm-air heater.	On	Off
On/off status — The relay will change the mode in error situations or when the unit has stopped.	Normal operation	Error situation/the unit has stopped

9. Confirm your choice by pressing **Select**: 
10. When you have confirmed the selection, press **Back**: 

The operating mode of the ventilation unit's 24 V relay has now been set.

4.7.3.4. Duct radiator control

The duct radiator can be placed in the outdoor or supply air duct. If the duct radiator is placed in the outdoor air duct, it can be used for pre-heating and/or cooling. If the duct radiator is placed in the supply air duct, it can only be used for cooling.

The duct radiator can be set to work automatically or manually.

- **Automatic** — In summer, the set supply air temperature is maintained. In winter, the duct radiator is switched on when the outdoor air temperature drops below the winter setting.
- **Manual** — In summer, the duct radiator is switched on when the outdoor air temperature rises above the summer setting. In winter, the duct radiator is switched on when the outdoor air temperature drops below the winter setting.


To eliminate the supply air duct's condensation risk, decide whether the supply air limit is adjusted automatically or manually:

- **Automatic** — The supply air limit is adjusted automatically according to the extract air dew point. When the supply air temperature drops too low, the duct radiator is switched off.
- **Manual** — The supply air limit can be set manually. When the supply air temperature drops below the set value, the duct radiator is switched off.


IMPORTANT:


Please note the risk of condensation when changing the duct radiator settings.


1. Select **Settings**. 
2. Select **Expert settings** with the arrow buttons.





3. Select **OK**. 
4. Select **I/O and bus settings** with the arrow buttons.



5. Select **OK**. 
6. Select **Relay settings** with the arrow buttons.




7. Select **OK**. 
- The **Relay settings** screen opens.




8. Select **Duct radiator control** as the relay's operating mode with the arrow buttons.

The **Duct radiator settings** screen opens.



9. Set the duct radiator operation with the arrow buttons. The options are:
 - **Automatic**
 - **Manual**
10. Select **Right arrow**.
11. Use the **Plus** and **Minus** buttons to set the summer setting.




NOTE:


If you have selected automatic duct radiator operation, you cannot change the summer setting. The summer setting is set between +10°C and +25°C. The factory setting is +15°C.

12. Select **Right arrow**.

13. Use the **Plus** and **Minus** buttons to set the winter setting. The winter setting is set between -10°C and +5°C. The factory setting is -5°C.




14. Select **Right arrow**.
15. Use the arrow buttons to select the duct radiator operating mode.



The options are:


- **Both** — The duct radiator is used for pre-heating and cooling.
 - **Pre-heating** — The duct radiator is only used for pre-heating.
 - **Cooling** — The duct radiator is only used for cooling.
16. Select **Right arrow**.
17. Use the arrow buttons to configure how the supply air limit is adjusted.



The options are:

- **Automatic** — The supply air limit is adjusted automatically according to the extract air dew point.
 - **Manual** — The supply air limit can be set manually.
18. Select **Right arrow**.


19. Use the arrow buttons to configure how the supply air limit is adjusted. The supply air limit is adjusted between +12°C and +25°C.



NOTE:

If you have selected automatic supply air limit adjustment, you cannot adjust the supply air limit manually.

20. Select **Right arrow**.
21. The **External sensor settings** screen opens.



Use the arrow buttons to configure the operating mode of the external sensor. The options are:

- **None** — The duct radiator is in the outdoor air duct and no external sensor has been connected.
- **Outdoor air duct radiator control** — The duct radiator and external sensor are in the outdoor air duct.
- **Air heating control** — Not used to control the duct radiator.
- **Supply air duct radiator control** — The duct radiator and external sensor are in the supply air duct.

4.7.3.5. Input settings

The ventilation unit has three inputs: one analog input and two digital inputs. You can assign different functions to each input according to the table below. The digital controls can be implemented by a push button or rocker switch. Both digital inputs recognise the switch type automatically.

Potential uses of the analog and digital inputs include a request to boost ventilation from the cooker hood/central vacuum system or a button for activating the Custom mode next to the fireplace.

The push button functions are activated whenever the push button is released. To cancel a push button function, press the button for five seconds. The rocker switch function is triggered by the switch position. When the switch is turned to ON, the function is activated. When the switch is turned to OFF, the function is deactivated. You can cancel the rocker switch function by pressing the switch for five seconds.

NOTE:

When you turn the rocker switch to ON for the first time, the function is activated after a five-second delay. After the first time, the function is activated immediately.


The rocker switch can also be used to activate a push button function. To do this, turn the switch to ON for less than five seconds. To cancel the push button function, turn the rocker switch to the ON position for more than five seconds.

The mode selected last from any user interface stays active.

You can make changes to the three inputs in the **Input settings** menu.


To make changes to the ventilation unit's analog input or digital inputs:

1. Select **Settings**. 
2. Select **Expert settings** with the arrow buttons.




3. Select **OK**. 

4. Select **I/O and bus settings** with the arrow buttons.




5. Select **Input settings** with the arrow buttons



6. Select **OK**. ✓

The **Input settings** screen opens:



7. Select an input by browsing the menu with the arrow buttons. Press **OK** at the input you want to select. The options are:

- **Analog input** — Select an analog input function.

The options are given in the table below:

Table 5. Analog input functions

Function	Voltage rating
Stop, Away, At Home, Boost, 0.1–1.0 V, 2–4 V, 5–7 V, 8–10 V — The remote monitoring system uses these voltage signals to control ventilation by changing the ventilation mode.	Stop=0.1–1.0 V, Away= 2–4 V, At Home= 5–7 V, Boost= 8–10 V

Function	Voltage rating
----------	----------------

Supply air temperature control, 0–10 V = +5°C – +25°C – The remote monitoring system uses these voltage signals to control ventilation by adjusting the supply air temperature.

0–10 V = +5°C – +25°C

- **Digital input 1 / Digital input 2** – Assign a function for digital input 1 or 2.

The options are given in the table below:

Table 6. Digital input control functions

Function	Rocker switch		Push button
	0 V	24 V	24 V pulse for less than 5 seconds
Custom mode off/on 0V / 24V	Off	On	On for the set time
At Home/Away 0V / 24V Does not work in the <i>Boost</i> mode.	-	Away	Switches the mode between <i>At Home</i> and <i>Away</i> .
Emergency stop / Normal operation 0V / 24V	Unit shuts down	Normal operation	-
Boost off/on 0V / 24V When the Boost mode is deactivated, the unit switches back to the previous ventilation mode.	Off	On	On for the set time.
Normal operation / HR cell bypass 0V / 24V	Automatic	Bypass	Switches the bypass mode
Week clock off/on 0V / 24V	Off	On	Switches the week clock mode
Programmable input off/on 0V / 24V	Off	On	On for the set time

! NOTE:

Only one function per input can be active at a time.

8. When you are done, select **Back** two times:



The ventilation unit's input settings have now been configured.

4.7.3.6. Programmable input


The programmable input can be used to compensate for negative pressure caused by a central vacuum system or cooker hood, for example. When the building automation system detects that the device has been turned on, it sends a signal to the digital programmable input. The ventilation unit adjusts the air flows according to the values set.

NOTE:

The ventilation unit has two digital inputs (digital input 1 and digital input 2). You can set the programmable input to activate from either digital input, but there is only one programmable input profile. Therefore, both digital inputs have the same settings.

To programme an input:

1. Select **Programmable input, 0 V / 24 V, for one digital input**. See section *Input settings*.
2. Set the duration of the programmable input in hours and minutes.



3. **CFi:** Set the air flows of the programmable input's supply air fan and extract air fan (l/s or m³/h).


MV: Set the supply and extract air fan output as a percentage of the maximum output for the programmable input.

NOTE: When compensating for differences in pressure, the difference between the supply and extract air flows should not exceed 30%.

Figure 5. Programmable input CFi/MV




- Set the target supply air temperature for the programmable input. The temperature range is +5°C – +25°C. The factory setting is 15°C.




In addition to the aforementioned expert settings, the MyVallox MyVallox Home/Cloud user interface can be used to enable or disable a timer.

4.7.3.7. External sensor settings

- Select **Settings**. 
- Select **Expert settings** with the arrow buttons.




- Select **OK**. 
- Select **I/O and bus settings** with the arrow buttons.




- Select **OK**. 

6. Select **External sensor settings** with the arrow buttons:



7. Select **OK**. ✓

The **External sensor settings** screen opens:



8. Use the arrow buttons to select the external sensor's operating mode. The options are:
- **None** — No external sensor in use.
 - **Outdoor air duct radiator control** — The duct radiator and external sensor are in the outdoor air duct.
 - **Air heating control** — Only used for air heating control.
 - **Supply air duct radiator control** — The duct radiator and external sensor are in the supply air duct.

4.7.4. Access rights

The next sections describe how to set an access code and enable the access code prompt and how to set the access level.

4.7.4.1. Access code

The access code is used to restrict the use of the ventilation unit functions at different access levels. If the access code prompt is enabled and the access level is limited or normal, the user is required to enter the access code before certain settings can be changed.

When the access code prompt is active, a lock icon appears on the screen. The access code consists of four digits.

NOTE:

If you do not change the default access code 0000, the access code prompt is disabled.

To set a new access code:

1. Select **Settings**.
2. Go to **Expert settings** and select **Access rights**.



3. Go to **Access code** and select **Modify** to change the access code. The default access code is 0000, and the access code prompt is disabled.



4.7.4.2. Access level

The access level determines which settings the user can change and access. The access levels are:


- **Limited** — The user can change the ventilation mode and view the ventilation unit information. However, the user cannot change the system settings.
- **Normal** — The user can view the ventilation unit information and make limited changes to the settings. Access to expert settings is restricted.
- **Extensive** — The user can change all settings of the ventilation unit.

The factory-set access level is **Extensive**.

TIP: See also *Access level diagrams*.

To change the access level of the ventilation unit:

1. Select **Settings**.
2. Go to **Expert settings** and select **Access rights**.



3. Select the desired access level.



NOTE: To confirm the access level restrictions, enter the access code.

4.7.5. Defrost settings

The next sections describe the settings related to the ventilation unit's defrosting feature.

4.7.5.1. Defrosting method

The HR cell is defrosted when it becomes frozen. The defrosting method determines how the HR cell is defrosted. Depending on the accumulation of ice, the defrosting process takes 15–45 minutes. This function is used in winter.

The defrosting methods:

- **Bypass** (factory setting) — The HR cell is bypassed from the supply air side. The supply and extract air fans function normally, and the ventilation balance remains constant during defrosting. This prevents drafts or air breaks caused by differences in pressure. This setting is recommended for tightly sealed buildings that may experience negative pressure. When the bypass function is used, the ventilation unit's post-heating resistor and optional additional heating resistor must be activated.


- **Supply fan stop** — The supply air fan stops during defrosting. This causes temporary negative pressure in the apartment. This setting is recommended if the indoor air temperature is exceptionally low (<15°C) or if you want to reduce the use of the heating resistors during defrosting.

! IMPORTANT:


It is usually not necessary to adjust the defrosting settings. The factory settings suffice in normal household use. In exceptional situations, for example, in indoor pool facilities or when a great amount of ice accumulates in the exhaust air duct, the settings could be adjusted.

To set the defrosting method:

1. Select **Settings**.
2. Go to **Expert settings** and select **Defrost settings**:



3. Select a defrosting method.




! NOTE: If post-heating and additional heating is not used, the fan is automatically stopped for defrosting and no other defrosting method can be selected.


4.7.5.2. Supply air temperature during defrosting

The supply air temperature setting determines the supply air temperature during bypass defrosting. The temperature range is 12–20°C (factory setting: 15°C). In severe frost, if the heating resistor's capacity is not enough, the ventilation unit does not allow the supply air temperature to drop below 12°C.

-
1. Select **Settings**: 
 2. Go to **Expert settings** and select **Defrost settings**:




3. Set the target supply air temperature during defrosting. The temperature range is +12°C – +20°C. The factory setting is 15°C.




4.7.5.3. Defrost sensitivity (CFi)

The defrost sensitivity setting determines how easily the ventilation unit starts to defrost the HR cell.

1. Select **Settings**. 
2. Go to **Expert settings** and select **Defrost settings**:



- If necessary, adjust the defrost sensitivity. The factory setting is 0, which is usually sufficient in normal use.



4.7.5.4. Adjusting the defrost humidity level (MV)


The humidity of indoor air affects the freezing of the HR cell significantly. The unit is optimised to operate in normal household conditions. If the unit is used in exceptional humidity conditions, for example in indoor pool facilities, the humidity level set for defrosting may have to be adjusted. The humidity percentage should be higher than zero in exceptional conditions and lower than zero in dry conditions.

! IMPORTANT:

Do not change the relative humidity of indoor air without consulting an HVAC expert.


To set the relative humidity of indoor air:

- Select **Settings**. 
- Select **Expert settings** with the arrow buttons. 




- Select **OK**. 

4. Select **Defrost settings** with the arrow buttons.



5. Select **OK**. ✓
6. Select **Right arrow**.

The **Defrost settings** screen opens:



7. Use the **Plus** and **Minus** buttons to adjust the humidity level. The factory setting is 0%, which is a normal indoor air humidity level. The humidity range is -50% – +50% RH.
8. Select **OK**. ✓

The defrost humidity level has now been adjusted.

4.7.5.5. Outdoor air temperature (MV)

The outdoor air temperature setting influences the unit's operation in very cold conditions (aluminium cell: below -20°C; plastic cell: below -5°C). The setting is optimised according to the cell type and installation conditions.


! IMPORTANT:

Do not change the outdoor air temperature without consulting an HVAC expert.


To set the outdoor air temperature:

1. Select **Settings**. ☰

2. Select **Expert settings** with the arrow buttons.




3. Select **OK.** ✓
4. Select **Defrost settings** with the arrow buttons.



5. Select **OK.** ✓
6. Select **Right arrow** two times.

The **Defrost settings** screen opens:




7. Use the **Plus** and **Minus** buttons to set the outdoor air temperature. The setting range is 0–100%. The factory setting depends on the ventilation unit type.
8. Select **OK.** ✓


The outdoor air temperature has now been set.

4.7.6. Settings management

1. Select **Settings:** 
2. Go to Expert settings and select **Settings management:**



3. Select the desired function:



- **Restore setup settings** — Restores the ventilation unit settings configured during setup.
- **Restore factory settings** — Restores the ventilation unit's original settings. All changes made by the user are reset.
- **Start commissioning** — Launches the ventilation unit's setup process.

4.7.7. Control settings

The ventilation unit's sensors measure the air temperature, relative humidity and carbon dioxide content.

This section describes how to adjust the following sensor settings:

- Adjustment of the temperature of air flowing into the apartment
- Adjustment of humidity control

Humidity control refers to a function the ventilation unit uses to control ventilation based on the relative humidity of room air. If more than one humidity sensor is in use, the fan speed is adjusted according to the highest level.

- Humidity limit

The humidity limit refers to the air's relative humidity level. If this level is exceeded, the ventilation unit boosts ventilation.

- Carbon dioxide limit

The carbon dioxide limit refers to the air's carbon dioxide content. When the limit value is exceeded, the ventilation unit boosts ventilation. If more than one carbon dioxide sensor is in use, the fan speed is adjusted according to the highest level. The carbon dioxide sensor is an optional accessory.

! NOTE:

The indicative maximum carbon dioxide content of good room air is 900 ppm.

Other limits related to carbon dioxide content:

- 1200 ppm — Limit of acceptable indoor air
- 700 ppm — Limit of excellent indoor air

Source: Classification of Indoor Environment 2018


- Constant air flow limiter

4.7.7.1. Setting the supply air temperature control method

The supply air temperature control method defines how the ventilation unit controls the temperature of inflowing air. The control method determines how the unit reacts to changes in indoor and outdoor air temperature. The temperature setting (+5...+25°C, recommendation: +18°C) is set in the ventilation mode (At Home, Away, Boost, Custom) settings.

To change the supply air temperature control method:

1. Select **Settings**.
2. Select **Expert settings** with the arrow buttons.




3. Select **OK**.

4. Select **Control settings** with the arrow buttons.



5. Select **OK**. ✓

The **Control settings** screen opens:



6. Use the arrow buttons to select the control method of the supply air temperature.

The options are **Supply air**, **Extract air**, and **Cooling**.

- **Supply air** (factory setting) — The supply air temperature is maintained at the set target value (+5...+25°C). The unit uses automatic heat recovery and, if necessary, post-heating to maintain the target temperature.
 - If the air temperature is lower than the target supply air temperature after the air has passed through the HR cell, the ventilation unit activates the post-heating resistor.
 - If heating the supply air is not necessary, the HR cell is bypassed.
- **Extract air** — The supply air temperature is adjusted automatically according to the temperature of air extracted from indoors. The unit reacts to changes in indoor air temperature and maintains balanced indoor air conditions. If the apartment is warm, the supply air is cooled down automatically and vice versa.
 - If the extract air temperature is lower than the supply air temperature set for the active ventilation mode, the unit increases the supply air temperature (max. 10°C). If necessary, the unit uses the post-heating resistor.
 - If the extract air temperature is higher than the supply air temperature set for the active ventilation mode, the unit reduces the supply air temperature (max. 10°C). If heating the supply air is not necessary, the HR

cell is bypassed.

- **Cooling** — This control method is based on the extract air temperature. In addition, ventilation is boosted when necessary to keep the supply air temperature close to the target temperature, especially in warm weather. This control method is ideal for situations, in which the indoor temperature rises easily.

NOTE:

If the outdoor air is warmer than the indoor air, the ventilation unit is not able to cool the supply air. If the outdoor air is colder than the indoor air, it is recommended partial bypass be activated to maintain the target supply air temperature.

7. Select **OK**. ✓

The temperature control method has now been set.


4.7.7.2. Humidity control (Automatic / Manual)

The humidity control method determines how the ventilation unit reacts to the humidity level of indoor air. The unit's integrated humidity sensor is located in the extract air chamber. The unit can also be connected to an external humidity sensor (optional) installed in the apartment.

The humidity control boosts the fan speed to the speed set for the **Boost** mode. If the **Boost** mode is activated, the speed can be increased to the maximum fan speed. In any case, the humidity control does not reduce the fan speed below the level set for the active ventilation mode (e.g. **At Home**, **Away**). The humidity control can be disabled from the ventilation mode settings.

NOTE: The humidity control does not increase the humidity level in the apartment but removes excess humidity more efficiently.

1. Select **Settings**. 
2. Select **Expert settings** with the arrow buttons.




3. Select **OK**. ✓

4. Select **Control settings** with the arrow buttons.



5. Select **OK**.
6. Select **Right arrow**.

The **Control settings** screen opens:



7. Use the arrow buttons to select the humidity control adjustment method.

The options are:

- **Automatic** (factory setting) — Use the **Automatic** setting for regular apartment ventilation. If automatic humidity control is in use, the unit determines the normal humidity level and records it. The unit strives to restore this humidity level after a shower, for example. The normal humidity level changes automatically seasonally. If you are using the **Automatic** setting, you do not have to manually adjust the humidity limit.

! NOTE: Automatic humidity control is selected during unit setup. It takes 3–10 hours to determine the relative humidity level. The humidity level cannot be adjusted during this period.

- **Manual** — Use the **Manual** setting in places, where the humidity level of indoor air stays constant around the year. For example, this setting is recommended for use in indoor swimming pools. You can set the humidity level between 1–99%RH. The unit strives to maintain this humidity level. If you are using the **Manual** setting, remember to set the humidity limit.

For more information about setting the humidity limit, see section *Setting the humidity*

limit.

8. Select **OK**. ✓

The humidity control adjustment method has now been set.

4.7.7.3. Setting the humidity limit

The humidity limit means the relative humidity content of air that triggers boosted ventilation when exceeded.

NOTE:


The humidity level must only be set if manual humidity control adjustment is enabled.

When the humidity control is set to **Automatic**, the unit determines the base level automatically. This mode is ideal for regular household ventilation, and the user does not have to set the humidity level separately. If the screen says **Calibrating**, the unit is in the middle of determining the normal humidity level.

When the humidity control is set to **Manual**, the user must set the humidity limit between 1 and 99%RH. Usually, the suitable humidity level for a normal living environment is around 40–60%RH. A higher humidity limit (e.g. over 70%RH) is suitable for spaces with a naturally high humidity level, such as indoor pool facilities or humid work environments.


To set the humidity limit:

1. Select **Settings**. 
2. Select **Expert settings** with the arrow buttons.




3. Select **OK**. ✓

4. Select **Control settings** with the arrow buttons.



5. Select **OK**. ✓
6. Select **Right arrow** two times.

The **Control settings** screen opens:



7. Use the **Plus** and **Minus** buttons to set the humidity level as a percentage.
8. Select **OK**. ✓

The humidity level has now been set.

4.7.7.4. Setting the carbon dioxide limit

The carbon dioxide limit refers to the air's carbon dioxide content. When the limit value is exceeded, the ventilation unit boosts ventilation. If more than one carbon dioxide sensor is in use, the fan speed is adjusted according to the highest level. The carbon dioxide sensor is an optional accessory.

! NOTE:

The indicative maximum carbon dioxide content of good room air is 900 ppm.

Other limits related to carbon dioxide content:

- 1200 ppm — Limit of acceptable indoor air
- 700 ppm — Limit of excellent indoor air

Source: Classification of Indoor Environment 2018

The ventilation unit adjusts the fan speed automatically according to the carbon dioxide content of indoor air. The carbon dioxide level can be set between 500 and 2000 ppm, and the factory setting is 800 ppm. This level is suitable for regular household use and ensures a good indoor air quality.


You can set the level higher if, for example, there is a large number of people in the apartment simultaneously and ventilation seems to activate too easily. A lower carbon dioxide level improves the indoor air quality further, as the system reacts quickly to minor increases in carbon dioxide content and activates the ventilation.


The ventilation unit is equipped with a carbon dioxide sensor, which is located in the unit's extract air chamber. A separate carbon dioxide sensor (optional) can also be installed in the apartment.

The carbon dioxide control boosts the fan speed to the speed set for the Boost mode. If the **Boost** mode is activated, the fan speed can be increased to the maximum fan speed. In any case, the carbon dioxide control does not reduce the fan speed below the level set for the active ventilation mode (e.g. **At Home**, **Away**).

To set the carbon dioxide limit:

1. Select **Settings**. 
2. Select **Expert settings** with the arrow buttons.




3. Select **OK**. 
4. Select **Control settings** with the arrow buttons.



5. Select **OK**. 

6. Select **Right arrow** three times.

The **Control settings** screen opens:



7. Use the **Plus** and **Minus** buttons to set the carbon dioxide limit in parts per million (ppm). You can set the limit between 500 and 2000 ppm. The factory setting is 900 ppm.

8. Select **OK**. 

The carbon dioxide limit has now been set.

4.7.7.5. Activating the constant air flow limiter (CFi)

By default, the constant air flow limiter is deactivated. When the function is activated, it monitors the ventilation unit's operation automatically and the unit runs as usual with the constant air flow function enabled. If ventilation performance becomes weaker due to, for example, a blocked filter, the constant air flow limiter stops the fan speed from spiking to avoid excessive noise.

The limiter icon in the main view indicates when the function is active:



The limiter icon in the main view indicates when the function is active:




When the air flow goes back to normal (e.g. after the blocked filter has been cleaned), the constant air flow limiter is deactivated automatically and the unit continues to adjust the constant air flow normally. The function remains in stand-by mode.

The function is used in locations where the filters are replaced centrally, for example, in apartment blocks.


To enable the constant air flow limiter:

1. Select **Settings**. 

- Go to **Expert settings** and select **Control settings**.




- Enable or disable the constant air flow limiter.





4.7.8. Bypass settings of the HR cell


- Select **Settings**.
- Select **Expert settings** with the arrow buttons.



- Select **OK**.
- Select **Bypass settings of the HR cell** with the arrow buttons




5. Select **OK**. 
- The **Bypass settings of the HR cell** screen opens.
6. Select with the arrow buttons:



- **Bypass On** — Bypass automatics are in use.
- **Bypass Off** — Bypass automatics are not in use. The **Heat recovery** mode is active.

7. Select **Right arrow**.

Select with the arrow buttons:



- **Partial bypass On** — Partial bypass is enabled when bypass is activated and the outdoor air temperature exceeds the value set for the heating season.
- **Partial bypass Off** — Partial bypass is not in use.
- **Special modes** — Partial bypass is always in use.

! IMPORTANT:


The **Special modes** mode is only used in special modes when the heat load is large. Do not select **Special modes** without consulting an HVAC expert.

4.7.9. Heating settings


! IMPORTANT:

Do not change the heating settings without consulting an HVAC expert.


1. Select **Settings**.
2. Select **Expert settings** with the arrow buttons.



3. Select **OK**.
4. Select **Heating settings** with the arrow buttons:




5. Select **OK**.
- The **Heating settings** screen opens:
6. Select the heating method with the arrow buttons:



- **Electrical resistor**
- **Water heater**
- **None**

7. Select **Right arrow**.


8. Select the additional heating method with the arrow buttons:



- Electrical resistor
- Water heater
- None

9. Select Right arrow.

10. Use the Plus and Minus buttons to select the heating season setting. The temperature range is 0°C – +19°C. The factory setting is +12°C. Seasonal heating is triggered by the outdoor air temperature. When the outdoor air temperature drops below the set value, post-heating may be used to heat the supply air. 100% bypass is always used for heat recovery.




NOTE: When the outdoor air temperature is above the reference value:

- Seasonal heating is not in use.
- The supply air heater is not in use.
- Bypass and partial bypass are in use.

11. Select Right arrow.

12. Select HR cell with the arrow buttons:



- Aluminium

- Plastic
- Enthalpy


4.8. Service menu


This section describes the **Service menu** of the MyVallox Control panel.


4.8.1. Unit information

Unit information is a list of all the ventilation unit properties and different ventilation events.

1. Select **Settings**. 
2. Select **Service menu** with the arrow buttons.



3. Select **OK**. 
4. Select **Unit information** with the arrow buttons:



5. Select **OK**. 

The **Unit information** screen opens:

Unit info	
SW version	2.0.29
Humidity sensors (pcs)	1
CO2 sensors (pcs)	1
Type	

6. The information appears on six different screens. Use the arrow buttons to move between the screens. The information is:


- **Software version** — Software version of the ventilation unit
- **Humidity sensors (pcs)** — Number of humidity sensors connected to the unit
- **CO2 sensors (pcs)** — Number of carbon dioxide sensors connected to the unit
- **Type** — Type code of the ventilation unit
- **Model** — Model of the ventilation unit
- **Serial number** — Serial number of the ventilation unit
- **Time in operation** — The operating time of the ventilation unit in days and in years
- **Latest power cut** — Time elapsed since the latest power cut
- **Handedness** — Ventilation unit handedness. The ventilation unit is either right-handed (R) or left-handed (L).
- **IP address** — The IP address of the ventilation unit
- **Gateway** — The gateway of the ventilation unit
- **Mask** — The mask of the ventilation unit
- **Extract air** — The temperature of extract air.
- **Exhaust air** — The temperature of exhaust air.
- **Outdoor air** — The temperature of outdoor air.
- **Supply air** — The temperature of supply air.
- **Supply air temperature** — The temperature of air from the HR cell.
- **External sensor** — External sensor temperature.
- **Cloud connection status**:
 - **Not connected** — The ventilation unit has not been connected to the MyVallox Cloud service.
 - **Connected** — The ventilation unit is connected to the MyVallox Cloud service.
 - **Connection error** — Failed to connect to the MyVallox Cloud service.
 - **Bad Gateway error** — Invalid gateway address.
 - **DNS error** — The DNS name service is not working.
 - **Certificate error** — Invalid ventilation unit certificate. Please contact the service centre.
 - **Handshake error** — Failed to connect to the MyVallox Cloud service.
 - **Internal error** — Internal error in the ventilation unit. Please contact the service centre.
 - **Old software version** — The ventilation unit uses an old software version.

- Software update in progress — Updating the ventilation unit software.
- MyVallox Cloud UUID — The unique ID of the ventilation unit in the MyVallox Cloud service.

TIP:

If the ventilation unit fails to connect to MyVallox Cloud, check that:


- The ventilation unit is connected directly to a router.
- The router assigns the ventilation unit a private IP address (starting with 192, 172 or 10).
- You can access <https://cloud.vallox.com> on a computer browser via LAN.
- The router input ports 80 and 443 are available.

7. Select **Back**. 


4.8.2. Error log

To view and acknowledge errors:

1. Select **Settings**. 
2. Select **Service menu** with the arrow buttons.




3. Select **OK**. 
4. Select **Error log** with the arrow buttons:



5. Select **OK**. 


The **Error log** screen displaying a list of errors opens:



6. Use the arrow buttons to browse the error messages in the error log. To acknowledge error messages in the error log:
- Select an error message.

- Select **OK**. ✓

A detailed error message screen opens:





The detailed error message contains the following information:


- **Error name** — The top row in the detailed error notification describes the error.
- **1st occurrence** — Time when the error occurred for the first time.
- **Times occurred** — The number of times the error has occurred.
- **Latest occurrence** — Time when the error last occurred.
- **Severity** — Seriousness of the error.
- **Status** — Error alarm status. The status options are:
 - **Acknowledged** — Error acknowledged. No active alarm for the error.
 - **Alarm** — The alarm is active until the error is acknowledged.

- To acknowledge the error message, select **OK**: ✓

The error is shown acknowledged in the error list:




d. To acknowledge more error messages, select **Back**: 

7. Select **Back**. 

4.8.3. Fan test

Carry out the fan test to easily check the operation of the ventilation unit's fans.


1. Select **Settings**. 
2. Go to the Maintenance menu and select **Fan test**.



3. Select the fan to be tested (**Supply air** or **Extract air**) and:
 - **CFi**: Adjust the fan's airflow (l/s or m³/h).
 - **MV**: Set the extract air volume as a percentage of the maximum output.

You can hear when the fan speed changes according to the value set. The fan's rotational speed is shown in the **rpm** field.


Figure 6. Fan test CFi / MV




4.8.4. Heater test

To test the operation of the ventilation unit's heaters:

1. Select **Settings**.
2. Select **Service menu** with the arrow buttons.




3. Select **OK**.
4. Select **Heater test** with the arrow buttons:




5. Select **OK**.


The **Heater test** 1/2 screen opens:



6. Use the **Up arrow** button to enable post-heating.
7. Make sure the post-heating function is working.
8. Use the **Down arrow** button to disable post-heating.
9. Select **Right arrow**.

The **Heater test 2/2** screen opens:



10. Use the **Up arrow** button to turn on the additional heating resistor.
11. Make sure the additional heating resistor is working.
12. Use the **Down arrow** button to turn off the additional heating resistor.
13. Select **Back**. 


The heater test has been completed.

4.8.5. HR cell bypass test

To test the operation of the HR cell's bypass damper:


1. Select **Settings**. 

2. Select **Service menu** with the arrow buttons.




3. Select **OK**. ✓

4. Select **HR cell bypass test** with the arrow buttons:



5. Select **OK**. ✓


The **Position of the bypass damper** screen opens:



6. Use the arrow buttons to select the damper position. The options are:

- **Normal operation** — The HR cell bypass test is disabled, the bypass damper moves normally.
- **Heat recovery** — The damper is closed (“winter position”) and air flows through the HR cell.
- **Bypass** — The damper is open (“summer position”) and air passes by the HR cell.


7. Open the ventilation unit door to make sure the damper moves to the right position.


8. Select **Back**. 
9. The HR cell bypass test has been completed.


4.8.6. HR cell defrost

To defrost the HR cell manually:

1. Select **Settings**. 
2. Select **Service menu** with the arrow buttons.



3. Select **OK**. 
4. Select **HR cell defrost** with the arrow buttons:



5. Select **OK**. 

The unit asks you to confirm the task:



6. Select **OK**. ✓

Defrosting begins:



The defrosting process takes approximately 15–45 minutes, and when complete, the ventilation unit returns to normal operation.

7. Select **Back**. ↶

4.9. Turning the unit off

! IMPORTANT:


It is recommended ventilation be kept on constantly.

! NOTE:

The ventilation unit cannot be turned off when the external input has been set to **Emergency stop**.


To turn the ventilation unit off e.g. for maintenance:

1. Select **Turn unit off** with the arrow buttons



2. Select **OK**. ✓

3. The unit asks you to confirm the task:



4. Select OK. ✓

The ventilation unit has now been turned off.

TIP:

To restart the ventilation unit, press any button.

5. UPDATING THE UNIT SOFTWARE (MYVALLOX CONTROL)

To update the ventilation unit software through the MyVallox Control panel:

1. Download the latest update package to your computer from the home page of the MyVallox Cloud service <https://cloud.vallox.com>. You can find the latest update under Latest firmware version.

NOTE: The name of the update file must always be the same: HSWUPD.BIN. If you have downloaded an older update file to your computer, delete it before downloading the new update to make sure the file name does not change.

2. Connect the computer to the ventilation unit control panel with a USB Micro-B connector.

NOTE:

- The MyVallox control panel cannot be used when it is connected to the computer. A USB icon is shown on the control panel.
- If the computer is unable to find the ventilation unit, you are probably using a charging cable. Try another USB Micro-B cable.

3. When the ventilation unit is turned on, the control panel appears as an external drive in the computer's resource management.
4. Copy the new update package HSWUPD.BIN and paste it to the control panel, i.e. the root of the external drive.

IMPORTANT: Do not change the file name.

5. Make sure the update package has been completely transferred to the control panel by selecting Safely Remove USB. This is an OS-specific function.
6. Disconnect the USB cable.
7. The control panel loads the update for a moment (you can see the process on the panel) and starts to transfer the update package to the ventilation unit in the background. This takes approximately 4–5 hours.
8. When the update is complete, the unit launches the new software and restarts itself automatically.

NOTE: The ventilation unit must stay on throughout the update process. If the ventilation unit's power is cut off during the process, the transfer time of 4–5 hours starts from the beginning.

NOTE: If a red error screen appears on the control panel, the update must be downloaded again. Go back to step 1.

When the update is complete, the software version shown on the Unit information screen should

be the same as the version at <https://cloud.vallox.com>.

6. USER LEVEL DIAGRAMS

The following charts specify the user rights of three different user levels.

Figure 7. Limited user level




Figure 8. Normal user level





Figure 9. Extensive user level



VALLOX

www.vallox.com

Vallox Oy | Myllykyläntie 9-11 | 32200 LOIMAA | FINLAND

D5311/15.09.2025FIN/09.06.2026ENG/PDF