

## **INSTALLATION DATA SHEET**

## FORGED BALL VALVE - FULL PORT

## **Applications:**

W.O.G. = WATER, OIL AND GAS

W.S.P. = WORKING STEAM PRESSURE

## **Assembly: (Threaded End Ball Valves)**

- Make sure surfaces are clear and free of debris on the piping connection
- Use PTFE tape or approved sealant is recommended
- Prepare two smooth-jawed adjustable wrenches when installing the valve
- Note: A loosely fitting wrench can distort the valve and cause a leak
  - Apply one wrench on the hex nearest the joint being tightened to prevent breaking the seal between the end cap and body of the valve

			PIPE Female To Female		4		à.	Fem To	PIPE Female To Female	
	PART No.	Pipe	W.O.G.		P				53	
	BV2103-A	1/8	600	150		- 1			3 4	
	BV2103-B	1/4	600	150	3 >	PART No.	Pipe	W.O.G	W.S.P.	
	BV2103-C	3/8	600	150	/	BV2103-B-LH	1/4	600	150	
	BV2103-D	1/2	600	150		BV2103-C-LH	3/8	600	150	
	BV2103-E	3/4	600	150			1 100			
2	BV2103-H	1	600	150		BV2103-D-LH	1/2	600	150	
	BV2103-J	1-1/4	600	150		BV2103-E-LH	3/4	600	150	
	BV2103-K	1-1/2	600	150	1	BV2103-H-LH	at	600	150	
	BV2103-M	2	600	150	X	BV2103-J-LH	1-1/4	600	150	
	BV2103-N	2-1/2	400	150		BV2103-K-LH	1-1/2	600	150	
	BV2103-N BV2103-P	3	400	150	1	BV2103-M-LH	2	600	150	

Installation guide for threaded, brass, full port, two piece ball valves. (BV2103 SERIES, BV4103 SERIES, BVSE2103 SERIES, BV2101 SERIES, BV9500 SERIES)

CAUTION: Do not attempt to remove valve while under pressure nor with entrapped hazardous fluid therein. NOTE: Always test valve and system before putting system into service. (Disassembling this valve to attempt internal repairs is not recommended.)

5×45