

## **Instructions for Testing**

## Pressure Test Kits #79935 & #79965



## 79935

- · 2 1" brass plugs
- 4 red rubber gaskets
   (1 per plug, 2 extra gaskets included)
- 1 pressure test assembly



## 79965

- 2 1" brass plugs
- 4 red rubber gaskets

   (1 per plug, 2 extra gaskets included)
- 1 pressure test assembly

The valve allows the gauge to be 'zeroed' and demonstrate the system is under pressure.

- 1. The gauge is recommended for air tests; take appropriate measure to prevent corrosion if using for hydrostatic tests; in cold environments, a hydrostatic test must be properly freeze protected before testing.
- 2. For the purposes of air testing, replace the automatic air vent with the manual air vent. Install the pressure test gauge on the supply manifold at either of the 2 indicated locations (not all manifolds will support installation at hose bib location).

Caution: The gauge has a running thread with o-ring seal. Do not use dope or teflon tape on threads.

- 3. Sealing manifold end connections:
  - a. TwistSeal® (55 mm): Use 1" Brass plugs with standard thread sealant (not included).
  - **b. TwistSeal® Mini (40 mm):** Use 1" Brass plugs with Red Rubber Gaskets (1 per plug, 2 extra gaskets included).
  - c. **Do not** overtighten (Gasket can shear)
  - d. Do not add dope or teflon tape to threads.
  - e. Stainless Steel: close shut-off valves.

**Note:** the fiber gasket provided with mainfold assembly kit should not be used with an air test

4. For the pressure test use:


Air pressure: 60-80 psi (415-550 kPa)

Hydrostatic pressure: 80-100 psi (550-690 kPa)[see 1]


- 5. This test must be performed for a minimum of 12-24 hours before the placement of the topping.
- 6. Special care must be taken to check and re-tighten all joints and connections. During the pouring of the topping the pipe must be left under pressure so that possible damage to the pipe can be immediately detected.
- 7. Replacement Gaskets (Stk.# 79953) can be ordered from HeatLink through your local wholesaler.

Note: Be aware of how temperature can affect air tests.

Rising air temperature increases pressure, falling air temperature decreases pressure.



**Note:** To remove flow meter first pop off red collar with a flat head screwdriver, then remove flow meter with a 24mm wrench or deep socket. When replacing the flow meter do not over-tighten as this may damage the O-ring.



76104 Stainless Steel Manifold shown with 79965

TwistSeal® Mini Multiport (40 mm) Deluxe shown with 79935

L679935