



## GENERAL NOTES

1. ALWAYS PROTECT THE WORKSURFACE DURING INSTALLATION.
2. ALWAYS LEVEL UNITS(S) AT FINAL LOCATION.


## ATTACHMENT HARDWARE




19962-0001-00  
GLIDE & INSTRUCTION SHEET



WSR 5/16 ID ZN  
QTY. 8




WSR LOCK 5/16 ID ZN  
QTY. 8




NUT HX 5/16-18X1/2  
QTY. 8


- 1 PLACE TABLE UP-SIDE DOWN AND ALIGN LEGS WITH THE HOLES IN THE CORNER BRACKET



- 2 WITH THE HANGER BOLTS PLACED IN THE BRACKET HOLES, PLACE THE WASHERS AND NUT ON THE HANGER BOLTS



DETAIL A  
SCALE 0.150



SEE DETAIL A

- 3 FIRMLY TIGHTEN NUT TO BOLTS & APPLY GLIDES TO LEGS.  
WITH ASSISTANCE, CAREFULLY FLIP TABLE OVER

