

3-Phase Slim Power Controllers

SPR3 Series

INSTRUCTION MANUAL

DRW180136AE

Autonics

Thank you for choosing our Autonics product.

Read and understand the instruction manual and manual thoroughly before using the product.

For your safety, read and follow the below safety considerations before using.

For your safety, read and follow the considerations written in the instruction manual, other manuals and Autonics website.

Keep this instruction manual in a place where you can find easily.

The specifications, dimensions, etc. are subject to change without notice for product improvement. Some models may be discontinued without notice.

Follow Autonics website for the latest information.

Safety Considerations

- Observe all 'Safety Considerations' for safe and proper operation to avoid hazards.
- ▲ symbol indicates caution due to special circumstances in which hazards may occur.

▲ Warning Failure to follow instructions may result in serious injury or death.

01. Fail-safe device must be installed when using the unit with machinery that may cause serious injury or substantial economic loss. (e.g. nuclear power control, medical equipment, ships, vehicles, railways, aircraft, combustion apparatus, safety equipment, crime / disaster prevention devices, etc.) Failure to follow this instruction may result in personal injury, economic loss or fire.

02. Do not use the unit in the place where flammable / explosive / corrosive gas, high humidity, direct sunlight, radiant heat, vibration, impact or salinity may be present. Failure to follow this instruction may result in explosion or fire.

03. Install on the device panel, and ground to the bolt for grounding separately. Failure to follow this instruction may result in fire or electric shock.

04. Do not connect, repair, or inspect the unit while connected to a power source. Failure to follow this instruction may result in fire or electric shock.

05. Check 'Connections' before wiring. Failure to follow this instruction may result in fire.

06. Do not disassemble or modify the unit. Failure to follow this instruction may result in fire or electric shock.

▲ Caution Failure to follow instructions may result in injury or product damage.

01. Use the unit within the rated specifications.

Failure to follow this instruction may result in fire or product damage.

02. Use a dry cloth to clean the unit, and do not use water or organic solvent.

Failure to follow this instruction may result in fire or electric shock.

03. Keep the product away from metal chip, dust, and wire residue which flow into the unit.

Failure to follow this instruction may result in fire or product damage.

04. Since leakage current still flows right after turning off the power or in the output OFF status, do not touch the load terminal.

Failure to follow this instruction may result in electric shock.

Cautions during Use

- Follow instructions in 'Cautions during Use'. Otherwise, it may cause unexpected accidents.
- Use the product, after 3 sec of supplying power.
- Before use, set the mode and function according to the specification. Especially, be cautious that the product does not operate when OUT ADJ. is set to 0%. Since changing the mode / parameter during operation may result in malfunction, set the mode and function after disconnecting load output.
- Re-supply the power to the unit after the unit is discharged completely. Failure to follow this instruction may result in malfunction.
- To ensure the reliability of the product, install the product on the panel or metal surface vertically to the ground.
- Install the unit in the well ventilated place.
- While supplying power to the load or right after turning off the power of the load, do not touch the body and heat sink. Failure to follow this instruction may result in a burn due to the high temperature.
- Install a power switch or circuit breaker in the easily accessible place for supplying or disconnecting the power.
- Do not wire to terminals which are not used.
- Since inter element can be damaged when using with coil load, inductive load, etc., the inrush current must be under the rated load current.
- Do not use near the equipment which generates strong magnetic force or high frequency noise.
- This unit may be used in the following environments.
 - Indoors (in the environment condition rated in 'Specifications')
 - Altitude max. 2,000 m
 - Pollution degree 2
 - Installation category III

Product Components

- Product ×1
- 11-pin connector ×1
- Insulating barrier ×4

Manual

For the detailed information about communication, etc., please refer to the manuals, and be sure to follow cautions written in the technical descriptions. Visit Autonics website to download manuals.

DAQMaster

- DAQMaster is comprehensive device management program. It is available for parameter setting, monitoring.
- Visit Autonics website to download the manual and the program.

Ordering Information

This is only for reference.

For selecting the specified model, follow the Autonics website.

SPR 3 - ① ② ③ ④ ⑤

① Rated load voltage

- 110 VAC~
- 220 VAC~
- 380 VAC~
- 440 VAC~

② Rated load current

Number: Rated load current (unit: A)

③ Option output

- N: Alarm output
- T: Alarm output + RS485 comm. output

④ Feedback control

- N: Normal control
- F: Normal, feedback control (constant current / constant voltage / constant power)


⑤ Fuse

- N: None
- F: Supports fuse


Dimensions

- Unit: mm, For the detailed drawings, follow the Autonics website.


■ Rated load current 25 / 35 / 50 A



■ Rated load current 70 A




■ Rated load current 100 / 150 A



Insulating Barrier

It is recommended to use the included interphase barriers for insulation between phases and reduce influence from conductive material.

- Unit: mm, For the detailed drawings, follow the Autonics website.



Rated load current	A	B	C
25 / 35 / 50 A	30	28.2	300
70 A	30	28.2	300
100 / 150 A	40.5	50	370

Cautions during Installation


▲ High Temperature Caution

While supplying power to the load or right after turning off the power of the load, do not touch the body and heatsink. Failure to follow this instruction may result in a burn due to the high temperature.


■ Mount space

- When installing multiple power controllers, keep space between power controllers for heat radiation.

Horizontal: ≥ 50 mm, vertical: ≥ 100 mm



Unit Descriptions



01. Bracket [except rated load current 100 / 150 A model]

02. Indicator

Indicator	Function	
RUN	Operation indicator (green)	Turns on in the RUN mode.
MAN	Manual control indicator (green)	Turns on when adjusting load output in the manual control mode.
ALM	Alarm indicator (red)	Flashes in alarming status.
OUT	Output indicator (red)	Turns on when load control outputs.

03. Display part

RUN mode: Displays depending the front display setting

Setting mode: Displays parameter and setting value

04. Unit indicator (V, A)

Dependent on the display setting.

Display setting	V	A
Resistance and input	OFF	OFF
Voltage	ON	OFF
Current	OFF	ON
Power	ON	ON

05. [MODE] key

Enters parameter group, returns to RUN mode, moves parameters, and saves the setting value.

06. [◀], [▼], [▲] key

Enters SV setting mode and move digits.

07. Output limit adjuster (OUT ADJ)

Limits output from 0 to 100%.

08. Control input / comm. output terminal (11-pin connector terminal)

09. Terminal protection cover

10. R, S, T load input terminal

11. Alarm output / power input terminal

12. U, V, W load output terminal

13. Cooling fan

[Rated load current 70 / 100 / 150 A model]

14. Heatsink

Rated load current 100 / 150 A models have left / right mounting holes.

15. Bolt for grounding (M4)

Specifications

Model	SPR3-1	SPR3-2	SPR3-3	SPR3-4
Control phase	3-Phase			
Rated load voltage	110 VAC~ 50 / 60 Hz	220 VAC~ 50 / 60 Hz	380 VAC~ 50 / 60 Hz	440 VAC~ 50 / 60 Hz
Rated load current	Rated load current 25 / 35 / 50 / 70 / 100 / 150 A			
Display method	3 digit 7segment LED			
Indicators	Operation / manual control indicator (green) Alarm / output / unit (V, A) indicator (red)			
Auto control input	DC 4 - 20 mA, 1 - 5 VDC≐, ON / OFF contact (non-voltage input), pulse voltage (5 - 12 VDC≐)			
Manual control input	External adjuster (10 kΩ), internal adjuster (output limit)			
Digital input (DI)	RUN / STOP selectable, AUTO / MAN selectable, RESET			
Alarm output	250 VAC~ 3 A, 30 VDC≐ 3 A, 1c resistance load			
RS485 comm. output	Modbus RTU method			
Cooling method	Rated load current 25 / 35 / 50 A: natural cooling Rated load current 70 / 100 / 150 A: forced air cooling (with cooling fan)			
Unit weight (packaged)	Rated load current 25 / 35 / 50 A: ≈ 4.1 kg (≈ 4.9 kg) Rated load current 70 A: ≈ 4.2 kg (≈ 5 kg) Rated load current 100 / 150 A: ≈ 8.7 kg (≈ 9.7 kg)			
Approval	CE			

Control method	Phase control	Cycle control	ON/OFF control
Control mode	Normal / constant current feedback / constant voltage feedback / constant power feedback	Fixed cycle	-
Applied load	Resistance load, inductive load	Resistance load	Resistance load, inductive load
Output range	0 to 98%	0 to 100%	0 / 100%
Phase control output accuracy	<ul style="list-style-type: none"> Normal control: within ± 10% F.S. of rated load voltage Constant current feedback control: within ± 3% F.S. of rated load current Constant voltage feedback control: within ± 3% F.S. of rated load voltage Constant power feedback control: within ± 3% F.S. of rated load power 		

Power supply	100 - 240 VAC~ ±10% 50 / 60 Hz
Min. load current	1 A
Power consumption	Rated load current 25 / 35 / 50 A: ≤ 14 VA Rated load current 70 A: ≤ 22 VA Rated load current 100 / 150 A: ≤ 32 VA
Insulation resistance	≥ 200 MΩ (500 VDC≐ megger)
Dielectric strength	2,000 VAC~ 50 / 60 Hz for 1 min (between input and power terminal)
Output leakage currents	≤ 10 mA rms
Noise immunity	±2 kV the square wave noise (pulse width: 1 μs) by the noise simulator
Memory retention	≈ 10 years (when using non-volatile semiconductor memory type)
Vibration	0.75mm amplitude at frequency of 5 to 55Hz in each X, Y, Z direction for 2 hours
Vibration (malfunction)	0.5mm amplitude at frequency of 5 to 55Hz in each X, Y, Z direction for 10 min
Ambient temp.	-10 to 55 °C, storage: -20 to 80 °C (rated at no freezing or condensation)
Ambient humi.	35 to 85%RH, storage: 35 to 85%RH (rated at no freezing or condensation)

RS485 Communication Interface

Communication protocol	Modbus RTU
Connection	RS485
Application standard	Compliance with EIA RS485
Max. connections	31 units (address: 01 to 99)
Synchronous method	Asynchronous
Communication method	Two-wire half duplex
Communication distance	Max. 800 m
Communication speed	2400, 4800, 9600, 19200, 38400 bps
Communication response time	5 to 99 ms (default: 20 ms)
Start bit	1-bit (fixed)
Data bit	8-bit (fixed)
Parity bit	None, Even, Odd
Stop bit	1-bit, 2-bit


Load Output Formula

Type	Input	Formula
Auto (AUTO)	Current	DC 4 - 20 mA
	Voltage	1 - 5 VDC≐
	RS485 communication	Load output [%] = Control input [%] × output slope [%]
		Load output [%] = RS485 [%]
Manual (MAN)	Output limit	Internal adjuster
		External adjuster
		Load output [%] = internal adjuster [%]
		Load output [%] = external adjuster [%]
		Load output [%] = internal adjuster [%] × External adjuster [%]


Connections

• Terminal configuration by model may differ depending on the supported spec.


Control input / comm. output terminal (11-pin connector)



Alarm output / power input terminal



Load input / output terminal




01) When connecting noise filter and capacitor, it is appropriate for EMC. [CAP]
Rated load voltage 110 / 220 VAC~ : 1 μF / 250 VAC~
Rated load voltage 380 / 440 VAC~ : 0.47 μF / 500 VAC~

Cautions during Wiring


Control input / comm. output terminal (11-pin connector)

• Unit: mm, Use penhole terminals of size specified below.



Alarm output / power input & R, S, U load output terminal

• Unit: mm, Use crimp terminals of size specified below.



Rated load current	Spec.	Alarm output / power input	Load input / output
25 / 35 / 50 / 70 A	a	≥ 3.0	≥ 6.0
	b	≤ 6.0	≤ 16.0
100 / 150 A	a	≥ 3.0	≥ 8.0
	b	≤ 6.0	≤ 26.0

• Cable / screw / tightening torque spec. is different depending on the load current. Be sure to the below before connection.

Rated load current	Spec.	Alarm output / power input	Load input / output
25 / 35 / 50 / 70 A	Cable	AWG 18 to 14	AWG 13 to 4
	Screw	M3	M6
100 / 150 A	Tightening torque	0.5 N m	5.5 to 6.0 N m
	Cable	AWG 18 to 14	AWG 4 to 2 / 0
100 / 150 A	Screw	M3	M8
	Tightening torque	0.5 N m	6.5 to 7.0 N m

Alarm

• Supported alarms are different depending on the model.
• When several alarms occur at same time, the highest priority error is displayed based on priority.

Priority	Type	Display	Operation Alarm	Output	Alarm release	Model	
1	SCR error	5 L r	<ul style="list-style-type: none"> Error display flashes. Alarm indicator (ALM) flashes. Alarm output turns ON 	Output stops. (SCR OFF)	<ul style="list-style-type: none"> Re-supply power. RESET input Switch to stop (STOP) mode. 	Feedback control	
2	Over current	o - L				Feedback control	
4	Heatsink over heat	ε E n				Normal / Feedback control	
5	Over voltage	o - u				Feedback control	
3	Fuse break	F U S				Automatically cleared when returning within the setting range	Normal / Feedback control
6	Heater break	H - b				Normal operation	Feedback control

- **SCR error alarm**
Even though output is 0%, if the current of 10% or more of the rated load current flows for over 3 sec continuously, SCR error alarm occurs.
- **Over current alarm**
This function protects the load from over current. If the current flows over the P2-7 over current alarm value and P2-8 over current alarm delay time, over current alarm occurs.
- **Heatsink over heat alarm**
When the temperature of a heatsink is over 85 °C, heatsink over heat alarm occurs.
- **Over voltage alarm**
This function protects the load from over voltage. If the current flows over the P2-9 over voltage alarm value and P2-10 over voltage alarm delay time, over voltage alarm occurs.
- **Fuse break alarm**
When breaking fuse, not supplying load power, breaking load (single load), fuse brake alarm occurs. In the case of normal control model, real-time fuse break alarm is not available during output, and fuse break alarm operates at 0% output such as RESET.
- **Heater break alarm**
Comparing the full load resistance value and the current load resistance value, if the current load resistivity is maintained under the P2-12 heater break alarm value for over 3 sec continuously, heater break alarm occurs. This alarm operates when control output is over 10% and load current is over 10% of the rated current. Output does not stop and operates normally.

$$\text{Current load resistance (\%)} = \frac{\text{Full load resistance value} \times 100}{\text{Current load resistance value}}$$

Mode Setting

[MODE]	→	Monitoring group	[MODE] 3 sec	→	[MODE]
[MODE] 2 sec	→	Parameter 1 group	[MODE] 3 sec	→	[MODE]
[MODE] 4 sec	→	Parameter 2 group	[MODE] 3 sec	→	[MODE]
[MODE] 4 sec	→	Parameter reset	[MODE]	→	[MODE]
6-9 terminal external contact	→	RUN / STOP	Auto	→	RUN
7-9 terminal external contact	→	Auto / Manual control	Auto	→	RUN
[▲] + [▼] 2 sec or 8-9 terminal	→	Reset 01)	Auto	→	RUN

01) In the event of system anomalies and alarms, RESET input restarts the power controller. (parameters are not reset.)

Parameter Setting

- Some parameters are activated / deactivated depending on the model or setting of other parameters. Refer to the description of each parameter.
- If any key is not entered for 30 sec in each parameter, it returns to RUN mode.
- [MODE] key: Saves current setting value and moves to the next parameter.
- [▲], [▼] key: Changes setting values.

Monitoring group

Parameter	Display	Display range
M1-1 Monitoring value	i n	0 to 100%
M1-2 U-V line load voltage value	U - u	[Feedback control model]
M1-3 V-W line load voltage value	u - u	0 to rated voltage range, V
M1-4 W-U line load voltage value	u - u	
M1-5 U-phase load current value	U - R	[Feedback control model]
M1-6 V-phase load current value	u - R	0 to rated current range, A
M1-7 W-phase load current value	u - R	
M1-8 Load power value	L - u	[Feedback control model] 0 to rated Power range, kW
M1-9 Resistance value percentage	L - r	[Feedback control model] 0 to 100% • Displays the present resistance as percentage compared to the set resistance of full load auto recognition.
M1-10 Heatsink temp.	ε n P	0 to 100 °C
M1-11 Power supply frequency	F r q	50, 60 Hz

Parameter 1 group

Parameter	Display	Default	Setting range
P1-1 SOFT START time	5 - t	3	
P1-2 SOFT UP time	U - t	3	0 to 100 sec
P1-3 SOFT DOWN time	d - t	3	
P1-4 Output low-limit value	L - L	0	0 ≤ L-L ≤ H-L ≤ 100%
P1-5 Output high-limit value	H - L	100	
P1-6 Output slope 01)	S L P	100	0 to 100% • In case of auto control (AUTO), set the output slope limit proportional to control input for limit load power.

Parameter 2 group


Parameter	Display	Default	Setting range		
P2-1 Control input 01)	i n t	420	420: DC 4 - 20 mA 1-5: 1 - 5 VDC= 512: 5 - 12 VDC= ONF: ON / OFF contact COM: RS485 communication		
P2-2 Control method	C - n	P R	*[Feedback control model]		
			Set	Control method	
			PA	Normal	
			V-F*	Phase control	Constant voltage feedback
			C-F*	Constant current feedback	
			W-F*	Constant power feedback	
F-C	Cycle control	Fixed cycle			
ONF	ON / OFF control				
P2-3 Manual control (MAN) output limit method 01)	n R n	i - r	I_R: Internal adjuster E_R: External adjuster E_I: Internal / external adjuster		
P2-4 Input correction 01)	i n b	0.0			
P2-5 Input slope correction 01)	S P n	0.0	-99 to 99%		
P2-6 Front display	d i S	i n	*[Feedback control model] IN: Resistance and input U-V*: U-V line load voltage V-W*: V-W line load voltage W-U*: W-U line load voltage U-A*: U-phase load current V-A*: V-phase load current W-A*: W-phase load current L-W*: Load power		
P2-7 Over current alarm value	o C u	120	[Feedback control model] 0 to 120%		
P2-8 Over current alarm delay time	o C t	5	[Feedback control model] 0 to 100 sec		
P2-9 Over voltage alarm value	o u u	120	[Feedback control model] 0 to 120%		
P2-10 Over voltage alarm delay time	o u t	5	[Feedback control model] 0 to 100 sec		
P2-11 Load resistance value auto recognition	F - L	o F F	[Feedback control model] OFF, ON • It executes 100% control output for 3 sec and the load resistance value recognized automatically as the initial set when the function is ON.		
P2-12 Heater break alarm value	H b u	10	[Feedback control model] 10 to 100%, OFF		
P2-13 Comm. address	R d r	0 1	[RS485 communication output model] 01 to 99		
P2-14 Comm. speed	b P S	9 6	[RS485 communication output model] 24, 48, 96, 192, 384 bps (X 100)		
P2-15 Comm. parity bit	P r t	n o n	[RS485 communication output model] NON, EVE, ODD		
P2-16 Comm. stop bit	S t P	2	[RS485 communication output model] 1, 2 bit		
P2-17 Comm. response time	r s t	2 0	[RS485 communication output model] 5 to 99 ms		
P2-18 Comm. write	C n u	E n R	[RS485 communication output model] EN.A: Enable, DSA: Disable		
P2-19 Lock	L o C	o F F	OFF LC1: Locks parameter 1 group LC2: Locks parameter 2 group		
P2-20 Parameter reset	i n i	n o	NO, YES		

01) Set the below parameters available depends on the control input.

Type	Control input	Display	Input correction	Input slope correction	Output slope	Monitoring value
Auto control (AUTO)	Current	DC 4 - 20 mA	420	○	○	○
	Voltage	1 - 5 VDC= 5 - 12 VDC=	1-5	○	○	○
	Pulse voltage	5 - 12 VDC=	512	×	×	○
	No-voltage	ON / OFF contact	ONF	×	×	○
Manual control (MAN)	Output limit	Internal adjuster	I_R	×	×	×
		External adjuster	E_R	×	×	×
		Internal / external adjuster	E_I	×	×	×

Replacement of Fuse

Case removal



Replacement of fuse

- Fuse none model is not equipped with a rapid fuse inside. Install the suitable fuse for rated load current of the model separately.
- The performance of the product is guaranteed only when using the fuse provided by us. For replacing the fuse, use the recommended fuse.


Rated load current	Rec. fuse	Manufacturer
25 A	50FE	BUSSMANN
35 A	63ET	
50 A	80ET	
70 A	100FE	
100 A	660GH-160	HINODE
150 A	660GH-200	

Bolt specification


Rated load current	Case fixed bolt	Fuse fixed bolt
25 / 35 / 50 / 70 A	M3	M6
100 A	M4	Top: M8 Bottom: M6
150 A	M4	M8

Derating Curve


Rated load current 25 A




Rated load current 35 A




Rated load current 50 A



Rated load current 70 A



Rated load current 100 A



Rated load current 150 A

