DirecTV Set-Ups
Stored in Super Buddy Meter

Select Service	Select System	Select LNB	Meter Automatically Selects Switch	LNB Soft Keys					
				LNB 1	LNB 2	LNB 3	LNB 4	LNB 5	LNB 6
DIRECTV	Triple Sat (Sat-C)	N/A	22kHz	101	110 & 119	------	------	------	------
	Triple Sat Stacked	N/A	22kHz	101	110 & 119	------	------	------	------
	Twin Sat 101/119	N/A	22kHz	101	119	------	------	------	------
	Phase 4 AT9 Ka	N/A	22kHz	101	110 & 119	99	103	------	------
	MFH-1	N/A	DTV6x8	101	101	110 & 119	110 & 119	72.5	95
	Single Sat	N/A	none	110	------	------	------	------	------
		Single Sat 72.5	none	72.5	------	------	------	------	------
		Single Sat 101	none	101	------	------	------	------	------
		Single Sat 110	none	110	------	------	------	------	------
		Single Sat 119	none	119	------	------	------	------	------
		101 Stacked	none	101	------	------	------	------	------
		Internatnl 95	none	95	------	------	------	------	------

After powering up the Super Buddy and pressing the SYST soft key, the selections shown above are available. Select the appropriate service and system for your application. To make selections, arrow up or down to the item to change and press Enter, then arrow up or down to the desired option and press Enter. Press EXIT or DONE to return to the RUN mode. The switch type is automatically entered based on your SYSTEM and LNB selection. After choosing the System and LNB type, connect the Super Buddy to your LNB. Press the LNB soft key to power the LNBs. For multi-sat/LNB systems, use the LNB soft key to power and toggle between the different sats/LNBs. The satellite associated with each LNB selection is shown in the upper left corner of the Super Buddy's LCD screen. For single-sat/LNB systems, use the left/right arrow buttons to select different satellites.

Rev 01/10/2007