


ENGLISH

Authentication for Ethernet/LAN

By default the web-interface of the camera can be accessed without user name and password. Password protection can be activated in the on-screen menu (Advanced Settings / Ethernet Settings / Security Settings). Two user names are available: "admin" and "guest". The default password of both accounts is: "Password". In case you change these passwords, we recommend to write them down below:



Username: **admin**
Password:
Username: **guest** Default: Password
Password:
Default: Password

In case the user defined administrator password is lost, please contact your WolfVision dealer or the WolfVision support (support@wolfvision.net).

DEUTSCH

Passwortschutz für Ethernet/LAN

Der Zugang zum Web-Interface der Kamera ist im Auslieferungszustand ohne Passwort möglich. Im On-Screen Menü (Advanced Settings / Ethernet Settings / Security Settings) kann ein Passwortschutz aktiviert werden. Zwei Usernamen stehen zur Verfügung: "admin" und "guest". Das Standardpasswort ist bei beiden Benutzernamen: "Password". Sollten Sie die beiden Passwörter ändern, empfehlen wir diese hier zu notieren:



Username: **admin**
Password:
Username: **guest** Standard: Password
Password:
Standard: Password

Falls das Administrator Passwort vergessen wurde oder abhanden gekommen ist, wenden Sie sich bitte an Ihren WolfVision Händler oder den WolfVision Support (support@wolfvision.net).