



MONTERING

Ställ ventilen som skall motoriseras i halvöppet läge.

Träd ventilspindel genom konsolens hål (1).

Fäst ventilens mutter (2) något varv, skruva inte fast.

Montera medbringaren (3) över ventilspindeln och fäst med låsskruven (4)

Trä handmanöverspaken (5) över medbringaren så att den är riktad rakt uppåt.

Spänn fästmuttern (2)

Montera två bultar (6) i motorns fästen.

För ställdonsmotorn över medbringaren samt fäst den i konsolen med två muttrar (7).

För inkoppling och eventuell inställning av ställdonsmotorn hänvisas till instruktion som medföljer ställdonsmotorn.

ASSEMBLY

Position the valve half-open.

Push the valve stem through the hole in the bracket (1). Mount the valve nut (2) a few turns don't fasten fully.

Mount the driver (3) on the valve stem and secure with the locking screw (4).

Mount the manual lever (5) on the driver so that the handle points straight up.

Secure the valve nut (2).

Install two bolts (6) in the motor hold.

Mount the actuator motor over the driver and secure it with the two nuts (7).

For the electrical wiring and settings please refer to the instruction delivered together with the actuator motor.

Blank page.

