Altek

Supplement

Manual Title:	820	Supplement Issue:	**1**
Part Number:	1839053	Issue Date:	6/02
Revision/Date:	Rev A April 2002		

This supplement contains information necessary to ensure the accuracy of the above manual.

Safety Information

⚠	Caution, risk of Danger; read the manual with particular attention to WARNINGS and user operation.
CE	Conforms to European Low Voltage 73/23/EEC, EN61010-1 + Amendments 1,2 and EMC Directive 89/336/EEC standard EN61326
⎓	Direct Current: For this product only direct currents and voltages are applicable
⧈	Equipment protected throughout by DOUBLE INSULATION or REINFORCED INSULATION
CAT I	OVERVOLTAGE CATEGORY I: Signal level, special equipment or parts of equipment, telecommunications, electronics, etc., with smaller transient overvoltages than OVERVOLTAGE CATEGORY II.

Cleaning Instructions
Clean with mild soap and water with care applied in removing any excess soap or water.

⚠ WARNINGS ⚠

- **If the equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.**
- **Before use, verify the meter's operation by measuring a known voltage or current.**
- **Inspect the test leads for damaged insulation or exposed metal and do not used if damaged.**
- **Do not use this product if it is damaged. Before you use the product, inspect the case. Look for cracks or missing plastics. Pay particular attention to the insulation surrounding the connectors.**
- **To avoid false readings, which could lead to possible electric shock or personal injury, replace the batteries as soon as the low battery indicator appears.**
- **When using the probes, keep your fingers behind the exposed metal by at least 10mm.**
- **Do not operate the meter with the instrument open.**
- **Remove test probes from any measurement circuits prior to opening or changing batteries.**
- **Use only 9V alkaline batteries.**

© 2002 Altek Industries, Inc. All rights reserved. Printed in U.S.A.