



695-064 Sonoma Wine & Bar Cabinet Set-up Instructions

1. Adjust the (4) levelers on the bottom so that they are all the way screwed in. This will require (2) people; one to tip the cabinet and the other to turn the levelers in by turning them clockwise. Otherwise lay the cabinet on its back to make sure the levelers are in all the way.



2. Verify that the area where the cabinet is to be placed is flat and level. An uneven floor will make it more difficult to adjust the cabinet. Place the cabinet in the location it is going to be used. Note that a tack strip used in carpeting along the wall might effect the leveling of the cabinet.

3. To align the door gap at the top, press up on either the left or right pediment molding at the top. The door alignment will either get better or worse. If it gets better, lower the leveler on the front corner that was pushed up by turning it counter-clockwise. This will require (2) people.





4. Usually only one front leveler will need to be adjusted. However this method can be used to make any adjustments with the other (3) levelers if it is necessary.

5. Once the top gap is aligned, the doors should operate correctly. Note that the gap between the two doors cannot be adjusted with the levelers.

6. Generally the back levelers will only need to be adjusted if the top or bottom end of one of the doors sticks out further than the other.