

Microwave & Refrigerator Combo

Bracket Installation Guide



Thank you for purchasing this microwave and refrigerator combo. Before you begin assembly, make sure you have the appropriate tools and parts.

Tools Needed:

1. ¼" Drill bit (not included)
2. Drill (not included)
3. Hammer (not included)
4. T-20 Torx Wrench with tamper-proof end (included)
5. Pencil or pen (not included)
6. Safety glasses (not included)

Parts List

1. Mounting Bracket
2. Four Screws (Flat Head)
3. Four Plastic Anchors
4. Microwave
5. Refrigerator

Note: All the pictures in this guide are for reference only. Your unit may be slightly different than the images depicted. Parts included may be subject to change.

Caution: Make sure the microwave and refrigerator are not plugged in when installing the bracket. Use safety glasses when using your drill. Follow all safety precautions when using power tools.

Notes: 1. You have the option to install the microwave near the back, middle or front of the top of the refrigerator.

2. You may want to purchase an optional Amperage Overload Protector from Living Direct to keep the combo microwave refrigerator from tripping 10 Amp circuits.

Bracket Installation Instructions



1. Place and center the microwave on the refrigerator and slide the mounting bracket underneath.



2. Remove the microwave and use the mounting bracket as a template to mark the 4 holes that will be drilled on top of the refrigerator.



3. Remove the bracket and use a ¼" drill bit to drill the 4 holes you marked on top of the refrigerator.



4. Insert the 4 plastic anchors into the 4 holes you drilled. You may need a hammer to secure the anchors.



5. Place the bracket on the refrigerator. Secure the bracket by fastening the flat head screws through the bracket and into the plastic anchors.



6. Use the Torx wrench to remove the two lower screws from the back of the microwave. Then, place the microwave against the bracket and secure the two screws with the Torx wrench.