

WARNING: TO AVOID FIRE, SHOCK, OR DEATH; TURN OFF POWER AT CIRCUIT BREAKER OR FUSE. TEST THAT THE POWER IS OFF BEFORE WIRING!

CAUTION: OUTLET MUST BE WIRED TO A SEPARATE 3-WIRE CIRCUIT OF UP TO #4 AWG SIZE CONDUCTORS.

NOTE: THIS DEVICE MAY BE USED WITH COPPER, COPPER-CLAD, OR ALUMINUM WIRE.

TO INSTALL: Connect wires per wiring diagram as follows: Insert stripped wires fully into terminal holes and tighten terminal screws to 25 inch pounds.

