

# TURN OFF "FIT TO PAGE" WHEN PRINTING

**PANDUIT**  
LC OptiCam  
Fiber Optic Connector  
Stripping Template

Read installation instructions thoroughly before proceeding with termination

**900µm Buffered**

900µm Buffer  
Insertion Mark  
Bare Fiber

Insertion Mark .59" (15mm)  
Buffer Removal 1.18" (30mm)

After Cleaving .28" (7mm)

REFER TO OTHER SIDE FOR JACKETED CABLE

Stripping Template FS115

LC OptiCam Fiber Optic  
Connector Stripping Template

Read installation instructions thoroughly before proceeding with termination

**Jacketed**

Cable Jacket  
Aramid Yarn  
Insertion Mark  
900µm Buffer  
Bare Fiber

Insertion Mark .59" (15mm)  
Buffer Length .71" (18mm)  
Jacket Removal 1.89" (48mm)

Buffer Removal 1.18" (30mm)

After Cleaving .28" (7mm)

REFER TO OTHER SIDE FOR 900µm BUFFERED