

Push padlock staple through slot in the bottom of the enclosure (from inside) until it snaps in place.