
## AstroSafe® V: Test Shroud Installation


## **SUPPLEMENT TO CSP-3-110**

## Use for Overall Efficiency Test or Scan Testing with AstroScan M

- 1. Open inlet grill of the AstroSafe V and lift off hinge.
- 2 Place the Test Shroud on the hinge of the AstroSafe V.
- 3. Before closing the Test Shroud, attach the downstream duct connection tube (Fig. 1) to the downstream through wall quick disconnect on the AstroSafe V (Fig. 2).




- 4. Once the downstream duct connection tube is connected, close the test shroud (Fig.3).
- 5. Connect the photometer to the Test Shroud downstream sample port (Fig. 1) and the upstream sample port, just before the HEPA filter door (Fig. 3).
- 6. Connect the smoke generator to the Test Shroud injection port (Fig. 1).
- 7. Perform the filter test.



- 8. Once the test is completed and the filter has passed, remove the photometer, smoke generator, and test shroud.
- 9. Place the inlet grill back on the AstroSafe V hinge and close.

Note: Photometer and Smoke Generator by others.





AAF International has a policy of continuous product research and improvement. We reserve the right to change design and specifications without notice.

©2025 AAF International and its affiliated companies.