



**Notes:**

- ▲ Insert backset here  $2\frac{1}{2}"$ ,  $2\frac{3}{4}"$
- ▲ Thru bolting holes **ONLY** if required. See trim manufacturers standard template for details. Accurate locks accommodate  $1\frac{1}{2}"$  to  $1\frac{11}{16}"$  center to center and up to  $\frac{1}{4}"$  dia. post. If there are any additional questions about the thru-bolting, please contact our office.
- ▲ Lever and thumbturn holes may vary from different trim manufacturers. Please refer to their templates to confirm these dimensions.

**Additional Notes:**

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-reinforcement for proper installation of hardware shown.
- b) See catalog / spec sheets for additional lock details



**SM9159EUSD Lever x Lever  
or Knob x Knob Template  
All Backsets**

**T-ALH.SM9159EUSD.LL**