



Centerline
lock
and strike

5/32

Centerline
of door

Line up centerline of
strike with the centerline
of the door

Installation:

S-161: Install **161PDL** lock and strike using the (4) #8 screws provided, surface mount the **S161T x S161E** rectangular flush pulls using the (8) #6 screws provided.

R-161: Install **161PDL** lock and strike using the (4) #8 screws provided, surface mount the **R161T x R161E** round flush pulls using the (2) thru-bolting screws provided.



S-161 and R-161 Pocket Door Lock-
2 3/8" & 2 3/4" Backset

T-161PDL(W)