



Notes:

- Corresponding lock templates SL9100.PDL / SL9100.ADA
- Prep for #12 wood or 12-24 machine screws

additional notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) See catalog / spec sheets for additional lock details

Standard ASA Deadbolt
SL9100.PDL/SL9100.ADA Strike w/ Dust Box

T-ALH.SL9100.STK