



1
T-ALH.9100.SDL

Notes:

- 1 Corresponding lock templates (see side bar)
- 2 Prep for #12 wood or 12-24 machine screws
- 3 Centerline of strike is 1 1/4" ABOVE the centerline of the lock

additional notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) See catalog / spec sheets for additional lock details



9100SDL Strike with Dust Box

T-ALH.9100SDL.STK