



Notes:

- △ Insert backset here $2\frac{1}{2}"$, $2\frac{3}{4}"$,
- △ Prep for #12 wood or 12-24 machine screws
- △ Thru bolting holes **ONLY** if required. See trim manufacturers standard template for details.
Accurate lock's accommodates $1\frac{1}{2}"$ to $1\frac{11}{16}"$ center to centers and up to $\frac{1}{4}"$ dia. post.
If there are any additional questions about the thru-bolting, please contact our office.
- △ Knob, thumbturn and ER holes may vary from different trim manufacturers. Please refer to their templates to confirm these dimensions.

Additional Notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing
 - adequate construction or re-inforcement for proper installation of hardware shown.
- b) Please contact us if a double lip strike is needed - for a proper template
- c) See catalog / spec sheets for additional lock details

ACCURATE
LOCK & HARDWARE
AMERICAN CRAFTED SINCE 1972

Standard M9159E.USD UPSIDE DOWN
Lever x Lever or Knob x Knob
Template All Backsets

T-ALH.M9159E.USD