


## **Important Notes:**

- $\frac{1}{2}$  Insert backset here  $1\frac{1}{2}$ ,  $1\frac{3}{4}$ , 2,  $2\frac{1}{4}$ .
- ASA strike mounted  $\frac{3}{8}$ " ABOVE centerline of lock.  $\frac{3}{8}$  Prep for 12-24 machine screws (lock and strike.)
- Through-bolting holes **ONLY** if required. See trim manufacturers' standard template for details. Accurate locks accomodate  $1\frac{1}{2}$ " to  $1\frac{11}{16}$ " center to centers and up to  $\frac{1}{4}$ "dia. post. If there are any additional questions about through-bolting, please contact us.
- Knob/Lever holes may vary from different trim manufacturers. Please refer to their templates to confirm dimensions.

## **Additional Notes:**

- a) Responsibility: Door and frame manufacturers are responsible for providing adequate contruction or re-inforcement for proper intallation of hardware shown.
- b) Please contact us for double lipped template if needed.
- c) See spec sheets for additional lock details.



Required Holes

Optional Holes



Standard M8700ELR for Hollow Metal Door - All Backsets

AMERICAN CRAFTED SINCE 1972

T-ALH.M8700ELR.HM