




Additional Notes:

a) Responsibility: Door and frame manufacturers are responsible for providing adequate contruction or re-inforcement for proper intallation of hardware shown.

Knob/Lever holes may vary from different trim manufacturers. Please refer to their

- b) Please contact us for double lipped template if needed.
- c) See spec sheets for additional lock details.

templates to confirm dimensions.



Required Holes

Optional Holes

Standard M8700ELR for Wood Door -All Backsets

AMERICAN CRAFTED SINCE 1972

T-ALH.M8700ELR.WD