



Notes:

- ▲ Prep for #8 wood or 8-32 machine screws.

Additional Notes:

- a) **Responsibility:** Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) See Spec.2011PDP/2011PDP-Q for additional information.