



Notes:

- ☒ The flush pull should be located in accordance to the rest of the project 2", 2 1/2", 2 3/4", 3 3/4", 5", 6" (ie if your 2002CPDL/2002Q is a 2 3/4" backset then place your 2002CPDS/CDPS-Q at the 2 3/4" location).
- ☒ The 2002CPDS/CPDS-Q is in line w/ the corresponding 2002CPDL/2002Q in the active door.
- ☒ Prep for #8 wood or 8-32 machine screws
- ☒ If you have flush pulls on both sides of the door, you may simply drill the flush cup thru NOTE: in a few rare situations, the flush pull may be mounted on one side only.

Additional Notes:

- a) **Responsibility** : Door and frame manufacturers are responsible for providing adequate construction or re-reinforcement for proper installation of hardware shown.
- b) See catalog / spec sheets for additional details.
- c) See template T-ALH.2002CPDL.2002Q

Standard 2002CPDS/CPDS-Q Quiet
Pocket Door Strike with Integrated Edge
Pull IS2002

T-ALH.2002CPDS.CPDS-Q.IS