



Standard 2002CPDP/2002CPDP-Q Quiet Pocket Door Edge Pull CA2002, CN2002, CO2002

Notes:

- The flush pull should be located in accordance to the rest of the project 2", $2\frac{1}{2}$ ", $2\frac{3}{4}$ ", $3\frac{3}{4}$ ", 5", 6"
- ⚠ Prep for #8 wood or 8-32 machine screws
- If you have flush pulls on both sides of the door, you may simply drill the flush cup thru NOTE: in a few rare situations, the flush pull may be mounted on one side only.

Additional Notes:

- a) Responsibility: Door and frame manufacturers are responsible for providing adequate construction or re-inforcement for proper installation of hardware shown.
- b) See Spec.2002CPDP/2002CPDP-Q and Spec.CA2002/CN2002/CO2002 for additional lock details.

T-ALH.2002CPDP.CPDP-Q.CA.CN.CO